

+3.3V	1	3.3V	2	+5V
SDA	3	SDA	4	+5V_2
SCL	5	SCL	6	GND5
GPIO4	7	GPIO4	8	TXD
GND	9	GND@4	10	RXD
GPIO17	11	GPIO17	12	GPIO18
GPIO27	13	GPIO21	14	GND4
GPIO22	15	GPIO22_27	16	GPIO23
+3.3V_2	17	3.3V@1	18	GPIO24
MOSI	19	SPL_MOSI	20	GND3
MISO	21	SPL_MISO	22	GPIO25
CLK	23	SPL_SCLK	24	CE0
GND2	25	GND@3	26	CE1
		#SPL_CE1		

Sheet: /		
File: working.kicad_sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. kicad-cli 7.0.6-7.0.6-ubuntu22.04.1		Id: 1/1