



Audio Amp

C3: Use 1uF to filter high frequency noise,
or 10uF if lower frequency noise is present



Backlight



Reset