



MAX98357A



Jumpers


Stereo Output Channel Select



Mono Output (Default)
(Left/2 + Right/2)



Connector



Gain Selection

GAIN_SLOT	GAIN
Connect to GND through 100kΩ resistor	+15 dB
Connect to GND	+12 dB
Unconnected (Default)	+9 dB
Connect to VDD	+6 dB
Connect to VDD through 100kΩ resistor	+3 dB

sparkfun

open hardware

Released under the Creative Commons
Attribution Share-Alike 4.0 License
<https://creativecommons.org/licenses/by-sa/4.0/>



TITLE: \${PROJECTNAME}

Design by: Alex Wende

REV:
v10

Date: \${CURRENT_DATE}

Sheet: \${#}/\${##}

Size: User Date:
KiCad E.D.A. eeschema 7.0.6

Rev:
Id: 1/1