

Leave the copper-connected jumper SJ2 as default, use SJ1 to set the I2C address between 0x18 and 0x19. SJ1 is the LSB of the address.

SPI 4-WIRE:

Jumpers SJ2 can be opened to remove 4.7k load on the SPI lines. SJ1 must be open for SPI operation.

[illegible]

Diagram showing the pin connections for headers J1 and J2. Header J1 has pins 1 through 6 connected to GND, SDA, SCL, SA0, CS, and VCC respectively. Header J2 has pins 1 through 6 connected to GND, ADC1, ADC2, ADC3, INT1, and INT2 respectively.



Rev:
Id: 1/1