

OPA documentation version 4.3.0

Andreas Streun, June 29, 2026

1 How to use this document

This document is intended to support program developers, who want to maintain the existing OPA code, or to rewrite it in another environment, or to extract useful parts for integration into other codes. When reading this document, the source code may be examined in parallel, preferably in the Lazarus IDE. In order to see how the code works, OPA may be executed or the tutorial [1] may be consulted. Further information on using OPA is found in the user guide [2] and the underlying physics is outlined in [3].

In this document following styles are used: Pieces of code are shown in **typewriter style**. **GUI** is a graphical user interface, **Frame** is a frame and **Unit** is a standard Pascal unit.

Lazarus knows different kinds of units: A **standard Pascal unit** usually is a **.pas** file containing a library of functions and procedures to be called from one or more GUIs. A **Graphical User Interface** is a form containing buttons, edit fields etc. It is a **.pas** file accompanied by a **.lfm** file defining the layout. A **GUI** declares a class and is the only instance of this class. Usually it is based on class **TForm**. The third kind, called **Frame** is a user-defined GUI-component, usually based on class **TFrame**. Basically it is a macro for GUI components, like a small GUI on its own, which is added like any other component to a parent GUI. So a frame defines a class but not an instance. The parent GUI then will declare instances of this frame.

A GUI or a frame has a list of **actions** corresponding to the event handlers of its components, for example a button to be pressed. The pure Pascal units are passive, they contain a set of public **procedures** which are called from the GUIs. Frames too may contain public **procedures**. Thus in this documentation, action lists are given for the GUIs and frames, and lists of public procedures for the frames and units. All modules may offer public variables, here coloured **x**, **y**, **z** for GUIs, frames, units.

GUI components accept user input and/or launch events. Some have captions, like **Buttons**, others not, like for example a **(plot area)** responding to mouse clicks. The general scheme is **component** → **event handler**. Event handlers may call private procedures of the GUI or public procedures from units as listed in the **uses** section. For the units **unit>procedure** refers to a procedure in a unit and **unit:variable** to a public variable..

Red text gives informations about bugs and other problems and/or suggestions for future improvements. Green text mentions particular features which distinguish OPA from other beam dynamics codes and should be preserved.

Questions may be adresssed to the author at <mailto:psi@andreas-streun.de>.

2 OPA status

Following semantic versioning [4] version 4.063 of OPA was renamed 4.1.0. However, since up to now only the author worked on the code, the distinctions MAJOR, MINOR, PATCH rather refer to the changes as visible to the users than to the API.

In version 4.3.0 OPA includes 48 Pascal units `.pas`, 29 of them are `GUIs` which are accompanied by a Lazarus form `.lfm` (created by the Lazarus IDE), and 19 of them are Pascal `units`. Four of the GUIs are `frames`, i.e. self-defined components embedded in other GUIs. Table 1 lists the units. The column "Size" lists the lines of code as a rough estimate for the complexity of the unit. Furthermore, OPA includes the main program file `opa.lpr` and 10 image files `.ico`, `.bmp` to draw symbols on buttons.

A GUI defines a class, given in table 1 in the column "class". The actual GUI is the one and only instance of this class, i.e. a public variable, usually with the name as the class but without the leading "T". A frame also defines a class but no instance. A standard Pascal unit may also define a class to be instantiated, or it is a library, i.e. a collection of variables and public procedures.

In general GUIs should handle the user interactions only while the Pascal units do all the calculations. This separation was largely realized after major refactoring leading to version 4.3.0, see protocol `changelog.md` for details.

In version 4.2.0 all files had been renamed following this convention for the file name: `opa*` is a first level GUI, i.e. one of the main design programs launched from the main menu. `*lib` is a plain Pascal units which contains a library of physics procedures. `o*` is a second level GUI, which is launched by a first level GUI, for example a start menu. `*frame` is a frame. `com*` are a couple of files which are not OPA-specific and may be used with other codes as well.

Figure 1 shows a block diagram of the GUIs.

Table 1 also serves as a **table of contents** with the first column listing the section numbers: after section 3 on organization of lattice data, section 4 will explain the "backbone" of OPA, which are global data and procedures, the main menu and units for mathematics and graphics which are used by many GUIs. Section 5 contains lattice file handling and the two editors, text-based and "LEGO" block like, and a special editor for longitudinal gradient bends.

Beam physics starts with section 6 on the interactive linear optics design panel and related GUIs and units and continues with section 7 on off-momentum optics and bucket viewer. The non-linear optimization module is explained in section 8, and section 9 covers injection, orbit correction and machine layout.

The three tracking modules with their library are explained in section 10. Finally, magnet currents and a unit for code testing are in section 11.

Sec	Name	SC	Table 1: OPA units class	overview Purpose	Size
4.2	opamenu		TMenuForm	the main menu	903
4.3	globlib	GL		global variables and procedures	1477
4.4	mathlib	ML		mathematical library	2117
4.5	comvgraphlib	VG	Vplot	real number graphics library	1277
4.6	comfigureframe	FF	TFigure	general plot procedure	315
4.7	comcontourlib	CO		contour plot calculation	332
4.8	comauxlib	AX		little helpers	349
5.1	latfilelib	LA		file reading and writing	1774
5.2	opatexteditor		TFormTxtEdt	text editor for lattice file	190
5.3	opaeditor		TFormEdit	interactive lattice editor	231
5.4	oelecreate		TEditElemCreate	creation of an element	144
5.5	oeleedit		TEditElemSet	edit element parameters	861
5.6	osegedit		TEditSegSet	edit segment parameters	451
5.7	varlib	VL		arithmetic evaluator	288
5.8	editorlib	ED		element and segment handling	835
5.9	opalgbedit			longitudinal gradient bend editor	702
5.10	lgbeditlib	LG		longitudinal gradient bend calculations	471
6.1	opalinop		Toptic	linear optics design	1147
6.2	knobframe	KF	TKnob	slider to set element property	421
6.3	ostartmenu		Tstartsel	setting for start parameters	615
6.4	obetenvmag		TsetEnvel	setting for optical functions plot	372
6.5	otunematrix		TtuneMatrix	adjustment of lattice tune	251
6.6	owriteomrk		TWOMK	write optics markers	125
6.7	linoplib	LO		linear beam dynamics calculations	2781
6.8	elemllib	EL		element propagation calculations	2384
6.9	omatching		TMatch	linear optics matching	1461
6.10	omatchscan		TsetMatchScan	parameter scan	119
6.11	opatunediag		TTunePlot	show the tune diagram	634
7.1	opamomentum		Tmomentum	momentum dependent optics	949
7.2	momentumlib	MO		momentum dependent calculations	480
7.3	opabucket		TBucketView	plot RF bucket	632
8.1	opachroma		TChroma	nonlinear optimization	1329
8.2	csexframe	SF	TCSex	controller for nonlinear element	427
8.3	chamframe	HF	TCHam	bar indicator for Hamiltonian mode	420
8.4	chromreslib	CR		little helper to pass results handles	79
8.5	chromelelib	CE		little helper to pass element handles	93
8.6	ochromsvector		TSVectorPlot	show Hamiltonian as complex vector	145
8.7	chromlib	CH		nonlinear dynamics calculations	1813
9.1	opaorbit		TOrbit	orbit correction and injection	1507
9.2	opageometry		TGeometry	geometric machine layout and matching	882
9.3	georlib	GO		orbit, injection and geometry calc.	2250
10.1	opatrackps		TtrackP	phase space tracking	1422
10.2	opatrackda		TtrackDA	dynamic aperture tracking	1666
10.3	opatracktt		TtrackT	Touschek tracking	1660
10.4	tracklib	TL		particle tracking calculations	1502
11.1	opacurrents		TCurrents	magnet currents to machine control	414
11.2	testcode	TC		test of new features	472




Figure 1: Block diagram of the OPA GUIs. **Frames** and **units** are indicated by the short cuts given in column "SC" of table 1 in order to avoid a messy diagram. The **PER** switch indicates that these calls are only available if a periodic solution exists. Dashed arrows correspond to results calculated in one GUI and optionally used by another one.

3 Data structure

This section will give an overview of the data types and variables used globally, i.e. by many or all of the GUIs and units of OPA. This includes the internal representation of the lattice and its elements, global parameters, data calculated by one unit and to be used by another one (the dashed arrows in Fig. 1), status flags and user settings. All these types and variables are defined in `globlib`.

Like other beam dynamics programs OPA works on a lattice file. It contains *elements*, mainly magnets of different type, and *segments*, which are line-ups of elements and segments. One of the segments is selected and expanded to become *the lattice* to work with. Element parameters, e.g. quadrupole strength in the lattice file can be numbers or arithmetic expressions using *variables*, which are part of the lattice file too.

3.1 Variables

A variable contains a value and, optionally, a string representing an arithmetic expression. If the string is `nil` the variable is just a value, otherwise the value is given by evaluation of the expression at runtime. The expression may contain numbers, other variables, basic operators (`+*/`) and an arbitrary number of bracket pairs. The variable name has to start with a character, then numbers and characters may follow. Syntax check is performed. Example: `A = 0.5; XB3S = (1.0-A)/2;`

Variables may be referenced by elements. Two more fields in the variable record control if the variable is used by an element or connected to a knob in design.

3.2 Elements

All elements have length, aperture and a rotation angle (roll) and a type. Furthermore a pointer may give a list of real names for machine control (optionally used for geometry data output, `opageometry` and exporting power supply currents, `opacurrents`).

Depending on type different parameters are defined in tables 2 and 3. Columns "in file" and "in record" refer to the keywords to be set in the lattice text file and the corresponding field in the element record (see `globlib`). An asterisk after a field name like `l*` indicates, that an arithmetic expression is allowed too. The column "unit" refers to the physical unit to be given in the file. Internally all values are SI-units. The column "note" refers to these comments:

- a) a rectangular aperture ($\pm a_x \times \pm a_y$) is assumed for aperture checks in tracking, however an elliptic aperture (half axes a_x, a_y) is assumed for calculation of linear acceptance and for Coulomb lifetime.
- b) positive rotation is counter-clockwise around the beam direction, i.e. 90° rotation of a dipole will deflect the beam upwards.
- c) if keyword is present, the drift is shown as grey solid, not invisible; useful to indicate protected space, e.g. coils of a magnet.

Table 2: Element description, part I

Property	in file	in record	unit	note
All elements				
Name		<code>nam</code>		
Length	L	<code>l*</code>	m	
Apertures	Ax, Ay	<code>ax, ay</code>	mm	a)
Rotation	Rot	<code>rot*</code>	°	b)
Type		<code>cod</code>		
Drift	Drift	<code>cod=cdrif</code>		
(protect)	Block	<code>block</code>	-/-	c)
Quadrupole	Quadrupole	<code>cod=cquad</code>		
Strength	K	<code>kq*</code>	m^{-2}	
Bending magnet	Bending	<code>cod=cbend</code>		
Deflection	T	<code>phi*</code>	°	d)
Edge angles	T1, T2	<code>tin*, tex*</code>	°	
Focusing strength	K	<code>kb*</code>	m^{-2}	
Full gap	Gap	<code>gap</code>	mm	
Edge K1	K1, K1in, K1ex	<code>k1in, k1ex</code>	1	e)
Combined function	Combined	<code>cod=ccomb</code>		f)
Deflection	T	<code>cphi*</code>	°	d)
Edge angles	T1, T2	<code>cerin*, cerex*</code>	°	
Focusing strength	K	<code>ckq*</code>	m^{-2}	
Full gap	Gap	<code>cgap</code>	mm	
Edge K1	K1, K1in, K1ex	<code>ck1in, ck1ex</code>	1	e)
Sextupole strength	M	<code>cms</code>	m^{-3}	g)
(slices)	N	<code>cslice</code>	1	h)
Sextupole	Sextupole	<code>cod=csext</code>		
Sextupole strength	K	<code>ms</code>	m^{-3}	g)i)
(slices)	N	<code>sslice</code>	1	h)
Thin multipole	Multipole	<code>cod=cmpol</code>		
Multipole order	N	<code>nord</code>	1	
Integrated strength	K	<code>bnl</code>	m^{1-n}	g)
length	Lmag	<code>lmpol</code>	m	j)
Undulator	Undulator	<code>cod=cundu</code>		k)
Period length	Lamb	<code>lam</code>	mm	
Peak field	Bmax	<code>bmax</code>	T	
Full gap	Gap	<code>ugap</code>	mm	
Fill factors	F1,2,3	<code>fill1,2,3</code>	1	l)
(half)	Half	<code>halfu</code>	-/-	m)

Table 3: Element description, part II

Property	in file	in record	unit	note
Kicker		cod=ckick		
Multipole order	N	mpol	1	
Peak field offset	X	xoff	mm	n)
Int. strength $\leftrightarrow$ peak kick	K	amp	$m^{1-n} \leftrightarrow$ mrad	
Period	T	tau	ns	o)
Delay	Delay	delay	ns	o)
(slices)	NK	kslice	1	
Septum (not yet implemented)		cod=csept		
Solenoid		cod=csole		
Strength	K	ks	m^{-1}	
Hor. corrector	H-corrector	cod=ccorh		p)
Kick	Dxp	dxp	mrad	
Vert. corrector	V-corrector	cod=ccorv		p)
Kick	Dyp	dyp	mrad	
BPM	Monitor	cod=cmoni		p)
– no parameters to set –				
Girder		cod=cgird		
Type	typ	gtyp	1	q)
Shift	(not implemented)			
Optics marker		cod=comrk		r)
Orbit	OrbitX/Y, OrbitXp/Yp	om^.orb	mm, mrad	
Normal mode betas	BetaX/Y, AlphaX/Y	om^.bet	m, 1	
Dispersion	EtaX/Y, EtaXp/Yp	om^.eta	m, 1	
Coupling matrix	C11, C12, C21, C22	om^.cma	m, 1, m^{-1}	
(screen)	Screen	screen	-/-	
Photon beam	PhotonBeam	cod=cxmrk		s)
Length	XL	xl	m	
Style	Style	nstyle	1	
Marker	Marker	cod=cmark		t)
Rotation	Rotation	cod=crota		t)

- d) Positive deflection is towards the ring center, i.e. in $-x$ -direction and thus will create positive dispersion.
- e) K_1 is the fringe field parameter defined by Brown (see [3]: elements/on-axis). If only K1 is given in the lattice, the same parameters is applied to both edges.
- f) “Bending” and “Combined” are almost identical, except that “Combined” allows a sextupole component. This has historical reasons – **to be merged in one element**.
- g) Multipole definition includes the factorial, i.e. $b_n = \frac{p}{e} \frac{1}{(n-1)!} \frac{dB_y^{(n-1)}}{dx^{n-1}}$
- h) Internally the thick, nonlinear magnet is approximated by N slices of length L/N with a thin multipole of integrated strength $b_n L/N$ at the center.
- i) If sextupole length is given as zero, the strength is integrated strength, unit m^{-2} .
- j) Multipole is always considered thin. If a length **LMAG** (not **L**!) is given, it just reserves spaces of **LMAG/2** on both sides of the single, thin kick.
- k) Helical undulators are not (yet) implemented, only planar undulators are supported.
- l) Undulator fill factors used for fast calculation of radiation integral [3], depending on the field variation over a period. Default is sinusoidal field.
- m) Internally, an undulator is modelled as a series of small dipoles, where the dipoles at entry and exit are attenuated to 1/4 and $-3/4$ field of the inner array dipoles. The keyword **half** suppresses the attenuation at the exit, because sometimes one likes to split the undulator (**U**) to insert a marker (**M**). In this case the full undulator is modeled from two halves as (**U,M,-U**).
- n) For **X=0** the kicker is considered a pure multipole kicker and **K** gives its integrated strength. Non-zero **X** identifies a non-linear kicker with $\sin^{n-1}(2\pi x/X)$ shaped field, and **K** is the maximum kick in mrad at **X**. For a dipole kicker (**N=1**) the field shape is the same for both cases, and **K** is the kick in mrad.
- o) The pulse is assumed to be of half-sine shape with length (= half period) **T**, starting/ending at **Delay** $\pm$ **T/2**. Beam time of flight is counted from the start of the lattice, and the delay has to be adjusted appropriately to kick the beam (the injection module provides a synchronization button).
- p) Correctors with reserved names **CH**, **CV**, and monitors with name **MON** are considered components of the orbit correction system, will be expanded into a series of individual elements and set by the orbit correction procedure in **opaorbit**. In the lattice a series of elements named **CH001**, **CH002** ... will appear, but these are not saved to the file, since they don't have design values but will be set by orbit correction. The same is true for skew quadrupoles with reserved name **CS** and corrector quadrupoles with reserved name **QAC**. **However, OPA does not yet contain a coupling and gradient correction scheme.**
- q) The girder element defines the begin or end of a girder, thus they should appear always in pairs. Type 0 is a loose end, type 1 is a “train link”, i.e. a [virtual] joint to the next girder, type 2,3 are secondary girders sitting on top of primary girders, where the roll of the primary girder is transmitted for type 3, but not for type2 For example the SLS dipoles bridge the girders, with 2 contact points (type 3) on one girder, and 1 contact point (type 2) on the other girder.
- r) OpticsMarkers are useful for building a lattice and matching. They are markers in the

lattice which on request save all 16 transverse optical parameters defining the beam (orbit, beta functions, dispersions and the coupling matrix), and which can be used as starting point for optics calculations or target points for matching. The keyword `screen` indicates an optical screen to be indicated in the geometry layout.

s) Presently photon beam is only used for plotting x-ray beams in the geometry layout, `opageometry`. There are 3 different styles (0,1,2) which can be used for different source types.

t) Simple marker and beam rotation don't have additional parameters.

Furthermore, not listed in the table, an element [family] definition may be connected to a list of [individual] control system names, power supply names and information on polarity and family topology. These data are defined in additional files defined by the keywords `ALLOCATION` and `CALIBRATION` in the lattice file. Unit `latfilelib`, reads and assigns these data. Unit `opacurrents` exports these data including calculated currents and more to the control system, and unit `opageometry` exports list of real names and geo data.

However, for correctors (dipoles and monitors, skew and regular quads) with reserved names in the lattice file, the name list is used to generate individual corrector names to adress them in orbit correction, unit `opaorbit`.

3.3 Segments and Lattice

A segment is a mixed line-up of elements and segments referenced by name. Segments are unpacked recursively to build the lattice. The lattice is a series of element names with additional information how the elements are installed: most important is the orientation of the elements. Unlike several other codes OPA handles correctly nested inversions of segments to obtain the correct orientation of the element in the lattice. This is relevant for bending magnets with unequal edge properties.

Additional information contains allocation of elements on girders and misalignments. Using girders is optional and not required for optics design. Girders are used in orbit correction, `opaorbit`, and also shown in the geometry plot, `opageometry`.

3.4 Global parameters, status flags and intermediate results

There is a couple of global variables used by many units, for example the beam energy or the size of the lattice.

Status flags keep track of the calculation progress, e.g. if the lattice has been built already, or if special lattice features are present, e.g. if there are active kickers. Depending on the status the different GUIs are enabled, for example non-linear optimization is only possible if a periodic solution exists.

Intermediate results are stored for internal communication between the OPA GUIs, see the dashed arrows in Fig. 1. These include

- tunes and chromaticities and two 2×2 matrices for moving the working point using all quadrupoles as calculated by `otunematrix` and shifting the chromaticities using two sextupole families as calculated by `opachroma`.
- Analytical results for amplitude dependent tune shifts and chromaticities calculated by `opachroma` are used by `opamomentum` and `opatrackps` for comparison.
- Momentum compaction up to fifth order calculated by `opamomentum` is used by `opabucket` for RF bucket calculation.
- RF voltage up to fifth order and RF wavelength as entered into the `opabucket` GUI, and bunch length and momentum acceptance calculated from the RF bucket are used by `opatracktt` for Touschek lifetime calculation.

3.5 User settings

For convenience OPA writes and reads user settings to/from files.

In the OPA program folder, are two files, `opa4_path.ini` and `opa4_glob.ini` which contain a list of last used lattice files and global settings (presently only the level how much diagnostics output is sent to an optional terminal window). *It's a bad solution to have these files in the OPA program folder, because OPA needs write permission to this folder. A better solution should be found.*

In each working folder containing lattice files is a file `opa4_set.ini`, which is read at start or when switching the working folder, and written on exit or leaving the working folder. If the `.ini` file does not exist it is created and filled with default values. Presently (version 4.3.0) 291 user settings are remembered, for example target values for matching or size of a GUI.

4 Main programs and general use

4.1 Main program

`opa.lpr`

The main program file which allocates the units as described below and creates some of the forms. It is created more or less automatically by the Lazarus IDE.

4.2 Menu

`opamenu`

The main GUI for reading and writing files and to launch the other GUIs. It includes message (log) and status windows. It is always open in the background. Closing it exits OPA.

Uses: `globlib`, `opaeditor`, `opatexteditor`, `editorlib`, `latfilelib`, `opalinop`, `opatunediag`, `opamomentum`, `opachroma`, `opatrackps`, `opatrackda`, `opatracktt`, `opaorbit`, `opageometry`, `opalgbedit`, `opabucket`, `opacurrents`, `testcode`

Actions

`FormCreate` called at start creates the GUI and fills the menu items with data: the list of last used files is established and the status labels are set. Then handles to most components are passed to `globlib` to make them available to all GUIs, in order to send messages to the log window, update the status in the status window and enable or disable options depending on the result of calculations. Note, that the initialization of `globlib` is executed first to provide the required information.

File Menu

New → `fi_new` delete all data to start new lattice from scratch.

Open... → `fi_open` read OPA lattice file or try to read a lattice file from Tracy2, Tracy3, MAD-X, elegant or BMAD. The file name is displayed as "active file".

Last Used ► → `fi_last` select file from list of last used files

Save, Save as... → `fi_[save,svas]` save OPA lattice file with old or new name.

Export to ► → `ex_[tracy2,tracy,madx,elegant,bmad,opanovar]` save as file for other programs. Last option expands all arithmetic expressions in lattice and saves as OPA file.

Exit → `fi_exit` save all settings from session and exit OPA (just closing the GUI will exit OPA without saving settings).

Edit Menu

Text Editor → `ed_text` launch lattice file text editor `opatexteditor`.

OPA Editor → `ed_oped` launch interactive "LEGO block" editor `opaeditor`.

Design Menu

Linear Optics → `ds_opti` launch interactive linear design `opalinop`.

Off-momentum Optics → `ds_dppo` launch momentum dependent optics `opamomentum`

Non-linear Dynamics → `ds_sext` launch non-linear optimizer `opachroma`

Orbit Correction → `ds_orbc` launch orbit & injection panel `opaorbit`

Injection Bumps → `ds_injc` launch orbit & injection panel `opaorbit`

RF opabucket Viewer → `ds_rfbu` launch RF bucket visualization `opabucket`

Geometry Layout → `ds_geo` launch geometry layout and matching `opageometry`

LGB Optimizer → `ds_lgbo` launch editor for longitudinal gradient bends `opalgbedit`

Tracking Menu

Phase Sapce → `tr_phsp` launch phase space tracking `opatrackps`

Dynamic Aperture → `tr_dyna` launch dynamic aperture tracking `opatrackda`

Touschek Lifetime → `tr_ttau` launch Touschek lifetime tracking `opatracktt`

Extra Menu

Output ► → `tm_di` select the amount of output provided in the log window.

The implementation is incomplete and inconsistent: some output goes to the log window, some to a terminal console (only visible if it is open) and some to a file `diagopa.txt`, which is created (but never closed...).

Magnet Currents → `tm_cur` launch panel to calculate magnet currents `opacurrents`

The other menu items in this group are temporary tests calling procedures from unit `testcode` and not relevant to be documented here.

(Segment name) → `ComboSeg` is a drop-down list of the available segments. The one selected is expanded to become the lattice, calling `editorlib>MakeLattice`.

Show lattice expansion → `butlatsh` displays the expanded lattice in the log window.

Print → `ButLogPrt` prints the content of the log file to `LogPrint.txt` in the working directory.

Clear → `ButLogClr` clears the log window.

4.3 Global data

globlib

This unit is OPAs database containing definitions of global constants and types and declaration of global variables as described in sec. 3. The initialization part is executed when OPA starts and sets environment variables and default values. The unit further contains a couple of public procedures for managing status and user settings.

Uses: `mathlib`, `comauxlib`

Public constants, types and variables

Constants include general settings, physical constants, maximum array sizes, color definitions, name strings and values of flags later to be referenced by name.

`Variable.type` for defining variables is a record including a name, a value and a string containing an arithmetic expression, and the global array named `Variable` stores the variables.

`ElementType` is a case-record for defining element parameters as listed in tables 2 and 3: column `in record` lists the fields in the type declaration. The asterisk indicates that a field of same name with suffix `_exp` exists (for example `l*` means `l_exp`), which may contains an arithmetic expression as string (in order to make use of variables).

`OmarkType` defines a set of optics data as property of the element type "optics marker".

`ElemArr` type is an array of `ElementType`. The global variables `Elem` and `Ella` are of type `ElemArr` and store all elements, resp. the subset of elements currently used in the active lattice. The elements in `Elem` are read from the lattice file and manipulated in the editors, while the elements in `Ella` are modified in the various GUIs. After terminating a design calculation the user is asked to save or cancel the changes, which causes the `Ella`-data to be copied back to the `Elem` array or not.

Furthermore, not listed in the table, the element record contains a field `nl` of type `NameListType` which is a linked containing real element names, power supply names and information on polarity and family topology. `calibrationType` is a record to optionally store the magnet calibration for calculation of currents in `opacurrents`.

`Segment_type` is a linked list for defining segments. The record contains a name and two pointers to the first and last entry. These pointers are of type `AbstractElement_type`, which contains the name of the element or segment, the kind, i.e. if it is an element *or* a segment, a flag to tell if the entry is inverted, a number how often to repeat the entry, and two pointers to the previous and next element. The global array `Segm` of `Segment_type` keeps the segments.

`LatticeType` is a lattice entry, and the global variable `Lattice` is an array of these. The record contains the name and index of the element in the lattice and its orientation (i.e. if it is inverted or not, important for bends with unequal edges). Further it includes the index of a *girder* the element sits on, and five real numbers for misalignment and attenuation factors. Two boolean flags tell if the element is coupling and if misalignments were set to speed up calculations later.

Variable `Glob` of type `GlobType` contains parameters which are used by most units, like the beam energy, the sizes of lattice and element arrays, the optics parameters at the begin and end of the current lattice and more.

Variable `Beam` of type `BeamParType` contains calculated beam parameters like emittances, tunes etc. However, units making use of beam parameters usually recalculate the lattice at start to make sure that the parameter settings are correct and consistent.

`OpValType` is an extended set of optics data used for propagation in `elemlib`.

`CurveType` is a point in an optical functions curve including a pointer to the next point.

`CurvePlotType` defines a curve by a pointer to its initial point.

`MainButtonHandles` provides global control of the various options in `opamenu` to enable or disable them based on the status flags.

Variable `Status` of type `StatusType` contains boolean flags to keep track of the calculation and design progress. Furthermore, the array `StatusLabels` of type `TLabel` gives status information in the main menu `opamenu`. Several constants named `Status...` control the appearance.

Variable `SnapSave` of type `SnapSaveType` keeps intermediate results. Originally it was used at SLS to export data to an EPICS `.snap` file for machine control by `opacurrents`, that's why it is named "snap", but later it was extended to transfer internally calculation results as shown in Fig. 1 (dashed arrows). Furthermore the record stores some data for synchrotron radiation source points (type `XB.SnapSaveType`) which once were exported to an camera

application in the SLS control system. On the other hand, dynamic aperture data calculated by `opatrackda` and to be used for fast Touschek tracking in `opatracktt` are not included in the global `SnapSave` variable in `globlib` but located as a couple of variables named `Flo...` in `tracklib`, which is used by these two tracking GUIs.

Arrays `GlobDef` and `Def` keep the user settings. They are of type `DefaultType` which is a record containing a unique name for the setting and its value. The names of recently used files are stored in string array `LastUsedFiles`.

Public procedures

`Initialization` sets global variables to reasonable initial values, sets all status flags to false, and sets default values for the user settings. Then it sets the OPA folder and tries to read the files `opa4_path.ini` which contains a list of last used files, and `opa4_globini` containing global user settings. Finally, it takes the folder from the first entry in the list of last used files to set the working folder and reads the local file `opa4_set.ini` in this folder to restore the user settings. If these files are missing, the default values are used.

`GlobDefWriteFile` and `DefWriteFile` write the user settings back to these files if the session is regularly terminated by `opamenu` → `ExitOPA`.

`AppendCurve`, `ClearCurve` prepare data sets for plotting curves of optical functions.

`AppendChar` builds a linked list of characters for `opatexteditor` (wrong place).

`putkval`, `getkval`, `putSexkval`, `getSexkval` functions are shortcuts to set or get the parameter which is considered the strength of a magnet.

`EllaSave` checks if elements in lattice (`Ella`) have been changed with regard to the original elements (`Elem`) and ask the user if the changes should be saved.

`OPALog` writes a message to the log window in `opamenu`.

`MainButtonEnable` enables or disables the options in `opamenu` depending on the status flags. For example, tracking is only enabled if a periodic solution exists.

`PassMainButtonHandles` and `passErrLogHandle` take handles to the GUI components of `opamenu` to enable other units using `globlib` to enable/disable them.

4.4 Mathematics library

`mathlib`

A library of mathematical functions: definition of types and operations with vectors, matrices and complex numbers. It further contains some special functions, among them the Touschek integral function, and implementations of Powell's minimizer, LU decomposition and Singular Value Decomposition taken from [14], but extended to dynamic array size. OPA does not link external libraries but all algorithms needed are included in the code.

Uses: none

Public constants, types and variables

Types define vectors and matrices for beam dynamics, geometry and for the Powell minimization procedure. The only public variables are the parameters for Powell.

Public procedures

Most procedures are elementary operations on vectors, matrices and complex numbers, or for special functions, and don't need to be explained.

CTouschek and **CTouschek_pol** solve the Touschek lifetime integral, see appendix C.1 in [3] for details. The first procedure solves the integral based on Simpson's rule, the second procedure uses a polynomial approximation for speed-up.

EulerAng calculates rotation angles from a rotation matrix as explained in [5].

LUDEMP and **LUBKSB** perform LU-decomposition and backsubstitution to solve linear systems of equations as described in [14]. This is used in particular for matrix inversion, **MatInv** and **MatDet**. The procedures are set fix to 5 dimensions.

svdcmp and **svbksb** perform singular value decomposition and backsubstitution to solve linear systems of equations as described in [14]. SVD is superior to LUD for non-square and degenerate systems. An packing/unpacking algorithms was added to use the procedures with arbitrary dimension. The procedure is used in orbit correction in **opaorbit** and for setting octupole families in **opachroma**.

Powell is an implementation of Powell's minimizer for steepest gradient search in N dimensions taken from [14]. It is used for sextupole optimization in **opachroma**, for longitudinal gradient optimization in **opalgbedit**, and (test mode only) for non-linear optimization in **opamomentum**.

4.5 Graphics library

comvgraphlib

Class **Vplot** based on **TObject** contains a Lazarus **TCanvas** object. Plot commands for **TCanvas** use integer screen pixel coordinates. **comvgraphlib** wraps these standard plotting commands with procedures of same name but accepting physics coordinates as real numbers. Data are either scaled and forwarded to **TCanvas** or written to an Encapsulated postscript file ***.eps**.

Furthermore procedures for crating nice axes, for drawing circles and ellipses and for grabbing the screen image have been added.

Uses: none

Public constants, types and variables

There are no public variables. A GUI will define one or more variables of class `Vplot`

Public procedures

`Create` accepts a handle to a `TCanvas` object, which is needed to construct a `Vplot` object. Further some initialization is done.

`PS_start` opens an `*.eps` file of name `psfile` supplied by the calling procedure for output and sets the private flag `PS` to `true` to direct the output to the file and not to the screen. A file header is written, defining the `BoundingBox` as the canvas screen size. Then macros for text alignment are defined in postscript language. If opening the file fails, an error message is returned.

`PS_stop` closes the `*.eps` file and sets the flag `PS` to `false`.

`SetRange*`, `SetMargin*` etc set plot ranges and scaling as displayed in Fig.2. The vertical screen coordinate counts downwards whereas the physical coordinates as well as the Postscript coordinates count upwards.

`getpx, getpy` and `PS_getpxr, PS_getpyr` translate physical coordinates x, y into screen, resp. Postscript coordinates (upper/lower line):

$$px = px0 + \frac{pxrange}{xrange}(x - x_{\min}) \quad py = \left\{ \begin{array}{l} py0+ \\ pytotal - py0- \end{array} \right\} \frac{(-pyrange)}{yrange}(y - y_{\min})$$

`AdjustAspectRatio` adjusts the plot ranges such, that the unit is the same horizontal and vertical, i.e. a circle appears as circle not as an ellipse.

`Axis` plots an axis with even numbers as annotations and ranges, also extracting an exponent if needed.

`GetAxisSpace` returns the space required for the axis annotations without drawing the axis in order to adjust the plot range accordingly. It is called first by the calling GUI, in particular by `comfigureframe`.

`Circle` and `Ellipse` plot a circle or a (sheared) ellipse in beam dynamics notation.

`GrabImage` copies the screen canvas to the system clipboard, useful to catch plots for draft notes.

All the other procedures are mainly wrappers for the standard plot commands or shortcuts to draw arrows, symbols etc.

`Stroke` does nothing on the screen but terminates a series of plot commands in Postscript. Curve plotting procedures need to terminate a `LineTo...` loop by calling `stroke`.

Direct EPS export is a convenient function to immediately create high resolution graphics ready for publication in a $\text{\LaTeX}$ document.




Figure 2: `comvgraphlib` coordinates

4.6 Plot area

`configureframe`

This frame contains a paintbox (i.e. a plot area) to be embedded in a GUI and a `Vplot` object using the paintbox canvas. Added functionality includes handles to edit fields in order to translate mouse actions to numbers.

Uses: `comvgraphlib`, `comauxlib`

Public constants, types and variables

`plot` is a variable of class `Vplot` in `comvgraphlib`. It is accessible to the parent GUI for direct plotting.

Public procedures

`assignScreen` creates `Vplot` and passes the paintbox canvas in order to plot on the screen.

`forceMargin*` set fixed margins for the plot and suppresses auto-scaling by subsequent calls to `Init` or `vgraph>Axis`.

`Init` starts the plot. Inputs are the horizontal and vertical ranges, flags where to put axes and the descriptions of the axes, a flag to mark the origin and another flag to adjust the aspect ratio (i.e. increasing the smaller of the two ranges until the units are of same size, see `vgraph>AdjustAspectRatio`).

SetSize to be called from the parent GUI on resizing is used to change the size of this frame. **PassEditHandle*** accepts the handle to a **TEdit** field in order to link it to the mouse position inside this frame.

PassFormHandle accepts a handle to the parent GUI. (?)

GetRange returns the range of a rectangular region in physical coordinates, which has been marked by dragging the mouse inside the plot.

UnfreezeEdit frees the edit fields again, when it had been frozen by an Mouse/up event (see below).

Actions

(plot area) → **pMouseDown**, **pMouseMove**, **pMouseUp** handles mouse events inside the plot area. When edit fields are linked, the physical coordinates of the plot are displayed in the fields while moving the mouse. On releasing the mouse, the edit field freezes, i.e. saves the last data and changes its color. This is used in **opatrackps** to see the particle coordinates corresponding to the cursor position.

When the mouse is dragged, the region between mouse down and up is used to rescale the plot area. This is used to zoom in in **opageometry** – This works in Windows but not in Linux, probably due to different event handling – not yet understood.

(plot area) → **pDb1Click** grabs the plot image to the Clipboard on double-clicking the mouse.

4.7 Contour plot calculation

comcontourlib

This contour plot calculation is taken from [15] with minor adaptations. Given a 2D array of rectangular gridded data it returns an array of contour lines.

Uses: none

Public constants, types and variables

Con... are a set of types to store the data. **ConLinesType** contains points of a straight line belonging to an contour of height index **ih**, and **ConLinesArray** is an array of these.

Public procedures

Conrec is the only procedure, calculating the contours.

4.8 Utilities

comauxlib

This unit is a collection of "little helpers" for formatting numbers and strings, for defining colors etc. Some of this functions may be obsolete meanwhile, since newer versions of Lazarus and Pascal may include corresponding functions. Procedures are short and probably self-explaining. Not all of them are used in OPA (the `com*` files may be used by other programs too).

Uses: none

5 Lattice I/O and Edit

5.1 Lattice files

latfilelib

Lattice data are read from and saved to files called `*.opa`. Reading a file copies its content into a linked list of characters (basically a long string) in `opamenu>ReadFile`.

There is an option to read additional files of magnet calibrations and allocations (i.e. real magnet types and names associated with the element), in order to prepare data for the machine control system.

Files from other beam dynamics programs can be read and written, however, this includes only the basic parameters and may require some manual editing to make these files work. This includes Tracy-2 or -3 files `*.lat`, Elegant files `*.ele`, `*.lte`, MAD files `*.mad` and MAD sequence files `*.seq`.

Uses: `globlib`, `editorlib`, `varlib`, `mathlib`, `comauxlib`

Public procedures

`Latread` evaluates the character list of type `TextBuffer`: comments, enclosed by `{ }` brackets, are skipped. An input line is terminated by a semicolon (`;`), its length is unlimited and it may break over several lines in the lattice file. Input lines are evaluated by searching first for a colon (`:`) which identifies an element or segment, or, if not found, a variable.

A variable input line contains a name, an equal sign (`=`) and a value or an expression. Reserved variables are found searching for the names `TITLE`, `ALLOCATION`, `CALIBRATION` (containing a title of the lattice and the names of optional allocation and calibration files), and by searching in the list of keywords `globkeyw` containing `ENERGY` and other global parameters. Other names not matching these keywords are considered as user-defined variables.

An element or segment input line contains a name, the colon (`:`) and a comma-separated list of tokens.

An element is recognized if the colon is followed by a valid element type name in list `elemkeyw` (which is based on `ElemName` in `globlib`). Then the tokens are expected to contain each a parameter identifier, an equal sign (=) and a value or expression. There are many parameters for the different element types. The element is created and the values are assigned.

For a segment the tokens are names of elements or segments, both are assigned to a linked list of type `AbstractEleType` as defined in `globlib`.

If names of allocation or calibration files were given, these files are read now.

Finally, the lattice is built from the last segment calling `editlib>MakeLattice`.

`LatReadCom` is called after `LatRead` and searches the lattice string for a pair of tokens {`com` and `com`} to save the text between. All other comments contained in the lattice and enclosed in { } brackets only are not saved.

`ReadAllocation` and `ReadCalibration` read additional optional files containing lists of magnet types and real names and the magnet calibrations in order to calculate the magnet currents in `opacurrents`. An example for SLS is found at <https://ados.web.psi.ch/slsdesc/optic/magnets.html>.

The `ElementType` in `globlib` contains a pointer to a linked list of `NameListType`, which contains real names of elements, name of power supply, i.e. control channel, polarity etc. `lteconvert`, `madconvert` and `madseqconvert` try to make Elegant *.lte and MAD *.mad and *.seq files understandable for OPA. They work on the `TextBuffer` string by exchanging keywords and inserting conversion factors without analyzing the lattice itself. This is then done by a subsequent call to `LatRead`. Tracy *.lat and Elegant *.ele files can be digested directly by `LatRead`.

`WriteLattice` accepts a variable `mode` of value 0..5 to write an OPA, Tracy-2, Elegant, MAD-X, BMAD or Tracy-3 file. `mode` 6 writes an OPA-file with all arithmetic expressions expanded into numbers.

Different beam dynamics codes use different units (e.g. degrees or radians) and different definitions of magnet order and strength. Only OPA, Elegant and Tracy-3 handle correctly nested inversions of segments to implement an asymmetric element (e.g. dipole with different entry and exit edge angles) correctly in the lattice. Export to the other programs requires to create and insert inverted segments (prefix I_) for all segments containing asymmetric elements.

All programs mentioned above allow arithmetic expressions instead of plain values for element parameters. However, unlike the others, Elegant uses inverse Polish notation, which is not included here, therefore expressions are expanded, i.e. resolved to values, for Elegant.

Further export of data is straightforward: first variables, then elements, then segments. The complete lattice file is returned as one long string.

Type `TextBuffer` is a linked list of characters and has historical origin. It could be replaced by a long string, which would be much simpler.

5.2 Text Editor

opatexteditor

A simple Notepad-like text editor to edit the lattice file. The content of the edit window is one variable of type `textbuffer`, i.e. the editor "does not know" what the content means. At exit or when a test is requested, `latfilelib>LatRead` is used to analyze the lattice.

Uses: `globlib`, `editorlib`, `latfilelib`

Public procedures

`Init` called from `opamenu` accepts a handle to the drop down list of segments in order to change its content when segments are created or deleted.

`LoadLattice` called from `opamenu` calls `latfilelib>WriteLattice` to write the lattice file into the text window `EdtWin`. Then the text window is copied into a text buffer to save its content.

Actions

(text window) → `disableOKBut` disables the **OK** button when text is changed. No other action is done on text input.

Test → `filetest` performs a test of the input by calling `latfilelib>LatRead`. Before, the input is copied into a buffer, then, by calling `globlib>PassErrLogHandle`, the output from `LatRead` is redirected from the `opamenu` main log window to the local error log window `myerrlog`, because the main GUI may be covered by the text editor GUI. If the test is successful, the **OK** button is enabled. Then the handle for output is set back to the main GUI.

OK → `fileget` reads the lattice in the same way, now knowing that the input is a valid lattice, and exits. At Exit, the segment drop down list in the main GUI is set to the last segment, from which the lattice was built by `latfilelib>LatRead`.

Cancel → `fileRestore` ignores the text window, reads the lattice from the buffer as saved at `Init` and exits.

Nowadays better text editors may be available, which include colored mark-up, auto-complete options and real time checks.

5.3 Interactive Editor

opaeditor

The "OPA Editor" allows to create elements and compose a lattice without knowing element type names and lattice file syntax. It is more suitable for beginners, while the text editor may be more convenient for experienced users.

The GUI displays two lists, one for variables and elements, the other one for segments. In addition some global parameters like beam energy and default magnet aperture may be set.

Uses: `globlib`, `editorlib`, `varlib`, `oelecreate`, `oeleedit`, `osegedit`, `editorlib`, `comauxlib`

Public procedures

`Init` called from `opamenu` accepts a handle to the drop down list of segments in order to change its content when segments are created or deleted. `Init` is also called internally to update the list contents.

Actions

(Element list) → `ListBoxEClick`: if the first line of the list is clicked, the object `EditElemCreate` of class `oelecreate` is initialized by passing handles to this list and to the `osegedit` object for editing segments. If another line of the list is clicked then object `EditElemSet` of class `oeleedit` is initialized by calling two different procedures depending on if the clicked item represents a variable or an element, and a handle to this list is passed.

(Segment List) → `ListBoxSClick` initializes object `EditSegSet` of class `osegedit` by passing a handle to this list.

Beam energy → `EditGloEKeyPress`, (aperture fields) → `EditA*KeyPress`, **Magnet pole radius** → `EdrrefKeyPress` are edit fields to accept values for beam energy, for element default apertures, and for default magnet pole inscribed radius.

(Comment window) (no event) text window `MemCom` accepts a comment, which will be saved in the lattice file between the `{com...com}` tokens.

Invert all dipole polarities → `ButDipInv` inverts all dipole polarities.

Expand undulators → `ButExpUndClick` expands an undulator into a series of dipoles and drift spaces creating the elements and re-defining the undulator as segment. Usually undulator is a basic element, and the series of dipoles and drifts is executed internally and not visible to the user.

Set all apertures → `ButAllAperClick` sets all apertures to the values given in the `EditAx`, `EditAy` fields thus overwriting individual element settings.

Set all (not only if larger) (no event) if checkbox `ChkAll` is checked, apertures of all elements are set, otherwise only those which have a larger aperture than the values in the fields.

Invert rotations in inverted segments (no event): If checkbox `ChkGloRi` is ticked or not defines if a beam rotation is inverted (like an asymmetric elements) or not when a segment containing the rotations is inverted. A corresponding flag `glob.rot_inv` is set and saved in the lattice file.

Exit → **ButExit** saves data, updates the segment drop down list in **opamenu** and closes the GUI.

5.4 Element Creator

oelecreate

This small GUI pops up, when **new entry** is clicked in the **opaeditor** elements and variables list. A new element or variable is created after selecting its type and giving it a name. Then the GUI is closed and the **oeleedit** GUI pops up.

Uses: **globlib**, **editorlib**, **oeleedit**, **osegedit**

Public procedures

Init accepts handles to the **opaeditor** elements list and to the segment editor **osegedit**, because if an element is created or subsequently modified by **oeleedit**, the changes should appear in these two GUIs. Then the list of element types is filled with the types defined in **globlib**.

Actions

(Kind) → **ComETypeChange** selects the type of element from the list.

(Name) → **EdENameChange** accepts the name of the element.

Create → **ButCreClick** tests the input, if a type was defined, if the new entry is a variable or an element, and adds it to the corresponding arrays. Then the GUI closes itself and launches **oeleedit** using one of the two initialization procedures for variables and elements. If it is an element, in case the segment editor **osegedit** is open, it is updated.

Cancel → **ButCanClick** closes the GUI doing nothing.

Bug: there is no check for duplicate entries, should be added.

5.5 Element Editor

oeleedit

Main component of the GUI is a table to edit all parameters of an element or a variable. Some fields may contain algebraic expressions to calculate parameters from variables. This procedure is called in four different ways, for elements and for variables, and from editor or from optics design. For (iron dominated) magnets, a possible pole-profile is plotted.

Uses: **globlib**, **editorlib**, **varlib**, **linoplib**, **comfigureframe**, **comauxlib**

Public procedures

`InitE`, `InitEVar`, `InitO`, `InitOVar` are four different initialization procedures, for elements and variables, and for calling from the interactive editor `opaeditor` or from the linear optics design `opalinop`. In edit mode, a handle to the element list in `opamenu` is passed, the element index is taken from the list, and the element to be edited is taken from the original element array `Elem`. In optics mode, the index is given explicitly and addresses the `Ella` subset of elements in the lattice, and a handle to the plot window of `opalinop` is passed to enable an update of the plot when the element is changed. For variables there is only one array `Variable` (The arrays are defined in `globlib`).

Then two private procedures are called, which are common for edit and optics mode, to fill the table with data of the element or variable. For elements several lines are filled depending on the type of element, for variables it is only one line. Some element properties and variables may have a value *and* an arithmetic expression (like "A+B"), which is a string for variables and a pointer for elements. If the string is empty or the pointer is `nil`, the value is taken in edit mode. In optics mode, the calculated value from the expression is shown too ("2.5 = A+B") for elements. For variables the expression is shown in both modes.

If the element is a quadrupole or a bending magnet, the GUI is extended by a plot area of type `comfigureframe` to show its pole profile.

`getJelem` just returns the index of the selected element in order to enable `opalinop` to kill this GUI if the user assigns the element to a knob.

Actions

`Done` → `butOKClick` and `Apply` → `butApplyClick` both read the table and update the element. The `Apply` button is only enabled in optics mode and does not close the GUI in order to view how the change affects the optics.

The private procedure `SetElem` for updating the element performs several steps: In edit mode, it reads the name of the element, checks if it already exists, and, if not, if this element is used in segments, and asks, if all these entries should be renamed too. Then, in both modes, the table is read and the values are assigned to the element depending on its type. This includes conversion from convenient input units to internal SI-units. The validity of data is checked, i.e. if values are valid numbers, and if expressions can be executed without error. If everything is ok, then, in edit mode, data are written to the selected element in the `Elem` array and updated in the elements list of the calling `opamenu` GUI. In optics mode, the element in the `Ella` array is updated, the optics is recalculated calling `linoplib>OpticReCalc`, and the plot in the calling `opalinop` GUI is updated by sending it a `repaint` event.

For variables, the private procedure `SetVar` performs similar actions: In edit mode it reads the name, checks if it already exists, and, if not, if this variable is used in any expression, and asks if all these entries should be renamed too. Then in both modes, its expression is read from the table. (If the expression can be converted into a valid number, this value is assigned and the expression set to an empty string to identify a primary variable, which is a pure number.) Then, depending on the mode, the `opamenu` list is updated or the `opalinop` plot is updated.

Cancel → `butCancelClick` does nothing but closing the GUI.

(Parameter table) → `TabDrawCell` checks if input is a valid number and marks it red in case of error. This is not done in edit mode, since input may be an expression. In optics mode, expressions as input are not editable.

`ppaint` reacts on repaint events for the form and plots the magnet profile, it is activated at initialization.

5.6 Segment Editor

osegedit

The GUI displays an editable string grid with names of elements and segments, which are marked in color depending on its kind and type.

Uses: `globlib`, `editorlib`, `comauxlib`

Public procedures

`Init` passes a handle to the segment list in `opaeditor` and loads the abstract element sequence of the segment, which was clicked in the list, into the string grid. If entries contain an inversion flag or a multiplication factors, this is written to the grid cell too. The segment name is written to the (Modify segment) name field at top, and its periodicity (replication factor) to the (periodicity) field at bottom. If the first line of the segment list was clicked, a new segment is to be created and grid and name edit field stay empty.

Actions

(Grid) → `drawCell` analyzes the content of the cell and assigns a color code for element type, segment or unknown using private procedure `ElemCol.C`.

(Grid) → `gridKeyDown` reacts to pressing the CTRL+INSERT or CTRL+DELETE keys on the keyboard by inserting or deleting a grid cell, and shifting up or down the higher cells using private procedure `ShiftCells`.

(Modify segment) → `EditSegNameChange`: If the name of the segment was changed, the button to create a new segment is enabled.

`update` → `butokClick` and `create` → `butcreClick` call private procedure `SaveSeg` to read the grid cells and edit fields, and to perform several checks before creating or updating the segment:

If the grid is empty and the segment is not used by any other segment, then the segment is deleted, otherwise an error message is sent.

If the name is invalid or if the name already exists, or if the segment contains unknown names, error messages are sent.

If tests were successful, in case of `(create)` a new segment is appended to the list, in case of `(update)` the existing segment is deleted first by disposing all its abstract element pointers in `editorlib>ClearSeg`.

If an existing segment was renamed, the entry is updated in all others segments. Then, the new segment sequence is saved as linked list of abstract elements by `editorlib>AppendAE`. If the segment was deleted, it is removed from the global `Segm` array and from the `opaeditor` segment list, else the list is updated. Finally the exit procedure destroys the GUI.

`delete` → `butdelClick` sets all grid cells to empty strings and performs the delete procedures for an empty segment as described above, and exits.

`cancel` → `butcanClick` does nothing but exit.

5.7 Arithmetic evaluator

`varlib`

Evaluation of arithmetic expressions in variables or elements uses an arithmetic evaluator, which was taken from [16] and slightly modified. Evaluation is called recursively since variables may be nested. Only basic operators (`+` `-` `*` `/`) are supported. An arbitrary number of bracket pairs is allowed.

Uses: `globlib`

Public constants, types and variables

There are no public variables.

Public procedures

`Eval_Exp` accepts a string expression and returns the result of the evaluation and a flag to tell if an error occurred.

`Get_Eval_exp_errmess` returns the error message.

5.8 Editor functions

`editorlib`

Uses: `globlib`, `mathlib`, `comauxlib`

Public procedures

`FillComboSeg` fills the list of last used files in `opamenu`.

`MakeLattice` builds the lattice from elements and segments. Since a segment itself contains elements and segments, the internal procedure `SegLat` is called recursively to unpack the data. The elements, which are used in the lattice are copied from the `Elem` to the `Ella` array, and correctors and monitors with generic names `CH,CV,MON` are expanded into separate instances named `CH001,CH002...` to address them individually in orbit correction in unit `opaorbit`. Finally status flags are set.

`IniElem` sets default values for new elements.

`AppendAE`, `ClearSeg`, `NAESeg` are procedures to handle segments, which are series of pointers to elements or other segments.

5.9 Longitudinal gradient bend editor

`opalgbedit`

This GUI is used to interactively optimize the field profile of a longitudinal gradient bend (LGB) in order to minimize quantum excitation, i.e. the I_5 radiation integral. Input fields accept the magnet type, i.e. end bend (dispersion suppressor) or center bend (symmetric cell), its length and peak field and the number of slices to model the magnet as a series of rectangular dipoles. A Powell minimizer is employed to adjust the magnetic field in the slices and the initial parameters (beta function and alpha function for end bend, resp. dispersion for center bend). Various plots demonstrate the results in comparison to a homogeneous bend. The LGB thus established is inserted into the element and segment arrays as an optics marker followed by a series of rectangular dipoles.

Although this GUI is well elaborated its practical use turned out to be limited, since the ideal LGB solution usually is compromised by constraints from optics and magnet design. Actually, deviations from the ideal field shape don't affect the emittance very much, and a simple low-high-low field "sandwich" magnet often is good enough. Therefore this GUI is considered as "nice to have", and detailed documentation of the `opalgbedit` and `lgbeditlib` units is postponed until the usefulness for design or education becomes more clear.

Uses: `globlib`, `mathlib`, `comfigureframe`, `comauxlib`

5.10 LGB calculations

`lgbeditlib`

Physics procedures for LGB optimization and plotting of results.

Uses: `globlib`, `editorlib`, `varlib`, `comfigureframe`, `comauxlib`

6 Linear Optics

6.1 Linear optics design

opalnop

This is the main GUI for linear optics development. It contains a plot window to show optical functions along the lattice, a table to display beam parameter results, a couple of knobs to be assigned to elements and several buttons for various options and for changing the display.

Unlike all other GUIs, the plot window here is not based on `configureframe`, because it is too complex. All the beam dynamics calculations are done by `linoplib`.

Uses: `knobframe`, `ostartmenu`, `otunematrix`, `owriteomrk`, `obetenvmag`, `omatching`, `linoplib`, `opatunediag`, `oeleedit`, `globlib`, `mathlib`, `comvgraphlib`, `comauxlib`

Public procedures

`Init` is called from `opamenu` passing a handle to a tune diagram as defined in `opatunediag`, which is further passed to `linoplib`. A `Vplot` object as defined in `comvgraphlib` is created, the corresponding variable for the plot window named `vp`, however, is defined in `linoplib`, where the calculations take place. A handle to the parameter table `tab` is also passed to `linoplib`. Then some initial values are set for various data.

If the lattice contains variables, copies of their values are saved, and all elements containing expressions are evaluated to check if the variables are used or not in the lattice. For each variable in use, a label is created underneath the plot window. If it is a primary variable (i.e. a number), which can be edited, the label is yellow, if it is a dependant variable (i.e. an expression) the label is pale yellow.

Finally the GUI is resized based on saved user settings. This causes a repaint event of the plot area:

Actions

(GUI resize) → `FormResize` reacts to a resize of the GUI by the user or by the `Init` procedure. The GUI is resized by reserving space for buttons etc. and adjusting plot area, parameter table and labels for the variables to left over space. Then as many knobs as fit into the GUI are created. these knobs of class `TKnob` are defined in `knobframe`. Since a knob may affect the values of other knobs (in case it will be assigned to a variable), each knob receives handles to all other knob calling public procedure `BrotherHandles` of `knobframe`. If the GUI was shrunk, knobs which don't fit in anymore are freed (i.e. destroyed). Finally, the sizes of all components of the GUI are calculated and set.

(plot area) → `pwpaint` is not activated by the user but by the system if the `paintbox` of the plot area receives a generic `repaint` event. This is also done by `opamenu` after calling `Init`. The event calls the private procedure `MakePlot`, which performs these actions:

The plot is initialized, i.e. plotting axes etc. The abscissa is always the longitudinal coordinate along the lattice. Regions representing magnets in the lattice are calculated, plotted and saved to later enable reaction on mouse operations.

If `MakePlot` is called for the first time, the start GUI `ostartmenu` is launched in front of this GUI and will start the first calculation calling `linoplib>OpticCalc`. Finally the resulting optical functions are plotted.

This way to launch the start menu is a bit awkward, there may be a better solution.

`(plot area)` → `pwMouseMove` shows the name of an element when hovering over.

`(plot area)` → `pwMouseDown`, `pwMouseUp` drag an element to a knob, if the left mouse button was pressed inside an element region and released inside a knob region. If an element editor `oeleedit` is open for this element, it is killed. If the element is already connected to another knob, an error message is displayed.

If the element is double-clicked, the element editor `oeleedit` is opened in optics mode, and if there was a connection to a knob, it is released.

If the right mouse button is pressed, the optical function values at this location are shown in the lower part of the table `tab`.

`(variable labels)` → `varbutMouseDown`, `varbutMouseUp` perform the corresponding actions to a variable, if the mouse is pressed inside the region of a yellow variable label and released inside a knob region.

Start → `butStarClick` launches the start GUI `ostartmenu` again, to change initial parameters of the calculation.

PlotMode → `butenvlClick` launches the GUI `obetenvmag` to select plot of beta functions, envelopes or magnetic fields, and to set some plot parameters.

TuneMatrix → `buttuneClick` launches the GUI `otunematrix` to smoothly adjust the lattice tune within a small range by changing all quadrupoles.

Matching → `butmatClick` launches the GUI `omatching` for automatic matching of optical functions to target values by changing selected knobs (i.e. magnet strengths). Since some magnets may be connected to knobs, a handle to all knobs is passed that the matching program may set them to new values.

Write OMK → `butwomkClick` launches a small GUI `owriteomrk` to select the optics markers to overwrite with the current optics data. (An optics marker is an element to store local optics data, which may be used as a starting point for forward/backward optics calculations.)

linear → `butnlinClick` toggles between linear and non-linear calculation by setting the flag `UseSext`, and performs the calculation. The caption of the button is changed to **nonlinear** in non-linear mode. This option has only an effect on off-axis beams.

Kicker OFF → `butkickClick` toggles between kickers on and off by setting the flag `UsePulsed`, and performs the calculation. The caption of the button is changed to

Kicker ON if kickers are on.

->txt → `butdataClick` writes four text files to the working folder, which are named (opa file name)_data, _beta, _mag, _rad.txt. They contain the equilibrium beam parameters,

the beta functions along the lattice, the magnet field data and another output of beta functions for radiation calculations.

->EPS → **butepsClick** exports the plot to an encapsulated postscript file in the workig folder, which is named (opa file name).betas, _envel, _magfd.eps depending if betas, envelopes or magnetic fields are shown. The procedure **PS_start** and **PS_stop** are called to switch on and off the postscript mode in **comvgraphlib**.

Exit → **butexitClick** calls **globlib>EllaSave** to check for changes of element parameters and to ask the user to save the changes. Then user settings are saved and the GUI is closed.

(GUI close) → **FormClose** closes the GUI without saving anything.

<-> → **buzoominClick** zooms into the plot. The six other similar buttons perform similar actions like zoom out, shift left etc.

Internally, elements are subdivided in slices of a maximum length corresponding to one pixel on the screen, so a mini-beta-focus or the dispersion oscillation inside an undular may be resolved!

^B(x) → **buyupClick** magnifies vertically the plot of betafunctions or the horizontal envelope, if in envelope mode. In magnetic field plot mode, it has no effect. The four other similar buttons are to shrink the beta plot and to magnify/shrink the dispersion plot, and to return to automatic scaling.

save → **bucsaveClick** saves the plot data to a second set of curves, which then is plotted in a darker color then the current curves in order to have a visual comparison of the changes. These actions take place in **linoplib**.

clear → **bucclearClick** removes the saved curves.

6.2 Parameter knob

knobframe

This component provides a knob to control an element parameter considered as strength as defined by **OPAgloal>putkval/getkval**. Values may be set by slider or edit field, including range limits and a reset function. As many knobs as fit into the GUIs are dynamically embedded in optics design **opalinop** and orbit correction **opaorbit**. Knob actions trigger calculations and plots. Knobs may stay passive and only display the value, if the parameter is an expression controlled by a variable (which may be connected to another knob). Therefore a knob has to know his fellow knobs and to trigger their updates.

Uses: **globlib**, **mathlib**, **varlib**, **linoplib**, **comauxlib**

Public procedures

Init gives a name using an index provided by the calling GUI (because it numbers the knobs) and initializes the knob as being not yet connected.

SetSize adjusts the knob to the size as given by the calling GUI. There is a minimum and maximum size, within this range the knob component is "elastic". If the range is exceeded, the number of knobs is adjusted by the parent GUI.

Brotherhandles accepts handles to the other knobs in the GUI.

Load and **LoadVar** connect the knob to an element or variable, accepting as input the index of the element or variable and a handle to the plot window of the parent GUI. If the parameter is an expression, the knob stays in passive mode, if it is a number, the knob is active.

Element/variable name is written to the knob and range limits are set to values of same magnitude like the current value. The current value is saved. The element/variable is tagged in order to not connect it twice.

UnLoad removes the element/variable tags and sets back all captions to the initial status of being not connected.

KUpdate sets the knob to a new value by adjusting edit field and slider, and, if exceeded, also the range limits. If the knob was updated manually, private procedure **Action** is called to trigger calculations and plots and, if needed, to update the other knobs. If the knob is updated in this way from another plot, no further action takes place.

If the knobs are components of **opalinop** the *optics* is re-calculated and the plot is updated depending which mode (betas, envelopes, magnetic field) is set. If the knob is component of **opaorbit** the *orbit* is re-calculated and the plot is updated.

If the knob is connected to a variable, changing it may affect other knobs connected to elements or variables using *this* variable in an expression. So all elements' expressions are evaluated to update their values, and, if they are connected to another knob, the **KUpdate** procedure is called for the *other* knob (therefore it's not a circular reference). Of course, this affects only knobs which are in passive mode. **This feature is yet only implemented for optics mode, since in orbit/injection mode no expressions are allowed for corrector magnets and kickers, which are the only elements to be connected. Thus it wasn't needed, however this is an unnecessary restriction.**

getella and **getvar** return the index of the connected element/variable.

Actions

(value field) → **editKKeyPress** calls **KUpdate** to perform actions and adjust the range if the input value exceeds it.

(slider) → **sliderScroll** only performs actions, since the slider cannot exceed the given range.

(min/max fields) → **editmin/maxKeyPress** as well as **><** → **butwidClick** and **<>** → **butnarClick** adjust the range limits by setting minimum/maximum or widening/narrowing the range, all calling private procedure **SetKrange**, which sets the small range fields and the slider parameters.

Reset → **butresClick** resets the knob to the value it had when connecting it and performs the actions.

X → **butfreeClick** disconnects the knob calling **Unload**.

6.3 Start parameters

ostartmenu

This GUI pops up on initialization of the optics module **opalinop** or the orbit/injection module **opaorbit** (see sec.9), or when pressing the **Start** buttons in these modules. The starting conditions for the optics calculation are to be selected, either periodic/symmetric, or forward/backward from start/end of lattice or from one of the optics markers. In case of forward/backward calculation the initial beam parameters may be entered manually, in orbit/injection mode this is only the orbit. In optics mode it includes also the normal mode beta functions, the dispersions and the elements of the coupling matrix.

Uses: **linoplib**, **globlib**, **mathlib**, **comauxlib**

Public procedures

Load accepts a number for the mode of operation, which is 0,1,2 for optics, orbit, injection, and a handle to the parent form, which is either **opalinop** or **opaorbit**. Depending on the mode radio buttons to select periodic/symmetric or forward/backward options are enabled or disabled (per/symm makes no sense in injection mode). Then the lattice is searched for optics marker and corresponding radio buttons are added to the GUI. In optics mode a check box to perform calculations with or without coupling becomes visible and is checked at start if the lattice contains coupling elements. Finally the panels to enter/edit initial beam parameters are enabled/disabled and filled with data calling the private procedure **set_pan_ini**.

Exit is called from the parent GUI (**opalinop** or **opaorbit**) on exit to close this GUI too if it is still open.

Actions

(radio buttons) → **rbutClick** enables the tables to edit initial parameters depending on the selection of periodic/symmetric or forward/backward calculation, calling the private procedure **set_pan_ini**, and enables the buttons to start the calculations.

(periodic solution) → **rbutperChange**, this radio button has an additional event to hide/unhide the **flip** check box to start with flipped solution in case of coupling. (Further a button **pp** appears, which is a temporary test only.)

coupling → **chk_coupChange** hides/unhides the **flip** check box.

dp/p[%]= → **but_dppClick** unhides an edit field to enter a value for momentum offset, and a check box to select if one calculation for $\Delta p/p$ or three calculations for $0, \pm \Delta p/p$ are to be done.

Apply → **butapplyClick** (or **Close** → **butcloClick**) starts the calculation calling private procedure **Go** (and closes this GUI). Before starting the calculation several flags are set

depending on the mode (optics with or without coupling, orbit, injection) and the initial conditions. Afterwards, the plot procedures `linoplib>OpticCalc` or `linoplib>OrbitCalc` are called.

Exit → `butexitClick` closes this GUI and the parent GUI (`opalinop` or `opaorbit`).

(Coupling panel) → `ed_couKeyPress,ed_couExit` check the input into the edit fields of the coupling matrix (rarely used).

6.4 Optics plot mode selection

obetenvmag

This GUI is launched by `opalinop` to select what to show: beta functions (normal mode and/or projected) and dispersions, envelopes with orbit and apertures or magnetic fields. Additional parameters may be set.

Uses: `globlib`, `mathlib`, `comauxlib`

Public procedures

Load sets GUI components (check boxes, fields etc.) for the current plot settings (explained below) and saves initial settings in order to restore them later.

Actions

(Beta, Envelope, Mag. field radio buttons) → `rmodClick` selects one of the three plot modes (Betas, Envelopes, Magnetic fields), unhides the corresponding panel and hides the two other, and enables options depending on flags: one flag is coupling, another flag is for using equilibrium emittances or input emittances. Further the data table on the right side of `opalinop` is configured, and table and plot are updated calling procedures

`linoplib>InitBetaTab,FillBetaTab`. Then the private procedure `MakePlot` sets plot ranges etc. and calls the corresponding plot procedures

`linoplib>PlotBeta,EnvPlot,MagPlot`.

Apply → `butgoClick` also calls for a new plot and updates the data table.

Close → `butcanClick` closes the GUI.

Beta and Dispersion panel:

Fix plot range → `cbxbetamaxClick` enables the fields for max. beta and dispersion if checked. Then, **Apply** will read the edit fields `max. betafunction` and `max.dispersion` and fix the plot range. Otherwise the plot will auto-scale.

normalmode → `chk_betabChange` and **projected** → `chk_betxyChange` select to show normal mode and/or projected beta functions. Without coupling this is the same. (The third option `n.mode one-turn` is only a test.)

Dispersion → `rbu_dspChange`, **det(C)** → `rbu_cdetChange`, **Orbit** → `rbu_orbiChange`
radio buttons select to show the dispersion functions, the determinant of the coupling matrix or the orbit.

Envelopes panel:

use equilibrium / use input values → `rbuClick` radio buttons select to use equilibrium emittances and energy spread or manual input values for envelope calculation. In the equilibrium case, if the lattice is uncoupled, the field **emittance coupling** is enabled, otherwise both emittances from the coupled calculation are used. In the input case, three fields **horizontal emittance**, **vertical emittance** and **rms energy spread** are enabled.

Magnet field panel:

Fix plot range → `chk_bfieldfixClick` enables the fields for min. and max. field if checked. Otherwise the plot will auto-scale. **Apply** will read the **Reference radius** field for pole-tip field calculation, and the two edit fields **min. B[T]** and **max.B[T]** to set the plot range.

6.5 Tune matching

otunematrix

This small GUI launched by `opalinop` calculates a 2×2 sensitivity matrix how the lattice tunes depend on a scaling factor applied to the two groups of all horizontally and all vertically focusing quads. A new tune may be entered manually, and the inverse of the sensitivity matrix is then used to adjust all quads correspondingly. This procedure converges for small tune changes and was also used in SLS control by exporting the sensitivity matrix to EPICS channels from module `opacurrents`. The code is simple and may not need further explanation.

Uses: `linoplib`, `globlib`, `mathlib`, `comauxlib`

6.6 Optics marker update

owriteomrk

Optics markers are markers in the lattice which can store beam data (betas etc.) and may be used as starting points for forward/backward calculations by `ostartmenu`. This GUI establishes a list of all optics markers in the lattice with tick marks and asks if their data should be overwritten with the current optics solution. This may be ambiguous since an optics marker may appear several times in a lattice, so the data refer to the first instance, counting from begin of lattice. The code is simple and may not need further explanation.

Uses: `globlib`, `comauxlib`

6.7 Lattice calculations

linoplib

Linear beam optics includes closed orbit finder, periodic solution for coupled and uncoupled lattices, and radiation integrals. This unit has handles to the plot areas and tables of the optics and orbit/injection GUIs, `opalinop` and `opaorbit`. Plot routines show beta functions and dispersions, or orbit, envelopes and apertures, or magnetic fields. Lattice and local beam parameters are filled into the tables, and several output files can be printed.

Uses: `globlib`, `varlib`, `elemlib`, `opatediag`, `mathlib`, `comvgraphlib`, `comauxlib`

Public constants, types and variables

Several variables used by `opalinop`, `ostartmenu` etc. are defined in the interface section, i.e. as public, for convenience (i.e. lazyness). Most of them are flags to control the flow. Few of them may require an explanation:

`vp` defines a `vgraph` object for the optics GUI `opalinop`, which creates it at start. Later, `linoplib` itself will plot to `vp`. The orbit/injection GUI `opaorbit`, however, defines its own plot areas of class `asfigure` and only gets the data from `linoplib`. The reason for this different solutions was partly historical, partly due to the higher complexity of the `opalinop` plot.

`Opval` is a dynamic 2-dimensional array of `OpvalType` to save optics parameters after each lattice element and for up to three calculations, e.g. for on- and $\pm$ off-momentum.

`Obeam` is a 3-element array to save beam parameters like tunes, emittances etc. for up to three calculations.

Public procedures

`allocOpval` allocates the array of optics values.

`shiftOpval` shifts up the optics values for one solution the next row in the lattice; this is used to save a solution for comparison with a newer one.

`setTabHandle` receives a handle to the table in `opalinop` in order to fill in optics results

`setTunePlotHandle` receives a handle to the tune diagram GUI `opatediag` in order to plot working points.

`setOrbitHandle` receives a handle to the `opaorbit` GUI. Actually it is only needed to send it a `repaint` event, it will then get and plot the data from `linoplib`.

Beam dynamics procedures:

`OptInit` initializes all variables (beta functions, transfer matrix etc.) to be used for the optics calculations.

`Lattel` is the basic procedure for all calculations. It propagates the optical functions through one lattice element. Input is the lattice index and a mode flag telling it what to include in the calculation (integrals, misalignments etc).

`ClosedOrbit` tries to find the fixpoint of the one-turn map, i.e. the closed orbit, by a Newton-Raphson root finder with the *local* transfermatrix as Jacobian. It returns a flag to tell

if it failed or not. For on-momentum calculation without misalignments, it is trivial and the orbit is on-axis. Else down-feeds from non-linearities affect the local transfermatrix and require some iterations, usually only a few since the method converges quadratically.

Periodic tries to find the periodic optics solution, if the closed orbit was found. Depending on coupling it switches to two procedures:

Flatperiodic calculates the periodic solution for uncoupled, i.e. flat lattices without coupling elements, where horizontal and vertical dimension can be calculated independently, and vertical dispersion is always zero. The algorithm is described in Klaus Wille's book [7].

NormalMode calculates the periodic solution for coupled lattices using the Edward-Teng formalism in the version of Sagan and Rubin and implemented as described in [6]. Section 2 of the "inside OPA" guide [3] gives a summary. If successful the procedure returns the normal mode beta functions, which have no physical meaning and exist in an uncoupled system (coordinates a, b) and the coupling matrix, which translates the normal mode system to the real coordinate system (coordinates x, y). It further returns the 4-vector of dispersions and the lattice tunes.

Symmetric calculates the symmetric solution with $\alpha_x = \alpha_y = D'_x = 0$ and works only for uncoupled lattices. It is rarely used and not well tested. The algorithm is also described in [7].

LinOp is a *private* procedure to propagate the beta functions through the lattice and save the values after each element to the **Opval** array by calling procedure **StoVar**. Usually it would start at the begin of the lattice with initial conditions from the periodic solution or entered manually. But it may also start at an optics marker and propagate forward and backward to end and start of lattice. Care is taken to handle inverted elements and derivatives of optical parameter and to sum up integrals correctly. Depending on the input flag **latmode** only the beta functions and dispersions are calculated or chromaticities and radiation integrals are calculated too by passing the flag to the **Lattel** routine, which passes it further to the element propagation routines.

OpticCalc performs the full linear optics calculation by calling **ClosedOrbit**, **Periodic** and **LinOp**. Afterwards, the working point is plotted to the tune diagram (in case of periodic solution only) and the table in **opalino** is filled calling procedures **FillBeamTab** and **FillBetaTab**.

The code is a bit messy due to the different cases it has to handle – periodic/symmetric solution or forward/backward from an optics marker, how many calculations to do, on- or off-momentum.

OrbitCalc is a simplified version of **OpticCalc** used by **opaorbit** for calculation of orbit only. An additional feature is the ability to do several turns which is useful in injection simulation.

MatchValues is a function returning an array of type **globlib:MatchFuncType** containing optics values at the begin and end of the lattice, and optionally, at an intermediate point. It is used by **omatching** for matching optics parameters to target values.

Plot procedures:

SliceCalcN calculates optical functions *inside* an element by subdividing it into slices of a length corresponding to one pixel on the screen. Calculations start at each lattice element,

where optical functions have been before calculated by `Linop` and saved in the `Opval` array. Elements outside the plot window are skipped, if the user zoomed in to a part of the lattice in `opalinop`. The variable `globlib:CurvePlot` stores the start and end point and the number of slices and their length, and the optical functions at the slices are saved in the variable `globlib:Curve`, which is a linked list of pointers for storing optical data. Procedure `elemlib:SlicingN` performs these calculation and generates the curve.

It's a unique feature of OPA to display the optical functions at pixel resolution. This allows to export nice plots ready for publication.

`PlotBeta` displays the beta functions and dispersions. The procedure is lengthy due to the various plot modes as selected in `obetenvmag`, but in principle it is relatively simple: After setting the ranges, the internal procedure `BetaCurveN` is called to generate the curves calling `SliceCalcN` and to plot them. More than one curve for each function is plotted if a previous curve was saved for comparison, or if a $0, \pm\Delta p/p$ calculations was done.

`PlotEnv` displays the envelope functions. Before, they need to be calculated. Therefore several arrays are created to hold all the data for the orbit and the different contributions to the beam size (from dispersion, from coupling). They are calculated either using input or equilibrium emittances and energy spread as selected in `obetenvmag`. Also the apertures are plotted calling procedure `PlotApertures`.

`PlotMag` displays the pole-tip field of the magnets. No slicing is done since the magnets have no longitudinal variation of the fields (longitudinal gradient bends are approximated by a stack of dipoles). In case of the solenoid, the longitudinal field is shown. For combined function magnets only dipole and quadrupole field is used for pole-tip field calculation. The reference radius as set in `obetenvmag` is assumed to be the same for all magnets.

`PlotOrbit` is used by the orbit & injection GUI `opaorbit` only, whereas the other plot procedures are only used by the optics GUI `opalinop`. `opaorbit` does the plotting by itself, so this plot procedure just sends a repaint event to its formhandle.

Output

`FillBeamTab` and `FillBetaTab` write equilibrium beam parameters and beta functions at the location which was right-clicked (see above: `opalinop` action (plot area) $\rightarrow$ `pwMouseDown`) to the table on the right side of `opalinop`. In envelope mode, beam sizes, correlations and beam tilt angles are calculated and displayed.

`Print...` These procedures print various data to files: lattice data in text or html format, beta functions curves, magnet and radiation data.

6.8 Element calculations

elemlib

This unit contains the procedures to propagate optical parameters through the different elements in the lattice. They all receive the variable `mode` telling them what to include in the calculation, by evaluating `elemlib>switch`. Most elements receive the variable `idir` to set forward or reverse orientation of the element (for example important for a dipole with

different edge angles). All other parameters are explained in the user guide [2]. The flags `UseSext`, `UsePulsed` in `globlib` switch on/off non-linearities and kickers. Coupled calculation is selected by the element procedures. Another set of procedures performs the sliced calculations for thick elements to provide data in pixel-resolution for a nice display.

Uses: `globlib`, `mathlib`

Procedures

This section tries to list the procedures in a logical order (not as they appear in the file) for best understanding. Some are public, to be called by `linoplib`, others are private and commented out in the `INTERFACE` section of the file.

Beam propagation

`Propagate` receives the transfermatrix of an element and a flag on coupling to propagate the optical functions from start to end of the element using two procedures:

`MCC_prop` proceeds *with* coupling to propagate the normal mode beta functions and the coupling matrix. In the beginning, on- and off-diagonal 2×2 submatrices are extracted from the 5×5 transfer matrix, and a test is done, if a mode flip will happen. Then follows a longer section to handle a possible mode flip. **This section is partly experimental and needs further elaboration. It does not work correctly with regard to tunes and integrals in all cases.** At the end follows the normal case which works reliably with weak coupling. Phase advances are calculated by procedure `PhaseAdvance` and added to the ring tunes, and the dispersion vector is propagated, which always works.

`MBD_prop` proceeds *without* coupling where the transfer matrix is known to be block-diagonal. Nevertheless, possible coupling in the beam has to be propagated too by transforming the coupling matrix, which may have non-zero elements in this case.

`PropForward` just copies optics parameters after propagation (suffix 2) to parameters before propagation (suffix 1) in order to continue with the next element.

`PhaseAdvance` calculates the block-diagonal normalized normal mode matrix from the local beta functions using the transformation matrix from function `CirMat`, and extracts the phase advances from the traces of the sub-matrices. `getdTune` is a simplified version for a transfer matrix which is known to be block-diagonal.

`GetBeta12` calculates the projections of the normal mode beta functions to the physical beta functions.

`Pathlength` calculates the path length by estimating the second order matrix elements as defined in TRANSPORT (see comment in code for details).

The elements

The `...Matrix` functions return 5×5 transfer matrices of the basic linear elements. Since OPA does not include longitudinal dynamics, there are no rows and columns for phase/time and the 55-element is always 1. The fifth column of the matrix contains the dispersion production vector. Drift space, quadrupole, sector magnet and edge kick have block-diagonal

matrices, i.e. they don't couple. Coupling elements are the explicit rotation and the solenoid. The Bending magnet matrix is a sector matrix sandwiched between edge kicks. The matrix functions are called by the element procedures. OPA knows 17 different elements as listed at the very beginning of `globlib`:

There are no procedures for markers, optics markers and photon beam markers, because they don't act on beam dynamics. There is a placeholder procedure `Monitor` for beam position monitors but it does nothing. The septum element – as seen from the stored beam – is handled as a drift space in beam dynamics.

`DriftSpace`, `Quadrupole` and `Bending` are the standard linear lattice elements. Actually `Bending` switches to `Quadrupole` if the bend angle is zero, and `Quadrupole` switches to `Driftspace` if the gradient is zero. So `Bending` is the most complex procedure and should be explained in some detail. It performs the following steps: at first the magnet is misaligned, if misalignments were requested, then a rotation is applied if the magnet is tilted. Depending on the direction of the magnet, the edge angles are interchanged and the edge kick matrices are calculated. Then the beam (i.e. the optical functions) is propagated through the entry edge because the values at the beginning of the sector are needed to estimate the phase advance inside the sector (procedure `getdtune`) in order to set the right number of points for numerical evaluation of the radiation integrals. Before doing so, the complete bending magnet matrix including entry edge, sector and exit edge is calculated twice, first on-axis (TM0) as needed for the closed orbit finder, then off-axis (TM) to include dispersion downfeeds for the integrals. If radiation integrals or chromaticities are requested, the sector is split in a number of slices, the beam is propagated step-wise, and the integrals are obtained by Simpson's rule (see section 3 in [3] for details, also for the other elements). Finally, the beam is propagated through the complete bending magnet, and rotation and misalignments are undone at exit. `Quadrupole` contains a simplified version of this algorithm, but including radiation integrals too, since there may be off-axis contributions.

`Combined` is a bending magnet which also has a sextupole component. It is modelled as a series of bending magnets with thin sextupole kicks between. Having both `Combined` and `Bending` has historical reasons, and maintaining both is for backward compatibility, but in principle they could be united.

`Undulator` contains a loop over rectangular bends and drift spaces, where the parameters of these sub-elements are set by the procedure `UnduFacs`. For the radiation integrals a simplified algorithm using averages is applied since the bends inside the array are small.

`Solenoid` is a simplified treatment of the solenoid providing beam rotation and focusing in both planes. Note, that the transverse vector potential components of the solenoid are not taken into account, also contributions to chromaticity and radiation are not considered.

`Rotation` is an explicit beam rotation. It's rarely used, because rotated elements like skew quadrupoles are rather set up by passing a rotation angle to the corresponding element procedure. Then the element matrix internally is sandwiched between the rotation and its inverse.

`ThinSextupole` and `Multipole` are thin multipole kicks – basically, a sextupole is just a

multipole of order 3, but the dedicated procedure executes faster. The procedures apply a non-linear kick to the orbit and a transfer matrix to the optics for off-axis gradient downfeed. (For order 2, quadrupole, there is a gradient on-axis too.) Contributions to radiation integrals are usually negligible and therefore not included. The **Multipole** procedure uses explicit expressions up to octupole (order $n = 4$). For higher orders the general complex expression is evaluated (see comment in code). A vertical offset of the beam requires coupled treatment due to skew quad down-feed.

Sextupole is a thick sextupole, internally modelled as a series of drifts and thin sextupole kicks as the most simple second order symplectic integrator. A corresponding procedure for a thick general multipole does not exist yet.

Kicker is a time-dependent thick multipole. Parameters delay and period (of half sine bump) and the time of flight from the start of the lattice define the kick strength applied. Like the thick sextupole, the kicker is subdivided in a series of drifts and thin kicks. The transverse shape of the kick can be selected to be of multipole or sine shape (BESSY type NLK). Note that for the NLK, the kicks are only correct in the midplane ($y = 0$).

HCorr and **VCorr** are correctors, i.e. weak dipoles which just give a kick to the orbit and to the dispersion function without further effect on the beam optics.

Slicing

The **SliceSet** function calculates the number of slices for the optical functions inside an element to be displayed in one-pixel resolution on the screen. The record **globlib:CurvePlot** contains a field **slice** for the length of the slice in physical coordinates, i.e. in meters, calculated by **opalinop>Zoom**. The **SliceSet** function checks if the element is outside, partially inside or completely inside the current plot window, or if the plot window is completely inside the element. It writes start and end position inside the element and the number and length of slices to the **CurvePlot** record and returns **true** if at least a part of the element will be visible in the plot area.

SlicingN receives transfer matrices **msl** for a slice, **mof** for the invisible part of the element left of the plot window, and **min** and **mex** for edge focusing at entry and exit of the element (applies to bends only). Additional matrices **mof0,msl0** without dispersion down-feeds are supplied to show both orbit and dispersion functions correctly. The procedure further receives the optics values at the entry to the element, because these are known from the previous run of **linoplib>Lattel**. Then optical parameters at the slices are calculated using a simplified propagation procedure and the results are appended to the **globlib:Curve** variable for later plotting by **linoplib**. Finally the optics value at the end of the calculation (which may be still inside the element) overwrite the optics values from input.

SkippingN is only needed for undulators, which are modelled as a loop over drifts and bends, and where several of these basic elements may be left of the plot window. The optics values are propagated through these invisible basic elements to get the correct initial values at the first partially visible undulator pole. *In this way it is possible to zoom into an undulator and see the dispersion oscillation!*

The **Slice(Drift,Quad,Sol,Bend)N** procedures call **SliceSet** and calculate the required

transfermatrices for `SlicingN` and `SkippingN`.

`SliceUnduN` loops over bends and drifts of the magnet array if at least a part of the undulator is inside the plot window.

`SextKickN` is a simplified version of `ThinSextupole` to propagate optics values through a sextupole kick.

`SliceSextN` and `SliceCombN` make use of `SextKickN` because they model thick sextupole and combined function magnet as loop over drifts or bends with sextupole kicks between.

6.9 Linar matching

omatching

Matching implements a linear equation solver based on LU decomposition for the linear optics. For historical reasons, it does not use the solver in `mathlib` `>LUDCMP`, `LUBKSB` but the algorithm was explicitly coded in the 1980's by Klaus Wille (procedure `Step`), and is documented in his book [7]. Matching is done from a start point to an end point in the lattice. The lattice tunes and optics functions at an additional intermediate point may be included too. After selecting these options, a list of available knobs is established. Then the user selects the constraints, i.e. the optics parameters at end (and intermediate) point, sets the target values and selects at least the same number of knobs (e.g. quadrupole strength, variable etc.) from the list. The solver proceeds using the square matrix of most sensitive knobs, which is recalculated after each step to take into account non-linearities. If successful, the method converges quadratically, if not it returns messages, what went wrong (procedure `Term`). Reduced step size can be set for slower but more robust convergence. It is possible to run a scan over some range of target values.

There are three panels at the right side of the GUI, one for the knobs, one for the matching process and one for parameter scans. Only one of them is visible at a time.

The algorithm itself with catches for errors as implemented over the years, is quite robust and could be used further in principle. However, nowadays better and well proven solvers may be available, which also include limit ranges for the knobs. Further, the present procedure is restricted to uncoupled lattices and to only one intermediate point besides start and end of matching, which sometimes is a nuisance. The present GUI is well consistent (how options are enabled etc.) but its rigid structure makes extensions cumbersome. It should be re-organized for example using tabs.

Expecting a rewrite of this module in future, only a brief summary of the most important actions will be given here.

Uses: `linoplib`, `knobframe`, `omatchscan`, `globlib`, `comfigureframe`, `comauxlib`

Public procedures

`Load` initializes the GUI. It receives handles to the `PaintBox` plot window and to the array of `knobframe` knobs in `opalinop` in order to be able to set the knobs to new values and to show

the new optical functions after matching. Then it searches for optis markers, which may be used as start, end or intermediate point for matching, and adds them to the `ini/mat/midpoint` pulldown lists. Several user settings are restored from a previous session, since often the same matching scenario is used again.

Actions

starting,matching,intermediate → `(ini,mat,mid)pointChange` call the private procedure `knoblist` to establishes the list of available knobs after selecting the start, end (and optionally intermediate) points for matching. For each knob a named check box is created.

Optics parameter check boxes → `cselClick` and **Knob check boxes** → `knobSelect` build the lists of constraints and knobs and set the **Go** button if there are at least as many knobs as constraints.

incl.bends → `cbxIncBendsClick` includes bending magnets in the knob list, because often they are not used, so the panel is less crowded if they are not shown.

Go → `gobutClick` hides the knob panel `panknobs` and shows the matching panel `panmat` with a grid of knob values. Then the iteration starts until the procedure `Step` returns `true` because it terminated with success or failure, or the user stopped the iteration pressing

Abort → `bustopClick`. The last option requires the Pascal procedure

`Application.ProcessMessages`, which reacts to GUI events, to be called inside the loop. After termination buttons become active to show the result in `opalinop`, to accept the new values, to reset to initial values or to retry the calculation (for example with reduced step size to be entered in the **Fraction [%]** field, in case of bad convergence.)

Show → `butShowClick` actually only hides the `omatching` GUI (which is modal!) to uncover the `opalinop` GUI which is behind and shows the current optical functions anyway.

Accept → `butaccClick` saves the settings and closes `omatching`.

Reset → `butaccresClick` restores the old knob values, recalculates the optics, saves the scenario and closes the GUI.

Retry → `butrtyClick` restores the old knob values and sets up for a new iteration.

Scan → `ScanClick` prepares for a parameter scan, i.e. a series of matching iterations for a range of target values. For this purpose, the scan panel `panfig` becomes visible, the modal GUI `omatchscan` is launched to enter range parameters, and then the matching series are started, the results are saved and plotted eventually. The `<`, `>` buttons under the plot window allow to toggle between displays for the knobs and functions.

6.10 Parameter scan

`omatchscan`

This very simple modal GUI is launched by `omatching` → `ScanClick` that the user may enter the range for a parameter scan. At exit it writes the data to the variable `linoplib:ScanPar`, from where `omatching` takes them to perform the scan.

Uses: `linoplib`, `globlib`, `comauxlib`

6.11 Tune diagram

`opatunediag`

The tune diagram GUI is created at start of OPA already and provides the variable `tuneplot`, which is passed in the initialization procedures of the modules using it: `opalinop` shows the working point, i.e. the tunes of a periodic solution. `opamomentum` shows the variation of tunes with momentum. `opachroma` shows an analytical estimate of the tune footprint. And `opatrackps` shows the amplitude dependent tune variation. In the background always shown is the web of resonance lines.

Uses: `globlib`, `comfigureframe`, `comauxlib`

Public procedures

`Diagram` makes the tune diagram visible if a periodic solution exists. Input is the point in tune space where to center the diagram. The resonance lines inside the visible tune region up to the selected order are calculated by private procedure `getLines` and characterized as regular, skew, non-systematic. The periodicity of the lattice is stored in `globlib:NPer` and determines the selection of systematic resonances.

`AddTunePoint` adds a tune point to the diagram. If the input flag `connect` is `true` the point is connected to the previous point. The inputs `dpp`, `dppmax` are used to show off-momentum points in a color range. Used by `opalinop` and `opamomentum`.

`AddChromLine` adds a line to show the chromaticity, i.e. the variation of tune with momentum, with chromaticities up to third order and the momentum range as input. Used by `opachroma`.

`AddTushPoint` adds points from amplitude dependant tune shift tracking. Input `xmy` controls the color of the points: horizontal, coupled, vertical in blue, purple, red; outside aperture in grey. Used by `opatrackps`.

`Refresh` clears the diagram from points which had been added.

Actions

(On create) → `FormCreate` sets defaults and restores user settings.

(On resize) → `FormResize` adjusts the GUI if the user changes its size.

All other actions control the plot: The buttons (Order) `+` `-` increase/decrease the maximum resonance order. The `nsys` and `skew` check boxes switch on/off non-systematic and skew resonances. The buttons under the plot window are to zoom in/out, to shift the region right/left, up/down and to re-center. `EPS` exports the diagram.

7 Longitudinal optics

OPA does not contain true longitudinal dynamics, i.e. all calculations are for fixed momentum offset, and tracking proceeds only in 4-D, not in 6-D. There are no cavities and no acceleration.

7.1 Momentum dependence

opamomentum

This GUI shows optical functions at lattice start and lattice integrals like tunes, emittance etc. for some momentum range. This functionality is the same like performed in `opalinop/linoplib`: for periodic lattices closed orbit and periodic solution are calculated, then for any lattice, the initial parameters are propagated and the integrals are calculated. The plotted curves of momentum dependent parameters are then fitted by polynomials. In case of pathlength, coefficients are saved internally to be used later in the bucket viewer `opabucket`.

For the particular problem to design a non-linear bunch-compressor for an FEL [10], the module once was extended to set target values for polynomial coefficients and allocate non-linear elements to align the polynomial to the target by means of a Powell minimizer. This feature is never used for synchrotrons and storage rings, where the side-effects of this brute force alignment are devastating with regard to non-linear dynamics. Since this extension is irrelevant, improvised and fragile, it should be removed – however, this requires some disentangling.

Therefore only the first part of the GUI is briefly explained here.

Uses: `momentumlib`, `linoplib`, `opatunediag`, `globlib`, `mathlib`, `comfigureframe`, `comauxlib`

Public procedures

`Start` called from `opamenu` receives a handle to the tune diagram. Then it assigns handles defined in `momentumlib` to some of its GUI components to give `momentumlib` access. Then user settings are restored, and some initialization is done, and the GUI is resized.

Actions

(On create) → `FormCreate` builds the GUI by dynamically creating its components. These include radio button for the 20 different available plots as defined in the header of `momentumlib`. More components, which have the `panmin` panel as parent, are for the minimizer and to be removed.

(On resize) → `FormResize` performs a dynamic resize if the user changes the size of the GUI, distributing evenly the available space.

(On paint) → `FormPaint` calls `momentumlib>MakePlot`

periodic → `chkPerClick` sets the optics mode to periodic. Of course, a periodic solution may not exist for all values in the momentum range. These failed points will be omitted in the plot.

Go → `butGoClick` performs the calculation calling `momentumlib>FullCalc`. It also plots the result for the currently selected plotmode, including calculation and display of the fitted polygon. Polynomial coefficients are listed in table `gfit`.

Fit → `butFitClick` repeats fit and plot with the selected fit parameters.

Units for table → `butfunitClick` toogles between showing the polynomial coefficients in table `gfit` in SI-units or in convenient units as used for the plot annotations.

(Radio buttons) → `rbClick` sets the plot mode according to the clicked radiobutton and repeats fit and plot.

Events not mentioned are either trivial (e.g. check for valid number in edit fields), or they belong to the (working but irrelevant) Powell minimizer, which is started by the **optimize** button.

7.2 Calculations

`momentumlib`

This unit contains the physics and plotting for the `opamomentum` GUI.

Uses: `linoplib`, `opatunediag`, `globlib`, `mathlib`, `comfigureframe`, `comauxlib`

Public constants, types and variables

The header contains parameters for the 20 plot modes: color of plot, number format for table, annotation of radio buttons in `opamomentum` etc. Some plots show two functions, for example horizontal and vertical tune shift. The arrays `ires1,2` control, what to plot. `ires2=-1` suppresses the second curve.

`result` is an array of a 20-element array to store the results over the momentum range. The size of the array depends on the number of momentum values to be calculated.

The `...HANDLE` variables refer to components of the `opamomentum` GUI.

`res_funit` contains factors to switch between SI-units and plot units in the polynomial coefficients table.

All the variables containing "op_" or "kn_" or "Pen" in the name belong to the obsolete minimizer.

Public procedures

`Makeplot` shows the selected results. Valid points are plotted as symbols. The internal procedure `fit_and_plot` performms a polynomial fit of the requested order over the valid

points, shows the fit result as (an) additional line(s) in the plot, and writes the fit coefficients to the table. The internal procedure `plot_qclines` adds the predictions for the chromaticities from the non-linear optimizer `opachroma` if available, and if tunes were selected for plotting.

`FullCalc` contains the complete calculation:

`PreCalc` prepares for the calculation by setting up the momentum values. In case for periodic solution requested, it first checks the on-momentum solution. If successful, the tune diagram `opatuneddiag` is launched and the working point is plotted. If chromaticity data are available from a previous run of `opachroma`, they are also shown in the tune diagram as a line. **BUG: diagram appears but no plot, area stays grey.**

`Calculate` loops over the momentum range, calculates the optics parameters and integrals for each momentum value, and stores the results in the `result` array if valid.

Afterwards `MakePlot` is called.

`PostCalc` finally plots results to the tune diagram if available to show the chromatic tune shift.

Procedures `CalcPenalty`, `ShowPenalty`, `CalcTarg` are obsolete.

7.3 RF bucket viewer

opabucket

The RF bucket is calculated based on up to five orders of momentum compaction and RF harmonics as described in [3]. A contour plot of equipotentials and the separatrix are displayed, and momentum acceptance and the bunch length are estimated.

The coefficients of momentum compaction may be taken over from a previous calculation of momentum dependent optics, `opamomentum`. The estimates for momentum acceptance and bunch length are saved to be used later in Touschek tracking `opatracktt`.

For "playing" with the bucket, the viewer may also be used with manual input for cavity voltages and momentum compaction, even without any lattice. Therefore the option is always enabled in `opamenu`.

Uses: `globlib`, `mathlib`, `comcontourlib`, `comfigureframe`, `comauxlib`

Actions

(On show) → `FormShow` performs all initializations when the GUI becomes visible: private procedure `Layout` is called to arrange the components (although this GUI does not react to resize by user), user settings are loaded and filled into the edit fields. With this settings, the bucket is calculated immediately and shown by calling private `CalcBucket` and `MakePlot`:

`CalcBucket` performs all the calculations as described in [3]. This also includes the call to `comconrect>conrec` to get the equipotential contours, because from these the energy acceptance and bunch length are estimated. However, this requires the central fixpoint to be elliptic (i.e. no overstretched bunches). And bunch length can be estimated only if there is a value for energy spread from a previous optics run.

`MakePlot` just plots the results and writes them to labels in the GUI.

(On paint) → `FormPaint` just calls `MakePlot` again.

`Show bucket` → `butconClick` calls `CalcBucket` and `MakePlot` again.

`EPS` → `buteptsClick` sets mode to postscript export and calls `MakePlot` to write file `(lattice name).bucket.eps`.

`mode` → `butmodClick` toggles between "lattice" and "play" mode, i.e using momentum compaction coefficients from the lattice or from manual input.

`use Lattice` → `butcopyClick` copies the lattice coefficients to the edit fields for manual modification in "play" mode. This knob and the `mode` knob are only visible if an optics calculation had been done before.

`Exit` → `butexClick` saves the user settings and closes the GUI.

8 Non-linear Optimization

The units of this section are linked in a rather complex way as indicated by the `uses` declarations, since the main GUI `opachroma` contains many frames for knobs, `csexframe`, and for results, `chamframe`, which affect each other. This required the two small units `chromreslib`, `chromelelib`, to pass the handles. `csexframe` declares use of `chromreslib`, which declares use of `chamframe`. Vice versa, `chamframe` declares use of `csexframe` in the implementation section, i.e. at runtime, not in the interface section, to avoid a circular reference.

There may be a better way to declare these dependencies.

OPA's non-linear optimizer is a rather useful tool to get a quick optimization of dynamic aperture – or to help in understanding why it can't work. Manually playing with the multipoles may give a "feeling" by visualizing the effect on the Hamiltonian modes and the tune footprint, before the automatic minimizer is started. The code executes fast, since all coefficients to sextupole family strengths and products of two families, are calculated only once at start. Multiple periods are realized by a complex factor derived for this purpose [3].

8.1 Non-linear optimization panel

`opachroma`

The GUI contains a fixed set of first and second order sextupole Hamiltonian modes and a variable set of knobs connected to non-linear multipole families. These are the sextupoles in first place, which have to maintain corrected chromaticities during optimization, and optional octupoles and even decapoles. Also sextupole moments in combined function magnets may be included.

The Hamiltonian modes are scaled by reasonable betatron amplitudes and momentum range to make them comparable. In addition weight factors are set manually. Optimization may be done by hand "to get a feeling", but usually it is done automatically with frequent user

intervention to adjust weights, exclude certain knobs etc. For minimization, the scaled and weighted Hamiltonian modes are summarized to provide a scalar penalty function.

A Powell minimizer is employed to suppress first and second order sextupole terms. Second order terms may also be suppressed by an SVD procedure using the octupole families. Both algorithms are based on [14] and coded in unit `mathlib`. Decapoles may only be used manually for third order chromaticity, which is the only third-order effect included.

Basically, SVD could optimize sextupoles too using the linear system of first order sextupole terms and the linearized (i.e. local tangential) system of second order terms as suggested by Johan Bengtsson and previously implemented in Tracy-2. The mixed approach using Powell and SVD has historical origins but also turned out to perform quite robust.

Chromaticities up to third order are calculated by numeric differentiation, whereas the other Hamiltonian modes are calculated analytically. A real/complex factor is applied to non-resonant/resonant modes to change the periodicity of the structure [3].

Besides frames for Hamiltonian modes and multipoles, the GUI contains several edit fields for amplitudes, ranges, periodicity and minimizer settings, many check boxes to select knobs and Hamiltonian modes to be in- or excluded and several buttons to change settings and to control program flow.

BUG: in the linux version, the frames in the GUI don't update. After touching the GUI (i.e. resize by tiny amount) it works. Not yet understood.

Uses: `chamframe`, `csexframe`, `chromreslib`, `chromelelib`, `chromlib`, `ochromsvector`, `opatunediag`, `globlib`, `mathlib`, `comauxlib`

Public procedures

Start, called by `opamenu` receives a handle to the tune diagram `opatunediag` (to show the prediction of the tune footprint), and then performs many actions:

A fixed number (26) of `chamframe` frames is installed to show the Hamiltonian modes and change their weights. This requires passing to each one handles to the other ones, because changing a weight may result in rescaling all. Handles are passed to `chromreslib` to perform an update of all, if called by a knob `csexframe`. Further handles to GUI components, e.g. labels to show pathlength, are passed to `chromlib`, which contains the physics part. Check boxes are added to select groups of modes to be included in the optimization.

Then the cursor is set to "hourglass" while `chromlib>ChromInit` is called, which may need some time to set-up the matrices which connect the vectors of knobs (first order) and knob products (second order) to the Hamiltonian modes. It also reads user settings, so the next step is to update the GUI with these settings and to use them for a first calculation of the penalty function. The Hamiltonian modes are set to show the results.

As next step, the knobs are installed, one instance of `csexframe` for each family of sextupoles, octupoles, decapoles and combined function magnets. Each sextupole needs handles to the other ones, because if a family is assigned to automatically maintain constant

chromaticity, a change of another family will change its value. Octupole family handles are passed to `chromelelib`, which controls the SVD actions.

Check boxes are added to sextupole families to select them for chromaticity corrections, or to exclude them from optimization. If there are octupoles, check boxes are added to the second order terms to select them for the octupole-SVD, and controls for the octupole-SVD are made visible. Further, range edit fields for octupoles and decapoles are made visible if elements of these kinds are present.

Finally a tune diagram is drawn to show the tune footprint estimate based on the initial calculation.

Actions

("inc row") → `Check(2Q,Qxx,Cr2,Oct)Click` include in or exclude from the calculations the half integer chromatic resonances, amplitude dependent tune shifts (ADTS), nonlinear chromaticities and 2nd order resonant terms, and perform a new calculation.

("O" row) → `CheckOctClick` selects the Hamiltonian mode beside the checkbox for the octupole SVD (only visible if the lattice contains octupoles), sets up the SVD matrices and initializes the filter for weight factors to no cut (threshold 0).

Periods → `edPer(KeyPress,Exit)` sets the number of periods, calls `chromlib>S_Period` to recalculate the complex periodicity factors to be multiplied with the Hamiltonian modes and updates calculation and GUI.

2Jx, 2Jy, dpp, F → `EdScPar(KeyPress,Exit)` reads values for the relevant betatron amplitudes and momentum spread and updates the Hamiltonian modes. The last one is a factor how to weight the quadratic sum of sextupoles strengths.

("ξ" row) → `CSelectClick` reacts to the dynamically created row of checkboxes and selects the corresponding sextupole family for automated correction of linear chromaticity. Exactly two families have to be selected to activate the `AutoChrom` flag. Then the linear chromaticities and the corresponding `csexframe` instances are highlighted in yellow and calculations are repeated.

incl.Comb. → `ChkCombClick` in/excludes combined function bends from the sextupole families and en/disables the corresponding `csexframe` instances.

max B(3[,4[,5]])L, step B(3[,4[,5]])L → `edSOD(KeyPress,Exit)` are fields to set ranges and step size for manual change for the sextupoles [and octupoles [and decapoles]]. The corresponding `csexframe` instances are updated, because the number they show turns red if the range is exceeded.

Smatrix → `butSmatClick` calls `chromlib>S_TestOut` to write sextupole data to a file. **For testing, not used anymore.**

select → `butSelectClick` launches `ochromsvector` to show the first order sextupole kicks in the complex plane. At first, all the resulting vectors of the first order resonance terms are shown and the eight corresponding `chamframe` instances are highlighted in same color like the vectors. Pressing the button repeatedly shows the single sextupole kicks for one of them, and

the corresponding `chamframe` instance is highlighted in blue.

Minimizer initial step → `EdMinAmp(KeyPress,Exit)` sets the start amplitude of the Powell optimizer. *Seems to have little impact, since Powell anyway scales the step size.*

Dpp num.diff. → `EdNumDiff(KeyPress,Exit)` sets the dpp interval for the numeric differentiation of tune to get the chromaticities. In particular third order chromaticity is sensitive to this number, and the value has to be test to get a stable result.

Start → `ButMinClick` prepares the arrays for the Powell minimizer, starts `mathlib>Powell` and turns the caption of the button to **Break**. The function `PenaltyFunction` is passed as a parameter to `Powell`, which will send it a vector of internal knob values. `PenaltyFunction` contains a hyperbolic scaling of these knobs to the sextupole strengths in order to not exceed the range (however, this may cause a sextupole to get stuck at its maximum value without further progress). If automatic chromaticity or sextupole SVD are enabled, these steps are performed first before calculating all the drive terms and add them quadratically with weights as set in the `chamframe` instances to compose a single scalar penalty function and write it to a label in the GUI. If the penalty improved the color of the label turns green, if not it is red. Calling `Application.ProcessMessages` allows the GUI to handle events while the minimizer is running in order to interrupt, if the user pressed **Break**.

Exit → `ButExClick` saves data for chromaticity and ADTS internally for later comparison to tracking results, and closes the GUI.

If there are octupoles in the lattice, controls for the SVD appear in the GUI. If some of the second order modes have been selected (see above, ("O" row) SVD is set up calling `chromlib>Oct.SVDCMP` and the line `Con=..., Nw=...` shows the condition, i.e. the ratio of minimum to maximum weight factor and the number of weight factors.

-,+ → `ButOsvdN(m,p)Click` decreases or increases the weight factor spectrum (setting the smallest ones to zero) to find the best solution. (Small N_w gives a robust but incomplete solution.)

SVD → `ButOsvdDoClick` calls `chromlib>Oct.SVBKSB` to set the octupoles and updates the Hamiltonian modes and penalty function.

undo → `ButOsvdUndoClick` restores the octupoles to the values they had before pressing **SVD**.

auto → `chkOsvdAutoClick` sets the SVD to automatic mode. Then it will run in a master-slave mode while the Powell minimizer is working, for example to maintain constant ADTS.

all off, res → `ButOct(Off, Res)Click` sets all octupoles to zero and restores the values again.

8.2 Element controller

`csexframe`

At start, one instance of this frame is embedded in the GUI for each family of sextupole, octupole, decapole and combined function bend. It provides knobs to increase or decrease the

magnet strength. Changing the value triggers a calculation of the Hamiltonian modes. If the minimizer is running, the strength field follows.

Uses: `chromreslib`, `chromelelib`, `chromlib`, `ochromsvector`, `globlib`, `comauxlib`

Public procedures

This frame contains several public procedures, because the parent GUI `opachroma` and other units in this section have to control it. Further, the instances in the parent GUI have to control each other.

`Init` called by `opachroma` when creating the instance receives a type information if it is sextupole, octupole or decapole and an index for identification. It then gets the corresponding element family and its value, sets the name label and strength field (calling `SetVal`), and sets the appearance depending on the type.

`Brothers`, also called by `opachroma` receives handles to all instances of `csexframe` including the instance itself.

`SetSize` places the components inside the frame depending on the available space, which depends on the size of the parent GUI and on the number of knobs.

`getTabs` returns the position of label, value field and lock checkbox for `opachroma` to properly align the headline above the knobs.

`SetRange` sets the minimum and maximum value from the range fields in `opachroma` and calls private procedure `LimitVal` to cut the value to the limit if it exceeds the range and set the font color to red.

`SetVal` sets the value and also calls `LimitVal`.

`UpdateValbyMin` is used by the minimizer function `opachroma>PenaltyFunction` to only update the value but not trigger any calculation.

`mySetColor` changes the appearance, called by `opachroma` if the knob is reserved (e.g. for chromaticity correction).

`Lock,Unlock` locks or unlocks a knob. If locked the frame components are disabled. In case of an octupole family already included in the SVD, the SVD is set-up again without this family.

`Chrom(Lock,Unlock)` locks/unlocks a sextupole knob reserved for automatic chromaticity correction and disables/enables the check box to lock/unlock manually.

Actions

The event handlers are trivial: The edit field reacts to manual input and calls private procedure `UpdateVal`. The `<<`, `<`, `>`, `>>` buttons decrease or increase the value by a step as given in the corresponding fields in the `opachroma` GUI, or by a 20 times larger step. The `off` and `res` buttons set the value to zero or restore the initial value. And clicking the check box locks/unlocks the element.

Private procedure `UpdateVal` sets the value and recalculates the drive terms and the penalty function. In case of a sextupole knob, however, if automated chromaticity correction or automated octupole SVD are active, these are executed before. For chromaticity `chromlib>ChromCorrect` is called. For octupole SVD the private procedure `OsvdStep` recalculates the second order terms which may have been affected by the change in sextupole strength, and then performs another iteration of the SVD.

8.3 Result indicator

`chamframe`

26 instances of this frame are created in the `opachroma` GUI at start. This frame displays the result for one of the Hamiltonian modes and allows a weight factor to be set for the minimizer, and, in case of non-resonant terms, a target value, which is subtracted for penalty calculation. The result is shown as number and as bar. The number is the true value in SI units, whereas the bar size corresponds to the value multiplied with relevant amplitudes (set in `2Jx` etc. fields in `opachroma`) and the relative weight factor. Changing the weight may force a resize of the bar scale and thus affects all other `chamframe` instances too. Changing a target may affect sextupoles or octupoles if automated chromaticity correction or octupole SVD is active, therefore access to `csexframe` instances is needed. Since `csexframe` already uses `chamframe` (via `chromreslib`), the use is not declared in the `interface` section to avoid a circular reference but in the `implementation` section.

Uses: `chromelelib`, `chromlib`, `globlib`, `comauxlib` – and `csexframe` at runtime.

Public procedures

This frame contains several public procedures, because the parent GUI `opachroma` and other units in this section have to control it. Further, the instances in the parent GUI have to control each other.

`Init` called by `opachroma` when creating the instance sets default values and the appearance to distinguish resonant from non-resonant modes.

`SetLab` writes the name of the mode to the name label.

`Brothers`, also called by `opachroma` receives handles to all instances of `chamframe` including the instance itself.

`getChromSexHandles` receives handles to the two sextupole families assigned to automated chromaticity correction.

`passOctupoleHandle` receives a handle to an octupole family and adds it to an internal array of octupole handles. These are needed to update the octupole families if automated octupole SVD is active, and weight or target for one of the modes assigned is changed.

`SetSize` places the components inside the frame depending on the available space, which depends on the size of the parent GUI and on the number of knobs.

`getTabs` returns the position of target, value and weight fields for `opachroma` to properly align the headline above the knobs.

`SetValmax` sets the maximum value to scale the bar.

`SetWeight` sets the weight factor field and its font color.

`UpdateWeight` accepts a new weight factor and adjusts the scale of *all* `chamframe` instances to maintain comparability of the bars. If automated octupole SVD is active, a change of weight will affect its result, therefore the SVD is repeated. This will change the second order modes, so the scale of all instances is adjusted again.

`SetTarget` sets the target field (non-resonant modes only).

`UpdateTarget` accepts a new target value and performs the same steps like `UpdateWeight` (see above). In addition, if automated chromaticity correction is active and the target value actually is one of the desired linear chromaticities, then `chromlib>ChromCorrect` is called, and the two sextupole families assigned to chromaticity correction are updated.

`UpdateHam` writes the value field and calls private procedure `PlotBar` to plot the bar.

`mySetColor` changes the appearance, called by `opachroma` if the mode is to be highlighted for various reasons.

`MinInclude` sets the color to grey and disables all components, if this mode is not included in penalty calculation.

Actions

The event handlers are trivial: The target and weight edit fields react to manual input and call `UpdateTarget` or `UpdateWeight` (see above). The `-` `+`, buttons decrease or increase the weight.

`(bar panel)` → `PanBarPaint` reacts to a `repaint` event. It first erases the bar by filling the panel with black color, than it plots the bar like `PlotBar`. (Should be united with `PlotBar`).

8.4 Result handles

`chromreslib`

This small unit organizes handles, which are accessed by other units. It was introduced to avoid too many passes between these units.

Uses: `chamframe`, `chromlib`

Public procedures

`Pass_CH_Handles` and `Pass_LabPath_Handles` receive handles to the 26 `chamframe` instances and to the three pathlength labels in the `opachroma` GUI.

`UpdateHamilton` calls `chamframe>UpdateHam` for all handles.

`UpdatePath` writes path length data to the label handles.

`UpdatePenalty` writes the current penalty to the label in the `opachroma` GUI.

8.5 Element handles

`chromelib`

This small unit organizes handles related to the octupole SVD.

Uses: `chromlib`

Public procedures

`Pass_Osvd_Handles` receives handles to all the components of the `opachroma` GUI related to octupole SVD.

`Osvd_Status` contains some logic to enable or disable the components of the octupole SVD depending on the status. It further displays condition (ratio of min. to max. SVD weight factor) and number of weight factors in use.

`Osvd_Wfilter` filters the SVD weights, i.e. increases or decreases the null space, depending on how many weight factors are to be cut off.

8.6 Vector diagram

`ochromsvector`

This little form contains only a plot window to show the sextupole kicks in the complex plane in order to visualize phase cancellations. All control is done by the `Select` button in the `opachroma` GUI.

Uses: `chromlib`, `globlib`, `mathlib`, `comfigureframe`

Public procedures

`Init` is always called by `opachroma` → `butSelectClick` (see above) and steps up the variable `chromlib:VSelect` to select one of the eight first order resonant sextupole Hamiltonians for display or to compare the sum vectors of all. The caption of the form is set to tell which mode it is, and `Star` is called to do the plot.

`Star` plots a star diagram of complex vectors for all sextupole kicks in the lattice. The vectors are calculated by `chromlib>getSVector`. The colors for the sextupole families as given by the `chromlib:SexFam` record are the same like the sextupole knob `csexframe` color in the `opachroma` GUI. The sum vector is shown as a white line, enclosed by a white circle to better see it. In comparison mode, the sum vectors for the eight first order resonant terms are shown in one diagram. The colors are the same like the colors of the corresponding `chamframe` instances showing the first order modes.

Actions

(on create) → **FormCreate** and (on close) → **FormClose** get and set the user defined size of the window and save the setting on close.

8.7 Calculations

chromlib

This unit is the base for all other units and GUIs of this section. It contains constants, type declarations and variables, and all the physics procedures.

Uses: **linoplib**, **elemlib**, **opatunediag**, **globlib**, **mathlib**, **comvgraphlib**, **comauxlib**

Public constants, types and variables

Several array constants contain indices for calculating the Hamiltonian modes and annotations, colors etc.

Type declarations define **SextupoleType** for a single sextupole kick, and **(Sex, Octu, Deca) FamType** for the (sextu, octu, deca)-pole families.

SM1_row defines one row of a matrix to get the contribution to the 10 first order modes from one of the sextupole families. **SM2_row** is for the 11 second order modes (ADTS and resonant) and for one *product* of two sextupole families. The corresponding matrix rows for octupoles are contained in **OctuFamType** as fields **omat**, **om1**.

In the public variables section the sextupole matrices **SM1**, **SM2** are defined as arrays of **SM(1,2)_row** of variable length, since the size will depend on the number of families. The group of variables named **osvd_...** are 1-dimensional arrays to pack the matrices for octupole SVD, they will be unpacked to 2-dimensional arrays in **mathlib**>**SVDCMP**. Other variables of simpler types are for keeping intermediate results and control flags.

Public procedures

ChromInit restores user settings, sets up all the arrays and performs calculations which are only needed once at start like the **SM1**, **SM2** matrices.

In order to set up the arrays the element list (**E11a**) is searched for sextupole families and the lattice line-up is searched for sextupoles installed. Also combined function magnets are included since they may contain a sextupole component. Before, the periodic solution is calculated, which can not fail, since the non-linear optimization GUI is only enabled if a periodic solution exists. With the initial values from the periodic solution, the optical functions are calculated element by element. Beta functions and phases at each sextupole *kick* are obtained and stored in the **Sextupole** array.

Optical functions are also calculated at entry, midpoint and exit of quadrupoles and bending magnets, since they contribute to chromaticity and chromatic half-integer modes (this is an

approximation, therefore there may be small differences between chromaticity obtained this way and from numeric differentiation).

Octupoles are handled a bit differently than sextupoles by building the `OctuFam` family array "on the fly" and not in advance, and calculating the constant part of the octupole matrix `omatpre`, `om1pre` already here. For decapoles only a small matrix `dmatrix` for their first order effect on third order chromaticity is calculated.

When finished with collecting the elements in the lattice, a linked list of sextupole kicks belonging to the sextupole families is established and the start pointer is saved in `SexFam.kid`.

Finally the sextupole matrices `SM1`, `SM2` are calculated calling procedure `S_Matrix`, which may take a while, the periodicity factors are calculated calling `S_Period`, and the tune diagram `opatunediag` is launched.

When `ChromInit` is finished, all data have been established for `opachroma` to compose the GUI, i.e. install `csexframe` knobs etc.

These procedures are called by `ChromInit`:

`S_Matrix` calculates the first and second order extupole matrices `SM1`, `SM2`: a lattice may contain some 100 sextupoles, each one modelled by several kicks, so a total of about 1000 kicks. But since they belong to a small number (~ 10) families, the phase and amplitude terms to be multiplied with the sextupole strength are calculated in advance and stored in the matrices. Then the optimizer will only vary the vector of family strengths and multiply it with the matrix to get the Hamiltonian modes. For the second order this procedure is mandatory to get results in acceptable time, since it contains double sums over the cross-terms from all kicks, which may result in a million terms to be added. The formulae coded are found in [11] and [12].

`S_Period` calculates a complex factor to be multiplied with the Hamiltonian mode if more than one period is assumed. Calculating one period and apply this factor is much faster than calculating the whole lattice made from many identical periods. Entering zero to the procedure gives the extrapolated result for an infinite number of periods. The formula coded are found in [11] and [3].

`S_TestOut` writes the matrices and optics data at multipoles to a file named `(lattice)_smatrix.txt` for testing or cross-check with other codes.

`set_cd_matrix` sets up a matrix for numeric differentiation of tunes to get chromaticity up to third order from a polynomial fit.

Following procedures are performed on user input or during optimization:

`UpdateChromMatrix` sets up the 2×2 matrix how two selected sextupole families affect the linear chromaticity. Then the matrix is inverted and saved to be used for automated chromaticity correction.

`getLinChroma` calculates the linear chromaticity by adding the sextupole contribution to the initially calculated, constant contribution from quadrupoles and bending magnets.

`ChromCorrect` sets two selected sextupole families to adjust the chromaticity to the set values, contained in `HamTarg([0],[1])` as target values.

`Update(SexFam, SexFamInt, OcFamInt)` set the multipoles to the given value in two ways: in the arrays initially compiled for fast calculation of the Hamiltonian modes, and in the element list `Ella` for chromaticity calculation from numeric differentiation by variation of momentum offset of the periodic solution.

The `DriveTerms...` procedure calculate different groups of Hamiltonian modes as included by the check boxes in the ("inc" row) in the `opachroma` GUI. These are the first order geometric terms, the first order chromatic terms, the ADTS, the second (and third) order chromaticity, the octupole resonant modes, and the square sum of all sextupole strenghts.

The `Penalty` functions subtracts target values (for non-resonant modes), gets the absolut value of the (complex) mode, applies relevant amplitude factors and manually set additional weights (in `chamframe`), and finally sums up all these results quadratically to get a simple number as objective for the minimizer.

`HamScaling` calculates the weight factor corresponding to relevant betatron amplitudes and momentum range to be applied by `Penalty`.

`Oct_sv(dcmp,bskb)` contain the octupole SVD. The first procedure sets the size of the linear system to be solved by SVD depending on the number of selected Hamiltonian modes and octupole families. It builds the coefficient matrix of the system, where resonant modes get two rows, because they are complex, whereas the real-valued non-resonant modes get one row. And in packs the matrix in the 1-dimensional array `osvd_aupack` in order to run the SVD procedure from [14] as coded in `mathlib>SVDcmp` with variable array size. The scnd procedure gets the vector of target values for the selected modes and performs the backsubstituion calling `mathlib>SVBksb` to set the octupole families. The information on null space, i.e. cut off weighting factors, is transmitted in the array `osvd_wuse`.

`getSVector` calculates the complex vectors of sextupole kicks for `ochromsvector` (see above).

`TdiagPlot` shows a prediction of the tune footprint from ADTS and chromaticity in the tune diagram. Procedure `TdiagPlotFull` refreshes the tune diagram before doing so.

`ChromSaveDef` and `ChromDispose`, finally called when closing `opachroma`, save user settings and release the dynamic arrays and linked lists, and `CloseTuneDiagram` closes the tune diagram.

9 Orbit, Injection and Machine Layout

9.1 Orbit and injection

`opaorbit`

Depending on a flag set at start, this GUI is used for orbit or injection studies.

In orbit mode, correlated misalignments are applied, the response matrix is calculated and pseudo-inverted using an SVD procedure in order to correct the orbit. A loop function may run several error seeds to obtain some statistics. Note, that correctors and BPMs defined with reserved names `CH,CV,MON` in the lattice file are internally expanded to a set of individual

elements, e.g. CH001... when unpacking the lattice by `editorlib>MakeLattice`.

In injection mode, kickers may be synchronized for correct timing, and the injected (and/or stored) beam trajectory is calculated for a few turns.

In both modes, when leaving the unit, results for misalignments and corrector settings, or for kicker settings, are saved internally and will be used in subsequent linear optics calculations or tracking. **There are problems with misalignments in tracking, not yet solved.**

The GUI contains two plot windows for horizontal and vertical orbit and a line-up of elements, which may be dragged to knobs. These are correctors and beam position monitors (BPM) in orbit mode, and kicker magnets and BPMs in injection mode. In orbit mode a panel becomes visible which contains several controls to set misalignments, correct the orbit, get orbit statistics and switch the plot mode. In injection mode a simpler panel appears in the same place which contains controls to set kicker timing and select turn number.

`ostartmenu` is called in both modes to set the initial conditions, where the periodic option is disabled in injection mode, because it makes no sense.

`opaorbit` is similar to `opalinop` for linear optics design, because both show the orbit and provide clickable elements to be dragged to knobs. Furthermore, data are transferred from one to the other to calculate the optics on a corrected orbit. Thus it would make sense to combine both GUIs into one, perhaps using tabs for the different modes. However, `opaorbit` uses two `comfigureframe` instances for plotting and the clickable elements are realized as `TShape` objects on the form, underneath the plot, whereas `opalinop` has its own, much more complex plot window with bars inside the plot for the elements.

Uses: `globlib`, `georblib`, `knobframe`, `linoplib`, `ostartmenu`, `mathlib`, `comfigureframe`, `comauxlib`

Public procedures

`Start` receives a flag to set orbit or injection mode. Then the form passes a handle to itself to `linoplib` to enable a repaint. The girders are set up calling `georblib>GirderSetup`. Then `georblib>OrbitInit` is called to allocate arrays for BPMs and correctors, and symbols are created on the form. After restoring user settings and filling edit fields, `ostartmenu` is launched to get started.

Actions

Actions available in both modes

Some of these actions (marked by *) don't make sense in injection mode and should be hidden or disabled. The historical reason is, that the orbit mode was first and the injection mode was "squeezed" in later.

(repaint) → `FormPaint` plots the orbit. The procedure is called by `linoplib>PlotOrbit` via the handle to the form passed at initialization. Orbit calculation and plotting is triggered by

`ostartmenu` and also by some components in the GUI. Plotting is done by private procedure `Makeplot` which calls several other private procedures: `georblib>Get(Orbit,Cor,Mis)Max` get the maxima of data for plot scaling, `plot(X,Y)` plot the orbit, `WeightPlot` shows a histogram of orbit correction SVD weighting factors, `BPMshow` fills the BPM readout panel, `LabelShow` updates the correction status and `CodStat` fills a panel with orbit statistics data. In injection mode some of these procedures do nothing.

(symbols) → `BoxMouse(Down, Up)` drag an element shown as symbol (`TShape`) to either a knob (class `knobframe`) if it is an active element, i.e. corrector or kicker, or, if it is a BPM to the BPM panel `panbpm` to show its readout.

`<->` , `>-<` , `-->` , `<--` → `butzooClick` are zoom functions, similar but simpler than in `opalinop`.

"BPM" panel `panbpm`:

- * **Orbit/Reference** → `butBPMmpodeClick` toggles between "Orbit" mode, where the BPM shows the readout (also x' , y' which a real BPM can't read), and "Reference" mode, where values for x , y can be entered to be used as a reference in orbit correction.

- * **Set** → `butBPMrefClick` saves the reference.

"Start and statistics" panel `panctr`:

Start → `butStaClick` launches the `ostartmenu` start panel again to change initial conditions etc. **BUG: plot error when starting from an optics marker.**

include nonlinear elements → `chkSextClick` switches on/off nonlinear elements for the calculations.

- * **BPM/all/Cor** → `butCODstatClick` selects which statistical data to show in the table underneath the button: BPM only, all elements or corrector strength.

"Show" panel `panplo`:

- * **Orbit+BPMs, Correctors, Misalignments** → `butplot0CClick` selects the plot mode: orbit, corrector strengths or misalignments.

- * **keep max.** → `chkKeepMaxClick` freezes the maximum value for the plot, may be used to avoid rescaling after orbit correction.

-> EPS → `butEPSClick` exports the current plot to an `.eps` file.

Actions available in orbit mode only

"Misalign and correct" panel `panmis`:

set → `butMisalClick` reads misalignment data from the edit fields and calls

`georblib>SetMisalignments` to set correlated misalignments for elements on girders. Then the orbit is calculated and shown. The edit fields contain data for the girder ends, for the elements relative to the girder and for the joint play of a virtual link assumed to connect girders ("train link"). Misalignments are sway and heave, and for girders and elements also roll. The **El/Gird** field contains a percentage how to reduce the misalignment of elements on girder relative to single elements, assuming that they may be aligned better. The **seed** field takes any number to generate different random seeds for testing.

include BPM → **butMonabsClick** includes or excludes the BPMs from misalignments, i.e. if their readings are absolute or relative to their own misalignments, which is the realistic case. The caption of the button is changed to "exclude" if BPMs are absolute.

zero → **butZeroClick** and **re-set** → **butSetAgainClick** sets all misalignments to zero or restores them again.

Correct → **butCorClick** performs the orbit correction: if not yet done, the arrays for the SVD are dimensioned calling **PrepOrbCorr** and the response matrix and the SVD are set up based on the analytical, linear lattice model by **georlib>GetResponseMatrix**. Then **OrbitCorrection** corrects the orbit calling **georlib>oco_step**.

The correction result is evaluated calling **CodStat** to check if the orbit as changed and **georlib>CodStatCalc** to get statistical data. The label **LabOrbStat** is set to "zeroed" if all BPM read zero, to "minimized" if correction converged with some residual (this is the case if there are more BPMs than correctors), to "too many it." if correction did not converge within the limited number of iterations, and to "failed!" if it diverged and the orbit became too large. Statistics results are written to the table in the statistics panel **panctr**, showing mean, rms and max value for BPM readings, orbit everywhere and corrector strengths.

Finally **MakePlot** is called to show the corrected orbit, it contains the procedure **WeightPlot** which plots a histogram of weight factors, showing in darker color weight factors which were set to zero (in case a more robust but incomplete correction is tried).

Loop → **butLoopClick** performs a series of orbit corrections to get statistical data. When pressing the button, at first the seed field changes to **Nseed** and the number inside is the number of seeds to do, and the button caption changes to **Run**.

Pressing again starts the loop and the caption is set to **Break**. Pressing again while running aborts the loop, otherwise it continues to the end and the caption becomes **Done**. Pressing again sets the caption back to **Loop**. Internally this is controlled by variable **georlib:loopstatus**.

During running, the seed index is shown, and in the OPA log window in the main GUI **opamenu** the results of the seeds are listed. When done, the statistics data as calculated by **opageometry>LoopStatCalc** have a different meaning than for single orbit correction: "mean" is the mean rms orbit from all seeds, "rms" is the maximum of the rms values, and "max" is the absolute maximum.

Corr=0 → **butCorZeroClick** and **BPM=0** → **butBPMZeroClick** set all correctors or all BPM references to zero.

X → **butOcoWplotClick** toggles between horizontal and vertical weight factor plot, button caption changes between **X** and **Y**.

(slider) → **sliderWChange** sets all weighting factors above the slider to zero.

Actions available in injection mode only

"Pulsed magnets" panel **pankick**:

ON → **butKickClick** activates the kickers, sets the caption of the button and enables the multi-turn buttons if the lattice is circular. Then the orbit is calculated and shown.

Sync → **butSyncClick** synchronizes the kickers calling **georlib>SyncKickers** .

-,+ → **butKickT(m,p)Click** increase the number of turns (max 3) to be calculated and plotted in a circular lattice. **linoplib>OrbitCalc** is called with a negative number used as a switch to count turns and start at begin of lattice in successive turns.

9.2 Machine Layout

opageometry

The layout of the lattice in physical space is shown, by default as seen from top. The geometry as defined by the design orbit is calculated in 3D-space from elements lengths, deflection and rotation angles. Depending on initial conditions, the orbit curve in space is rotated and translated. The elements are made from faces, i.e. polygons in 3D-space, which become polygons in 2D-space when projected to the image plane.

Several files can be exported, among them a **.geo** file of polygons, which can also be read again in order to show several lattice structures in one plot (e.g. ring with transfer lines).

Geometric matching is used to exactly close a ring or to adjust the final position and angle of a transfer line. For that purpose the lattice should contain variables with names starting with the letter “G”, which control lengths and deflection or rotation angles of elements. Then an SVD optimizer is used to adjust the final (or initial) coordinates and angles of the lattice structure to given target values.

The GUI contains plot window **geo** to show the machine layout, panel **PanParam** with a table to define how elements are shown in the plot, panel **PanGeo** for initial and final position data and panel **PanMat** to control geometric matching.

Unfortunately this unit is still incomplete and buggy, nevertheless it is quite useful. Following measures need to be addressed for improvement and completion:

- Mouse actions to zoom to a region of interest work well in the Windows version but not in the Linux version. Reasons are not yet understood, probably related to different event handling.
- Up to now the elements are “flat”, i.e. represented by a face of some length and width in the midplane. When changing initial conditions from top to side view, they look ugly. It would be straightforward to define bodies composed from top and side faces, however this would also require some rendering algorithm for 3D-display which may be beyond the scope of OPA – instead, the data export to CAD programs may be used.

Uses: **globlib**, **varlib**, **georlib**, **linoplib**, **mathlib**, **comfigureframe**, **comauxlib**

Public procedures

Start at first passes a handle to the GUI to the embedded `comfigureframe` frame `geo` in order to later react to mouse events in the plot window. Then it calls `georblib>GeoInit` to read settings, to set up the girders and to create dynamically all required GUI components. Variables for geometric matching are allocated and corresponding components are created. Then a first geometric plot is generated calling procedures `georblib>CalcOrbit,CalcFaces,TransPoly,GeoMinMax`. Finally `MakePlot` plots the 2D-polygons and additional data to the screen.

Actions

(arrow buttons) → `but(Left,Right,Up,Down,SForward,SBackward,ZoomFull)Click` select the view by shifting, by following the lattice or by returning to full view. Further marking a rectangle with the mouse selects a region of interest (see `comfigureframe`, **BUG: does not work in the linux version**).

(geo.p repaint) → `geopaint`: an `OnPaint` for the paintbox object `p` inside `geo` calls `MakePlot` to update the plot. **Probably the malfunction in the linux version is related to that – to be explored.**

show Orbit → `chkOrbitClick` overplots the orbit.

fix aspect ratio → `chkAspratClick` fixes the aspect ratio to have same scales horizontal and vertical (true by default).

(parameter table) → `GridParamKeyPressed` reads data how to show the various lattice elements from the paramter grid at left and updates the plot.

→ **Data** → `butListClick` calls `georblib>WriteGEOFiles` to export text files with geometry data.

← **Data** → `butListClick` opens a dialog to select geomery files and calls `georblib>ReadGeoFiles` to read and add the data to the current plot. This is useful to overplot various lattices, for example booster, transfer line and storage ring.

Mode (cen,ini,fin) → `rbdrawClick` enables/disables the edit fields at left for initial and final position depending on the mode of calculation, which is from start or end of latice, or centering provided there are markers with reserved name `CENTER` in the lattice.

If geometric matching is possible, i.e. the panel `PanMat` is visible listing simple variables with names starting with the latter “G”, then check boxes for geometric matching are enabled to select target values and knobs, and following actions become available:

check boxes → `chkg_Click`, `chkgvar_Click` select target fields and knobs (i.e. variables) and enable the matching button **match** if there are at least as many kobs as targets.

actual → `butGoalClick` switches the button caption to **target** and highlights the checked edit fields for positions and angles to enter target values. Pressing the button again switches back to the actual values.

match → `butMatClick` performs the SVD for geometric matching calling `georblib>gmat_ini,gmat_step`.

reset → **butResetClick** restores initial values calling **georblib>gmat.reset** if the user doesn't like the solution.

Exit → **butExClick** saves the user settings and closes the GUI.

9.3 Orbit, injection and geometry calculations

georblib

This unit contains the calculations for **opaorbit** and **opageometry**. It defines the girders, which are used for correlated misalignment or for showing the machine layout. Two SVD procedures are included, one for orbit correction using orbit correctors and BPMs, the other one for geometric matching using variables with names starting with letter "G" and manual target input.

Uses: **globlib**, **linoplib**, **elemllib**, **mathlib**, **comauxlib**

Public constants, types and variables

Many constants define properties of the parent GUIs like label strings, number formats, etc.

Girder is an array of **GirderType** records. It contains position and orientation of the girder, the misalignments of its feet, the index in the lattice array where it starts and ends, and an information how it is connected to the adjacent girders.

For orbit correction, types **cortype** and **bpmtyp** define correctors and BPMs as used here, i.e. with properties copied from/to the global **Ella**-array. **OrbLoopType** saves results from many orbit corrections. For injection, type **kicktype** defines pulsed elements. For machine layout, types **midpt**, **unicofaceType** and **fpolytype** define orbit coordinates, 3D-faces of elements and 2D-polygons for plotting. Array variables of corresponding types are named same without suffix "Type".

Arrays named **oco...** are used for the orbit correction SVD, which is rather complex including filtering of weight factors and individual target values for BPMs. The geometry SVD is far more simple and contained inside procedure **gmat_step**.

Public procedures

Procedures for all modes

GirderSetup evaluates the girder structure if contained in the lattice and allocates the lattice elements to the corresponding girders.

Procedures for orbit and injection

OrbitInit searches the lattice for correctors, resp. kickers and monitors and declares the **cor**, **bpm** and **kick** arrays to manage them. Then it restores user settings and sets initial parameters.

OrbitExit is called on regular exit from **opaorbit**. It sets the status label of **opamenu** to indicate whether correctors are active or not and saves the user settings.

OrbitClose is called when closing the **opaorbit** form and releases dynamic arrays which had been allocated for orbit correction.

GetOrbitMax, **GetCorMax** and **GetMisMax** simply get the min/max values for orbit data, corrector strength and misalignment data to set plot range.

setMisalignments applies Gaussian distributed misalignment with the rms values as entered in the edit fields of the **opaorbit** form and cut at a number of sigma also given there. First, the girders are set, then the secondary girders supported by other girders, then compound elements, i.e. series of lattice elements with no space between which are assumed to be one rigid body, and finally individual single elements.

GetResponseMatrix calculates the analytical response matrix for the ideal lattice in periodic or single pass mode. Then the SV decomposition is performed calling **mathlib>SVDcmp**.

CodstatCalc calculates mean, rms and max values for orbit, correctors and misalignments.

LoopstatCalc evaluates a number of orbit corrections. It classifies the corrections (zeroed, minimized, failed etc.) and calculates the mean rms value from all successful corrections, the maximum rms value and the absolute maximum for orbit, correctors and misalignments.

oco_init just sets up the right and side vector of the linear system for SVD.

oco_step performs an iteration of the correction by passing the target vector of BPM readings and references to the vector and calling **mathlib>SVBKSB**.

oco_term releases temporary arrays.

SyncKickers is called in injection mode to synchronize the kickers with the beam: It calculates the time of beam arrival at the kicker entry and adjusts its field **delay** to the same value. If the kicker is of finite length, **elemllib>Kicker** takes care of internal time of flight.

Procedures for machine layout

GeoInit reads user settings, initializes the variables for geometry calculations and sets up the girders calling **GirderSetup**.

GeoExit saves user settings and is called on regular exit from **opageometry**.

GeoClose releases dynamic arrays and is called when closing **opageometry**.

CalcOrbit calculates the orbit in 3D-space, i.e. the location and orientation of all elements starting from a zero position and direction. These data are saved in array **midpt**, and later variations of initial conditions don't require re-calculations but only transformations.

CalcFaces calculates the faces of a body in 3D-space representing a lattice element. Data include the array **vpt** of corner points and the array **face** listing the face properties and where to start and end reading points from the corner point array. **As mentioned, presently only one face in the element midplane is used, extension to front and side faces would be straightforward.**

CalcPoly calculates 2D-polygons (arrays **ptx**, **pty**) for plotting from the faces in 3D-space using the current imaging options like observer location and direction of view (**incomplete**).

TransRot and **TransPoly** transform (translate and rotate) the orbit only or all faces including

recalculation of polygons.

`geoMinMax` calculates the plot ranges.

`WriteGeoFiles` exports file `*_geo.txt` of polygon data. Further files of geometry data named `*(holy,srad,mpo,pos).txt` are exported too, however these have only historical or SLS-specific meanings and may be adapted as needed.

`ReadGeoFiles` imports files of polygon data `*_geo.txt` to add them to the current plot.

`gsetedgval` stores values of initial parameters, positions and angles.

`gmat_ini` sets up arrays for geometric matching through SVD.

`gmat_step` executes the SVD procedure for geometric matching. It calculates a sensitivity matrix how the target values react on the knobs, starts an SVD-procedure calling `mathlib>svdcmp,svbksb` and updates the plot. If the fit fails, variables are reset, otherwise they are updated.

`gmat_reset` resets variables to initial values.

10 Tracking

There are three GUIs for phase space tracking, dynamic aperture and Touschek lifetime, and a physics unit used by all three.

10.1 Phase space

opatrackps

Uses: `tracklib`, `globlib`, `opatunediag`, `mathlib`, `comfigureframe`, `comvgraphlib`, `comauxlib`

The GUI for phase space tracking contains four plot windows for the transverse phase spaces (`psx`, `psy`) and for the particle spectra (`ftx`, `fty`), and six panels to set parameters or show results. Single particles are started from coordinates entered manually in edit fields or passed from mouse clicks in the phase space plots. Amplitude dependent tune shifts (ADTS) are obtained by stepping up particle coordinates. For simulation of injection, a beam ellipse populated with many particles can be tracked.

The six panels are `PanParam` to set tunes and apertures, `PanCtrl` to set start coordinates, `PanRes` to show a table of tunes found in the spectra, `PanFFT` to set parameters of the Fast Fourier Transform (FFT), `PanTush` to set parameters for the ADTS loop and `PanBeam` to set parameters for the beam ellipse. From the last four only two are visible at a time.

Public procedures

`Start` receives a handle to the tune diagram `opatunediag`. The combobox `comTurns` is populated with powers of 2 for the available number of turns. User settings are restored. The

four `configureframe` instances for plotting are assigned and handles are passed to the edit fields for starting coordinates in order to later read coordinates from clicking into the plot. Flags and fields are initialized. Finally, `tracklib>Initdpp` is called, which provides the periodic solution (it will exist, otherwise the tracking option would not be enabled in `opamenu`) and the physical aperture limitations projected to the track point. The `(onPaint)` event of the plot areas will then show empty beam ellipses corresponding to the linear physical limit. **BUG: at start the plot sometimes appears too small, ok after touching (resizing) the GUI.**

Actions

Note: a common event handler `ediAction` is used for most edit fields in this GUI. It is called by `KeyPress` or `Exit` events, i.e. when a key is pressed in the field or the cursor leaves the field.

Panel `PanParam`

Nturns → `comTurnsChange` gets the number of turns from the selected item. It is always a power of 2 as required by the FFT.

Element apertures → `cbxElAperClick` toggles between using the apertures of the elements or the values in the `Ax[mm]`, `Ay[mm]` edit fields before calling `tracklib>Initdpp` again to calculate the physical limit for tracking. The `psx,psy` figures are initialized again.

A(x,y)[mm] → `ediAction[edi(x,y)aper]` has the same effect when entering a value in the edit fields.

Trackpoint → `ediAction[edistartpos]` takes the value from the edit field as trackpoint position (can be anywhere in the lattice, even inside an element) and calls `tracklib>Initdpp` again to get the optics and aperture limit at that location. Before the input is checked to be within the length of the active lattice segment.

4D → `butT6Click` sets tracking mode from 4- to 6-dimensional and changes the button caption. **Experimental mode, incomplete implementation!**

Panel `PanCtrl`

dp/p[%] → `ediAction[edidpp]` calls `tracklib>Initdpp` again for the momentum offset as entered. The periodic solution may be lost, if the value is too large, then a warning pops up.

Run → `butRunClick` reads the coordinates from the four edit fields `X[mm]` etc. These values may have been entered manually or by a `pMouseDown` event in the `psx,psy` plot areas (see `configureframe` above). Before starting tracking, the particle amplitude is calculated using the local beta functions, and an ellipse is drawn for comparison with the aperture limitation. Then the function `Track` is called to track the given number of turns by calling `tracklib>Oneturn` in a loop, and to plot the coordinates during tracking. When finished it will return `false`, when the particle was lost it will return `true`. If succesfull, private procedure `Spectrum` is called, which applies a sine-window to the data for peak interpolation before calling `tracklib>TWOFFT` and `FFTtoAmp` to get horizontal and vertical particle spectra as real amplitudes. Then private `FFTplot` is called: it plots the spectra, tries to guess the

resonances corresponding to the peaks found by calling `tracklib>FindPeaks` and `ResoGuess`, and shows the results in the spectrum plots and in the table `resgrid` in panel `PanRes`. The tune identified as fundamental is plotted in the tune diagram `opatunediag`.

More → `butMoreClick` continues tracking with the same number of turns and updates the spectra with the new points.

Clear → `butClearClick` clears the plot areas by initializing again and also clears the tune diagram.

Beam → `butBeamClick` sets panel `PanBeam` visible (and hides `PanTush`, or vice versa).

Exit → `butExitClick` saves the user settings and closes the GUI.

Panel `PanTush`

Run → `butTushClick` starts an ADTS scan by stepping up particle amplitude and tracking the tune. At first the number of steps is taken from the `Nsteps` field, and the **Break** button is enabled to abort the scan. Then three arrays for tunes and amplitudes are declared, for horizontal, vertical and coupled motion. Maximum amplitudes are given by element apertures or by manually entered apertures (see above) and calculated by `tracklib>AmpKappa` assuming elliptical apertures [3]. If manually entered apertures are used, the acceptance from element apertures are also shown in the plot. Since FFT does not distinguish between below and above half integer, following the tune has to take into account on which side the tune is located.

During tracking label `labtprog` is updated to inform about the progress, the start coordinates are shown in the edit fields of panel `PanCtrl` and the Poincaré plot of the particle motion is shown in the `psx,psy` plot areas. When the number of turns is completed and the particle was not lost, then the spectra are calculated and plotted, and identification of the fundamental tune is tried. *The lines in the code following the call of `Spectrum` are an attempt to still follow the particle tune if it moves over half integer. It sometimes works but often doesn't – to be improved.* The found tunes are plotted in the tune diagram calling `opatunediag>AddTushPoint`. If manually entered apertures are used, particles outside the acceptance from element apertures are plotted in grey color in the tune diagram.

When the scan is done, the tune as function of amplitudes is plotted for the three series horizontal, coupled and vertical, and the button **Amplitude** is enabled. If analytical ADTS had been calculated in non-linear optimization, `opachroma`, then arrays are prepared for plotting them too.

Amplitude → `TSplotButClick` toggles between plotting tune shifts vs. betatron amplitude, pinger kick and transverse max. position and changes the caption of the button accordingly. During the scan transverse kicks were stepped up simulating a pinger, so this plot is most realistic. Amplitudes had been calculated by linear interpolation up to the maximum amplitude, and position is calculated from the amplitude using the local beta function. (In a previous version amplitudes were taken from the peak height in the spectrum, but this turned out to be confusing in case of strong non-linearity or coupling.)

--> **EPS** → `butExportClick` exports the ADTS plots to two `.eps` files. Note that the Poincaré plots have no eps export because this would require to store too much data.

(Anyway, screenshots can always be taken by couple-clicking the plot.)

--> **TEXT** → [butTXTClick](#) writes ADTS data to a text file.

Panel [PanBeam](#)

X → [ButBeamXYClick](#) toggles the edit field between accepting data for horizontal or vertical beam size. If vertical, caption changes to **Y**.

Set → [ButBeamShowClick](#) reads the edit fields for beta and alpha function and emittance and the number of particles and creates the particle ensemble centered at the initial coordinates as given in the [PanCtrl](#) panel. Note, that the ensemble is generated only in one dimension, while the coordinates in the other dimension are the same for all particles. The start ensemble is plotted in green.

Run → [ButBeamRunClick](#) reads the **show turns** field, which tells the first N turns to be plotted (useful for injection studies). The last turn is plotted anyway. The function [TrackBeam](#) performs tracking. It tracks all particles of the ensemble for one turn after the other, counts how many are left, and plots the ensemble if plotting this turn was requested. And it writes the number of turns done and the number of surviving particles to label **LabT** in panel [PanParam](#). If there are surviving particles, the button caption is set to **More** and pressing it again will continue tracking.

Break → [ButBeamBreak](#) aborts tracking by setting flag [BeamBreak](#) which is checked in the [TrackBeam](#) loop.

Other actions

Resonance Guess – Parameters → [butParamClick](#) switches visibility from panel [PanRes](#) to [PanFFT](#) and fills the edit fields. Panel [PanRes](#) is passive, it contains only a table listing found peaks and resonance guesses, and panel [PanFFT](#) contains edit fields to set parameters for peak and resonance identification. Label and button captions change to **FFT parameters – Update**. Pressing the button again switches back to panel [PanRes](#), updates the filter, repeats the FFT plot and evaluation, and sets back label and button captions.

(resize) → [FormResize](#) calls [ResizeAll](#) to dynamically resize the complete GUI and initialize the plot areas again.

10.2 Dynamic aperture

opatrackda

There are four modes of dynamic aperture tracking, three 2-dimensional scans for the areas $(\pm x, y)$, $(\pm x, \pm \Delta p/p)$ and $(y, \pm \Delta p/p)$, and one 3-dimensional scan for the volume $(\pm x, \pm x', \pm \Delta p/p)$. They may be combined with three scan methods, grid probing (GP), binary search (BS) and flood fill (FF), however FF is not available for the 2-d $\Delta p/p$ scans, whereas the 3-d scan works only with FF. GP probes every point in a rectangular grid which is successively refined to get an early impression. BS search finds separatrix points along a set of rays from the origin. And FF from computer graphics fills the unstable area outside the

separatrix. FF was implemented in OPA by Bernard Riemann.

The FF 3-d scan provides data for "Fast Touschek Tracking" in `opatracktt`. A detailed description is given in [17].

The GUI contains a plot window `fig`, two radio button groups `rgmode` and `rgmeth` to set mode and method, two panels `PanNray` and `pangrid` to set parameters for BS and GP/FF modes, and edit fields for turns and momentum offset.

Uses: `tracklib`, `globlib`, `mathlib`, `comfigureframe`, `comvgraphlib`, `comauxlib`

Public procedures

`Start` reads user settings and fills the GUI with these values. The corresponding components are shown or hidden, and incompatible settings are corrected. `tracklib>Acc_dpp` and `tracklib>Initdpp` are called, which provide the momentum dependant physical acceptance and the periodic solution for the given $\Delta p/p$ ($= 0$ at start, has to exist, otherwise launching the GUI would be blocked in `opamenu`).

Actions

(mode/method radio groups) → `rbClick` reacts to setting the mode or the method. Mode and method are encoded in the `Tag` fields of the components. Incompatible combinations of mode and method are corrected. Labels and edit field captions are set depending on mode/method calling private procedure `rbsetfields`. Then the grids for probing are updated calling `UpdateGridParams`: the grid dimension are numbers like $2^N + 1$ in order to successively refine the grid during execution. Finally `UpdateApertures` is called to calculate the available apertures to be used for testing on particle loss. Depending on if the **Element apertures** field is checked or not, these are either defined by the element apertures or by values set in the `Ax,Ay` fields. Depending on the selected mode, `UpdateApertures` calls `tracklib>Acc_dpp` to calculate the momentum dependent horizontal and vertical apertures, or `tracklib>Initdpp` and `Silhouette` to calculate the transverse aperture for the set momentum offset as it appears at the trackpoint (in linear transformation). Finally `MakePlot` plots the yet empty apertures.

dpp offset/range → `eddpaction` performs the same steps to calculate the transverse aperture at the set momentum offset or the momentum dependent apertures, depending on the mode. If the periodic solution is not found for the given momentum offset, an error message is launched and the offset is set to zero.

Nturs → `edturns(KeyPress,Exit)` takes the given number of turns.

TrackPoint → `esposaction` should set the track point anywhere but was never implemented because it was not needed yet. However, this option is used in `opatrackps` and `opatracktt`, so it could be implemented here too.

In BS mode panel `PanNray` is visible:

Number of rays → `butnrclick` reacts to the `+-` buttons to step up or down the number of rays for binary search calling `UpdateGridParams` and shows it in label `labnr`.

Resolution → `edreso(KeyPress,Exit)` just reads the required resolution when to stop the binary search.

In GP and FF mode panel `PanGrid` is visible:

Cells... → `bugNgClick` reacts to the `+-` buttons to step up or down the number of grid points calling `UpdateGridParams` and shows it in the labels. The meaning of the two lines in the panel depends on the selected mode; captions are set when clicking the mode/method radio buttons. In case of the 3-d mode is checked, if the number of momentum slices agrees with the number of points used for calculating the momentum dependent physical apertures, and if this is not the case, the latter is recalculated again, because both tracked and physical apertures at same momentum values are required if results are to be used later in `opatracktt`.

Element Apertures → `cbxAperClick` switches between using element apertures or set apertures as given in the `eda(x,y)` fields to calculate the physical acceptance calling `UpdateApertures`.

Ax,Ay → `eda(x,y)(KeyPress,Exit)` read the apertures, which are assumed to be at all elements, and calculates the physical acceptance based on these values.

plot style → `butplotStyleClick` toggles between a simple and a nicer plot style for the DA result.

Start → `butStartClick` starts tracking by calling procedure `DATracking`: it first changes the button caption to **Stop** and its `Tag` to 1, so pressing the button again will abort tracking. Then, depending on the method, either the rays for BS method or the grid for GP and FF method are set up calling `DARaySetup` or `DAGridSetup`. Depending on the mode the coordinates (variables `ko...`) to be plotted are assigned (1, 2, 3, 5 corresponding to $x, x', y, \Delta p/p$). Different tracking procedures are used depending on mode and method. They all make use of `DASingleTracking`, which also marks the particles by green or red symbols in the plot if they survived or not.

`DATrackingClassicGrid` for GP method addresses the grid cells as stored in array `dagord`, which was established by `DAGridSetup`. The idea behind is too start with a coarse probing and refine it iteratively in order to quickly get an impression if DA is good or bad.

`DATrackingBinRays` for BS method performs a binary search along the rays established by `DARaySetup` by increasing or decreasing the relative coordinate along the ray depending on survival or loss, where in case of loss the decrement is halved until it becomes smaller than the given resolution.

`DATrackingFillToolGrid` for the FF method is an implementation of the flood fill algorithm from computer graphics, written by Bernard Riemann [17]: it finds the separatrix between stable and unstable regions by checking if adjacent pixels have different results for loss and survival. Inside the stable areas no further testing is done, inside the unstable areas all particles are tested, which is fast, because they usually get lost quickly. Particles results are saved in an array `queue` of class `TIndexQueue` which contains its own methods for

management.

The 3-d FF scan for momentum dependent separatrix in horizontal phase space requires pre- and postprocessing: arrays and variables named `Flo...` defined in `tracklib` contain parameters of the separatrix polygons for the momentum slices. Procedure `FloPinit` sets them up before tracking, and procedure `FloPoly`, called after tracking each slice, finds a polygon approximating the separatrix, i.e. the boundary between stable and unstable pixels, centered at the closed orbit. These polygons are overplotted to the grid for each slice. After termination all polygons are shown together with color changing from blue to red indicating the momentum. The polygon data are saved and may be re-used for Fast Touschek Tracking by `opatracktt`.

The `MakePlot` procedure shows a variety of DA-plots depending on mode, method and status. The code may be understandable without further comment. The only complication is the flag `MonitorXXP` introduced to show results during 3-d scan in a different way than after termination.

`--> EPS` → `butExportClick` exports the current plot as `.eps` file.

`Exit` → `Exit` saves the user settings and closes the GUI.

10.3 Touschek lifetime

`opatracktt`

Touschek lifetime is calculated from bunch volume and momentum acceptance (MA). The MA is the minimum of the linear MA given by the beam pipe apertures, of the RF-MA which is derived from input parameters or has been calculated previously by `opabucket`, and of the dynamic MA obtained from tracking and binary search for min./max. stable momentum offset. The bunch volume is calculated from the periodic optics solution with its emittance and energy spread.

The GUI has two plot windows, `fig` to show parameters along the lattice, to be selected by the radio buttons in the `rgshow` group, and `flofig` to show the 3-d $(x, x', \Delta p/p)$ acceptance if it has been previously calculated by `opatrackda`. There are two panels `panin` and `panot`, one for manual input values and the other one for derived values, like a spreadsheet. However, the input for emittance coupling is disabled if the lattice contains coupling to generate vertical emittance, and the inputs for cavity voltage and harmonic number are disabled if a previous call to `opabucket` provides values for RF-MA and bunch length.

Lifetime, or actually the MA, can be calculated in two modes: In both modes a binary search for the maximum/minimum momentum of a test particle started on axis is performed, and the starting position is stepped up along the lattice at a given spatial resolution. In the classical mode (`Track`), a given number of turns is tracked to check if the particle survives. In the new Fast Touschek Tracking (FTT) mode [17] (`Track fast`) the particles are only tracked to the end of the lattice and tested to be within the 3-d acceptance from `opatrackda`. **There is a draft implementation of a third mode (`Track sync`) including a primitive model of synchrotron oscillation, but it is incomplete and very slow. For 6-d Touschek tracking other**

codes like **Tracy-3** in batch mode are more suitable.

Gas lifetime is calculated too, Coulomb lifetime (elastic scattering) from the effective acceptance, **however this includes only the physical, not the dynamic aperture limits.** Bremsstrahlung (inelastic scattering) uses the negative MA as used for Touschek lifetime anyway.

Uses: `tracklib`, `linoplib`, `globlib` `mathlib`, `comfigureframe`, `comvgraphlib`, `comauxlib`

Public procedures

Start sets plot window `flofig` to visible and reduces the size of the main plot `fig` correspondingly, if there are data for the 3-d acceptance (flag `status.FloPoly`). Then it reads user settings and fills the input fields with these values. All labels and edit fields are created dynamically and thus not visible in the IDE. If coupling and bucket data are available, the corresponding input fields are disabled and only passively show the existing values (flags `status.uncoupled`, `.rfaccept`).

Periodic solution is calculated. It has to exist, otherwise launching the GUI would be blocked in `opamenu`). An array of data for plotting apertures is established. `tracklib` is told to use element apertures for tracking, and the MA is set to include RF-MA by default (can be changed by checkbox `chkRFL`).

Procedure **Output** is called to set up to do a complete calculation of linear lifetime, i.e. lifetime based on apertures and linear beam dynamics. It calls procedure **CalcBeta**, which performs following steps: 1. it defines plot parameters. 2. It calls **InitSigma** to create typed array `tsig` to keep all position dependent data like beta function, MA, loss rate etc. Beta functions are already known and written into this array. 3. It calls **CalcMAlin** to calculate the linear physical lattice MA from the apertures and the local $\mathcal{H}$ -function [3]. 4. It calls **CalcAccEL** to calculate the relevant acceptances for elastic scattering lifetime [3].

After these initialization, **Output** calculates the derived values: it first converts the input values to SI-units. If the lattice contains coupling, emittances are taken over from the periodic solution, if not, they are calculated from the input value for coupling. If coupling is zero, it is set to 0.1% and a warning message pops up. If RF-MA and bunchlength were calculated by `opabucket`, the values are taken over, if not, they are calculated from the input values for voltage and harmonic number. In both cases the synchrotron tune is calculated in linear approximation from the main voltage only. Then the bunch volume is calculated from betas, emittance and bunch length (**CalcSigma**). Linear Touschek lifetime is calculated from the minimum of the linear MA (as given by the apertures) and the RF-MA (**CalcLifetime**), if the check box **RF limit** is checked, otherwise RF-MA is ignored. Gas lifetime and total lifetime are calculated as described above. Finally the derived values are written to the output fields after conversion from SI to convenient units.

Actions

(input fields) → `edin_Action` is used by all input fields. Values are checked for consistency and corrected if needed, then procedure `Output` is called with different flags depending on the input to only calculate derived values which are affected by this input. At start (see above) `Output` calculates all.

(radio buttons) → `rbClicked` creates the selected plot calling `MakePlot`. If 3-d acceptance data are available, the 3-d volume is plotted by `FloFigPlot`.

(form resize) → `ResizeAll` performs a dynamic resize of the GUI and its components. If 3-d acceptance data are available, space is left for a plot to show them and the main plot window is reduced in size.

Track, Track fast, Track sync → `but(t,t_F,t_S)Click` start the three tracking procedures. They all call `beforeTracking` and `afterTrackin` before and after tracking to disable or enable buttons and show the MA plot during execution. First and third mode call `TrackMAdyn` without and with synchrotron oscillation to get the local MA from tracking (`TrackLat`) and binary search for momentum (`Trackdbins`). Whenever momentum changes, `tracklib>TrackingMatrix` is called to concatenate linear elements to speed up tracking. `TrackLat` uses `tracklib>OneTurn` to calculate a number of turns and check for Loss. In the third mode, the particle momentum is varied using a primitive model of synchrotron oscillation (**not recommended, because momentum change in every turn makes it very slow.**)

The second mode calls `TrackMA_FTT`: it loops over a given momentum range, sets up the tracking matrices (`tracklib>TrackingMatrix`), tracks particles from all positions to the end of the lattice (`tracklib>TrackToEnd`) and checks loss at the 3-d acceptance voume (`checkFloP`). For details see [17].

During execution, the ongoing search for min/max local MA is shown in the MA plot. After termination, the dynamic MA thus found is shown together with the linear MA and the RF-MA, and the dynamic lifetime is calculated.

Break → `butBreakClick` aborts the tracking.

(zoom buttons) → `butPlot[V]ZoomClick` are used to zoom into the main plot.

Exp data → `butFileClick` writes data to a text file (**never used**).

EPS → `butPSClick` exports the currently set plot (main window only) to an `eps` file.

Exit → `Exit` saves user settings and closes the GUI.

10.4 Calculations

tracklib

This unit contains procedures to prepare for tracking, to do the tracking and for postprocessing of tracking data. OPA tracking is 4-d treating particle momentum as a constant (adiabatic approximation). **Implementation of a 6-d mode including synchrotron motion has been started but was never completed.**

Uses: `linoplib`, `elemplib`, `globlib` `mathlib`

Public constants, types and variables

Base for all tracking calculations is the array `TMat` of record `TrackMatrixType`, where each element contains a transfer matrix and a thin non-linear kick representing the lattice. The matrix is a concatenation of all linear elements between non-linear kicks, this may range from a simple drift space inside a thick sextupole to a whole straight section. The non-linear kick may be a multipole or a kicker. *There is also a vector to concatenate misalignments, but not yet well debugged.*

Arrays `data1,2` and `FFT1,2` keep tracking data and Fourier spectra.

Array `geodpp` of `geodpp_type` keeps optics parameters of the momentum dependent periodic solution.

Variables named `FloP...` keep parameters of the 3-d acceptance calculated by `opatrackda` and used by `opatracktt`.

Other variables, mostly of elementary type, keep temporary data and control flags.

Public procedures

`TrackInit` allocates arrays for signal processing and checks if data for synchrotron oscillation are available.

`Initdpp` gets the periodic solution for given momentum calling `linoplib>ClosedOrbit,Periodic` and calls `Acceptances` to get the physical acceptance. Then it calls `TrackingMatrix` to set up the `TMat` array and `TrackPoint` to set the track point.

`Acceptances` calculates the optics element by element and checks the available stay clear based on local aperture and orbit. From beta function and dispersion follows the maximum betatron amplitude, which is then transformed to the track point to provide the physical acceptance. If the flag `elaper` is set, element apertures are used, else apertures entered into the GUI override them (used for example to check the true DA independent from physical limits).

`Ampkappa` does the same but divides the available betatron amplitudes to horizontal and vertical depending on coupling [3] in order to plot the physical acceptance in the (x, y) -plane (used by `Silhouette` in `opatrackda`).

`Acc_dpp` gets periodic solutions and calls `Acceptances` for a range of momentum values and saves data in the `geodpp`-array.

`TrackingMatrix` concatenates all linear elements into one matrix, until it reaches a non-linear kick, and saves the matrix and the kick parameters. This gives an alternative lattice representation suitable for fast tracking. One turn may start/end at any location, even inside an element. This is needed for Touschek tracking in `opatracktt`. In `opatrackps` the track point may be set anywhere on purpose too. Internal procedures named `...Cut` handle cut thick elements properly. Internal procedure `appendTMat` appends another element (matrix

+ kick) to the **TMat**-array.

TrackPoint gets the optical parameters at any location in the lattice, even inside an element. For this purpose it contains a short-cut version of **elemlib>MCC_prop**, the most general propagation through an element which may also include coupling. It uses the **TMat**-array which starts/ends at the specified lattice position.

TMatKick uses the **TMat**-array to propagate a particle by multiplication with the matrix and applying the thin non-linear kick. Particle loss is checked at the kick **only** by comparing particle amplitude to kick element aperture. Time of flight is summed up using the length of the lattice section corresponding to the concatenated matrix for correct modeling of kicker magnets.

OneTurn tracks one turn using **TMatKick** and returns **true** if the particle was lost.

(**OneTurn_S** was an attempt to implement synchrotron oscillation but not completed.)

The procedures in the last third of the unit are for signal processing, to calculate the FFT, interpolate frequencies and guess the related resonances, to be used by **opatrackps**:

savePStrackData saves particle data for postprocessing.

SineWindow multiplies data with a half sine window to interpolate frequencies.

TwoFFT,FOUR1,FFTtoAmpFTmax perform the fast Fourier transformation [14] and turn the complex spectrum into amplitudes.

FindPeaks together with its little helper procedures performs frequency interpolation based on the sine window.

ResoGuess,GuessRes try to identify the resonances driving the observed frequencies [18].

11 Magnet currents

11.1 Magnet currents

opacurrents

This GUI was made for exporting lattice data to the EPICS control system of the SLS¹: Magnet strengths are converted to power supply currents and local current gradients taking into account the nonlinearity of the magnets due to saturation. Furthermore the elements of 2×2 matrices for shifting tunes and chromaticities as calculated by **otunematrix** and **opachroma** are exported.

Data are exported to an EPICS **.snap** file which is rather SLS-specific, however features like current calculation may be of general interest. In order to do so, additional files for magnet allocations, listing the magnet types of lattice elements, and for calibration, listing the coefficients of the characteristic hysteresis curve, have to be provided (see unit **latfilelib**). Coefficients are explained in the comments section of procedure **getKfromI**. Example files for SLS are provided with this document as **sls_currents.zip**.

¹The first SLS, operating 2000-2023

Uses: `globlib`, `mathlib`, `comauxlib`

Public procedures

`Start` already performs all current calculations: The used elements in the `Ella` should have an entry in the namelist field (see page 9) telling about the magnet type. Using the corresponding calibration, procedures `getIfromK` and `getdIdKfac` calculate the current and the attenuation factor at this current, i.e. the relative reduction of the hysteresis slope. This is performed by a root finder iterating on the reverse function `getKfromI`. Polarity is also taken into account. Power supplies are then listed with number of connected magnets and current in the left table `cgrid`.

Actions

(left table) → `cgridSelectCell` shows the individual magnets of the clicked power supply in the right table `pgrid`.

SNAP export → `busnapSLSClick` writes the EPICS `.snap` file: name of lattice file, beam energy, nominal tunes and chromaticities, and matrices for moving tunes and chromaticities. Then follows a list of X-ray source points with their beta functions (one implemented for pin hole beam size measurements) and finally the list of magnets with current and attenuation factor for current variation.

11.2 Test procedures

`testcode`

This unit is for temporarily needed procedures or for testing new stuff, which then, if it works well, is moved to another place. Habitually, procedures are called when clicking items in brackets in the **Extra** pulldown menu of `opamenu`.

Uses: may vary depending on what to be tested.

Public procedures

Procedures are public in order to call them from `opamenu`.

References

- [1] OPA Tutorial, <https://andreas-streun.de/opa/tutorial2.pdf>
- [2] OPA userguide, <https://andreas-streun.de/opa/opa4.pdf>
- [3] Inside OPA, <https://andreas-streun.de/opa/inside.pdf>

- [4] Semantic versioning, <https://semver.org/>
- [5] G. Slabaugh, Computing Euler angles from a rotation matrix,
<https://eecs.qmul.ac.uk/~gslabaugh/publications/euler.pdf>.
- [6] V. Ziemann and A. Streun, Equilibrium parameters in coupled storage ring lattices and practical applications, Phys. Rev. Accel. Beams, 25, 050703, 2022,
<https://link.aps.org/doi/10.1103/PhysRevAccelBeams.25.050703>.
- [7] K. Wille, Physik der Teilchenbeschleuniger und Synchrotronstrahlungsquellen, 1996.
- [8] D. Edward and L.Teng, *Parametrization of linear coupled motion in periodic systems*, IEEE Trans.Nucl.Sci. 20, 885 (1973),
<https://ab-abp-rlc.web.cern.ch/AP-literature/Edwards-Teng-1973.pdf>.
- [9] D. Sagan, D. Rubin, *Linear Analysis of coupled lattices*, Physical Review Special Topics–Accelerators and Beams 2 (1999) 074001,
<https://doi.org/10.1103/PhysRevSTAB.2.074001>.
- [10] A. Streun, A non-linear bunch compression scheme for SwissFEL,
<https://andreas-streun.de/phys/nlbuco.pdf>
- [11] J. Bengtsson, The sextupole scheme for the SLS, SLS-Note 9/97,
<https://ados.web.psi.ch/slsnotes/sls0997.pdf>.
- [12] Chun-xi Wang, Explicit formulas for 2nd-order driving terms due to sextupoles and chromatic effects of quadrupoles, ANL/APS/LS-330, 2012,
https://www.aps.anl.gov/files/APS-sync/lsnotes/files/APS_1429490.pdf.
- [13] S. C. Leemann and A. Streun, Perspectives for future light source lattices incorporating yet uncommon magnets, Phys. ST Rev. Accel. Beams, 14, 030701, 2011
<https://doi.org/10.1103/PhysRevSTAB.14.030701>.
- [14] W. H. Press et al., Numerical Recipes in Pascal, Cambridge 1989.
- [15] P. Bourke, CONREC, a contouring subroutine,
<https://paulbourke.net/papers/conrec/>.
- [16] Rosetta Code, Arithmetic Evaluation,
https://rosettacode.org/wiki/Arithmetic_Evaluator/Pascal.
- [17] B. Riemann, M. Aiba, J. Kallestrup, A. Streun, Efficient algorithms for dynamic aperture and momentum acceptance calculation in synchrotron light sources, Phys. Rev. Accel. Beams, 27, 094002, 2024, <https://doi.org/10.1103/PhysRevAccelBeams.27.094002>.
- [18] J. Bengtsson, Non-linear transverse dynamics, CERN-88-05.