

Mission Autonomy L1 Compliance Document

For

A-GRA

6.0a

31 July 2026

Revision History

Version	Description	Release Date
5.0a	Initial Public ASK 5.0a Release	21 APR 2026
6.0a	ASK 6.0a Release	31 JUL 2026

Table of Contents

1	Mission Autonomy L1 Compliance Introduction	71
2	Mission Autonomy L1 Compliance Requirements	72
2.1	C2 Interface Compliance Requirements	72
2.2	Mission Debrief Compliance Requirements	72
2.3	Mission Plan Interface Compliance Requirements	72
2.4	Mission Systems Interface Compliance Requirements	73
2.5	OMS Compliance Requirements	74
2.6	Peer Interface Compliance Requirements	74
2.7	Vehicle Interface Compliance Requirements	75
3	Mission Autonomy L1 Minimum Message Set	75
3.1	C2 MMS	75
3.2	MP MMS	87
3.3	MS MMS	91
3.4	Peer MMS	97
3.5	VI MMS	108
4	Mission Autonomy L1 UCI 2.3 Extension Set	110
4.1	C2 Interface	110
4.1.1	MA_FlightCapabilityMT UCI Extension	110
4.1.2	MA_FlightCommandMT UCI Extension	116
4.1.3	MA_FlightCommandStatusMT UCI Extension	124
4.1.4	MA_FlightActivityMT UCI Extension	125
4.1.5	MA_OpVolumeMT UCI Extension	128
4.1.6	MA_TaskMT UCI Extension	130
4.1.7	MA_MissionPlanActivationCommandStatusMT UCI Extension	135
4.1.8	MA_MissionPlanMT UCI Extension	137
4.1.9	MA_PositionReportMT UCI Extension	138
4.1.10	MA_TaskPlanMT UCI Extension	139
4.1.11	MA_PackagePartnerStatusReportMT UCI Extension	140
4.1.12	MA_ApprovalRequestMT UCI Extension	141
4.1.13	MA_ResponseActivityMT UCI Extension	145
4.1.14	MA_PackageManagementCommandMT UCI Extension	149
4.1.15	MA_PackageManagementCommandStatusMT UCI Extension	151

4.1.16	MA_ApprovalRequestStatusMT UCI Extension	152
4.1.17	MA_TaskCommandStatusMT UCI Extension	153
4.1.18	MA_MissionPlanExecutionStatusMT UCI Extension	154
4.1.19	MA_StrikeCapabilityMT UCI Extension	155
4.1.20	MA_LeadershipMetricsMT UCI Extension	156
4.1.21	MA_WEZ_MT UCI Extension	157
4.1.22	MA_TaskCommandMT UCI Extension	163
4.1.23	MA_OpZoneMT UCI Extension	164
4.1.24	MA_NavigationReportMT UCI Extension	193
4.1.25	MA_AcceptableLevelOfRiskCommandMT UCI Extension	194
4.1.26	MA_ConstraintPriorityListActivationDataMT UCI Extension	195
4.1.27	MA_ConstraintPriorityListCommandMT UCI Extension	195
4.1.28	MA_ConstraintPriorityListMT UCI Extension	196
4.1.29	MA_ExecutionPriorityListActivationDataMT UCI Extension	197
4.1.30	MA_ExecutionPriorityListCommandMT UCI Extension	197
4.1.31	MA_ExecutionPriorityListMT UCI Extension	198
4.1.32	MA_IgnoreConstraintCommandMT UCI Extension	199
4.1.33	MA_EngagementCriteriaCommandMT UCI Extension	199
4.1.34	MA_EngagementCriteriaMT UCI Extension	200
4.1.35	MA_AcceptableLevelOfRiskCommandStatusMT UCI Extension	201
4.1.36	MA_ConstraintPriorityListActivationStatusMT UCI Extension	202
4.1.37	MA_ConstraintPriorityListCommandStatusMT UCI Extension	203
4.1.38	MA_ExecutionPriorityListActivationStatusMT UCI Extension	203
4.1.39	MA_ExecutionPriorityListCommandStatusMT UCI Extension	204
4.1.40	MA_IgnoreConstraintCommandStatusMT UCI Extension	205
4.1.41	MA_EngagementCriteriaStatusMT UCI Extension	206
4.1.42	MA_EngagementCriteriaCommandStatusMT UCI Extension	206
4.1.43	MA_SystemNotificationMT UCI Extension	207
4.1.44	MA_EffectCapabilityMT UCI Extension	209
4.1.45	MA_ActionCapabilityMT UCI Extension	210
4.1.46	MA_AMTI_CapabilityMT UCI Extension	213
4.1.47	MA_SystemManagementRequestMT UCI Extension	215
4.1.48	MA_SystemManagementRequestStatusMT UCI Extension	218

4.1.49	MA_RoutePlanMT UCI Extension	218
4.1.50	MA_ActionMT UCI Extension	219
4.1.51	MA_COP_ConfigurationSettingsCommandStatusMT UCI Extension	221
4.1.52	MA_COP_ConfigurationSettingsRequestStatusMT UCI Extension	221
4.1.53	MA_COP_ConfigurationSettingsCommandMT UCI Extension	222
4.1.54	MA_COP_ConfigurationSettingsRequestMT UCI Extension	223
4.1.55	MA_DesignationRequestMT UCI Extension	224
4.1.56	MA_DesignationMT UCI Extension	224
4.1.57	MA_DesignationRequestStatusMT UCI Extension	225
4.1.58	MA_AcceptableLevelOfRiskStatusMT UCI Extension	225
4.1.59	MA_CapabilitySetMT UCI Extension	226
4.1.60	MA_CAP_ExecutionStatusReportMT UCI Extension	227
4.1.61	MA_SystemsNeededRequestMT UCI Extension	227
4.1.62	MA_SystemsNeededRequestStatusMT UCI Extension	228
4.1.63	MA_MissionPlanActivationCommandMT UCI Extension	229
4.1.64	MA_ApprovalAuthorityMT UCI Extension	233
4.1.65	MA_ResponseMT UCI Extension	234
4.1.66	MA_ActionPlanMT UCI Extension	236
4.1.67	MA_ActivityPlanMT UCI Extension	237
4.1.68	MA_RouteActivityPlanMT UCI Extension	238
4.1.69	MA_AssessmentRequestMT UCI Extension	238
4.1.70	MA_AssessmentRequestStatusMT UCI Extension	240
4.1.71	MA_AssessmentMT UCI Extension	242
4.1.72	MA_FlightCapabilityStatusMT UCI Extension	244
4.1.73	MA_COP_ConfigurationSettingsMT UCI Extension	245
4.1.74	MA_StrikeActivityMT UCI Extension	246
4.1.75	MA_OperatorRoleMT UCI Extension	250
4.1.76	MA_OpPlanMT UCI Extension	251
4.1.77	MA_OpStatusMT UCI Extension	252
4.1.78	MA_OpCommandMT UCI Extension	252
4.1.79	MA_InteroperabilityPolicyMT UCI Extension	253
4.1.80	MA_AuthorizationMT UCI Extension	254
4.1.81	MA_OpCommandStatusMT UCI Extension	271

4.1.82	MA_ApprovalPolicyMT UCI Extension	272
4.1.83	MA_ActionCommandMT UCI Extension	287
4.1.84	MA_ActionCommandStatusMT UCI Extension	299
4.1.85	MA_MissionPlanActivationStatusMT UCI Extension	300
4.1.86	MA_ActionStatusMT UCI Extension	302
4.1.87	MA_CarrierReportMT UCI Extension	306
4.1.88	MA_CarrierStateMT UCI Extension	310
4.1.89	MA_PositionReportDetailedMT UCI Extension	314
4.1.90	MA_PrioritizationListMT UCI Extension	315
4.1.91	MA_ResponsePlanCommandStatusMT UCI Extension	318
4.1.92	MA_ResponsePlanCommandMT UCI Extension	321
4.1.93	MA_PlanningFunctionSettingsCommandMT UCI Extension	322
4.1.94	MA_PlanningFunctionSettingsCommandStatusMT UCI Extension	332
4.1.95	MA_OpLineMT UCI Extension	332
4.1.96	MA_MissionPlanCommandMT UCI Extension	335
4.1.97	MA_MissionPlanCommandStatusMT UCI Extension	347
4.1.98	MA_PlanningFunctionStatusMT UCI Extension	351
4.1.99	MA_OpPointMT UCI Extension	368
4.1.100	MA_OpRoutingMT UCI Extension	370
4.1.101	MA_PlanningFunctionMT UCI Extension	372
4.1.102	MA_TaskStatusMT UCI Extension	386
4.1.103	MA_PlanModificationRequestMT UCI Extension	390
4.1.104	MA_PlanModificationRequestStatusMT UCI Extension	395
4.1.105	MA_MessageAcknowledgmentConfigurationRequestMT UCI Extension	395
4.1.106	MA_MessageAcknowledgmentConfigurationMT UCI Extension	396
4.1.107	MA_MessageAcknowledgmentConfigurationRequestStatusMT UCI Extension	397
4.1.108	MA_ResponseCommandMT UCI Extension	398
4.1.109	MA_ResponseCommandStatusMT UCI Extension	398
4.1.110	MA_PlatformOverrideCommandStatusMT UCI Extension	399
4.1.111	MA_PlatformOverrideCommandMT UCI Extension	400
4.1.112	MA_GatewayActivityMT UCI Extension	401
4.1.113	MA_DataDisseminationPlanOverrideRequestMT UCI Extension	402
4.1.114	MA_DataDisseminationPlanOverrideRequestStatusMT UCI Extension	402

4.1.115	MA_DataDisseminationPlanMT UCI Extension	403
4.1.116	MA_DataDisseminationPlanActivationCommandMT UCI Extension	405
4.1.117	MA_DataDisseminationPlanActivationCommandStatusMT UCI Extension	406
4.1.118	MA_DataDisseminationPlanActivationStatusMT UCI Extension	407
4.1.119	MA_PlatformOverrideStatusMT UCI Extension	407
4.2	Peer Interface	409
4.2.1	MA_WEZ_MT UCI Extension	409
4.2.2	MA_COP_ConfigurationSettingsRequestStatusMT UCI Extension.....	415
4.2.3	MA_COP_ConfigurationSettingsRequestMT UCI Extension.....	416
4.2.4	MA_SystemNotificationMT UCI Extension	417
4.2.5	MA_COP_ConfigurationSettingsCommandMT UCI Extension	419
4.2.6	MA_EngagementCriteriaCommandStatusMT UCI Extension	420
4.2.7	MA_EngagementCriteriaCommandMT UCI Extension.....	420
4.2.8	MA_COP_ConfigurationSettingsCommandStatusMT UCI Extension	421
4.2.9	MA_DesignationRequestStatusMT UCI Extension.....	422
4.2.10	MA_EngagementCriteriaStatusMT UCI Extension.....	423
4.2.11	MA_AcceptableLevelOfRiskStatusMT UCI Extension.....	423
4.2.12	MA_DesignationRequestMT UCI Extension	424
4.2.13	MA_RaftVoteRequestMT UCI Extension	425
4.2.14	MA_RaftVoteRequestStatusMT UCI Extension	425
4.2.15	MA_RaftAppendEntriesRequestMT UCI Extension	426
4.2.16	MA_RaftAppendEntriesRequestStatusMT UCI Extension	427
4.2.17	MA_CAP_ExecutionStatusReportMT UCI Extension.....	428
4.2.18	MA_MissionPlanMT UCI Extension	429
4.2.19	MA_ActionPlanMT UCI Extension	430
4.2.20	MA_TaskPlanMT UCI Extension.....	431
4.2.21	MA_RoutePlanMT UCI Extension.....	431
4.2.22	MA_ActivityPlanMT UCI Extension	432
4.2.23	MA_RouteActivityPlanMT UCI Extension.....	433
4.2.24	MA_ActionMT UCI Extension.....	434
4.2.25	MA_ResponseMT UCI Extension	435
4.2.26	MA_OpVolumeMT UCI Extension.....	437
4.2.27	MA_ApprovalAuthorityMT UCI Extension	438

4.2.28	MA_CapabilitySetMT UCI Extension.....	439
4.2.29	MA_MissionPlanActivationCommandStatusMT UCI Extension	440
4.2.30	MA_MissionPlanExecutionStatusMT UCI Extension	442
4.2.31	MA_ConstraintPriorityListActivationStatusMT UCI Extension	443
4.2.32	MA_ConstraintPriorityListCommandMT UCI Extension	444
4.2.33	MA_ConstraintPriorityListCommandStatusMT UCI Extension	444
4.2.34	MA_EscortCommandMT UCI Extension	445
4.2.35	MA_EscortCommandStatusMT UCI Extension	446
4.2.36	MA_ExecutionPriorityListActivationStatusMT UCI Extension.....	447
4.2.37	MA_ExecutionPriorityListCommandMT UCI Extension.....	447
4.2.38	MA_ExecutionPriorityListCommandStatusMT UCI Extension.....	448
4.2.39	MA_FlightActivityMT UCI Extension.....	449
4.2.40	MA_FlightCommandMT UCI Extension	452
4.2.41	MA_FlightCommandStatusMT UCI Extension	459
4.2.42	MA_IgnoreConstraintCommandMT UCI Extension.....	461
4.2.43	MA_IgnoreConstraintCommandStatusMT UCI Extension.....	462
4.2.44	MA_LeaderUpdateRequestMT UCI Extension.....	463
4.2.45	MA_LeaderUpdateRequestStatusMT UCI Extension	463
4.2.46	MA_AcceptableLevelOfRiskCommandMT UCI Extension	464
4.2.47	MA_AcceptableLevelOfRiskCommandStatusMT UCI Extension	465
4.2.48	MA_MissionPlanActivationCommandMT UCI Extension	466
4.2.49	MA_OpZoneMT UCI Extension.....	470
4.2.50	MA_PositionReportMT UCI Extension	499
4.2.51	MA_PackageManagementCommandMT UCI Extension	500
4.2.52	MA_PackageManagementCommandStatusMT UCI Extension	502
4.2.53	MA_PackagePartnerStatusReportMT UCI Extension	503
4.2.54	MA_SystemManagementRequestMT UCI Extension.....	504
4.2.55	MA_SystemManagementRequestStatusMT UCI Extension	506
4.2.56	MA_AMTI_CapabilityMT UCI Extension	507
4.2.57	MA_ActionCapabilityMT UCI Extension	509
4.2.58	MA_ApprovalRequestMT UCI Extension	512
4.2.59	MA_ApprovalRequestStatusMT UCI Extension	516
4.2.60	MA_EffectCapabilityMT UCI Extension.....	517

4.2.61	MA_FlightCapabilityMT UCI Extension	518
4.2.62	MA_FlightCapabilityStatusMT UCI Extension	524
4.2.63	MA_TaskMT UCI Extension	526
4.2.64	MA_NavigationReportMT UCI Extension	531
4.2.65	MA_StrikeActivityMT UCI Extension	532
4.2.66	MA_StrikeCapabilityMT UCI Extension	536
4.2.67	MA_TaskCommandMT UCI Extension	537
4.2.68	MA_TaskCommandStatusMT UCI Extension	538
4.2.69	MA_COP_ConfigurationSettingsMT UCI Extension	539
4.2.70	MA_OpCommandMT UCI Extension	539
4.2.71	MA_OpCommandStatusMT UCI Extension	540
4.2.72	MA_DeconflictionSolutionRequestStatusMT UCI Extension	541
4.2.73	MA_OpPlanMT UCI Extension	541
4.2.74	MA_RouteDeconflictionAlertMT UCI Extension	542
4.2.75	MA_OpStatusMT UCI Extension	543
4.2.76	MA_DeconflictionSolutionRequestMT UCI Extension	543
4.2.77	MA_PrioritizationListMT UCI Extension	544
4.2.78	MA_MissionPlanActivationStatusMT UCI Extension	547
4.2.79	MA_ActionCommandMT UCI Extension	549
4.2.80	MA_ActionCommandStatusMT UCI Extension	562
4.2.81	MA_ActionStatusMT UCI Extension	563
4.2.82	MA_AssessmentMT UCI Extension	566
4.2.83	MA_AssessmentRequestMT UCI Extension	568
4.2.84	MA_AssessmentRequestStatusMT UCI Extension	570
4.2.85	MA_OperatorRoleMT UCI Extension	571
4.2.86	MA_ActionPlanValidationMT UCI Extension	572
4.2.87	MA_ApprovalPolicyMT UCI Extension	575
4.2.88	MA_OpLineMT UCI Extension	591
4.2.89	MA_OpPointMT UCI Extension	594
4.2.90	MA_OpRoutingMT UCI Extension	596
4.2.91	MA_PlanningFunctionSettingsCommandMT UCI Extension	597
4.2.92	MA_PlanningFunctionSettingsCommandStatusMT UCI Extension	607
4.2.93	MA_ResponseActivityMT UCI Extension	608

4.2.94	MA_TaskStatusMT UCI Extension.....	612
4.2.95	MA_PlanModificationRequestMT UCI Extension	616
4.2.96	MA_PlanModificationRequestStatusMT UCI Extension	621
4.2.97	MA_ConstraintPriorityListActivationDataMT UCI Extension.....	621
4.2.98	MA_ConstraintPriorityListMT UCI Extension.....	622
4.2.99	MA_EscortActivityMT UCI Extension	623
4.2.100	MA_PositionReportDetailedMT UCI Extension	623
4.2.101	MA_EngagementCriteriaMT UCI Extension.....	625
4.2.102	MA_ExecutionPriorityListMT UCI Extension	626
4.2.103	MA_ExecutionPriorityListActivationDataMT UCI Extension	627
4.2.104	MA_MessageAcknowledgmentConfigurationMT UCI Extension.....	627
4.2.105	MA_MessageAcknowledgmentConfigurationRequestMT UCI Extension	628
4.2.106	MA_MessageAcknowledgmentConfigurationRequestStatusMT UCI Extension	629
4.2.107	MA_ResponseCommandMT UCI Extension	630
4.2.108	MA_ResponseCommandStatusMT UCI Extension	630
4.2.109	MA_PlatformOverrideStatusMT UCI Extension	631
4.2.110	MA_GatewayActivityMT UCI Extension	632
4.2.111	MA_DataDisseminationPlanOverrideRequestMT UCI Extension	633
4.2.112	MA_DataDisseminationPlanOverrideRequestStatusMT UCI Extension	634
4.2.113	MA_DataDisseminationPlanActivationCommandStatusMT UCI Extension	635
4.2.114	MA_DataDisseminationPlanActivationCommandMT UCI Extension	636
4.2.115	MA_DataDisseminationPlanMT UCI Extension	636
4.2.116	MA_DataDisseminationPlanActivationStatusMT UCI Extension.....	638
4.3	Mission Plan Interface	639
4.3.1	MA_EffectCapabilityMT UCI Extension	639
4.3.2	MA_EntityMT UCI Extension	640
4.3.3	MA_ActionCapabilityMT UCI Extension	644
4.3.4	MA_ActionMT UCI Extension	646
4.3.5	MA_ActionPlanMT UCI Extension.....	648
4.3.6	MA_ActivityPlanMT UCI Extension	649
4.3.7	MA_AMTI_CapabilityMT UCI Extension.....	650
4.3.8	MA_ApprovalAuthorityMT UCI Extension.....	652
4.3.9	MA_ApprovalPolicyMT UCI Extension	653

4.3.10	MA_AssessmentMT UCI Extension	668
4.3.11	MA_AuthorizationMT UCI Extension.....	670
4.3.12	MA_CapabilitySetMT UCI Extension.....	687
4.3.13	MA_CarrierReportMT UCI Extension	687
4.3.14	MA_CarrierStateMT UCI Extension	692
4.3.15	MA_ConstraintPriorityListActivationDataMT UCI Extension.....	695
4.3.16	MA_ConstraintPriorityListMT UCI Extension.....	696
4.3.17	MA_DesignationMT UCI Extension.....	696
4.3.18	MA_ExecutionPriorityListActivationDataMT UCI Extension	697
4.3.19	MA_ExecutionPriorityListMT UCI Extension	698
4.3.20	MA_FlightCapabilityMT UCI Extension	698
4.3.21	MA_InteroperabilityPolicyMT UCI Extension.....	704
4.3.22	MA_LeadershipMetricsMT UCI Extension	705
4.3.23	MA_MissionPlanMT UCI Extension	706
4.3.24	MA_OperatorRoleMT UCI Extension	707
4.3.25	MA_OpLineMT UCI Extension	708
4.3.26	MA_OpPlanMT UCI Extension.....	710
4.3.27	MA_OpPointMT UCI Extension.....	711
4.3.28	MA_OpRoutingMT UCI Extension	713
4.3.29	MA_OpVolumeMT UCI Extension.....	715
4.3.30	MA_OpZoneMT UCI Extension.....	716
4.3.31	MA_PlanningFunctionMT UCI Extension	745
4.3.32	MA_PrioritizationListMT UCI Extension	760
4.3.33	MA_ResponseMT UCI Extension	763
4.3.34	MA_RouteActivityPlanMT UCI Extension.....	765
4.3.35	MA_RoutePlanMT UCI Extension	766
4.3.36	MA_EngagementCriteriaMT UCI Extension	766
4.3.37	MA_StrikeCapabilityMT UCI Extension.....	767
4.3.38	MA_TaskMT UCI Extension	768
4.3.39	MA_TaskPlanMT UCI Extension.....	774
4.3.40	MA_WEZ_MT UCI Extension.....	775
4.3.41	MA_ResponsePlanMT UCI Extension	781
4.4	Mission Systems Interface.....	782

4.4.1	MA_StrikeCapabilityMT UCI Extension	782
4.4.2	MA_CommErrorReportMT UCI Extension.....	783
4.4.3	MA_PositionReportDetailedMT UCI Extension	784
4.4.4	MA_CommAvailableEndpointsMT UCI Extension	786
4.4.5	MA_CommTeamReportMT UCI Extension	788
4.4.6	MA_TaskMT UCI Extension	789
4.4.7	MA_TaskStatusMT UCI Extension	794
4.4.8	MA_TaskCommandStatusMT UCI Extension.....	798
4.4.9	MA_TaskCommandMT UCI Extension.....	799
4.4.10	MA_ActivityPlanMT UCI Extension	799
4.4.11	MA_MessagingSubscriptionSettingCommandMT UCI Extension	800
4.4.12	MA_RoutePlanMT UCI Extension	804
4.4.13	MA_TaskPlanMT UCI Extension.....	804
4.4.14	MA_TxDataPayloadCommandMT UCI Extension.....	805
4.4.15	MA_WEZ_RequestMT UCI Extension	807
4.4.16	MA_RouteActivityPlanMT UCI Extension.....	814
4.4.17	MA_FaultMT UCI Extension.....	815
4.4.18	MA_MessagingSubscriptionSettingCommandStatusMT UCI Extension	817
4.4.19	MA_RxDataPayloadMT UCI Extension.....	818
4.4.20	MA_TxDataPayloadCommandStatusMT UCI Extension.....	819
4.4.21	MA_WEZ_MT UCI Extension.....	820
4.4.22	MA_WEZ_RequestStatusMT UCI Extension	826
4.4.23	MA_StrikeActivityMT UCI Extension	833
4.4.24	MA_AMTI_CapabilityMT UCI Extension	838
4.4.25	MA_MessagingSubscriptionStatusMT UCI Extension	840
4.4.26	MA_MissionPlanValidationCommandMT UCI Extension	840
4.4.27	MA_MissionPlanValidationCommandStatusMT UCI Extension	853
4.4.28	MA_SystemNotificationMT UCI Extension	854
4.4.29	MA_EntityMT UCI Extension.....	857
4.4.30	MA_GatewayActivityMT UCI Extension	860
4.4.31	MA_GatewayCommandMT UCI Extension	861
4.4.32	MA_GatewayCommandStatusMT UCI Extension	862
4.4.33	MA_DataDisseminationPlanOverrideRequestMT UCI Extension	862

4.4.34	MA_DataDisseminationPlanOverrideRequestStatusMT UCI Extension	863
4.4.35	MA_DataDisseminationPlanActivationCommandMT UCI Extension	864
4.4.36	MA_DataDisseminationPlanActivationCommandStatusMT UCI Extension	865
4.4.37	MA_DataDisseminationPlanActivationStatusMT UCI Extension	866
4.4.38	MA_DataDisseminationPlanMT UCI Extension	866
4.5	Vehicle Interface	868
4.5.1	MA_FlightCapabilityMT UCI Extension	868
4.5.2	MA_FlightCommandMT UCI Extension.....	874
4.5.3	MA_FlightCommandStatusMT UCI Extension.....	882
4.5.4	MA_FlightActivityMT UCI Extension.....	884
4.5.5	MA_PositionReportDetailedMT UCI Extension	886
4.5.6	MA_NavigationReportMT UCI Extension	888
4.5.7	MA_FaultMT UCI Extension.....	889
4.5.8	MA_TaskMT UCI Extension	891
4.5.9	MA_RoutePlanMT UCI Extension	897
4.5.10	MA_SystemManagementRequestMT UCI Extension.....	897
4.5.11	MA_SystemManagementRequestStatusMT UCI Extension	900
4.5.12	MA_MissionPlanActivationCommandMT UCI Extension	900
4.5.13	MA_MissionPlanActivationCommandStatusMT UCI Extension	905
4.5.14	MA_FlightCapabilityStatusMT UCI Extension	907
4.5.15	MA_SystemNotificationMT UCI Extension	908
4.5.16	MA_TaskStatusMT UCI Extension.....	910
4.5.17	MA_ResponseMT UCI Extension	914
4.5.18	MA_MissionPlanExecutionStatusMT UCI Extension	916
4.5.19	MA_MissionPlanActivationStatusMT UCI Extension.....	917
4.5.20	MA_TaskCommandStatusMT UCI Extension	919
4.5.21	MA_TaskCommandMT UCI Extension	920
4.5.22	MA_ActionStatusMT UCI Extension	920
4.5.23	MA_PositionReportMT UCI Extension	924
4.5.24	MA_CarrierReportMT UCI Extension.....	925
4.5.25	MA_CarrierLaunchReadyStatusMT UCI Extension	929
4.5.26	MA_CarrierDeckHandlingCommandMT UCI Extension	930
4.5.27	MA_CarrierDeckHandlingCommandStatusMT UCI Extension.....	930

Table of Figures

No table of figures entries found.

Table of Tables

Table 2-1: C2 Interface Compliance Requirements	72
Table 2-2: Mission Debrief Compliance Requirements	72
Table 2-3: Mission Plan Interface Compliance Requirements.....	72
Table 2-4: Mission Systems Interface Compliance Requirements	73
Table 2-5: OMS Compliance Requirements.....	74
Table 2-6: Peer Interface Compliance Requirements	74
Table 2-7: Vehicle Interface Compliance Requirements	75
Table 3-1: C2 MMS	75
Table 3-2: MP MMS	87
Table 3-3: MS MMS	91
Table 3-4: Peer MMS	97
Table 3-5: VI MMS	108
Table A-4-1: C2 Interface MA_FlightCapabilityMT UCI Extension	110
Table A-4-2: C2 Interface MA_FlightCapabilityMT - HSA_CSA_PerformanceProfile UCI Extension Field	112
Table A-4-3: C2 Interface MA_FlightCapabilityMT - WaypointFollowingPerformanceProfile UCI Extension Field	113
Table A-4-4: C2 Interface MA_FlightCapabilityMT - CurveFollowingPerformanceProfile UCI Extension Field	114
Table A-4-5: C2 Interface MA_FlightCapabilityMT - AccelerationLimit UCI Extension Field	114
Table A-4-6: C2 Interface MA_FlightCapabilityMT - AccelerationLimitValue UCI Extension Field....	115
Table A-4-7: C2 Interface MA_FlightCapabilityMT - BodyReferenceOrientationRate UCI Extension Field	115
Table A-4-8: C2 Interface MA_FlightCapabilityMT - OrientationRateLimits UCI Extension Field	116
Table A-4-9: C2 Interface MA_FlightCapabilityMT - AirspeedPair UCI Extension Field.....	116
Table A-4-10: C2 Interface MA_FlightCommandMT UCI Extension	117
Table A-4-11: C2 Interface MA_FlightCommandMT - Command UCI Extension Field	117
Table A-4-12: C2 Interface MA_FlightCommandMT - Capability UCI Extension Field.....	118
Table A-4-13: C2 Interface MA_FlightCommandMT - HSA_CSA UCI Extension Field.....	119
Table A-4-14: C2 Interface MA_FlightCommandMT - WaypointFollowing UCI Extension Field	119
Table A-4-15: C2 Interface MA_FlightCommandMT - CurveFollowing UCI Extension Field.....	119
Table A-4-16: C2 Interface MA_FlightCommandMT - Speed UCI Extension Field	120
Table A-4-17: C2 Interface MA_FlightCommandMT - Heading UCI Extension Field	120

Table A-4-18: C2 Interface MA_FlightCommandMT - SpeedChoice UCI Extension Field	120
Table A-4-19: C2 Interface MA_FlightCommandMT - SpeedValue UCI Extension Field	121
Table A-4-20: C2 Interface MA_FlightCommandMT - CurveFitMethod UCI Extension Field	121
Table A-4-21: C2 Interface MA_FlightCommandMT - Reference UCI Extension Field	121
Table A-4-22: C2 Interface MA_FlightCommandMT - ControlPoint UCI Extension Field	122
Table A-4-23: C2 Interface MA_FlightCommandMT - RelativeAcceleration UCI Extension Field	122
Table A-4-24: C2 Interface MA_FlightCommandMT - RelativeVelocity UCI Extension Field	123
Table A-4-25: C2 Interface MA_FlightCommandMT - OrientationRate UCI Extension Field	123
Table A-4-26: C2 Interface MA_FlightCommandMT - Direction UCI Extension Field	123
Table A-4-27: C2 Interface MA_FlightCommandMT - Course UCI Extension Field	124
Table A-4-28: C2 Interface MA_FlightCommandStatusMT UCI Extension	124
Table A-4-29: C2 Interface MA_FlightCommandStatusMT - MessageData UCI Extension Field	124
Table A-4-30: C2 Interface MA_FlightCommandStatusMT - CannotComplyDetails UCI Extension Field	125
Table A-4-31: C2 Interface MA_FlightCommandStatusMT - Severity UCI Extension Field	125
Table A-4-32: C2 Interface MA_FlightActivityMT UCI Extension	126
Table A-4-33: C2 Interface MA_FlightActivityMT - VehicleCommandState UCI Extension Field	126
Table A-4-34: C2 Interface MA_FlightActivityMT - Activity UCI Extension Field	127
Table A-4-35: C2 Interface MA_FlightActivityMT - Speed UCI Extension Field	128
Table A-4-36: C2 Interface MA_FlightActivityMT - Heading UCI Extension Field	128
Table A-4-37: C2 Interface MA_OpVolumeMT UCI Extension	128
Table A-4-38: C2 Interface MA_OpVolumeMT - MessageData UCI Extension Field	129
Table A-4-39: C2 Interface MA_TaskMT UCI Extension	130
Table A-4-40: C2 Interface MA_TaskMT - TaskType UCI Extension Field	132
Table A-4-41: C2 Interface MA_TaskMT - TaskPlurality UCI Extension Field	132
Table A-4-42: C2 Interface MA_TaskMT - ConstraintID UCI Extension Field	132
Table A-4-43: C2 Interface MA_TaskMT - HSA_CSA UCI Extension Field	133
Table A-4-44: C2 Interface MA_TaskMT - WaypointFollowing UCI Extension Field	133
Table A-4-45: C2 Interface MA_TaskMT - CurveFollowing UCI Extension Field	133
Table A-4-46: C2 Interface MA_TaskMT - Speed UCI Extension Field	134
Table A-4-47: C2 Interface MA_TaskMT - Heading UCI Extension Field	134
Table A-4-48: C2 Interface MA_TaskMT - SpeedChoice UCI Extension Field	134
Table A-4-49: C2 Interface MA_TaskMT - SpeedValue UCI Extension Field	135

Table A-4-50: C2 Interface MA_TaskMT - CurveFitMethod UCI Extension Field	135
Table A-4-51: C2 Interface MA_MissionPlanActivationCommandStatusMT UCI Extension	135
Table A-4-52: C2 Interface MA_MissionPlanActivationCommandStatusMT - Plans UCI Extension Field	136
Table A-4-53: C2 Interface MA_MissionPlanActivationCommandStatusMT - MessageData UCI Extension Field	136
Table A-4-54: C2 Interface MA_MissionPlanActivationCommandStatusMT - ActivationCommandByState UCI Extension Field	137
Table A-4-55: C2 Interface MA_MissionPlanMT UCI Extension	137
Table A-4-56: C2 Interface MA_MissionPlanMT - MessageData UCI Extension Field	138
Table A-4-57: C2 Interface MA_PositionReportMT UCI Extension	138
Table A-4-58: C2 Interface MA_PositionReportMT - MessageData UCI Extension Field	139
Table A-4-59: C2 Interface MA_TaskPlanMT UCI Extension.....	139
Table A-4-60: C2 Interface MA_TaskPlanMT - MessageData UCI Extension Field.....	140
Table A-4-61: C2 Interface MA_PackagePartnerStatusReportMT UCI Extension	140
Table A-4-62: C2 Interface MA_PackagePartnerStatusReportMT - MessageData UCI Extension Field	141
Table A-4-63: C2 Interface MA_ApprovalRequestMT UCI Extension	141
Table A-4-64: C2 Interface MA_ApprovalRequestMT - ActivationDetails UCI Extension Field.....	141
Table A-4-65: C2 Interface MA_ApprovalRequestMT - OpPlanID UCI Extension Field.....	142
Table A-4-66: C2 Interface MA_ApprovalRequestMT - MissionPlanActivationApproval UCI Extension Field	142
Table A-4-67: C2 Interface MA_ApprovalRequestMT - ApprovalReferences UCI Extension Field...	142
Table A-4-68: C2 Interface MA_ApprovalRequestMT - ApprovalItem UCI Extension Field	143
Table A-4-69: C2 Interface MA_ApprovalRequestMT - ByExecutionPlanSet UCI Extension Field...	143
Table A-4-70: C2 Interface MA_ApprovalRequestMT - MessageData UCI Extension Field	144
Table A-4-71: C2 Interface MA_ApprovalRequestMT - BySubPlan UCI Extension Field	145
Table A-4-72: C2 Interface MA_ApprovalRequestMT - OpPlan UCI Extension Field	145
Table A-4-73: C2 Interface MA_ResponseActivityMT UCI Extension	145
Table A-4-74: C2 Interface MA_ResponseActivityMT - RequirementInstantiation UCI Extension Field	146
Table A-4-75: C2 Interface MA_ResponseActivityMT - ActivatedPlans UCI Extension Field	146
Table A-4-76: C2 Interface MA_ResponseActivityMT - Activity UCI Extension Field.....	148
Table A-4-77: C2 Interface MA_ResponseActivityMT - MessageData UCI Extension Field	148
Table A-4-78: C2 Interface MA_ResponseActivityMT - ResultingPlans UCI Extension Field	149

Table A-4-79: C2 Interface MA_ResponseActivityMT - OpPlanID UCI Extension Field.....	149
Table A-4-80: C2 Interface MA_PackageManagementCommandMT UCI Extension	150
Table A-4-81: C2 Interface MA_PackageManagementCommandMT - MessageData UCI Extension Field	151
Table A-4-82: C2 Interface MA_PackageManagementCommandStatusMT UCI Extension	151
Table A-4-83: C2 Interface MA_PackageManagementCommandStatusMT - MessageData UCI Extension Field	152
Table A-4-84: C2 Interface MA_ApprovalRequestStatusMT UCI Extension	152
Table A-4-85: C2 Interface MA_ApprovalRequestStatusMT - MessageData UCI Extension Field ...	153
Table A-4-86: C2 Interface MA_TaskCommandStatusMT UCI Extension	153
Table A-4-87: C2 Interface MA_TaskCommandStatusMT - MessageData UCI Extension Field	154
Table A-4-88: C2 Interface MA_MissionPlanExecutionStatusMT UCI Extension	154
Table A-4-89: C2 Interface MA_MissionPlanExecutionStatusMT - ExecutionPlanSetStatus UCI Extension Field	154
Table A-4-90: C2 Interface MA_MissionPlanExecutionStatusMT - PlanExecutionStatus UCI Extension Field	155
Table A-4-91: C2 Interface MA_MissionPlanExecutionStatusMT - MessageData UCI Extension Field	155
Table A-4-92: C2 Interface MA_StrikeCapabilityMT UCI Extension.....	155
Table A-4-93: C2 Interface MA_StrikeCapabilityMT - MessageData UCI Extension Field.....	156
Table A-4-94: C2 Interface MA_LeadershipMetricsMT UCI Extension	156
Table A-4-95: C2 Interface MA_LeadershipMetricsMT - MessageData UCI Extension Field	157
Table A-4-96: C2 Interface MA_WEZ_MT UCI Extension	157
Table A-4-97: C2 Interface MA_WEZ_MT - MessageData UCI Extension Field.....	158
Table A-4-98: C2 Interface MA_WEZ_MT - WEZ_ID UCI Extension Field	158
Table A-4-99: C2 Interface MA_WEZ_MT - WEZ_Data UCI Extension Field	160
Table A-4-100: C2 Interface MA_WEZ_MT - RangeTurnAndClose UCI Extension Field	160
Table A-4-101: C2 Interface MA_WEZ_MT - RangeMinimum UCI Extension Field.....	161
Table A-4-102: C2 Interface MA_WEZ_MT - RangeTurnAndRun UCI Extension Field.....	161
Table A-4-103: C2 Interface MA_WEZ_MT - RangeProbabilityOfIntercept UCI Extension Field.....	162
Table A-4-104: C2 Interface MA_WEZ_MT - RangeMaxGuidance UCI Extension Field	162
Table A-4-105: C2 Interface MA_WEZ_MT - RangeOptimal UCI Extension Field.....	163
Table A-4-106: C2 Interface MA_WEZ_MT - RangeMaxAero UCI Extension Field.....	163
Table A-4-107: C2 Interface MA_TaskCommandMT UCI Extension	163
Table A-4-108: C2 Interface MA_TaskCommandMT - MessageData UCI Extension Field	164

Table A-4-109: C2 Interface MA_OpZoneMT UCI Extension.....	165
Table A-4-110: C2 Interface MA_OpZoneMT - MessageData UCI Extension Field.....	166
Table A-4-111: C2 Interface MA_OpZoneMT - Category UCI Extension Field	168
Table A-4-112: C2 Interface MA_OpZoneMT - CategoryUniqueData UCI Extension Field	169
Table A-4-113: C2 Interface MA_OpZoneMT - SpeedLimits UCI Extension Field	169
Table A-4-114: C2 Interface MA_OpZoneMT - VehicleConfiguration UCI Extension Field.....	170
Table A-4-115: C2 Interface MA_OpZoneMT - Zone UCI Extension Field	170
Table A-4-116: C2 Interface MA_OpZoneMT - GeometryReference UCI Extension Field	171
Table A-4-117: C2 Interface MA_OpZoneMT - ReferenceObjectsFilter UCI Extension Field	172
Table A-4-118: C2 Interface MA_OpZoneMT - OpPointFilter UCI Extension Field.....	172
Table A-4-119: C2 Interface MA_OpZoneMT - OpLineFilter UCI Extension Field	172
Table A-4-120: C2 Interface MA_OpZoneMT - OpLineCategory UCI Extension Field.....	173
Table A-4-121: C2 Interface MA_OpZoneMT - OpZoneFilter UCI Extension Field.....	174
Table A-4-122: C2 Interface MA_OpZoneMT - OpZoneCategory UCI Extension Field	176
Table A-4-123: C2 Interface MA_OpZoneMT - OpVolumeFilter UCI Extension Field.....	176
Table A-4-124: C2 Interface MA_OpZoneMT - OpVolumeCategory UCI Extension Field	179
Table A-4-125: C2 Interface MA_OpZoneMT - DMPI_Filter UCI Extension Field.....	179
Table A-4-126: C2 Interface MA_OpZoneMT - SignalReportFilter UCI Extension Field	179
Table A-4-127: C2 Interface MA_OpZoneMT - OpVolumeFilter UCI Extension Field.....	180
Table A-4-128: C2 Interface MA_OpZoneMT - OpLineFilter UCI Extension Field	180
Table A-4-129: C2 Interface MA_OpZoneMT - OpLineCategory UCI Extension Field.....	181
Table A-4-130: C2 Interface MA_OpZoneMT - SpeedLimits UCI Extension Field	182
Table A-4-131: C2 Interface MA_OpZoneMT - SignalReportFilter UCI Extension Field	182
Table A-4-132: C2 Interface MA_OpZoneMT - OpPointFilter UCI Extension Field.....	183
Table A-4-133: C2 Interface MA_OpZoneMT - VehicleConfiguration UCI Extension Field.....	183
Table A-4-134: C2 Interface MA_OpZoneMT - DMPI_Filter UCI Extension Field.....	184
Table A-4-135: C2 Interface MA_OpZoneMT - Zone UCI Extension Field	184
Table A-4-136: C2 Interface MA_OpZoneMT - Category UCI Extension Field	186
Table A-4-137: C2 Interface MA_OpZoneMT - CategoryUniqueData UCI Extension Field	187
Table A-4-138: C2 Interface MA_OpZoneMT - ReferenceObjectsFilter UCI Extension Field	188
Table A-4-139: C2 Interface MA_OpZoneMT - OpVolumeCategory UCI Extension Field	190
Table A-4-140: C2 Interface MA_OpZoneMT - GeometryReference UCI Extension Field	190
Table A-4-141: C2 Interface MA_OpZoneMT - OpZoneCategory UCI Extension Field	192

Table A-4-142: C2 Interface MA_OpZoneMT - OpZoneFilter UCI Extension Field	193
Table A-4-143: C2 Interface MA_NavigationReportMT UCI Extension	193
Table A-4-144: C2 Interface MA_NavigationReportMT - MessageData UCI Extension Field	194
Table A-4-145: C2 Interface MA_AcceptableLevelOfRiskCommandMT UCI Extension	194
Table A-4-146: C2 Interface MA_AcceptableLevelOfRiskCommandMT - MessageData UCI Extension Field	195
Table A-4-147: C2 Interface MA_ConstraintPriorityListActivationDataMT UCI Extension	195
Table A-4-148: C2 Interface MA_ConstraintPriorityListActivationDataMT - MessageData UCI Extension Field	195
Table A-4-149: C2 Interface MA_ConstraintPriorityListCommandMT UCI Extension	195
Table A-4-150: C2 Interface MA_ConstraintPriorityListCommandMT - MessageData UCI Extension Field	196
Table A-4-151: C2 Interface MA_ConstraintPriorityListMT UCI Extension	196
Table A-4-152: C2 Interface MA_ConstraintPriorityListMT - MessageData UCI Extension Field	197
Table A-4-153: C2 Interface MA_ExecutionPriorityListActivationDataMT UCI Extension	197
Table A-4-154: C2 Interface MA_ExecutionPriorityListActivationDataMT - MessageData UCI Extension Field	197
Table A-4-155: C2 Interface MA_ExecutionPriorityListCommandMT UCI Extension	197
Table A-4-156: C2 Interface MA_ExecutionPriorityListCommandMT - MessageData UCI Extension Field	198
Table A-4-157: C2 Interface MA_ExecutionPriorityListMT UCI Extension	198
Table A-4-158: C2 Interface MA_ExecutionPriorityListMT - MessageData UCI Extension Field	198
Table A-4-159: C2 Interface MA_IgnoreConstraintCommandMT UCI Extension	199
Table A-4-160: C2 Interface MA_IgnoreConstraintCommandMT - MessageData UCI Extension Field	199
Table A-4-161: C2 Interface MA_EngagementCriteriaCommandMT UCI Extension	199
Table A-4-162: C2 Interface MA_EngagementCriteriaCommandMT - MessageData UCI Extension Field	200
Table A-4-163: C2 Interface MA_EngagementCriteriaMT UCI Extension	200
Table A-4-164: C2 Interface MA_EngagementCriteriaMT - MessageData UCI Extension Field	201
Table A-4-165: C2 Interface MA_AcceptableLevelOfRiskCommandStatusMT UCI Extension	201
Table A-4-166: C2 Interface MA_AcceptableLevelOfRiskCommandStatusMT - MessageData UCI Extension Field	202
Table A-4-167: C2 Interface MA_ConstraintPriorityListActivationStatusMT UCI Extension	202
Table A-4-168: C2 Interface MA_ConstraintPriorityListActivationStatusMT - MessageData UCI Extension Field	203

Table A-4-169: C2 Interface MA_ConstraintPriorityListCommandStatusMT UCI Extension	203
Table A-4-170: C2 Interface MA_ConstraintPriorityListCommandStatusMT - MessageData UCI Extension Field	203
Table A-4-171: C2 Interface MA_ExecutionPriorityListActivationStatusMT UCI Extension	204
Table A-4-172: C2 Interface MA_ExecutionPriorityListActivationStatusMT - MessageData UCI Extension Field	204
Table A-4-173: C2 Interface MA_ExecutionPriorityListCommandStatusMT UCI Extension	204
Table A-4-174: C2 Interface MA_ExecutionPriorityListCommandStatusMT - MessageData UCI Extension Field	205
Table A-4-175: C2 Interface MA_IgnoreConstraintCommandStatusMT UCI Extension	205
Table A-4-176: C2 Interface MA_IgnoreConstraintCommandStatusMT - MessageData UCI Extension Field	206
Table A-4-177: C2 Interface MA_EngagementCriteriaStatusMT UCI Extension.....	206
Table A-4-178: C2 Interface MA_EngagementCriteriaStatusMT - MessageData UCI Extension Field	206
Table A-4-179: C2 Interface MA_EngagementCriteriaCommandStatusMT UCI Extension	206
Table A-4-180: C2 Interface MA_EngagementCriteriaCommandStatusMT - MessageData UCI Extension Field	207
Table A-4-181: C2 Interface MA_SystemNotificationMT UCI Extension	207
Table A-4-182: C2 Interface MA_SystemNotificationMT - MessageData UCI Extension Field	208
Table A-4-183: C2 Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field	209
Table A-4-184: C2 Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field	209
Table A-4-185: C2 Interface MA_EffectCapabilityMT UCI Extension.....	209
Table A-4-186: C2 Interface MA_EffectCapabilityMT - AssociatedTaskType UCI Extension Field...	210
Table A-4-187: C2 Interface MA_ActionCapabilityMT UCI Extension.....	211
Table A-4-188: C2 Interface MA_ActionCapabilityMT - AssociatedTaskType UCI Extension Field..	212
Table A-4-189: C2 Interface MA_ActionCapabilityMT - Capability UCI Extension Field	213
Table A-4-190: C2 Interface MA_ActionCapabilityMT - MessageData UCI Extension Field	213
Table A-4-191: C2 Interface MA_AMTI_CapabilityMT UCI Extension	213
Table A-4-192: C2 Interface MA_AMTI_CapabilityMT - MessageData UCI Extension Field	214
Table A-4-193: C2 Interface MA_AMTI_CapabilityMT - Capability UCI Extension Field.....	215
Table A-4-194: C2 Interface MA_SystemManagementRequestMT UCI Extension	216
Table A-4-195: C2 Interface MA_SystemManagementRequestMT - MessageData UCI Extension Field	216
Table A-4-196: C2 Interface MA_SystemManagementRequestMT - RequestType UCI Extension Field	217

Table A-4-197: C2 Interface MA_SystemManagementRequestMT - VehicleSettings UCI Extension Field	218
Table A-4-198: C2 Interface MA_SystemManagementRequestStatusMT UCI Extension	218
Table A-4-199: C2 Interface MA_SystemManagementRequestStatusMT - MessageData UCI Extension Field	218
Table A-4-200: C2 Interface MA_RoutePlanMT UCI Extension	219
Table A-4-201: C2 Interface MA_RoutePlanMT - MessageData UCI Extension Field	219
Table A-4-202: C2 Interface MA_ActionMT UCI Extension	219
Table A-4-203: C2 Interface MA_ActionMT - MessageData UCI Extension Field	221
Table A-4-204: C2 Interface MA_COP_ConfigurationSettingsCommandStatusMT UCI Extension ..	221
Table A-4-205: C2 Interface MA_COP_ConfigurationSettingsCommandStatusMT - MessageData UCI Extension Field	221
Table A-4-206: C2 Interface MA_COP_ConfigurationSettingsRequestStatusMT UCI Extension	222
Table A-4-207: C2 Interface MA_COP_ConfigurationSettingsRequestStatusMT - MessageData UCI Extension Field	222
Table A-4-208: C2 Interface MA_COP_ConfigurationSettingsCommandMT UCI Extension	222
Table A-4-209: C2 Interface MA_COP_ConfigurationSettingsCommandMT - MessageData UCI Extension Field	223
Table A-4-210: C2 Interface MA_COP_ConfigurationSettingsRequestMT UCI Extension	223
Table A-4-211: C2 Interface MA_COP_ConfigurationSettingsRequestMT - MessageData UCI Extension Field	224
Table A-4-212: C2 Interface MA_DesignationRequestMT UCI Extension	224
Table A-4-213: C2 Interface MA_DesignationRequestMT - MessageData UCI Extension Field	224
Table A-4-214: C2 Interface MA_DesignationMT UCI Extension	224
Table A-4-215: C2 Interface MA_DesignationMT - MessageData UCI Extension Field	225
Table A-4-216: C2 Interface MA_DesignationRequestStatusMT UCI Extension	225
Table A-4-217: C2 Interface MA_DesignationRequestStatusMT - MessageData UCI Extension Field	225
Table A-4-218: C2 Interface MA_AcceptableLevelOfRiskStatusMT UCI Extension	225
Table A-4-219: C2 Interface MA_AcceptableLevelOfRiskStatusMT - MessageData UCI Extension Field	226
Table A-4-220: C2 Interface MA_CapabilitySetMT UCI Extension	226
Table A-4-221: C2 Interface MA_CapabilitySetMT - MessageData UCI Extension Field	227
Table A-4-222: C2 Interface MA_CAP_ExecutionStatusReportMT UCI Extension	227
Table A-4-223: C2 Interface MA_CAP_ExecutionStatusReportMT - MessageData UCI Extension Field	227

Table A-4-224: C2 Interface MA_SystemsNeededRequestMT UCI Extension	228
Table A-4-225: C2 Interface MA_SystemsNeededRequestMT - MessageData UCI Extension Field	228
Table A-4-226: C2 Interface MA_SystemsNeededRequestStatusMT UCI Extension	228
Table A-4-227: C2 Interface MA_SystemsNeededRequestStatusMT - MessageData UCI Extension Field	229
Table A-4-228: C2 Interface MA_MissionPlanActivationCommandMT UCI Extension	229
Table A-4-229: C2 Interface MA_MissionPlanActivationCommandMT - OpPlanID UCI Extension Field	230
Table A-4-230: C2 Interface MA_MissionPlanActivationCommandMT - ApplicableToIDs UCI Extension Field	230
Table A-4-231: C2 Interface MA_MissionPlanActivationCommandMT - ByExecutionPlanSet UCI Extension Field	231
Table A-4-232: C2 Interface MA_MissionPlanActivationCommandMT - MessageData UCI Extension Field	231
Table A-4-233: C2 Interface MA_MissionPlanActivationCommandMT - ActivationDetails UCI Extension Field	232
Table A-4-234: C2 Interface MA_MissionPlanActivationCommandMT - Applicability UCI Extension Field	233
Table A-4-235: C2 Interface MA_MissionPlanActivationCommandMT - OpPlan UCI Extension Field	233
Table A-4-236: C2 Interface MA_MissionPlanActivationCommandMT - Command UCI Extension Field	233
Table A-4-237: C2 Interface MA_ApprovalAuthorityMT UCI Extension	234
Table A-4-238: C2 Interface MA_ApprovalAuthorityMT - MessageData UCI Extension Field	234
Table A-4-239: C2 Interface MA_ApprovalAuthorityMT - ApplicableIDs UCI Extension Field	234
Table A-4-240: C2 Interface MA_ResponseMT UCI Extension	235
Table A-4-241: C2 Interface MA_ResponseMT - MessageData UCI Extension Field	236
Table A-4-242: C2 Interface MA_ActionPlanMT UCI Extension	236
Table A-4-243: C2 Interface MA_ActionPlanMT - MessageData UCI Extension Field	237
Table A-4-244: C2 Interface MA_ActivityPlanMT UCI Extension	237
Table A-4-245: C2 Interface MA_ActivityPlanMT - MessageData UCI Extension Field	237
Table A-4-246: C2 Interface MA_RouteActivityPlanMT UCI Extension	238
Table A-4-247: C2 Interface MA_RouteActivityPlanMT - MessageData UCI Extension Field	238
Table A-4-248: C2 Interface MA_AssessmentRequestMT UCI Extension	239
Table A-4-249: C2 Interface MA_AssessmentRequestMT - MessageData UCI Extension Field	239

Table A-4-250: C2 Interface MA_AssessmentRequestMT - Category UCI Extension Field	240
Table A-4-251: C2 Interface MA_AssessmentRequestStatusMT UCI Extension.....	241
Table A-4-252: C2 Interface MA_AssessmentRequestStatusMT - Assessment UCI Extension Field	241
Table A-4-253: C2 Interface MA_AssessmentRequestStatusMT - MessageData UCI Extension Field	242
Table A-4-254: C2 Interface MA_AssessmentMT UCI Extension	242
Table A-4-255: C2 Interface MA_AssessmentMT - MessageData UCI Extension Field	243
Table A-4-256: C2 Interface MA_AssessmentMT - Assessment UCI Extension Field.....	244
Table A-4-257: C2 Interface MA_FlightCapabilityStatusMT UCI Extension	244
Table A-4-258: C2 Interface MA_FlightCapabilityStatusMT - Capability UCI Extension Field	245
Table A-4-259: C2 Interface MA_FlightCapabilityStatusMT - MessageData UCI Extension Field	245
Table A-4-260: C2 Interface MA_COP_ConfigurationSettingsMT UCI Extension.....	245
Table A-4-261: C2 Interface MA_COP_ConfigurationSettingsMT - MessageData UCI Extension Field	246
Table A-4-262: C2 Interface MA_StrikeActivityMT UCI Extension	246
Table A-4-263: C2 Interface MA_StrikeActivityMT - ActiveWeaponHSA_CSA UCI Extension Field	247
Table A-4-264: C2 Interface MA_StrikeActivityMT - Direction UCI Extension Field	247
Table A-4-265: C2 Interface MA_StrikeActivityMT - MunitionActive UCI Extension Field	247
Table A-4-266: C2 Interface MA_StrikeActivityMT - MessageData UCI Extension Field	248
Table A-4-267: C2 Interface MA_StrikeActivityMT - ActiveWeaponState UCI Extension Field.....	248
Table A-4-268: C2 Interface MA_StrikeActivityMT - Activity UCI Extension Field.....	250
Table A-4-269: C2 Interface MA_StrikeActivityMT - Course UCI Extension Field.....	250
Table A-4-270: C2 Interface MA_StrikeActivityMT - Heading UCI Extension Field	250
Table A-4-271: C2 Interface MA_StrikeActivityMT - Reference UCI Extension Field.....	250
Table A-4-272: C2 Interface MA_OperatorRoleMT UCI Extension	251
Table A-4-273: C2 Interface MA_OperatorRoleMT - SystemID UCI Extension Field.....	251
Table A-4-274: C2 Interface MA_OpPlanMT UCI Extension	251
Table A-4-275: C2 Interface MA_OpPlanMT - MessageData UCI Extension Field.....	252
Table A-4-276: C2 Interface MA_OpStatusMT UCI Extension.....	252
Table A-4-277: C2 Interface MA_OpStatusMT - MessageData UCI Extension Field.....	252
Table A-4-278: C2 Interface MA_OpCommandMT UCI Extension	253
Table A-4-279: C2 Interface MA_OpCommandMT - MessageData UCI Extension Field	253
Table A-4-280: C2 Interface MA_InteroperabilityPolicyMT UCI Extension	253

Table A-4-281: C2 Interface MA_InteroperabilityPolicyMT - MessageData UCI Extension Field.....	254
Table A-4-282: C2 Interface MA_AuthorizationMT UCI Extension.....	255
Table A-4-283: C2 Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field ..	255
Table A-4-284: C2 Interface MA_AuthorizationMT - CapabilityTaxonomy UCI Extension Field	257
Table A-4-285: C2 Interface MA_AuthorizationMT - Opaque UCI Extension Field	258
Table A-4-286: C2 Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field	258
Table A-4-287: C2 Interface MA_AuthorizationMT - CapabilityCommand UCI Extension Field	259
Table A-4-288: C2 Interface MA_AuthorizationMT - CapabilitySettingTypes UCI Extension Field ...	260
Table A-4-289: C2 Interface MA_AuthorizationMT - ByDataActivation UCI Extension Field	260
Table A-4-290: C2 Interface MA_AuthorizationMT - CAP UCI Extension Field	261
Table A-4-291: C2 Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field ..	261
Table A-4-292: C2 Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field	261
Table A-4-293: C2 Interface MA_AuthorizationMT - DataTypes UCI Extension Field	262
Table A-4-294: C2 Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field	262
Table A-4-295: C2 Interface MA_AuthorizationMT - CommTerminal UCI Extension Field	262
Table A-4-296: C2 Interface MA_AuthorizationMT - ByRequirementExecution UCI Extension Field	263
Table A-4-297: C2 Interface MA_AuthorizationMT - ByDataModification UCI Extension Field	263
Table A-4-298: C2 Interface MA_AuthorizationMT - ActivityPlan UCI Extension Field	264
Table A-4-299: C2 Interface MA_AuthorizationMT - MessageData UCI Extension Field.....	265
Table A-4-300: C2 Interface MA_AuthorizationMT - AuthorizedArea UCI Extension Field	265
Table A-4-301: C2 Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field	266
Table A-4-302: C2 Interface MA_AuthorizationMT - ByPlanActivation UCI Extension Field.....	266
Table A-4-303: C2 Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field	266
Table A-4-304: C2 Interface MA_AuthorizationMT - ByPlatformSettingsModification UCI Extension Field	267
Table A-4-305: C2 Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field ..	267
Table A-4-306: C2 Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field ..	267
Table A-4-307: C2 Interface MA_AuthorizationMT - RadarAltimeter UCI Extension Field.....	268
Table A-4-308: C2 Interface MA_AuthorizationMT - RequestTypes UCI Extension Field.....	268
Table A-4-309: C2 Interface MA_AuthorizationMT - ByPlanParts UCI Extension Field	269
Table A-4-310: C2 Interface MA_AuthorizationMT - AdditionalPlatformSettingTypes UCI Extension Field	269
Table A-4-311: C2 Interface MA_AuthorizationMT - IFF UCI Extension Field	269
Table A-4-312: C2 Interface MA_AuthorizationMT - RequirementTypes UCI Extension Field	270

Table A-4-313: C2 Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field ..	270
Table A-4-314: C2 Interface MA_AuthorizationMT - UserIdentifier UCI Extension Field	270
Table A-4-315: C2 Interface MA_AuthorizationMT - ByOperatorRequest UCI Extension Field	271
Table A-4-316: C2 Interface MA_OpCommandStatusMT UCI Extension	271
Table A-4-317: C2 Interface MA_OpCommandStatusMT - MessageData UCI Extension Field	271
Table A-4-318: C2 Interface MA_ApprovalPolicyMT UCI Extension	272
Table A-4-319: C2 Interface MA_ApprovalPolicyMT - TaskPlan UCI Extension Field	272
Table A-4-320: C2 Interface MA_ApprovalPolicyMT - OpLineCategory UCI Extension Field	273
Table A-4-321: C2 Interface MA_ApprovalPolicyMT - ActivityPlan UCI Extension Field	274
Table A-4-322: C2 Interface MA_ApprovalPolicyMT - ApplicablePlanningActivity UCI Extension Field	275
Table A-4-323: C2 Interface MA_ApprovalPolicyMT - OpVolumeCategory UCI Extension Field.....	277
Table A-4-324: C2 Interface MA_ApprovalPolicyMT - TaskType UCI Extension Field	278
Table A-4-325: C2 Interface MA_ApprovalPolicyMT - OrbitActivityPlan UCI Extension Field	278
Table A-4-326: C2 Interface MA_ApprovalPolicyMT - MessageData UCI Extension Field	279
Table A-4-327: C2 Interface MA_ApprovalPolicyMT - OpZoneCategory UCI Extension Field	282
Table A-4-328: C2 Interface MA_ApprovalPolicyMT - ByPlanParts UCI Extension Field	282
Table A-4-329: C2 Interface MA_ApprovalPolicyMT - CapabilityCommand UCI Extension Field.....	283
Table A-4-330: C2 Interface MA_ApprovalPolicyMT - PlanParts UCI Extension Field	284
Table A-4-331: C2 Interface MA_ApprovalPolicyMT - Plans UCI Extension Field	285
Table A-4-332: C2 Interface MA_ApprovalPolicyMT - RouteActivityPlan UCI Extension Field	286
Table A-4-333: C2 Interface MA_ApprovalPolicyMT - OpPlan UCI Extension Field	286
Table A-4-334: C2 Interface MA_ApprovalPolicyMT - PlanActivation UCI Extension Field	287
Table A-4-335: C2 Interface MA_ActionCommandMT UCI Extension	288
Table A-4-336: C2 Interface MA_ActionCommandMT - ActionConstraintOverride UCI Extension Field	288
Table A-4-337: C2 Interface MA_ActionCommandMT - RequiredAllocation UCI Extension Field	289
Table A-4-338: C2 Interface MA_ActionCommandMT - System UCI Extension Field	289
Table A-4-339: C2 Interface MA_ActionCommandMT - PreferredAllocation UCI Extension Field....	290
Table A-4-340: C2 Interface MA_ActionCommandMT - Analytic UCI Extension Field.....	291
Table A-4-341: C2 Interface MA_ActionCommandMT - Designation UCI Extension Field	291
Table A-4-342: C2 Interface MA_ActionCommandMT - AssessedObject UCI Extension Field	291
Table A-4-343: C2 Interface MA_ActionCommandMT - Characteristics UCI Extension Field	292
Table A-4-344: C2 Interface MA_ActionCommandMT - Allocation UCI Extension Field.....	292

Table A-4-345: C2 Interface MA_ActionCommandMT - ConstraintOverride UCI Extension Field	294
Table A-4-346: C2 Interface MA_ActionCommandMT - Allocation UCI Extension Field.....	295
Table A-4-347: C2 Interface MA_ActionCommandMT - AccessAssessmentThreshold UCI Extension Field	295
Table A-4-348: C2 Interface MA_ActionCommandMT - Command UCI Extension Field.....	296
Table A-4-349: C2 Interface MA_ActionCommandMT - ExcludedRequirementTypes UCI Extension Field	297
Table A-4-350: C2 Interface MA_ActionCommandMT - Kinematic UCI Extension Field	297
Table A-4-351: C2 Interface MA_ActionCommandMT - EngagementParameters UCI Extension Field	297
Table A-4-352: C2 Interface MA_ActionCommandMT - Subject UCI Extension Field	298
Table A-4-353: C2 Interface MA_ActionCommandMT - MessageData UCI Extension Field	298
Table A-4-354: C2 Interface MA_ActionCommandMT - AllowedRequirementTypes UCI Extension Field	299
Table A-4-355: C2 Interface MA_ActionCommandMT - Entity UCI Extension Field	299
Table A-4-356: C2 Interface MA_ActionCommandStatusMT UCI Extension	299
Table A-4-357: C2 Interface MA_ActionCommandStatusMT - MessageData UCI Extension Field ..	300
Table A-4-358: C2 Interface MA_MissionPlanActivationStatusMT UCI Extension.....	300
Table A-4-359: C2 Interface MA_MissionPlanActivationStatusMT - OpPlanID UCI Extension Field	301
Table A-4-360: C2 Interface MA_MissionPlanActivationStatusMT - MessageData UCI Extension Field	301
Table A-4-361: C2 Interface MA_MissionPlanActivationStatusMT - Plans UCI Extension Field.....	302
Table A-4-362: C2 Interface MA_MissionPlanActivationStatusMT - SubPlanActivationState UCI Extension Field	302
Table A-4-363: C2 Interface MA_ActionStatusMT UCI Extension	302
Table A-4-364: C2 Interface MA_ActionStatusMT - Traceability UCI Extension Field	303
Table A-4-365: C2 Interface MA_ActionStatusMT - Plans UCI Extension Field.....	304
Table A-4-366: C2 Interface MA_ActionStatusMT - OpPlanID UCI Extension Field	304
Table A-4-367: C2 Interface MA_ActionStatusMT - MessageData UCI Extension Field	305
Table A-4-368: C2 Interface MA_ActionStatusMT - ExecutingSystemOrPackage UCI Extension Field	306
Table A-4-369: C2 Interface MA_CarrierReportMT UCI Extension.....	306
Table A-4-370: C2 Interface MA_CarrierReportMT - LaunchCoordinates UCI Extension Field	307
Table A-4-371: C2 Interface MA_CarrierReportMT - Runway UCI Extension Field	307
Table A-4-372: C2 Interface MA_CarrierReportMT - CarrierReportID UCI Extension Field.....	308

Table A-4-373: C2 Interface MA_CarrierReportMT - Direction UCI Extension Field	308
Table A-4-374: C2 Interface MA_CarrierReportMT - Catapult UCI Extension Field	308
Table A-4-375: C2 Interface MA_CarrierReportMT - Information UCI Extension Field	309
Table A-4-376: C2 Interface MA_CarrierReportMT - CatapultID UCI Extension Field	309
Table A-4-377: C2 Interface MA_CarrierReportMT - MessageData UCI Extension Field	310
Table A-4-378: C2 Interface MA_CarrierReportMT - LandingCoordinates UCI Extension Field	310
Table A-4-379: C2 Interface MA_CarrierReportMT - Direction UCI Extension Field	310
Table A-4-380: C2 Interface MA_CarrierStateMT UCI Extension	311
Table A-4-381: C2 Interface MA_CarrierStateMT - CarrierStateID UCI Extension Field	311
Table A-4-382: C2 Interface MA_CarrierStateMT - CatapultID UCI Extension Field	311
Table A-4-383: C2 Interface MA_CarrierStateMT - Catapult UCI Extension Field	312
Table A-4-384: C2 Interface MA_CarrierStateMT - Runway UCI Extension Field	312
Table A-4-385: C2 Interface MA_CarrierStateMT - Information UCI Extension Field	313
Table A-4-386: C2 Interface MA_CarrierStateMT - MessageData UCI Extension Field	314
Table A-4-387: C2 Interface MA_PositionReportDetailedMT UCI Extension	314
Table A-4-388: C2 Interface MA_PositionReportDetailedMT - PositionReportData UCI Extension Field	315
Table A-4-389: C2 Interface MA_PositionReportDetailedMT - MessageData UCI Extension Field ..	315
Table A-4-390: C2 Interface MA_PrioritizationListMT UCI Extension	316
Table A-4-391: C2 Interface MA_PrioritizationListMT - ListType UCI Extension Field	317
Table A-4-392: C2 Interface MA_PrioritizationListMT - ListItem UCI Extension Field	317
Table A-4-393: C2 Interface MA_PrioritizationListMT - MessageData UCI Extension Field	318
Table A-4-394: C2 Interface MA_ResponsePlanCommandStatusMT UCI Extension	319
Table A-4-395: C2 Interface MA_ResponsePlanCommandStatusMT - MessageData UCI Extension Field	319
Table A-4-396: C2 Interface MA_ResponsePlanCommandStatusMT - AssociatedPlans UCI Extension Field	320
Table A-4-397: C2 Interface MA_ResponsePlanCommandStatusMT - AllocationResult UCI Extension Field	321
Table A-4-398: C2 Interface MA_ResponsePlanCommandStatusMT - OpPlanID UCI Extension Field	321
Table A-4-399: C2 Interface MA_ResponsePlanCommandMT UCI Extension	321
Table A-4-400: C2 Interface MA_ResponsePlanCommandMT - MessageData UCI Extension Field	322
Table A-4-401: C2 Interface MA_PlanningFunctionSettingsCommandMT UCI Extension	323

Table A-4-402: C2 Interface MA_PlanningFunctionSettingsCommandMT - AutonomousPlanningAction UCI Extension Field	323
Table A-4-403: C2 Interface MA_PlanningFunctionSettingsCommandMT - OpPlan UCI Extension Field	324
Table A-4-404: C2 Interface MA_PlanningFunctionSettingsCommandMT - AutonomousPlanningResponseChoice UCI Extension Field	324
Table A-4-405: C2 Interface MA_PlanningFunctionSettingsCommandMT - MissionPlanningAutonomy UCI Extension Field	325
Table A-4-406: C2 Interface MA_PlanningFunctionSettingsCommandMT - OrbitActivityPlan UCI Extension Field	325
Table A-4-407: C2 Interface MA_PlanningFunctionSettingsCommandMT - RouteActivityPlan UCI Extension Field	326
Table A-4-408: C2 Interface MA_PlanningFunctionSettingsCommandMT - ByResultSetting UCI Extension Field	327
Table A-4-409: C2 Interface MA_PlanningFunctionSettingsCommandMT - PlanningAllowed UCI Extension Field	328
Table A-4-410: C2 Interface MA_PlanningFunctionSettingsCommandMT - OutputPlanParts UCI Extension Field	328
Table A-4-411: C2 Interface MA_PlanningFunctionSettingsCommandMT - AllowedType UCI Extension Field	329
Table A-4-412: C2 Interface MA_PlanningFunctionSettingsCommandMT - AutonomousAction UCI Extension Field	330
Table A-4-413: C2 Interface MA_PlanningFunctionSettingsCommandMT - MessageData UCI Extension Field	330
Table A-4-414: C2 Interface MA_PlanningFunctionSettingsCommandMT - ActivityPlan UCI Extension Field	331
Table A-4-415: C2 Interface MA_PlanningFunctionSettingsCommandMT - TaskPlan UCI Extension Field	331
Table A-4-416: C2 Interface MA_PlanningFunctionSettingsCommandStatusMT UCI Extension	332
Table A-4-417: C2 Interface MA_PlanningFunctionSettingsCommandStatusMT - MessageData UCI Extension Field	332
Table A-4-418: C2 Interface MA_OpLineMT UCI Extension	332
Table A-4-419: C2 Interface MA_OpLineMT - Category UCI Extension Field	333
Table A-4-420: C2 Interface MA_OpLineMT - AppliesToIDs UCI Extension Field	334
Table A-4-421: C2 Interface MA_OpLineMT - MessageData UCI Extension Field	335
Table A-4-422: C2 Interface MA_MissionPlanCommandMT UCI Extension	336
Table A-4-423: C2 Interface MA_MissionPlanCommandMT - Inputs UCI Extension Field	337
Table A-4-424: C2 Interface MA_MissionPlanCommandMT - ActivityPlan UCI Extension Field	338

Table A-4-425: C2 Interface MA_MissionPlanCommandMT - ProposedRequirements UCI Extension Field	338
Table A-4-426: C2 Interface MA_MissionPlanCommandMT - RouteActivityPlan UCI Extension Field	339
Table A-4-427: C2 Interface MA_MissionPlanCommandMT - ProposedResponse UCI Extension Field	340
Table A-4-428: C2 Interface MA_MissionPlanCommandMT - OrbitActivityPlan UCI Extension Field	341
Table A-4-429: C2 Interface MA_MissionPlanCommandMT - ProposedTaskPlan UCI Extension Field	341
Table A-4-430: C2 Interface MA_MissionPlanCommandMT - ProposedTask UCI Extension Field ..	342
Table A-4-431: C2 Interface MA_MissionPlanCommandMT - MessageData UCI Extension Field...	342
Table A-4-432: C2 Interface MA_MissionPlanCommandMT - TaskType UCI Extension Field	343
Table A-4-433: C2 Interface MA_MissionPlanCommandMT - ProposedEffect UCI Extension Field	344
Table A-4-434: C2 Interface MA_MissionPlanCommandMT - PlanningCandidate UCI Extension Field	344
Table A-4-435: C2 Interface MA_MissionPlanCommandMT - ProposedAction UCI Extension Field	345
Table A-4-436: C2 Interface MA_MissionPlanCommandMT - OutputPlanType UCI Extension Field	346
Table A-4-437: C2 Interface MA_MissionPlanCommandMT - ProposedRequirementPlans UCI Extension Field	346
Table A-4-438: C2 Interface MA_MissionPlanCommandMT - CapabilityCommand UCI Extension Field	347
Table A-4-439: C2 Interface MA_MissionPlanCommandStatusMT UCI Extension.....	348
Table A-4-440: C2 Interface MA_MissionPlanCommandStatusMT - AllocationResult UCI Extension Field	348
Table A-4-441: C2 Interface MA_MissionPlanCommandStatusMT - ResultingPlanIdentifier UCI Extension Field	349
Table A-4-442: C2 Interface MA_MissionPlanCommandStatusMT - OpPlanID UCI Extension Field	350
Table A-4-443: C2 Interface MA_MissionPlanCommandStatusMT - OpPlanID UCI Extension Field	350
Table A-4-444: C2 Interface MA_MissionPlanCommandStatusMT - MessageData UCI Extension Field	350
Table A-4-445: C2 Interface MA_MissionPlanCommandStatusMT - AssociatedPlans UCI Extension Field	351
Table A-4-446: C2 Interface MA_PlanningFunctionStatusMT UCI Extension.....	352
Table A-4-447: C2 Interface MA_PlanningFunctionStatusMT - AutonomousPlanningAction UCI Extension Field	353

Table A-4-448: C2 Interface MA_PlanningFunctionStatusMT - PlanningAllowed UCI Extension Field	353
Table A-4-449: C2 Interface MA_PlanningFunctionStatusMT - ActivityPlan UCI Extension Field	354
Table A-4-450: C2 Interface MA_PlanningFunctionStatusMT - TaskPlan UCI Extension Field	354
Table A-4-451: C2 Interface MA_PlanningFunctionStatusMT - ByResultSetting UCI Extension Field	355
Table A-4-452: C2 Interface MA_PlanningFunctionStatusMT - RouteActivityPlan UCI Extension Field	356
Table A-4-453: C2 Interface MA_PlanningFunctionStatusMT - OpZoneCategory UCI Extension Field	358
Table A-4-454: C2 Interface MA_PlanningFunctionStatusMT - MessageData UCI Extension Field	358
Table A-4-455: C2 Interface MA_PlanningFunctionStatusMT - OpPlan UCI Extension Field	359
Table A-4-456: C2 Interface MA_PlanningFunctionStatusMT - OpLineCategory UCI Extension Field	360
Table A-4-457: C2 Interface MA_PlanningFunctionStatusMT - AutonomousPlanningResponseChoice UCI Extension Field	360
Table A-4-458: C2 Interface MA_PlanningFunctionStatusMT - OrbitActivityPlan UCI Extension Field	361
Table A-4-459: C2 Interface MA_PlanningFunctionStatusMT - TaskType UCI Extension Field	362
Table A-4-460: C2 Interface MA_PlanningFunctionStatusMT - OutputPlanParts UCI Extension Field	363
Table A-4-461: C2 Interface MA_PlanningFunctionStatusMT - AllowedType UCI Extension Field	364
Table A-4-462: C2 Interface MA_PlanningFunctionStatusMT - OpVolumeCategory UCI Extension Field	366
Table A-4-463: C2 Interface MA_PlanningFunctionStatusMT - CapabilityCommand UCI Extension Field	367
Table A-4-464: C2 Interface MA_PlanningFunctionStatusMT - AutonomousAction UCI Extension Field	367
Table A-4-465: C2 Interface MA_PlanningFunctionStatusMT - MissionPlanningAutonomy UCI Extension Field	368
Table A-4-466: C2 Interface MA_OpPointMT UCI Extension	368
Table A-4-467: C2 Interface MA_OpPointMT - MessageData UCI Extension Field	369
Table A-4-468: C2 Interface MA_OpPointMT - AppliesToIDs UCI Extension Field	370
Table A-4-469: C2 Interface MA_OpRoutingMT UCI Extension	370
Table A-4-470: C2 Interface MA_OpRoutingMT - ApplicableToIDs UCI Extension Field	371
Table A-4-471: C2 Interface MA_OpRoutingMT - MessageData UCI Extension Field	372
Table A-4-472: C2 Interface MA_PlanningFunctionMT UCI Extension	372

Table A-4-473: C2 Interface MA_PlanningFunctionMT - Process UCI Extension Field	373
Table A-4-474: C2 Interface MA_PlanningFunctionMT - RouteActivityPlan UCI Extension Field	374
Table A-4-475: C2 Interface MA_PlanningFunctionMT - ActivityPlan UCI Extension Field	374
Table A-4-476: C2 Interface MA_PlanningFunctionMT - OpVolumeCategory UCI Extension Field..	377
Table A-4-477: C2 Interface MA_PlanningFunctionMT - MissionPlan UCI Extension Field.....	377
Table A-4-478: C2 Interface MA_PlanningFunctionMT - MessageData UCI Extension Field	378
Table A-4-479: C2 Interface MA_PlanningFunctionMT - PlanningInterfaceDetails UCI Extension Field	379
Table A-4-480: C2 Interface MA_PlanningFunctionMT - TaskPlan UCI Extension Field	379
Table A-4-481: C2 Interface MA_PlanningFunctionMT - OrbitActivityPlan UCI Extension Field.....	380
Table A-4-482: C2 Interface MA_PlanningFunctionMT - OpZoneCategory UCI Extension Field.....	382
Table A-4-483: C2 Interface MA_PlanningFunctionMT - Output UCI Extension Field	383
Table A-4-484: C2 Interface MA_PlanningFunctionMT - CapabilityCommand UCI Extension Field.	384
Table A-4-485: C2 Interface MA_PlanningFunctionMT - TaskType UCI Extension Field	385
Table A-4-486: C2 Interface MA_PlanningFunctionMT - OpLineCategory UCI Extension Field	386
Table A-4-487: C2 Interface MA_PlanningFunctionMT - OpPlan UCI Extension Field	386
Table A-4-488: C2 Interface MA_TaskStatusMT UCI Extension.....	387
Table A-4-489: C2 Interface MA_TaskStatusMT - Plans UCI Extension Field.....	387
Table A-4-490: C2 Interface MA_TaskStatusMT - OpPlanID UCI Extension Field	388
Table A-4-491: C2 Interface MA_TaskStatusMT - ExecutingSystemOrPackage UCI Extension Field	388
Table A-4-492: C2 Interface MA_TaskStatusMT - MessageData UCI Extension Field.....	389
Table A-4-493: C2 Interface MA_TaskStatusMT - Traceability UCI Extension Field	390
Table A-4-494: C2 Interface MA_PlanModificationRequestMT UCI Extension	390
Table A-4-495: C2 Interface MA_PlanModificationRequestMT - SubPlansAdditions UCI Extension Field	391
Table A-4-496: C2 Interface MA_PlanModificationRequestMT - SubPlansRetractions UCI Extension Field	392
Table A-4-497: C2 Interface MA_PlanModificationRequestMT - SubPlansModification UCI Extension Field	392
Table A-4-498: C2 Interface MA_PlanModificationRequestMT - PlanModificationDetails UCI Extension Field	393
Table A-4-499: C2 Interface MA_PlanModificationRequestMT - MessageData UCI Extension Field	393
Table A-4-500: C2 Interface MA_PlanModificationRequestMT - Plans UCI Extension Field	394

Table A-4-501: C2 Interface MA_PlanModificationRequestMT - OpPlanID UCI Extension Field	395
Table A-4-502: C2 Interface MA_PlanModificationRequestStatusMT UCI Extension	395
Table A-4-503: C2 Interface MA_PlanModificationRequestStatusMT - MessageData UCI Extension Field	395
Table A-4-504: C2 Interface MA_MessageAcknowledgmentConfigurationRequestMT UCI Extension	396
Table A-4-505: C2 Interface MA_MessageAcknowledgmentConfigurationRequestMT - MessageData UCI Extension Field	396
Table A-4-506: C2 Interface MA_MessageAcknowledgmentConfigurationMT UCI Extension	396
Table A-4-507: C2 Interface MA_MessageAcknowledgmentConfigurationMT - MessageData UCI Extension Field	397
Table A-4-508: C2 Interface MA_MessageAcknowledgmentConfigurationRequestStatusMT UCI Extension	397
Table A-4-509: C2 Interface MA_MessageAcknowledgmentConfigurationRequestStatusMT - MessageData UCI Extension Field	398
Table A-4-510: C2 Interface MA_ResponseCommandMT UCI Extension	398
Table A-4-511: C2 Interface MA_ResponseCommandMT - MessageData UCI Extension Field	398
Table A-4-512: C2 Interface MA_ResponseCommandStatusMT UCI Extension	398
Table A-4-513: C2 Interface MA_ResponseCommandStatusMT - MessageData UCI Extension Field	399
Table A-4-514: C2 Interface MA_PlatformOverrideCommandStatusMT UCI Extension	399
Table A-4-515: C2 Interface MA_PlatformOverrideCommandStatusMT - MessageData UCI Extension Field	400
Table A-4-516: C2 Interface MA_PlatformOverrideCommandMT UCI Extension	400
Table A-4-517: C2 Interface MA_PlatformOverrideCommandMT - MessageData UCI Extension Field	400
Table A-4-518: C2 Interface MA_GatewayActivityMT UCI Extension	401
Table A-4-519: C2 Interface MA_GatewayActivityMT - ObjectState UCI Extension Field	401
Table A-4-520: C2 Interface MA_GatewayActivityMT - MessageData UCI Extension Field	402
Table A-4-521: C2 Interface MA_DataDisseminationPlanOverrideRequestMT UCI Extension	402
Table A-4-522: C2 Interface MA_DataDisseminationPlanOverrideRequestMT - MessageData UCI Extension Field	402
Table A-4-523: C2 Interface MA_DataDisseminationPlanOverrideRequestStatusMT UCI Extension	402
Table A-4-524: C2 Interface MA_DataDisseminationPlanOverrideRequestStatusMT - MessageData UCI Extension Field	403
Table A-4-525: C2 Interface MA_DataDisseminationPlanMT UCI Extension	403

Table A-4-526: C2 Interface MA_DataDisseminationPlanMT - ObjectState UCI Extension Field.....	404
Table A-4-527: C2 Interface MA_DataDisseminationPlanMT - MessageData UCI Extension Field .	405
Table A-4-528: C2 Interface MA_DataDisseminationPlanActivationCommandMT UCI Extension ...	405
Table A-4-529: C2 Interface MA_DataDisseminationPlanActivationCommandMT - MessageData UCI Extension Field	406
Table A-4-530: C2 Interface MA_DataDisseminationPlanActivationCommandStatusMT UCI Extension	406
Table A-4-531: C2 Interface MA_DataDisseminationPlanActivationCommandStatusMT - MessageData UCI Extension Field	407
Table A-4-532: C2 Interface MA_DataDisseminationPlanActivationStatusMT UCI Extension.....	407
Table A-4-533: C2 Interface MA_DataDisseminationPlanActivationStatusMT - MessageData UCI Extension Field	407
Table A-4-534: C2 Interface MA_PlatformOverrideStatusMT UCI Extension	408
Table A-4-535: C2 Interface MA_PlatformOverrideStatusMT - MessageData UCI Extension Field .	409
Table A-4-536: Peer Interface MA_WEZ_MT UCI Extension.....	409
Table A-4-537: Peer Interface MA_WEZ_MT - MessageData UCI Extension Field.....	410
Table A-4-538: Peer Interface MA_WEZ_MT - WEZ_ID UCI Extension Field	410
Table A-4-539: Peer Interface MA_WEZ_MT - WEZ_Data UCI Extension Field	412
Table A-4-540: Peer Interface MA_WEZ_MT - RangeTurnAndClose UCI Extension Field	412
Table A-4-541: Peer Interface MA_WEZ_MT - RangeMinimum UCI Extension Field.....	413
Table A-4-542: Peer Interface MA_WEZ_MT - RangeTurnAndRun UCI Extension Field	413
Table A-4-543: Peer Interface MA_WEZ_MT - RangeProbabilityOfIntercept UCI Extension Field...	414
Table A-4-544: Peer Interface MA_WEZ_MT - RangeMaxGuidance UCI Extension Field	414
Table A-4-545: Peer Interface MA_WEZ_MT - RangeOptimal UCI Extension Field.....	415
Table A-4-546: Peer Interface MA_WEZ_MT - RangeMaxAero UCI Extension Field.....	415
Table A-4-547: Peer Interface MA_COP_ConfigurationSettingsRequestStatusMT UCI Extension ..	415
Table A-4-548: Peer Interface MA_COP_ConfigurationSettingsRequestStatusMT - MessageData UCI Extension Field	416
Table A-4-549: Peer Interface MA_COP_ConfigurationSettingsRequestMT UCI Extension	416
Table A-4-550: Peer Interface MA_COP_ConfigurationSettingsRequestMT - MessageData UCI Extension Field	416
Table A-4-551: Peer Interface MA_SystemNotificationMT UCI Extension	417
Table A-4-552: Peer Interface MA_SystemNotificationMT - MessageData UCI Extension Field	418
Table A-4-553: Peer Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field .	418
Table A-4-554: Peer Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field .	419

Table A-4-555: Peer Interface MA_COP_ConfigurationSettingsCommandMT UCI Extension	419
Table A-4-556: Peer Interface MA_COP_ConfigurationSettingsCommandMT - MessageData UCI Extension Field	420
Table A-4-557: Peer Interface MA_EngagementCriteriaCommandStatusMT UCI Extension	420
Table A-4-558: Peer Interface MA_EngagementCriteriaCommandStatusMT - MessageData UCI Extension Field	420
Table A-4-559: Peer Interface MA_EngagementCriteriaCommandMT UCI Extension	421
Table A-4-560: Peer Interface MA_EngagementCriteriaCommandMT - MessageData UCI Extension Field	421
Table A-4-561: Peer Interface MA_COP_ConfigurationSettingsCommandStatusMT UCI Extension	421
Table A-4-562: Peer Interface MA_COP_ConfigurationSettingsCommandStatusMT - MessageData UCI Extension Field	422
Table A-4-563: Peer Interface MA_DesignationRequestStatusMT UCI Extension	422
Table A-4-564: Peer Interface MA_DesignationRequestStatusMT - MessageData UCI Extension Field	423
Table A-4-565: Peer Interface MA_EngagementCriteriaStatusMT UCI Extension.....	423
Table A-4-566: Peer Interface MA_EngagementCriteriaStatusMT - MessageData UCI Extension Field	423
Table A-4-567: Peer Interface MA_AcceptableLevelOfRiskStatusMT UCI Extension	424
Table A-4-568: Peer Interface MA_AcceptableLevelOfRiskStatusMT - MessageData UCI Extension Field	424
Table A-4-569: Peer Interface MA_DesignationRequestMT UCI Extension	424
Table A-4-570: Peer Interface MA_DesignationRequestMT - MessageData UCI Extension Field ...	424
Table A-4-571: Peer Interface MA_RaftVoteRequestMT UCI Extension	425
Table A-4-572: Peer Interface MA_RaftVoteRequestMT - MessageData UCI Extension Field	425
Table A-4-573: Peer Interface MA_RaftVoteRequestStatusMT UCI Extension	425
Table A-4-574: Peer Interface MA_RaftVoteRequestStatusMT - MessageData UCI Extension Field	426
Table A-4-575: Peer Interface MA_RaftAppendEntriesRequestMT UCI Extension	426
Table A-4-576: Peer Interface MA_RaftAppendEntriesRequestMT - MessageData UCI Extension Field	427
Table A-4-577: Peer Interface MA_RaftAppendEntriesRequestStatusMT UCI Extension	427
Table A-4-578: Peer Interface MA_RaftAppendEntriesRequestStatusMT - MessageData UCI Extension Field	428
Table A-4-579: Peer Interface MA_CAP_ExecutionStatusReportMT UCI Extension.....	428

Table A-4-580: Peer Interface MA_CAP_ExecutionStatusReportMT - MessageData UCI Extension Field	428
Table A-4-581: Peer Interface MA_MissionPlanMT UCI Extension	429
Table A-4-582: Peer Interface MA_MissionPlanMT - MessageData UCI Extension Field	430
Table A-4-583: Peer Interface MA_ActionPlanMT UCI Extension	430
Table A-4-584: Peer Interface MA_ActionPlanMT - MessageData UCI Extension Field	431
Table A-4-585: Peer Interface MA_TaskPlanMT UCI Extension.....	431
Table A-4-586: Peer Interface MA_TaskPlanMT - MessageData UCI Extension Field.....	431
Table A-4-587: Peer Interface MA_RoutePlanMT UCI Extension	432
Table A-4-588: Peer Interface MA_RoutePlanMT - MessageData UCI Extension Field	432
Table A-4-589: Peer Interface MA_ActivityPlanMT UCI Extension	432
Table A-4-590: Peer Interface MA_ActivityPlanMT - MessageData UCI Extension Field	433
Table A-4-591: Peer Interface MA_RouteActivityPlanMT UCI Extension	433
Table A-4-592: Peer Interface MA_RouteActivityPlanMT - MessageData UCI Extension Field	434
Table A-4-593: Peer Interface MA_ActionMT UCI Extension.....	434
Table A-4-594: Peer Interface MA_ActionMT - MessageData UCI Extension Field.....	435
Table A-4-595: Peer Interface MA_ResponseMT UCI Extension	435
Table A-4-596: Peer Interface MA_ResponseMT - MessageData UCI Extension Field	437
Table A-4-597: Peer Interface MA_OpVolumeMT UCI Extension.....	437
Table A-4-598: Peer Interface MA_OpVolumeMT - MessageData UCI Extension Field.....	438
Table A-4-599: Peer Interface MA_ApprovalAuthorityMT UCI Extension	438
Table A-4-600: Peer Interface MA_ApprovalAuthorityMT - MessageData UCI Extension Field	439
Table A-4-601: Peer Interface MA_ApprovalAuthorityMT - ApplicableIDs UCI Extension Field	439
Table A-4-602: Peer Interface MA_CapabilitySetMT UCI Extension	439
Table A-4-603: Peer Interface MA_CapabilitySetMT - MessageData UCI Extension Field	440
Table A-4-604: Peer Interface MA_MissionPlanActivationCommandStatusMT UCI Extension	440
Table A-4-605: Peer Interface MA_MissionPlanActivationCommandStatusMT - Plans UCI Extension Field	441
Table A-4-606: Peer Interface MA_MissionPlanActivationCommandStatusMT - MessageData UCI Extension Field	441
Table A-4-607: Peer Interface MA_MissionPlanActivationCommandStatusMT - ActivationCommandByState UCI Extension Field.....	442
Table A-4-608: Peer Interface MA_MissionPlanExecutionStatusMT UCI Extension	442
Table A-4-609: Peer Interface MA_MissionPlanExecutionStatusMT - ExecutionPlanSetStatus UCI Extension Field	442

Table A-4-610: Peer Interface MA_MissionPlanExecutionStatusMT - PlanExecutionStatus UCI Extension Field	443
Table A-4-611: Peer Interface MA_MissionPlanExecutionStatusMT - MessageData UCI Extension Field	443
Table A-4-612: Peer Interface MA_ConstraintPriorityListActivationStatusMT UCI Extension	443
Table A-4-613: Peer Interface MA_ConstraintPriorityListActivationStatusMT - MessageData UCI Extension Field	444
Table A-4-614: Peer Interface MA_ConstraintPriorityListCommandMT UCI Extension	444
Table A-4-615: Peer Interface MA_ConstraintPriorityListCommandMT - MessageData UCI Extension Field	444
Table A-4-616: Peer Interface MA_ConstraintPriorityListCommandStatusMT UCI Extension	445
Table A-4-617: Peer Interface MA_ConstraintPriorityListCommandStatusMT - MessageData UCI Extension Field	445
Table A-4-618: Peer Interface MA_EscortCommandMT UCI Extension	446
Table A-4-619: Peer Interface MA_EscortCommandMT - MessageData UCI Extension Field	446
Table A-4-620: Peer Interface MA_EscortCommandStatusMT UCI Extension	446
Table A-4-621: Peer Interface MA_EscortCommandStatusMT - MessageData UCI Extension Field	447
Table A-4-622: Peer Interface MA_ExecutionPriorityListActivationStatusMT UCI Extension	447
Table A-4-623: Peer Interface MA_ExecutionPriorityListActivationStatusMT - MessageData UCI Extension Field	447
Table A-4-624: Peer Interface MA_ExecutionPriorityListCommandMT UCI Extension	448
Table A-4-625: Peer Interface MA_ExecutionPriorityListCommandMT - MessageData UCI Extension Field	448
Table A-4-626: Peer Interface MA_ExecutionPriorityListCommandStatusMT UCI Extension	448
Table A-4-627: Peer Interface MA_ExecutionPriorityListCommandStatusMT - MessageData UCI Extension Field	449
Table A-4-628: Peer Interface MA_FlightActivityMT UCI Extension	449
Table A-4-629: Peer Interface MA_FlightActivityMT - VehicleCommandState UCI Extension Field	449
Table A-4-630: Peer Interface MA_FlightActivityMT - Activity UCI Extension Field	451
Table A-4-631: Peer Interface MA_FlightActivityMT - Speed UCI Extension Field	451
Table A-4-632: Peer Interface MA_FlightActivityMT - Heading UCI Extension Field	451
Table A-4-633: Peer Interface MA_FlightCommandMT UCI Extension	452
Table A-4-634: Peer Interface MA_FlightCommandMT - Command UCI Extension Field	453
Table A-4-635: Peer Interface MA_FlightCommandMT - Capability UCI Extension Field	454
Table A-4-636: Peer Interface MA_FlightCommandMT - HSA_CSA UCI Extension Field	454

Table A-4-637: Peer Interface MA_FlightCommandMT - WaypointFollowing UCI Extension Field ..	455
Table A-4-638: Peer Interface MA_FlightCommandMT - CurveFollowing UCI Extension Field	455
Table A-4-639: Peer Interface MA_FlightCommandMT - Speed UCI Extension Field	455
Table A-4-640: Peer Interface MA_FlightCommandMT - Heading UCI Extension Field	456
Table A-4-641: Peer Interface MA_FlightCommandMT - SpeedChoice UCI Extension Field	456
Table A-4-642: Peer Interface MA_FlightCommandMT - SpeedValue UCI Extension Field	456
Table A-4-643: Peer Interface MA_FlightCommandMT - CurveFitMethod UCI Extension Field	457
Table A-4-644: Peer Interface MA_FlightCommandMT - Reference UCI Extension Field	457
Table A-4-645: Peer Interface MA_FlightCommandMT - ControlPoint UCI Extension Field	458
Table A-4-646: Peer Interface MA_FlightCommandMT - RelativeAcceleration UCI Extension Field	458
Table A-4-647: Peer Interface MA_FlightCommandMT - RelativeVelocity UCI Extension Field	458
Table A-4-648: Peer Interface MA_FlightCommandMT - OrientationRate UCI Extension Field	459
Table A-4-649: Peer Interface MA_FlightCommandMT - Direction UCI Extension Field	459
Table A-4-650: Peer Interface MA_FlightCommandMT - Course UCI Extension Field	459
Table A-4-651: Peer Interface MA_FlightCommandStatusMT UCI Extension	460
Table A-4-652: Peer Interface MA_FlightCommandStatusMT - MessageData UCI Extension Field	460
Table A-4-653: Peer Interface MA_FlightCommandStatusMT - CannotComplyDetails UCI Extension Field	460
Table A-4-654: Peer Interface MA_FlightCommandStatusMT - Severity UCI Extension Field	461
Table A-4-655: Peer Interface MA_IgnoreConstraintCommandMT UCI Extension	461
Table A-4-656: Peer Interface MA_IgnoreConstraintCommandMT - MessageData UCI Extension Field	462
Table A-4-657: Peer Interface MA_IgnoreConstraintCommandStatusMT UCI Extension	462
Table A-4-658: Peer Interface MA_IgnoreConstraintCommandStatusMT - MessageData UCI Extension Field	463
Table A-4-659: Peer Interface MA_LeaderUpdateRequestMT UCI Extension	463
Table A-4-660: Peer Interface MA_LeaderUpdateRequestMT - MessageData UCI Extension Field	463
Table A-4-661: Peer Interface MA_LeaderUpdateRequestStatusMT UCI Extension	464
Table A-4-662: Peer Interface MA_LeaderUpdateRequestStatusMT - MessageData UCI Extension Field	464
Table A-4-663: Peer Interface MA_AcceptableLevelOfRiskCommandMT UCI Extension	464
Table A-4-664: Peer Interface MA_AcceptableLevelOfRiskCommandMT - MessageData UCI Extension Field	465
Table A-4-665: Peer Interface MA_AcceptableLevelOfRiskCommandStatusMT UCI Extension	465
Table A-4-666: Peer Interface MA_AcceptableLevelOfRiskCommandStatusMT - MessageData UCI	

Extension Field	466
Table A-4-667: Peer Interface MA_MissionPlanActivationCommandMT UCI Extension	466
Table A-4-668: Peer Interface MA_MissionPlanActivationCommandMT - OpPlanID UCI Extension Field	467
Table A-4-669: Peer Interface MA_MissionPlanActivationCommandMT - ApplicableToIDs UCI Extension Field	467
Table A-4-670: Peer Interface MA_MissionPlanActivationCommandMT - ByExecutionPlanSet UCI Extension Field	467
Table A-4-671: Peer Interface MA_MissionPlanActivationCommandMT - MessageData UCI Extension Field	468
Table A-4-672: Peer Interface MA_MissionPlanActivationCommandMT - ActivationDetails UCI Extension Field	469
Table A-4-673: Peer Interface MA_MissionPlanActivationCommandMT - Applicability UCI Extension Field	469
Table A-4-674: Peer Interface MA_MissionPlanActivationCommandMT - OpPlan UCI Extension Field	470
Table A-4-675: Peer Interface MA_MissionPlanActivationCommandMT - Command UCI Extension Field	470
Table A-4-676: Peer Interface MA_OpZoneMT UCI Extension.....	471
Table A-4-677: Peer Interface MA_OpZoneMT - MessageData UCI Extension Field.....	472
Table A-4-678: Peer Interface MA_OpZoneMT - Category UCI Extension Field	475
Table A-4-679: Peer Interface MA_OpZoneMT - CategoryUniqueData UCI Extension Field	475
Table A-4-680: Peer Interface MA_OpZoneMT - SpeedLimits UCI Extension Field	476
Table A-4-681: Peer Interface MA_OpZoneMT - VehicleConfiguration UCI Extension Field.....	476
Table A-4-682: Peer Interface MA_OpZoneMT - Zone UCI Extension Field	477
Table A-4-683: Peer Interface MA_OpZoneMT - GeometryReference UCI Extension Field	477
Table A-4-684: Peer Interface MA_OpZoneMT - ReferenceObjectsFilter UCI Extension Field	478
Table A-4-685: Peer Interface MA_OpZoneMT - OpPointFilter UCI Extension Field.....	478
Table A-4-686: Peer Interface MA_OpZoneMT - OpLineFilter UCI Extension Field	479
Table A-4-687: Peer Interface MA_OpZoneMT - OpLineCategory UCI Extension Field.....	480
Table A-4-688: Peer Interface MA_OpZoneMT - OpZoneFilter UCI Extension Field.....	480
Table A-4-689: Peer Interface MA_OpZoneMT - OpZoneCategory UCI Extension Field	482
Table A-4-690: Peer Interface MA_OpZoneMT - OpVolumeFilter UCI Extension Field.....	483
Table A-4-691: Peer Interface MA_OpZoneMT - OpVolumeCategory UCI Extension Field	485
Table A-4-692: Peer Interface MA_OpZoneMT - DMPI_Filter UCI Extension Field.....	485
Table A-4-693: Peer Interface MA_OpZoneMT - SignalReportFilter UCI Extension Field	486

Table A-4-694: Peer Interface MA_OpZoneMT - OpVolumeFilter UCI Extension Field	486
Table A-4-695: Peer Interface MA_OpZoneMT - OpLineFilter UCI Extension Field	487
Table A-4-696: Peer Interface MA_OpZoneMT - OpLineCategory UCI Extension Field.....	488
Table A-4-697: Peer Interface MA_OpZoneMT - SpeedLimits UCI Extension Field	488
Table A-4-698: Peer Interface MA_OpZoneMT - SignalReportFilter UCI Extension Field	488
Table A-4-699: Peer Interface MA_OpZoneMT - OpPointFilter UCI Extension Field.....	489
Table A-4-700: Peer Interface MA_OpZoneMT - VehicleConfiguration UCI Extension Field.....	490
Table A-4-701: Peer Interface MA_OpZoneMT - DMPI_Filter UCI Extension Field	490
Table A-4-702: Peer Interface MA_OpZoneMT - Zone UCI Extension Field	490
Table A-4-703: Peer Interface MA_OpZoneMT - Category UCI Extension Field	492
Table A-4-704: Peer Interface MA_OpZoneMT - CategoryUniqueData UCI Extension Field	493
Table A-4-705: Peer Interface MA_OpZoneMT - ReferenceObjectsFilter UCI Extension Field	494
Table A-4-706: Peer Interface MA_OpZoneMT - OpVolumeCategory UCI Extension Field	496
Table A-4-707: Peer Interface MA_OpZoneMT - GeometryReference UCI Extension Field	497
Table A-4-708: Peer Interface MA_OpZoneMT - OpZoneCategory UCI Extension Field	499
Table A-4-709: Peer Interface MA_OpZoneMT - OpZoneFilter UCI Extension Field.....	499
Table A-4-710: Peer Interface MA_PositionReportMT UCI Extension	499
Table A-4-711: Peer Interface MA_PositionReportMT - MessageData UCI Extension Field	500
Table A-4-712: Peer Interface MA_PackageManagementCommandMT UCI Extension	500
Table A-4-713: Peer Interface MA_PackageManagementCommandMT - MessageData UCI Extension Field	502
Table A-4-714: Peer Interface MA_PackageManagementCommandStatusMT UCI Extension	502
Table A-4-715: Peer Interface MA_PackageManagementCommandStatusMT - MessageData UCI Extension Field	503
Table A-4-716: Peer Interface MA_PackagePartnerStatusReportMT UCI Extension	503
Table A-4-717: Peer Interface MA_PackagePartnerStatusReportMT - MessageData UCI Extension Field	504
Table A-4-718: Peer Interface MA_SystemManagementRequestMT UCI Extension	504
Table A-4-719: Peer Interface MA_SystemManagementRequestMT - MessageData UCI Extension Field	505
Table A-4-720: Peer Interface MA_SystemManagementRequestMT - RequestType UCI Extension Field	505
Table A-4-721: Peer Interface MA_SystemManagementRequestMT - VehicleSettings UCI Extension Field	506
Table A-4-722: Peer Interface MA_SystemManagementRequestStatusMT UCI Extension	506

Table A-4-723: Peer Interface MA_SystemManagementRequestStatusMT - MessageData UCI Extension Field	507
Table A-4-724: Peer Interface MA_AMTI_CapabilityMT UCI Extension	507
Table A-4-725: Peer Interface MA_AMTI_CapabilityMT - MessageData UCI Extension Field	507
Table A-4-726: Peer Interface MA_AMTI_CapabilityMT - Capability UCI Extension Field.....	509
Table A-4-727: Peer Interface MA_ActionCapabilityMT UCI Extension	509
Table A-4-728: Peer Interface MA_ActionCapabilityMT - AssociatedTaskType UCI Extension Field	510
Table A-4-729: Peer Interface MA_ActionCapabilityMT - Capability UCI Extension Field	511
Table A-4-730: Peer Interface MA_ActionCapabilityMT - MessageData UCI Extension Field	512
Table A-4-731: Peer Interface MA_ApprovalRequestMT UCI Extension	512
Table A-4-732: Peer Interface MA_ApprovalRequestMT - ActivationDetails UCI Extension Field....	512
Table A-4-733: Peer Interface MA_ApprovalRequestMT - OpPlanID UCI Extension Field.....	513
Table A-4-734: Peer Interface MA_ApprovalRequestMT - MissionPlanActivationApproval UCI Extension Field	513
Table A-4-735: Peer Interface MA_ApprovalRequestMT - ApprovalReferences UCI Extension Field	514
Table A-4-736: Peer Interface MA_ApprovalRequestMT - ApprovalItem UCI Extension Field	514
Table A-4-737: Peer Interface MA_ApprovalRequestMT - ByExecutionPlanSet UCI Extension Field	514
Table A-4-738: Peer Interface MA_ApprovalRequestMT - MessageData UCI Extension Field	515
Table A-4-739: Peer Interface MA_ApprovalRequestMT - BySubPlan UCI Extension Field	516
Table A-4-740: Peer Interface MA_ApprovalRequestMT - OpPlan UCI Extension Field	516
Table A-4-741: Peer Interface MA_ApprovalRequestStatusMT UCI Extension	516
Table A-4-742: Peer Interface MA_ApprovalRequestStatusMT - MessageData UCI Extension Field	517
Table A-4-743: Peer Interface MA_EffectCapabilityMT UCI Extension.....	517
Table A-4-744: Peer Interface MA_EffectCapabilityMT - AssociatedTaskType UCI Extension Field	518
Table A-4-745: Peer Interface MA_FlightCapabilityMT UCI Extension	518
Table A-4-746: Peer Interface MA_FlightCapabilityMT - HSA_CSA_PerformanceProfile UCI Extension Field	520
Table A-4-747: Peer Interface MA_FlightCapabilityMT - WaypointFollowingPerformanceProfile UCI Extension Field	521
Table A-4-748: Peer Interface MA_FlightCapabilityMT - CurveFollowingPerformanceProfile UCI Extension Field	522
Table A-4-749: Peer Interface MA_FlightCapabilityMT - AccelerationLimit UCI Extension Field	522

Table A-4-750: Peer Interface MA_FlightCapabilityMT - AccelerationLimitValue UCI Extension Field	523
Table A-4-751: Peer Interface MA_FlightCapabilityMT - BodyReferenceOrientationRate UCI Extension Field	523
Table A-4-752: Peer Interface MA_FlightCapabilityMT - OrientationRateLimits UCI Extension Field	524
Table A-4-753: Peer Interface MA_FlightCapabilityMT - AirspeedPair UCI Extension Field.....	524
Table A-4-754: Peer Interface MA_FlightCapabilityStatusMT UCI Extension	524
Table A-4-755: Peer Interface MA_FlightCapabilityStatusMT - Capability UCI Extension Field	525
Table A-4-756: Peer Interface MA_FlightCapabilityStatusMT - MessageData UCI Extension Field	526
Table A-4-757: Peer Interface MA_TaskMT UCI Extension.....	526
Table A-4-758: Peer Interface MA_TaskMT - TaskType UCI Extension Field	528
Table A-4-759: Peer Interface MA_TaskMT - TaskPlurality UCI Extension Field	528
Table A-4-760: Peer Interface MA_TaskMT - ConstraintID UCI Extension Field.....	528
Table A-4-761: Peer Interface MA_TaskMT - HSA_CSA UCI Extension Field	529
Table A-4-762: Peer Interface MA_TaskMT - WaypointFollowing UCI Extension Field.....	529
Table A-4-763: Peer Interface MA_TaskMT - CurveFollowing UCI Extension Field	529
Table A-4-764: Peer Interface MA_TaskMT - Speed UCI Extension Field	530
Table A-4-765: Peer Interface MA_TaskMT - Heading UCI Extension Field	530
Table A-4-766: Peer Interface MA_TaskMT - SpeedChoice UCI Extension Field	530
Table A-4-767: Peer Interface MA_TaskMT - SpeedValue UCI Extension Field	531
Table A-4-768: Peer Interface MA_TaskMT - CurveFitMethod UCI Extension Field	531
Table A-4-769: Peer Interface MA_NavigationReportMT UCI Extension.....	531
Table A-4-770: Peer Interface MA_NavigationReportMT - MessageData UCI Extension Field	532
Table A-4-771: Peer Interface MA_StrikeActivityMT UCI Extension	532
Table A-4-772: Peer Interface MA_StrikeActivityMT - ActiveWeaponHSA_CSA UCI Extension Field	533
Table A-4-773: Peer Interface MA_StrikeActivityMT - Direction UCI Extension Field	533
Table A-4-774: Peer Interface MA_StrikeActivityMT - MunitionActive UCI Extension Field.....	533
Table A-4-775: Peer Interface MA_StrikeActivityMT - MessageData UCI Extension Field	534
Table A-4-776: Peer Interface MA_StrikeActivityMT - ActiveWeaponState UCI Extension Field.....	534
Table A-4-777: Peer Interface MA_StrikeActivityMT - Activity UCI Extension Field.....	536
Table A-4-778: Peer Interface MA_StrikeActivityMT - Course UCI Extension Field.....	536
Table A-4-779: Peer Interface MA_StrikeActivityMT - Heading UCI Extension Field.....	536

Table A-4-780: Peer Interface MA_StrikeActivityMT - Reference UCI Extension Field.....	536
Table A-4-781: Peer Interface MA_StrikeCapabilityMT UCI Extension.....	537
Table A-4-782: Peer Interface MA_StrikeCapabilityMT - MessageData UCI Extension Field.....	537
Table A-4-783: Peer Interface MA_TaskCommandMT UCI Extension	537
Table A-4-784: Peer Interface MA_TaskCommandMT - MessageData UCI Extension Field	538
Table A-4-785: Peer Interface MA_TaskCommandStatusMT UCI Extension	538
Table A-4-786: Peer Interface MA_TaskCommandStatusMT - MessageData UCI Extension Field	538
Table A-4-787: Peer Interface MA_COP_ConfigurationSettingsMT UCI Extension.....	539
Table A-4-788: Peer Interface MA_COP_ConfigurationSettingsMT - MessageData UCI Extension Field	539
Table A-4-789: Peer Interface MA_OpCommandMT UCI Extension	539
Table A-4-790: Peer Interface MA_OpCommandMT - MessageData UCI Extension Field	540
Table A-4-791: Peer Interface MA_OpCommandStatusMT UCI Extension	540
Table A-4-792: Peer Interface MA_OpCommandStatusMT - MessageData UCI Extension Field	540
Table A-4-793: Peer Interface MA_DeconflictionSolutionRequestStatusMT UCI Extension.....	541
Table A-4-794: Peer Interface MA_DeconflictionSolutionRequestStatusMT - MessageData UCI Extension Field	541
Table A-4-795: Peer Interface MA_OpPlanMT UCI Extension.....	541
Table A-4-796: Peer Interface MA_OpPlanMT - MessageData UCI Extension Field.....	542
Table A-4-797: Peer Interface MA_RouteDeconflictionAlertMT UCI Extension	542
Table A-4-798: Peer Interface MA_RouteDeconflictionAlertMT - MessageData UCI Extension Field	543
Table A-4-799: Peer Interface MA_OpStatusMT UCI Extension.....	543
Table A-4-800: Peer Interface MA_OpStatusMT - MessageData UCI Extension Field.....	543
Table A-4-801: Peer Interface MA_DeconflictionSolutionRequestMT UCI Extension	544
Table A-4-802: Peer Interface MA_DeconflictionSolutionRequestMT - MessageData UCI Extension Field	544
Table A-4-803: Peer Interface MA_PrioritizationListMT UCI Extension	544
Table A-4-804: Peer Interface MA_PrioritizationListMT - ListType UCI Extension Field	546
Table A-4-805: Peer Interface MA_PrioritizationListMT - ListItem UCI Extension Field	546
Table A-4-806: Peer Interface MA_PrioritizationListMT - MessageData UCI Extension Field	547
Table A-4-807: Peer Interface MA_MissionPlanActivationStatusMT UCI Extension.....	547
Table A-4-808: Peer Interface MA_MissionPlanActivationStatusMT - OpPlanID UCI Extension Field	548
Table A-4-809: Peer Interface MA_MissionPlanActivationStatusMT - MessageData UCI Extension	

Field	548
Table A-4-810: Peer Interface MA_MissionPlanActivationStatusMT - Plans UCI Extension Field....	549
Table A-4-811: Peer Interface MA_MissionPlanActivationStatusMT - SubPlanActivationState UCI Extension Field	549
Table A-4-812: Peer Interface MA_ActionCommandMT UCI Extension	550
Table A-4-813: Peer Interface MA_ActionCommandMT - ActionConstraintOverride UCI Extension Field	551
Table A-4-814: Peer Interface MA_ActionCommandMT - RequiredAllocation UCI Extension Field	551
Table A-4-815: Peer Interface MA_ActionCommandMT - System UCI Extension Field	552
Table A-4-816: Peer Interface MA_ActionCommandMT - PreferredAllocation UCI Extension Field	553
Table A-4-817: Peer Interface MA_ActionCommandMT - Analytic UCI Extension Field.....	553
Table A-4-818: Peer Interface MA_ActionCommandMT - Designation UCI Extension Field	553
Table A-4-819: Peer Interface MA_ActionCommandMT - AssessedObject UCI Extension Field	554
Table A-4-820: Peer Interface MA_ActionCommandMT - Characteristics UCI Extension Field.....	554
Table A-4-821: Peer Interface MA_ActionCommandMT - Allocation UCI Extension Field.....	554
Table A-4-822: Peer Interface MA_ActionCommandMT - ConstraintOverride UCI Extension Field	557
Table A-4-823: Peer Interface MA_ActionCommandMT - Allocation UCI Extension Field.....	557
Table A-4-824: Peer Interface MA_ActionCommandMT - AccessAssessmentThreshold UCI Extension Field	558
Table A-4-825: Peer Interface MA_ActionCommandMT - Command UCI Extension Field.....	558
Table A-4-826: Peer Interface MA_ActionCommandMT - ExcludedRequirementTypes UCI Extension Field	559
Table A-4-827: Peer Interface MA_ActionCommandMT - Kinematic UCI Extension Field	559
Table A-4-828: Peer Interface MA_ActionCommandMT - EngagementParameters UCI Extension Field	560
Table A-4-829: Peer Interface MA_ActionCommandMT - Subject UCI Extension Field	560
Table A-4-830: Peer Interface MA_ActionCommandMT - MessageData UCI Extension Field	560
Table A-4-831: Peer Interface MA_ActionCommandMT - AllowedRequirementTypes UCI Extension Field	561
Table A-4-832: Peer Interface MA_ActionCommandMT - Entity UCI Extension Field	562
Table A-4-833: Peer Interface MA_ActionCommandStatusMT UCI Extension	562
Table A-4-834: Peer Interface MA_ActionCommandStatusMT - MessageData UCI Extension Field	562
Table A-4-835: Peer Interface MA_ActionStatusMT UCI Extension	563
Table A-4-836: Peer Interface MA_ActionStatusMT - Traceability UCI Extension Field	563

Table A-4-837: Peer Interface MA_ActionStatusMT - Plans UCI Extension Field.....	564
Table A-4-838: Peer Interface MA_ActionStatusMT - OpPlanID UCI Extension Field	565
Table A-4-839: Peer Interface MA_ActionStatusMT - MessageData UCI Extension Field	566
Table A-4-840: Peer Interface MA_ActionStatusMT - ExecutingSystemOrPackage UCI Extension Field	566
Table A-4-841: Peer Interface MA_AssessmentMT UCI Extension	566
Table A-4-842: Peer Interface MA_AssessmentMT - MessageData UCI Extension Field	567
Table A-4-843: Peer Interface MA_AssessmentMT - Assessment UCI Extension Field.....	568
Table A-4-844: Peer Interface MA_AssessmentRequestMT UCI Extension.....	568
Table A-4-845: Peer Interface MA_AssessmentRequestMT - MessageData UCI Extension Field...	569
Table A-4-846: Peer Interface MA_AssessmentRequestMT - Category UCI Extension Field	570
Table A-4-847: Peer Interface MA_AssessmentRequestStatusMT UCI Extension.....	570
Table A-4-848: Peer Interface MA_AssessmentRequestStatusMT - Assessment UCI Extension Field	571
Table A-4-849: Peer Interface MA_AssessmentRequestStatusMT - MessageData UCI Extension Field	571
Table A-4-850: Peer Interface MA_OperatorRoleMT UCI Extension	572
Table A-4-851: Peer Interface MA_OperatorRoleMT - SystemID UCI Extension Field.....	572
Table A-4-852: Peer Interface MA_ActionPlanValidationMT UCI Extension.....	572
Table A-4-853: Peer Interface MA_ActionPlanValidationMT - AllocationResult UCI Extension Field.....	573
Table A-4-854: Peer Interface MA_ActionPlanValidationMT - OpPlanID UCI Extension Field	573
Table A-4-855: Peer Interface MA_ActionPlanValidationMT - MessageData UCI Extension Field...	574
Table A-4-856: Peer Interface MA_ActionPlanValidationMT - AssociatedPlans UCI Extension Field	575
Table A-4-857: Peer Interface MA_ApprovalPolicyMT UCI Extension.....	576
Table A-4-858: Peer Interface MA_ApprovalPolicyMT - TaskPlan UCI Extension Field	576
Table A-4-859: Peer Interface MA_ApprovalPolicyMT - OpLineCategory UCI Extension Field	577
Table A-4-860: Peer Interface MA_ApprovalPolicyMT - ActivityPlan UCI Extension Field	578
Table A-4-861: Peer Interface MA_ApprovalPolicyMT - ApplicablePlanningActivity UCI Extension Field	579
Table A-4-862: Peer Interface MA_ApprovalPolicyMT - OpVolumeCategory UCI Extension Field ..	581
Table A-4-863: Peer Interface MA_ApprovalPolicyMT - TaskType UCI Extension Field	582
Table A-4-864: Peer Interface MA_ApprovalPolicyMT - OrbitActivityPlan UCI Extension Field.....	582
Table A-4-865: Peer Interface MA_ApprovalPolicyMT - MessageData UCI Extension Field.....	583
Table A-4-866: Peer Interface MA_ApprovalPolicyMT - OpZoneCategory UCI Extension Field	585

Table A-4-867: Peer Interface MA_ApprovalPolicyMT - ByPlanParts UCI Extension Field	586
Table A-4-868: Peer Interface MA_ApprovalPolicyMT - CapabilityCommand UCI Extension Field ..	587
Table A-4-869: Peer Interface MA_ApprovalPolicyMT - PlanParts UCI Extension Field	588
Table A-4-870: Peer Interface MA_ApprovalPolicyMT - Plans UCI Extension Field	589
Table A-4-871: Peer Interface MA_ApprovalPolicyMT - RouteActivityPlan UCI Extension Field	590
Table A-4-872: Peer Interface MA_ApprovalPolicyMT - OpPlan UCI Extension Field	590
Table A-4-873: Peer Interface MA_ApprovalPolicyMT - PlanActivation UCI Extension Field	591
Table A-4-874: Peer Interface MA_OpLineMT UCI Extension	591
Table A-4-875: Peer Interface MA_OpLineMT - Category UCI Extension Field.....	592
Table A-4-876: Peer Interface MA_OpLineMT - AppliesToIDs UCI Extension Field.....	592
Table A-4-877: Peer Interface MA_OpLineMT - MessageData UCI Extension Field	594
Table A-4-878: Peer Interface MA_OpPointMT UCI Extension.....	594
Table A-4-879: Peer Interface MA_OpPointMT - MessageData UCI Extension Field.....	595
Table A-4-880: Peer Interface MA_OpPointMT - AppliesToIDs UCI Extension Field	596
Table A-4-881: Peer Interface MA_OpRoutingMT UCI Extension	596
Table A-4-882: Peer Interface MA_OpRoutingMT - ApplicableToIDs UCI Extension Field	596
Table A-4-883: Peer Interface MA_OpRoutingMT - MessageData UCI Extension Field	597
Table A-4-884: Peer Interface MA_PlanningFunctionSettingsCommandMT UCI Extension	598
Table A-4-885: Peer Interface MA_PlanningFunctionSettingsCommandMT - AutonomousPlanningAction UCI Extension Field	599
Table A-4-886: Peer Interface MA_PlanningFunctionSettingsCommandMT - OpPlan UCI Extension Field	599
Table A-4-887: Peer Interface MA_PlanningFunctionSettingsCommandMT - AutonomousPlanningResponseChoice UCI Extension Field	599
Table A-4-888: Peer Interface MA_PlanningFunctionSettingsCommandMT - MissionPlanningAutonomy UCI Extension Field	600
Table A-4-889: Peer Interface MA_PlanningFunctionSettingsCommandMT - OrbitActivityPlan UCI Extension Field	601
Table A-4-890: Peer Interface MA_PlanningFunctionSettingsCommandMT - RouteActivityPlan UCI Extension Field	602
Table A-4-891: Peer Interface MA_PlanningFunctionSettingsCommandMT - ByResultSetting UCI Extension Field	602
Table A-4-892: Peer Interface MA_PlanningFunctionSettingsCommandMT - PlanningAllowed UCI Extension Field	603
Table A-4-893: Peer Interface MA_PlanningFunctionSettingsCommandMT - OutputPlanParts UCI Extension Field	604

Table A-4-894: Peer Interface MA_PlanningFunctionSettingsCommandMT - AllowedType UCI Extension Field	605
Table A-4-895: Peer Interface MA_PlanningFunctionSettingsCommandMT - AutonomousAction UCI Extension Field	605
Table A-4-896: Peer Interface MA_PlanningFunctionSettingsCommandMT - MessageData UCI Extension Field	606
Table A-4-897: Peer Interface MA_PlanningFunctionSettingsCommandMT - ActivityPlan UCI Extension Field	607
Table A-4-898: Peer Interface MA_PlanningFunctionSettingsCommandMT - TaskPlan UCI Extension Field	607
Table A-4-899: Peer Interface MA_PlanningFunctionSettingsCommandStatusMT UCI Extension ..	607
Table A-4-900: Peer Interface MA_PlanningFunctionSettingsCommandStatusMT - MessageData UCI Extension Field	608
Table A-4-901: Peer Interface MA_ResponseActivityMT UCI Extension	608
Table A-4-902: Peer Interface MA_ResponseActivityMT - RequirementInstantiation UCI Extension Field	608
Table A-4-903: Peer Interface MA_ResponseActivityMT - ActivatedPlans UCI Extension Field.....	609
Table A-4-904: Peer Interface MA_ResponseActivityMT - Activity UCI Extension Field	611
Table A-4-905: Peer Interface MA_ResponseActivityMT - MessageData UCI Extension Field	611
Table A-4-906: Peer Interface MA_ResponseActivityMT - ResultingPlans UCI Extension Field	612
Table A-4-907: Peer Interface MA_ResponseActivityMT - OpPlanID UCI Extension Field.....	612
Table A-4-908: Peer Interface MA_TaskStatusMT UCI Extension.....	612
Table A-4-909: Peer Interface MA_TaskStatusMT - Plans UCI Extension Field.....	613
Table A-4-910: Peer Interface MA_TaskStatusMT - OpPlanID UCI Extension Field	614
Table A-4-911: Peer Interface MA_TaskStatusMT - ExecutingSystemOrPackage UCI Extension Field	614
Table A-4-912: Peer Interface MA_TaskStatusMT - MessageData UCI Extension Field.....	615
Table A-4-913: Peer Interface MA_TaskStatusMT - Traceability UCI Extension Field	616
Table A-4-914: Peer Interface MA_PlanModificationRequestMT UCI Extension	616
Table A-4-915: Peer Interface MA_PlanModificationRequestMT - SubPlansAdditions UCI Extension Field	617
Table A-4-916: Peer Interface MA_PlanModificationRequestMT - SubPlansRetractions UCI Extension Field	618
Table A-4-917: Peer Interface MA_PlanModificationRequestMT - SubPlansModification UCI Extension Field	618
Table A-4-918: Peer Interface MA_PlanModificationRequestMT - PlanModificationDetails UCI Extension Field	619

Table A-4-919: Peer Interface MA_PlanModificationRequestMT - MessageData UCI Extension Field	619
Table A-4-920: Peer Interface MA_PlanModificationRequestMT - Plans UCI Extension Field	620
Table A-4-921: Peer Interface MA_PlanModificationRequestMT - OpPlanID UCI Extension Field...	621
Table A-4-922: Peer Interface MA_PlanModificationRequestStatusMT UCI Extension	621
Table A-4-923: Peer Interface MA_PlanModificationRequestStatusMT - MessageData UCI Extension Field	621
Table A-4-924: Peer Interface MA_ConstraintPriorityListActivationDataMT UCI Extension	621
Table A-4-925: Peer Interface MA_ConstraintPriorityListActivationDataMT - MessageData UCI Extension Field	622
Table A-4-926: Peer Interface MA_ConstraintPriorityListMT UCI Extension	622
Table A-4-927: Peer Interface MA_ConstraintPriorityListMT - MessageData UCI Extension Field...	623
Table A-4-928: Peer Interface MA_EscortActivityMT UCI Extension	623
Table A-4-929: Peer Interface MA_EscortActivityMT - MessageData UCI Extension Field	623
Table A-4-930: Peer Interface MA_PositionReportDetailedMT UCI Extension	623
Table A-4-931: Peer Interface MA_PositionReportDetailedMT - PositionReportData UCI Extension Field	625
Table A-4-932: Peer Interface MA_PositionReportDetailedMT - MessageData UCI Extension Field	625
Table A-4-933: Peer Interface MA_EngagementCriteriaMT UCI Extension	625
Table A-4-934: Peer Interface MA_EngagementCriteriaMT - MessageData UCI Extension Field...	626
Table A-4-935: Peer Interface MA_ExecutionPriorityListMT UCI Extension	626
Table A-4-936: Peer Interface MA_ExecutionPriorityListMT - MessageData UCI Extension Field ...	626
Table A-4-937: Peer Interface MA_ExecutionPriorityListActivationDataMT UCI Extension	627
Table A-4-938: Peer Interface MA_ExecutionPriorityListActivationDataMT - MessageData UCI Extension Field	627
Table A-4-939: Peer Interface MA_MessageAcknowledgmentConfigurationMT UCI Extension	627
Table A-4-940: Peer Interface MA_MessageAcknowledgmentConfigurationMT - MessageData UCI Extension Field	628
Table A-4-941: Peer Interface MA_MessageAcknowledgmentConfigurationRequestMT UCI Extension	628
Table A-4-942: Peer Interface MA_MessageAcknowledgmentConfigurationRequestMT - MessageData UCI Extension Field	629
Table A-4-943: Peer Interface MA_MessageAcknowledgmentConfigurationRequestStatusMT UCI Extension	629
Table A-4-944: Peer Interface MA_MessageAcknowledgmentConfigurationRequestStatusMT -	

MessageData UCI Extension Field	629
Table A-4-945: Peer Interface MA_ResponseCommandMT UCI Extension	630
Table A-4-946: Peer Interface MA_ResponseCommandMT - MessageData UCI Extension Field ...	630
Table A-4-947: Peer Interface MA_ResponseCommandStatusMT UCI Extension	630
Table A-4-948: Peer Interface MA_ResponseCommandStatusMT - MessageData UCI Extension Field	631
Table A-4-949: Peer Interface MA_PlatformOverrideStatusMT UCI Extension	631
Table A-4-950: Peer Interface MA_PlatformOverrideStatusMT - MessageData UCI Extension Field	632
Table A-4-951: Peer Interface MA_GatewayActivityMT UCI Extension	632
Table A-4-952: Peer Interface MA_GatewayActivityMT - ObjectState UCI Extension Field	633
Table A-4-953: Peer Interface MA_GatewayActivityMT - MessageData UCI Extension Field	633
Table A-4-954: Peer Interface MA_DataDisseminationPlanOverrideRequestMT UCI Extension	633
Table A-4-955: Peer Interface MA_DataDisseminationPlanOverrideRequestMT - MessageData UCI Extension Field	634
Table A-4-956: Peer Interface MA_DataDisseminationPlanOverrideRequestStatusMT UCI Extension	634
Table A-4-957: Peer Interface MA_DataDisseminationPlanOverrideRequestStatusMT - MessageData UCI Extension Field	635
Table A-4-958: Peer Interface MA_DataDisseminationPlanActivationCommandStatusMT UCI Extension	635
Table A-4-959: Peer Interface MA_DataDisseminationPlanActivationCommandStatusMT - MessageData UCI Extension Field	635
Table A-4-960: Peer Interface MA_DataDisseminationPlanActivationCommandMT UCI Extension	636
Table A-4-961: Peer Interface MA_DataDisseminationPlanActivationCommandMT - MessageData UCI Extension Field	636
Table A-4-962: Peer Interface MA_DataDisseminationPlanMT UCI Extension	637
Table A-4-963: Peer Interface MA_DataDisseminationPlanMT - ObjectState UCI Extension Field ..	637
Table A-4-964: Peer Interface MA_DataDisseminationPlanMT - MessageData UCI Extension Field	638
Table A-4-965: Peer Interface MA_DataDisseminationPlanActivationStatusMT UCI Extension	638
Table A-4-966: Peer Interface MA_DataDisseminationPlanActivationStatusMT - MessageData UCI Extension Field	639
Table A-4-967: Mission Plan Interface MA_EffectCapabilityMT UCI Extension	639
Table A-4-968: Mission Plan Interface MA_EffectCapabilityMT - AssociatedTaskType UCI Extension Field	640

Table A-4-969: Mission Plan Interface MA_EntityMT UCI Extension.....	640
Table A-4-970: Mission Plan Interface MA_EntityMT - ObjectState UCI Extension Field	641
Table A-4-971: Mission Plan Interface MA_EntityMT - MessageData UCI Extension Field.....	643
Table A-4-972: Mission Plan Interface MA_ActionCapabilityMT UCI Extension	644
Table A-4-973: Mission Plan Interface MA_ActionCapabilityMT - AssociatedTaskType UCI Extension Field	645
Table A-4-974: Mission Plan Interface MA_ActionCapabilityMT - Capability UCI Extension Field ...	646
Table A-4-975: Mission Plan Interface MA_ActionCapabilityMT - MessageData UCI Extension Field	646
Table A-4-976: Mission Plan Interface MA_ActionMT UCI Extension.....	647
Table A-4-977: Mission Plan Interface MA_ActionMT - MessageData UCI Extension Field.....	648
Table A-4-978: Mission Plan Interface MA_ActionPlanMT UCI Extension.....	648
Table A-4-979: Mission Plan Interface MA_ActionPlanMT - MessageData UCI Extension Field.....	649
Table A-4-980: Mission Plan Interface MA_ActivityPlanMT UCI Extension	649
Table A-4-981: Mission Plan Interface MA_ActivityPlanMT - MessageData UCI Extension Field ...	649
Table A-4-982: Mission Plan Interface MA_AMTI_CapabilityMT UCI Extension.....	650
Table A-4-983: Mission Plan Interface MA_AMTI_CapabilityMT - MessageData UCI Extension Field	650
Table A-4-984: Mission Plan Interface MA_AMTI_CapabilityMT - Capability UCI Extension Field ...	652
Table A-4-985: Mission Plan Interface MA_ApprovalAuthorityMT UCI Extension.....	652
Table A-4-986: Mission Plan Interface MA_ApprovalAuthorityMT - MessageData UCI Extension Field	652
Table A-4-987: Mission Plan Interface MA_ApprovalAuthorityMT - ApplicableIDs UCI Extension Field	653
Table A-4-988: Mission Plan Interface MA_ApprovalPolicyMT UCI Extension	653
Table A-4-989: Mission Plan Interface MA_ApprovalPolicyMT - TaskPlan UCI Extension Field	654
Table A-4-990: Mission Plan Interface MA_ApprovalPolicyMT - OpLineCategory UCI Extension Field	655
Table A-4-991: Mission Plan Interface MA_ApprovalPolicyMT - ActivityPlan UCI Extension Field...	655
Table A-4-992: Mission Plan Interface MA_ApprovalPolicyMT - ApplicablePlanningActivity UCI Extension Field	656
Table A-4-993: Mission Plan Interface MA_ApprovalPolicyMT - OpVolumeCategory UCI Extension Field	658
Table A-4-994: Mission Plan Interface MA_ApprovalPolicyMT - TaskType UCI Extension Field	659
Table A-4-995: Mission Plan Interface MA_ApprovalPolicyMT - OrbitActivityPlan UCI Extension Field	660

Table A-4-996: Mission Plan Interface MA_ApprovalPolicyMT - MessageData UCI Extension Field	661
Table A-4-997: Mission Plan Interface MA_ApprovalPolicyMT - OpZoneCategory UCI Extension Field	663
Table A-4-998: Mission Plan Interface MA_ApprovalPolicyMT - ByPlanParts UCI Extension Field	664
Table A-4-999: Mission Plan Interface MA_ApprovalPolicyMT - CapabilityCommand UCI Extension Field	665
Table A-4-1000: Mission Plan Interface MA_ApprovalPolicyMT - PlanParts UCI Extension Field	665
Table A-4-1001: Mission Plan Interface MA_ApprovalPolicyMT - Plans UCI Extension Field	666
Table A-4-1002: Mission Plan Interface MA_ApprovalPolicyMT - RouteActivityPlan UCI Extension Field	667
Table A-4-1003: Mission Plan Interface MA_ApprovalPolicyMT - OpPlan UCI Extension Field	668
Table A-4-1004: Mission Plan Interface MA_ApprovalPolicyMT - PlanActivation UCI Extension Field	668
Table A-4-1005: Mission Plan Interface MA_AssessmentMT UCI Extension	668
Table A-4-1006: Mission Plan Interface MA_AssessmentMT - MessageData UCI Extension Field	669
Table A-4-1007: Mission Plan Interface MA_AssessmentMT - Assessment UCI Extension Field	670
Table A-4-1008: Mission Plan Interface MA_AuthorizationMT UCI Extension	671
Table A-4-1009: Mission Plan Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field	671
Table A-4-1010: Mission Plan Interface MA_AuthorizationMT - CapabilityTaxonomy UCI Extension Field	673
Table A-4-1011: Mission Plan Interface MA_AuthorizationMT - Opaque UCI Extension Field	673
Table A-4-1012: Mission Plan Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field	674
Table A-4-1013: Mission Plan Interface MA_AuthorizationMT - CapabilityCommand UCI Extension Field	675
Table A-4-1014: Mission Plan Interface MA_AuthorizationMT - CapabilitySettingTypes UCI Extension Field	676
Table A-4-1015: Mission Plan Interface MA_AuthorizationMT - ByDataActivation UCI Extension Field	676
Table A-4-1016: Mission Plan Interface MA_AuthorizationMT - CAP UCI Extension Field	676
Table A-4-1017: Mission Plan Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field	677
Table A-4-1018: Mission Plan Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field	677
Table A-4-1019: Mission Plan Interface MA_AuthorizationMT - DataTypes UCI Extension Field	677
Table A-4-1020: Mission Plan Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension	

Field	678
Table A-4-1021: Mission Plan Interface MA_AuthorizationMT - CommTerminal UCI Extension Field	678
Table A-4-1022: Mission Plan Interface MA_AuthorizationMT - ByRequirementExecution UCI Extension Field	678
Table A-4-1023: Mission Plan Interface MA_AuthorizationMT - ByDataModification UCI Extension Field	679
Table A-4-1024: Mission Plan Interface MA_AuthorizationMT - ActivityPlan UCI Extension Field ...	679
Table A-4-1025: Mission Plan Interface MA_AuthorizationMT - MessageData UCI Extension Field	681
Table A-4-1026: Mission Plan Interface MA_AuthorizationMT - AuthorizedArea UCI Extension Field	681
Table A-4-1027: Mission Plan Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field	681
Table A-4-1028: Mission Plan Interface MA_AuthorizationMT - ByPlanActivation UCI Extension Field	682
Table A-4-1029: Mission Plan Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field	682
Table A-4-1030: Mission Plan Interface MA_AuthorizationMT - ByPlatformSettingsModification UCI Extension Field	682
Table A-4-1031: Mission Plan Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field	683
Table A-4-1032: Mission Plan Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field	683
Table A-4-1033: Mission Plan Interface MA_AuthorizationMT - RadarAltimeter UCI Extension Field	683
Table A-4-1034: Mission Plan Interface MA_AuthorizationMT - RequestTypes UCI Extension Field	684
Table A-4-1035: Mission Plan Interface MA_AuthorizationMT - ByPlanParts UCI Extension Field ..	684
Table A-4-1036: Mission Plan Interface MA_AuthorizationMT - AdditionalPlatformSettingTypes UCI Extension Field	685
Table A-4-1037: Mission Plan Interface MA_AuthorizationMT - IFF UCI Extension Field	685
Table A-4-1038: Mission Plan Interface MA_AuthorizationMT - RequirementTypes UCI Extension Field	685
Table A-4-1039: Mission Plan Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field	686
Table A-4-1040: Mission Plan Interface MA_AuthorizationMT - UserIdentifier UCI Extension Field	686
Table A-4-1041: Mission Plan Interface MA_AuthorizationMT - ByOperatorRequest UCI Extension Field	686

Table A-4-1042: Mission Plan Interface MA_CapabilitySetMT UCI Extension	687
Table A-4-1043: Mission Plan Interface MA_CapabilitySetMT - MessageData UCI Extension Field	687
Table A-4-1044: Mission Plan Interface MA_CarrierReportMT UCI Extension	688
Table A-4-1045: Mission Plan Interface MA_CarrierReportMT - LaunchCoordinates UCI Extension Field	688
Table A-4-1046: Mission Plan Interface MA_CarrierReportMT - Runway UCI Extension Field	689
Table A-4-1047: Mission Plan Interface MA_CarrierReportMT - CarrierReportID UCI Extension Field	689
Table A-4-1048: Mission Plan Interface MA_CarrierReportMT - Direction UCI Extension Field	689
Table A-4-1049: Mission Plan Interface MA_CarrierReportMT - Catapult UCI Extension Field	690
Table A-4-1050: Mission Plan Interface MA_CarrierReportMT - Information UCI Extension Field ...	690
Table A-4-1051: Mission Plan Interface MA_CarrierReportMT - CatapultID UCI Extension Field ...	691
Table A-4-1052: Mission Plan Interface MA_CarrierReportMT - MessageData UCI Extension Field	691
Table A-4-1053: Mission Plan Interface MA_CarrierReportMT - LandingCoordinates UCI Extension Field	691
Table A-4-1054: Mission Plan Interface MA_CarrierReportMT - Direction UCI Extension Field	692
Table A-4-1055: Mission Plan Interface MA_CarrierStateMT UCI Extension	692
Table A-4-1056: Mission Plan Interface MA_CarrierStateMT - CarrierStateID UCI Extension Field	692
Table A-4-1057: Mission Plan Interface MA_CarrierStateMT - CatapultID UCI Extension Field	693
Table A-4-1058: Mission Plan Interface MA_CarrierStateMT - Catapult UCI Extension Field	693
Table A-4-1059: Mission Plan Interface MA_CarrierStateMT - Runway UCI Extension Field	694
Table A-4-1060: Mission Plan Interface MA_CarrierStateMT - Information UCI Extension Field	694
Table A-4-1061: Mission Plan Interface MA_CarrierStateMT - MessageData UCI Extension Field	695
Table A-4-1062: Mission Plan Interface MA_ConstraintPriorityListActivationDataMT UCI Extension	695
Table A-4-1063: Mission Plan Interface MA_ConstraintPriorityListActivationDataMT - MessageData UCI Extension Field	696
Table A-4-1064: Mission Plan Interface MA_ConstraintPriorityListMT UCI Extension	696
Table A-4-1065: Mission Plan Interface MA_ConstraintPriorityListMT - MessageData UCI Extension Field	696
Table A-4-1066: Mission Plan Interface MA_DesignationMT UCI Extension	697
Table A-4-1067: Mission Plan Interface MA_DesignationMT - MessageData UCI Extension Field	697
Table A-4-1068: Mission Plan Interface MA_ExecutionPriorityListActivationDataMT UCI Extension	697
Table A-4-1069: Mission Plan Interface MA_ExecutionPriorityListActivationDataMT - MessageData UCI Extension Field	697

Table A-4-1070: Mission Plan Interface MA_ExecutionPriorityListMT UCI Extension	698
Table A-4-1071: Mission Plan Interface MA_ExecutionPriorityListMT - MessageData UCI Extension Field	698
Table A-4-1072: Mission Plan Interface MA_FlightCapabilityMT UCI Extension	698
Table A-4-1073: Mission Plan Interface MA_FlightCapabilityMT - HSA_CSA_PerformanceProfile UCI Extension Field	700
Table A-4-1074: Mission Plan Interface MA_FlightCapabilityMT - WaypointFollowingPerformanceProfile UCI Extension Field	701
Table A-4-1075: Mission Plan Interface MA_FlightCapabilityMT - CurveFollowingPerformanceProfile UCI Extension Field	702
Table A-4-1076: Mission Plan Interface MA_FlightCapabilityMT - AccelerationLimit UCI Extension Field	702
Table A-4-1077: Mission Plan Interface MA_FlightCapabilityMT - AccelerationLimitValue UCI Extension Field	703
Table A-4-1078: Mission Plan Interface MA_FlightCapabilityMT - BodyReferenceOrientationRate UCI Extension Field	703
Table A-4-1079: Mission Plan Interface MA_FlightCapabilityMT - OrientationRateLimits UCI Extension Field	704
Table A-4-1080: Mission Plan Interface MA_FlightCapabilityMT - AirspeedPair UCI Extension Field	704
Table A-4-1081: Mission Plan Interface MA_InteroperabilityPolicyMT UCI Extension	704
Table A-4-1082: Mission Plan Interface MA_InteroperabilityPolicyMT - MessageData UCI Extension Field	705
Table A-4-1083: Mission Plan Interface MA_LeadershipMetricsMT UCI Extension	705
Table A-4-1084: Mission Plan Interface MA_LeadershipMetricsMT - MessageData UCI Extension Field	706
Table A-4-1085: Mission Plan Interface MA_MissionPlanMT UCI Extension	706
Table A-4-1086: Mission Plan Interface MA_MissionPlanMT - MessageData UCI Extension Field ..	707
Table A-4-1087: Mission Plan Interface MA_OperatorRoleMT UCI Extension	707
Table A-4-1088: Mission Plan Interface MA_OperatorRoleMT - SystemID UCI Extension Field	708
Table A-4-1089: Mission Plan Interface MA_OpLineMT UCI Extension	708
Table A-4-1090: Mission Plan Interface MA_OpLineMT - Category UCI Extension Field	709
Table A-4-1091: Mission Plan Interface MA_OpLineMT - AppliesToIDs UCI Extension Field	709
Table A-4-1092: Mission Plan Interface MA_OpLineMT - MessageData UCI Extension Field	710
Table A-4-1093: Mission Plan Interface MA_OpPlanMT UCI Extension	710
Table A-4-1094: Mission Plan Interface MA_OpPlanMT - MessageData UCI Extension Field	711

Table A-4-1095: Mission Plan Interface MA_OpPointMT UCI Extension	711
Table A-4-1096: Mission Plan Interface MA_OpPointMT - MessageData UCI Extension Field	713
Table A-4-1097: Mission Plan Interface MA_OpPointMT - AppliesToIDs UCI Extension Field.....	713
Table A-4-1098: Mission Plan Interface MA_OpRoutingMT UCI Extension.....	713
Table A-4-1099: Mission Plan Interface MA_OpRoutingMT - ApplicableToIDs UCI Extension Field	714
Table A-4-1100: Mission Plan Interface MA_OpRoutingMT - MessageData UCI Extension Field....	715
Table A-4-1101: Mission Plan Interface MA_OpVolumeMT UCI Extension	715
Table A-4-1102: Mission Plan Interface MA_OpVolumeMT - MessageData UCI Extension Field	716
Table A-4-1103: Mission Plan Interface MA_OpZoneMT UCI Extension	717
Table A-4-1104: Mission Plan Interface MA_OpZoneMT - MessageData UCI Extension Field	719
Table A-4-1105: Mission Plan Interface MA_OpZoneMT - Category UCI Extension Field	721
Table A-4-1106: Mission Plan Interface MA_OpZoneMT - CategoryUniqueData UCI Extension Field	721
Table A-4-1107: Mission Plan Interface MA_OpZoneMT - SpeedLimits UCI Extension Field	722
Table A-4-1108: Mission Plan Interface MA_OpZoneMT - VehicleConfiguration UCI Extension Field	723
Table A-4-1109: Mission Plan Interface MA_OpZoneMT - Zone UCI Extension Field.....	723
Table A-4-1110: Mission Plan Interface MA_OpZoneMT - GeometryReference UCI Extension Field	723
Table A-4-1111: Mission Plan Interface MA_OpZoneMT - ReferenceObjectsFilter UCI Extension Field	724
Table A-4-1112: Mission Plan Interface MA_OpZoneMT - OpPointFilter UCI Extension Field	725
Table A-4-1113: Mission Plan Interface MA_OpZoneMT - OpLineFilter UCI Extension Field	725
Table A-4-1114: Mission Plan Interface MA_OpZoneMT - OpLineCategory UCI Extension Field	726
Table A-4-1115: Mission Plan Interface MA_OpZoneMT - OpZoneFilter UCI Extension Field	726
Table A-4-1116: Mission Plan Interface MA_OpZoneMT - OpZoneCategory UCI Extension Field...	729
Table A-4-1117: Mission Plan Interface MA_OpZoneMT - OpVolumeFilter UCI Extension Field	729
Table A-4-1118: Mission Plan Interface MA_OpZoneMT - OpVolumeCategory UCI Extension Field	731
Table A-4-1119: Mission Plan Interface MA_OpZoneMT - DMPI_Filter UCI Extension Field	731
Table A-4-1120: Mission Plan Interface MA_OpZoneMT - SignalReportFilter UCI Extension Field .	732
Table A-4-1121: Mission Plan Interface MA_OpZoneMT - OpVolumeFilter UCI Extension Field	732
Table A-4-1122: Mission Plan Interface MA_OpZoneMT - OpLineFilter UCI Extension Field	733
Table A-4-1123: Mission Plan Interface MA_OpZoneMT - OpLineCategory UCI Extension Field	734
Table A-4-1124: Mission Plan Interface MA_OpZoneMT - SpeedLimits UCI Extension Field	734

Table A-4-1125: Mission Plan Interface MA_OpZoneMT - SignalReportFilter UCI Extension Field	735
Table A-4-1126: Mission Plan Interface MA_OpZoneMT - OpPointFilter UCI Extension Field	735
Table A-4-1127: Mission Plan Interface MA_OpZoneMT - VehicleConfiguration UCI Extension Field	736
Table A-4-1128: Mission Plan Interface MA_OpZoneMT - DMPI_Filter UCI Extension Field	736
Table A-4-1129: Mission Plan Interface MA_OpZoneMT - Zone UCI Extension Field	736
Table A-4-1130: Mission Plan Interface MA_OpZoneMT - Category UCI Extension Field	739
Table A-4-1131: Mission Plan Interface MA_OpZoneMT - CategoryUniqueData UCI Extension Field	739
Table A-4-1132: Mission Plan Interface MA_OpZoneMT - ReferenceObjectsFilter UCI Extension Field	740
Table A-4-1133: Mission Plan Interface MA_OpZoneMT - OpVolumeCategory UCI Extension Field	742
Table A-4-1134: Mission Plan Interface MA_OpZoneMT - GeometryReference UCI Extension Field	743
Table A-4-1135: Mission Plan Interface MA_OpZoneMT - OpZoneCategory UCI Extension Field	745
Table A-4-1136: Mission Plan Interface MA_OpZoneMT - OpZoneFilter UCI Extension Field	745
Table A-4-1137: Mission Plan Interface MA_PlanningFunctionMT UCI Extension	746
Table A-4-1138: Mission Plan Interface MA_PlanningFunctionMT - Process UCI Extension Field	747
Table A-4-1139: Mission Plan Interface MA_PlanningFunctionMT - RouteActivityPlan UCI Extension Field	747
Table A-4-1140: Mission Plan Interface MA_PlanningFunctionMT - ActivityPlan UCI Extension Field	748
Table A-4-1141: Mission Plan Interface MA_PlanningFunctionMT - OpVolumeCategory UCI Extension Field	750
Table A-4-1142: Mission Plan Interface MA_PlanningFunctionMT - MissionPlan UCI Extension Field	751
Table A-4-1143: Mission Plan Interface MA_PlanningFunctionMT - MessageData UCI Extension Field	752
Table A-4-1144: Mission Plan Interface MA_PlanningFunctionMT - PlanningInterfaceDetails UCI Extension Field	753
Table A-4-1145: Mission Plan Interface MA_PlanningFunctionMT - TaskPlan UCI Extension Field	753
Table A-4-1146: Mission Plan Interface MA_PlanningFunctionMT - OrbitActivityPlan UCI Extension Field	754
Table A-4-1147: Mission Plan Interface MA_PlanningFunctionMT - OpZoneCategory UCI Extension Field	756
Table A-4-1148: Mission Plan Interface MA_PlanningFunctionMT - Output UCI Extension Field	757

Table A-4-1149: Mission Plan Interface MA_PlanningFunctionMT - CapabilityCommand UCI Extension Field	758
Table A-4-1150: Mission Plan Interface MA_PlanningFunctionMT - TaskType UCI Extension Field	759
Table A-4-1151: Mission Plan Interface MA_PlanningFunctionMT - OpLineCategory UCI Extension Field	760
Table A-4-1152: Mission Plan Interface MA_PlanningFunctionMT - OpPlan UCI Extension Field ...	760
Table A-4-1153: Mission Plan Interface MA_PrioritizationListMT UCI Extension.....	760
Table A-4-1154: Mission Plan Interface MA_PrioritizationListMT - ListType UCI Extension Field	762
Table A-4-1155: Mission Plan Interface MA_PrioritizationListMT - ListItem UCI Extension Field	762
Table A-4-1156: Mission Plan Interface MA_PrioritizationListMT - MessageData UCI Extension Field	763
Table A-4-1157: Mission Plan Interface MA_ResponseMT UCI Extension.....	763
Table A-4-1158: Mission Plan Interface MA_ResponseMT - MessageData UCI Extension Field.....	765
Table A-4-1159: Mission Plan Interface MA_RouteActivityPlanMT UCI Extension.....	765
Table A-4-1160: Mission Plan Interface MA_RouteActivityPlanMT - MessageData UCI Extension Field	766
Table A-4-1161: Mission Plan Interface MA_RoutePlanMT UCI Extension	766
Table A-4-1162: Mission Plan Interface MA_RoutePlanMT - MessageData UCI Extension Field	766
Table A-4-1163: Mission Plan Interface MA_EngagementCriteriaMT UCI Extension	767
Table A-4-1164: Mission Plan Interface MA_EngagementCriteriaMT - MessageData UCI Extension Field	767
Table A-4-1165: Mission Plan Interface MA_StrikeCapabilityMT UCI Extension	768
Table A-4-1166: Mission Plan Interface MA_StrikeCapabilityMT - MessageData UCI Extension Field	768
Table A-4-1167: Mission Plan Interface MA_TaskMT UCI Extension	769
Table A-4-1168: Mission Plan Interface MA_TaskMT - TaskType UCI Extension Field	770
Table A-4-1169: Mission Plan Interface MA_TaskMT - TaskPlurality UCI Extension Field.....	771
Table A-4-1170: Mission Plan Interface MA_TaskMT - ConstraintID UCI Extension Field	771
Table A-4-1171: Mission Plan Interface MA_TaskMT - HSA_CSA UCI Extension Field	771
Table A-4-1172: Mission Plan Interface MA_TaskMT - WaypointFollowing UCI Extension Field	772
Table A-4-1173: Mission Plan Interface MA_TaskMT - CurveFollowing UCI Extension Field	772
Table A-4-1174: Mission Plan Interface MA_TaskMT - Speed UCI Extension Field.....	772
Table A-4-1175: Mission Plan Interface MA_TaskMT - Heading UCI Extension Field.....	773
Table A-4-1176: Mission Plan Interface MA_TaskMT - SpeedChoice UCI Extension Field.....	773
Table A-4-1177: Mission Plan Interface MA_TaskMT - SpeedValue UCI Extension Field.....	773

Table A-4-1178: Mission Plan Interface MA_TaskMT - CurveFitMethod UCI Extension Field	774
Table A-4-1179: Mission Plan Interface MA_TaskPlanMT UCI Extension	774
Table A-4-1180: Mission Plan Interface MA_TaskPlanMT - MessageData UCI Extension Field	774
Table A-4-1181: Mission Plan Interface MA_WEZ_MT UCI Extension	775
Table A-4-1182: Mission Plan Interface MA_WEZ_MT - MessageData UCI Extension Field	775
Table A-4-1183: Mission Plan Interface MA_WEZ_MT - WEZ_ID UCI Extension Field	776
Table A-4-1184: Mission Plan Interface MA_WEZ_MT - WEZ_Data UCI Extension Field	778
Table A-4-1185: Mission Plan Interface MA_WEZ_MT - RangeTurnAndClose UCI Extension Field	778
Table A-4-1186: Mission Plan Interface MA_WEZ_MT - RangeMinimum UCI Extension Field	779
Table A-4-1187: Mission Plan Interface MA_WEZ_MT - RangeTurnAndRun UCI Extension Field	779
Table A-4-1188: Mission Plan Interface MA_WEZ_MT - RangeProbabilityOfIntercept UCI Extension Field	780
Table A-4-1189: Mission Plan Interface MA_WEZ_MT - RangeMaxGuidance UCI Extension Field	780
Table A-4-1190: Mission Plan Interface MA_WEZ_MT - RangeOptimal UCI Extension Field	780
Table A-4-1191: Mission Plan Interface MA_WEZ_MT - RangeMaxAero UCI Extension Field	781
Table A-4-1192: Mission Plan Interface MA_ResponsePlanMT UCI Extension	781
Table A-4-1193: Mission Plan Interface MA_ResponsePlanMT - ObjectState UCI Extension Field	782
Table A-4-1194: Mission Plan Interface MA_ResponsePlanMT - MessageData UCI Extension Field	782
Table A-4-1195: Mission Systems Interface MA_StrikeCapabilityMT UCI Extension	783
Table A-4-1196: Mission Systems Interface MA_StrikeCapabilityMT - MessageData UCI Extension Field	783
Table A-4-1197: Mission Systems Interface MA_CommErrorReportMT UCI Extension	783
Table A-4-1198: Mission Systems Interface MA_CommErrorReportMT - MessageData UCI Extension Field	784
Table A-4-1199: Mission Systems Interface MA_CommErrorReportMT - CommErrorReportID UCI Extension Field	784
Table A-4-1200: Mission Systems Interface MA_PositionReportDetailedMT UCI Extension	785
Table A-4-1201: Mission Systems Interface MA_PositionReportDetailedMT - PositionReportData UCI Extension Field	786
Table A-4-1202: Mission Systems Interface MA_PositionReportDetailedMT - MessageData UCI Extension Field	786
Table A-4-1203: Mission Systems Interface MA_CommAvailableEndpointsMT UCI Extension	786
Table A-4-1204: Mission Systems Interface MA_CommAvailableEndpointsMT - MessageData UCI Extension Field	787
Table A-4-1205: Mission Systems Interface MA_CommAvailableEndpointsMT -	

AvailableNetworkEndpoints UCI Extension Field	787
Table A-4-1206: Mission Systems Interface MA_CommAvailableEndpointsMT - MessageNumbering UCI Extension Field	787
Table A-4-1207: Mission Systems Interface MA_CommAvailableEndpointsMT - SystemID UCI Extension Field	788
Table A-4-1208: Mission Systems Interface MA_CommTeamReportMT UCI Extension	788
Table A-4-1209: Mission Systems Interface MA_CommTeamReportMT - MessageData UCI Extension Field	788
Table A-4-1210: Mission Systems Interface MA_CommTeamReportMT - AvailableEndpoint UCI Extension Field	788
Table A-4-1211: Mission Systems Interface MA_CommTeamReportMT - SystemID UCI Extension Field	789
Table A-4-1212: Mission Systems Interface MA_TaskMT UCI Extension	789
Table A-4-1213: Mission Systems Interface MA_TaskMT - TaskType UCI Extension Field	791
Table A-4-1214: Mission Systems Interface MA_TaskMT - TaskPlurality UCI Extension Field	791
Table A-4-1215: Mission Systems Interface MA_TaskMT - ConstraintID UCI Extension Field	792
Table A-4-1216: Mission Systems Interface MA_TaskMT - HSA_CSA UCI Extension Field	792
Table A-4-1217: Mission Systems Interface MA_TaskMT - WaypointFollowing UCI Extension Field	792
Table A-4-1218: Mission Systems Interface MA_TaskMT - CurveFollowing UCI Extension Field	793
Table A-4-1219: Mission Systems Interface MA_TaskMT - Speed UCI Extension Field	793
Table A-4-1220: Mission Systems Interface MA_TaskMT - Heading UCI Extension Field	793
Table A-4-1221: Mission Systems Interface MA_TaskMT - SpeedChoice UCI Extension Field	794
Table A-4-1222: Mission Systems Interface MA_TaskMT - SpeedValue UCI Extension Field	794
Table A-4-1223: Mission Systems Interface MA_TaskMT - CurveFitMethod UCI Extension Field ...	794
Table A-4-1224: Mission Systems Interface MA_TaskStatusMT UCI Extension	794
Table A-4-1225: Mission Systems Interface MA_TaskStatusMT - Plans UCI Extension Field	795
Table A-4-1226: Mission Systems Interface MA_TaskStatusMT - OpPlanID UCI Extension Field ...	796
Table A-4-1227: Mission Systems Interface MA_TaskStatusMT - ExecutingSystemOrPackage UCI Extension Field	796
Table A-4-1228: Mission Systems Interface MA_TaskStatusMT - MessageData UCI Extension Field	797
Table A-4-1229: Mission Systems Interface MA_TaskStatusMT - Traceability UCI Extension Field	798
Table A-4-1230: Mission Systems Interface MA_TaskCommandStatusMT UCI Extension	798
Table A-4-1231: Mission Systems Interface MA_TaskCommandStatusMT - MessageData UCI Extension Field	799

Table A-4-1232: Mission Systems Interface MA_TaskCommandMT UCI Extension	799
Table A-4-1233: Mission Systems Interface MA_TaskCommandMT - MessageData UCI Extension Field	799
Table A-4-1234: Mission Systems Interface MA_ActivityPlanMT UCI Extension.....	799
Table A-4-1235: Mission Systems Interface MA_ActivityPlanMT - MessageData UCI Extension Field	800
Table A-4-1236: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT UCI Extension	800
Table A-4-1237: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - MessageData UCI Extension Field	801
Table A-4-1238: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - AddTopicSubscription UCI Extension Field	801
Table A-4-1239: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - ChangeTopicSubscription UCI Extension Field	802
Table A-4-1240: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - DataPayloadOriginatorID UCI Extension Field.....	802
Table A-4-1241: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - SubscriptionID UCI Extension Field	803
Table A-4-1242: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - SubscriptionFilterType UCI Extension Field.....	803
Table A-4-1243: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - SubscriptionID UCI Extension Field	803
Table A-4-1244: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - SubscriptionChangeType UCI Extension Field	803
Table A-4-1245: Mission Systems Interface MA_RoutePlanMT UCI Extension.....	804
Table A-4-1246: Mission Systems Interface MA_RoutePlanMT - MessageData UCI Extension Field	804
Table A-4-1247: Mission Systems Interface MA_TaskPlanMT UCI Extension	804
Table A-4-1248: Mission Systems Interface MA_TaskPlanMT - MessageData UCI Extension Field.....	805
Table A-4-1249: Mission Systems Interface MA_TxDataPayloadCommandMT UCI Extension	805
Table A-4-1250: Mission Systems Interface MA_TxDataPayloadCommandMT - MessageData UCI Extension Field	806
Table A-4-1251: Mission Systems Interface MA_TxDataPayloadCommandMT - SpecificDestinationID UCI Extension Field	807
Table A-4-1252: Mission Systems Interface MA_WEZ_RequestMT UCI Extension	807
Table A-4-1253: Mission Systems Interface MA_WEZ_RequestMT - MessageData UCI Extension Field	808
Table A-4-1254: Mission Systems Interface MA_WEZ_RequestMT - WEZ_RequestData UCI	

Extension Field	808
Table A-4-1255: Mission Systems Interface MA_WEZ_RequestMT - WEZ_ChoiceType UCI	
Extension Field	809
Table A-4-1256: Mission Systems Interface MA_WEZ_RequestMT - StaticWEZ UCI Extension Field	
.....	809
Table A-4-1257: Mission Systems Interface MA_WEZ_RequestMT - PlannedStaticWEZ UCI	
Extension Field	809
Table A-4-1258: Mission Systems Interface MA_WEZ_RequestMT - PredictedWEZ UCI Extension	
Field	810
Table A-4-1259: Mission Systems Interface MA_WEZ_RequestMT - PlannedPredictedWEZ UCI	
Extension Field	810
Table A-4-1260: Mission Systems Interface MA_WEZ_RequestMT - WEZ_FieldOfView UCI	
Extension Field	811
Table A-4-1261: Mission Systems Interface MA_WEZ_RequestMT - PlannedReleaseConditions UCI	
Extension Field	811
Table A-4-1262: Mission Systems Interface MA_WEZ_RequestMT - WEZ_FieldOfView UCI	
Extension Field	812
Table A-4-1263: Mission Systems Interface MA_WEZ_RequestMT - WEZ_FieldOfView UCI	
Extension Field	812
Table A-4-1264: Mission Systems Interface MA_WEZ_RequestMT - PlannedReleaseConditions UCI	
Extension Field	813
Table A-4-1265: Mission Systems Interface MA_WEZ_RequestMT - PredictedTargetStateData UCI	
Extension Field	813
Table A-4-1266: Mission Systems Interface MA_WEZ_RequestMT - WEZ_FieldOfView UCI	
Extension Field	813
Table A-4-1267: Mission Systems Interface MA_WEZ_RequestMT - PredictedTargetStateData UCI	
Extension Field	814
Table A-4-1268: Mission Systems Interface MA_RouteActivityPlanMT UCI Extension	814
Table A-4-1269: Mission Systems Interface MA_RouteActivityPlanMT - MessageData UCI Extension	
Field	815
Table A-4-1270: Mission Systems Interface MA_FaultMT UCI Extension	815
Table A-4-1271: Mission Systems Interface MA_FaultMT - MessageData UCI Extension Field	815
Table A-4-1272: Mission Systems Interface MA_FaultMT - FaultInformation UCI Extension Field...	817
Table A-4-1273: Mission Systems Interface MA_FaultMT - Severity UCI Extension Field	817
Table A-4-1274: Mission Systems Interface MA_MessagingSubscriptionSettingCommandStatusMT	
UCI Extension	817
Table A-4-1275: Mission Systems Interface MA_MessagingSubscriptionSettingCommandStatusMT -	
MessageData UCI Extension Field	818

Table A-4-1276: Mission Systems Interface MA_RxDataPayloadMT UCI Extension	818
Table A-4-1277: Mission Systems Interface MA_RxDataPayloadMT - MessageData UCI Extension Field	819
Table A-4-1278: Mission Systems Interface MA_TxDataPayloadCommandStatusMT UCI Extension	819
Table A-4-1279: Mission Systems Interface MA_TxDataPayloadCommandStatusMT - MessageData UCI Extension Field	820
Table A-4-1280: Mission Systems Interface MA_WEZ_MT UCI Extension	820
Table A-4-1281: Mission Systems Interface MA_WEZ_MT - MessageData UCI Extension Field	821
Table A-4-1282: Mission Systems Interface MA_WEZ_MT - WEZ_ID UCI Extension Field	821
Table A-4-1283: Mission Systems Interface MA_WEZ_MT - WEZ_Data UCI Extension Field	823
Table A-4-1284: Mission Systems Interface MA_WEZ_MT - RangeTurnAndClose UCI Extension Field	823
Table A-4-1285: Mission Systems Interface MA_WEZ_MT - RangeMinimum UCI Extension Field .	824
Table A-4-1286: Mission Systems Interface MA_WEZ_MT - RangeTurnAndRun UCI Extension Field	824
Table A-4-1287: Mission Systems Interface MA_WEZ_MT - RangeProbabilityOfIntercept UCI Extension Field	825
Table A-4-1288: Mission Systems Interface MA_WEZ_MT - RangeMaxGuidance UCI Extension Field	825
Table A-4-1289: Mission Systems Interface MA_WEZ_MT - RangeOptimal UCI Extension Field....	826
Table A-4-1290: Mission Systems Interface MA_WEZ_MT - RangeMaxAero UCI Extension Field..	826
Table A-4-1291: Mission Systems Interface MA_WEZ_RequestStatusMT UCI Extension	827
Table A-4-1292: Mission Systems Interface MA_WEZ_RequestStatusMT - MessageData UCI Extension Field	827
Table A-4-1293: Mission Systems Interface MA_WEZ_RequestStatusMT - WeaponEngagementZone UCI Extension Field	827
Table A-4-1294: Mission Systems Interface MA_WEZ_RequestStatusMT - WEZ_ID UCI Extension Field	828
Table A-4-1295: Mission Systems Interface MA_WEZ_RequestStatusMT - WEZ_Data UCI Extension Field	830
Table A-4-1296: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeTurnAndClose UCI Extension Field	830
Table A-4-1297: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeMinimum UCI Extension Field	831
Table A-4-1298: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeTurnAndRun UCI Extension Field	831

Table A-4-1299: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeProbabilityOfIntercept UCI Extension Field	832
Table A-4-1300: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeMaxGuidance UCI Extension Field	832
Table A-4-1301: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeOptimal UCI Extension Field	833
Table A-4-1302: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeMaxAero UCI Extension Field	833
Table A-4-1303: Mission Systems Interface MA_StrikeActivityMT UCI Extension	833
Table A-4-1304: Mission Systems Interface MA_StrikeActivityMT - ActiveWeaponHSA_CSA UCI Extension Field	834
Table A-4-1305: Mission Systems Interface MA_StrikeActivityMT - Direction UCI Extension Field ..	834
Table A-4-1306: Mission Systems Interface MA_StrikeActivityMT - MunitionActive UCI Extension Field	834
Table A-4-1307: Mission Systems Interface MA_StrikeActivityMT - MessageData UCI Extension Field	835
Table A-4-1308: Mission Systems Interface MA_StrikeActivityMT - ActiveWeaponState UCI Extension Field	835
Table A-4-1309: Mission Systems Interface MA_StrikeActivityMT - Activity UCI Extension Field.....	837
Table A-4-1310: Mission Systems Interface MA_StrikeActivityMT - Course UCI Extension Field	837
Table A-4-1311: Mission Systems Interface MA_StrikeActivityMT - Heading UCI Extension Field...	837
Table A-4-1312: Mission Systems Interface MA_StrikeActivityMT - Reference UCI Extension Field	837
Table A-4-1313: Mission Systems Interface MA_AMTI_CapabilityMT UCI Extension	838
Table A-4-1314: Mission Systems Interface MA_AMTI_CapabilityMT - MessageData UCI Extension Field	838
Table A-4-1315: Mission Systems Interface MA_AMTI_CapabilityMT - Capability UCI Extension Field	840
Table A-4-1316: Mission Systems Interface MA_MessagingSubscriptionStatusMT UCI Extension .	840
Table A-4-1317: Mission Systems Interface MA_MessagingSubscriptionStatusMT - MessageData UCI Extension Field	840
Table A-4-1318: Mission Systems Interface MA_MissionPlanValidationCommandMT UCI Extension	841
Table A-4-1319: Mission Systems Interface MA_MissionPlanValidationCommandMT - Inputs UCI Extension Field	841
Table A-4-1320: Mission Systems Interface MA_MissionPlanValidationCommandMT - OpLineCategory UCI Extension Field	842
Table A-4-1321: Mission Systems Interface MA_MissionPlanValidationCommandMT - TaskType UCI Extension Field	843

Table A-4-1322: Mission Systems Interface MA_MissionPlanValidationCommandMT - CapabilityCommand UCI Extension Field	844
Table A-4-1323: Mission Systems Interface MA_MissionPlanValidationCommandMT - PlanPart UCI Extension Field	845
Table A-4-1324: Mission Systems Interface MA_MissionPlanValidationCommandMT - TaskPlan UCI Extension Field	845
Table A-4-1325: Mission Systems Interface MA_MissionPlanValidationCommandMT - ActivityPlan UCI Extension Field	846
Table A-4-1326: Mission Systems Interface MA_MissionPlanValidationCommandMT - OpPlan UCI Extension Field	847
Table A-4-1327: Mission Systems Interface MA_MissionPlanValidationCommandMT - RouteActivityPlan UCI Extension Field	847
Table A-4-1328: Mission Systems Interface MA_MissionPlanValidationCommandMT - OpZoneCategory UCI Extension Field	850
Table A-4-1329: Mission Systems Interface MA_MissionPlanValidationCommandMT - OpVolumeCategory UCI Extension Field	852
Table A-4-1330: Mission Systems Interface MA_MissionPlanValidationCommandMT - OrbitActivityPlan UCI Extension Field	852
Table A-4-1331: Mission Systems Interface MA_MissionPlanValidationCommandMT - MessageData UCI Extension Field	853
Table A-4-1332: Mission Systems Interface MA_MissionPlanValidationCommandStatusMT UCI Extension	853
Table A-4-1333: Mission Systems Interface MA_MissionPlanValidationCommandStatusMT - MessageData UCI Extension Field	854
Table A-4-1334: Mission Systems Interface MA_SystemNotificationMT UCI Extension	855
Table A-4-1335: Mission Systems Interface MA_SystemNotificationMT - MessageData UCI Extension Field	856
Table A-4-1336: Mission Systems Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field	856
Table A-4-1337: Mission Systems Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field	856
Table A-4-1338: Mission Systems Interface MA_EntityMT UCI Extension	857
Table A-4-1339: Mission Systems Interface MA_EntityMT - ObjectState UCI Extension Field	857
Table A-4-1340: Mission Systems Interface MA_EntityMT - MessageData UCI Extension Field	860
Table A-4-1341: Mission Systems Interface MA_GatewayActivityMT UCI Extension	860
Table A-4-1342: Mission Systems Interface MA_GatewayActivityMT - ObjectState UCI Extension Field	861
Table A-4-1343: Mission Systems Interface MA_GatewayActivityMT - MessageData UCI Extension	

Field	861
Table A-4-1344: Mission Systems Interface MA_GatewayCommandMT UCI Extension	861
Table A-4-1345: Mission Systems Interface MA_GatewayCommandMT - MessageData UCI Extension Field	862
Table A-4-1346: Mission Systems Interface MA_GatewayCommandStatusMT UCI Extension	862
Table A-4-1347: Mission Systems Interface MA_GatewayCommandStatusMT - MessageData UCI Extension Field	862
Table A-4-1348: Mission Systems Interface MA_DataDisseminationPlanOverrideRequestMT UCI Extension	863
Table A-4-1349: Mission Systems Interface MA_DataDisseminationPlanOverrideRequestMT - MessageData UCI Extension Field	863
Table A-4-1350: Mission Systems Interface MA_DataDisseminationPlanOverrideRequestStatusMT UCI Extension	863
Table A-4-1351: Mission Systems Interface MA_DataDisseminationPlanOverrideRequestStatusMT - MessageData UCI Extension Field	864
Table A-4-1352: Mission Systems Interface MA_DataDisseminationPlanActivationCommandMT UCI Extension	864
Table A-4-1353: Mission Systems Interface MA_DataDisseminationPlanActivationCommandMT - MessageData UCI Extension Field	865
Table A-4-1354: Mission Systems Interface MA_DataDisseminationPlanActivationCommandStatusMT UCI Extension	865
Table A-4-1355: Mission Systems Interface MA_DataDisseminationPlanActivationCommandStatusMT - MessageData UCI Extension Field	866
Table A-4-1356: Mission Systems Interface MA_DataDisseminationPlanActivationStatusMT UCI Extension	866
Table A-4-1357: Mission Systems Interface MA_DataDisseminationPlanActivationStatusMT - MessageData UCI Extension Field	866
Table A-4-1358: Mission Systems Interface MA_DataDisseminationPlanMT UCI Extension	867
Table A-4-1359: Mission Systems Interface MA_DataDisseminationPlanMT - ObjectState UCI Extension Field	867
Table A-4-1360: Mission Systems Interface MA_DataDisseminationPlanMT - MessageData UCI Extension Field	868
Table A-4-1361: Vehicle Interface MA_FlightCapabilityMT UCI Extension	869
Table A-4-1362: Vehicle Interface MA_FlightCapabilityMT - HSA_CSA_PerformanceProfile UCI Extension Field	870
Table A-4-1363: Vehicle Interface MA_FlightCapabilityMT - WaypointFollowingPerformanceProfile UCI Extension Field	871
Table A-4-1364: Vehicle Interface MA_FlightCapabilityMT - CurveFollowingPerformanceProfile UCI	

Extension Field	872
Table A-4-1365: Vehicle Interface MA_FlightCapabilityMT - AccelerationLimit UCI Extension Field	872
Table A-4-1366: Vehicle Interface MA_FlightCapabilityMT - AccelerationLimitValue UCI Extension Field	873
Table A-4-1367: Vehicle Interface MA_FlightCapabilityMT - BodyReferenceOrientationRate UCI Extension Field	873
Table A-4-1368: Vehicle Interface MA_FlightCapabilityMT - OrientationRateLimits UCI Extension Field	874
Table A-4-1369: Vehicle Interface MA_FlightCapabilityMT - AirspeedPair UCI Extension Field	874
Table A-4-1370: Vehicle Interface MA_FlightCommandMT UCI Extension	875
Table A-4-1371: Vehicle Interface MA_FlightCommandMT - Command UCI Extension Field	875
Table A-4-1372: Vehicle Interface MA_FlightCommandMT - Capability UCI Extension Field	877
Table A-4-1373: Vehicle Interface MA_FlightCommandMT - HSA_CSA UCI Extension Field	877
Table A-4-1374: Vehicle Interface MA_FlightCommandMT - WaypointFollowing UCI Extension Field	877
Table A-4-1375: Vehicle Interface MA_FlightCommandMT - CurveFollowing UCI Extension Field..	878
Table A-4-1376: Vehicle Interface MA_FlightCommandMT - Speed UCI Extension Field	878
Table A-4-1377: Vehicle Interface MA_FlightCommandMT - Heading UCI Extension Field	878
Table A-4-1378: Vehicle Interface MA_FlightCommandMT - SpeedChoice UCI Extension Field	879
Table A-4-1379: Vehicle Interface MA_FlightCommandMT - SpeedValue UCI Extension Field	879
Table A-4-1380: Vehicle Interface MA_FlightCommandMT - CurveFitMethod UCI Extension Field.	879
Table A-4-1381: Vehicle Interface MA_FlightCommandMT - Reference UCI Extension Field	879
Table A-4-1382: Vehicle Interface MA_FlightCommandMT - ControlPoint UCI Extension Field	880
Table A-4-1383: Vehicle Interface MA_FlightCommandMT - RelativeAcceleration UCI Extension Field	881
Table A-4-1384: Vehicle Interface MA_FlightCommandMT - RelativeVelocity UCI Extension Field.	881
Table A-4-1385: Vehicle Interface MA_FlightCommandMT - OrientationRate UCI Extension Field .	881
Table A-4-1386: Vehicle Interface MA_FlightCommandMT - Direction UCI Extension Field	882
Table A-4-1387: Vehicle Interface MA_FlightCommandMT - Course UCI Extension Field	882
Table A-4-1388: Vehicle Interface MA_FlightCommandStatusMT UCI Extension	882
Table A-4-1389: Vehicle Interface MA_FlightCommandStatusMT - MessageData UCI Extension Field	883
Table A-4-1390: Vehicle Interface MA_FlightCommandStatusMT - CannotComplyDetails UCI Extension Field	883
Table A-4-1391: Vehicle Interface MA_FlightCommandStatusMT - Severity UCI Extension Field ...	884

Table A-4-1392: Vehicle Interface MA_FlightActivityMT UCI Extension	884
Table A-4-1393: Vehicle Interface MA_FlightActivityMT - VehicleCommandState UCI Extension Field	884
Table A-4-1394: Vehicle Interface MA_FlightActivityMT - Activity UCI Extension Field	886
Table A-4-1395: Vehicle Interface MA_FlightActivityMT - Speed UCI Extension Field	886
Table A-4-1396: Vehicle Interface MA_FlightActivityMT - Heading UCI Extension Field	886
Table A-4-1397: Vehicle Interface MA_PositionReportDetailedMT UCI Extension	887
Table A-4-1398: Vehicle Interface MA_PositionReportDetailedMT - PositionReportData UCI Extension Field	888
Table A-4-1399: Vehicle Interface MA_PositionReportDetailedMT - MessageData UCI Extension Field	888
Table A-4-1400: Vehicle Interface MA_NavigationReportMT UCI Extension	888
Table A-4-1401: Vehicle Interface MA_NavigationReportMT - MessageData UCI Extension Field ..	889
Table A-4-1402: Vehicle Interface MA_FaultMT UCI Extension	889
Table A-4-1403: Vehicle Interface MA_FaultMT - MessageData UCI Extension Field	889
Table A-4-1404: Vehicle Interface MA_FaultMT - FaultInformation UCI Extension Field	890
Table A-4-1405: Vehicle Interface MA_FaultMT - Severity UCI Extension Field	891
Table A-4-1406: Vehicle Interface MA_TaskMT UCI Extension	892
Table A-4-1407: Vehicle Interface MA_TaskMT - TaskType UCI Extension Field	893
Table A-4-1408: Vehicle Interface MA_TaskMT - TaskPlurality UCI Extension Field	894
Table A-4-1409: Vehicle Interface MA_TaskMT - ConstraintID UCI Extension Field	894
Table A-4-1410: Vehicle Interface MA_TaskMT - HSA_CSA UCI Extension Field	894
Table A-4-1411: Vehicle Interface MA_TaskMT - WaypointFollowing UCI Extension Field	895
Table A-4-1412: Vehicle Interface MA_TaskMT - CurveFollowing UCI Extension Field	895
Table A-4-1413: Vehicle Interface MA_TaskMT - Speed UCI Extension Field	895
Table A-4-1414: Vehicle Interface MA_TaskMT - Heading UCI Extension Field	896
Table A-4-1415: Vehicle Interface MA_TaskMT - SpeedChoice UCI Extension Field	896
Table A-4-1416: Vehicle Interface MA_TaskMT - SpeedValue UCI Extension Field	896
Table A-4-1417: Vehicle Interface MA_TaskMT - CurveFitMethod UCI Extension Field	897
Table A-4-1418: Vehicle Interface MA_RoutePlanMT UCI Extension	897
Table A-4-1419: Vehicle Interface MA_RoutePlanMT - MessageData UCI Extension Field	897
Table A-4-1420: Vehicle Interface MA_SystemManagementRequestMT UCI Extension	898
Table A-4-1421: Vehicle Interface MA_SystemManagementRequestMT - MessageData UCI Extension Field	898

Table A-4-1422: Vehicle Interface MA_SystemManagementRequestMT - RequestType UCI Extension Field	899
Table A-4-1423: Vehicle Interface MA_SystemManagementRequestMT - VehicleSettings UCI Extension Field	900
Table A-4-1424: Vehicle Interface MA_SystemManagementRequestStatusMT UCI Extension	900
Table A-4-1425: Vehicle Interface MA_SystemManagementRequestStatusMT - MessageData UCI Extension Field	900
Table A-4-1426: Vehicle Interface MA_MissionPlanActivationCommandMT UCI Extension	901
Table A-4-1427: Vehicle Interface MA_MissionPlanActivationCommandMT - OpPlanID UCI Extension Field	901
Table A-4-1428: Vehicle Interface MA_MissionPlanActivationCommandMT - ApplicableToIDs UCI Extension Field	902
Table A-4-1429: Vehicle Interface MA_MissionPlanActivationCommandMT - ByExecutionPlanSet UCI Extension Field	902
Table A-4-1430: Vehicle Interface MA_MissionPlanActivationCommandMT - MessageData UCI Extension Field	903
Table A-4-1431: Vehicle Interface MA_MissionPlanActivationCommandMT - ActivationDetails UCI Extension Field	903
Table A-4-1432: Vehicle Interface MA_MissionPlanActivationCommandMT - Applicability UCI Extension Field	904
Table A-4-1433: Vehicle Interface MA_MissionPlanActivationCommandMT - OpPlan UCI Extension Field	904
Table A-4-1434: Vehicle Interface MA_MissionPlanActivationCommandMT - Command UCI Extension Field	905
Table A-4-1435: Vehicle Interface MA_MissionPlanActivationCommandStatusMT UCI Extension ..	905
Table A-4-1436: Vehicle Interface MA_MissionPlanActivationCommandStatusMT - Plans UCI Extension Field	906
Table A-4-1437: Vehicle Interface MA_MissionPlanActivationCommandStatusMT - MessageData UCI Extension Field	906
Table A-4-1438: Vehicle Interface MA_MissionPlanActivationCommandStatusMT - ActivationCommandByState UCI Extension Field	906
Table A-4-1439: Vehicle Interface MA_FlightCapabilityStatusMT UCI Extension	907
Table A-4-1440: Vehicle Interface MA_FlightCapabilityStatusMT - Capability UCI Extension Field ..	908
Table A-4-1441: Vehicle Interface MA_FlightCapabilityStatusMT - MessageData UCI Extension Field	908
Table A-4-1442: Vehicle Interface MA_SystemNotificationMT UCI Extension	908
Table A-4-1443: Vehicle Interface MA_SystemNotificationMT - MessageData UCI Extension Field ..	909
Table A-4-1444: Vehicle Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field ..	

.....	910
Table A-4-1445: Vehicle Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field	910
Table A-4-1446: Vehicle Interface MA_TaskStatusMT UCI Extension	911
Table A-4-1447: Vehicle Interface MA_TaskStatusMT - Plans UCI Extension Field.....	911
Table A-4-1448: Vehicle Interface MA_TaskStatusMT - OpPlanID UCI Extension Field	912
Table A-4-1449: Vehicle Interface MA_TaskStatusMT - ExecutingSystemOrPackage UCI Extension Field	912
Table A-4-1450: Vehicle Interface MA_TaskStatusMT - MessageData UCI Extension Field	913
Table A-4-1451: Vehicle Interface MA_TaskStatusMT - Traceability UCI Extension Field	914
Table A-4-1452: Vehicle Interface MA_ResponseMT UCI Extension	914
Table A-4-1453: Vehicle Interface MA_ResponseMT - MessageData UCI Extension Field	916
Table A-4-1454: Vehicle Interface MA_MissionPlanExecutionStatusMT UCI Extension	916
Table A-4-1455: Vehicle Interface MA_MissionPlanExecutionStatusMT - ExecutionPlanSetStatus UCI Extension Field	916
Table A-4-1456: Vehicle Interface MA_MissionPlanExecutionStatusMT - PlanExecutionStatus UCI Extension Field	916
Table A-4-1457: Vehicle Interface MA_MissionPlanExecutionStatusMT - MessageData UCI Extension Field	917
Table A-4-1458: Vehicle Interface MA_MissionPlanActivationStatusMT UCI Extension	917
Table A-4-1459: Vehicle Interface MA_MissionPlanActivationStatusMT - OpPlanID UCI Extension Field	918
Table A-4-1460: Vehicle Interface MA_MissionPlanActivationStatusMT - MessageData UCI Extension Field	918
Table A-4-1461: Vehicle Interface MA_MissionPlanActivationStatusMT - Plans UCI Extension Field	919
Table A-4-1462: Vehicle Interface MA_MissionPlanActivationStatusMT - SubPlanActivationState UCI Extension Field	919
Table A-4-1463: Vehicle Interface MA_TaskCommandStatusMT UCI Extension	919
Table A-4-1464: Vehicle Interface MA_TaskCommandStatusMT - MessageData UCI Extension Field	920
Table A-4-1465: Vehicle Interface MA_TaskCommandMT UCI Extension	920
Table A-4-1466: Vehicle Interface MA_TaskCommandMT - MessageData UCI Extension Field	920
Table A-4-1467: Vehicle Interface MA_ActionStatusMT UCI Extension	921
Table A-4-1468: Vehicle Interface MA_ActionStatusMT - Traceability UCI Extension Field	921
Table A-4-1469: Vehicle Interface MA_ActionStatusMT - Plans UCI Extension Field	922

Table A-4-1470: Vehicle Interface MA_ActionStatusMT - OpPlanID UCI Extension Field	923
Table A-4-1471: Vehicle Interface MA_ActionStatusMT - MessageData UCI Extension Field	924
Table A-4-1472: Vehicle Interface MA_ActionStatusMT - ExecutingSystemOrPackage UCI Extension Field	924
Table A-4-1473: Vehicle Interface MA_PositionReportMT UCI Extension	924
Table A-4-1474: Vehicle Interface MA_PositionReportMT - MessageData UCI Extension Field	925
Table A-4-1475: Vehicle Interface MA_CarrierReportMT UCI Extension	925
Table A-4-1476: Vehicle Interface MA_CarrierReportMT - LaunchCoordinates UCI Extension Field	926
Table A-4-1477: Vehicle Interface MA_CarrierReportMT - Runway UCI Extension Field	927
Table A-4-1478: Vehicle Interface MA_CarrierReportMT - CarrierReportID UCI Extension Field	927
Table A-4-1479: Vehicle Interface MA_CarrierReportMT - Direction UCI Extension Field	927
Table A-4-1480: Vehicle Interface MA_CarrierReportMT - Catapult UCI Extension Field	928
Table A-4-1481: Vehicle Interface MA_CarrierReportMT - Information UCI Extension Field	928
Table A-4-1482: Vehicle Interface MA_CarrierReportMT - CatapultID UCI Extension Field	928
Table A-4-1483: Vehicle Interface MA_CarrierReportMT - MessageData UCI Extension Field	929
Table A-4-1484: Vehicle Interface MA_CarrierReportMT - LandingCoordinates UCI Extension Field	929
Table A-4-1485: Vehicle Interface MA_CarrierReportMT - Direction UCI Extension Field	929
Table A-4-1486: Vehicle Interface MA_CarrierLaunchReadyStatusMT UCI Extension	929
Table A-4-1487: Vehicle Interface MA_CarrierLaunchReadyStatusMT - MessageData UCI Extension Field	930
Table A-4-1488: Vehicle Interface MA_CarrierDeckHandlingCommandMT UCI Extension	930
Table A-4-1489: Vehicle Interface MA_CarrierDeckHandlingCommandMT - MessageData UCI Extension Field	930
Table A-4-1490: Vehicle Interface MA_CarrierDeckHandlingCommandStatusMT UCI Extension	931
Table A-4-1491: Vehicle Interface MA_CarrierDeckHandlingCommandStatusMT - MessageData UCI Extension Field	931

1 MISSION AUTONOMY L1 COMPLIANCE INTRODUCTION

The A-GRA prescribes compliance requirements for MA to meet the intended behavior as defined by the reference architecture. L1 interface compliance is defined at the system level, where the MA system is viewed as a black box interacting with external systems.

For an MA implementation to be compliant, all compliance requirements at a level must be met to achieve MA compliance for that level. No tiers of compliance or partial compliance are defined or allowed.

To claim L1 compliance, an MA L1 system must implement all compliance requirements for each implemented L1 interface as governed by the MA L1 Compliance Requirements, detailed in the MA L1 Interface Compliance References table. This implementation must be verified for compliance using the A-GRI Software Compliance Tool. For platforms/systems that support specific optional functionality, that functionality shall be implemented in a way that complies with the specified optional interfaces and sequences. Optional sequences do not mandate implementation of the defined feature for compliance; only that the given sequence is used when present. As a result, optional sequence messages are not contained within the MMS.

The A-GRA imposes L1 interface compliance requirements on C2, Peer, Mission Plan, Mission Systems, VI, and Mission Debrief interfaces. The C2, Peer, and VI L1 interfaces require implementation of an MMS and corresponding message interactions, defined by the sequence diagrams in this ICD. The Mission Systems L1 interface strictly follows the OMS standard, requiring implementation of the Mission Systems' OMS Service Contracts. The Mission Plan L1 interface is defined in this ICD as the minimum required Mission Data elements required per Mission Data Load. The MA L1 Interface Compliance References table summarizes the interface compliance information and points to document sections which define and discuss these requirements.

2 MISSION AUTONOMY L1 COMPLIANCE REQUIREMENTS

This section contains the compliance requirements for all Mission Autonomy L1 Interfaces.

2.1 C2 Interface Compliance Requirements

Table 2-1: C2 Interface Compliance Requirements

ID	Requirement
MA-L1-001	A Level 1 C2 interface shall support the C2 Interface Minimum Message Set defined in the C2 MMS table in the C2 feature profile (A-GRA location: 1 Problem Domain > 3 Exchange Items > Minimum Message Set (MMS)) for all messages in Core Mission Use Case sequences and all non-Core Mission Use Case sequences required for platform specific implementations.
MA-L1-002	A Level 1 C2 interface shall implement all required messaging sequences in the C2 feature profile (A-GRA location: 1 Problem Domain > 2 White Box > 3 Functional Analysis > L1 Functional Analysis > L1 Interface Behaviors > C2 Interface Behavior), marked Core and all non-Core Mission Use Case sequences that apply to the platform specific implementation.
MA-L1-017	Upon receipt of a Malformed Message (a message missing expected fields (i.e., required by the behavior but not the UCI schema) or with invalid context-dependent information within the scope of that individual message) from the C2 interface, MA shall respond to the error by notifying C2 of the malformed message and requesting the corrected message according to the Malformed Message Response (C2) sequence.
MA-L1-021	Upon receipt of any message from the C2 interface that is unauthorized according to C2's role and the RBAC configuration, MA shall respond in accordance with the C2 Unauthorized Response sequence, selecting the response message that corresponds to C2's unauthorized message the three tables (Unauthorized ActionRequest-2 Message Pairs, Unauthorized Command-2 Message Pairs, Unauthorized DataRequest-2 Message Pairs). The tables include primitive type, triggering message, and the specific unauthorization response message.
MA-L1-023	A Level 1 C2 interface shall follow state transitions for CommandProcessingState and RequestProcessingState in accordance with OAC-SPC-001 Rev C, Section 5.1.1.1 and 5.1.2.1. Representations of non-terminal statuses are optional and should align with the definitions and usage prescribed by the UCI Schema Style and Design Specification, ensuring consistent message state handling.

2.2 Mission Debrief Compliance Requirements

Table 2-2: Mission Debrief Compliance Requirements

ID	Requirement
MA-L1-015	A Level 1 Mission Debrief Interface shall support the external transfer of all debrief-relevant data sent on the ASB, with any necessary metadata.

2.3 Mission Plan Interface Compliance Requirements

Table 2-3: Mission Plan Interface Compliance Requirements

ID	Requirement
MA-L1-005	A Level 1 Mission Plan interface shall support the Mission Plan Interface Minimum Message Set defined in the MP MMS Table in the Mission Plan feature profile (A-GRA location: 1 Problem Domain > 3 Exchange Items > Minimum Message Set (MMS)) for all messages in Core Mission Use Case sequences and all non-Core Mission Use Case sequences required for platform specific implementations.
MA-L1-022	A Level 1 Mission Plan interface shall implement all required messaging sequences in the Mission Plan feature profile (A-GRA location: 1 Problem Domain > 2 White Box > 3 Functional Analysis > L1 Functional Analysis > L1 Interface Behaviors > Mission Plan Interface Behavior), marked Core and all non-Core Mission Use Case sequences that apply to the platform specific implementation.

2.4 Mission Systems Interface Compliance Requirements

Table 2-4: Mission Systems Interface Compliance Requirements

ID	Requirement
MA-L1-006	A Level 1 Mission Systems interface shall support the Mission Systems Interface Minimum Message Set defined in the MS MMS Table in the Mission Systems feature profile (A-GRA location: 1 Problem Domain > 3 Exchange Items > Minimum Message Set (MMS)) for all messages in Core Mission Use Case sequences and all non-Core Mission Use Case sequences required for platform specific implementations.
MA-L1-007	A Level 1 Mission Systems interface shall implement all required messaging sequences in the MS feature profile (A-GRA Location: 1 Problem Domain > 2 White Box > 3 Functional Analysis > L1 Functional Analysis > L1 Interface Behaviors > MS Interface Behavior), marked Core and all non-Core Mission Use Case sequences that apply to the platform specific implementation.
MA-L1-008	For a Level 1 Mission Systems interface, MA shall only communicate with Mission Systems via the platform hosted ASB.
MA-L1-009	The DMS's DDS middleware shall use the RTPS (Real-Time Publish-Subscribe) protocol, specifically the Simple Participant Discovery Protocol (SPDP) and Simple Endpoint Discovery Protocol (SEDP) for system discovery.
MA-L1-010	The DMS's DDS middleware shall use the MA_DataPayloadWrapper IDL (Interface Definition Language) to send messages OTA across all topics.
MA-L1-011	The DMS's DDS middleware shall use topic names that exactly match the message name of the EncodedPayload message. The only messages sent on that topic shall have an EncodedPayload that matches the corresponding topic name.
MA-L1-012	The DMS shall use a DDS middleware to handle OTA communication with other DMS instances.

ID	Requirement
MA-L1-019	Upon receipt of a Malformed Message (a message missing expected fields (i.e., required by the behavior but not the UCI schema) or with invalid context-dependent information within the scope of that individual message) from the MS interface, MA shall respond to the error by notifying MS of the malformed message and requesting the corrected message according to the Malformed Message Response (MS) sequence.
MA-L1-025	The DMS shall use the EXI standard for the MA_DataPayloadWrapper IDL EncodedPayload field using the settings table found in the "Serialization and Data Encoding" section of the L1 MA ICD. The contents to decode/encode will come from the EncodedPayload field within the MA_TxDataPayloadCommandMT. The datatype of the MA_TxDataPayloadCommandMT/MA_RxDataPayloadMT EncodedPayload fields is UTF-8 XML represented as hexBinary.

2.5 OMS Compliance Requirements

Table 2-5: OMS Compliance Requirements

ID	Requirement
MA-L1-016	For an OMS custom message that is not defined in the Minimum Message Sets (MMSs) defined in this model, the custom message format shall conform to all relevant requirements and guidance in OAC-SPC-001, the UCI Schema Style and Design Specification.

2.6 Peer Interface Compliance Requirements

Table 2-6: Peer Interface Compliance Requirements

ID	Requirement
MA-L1-003	A Level 1 Peer interface shall support the Peer Interface Minimum Message Set defined in the Peer MMS table in the Peer feature profile (A-GRA location: 1 Problem Domain > 3 Exchange Items > Minimum Message Set (MMS)) for all messages in Core Mission Use Case sequences and all non-Core Mission Use Case sequences required for platform specific implementations.
MA-L1-004	A Level 1 Peer interface shall implement all required messaging sequences in the Peer feature profile (A-GRA location: 1 Problem Domain > 2 White Box > 3 Functional Analysis > L1 Functional Analysis > L1 Interface Behaviors > Peer Interface Behavior), marked Core and all non-Core Mission Use Case sequences that apply to the platform specific implementation.
MA-L1-018	Upon receipt of a Malformed Message (a message missing expected fields (i.e., required by the behavior but not the UCI schema) or with invalid context-dependent information within the scope of that individual message) from the P2P interface, MA shall respond to the error by notifying P2P of the malformed message and requesting the corrected message according to the Malformed Message Response (P2P) sequence.
MA-L1-024	A Level 1 Peer interface shall follow state transitions for CommandProcessingState and RequestProcessingState in accordance with OAC-SPC-001 Rev C, Section 5.1.1.1 and 5.1.2.1. Representations of non-terminal statuses are optional and should align with the definitions and usage prescribed by the UCI Schema Style and Design Specification, ensuring consistent message state handling.

2.7 Vehicle Interface Compliance Requirements

Table 2-7: Vehicle Interface Compliance Requirements

ID	Requirement
MA-L1-013	A Level 1 Vehicle Interface shall support the Vehicle Interface Minimum Message Set defined in the VI MMS table in the VI feature profile (A-GRA location: 1 Problem Domain > 3 Exchange Items > Minimum Message Set (MMS)) for all messages in Core Mission Use Case sequences and all non-Core Mission Use Case sequences required for platform specific implementations.
MA-L1-014	A Level 1 VI interface shall implement all required messaging sequences in the VI feature profile (1 Problem Domain > 2 White Box > 3 Functional Analysis > L1 Functional Analysis > L1 Interface Behaviors > VI Interface Behavior), marked Core and all non-Core Mission Use Case sequences that apply to the platform specific implementation.
MA-L1-020	Upon receipt of a Malformed Message (a message missing expected fields (i.e., required by the behavior but not the UCI schema) or with invalid context-dependent information within the scope of that individual message) from the VI interface, MA shall respond to the error by notifying VI of the malformed message and requesting the corrected message according to the Malformed Message Response (VI) sequence.

3 MISSION AUTONOMY L1 MINIMUM MESSAGE SET

3.1 C2 MMS

Table 3-1: C2 MMS

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	ActionActivityMT	C2	in	Core
UCI 2.3	ActionCancelCommandMT	C2	out	Core
UCI 2.3	ActionCancelCommandStatusMT	C2	in	Core
UCI 2.3	ActionCapabilityStatusMT	C2	in	Core
UCI 2.3	ActionPlanStatusMT	C2	in	Core
UCI 2.3	ActivityPlanApprovalStatusMT	C2	in	Core
UCI 2.3	ActivityPlanExecutionStatusMT	C2	in	Core
UCI 2.3	ActivityPlanStatusMT	C2	in	Core
UCI 2.3	AirfieldReportMT	C2	inout	Core
UCI 2.3	AirSampleActivityMT	C2	in	Core
UCI 2.3	AirSampleCommandMT	C2	out	Core
UCI 2.3	AirSampleCommandStatusMT	C2	in	Core
UCI 2.3	AirSampleSettingsCommandMT	C2	out	Core
UCI 2.3	AirSampleSettingsCommandStatusMT	C2	in	Core
UCI 2.3	AMTI_ActivityMT	C2	in	Core
UCI 2.3	AMTI_CapabilityStatusMT	C2	in	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	AMTI_CommandMT	C2	out	Core
UCI 2.3	AMTI_CommandStatusMT	C2	in	Core
UCI 2.3	AMTI_SettingsCommandMT	C2	out	Core
UCI 2.3	AMTI_SettingsCommandStatusMT	C2	in	Core
UCI 2.3	AO_ActivityMT	C2	in	Core
UCI 2.3	AO_CapabilityMT	C2	in	Core
UCI 2.3	AO_CapabilityStatusMT	C2	in	Core
UCI 2.3	AO_CommandMT	C2	out	Core
UCI 2.3	AO_CommandStatusMT	C2	in	Core
UCI 2.3	AO_SettingsCommandMT	C2	out	Core
UCI 2.3	AO_SettingsCommandStatusMT	C2	in	Core
UCI 2.3	CargoDeliveryCapabilityMT	C2	in	Core
UCI 2.3	CargoDeliveryCapabilityStatusMT	C2	in	Core
UCI 2.3	COMINT_ActivityMT	C2	in	Core
UCI 2.3	COMINT_CapabilityMT	C2	in	Core
UCI 2.3	COMINT_CapabilityStatusMT	C2	in	Core
UCI 2.3	COMINT_CommandMT	C2	out	Core
UCI 2.3	COMINT_CommandStatusMT	C2	in	Core
UCI 2.3	COMINT_SettingsCommandMT	C2	out	Core
UCI 2.3	COMINT_SettingsCommandStatusMT	C2	in	Core
UCI 2.3	CommPointingCommandMT	C2	out	Core
UCI 2.3	CommPointingCommandStatusMT	C2	in	Core
UCI 2.3	CommRelayActivityMT	C2	in	Core
UCI 2.3	CommRelayCommandMT	C2	out	Core
UCI 2.3	CommRelayCommandStatusMT	C2	in	Core
UCI 2.3	CommRelaySettingsCommandMT	C2	out	Core
UCI 2.3	CommRelaySettingsCommandStatusMT	C2	in	Core
UCI 2.3	CommTerminalCapabilityMT	C2	in	Core
UCI 2.3	CommTerminalCapabilityStatusMT	C2	in	Core
UCI 2.3	CommTerminalCommandMT	C2	out	Core
UCI 2.3	CommTerminalCommandStatusMT	C2	in	Core
UCI 2.3	CommTerminalPlanActivationCommandMT	C2	out	Core
UCI 2.3	CommTerminalPlanActivationCommandStatusMT	C2	in	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	CommTerminalSettingsCommandMT	C2	out	Core
UCI 2.3	CommTerminalSettingsCommandStatusMT	C2	in	Core
UCI 2.3	ComponentStatusMT	C2	in	Core
UCI 2.3	ControlRequestMT	C2	out	Core
UCI 2.3	ControlRequestStatusMT	C2	in	Core
UCI 2.3	ControlStatusMT	C2	in	Core
UCI 2.3	DLZ_MT	C2	in	Core
UCI 2.3	DMPI_CancelCommandMT	C2	out	Core
UCI 2.3	DMPI_CancelCommandStatusMT	C2	in	Core
UCI 2.3	DoorCommandMT	C2	out	Core
UCI 2.3	DoorCommandStatusMT	C2	in	Core
UCI 2.3	EA_ActivityMT	C2	in	Core
UCI 2.3	EA_CapabilityMT	C2	in	Core
UCI 2.3	EA_CapabilityStatusMT	C2	in	Core
UCI 2.3	EA_CommandMT	C2	out	Core
UCI 2.3	EA_CommandStatusMT	C2	in	Core
UCI 2.3	EffectCapabilityStatusMT	C2	in	Core
UCI 2.3	EntityMT	C2	inout	Core
UCI 2.3	ESM_ActivityMT	C2	in	Core
UCI 2.3	ESM_CapabilityMT	C2	in	Core
UCI 2.3	ESM_CapabilityStatusMT	C2	in	Core
UCI 2.3	ESM_CommandMT	C2	out	Core
UCI 2.3	ESM_CommandStatusMT	C2	in	Core
UCI 2.3	ESM_SettingsCommandMT	C2	out	Core
UCI 2.3	ESM_SettingsCommandStatusMT	C2	in	Core
UCI 2.3	GatewayCapabilityMT	C2	in	Additional Comms Capabilities
UCI 2.3	GatewayCapabilityStatusMT	C2	in	Additional Comms Capabilities
UCI 2.3	IFF_CapabilityMT	C2	in	Core
UCI 2.3	IFF_CapabilityStatusMT	C2	in	Core
UCI 2.3	IFF_CommandMT	C2	out	Core
UCI 2.3	IFF_CommandStatusMT	C2	in	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	IFF_SettingsCommandMT	C2	out	Core
UCI 2.3	IFF_SettingsCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_AcceptableLevelOfRiskCommandMT	C2	out	ALR
A-GRA Custom Extension	MA_AcceptableLevelOfRiskCommandStatusMT	C2	in	ALR
A-GRA Custom Extension	MA_AcceptableLevelOfRiskStatusMT	C2	in	ALR
A-GRA Custom Extension	MA_ActionCapabilityMT	C2	in	Core
A-GRA Custom Extension	MA_ActionCommandMT	C2	out	Core
A-GRA Custom Extension	MA_ActionCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_ActionMT	C2	inout	Core
A-GRA Custom Extension	MA_ActionPlanMT	C2	inout	Core
A-GRA Custom Extension	MA_ActionStatusMT	C2	in	Core
A-GRA Custom Extension	MA_ActivityPlanMT	C2	inout	Core
A-GRA Custom Extension	MA_AMTI_CapabilityMT	C2	in	Core
A-GRA Custom Extension	MA_ApprovalAuthorityMT	C2	inout	Core
A-GRA Custom Extension	MA_ApprovalPolicyMT	C2	inout	Core
A-GRA Custom Extension	MA_ApprovalRequestMT	C2	in	Core
A-GRA Custom Extension	MA_ApprovalRequestStatusMT	C2	out	Core
A-GRA Custom Extension	MA_AssessmentMT	C2	in	Core, ALR
A-GRA Custom Extension	MA_AssessmentRequestMT	C2	out	Core, ALR
A-GRA Custom Extension	MA_AssessmentRequestStatusMT	C2	in	Core, ALR
A-GRA Custom Extension	MA_AuthorizationMT	C2	inout	Core
A-GRA Custom	MA_CAP_ExecutionStatusReportMT	C2	in	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
Extension				
A-GRA Custom Extension	MA_CapabilitySetMT	C2	inout	Core
A-GRA Custom Extension	MA_CarrierReportMT	C2	out	Carrier
A-GRA Custom Extension	MA_CarrierStateMT	C2	out	Carrier
A-GRA Custom Extension	MA_ConstraintPriorityListActivationDataMT	C2	out	Core
A-GRA Custom Extension	MA_ConstraintPriorityListActivationStatusMT	C2	in	Core
A-GRA Custom Extension	MA_ConstraintPriorityListCommandMT	C2	out	Core
A-GRA Custom Extension	MA_ConstraintPriorityListCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_ConstraintPriorityListMT	C2	out	Core
A-GRA Custom Extension	MA_COP_ConfigurationSettingsCommandMT	C2	out	Core
A-GRA Custom Extension	MA_COP_ConfigurationSettingsCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_COP_ConfigurationSettingsMT	C2	in	Core
A-GRA Custom Extension	MA_COP_ConfigurationSettingsRequestMT	C2	out	Core
A-GRA Custom Extension	MA_COP_ConfigurationSettingsRequestStatusMT	C2	in	Core
A-GRA Custom Extension	MA_DataDisseminationPlanActivationCommandMT	C2	out	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanActivationCommandStatusMT	C2	in	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanActivationStatusMT	C2	in	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanMT	C2	out	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanOverrideRequestMT	C2	out	Additional Comms Capabilities

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_DataDisseminationPlanOverrideRequestStatusMT	C2	in	Additional Comms Capabilities
A-GRA Custom Extension	MA_DesignationMT	C2	out	Core
A-GRA Custom Extension	MA_DesignationRequestMT	C2	in	Core
A-GRA Custom Extension	MA_DesignationRequestStatusMT	C2	out	Core
A-GRA Custom Extension	MA_EffectCapabilityMT	C2	in	Core
A-GRA Custom Extension	MA_EngagementCriteriaCommandMT	C2	out	Core
A-GRA Custom Extension	MA_EngagementCriteriaCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_EngagementCriteriaMT	C2	out	Core
A-GRA Custom Extension	MA_EngagementCriteriaStatusMT	C2	in	Core
A-GRA Custom Extension	MA_ExecutionPriorityListActivationDataMT	C2	out	Core
A-GRA Custom Extension	MA_ExecutionPriorityListActivationStatusMT	C2	in	Core
A-GRA Custom Extension	MA_ExecutionPriorityListCommandMT	C2	out	Core
A-GRA Custom Extension	MA_ExecutionPriorityListCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_ExecutionPriorityListMT	C2	out	Core
A-GRA Custom Extension	MA_FlightActivityMT	C2	in	Core
A-GRA Custom Extension	MA_FlightCapabilityMT	C2	inout	Core
A-GRA Custom Extension	MA_FlightCapabilityStatusMT	C2	in	Core
A-GRA Custom Extension	MA_FlightCommandMT	C2	out	Core, Carrier
A-GRA Custom Extension	MA_FlightCommandStatusMT	C2	in	Core, Carrier
A-GRA Custom Extension	MA_GatewayActivityMT	C2	inout	Additional Comms Capabilities

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_IgnoreConstraintCommandMT	C2	out	Core
A-GRA Custom Extension	MA_IgnoreConstraintCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_InteroperabilityPolicyMT	C2	out	Core
A-GRA Custom Extension	MA_LeadershipMetricsMT	C2	out	Core
A-GRA Custom Extension	MA_MessageAcknowledgmentConfiguration MT	C2	inout	Core
A-GRA Custom Extension	MA_MessageAcknowledgmentConfiguration RequestMT	C2	inout	Core
A-GRA Custom Extension	MA_MessageAcknowledgmentConfiguration RequestStatusMT	C2	inout	Core
A-GRA Custom Extension	MA_MissionPlanActivationCommandMT	C2	out	Core
A-GRA Custom Extension	MA_MissionPlanActivationCommandStatus MT	C2	in	Core
A-GRA Custom Extension	MA_MissionPlanActivationStatusMT	C2	in	Core
A-GRA Custom Extension	MA_MissionPlanCommandMT	C2	out	Core
A-GRA Custom Extension	MA_MissionPlanCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_MissionPlanExecutionStatusMT	C2	in	Core
A-GRA Custom Extension	MA_MissionPlanMT	C2	inout	Core
A-GRA Custom Extension	MA_OpCommandMT	C2	out	Core
A-GRA Custom Extension	MA_OpCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_OperatorRoleMT	C2	inout	Core
A-GRA Custom Extension	MA_OpLineMT	C2	inout	Core
A-GRA Custom Extension	MA_OpPlanMT	C2	out	Core
A-GRA Custom Extension	MA_OpPointMT	C2	inout	Core
A-GRA Custom Extension	MA_OpRoutingMT	C2	inout	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_OpStatusMT	C2	in	Core
A-GRA Custom Extension	MA_OpVolumeMT	C2	inout	Core
A-GRA Custom Extension	MA_OpZoneMT	C2	inout	Core
A-GRA Custom Extension	MA_PackageManagementCommandMT	C2	out	Core
A-GRA Custom Extension	MA_PackageManagementCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_PackagePartnerStatusReportMT	C2	in	Core
A-GRA Custom Extension	MA_PlanModificationRequestMT	C2	in	Core
A-GRA Custom Extension	MA_PlanModificationRequestStatusMT	C2	out	Core
A-GRA Custom Extension	MA_PlanningFunctionMT	C2	in	Core
A-GRA Custom Extension	MA_PlanningFunctionSettingsCommandMT	C2	out	Core
A-GRA Custom Extension	MA_PlanningFunctionSettingsCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_PlanningFunctionStatusMT	C2	in	Core
A-GRA Custom Extension	MA_PlatformOverrideCommandMT	C2	out	Core
A-GRA Custom Extension	MA_PlatformOverrideCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_PlatformOverrideStatusMT	C2	in	Core
A-GRA Custom Extension	MA_PositionReportDetailedMT	C2	in	Carrier, Core
A-GRA Custom Extension	MA_PositionReportMT	C2	in	Core, Carrier
A-GRA Custom Extension	MA_PrioritizationListMT	C2	inout	Core, ALR
A-GRA Custom Extension	MA_ResponseActivityMT	C2	in	Core
A-GRA Custom Extension	MA_ResponseCommandMT	C2	out	Core
A-GRA Custom Extension	MA_ResponseCommandStatusMT	C2	in	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_ResponseMT	C2	inout	Core
A-GRA Custom Extension	MA_ResponsePlanCommandMT	C2	out	Core
A-GRA Custom Extension	MA_ResponsePlanCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_RouteActivityPlanMT	C2	inout	Core
A-GRA Custom Extension	MA_RoutePlanMT	C2	inout	Core, Carrier
A-GRA Custom Extension	MA_StrikeActivityMT	C2	in	Core
A-GRA Custom Extension	MA_StrikeCapabilityMT	C2	in	Core
A-GRA Custom Extension	MA_SystemManagementRequestMT	C2	out	Carrier, Core
A-GRA Custom Extension	MA_SystemManagementRequestStatusMT	C2	in	Core
A-GRA Custom Extension	MA_SystemNotificationMT	C2	inout	Core, Carrier, ALR
A-GRA Custom Extension	MA_SystemsNeededRequestMT	C2	in	Core
A-GRA Custom Extension	MA_SystemsNeededRequestStatusMT	C2	out	Core
A-GRA Custom Extension	MA_TaskCommandMT	C2	out	Core
A-GRA Custom Extension	MA_TaskCommandStatusMT	C2	in	Core
A-GRA Custom Extension	MA_TaskMT	C2	inout	Carrier, Core
A-GRA Custom Extension	MA_TaskPlanMT	C2	inout	Core, Carrier
A-GRA Custom Extension	MA_TaskStatusMT	C2	in	Core, Carrier
A-GRA Custom Extension	MA_WEZ_MT	C2	in	Core
UCI 2.3	MissionContingencyAlertMT	C2	in	Core
UCI 2.3	MissionPlanApprovalStatusMT	C2	in	Core
UCI 2.3	MissionPlanStatusMT	C2	in	Core
A-GRA Custom Extension	MA_NavigationReportMT	C2	in	Carrier, Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	ObservationMeasurementReportMT	C2	in	Core
UCI 2.3	OpaqueCapabilityMT	C2	in	Core
UCI 2.3	OpaqueCapabilityStatusMT	C2	in	Core
UCI 2.3	OperatorMT	C2	inout	Core
UCI 2.3	OperatorNotificationAckMT	C2	out	Carrier
UCI 2.3	OperatorNotificationMT	C2	in	Carrier, Core
UCI 2.3	OpNotificationMT	C2	in	Core
UCI 2.3	PackageMT	C2	inout	Carrier, Core
UCI 2.3	PackageStatusMT	C2	in	Core
UCI 2.3	PO_ActivityMT	C2	in	Core
UCI 2.3	PO_CapabilityMT	C2	in	Core
UCI 2.3	PO_CapabilityStatusMT	C2	in	Core
UCI 2.3	PO_CommandMT	C2	out	Core
UCI 2.3	PO_CommandStatusMT	C2	in	Core
UCI 2.3	PO_SettingsCommandMT	C2	out	Core
UCI 2.3	PO_SettingsCommandStatusMT	C2	in	Core
UCI 2.3	QueryDataRequestMT	C2	inout	Core
UCI 2.3	QueryDataRequestStatusMT	C2	inout	Core
UCI 2.3	RadarAltimeterCapabilityMT	C2	in	Core
UCI 2.3	RadarAltimeterCapabilityStatusMT	C2	in	Core
UCI 2.3	RadarAltimeterCommandMT	C2	out	Core
UCI 2.3	RadarAltimeterCommandStatusMT	C2	in	Core
UCI 2.3	RadarAltimeterSettingsCommandMT	C2	out	Core
UCI 2.3	RadarAltimeterSettingsCommandStatusMT	C2	in	Core
UCI 2.3	ReferenceFrameMT	C2	in	Carrier
UCI 2.3	RefuelCapabilityMT	C2	in	Core
UCI 2.3	RefuelCapabilityStatusMT	C2	in	Core
UCI 2.3	RefuelCommandMT	C2	out	Core
UCI 2.3	RefuelCommandStatusMT	C2	in	Core
UCI 2.3	RefuelSettingsCommandMT	C2	out	Core
UCI 2.3	RefuelSettingsCommandStatusMT	C2	in	Core
UCI 2.3	RelationshipDesignationMT	C2	in	Core
UCI 2.3	ResponsePlanApprovalStatusMT	C2	in	Core
UCI 2.3	ResponsePlanExecutionStatusMT	C2	in	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	ResponsePlanMT	C2	inout	Core
UCI 2.3	RouteActivityPlanExecutionStatusMT	C2	in	Core
UCI 2.3	RouteActivityPlanStatusMT	C2	in	Core
UCI 2.3	RouteMetricsMT	C2	inout	Core
UCI 2.3	RouteMetricsRequestMT	C2	out	Core
UCI 2.3	RouteMetricsRequestStatusMT	C2	in	Core
UCI 2.3	RouteModificationRequestMT	C2	in	Core
UCI 2.3	RouteModificationRequestStatusMT	C2	out	Core
UCI 2.3	RoutePlanApprovalStatusMT	C2	in	Core
UCI 2.3	RoutePlanExecutionStatusMT	C2	in	Core
UCI 2.3	RoutePlanStatusMT	C2	in	Core
UCI 2.3	SAR_ActivityMT	C2	in	Core
UCI 2.3	SAR_CapabilityMT	C2	in	Core
UCI 2.3	SAR_CapabilityStatusMT	C2	in	Core
UCI 2.3	SAR_CommandMT	C2	out	Core
UCI 2.3	SAR_CommandStatusMT	C2	in	Core
UCI 2.3	SAR_SettingsCommandMT	C2	out	Core
UCI 2.3	SAR_SettingsCommandStatusMT	C2	in	Core
UCI 2.3	ServiceConfigurationChangeRequestMT	C2	out	Carrier
UCI 2.3	SMTI_ActivityMT	C2	in	Core
UCI 2.3	SMTI_CapabilityMT	C2	in	Core
UCI 2.3	SMTI_CapabilityStatusMT	C2	in	Core
UCI 2.3	SMTI_CommandMT	C2	out	Core
UCI 2.3	SMTI_CommandStatusMT	C2	in	Core
UCI 2.3	SMTI_SettingsCommandMT	C2	out	Core
UCI 2.3	SMTI_SettingsCommandStatusMT	C2	in	Core
UCI 2.3	StoreManagementCommandMT	C2	out	Core
UCI 2.3	StoreManagementCommandStatusMT	C2	in	Core
UCI 2.3	StrikeCapabilityStatusMT	C2	in	Core
UCI 2.3	StrikeCommandMT	C2	out	Core
UCI 2.3	StrikeCommandStatusMT	C2	in	Core
UCI 2.3	StrikeConsentRequestMT	C2	in	Core
UCI 2.3	StrikeConsentRequestStatusMT	C2	out	Core
UCI 2.3	SubsystemStatusMT	C2	in	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	SurvivabilityRiskLevelMT	C2	out	ALR
UCI 2.3	SystemDeploymentCapabilityMT	C2	in	Core
UCI 2.3	SystemDeploymentCapabilityStatusMT	C2	in	Core
UCI 2.3	SystemStatusMT	C2	inout	Core
UCI 2.3	TacticalOrderCapabilityMT	C2	in	Core
UCI 2.3	TacticalOrderCapabilityStatusMT	C2	in	Core
UCI 2.3	TaskCancelCommandMT	C2	out	Core
UCI 2.3	TaskCancelCommandStatusMT	C2	in	Core
UCI 2.3	TaskPlanApprovalStatusMT	C2	in	Core
UCI 2.3	TaskPlanExecutionStatusMT	C2	in	Core
UCI 2.3	TaskPlanStatusMT	C2	in	Core
UCI 2.3	TurretCommandMT	C2	out	Core
UCI 2.3	TurretCommandStatusMT	C2	in	Core
UCI 2.3	WeatherDatasetMT	C2	out	Core
UCI 2.3	WeatherMT	C2	in	Core
UCI 2.3	WeatherRadarActivityMT	C2	in	Core
UCI 2.3	WeatherRadarCapabilityMT	C2	in	Core
UCI 2.3	WeatherRadarCapabilityStatusMT	C2	in	Core
UCI 2.3	WeatherRadarCommandMT	C2	out	Core
UCI 2.3	WeatherRadarCommandStatusMT	C2	in	Core
UCI 2.3	WeatherRadarSettingsCommandMT	C2	out	Core
UCI 2.3	WeatherRadarSettingsCommandStatusMT	C2	in	Core

3.2 MP MMS

Table 3-2: MP MMS

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	AccessAssessmentMT	MP	out	Core
UCI 2.3	ActivityMetricsMT	MP	out	Core
UCI 2.3	AirfieldReportMT	MP	out	Core
UCI 2.3	AirSampleCapabilityMT	MP	out	Core
UCI 2.3	AnalysisRouteMT	MP	out	Core
UCI 2.3	AO_CapabilityMT	MP	out	Core
UCI 2.3	CargoDeliveryCapabilityMT	MP	out	Core
UCI 2.3	COMINT_CapabilityMT	MP	out	Core
UCI 2.3	CommRelayCapabilityMT	MP	out	Additional Comms Capabilities
UCI 2.3	CommTerminalCapabilityMT	MP	out	Additional Comms Capabilities
UCI 2.3	CounterSpaceCapabilityMT	MP	out	Core
UCI 2.3	DLZ_MT	MP	out	Core
UCI 2.3	EA_CapabilityMT	MP	out	Core
UCI 2.3	ESM_CapabilityMT	MP	out	ESM
UCI 2.3	ForeignKeyPairMT	MP	out	Core
UCI 2.3	GatewayCapabilityMT	MP	out	Core
UCI 2.3	IFF_CapabilityMT	MP	out	Core
A-GRA Custom Extension	MA_ActionCapabilityMT	MP	out	Core
A-GRA Custom Extension	MA_ActionMT	MP	out	Core
A-GRA Custom Extension	MA_ActionPlanMT	MP	out	Core
A-GRA Custom Extension	MA_ActivityPlanMT	MP	out	Core
A-GRA Custom Extension	MA_AMTI_CapabilityMT	MP	out	AMTI
A-GRA Custom Extension	MA_ApprovalAuthorityMT	MP	out	Core
A-GRA Custom Extension	MA_ApprovalPolicyMT	MP	out	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_AssessmentMT	MP	out	Core
A-GRA Custom Extension	MA_AuthorizationMT	MP	out	Core
A-GRA Custom Extension	MA_CapabilitySetMT	MP	out	Core
A-GRA Custom Extension	MA_CarrierReportMT	MP	out	Carrier
A-GRA Custom Extension	MA_CarrierStateMT	MP	out	Carrier
A-GRA Custom Extension	MA_ConstraintPriorityListActivationDataMT	MP	out	Core
A-GRA Custom Extension	MA_ConstraintPriorityListMT	MP	out	Core
A-GRA Custom Extension	MA_DesignationMT	MP	out	Core
A-GRA Custom Extension	MA_EffectCapabilityMT	MP	out	Core
A-GRA Custom Extension	MA_EngagementCriteriaMT	MP	out	Core
A-GRA Custom Extension	MA_EntityMT	MP	out	Core
A-GRA Custom Extension	MA_ExecutionPriorityListActivationDataMT	MP	out	Core
A-GRA Custom Extension	MA_ExecutionPriorityListMT	MP	out	Core
A-GRA Custom Extension	MA_FlightCapabilityMT	MP	out	Core
A-GRA Custom Extension	MA_InteroperabilityPolicyMT	MP	out	Core
A-GRA Custom Extension	MA_LeadershipMetricsMT	MP	out	Bully Leader Election, Max Consensus Leader Election, Static Fitness Score Leader Election
A-GRA Custom Extension	MA_MissionPlanMT	MP	out	Core
A-GRA Custom Extension	MA_OperatorRoleMT	MP	out	Core
A-GRA Custom Extension	MA_OpLineMT	MP	out	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_OpPlanMT	MP	out	Core
A-GRA Custom Extension	MA_OpPointMT	MP	out	Core
A-GRA Custom Extension	MA_OpRoutingMT	MP	out	Core
A-GRA Custom Extension	MA_OpVolumeMT	MP	out	Core
A-GRA Custom Extension	MA_OpZoneMT	MP	out	Core
A-GRA Custom Extension	MA_PlanningFunctionMT	MP	out	Core
A-GRA Custom Extension	MA_PrioritizationListMT	MP	out	Core
A-GRA Custom Extension	MA_ResponseMT	MP	out	Core
A-GRA Custom Extension	MA_ResponsePlanMT	MP	out	Core
A-GRA Custom Extension	MA_RouteActivityPlanMT	MP	out	Core
A-GRA Custom Extension	MA_RoutePlanMT	MP	out	Core
A-GRA Custom Extension	MA_StrikeCapabilityMT	MP	out	Store Management
A-GRA Custom Extension	MA_TaskMT	MP	out	Core
A-GRA Custom Extension	MA_TaskPlanMT	MP	out	Core
A-GRA Custom Extension	MA_WEZ_MT	MP	out	Core
UCI 2.3	OpaqueCapabilityMT	MP	out	Core
UCI 2.3	OrbitalSurveillanceCapabilityMT	MP	out	Core
UCI 2.3	OrbitalSurveillanceSensorCapabilityMT	MP	out	Core
UCI 2.3	OrbitChangeCapabilityMT	MP	out	Core
UCI 2.3	PackageMT	MP	out	Core
UCI 2.3	PO_CapabilityMT	MP	out	PO
UCI 2.3	RadarAltimeterCapabilityMT	MP	out	Core
UCI 2.3	ReferenceCapabilityMT	MP	out	Core
UCI 2.3	RefuelCapabilityMT	MP	out	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	RequirementMetricsMT	MP	out	Core
UCI 2.3	RequirementSetMT	MP	out	Core
UCI 2.3	ResponseCapabilityMT	MP	out	Core
UCI 2.3	RouteMetricsMT	MP	out	Core
UCI 2.3	SAR_CapabilityMT	MP	out	Core
UCI 2.3	SMTI_CapabilityMT	MP	out	Core
UCI 2.3	StoreLoadoutConfigurationMT	MP	out	Store Management
UCI 2.3	SurvivabilityRiskLevelMT	MP	out	ALR
UCI 2.3	SystemDeploymentCapabilityMT	MP	out	Core
UCI 2.3	SystemReadinessMT	MP	out	Core
UCI 2.3	TacticalOrderCapabilityMT	MP	out	Core
UCI 2.3	WeatherDatasetMT	MP	out	Core
UCI 2.3	WeatherMT	MP	out	Core
UCI 2.3	WeatherRadarCapabilityMT	MP	out	Weather Radar

3.3 MS MMS

Table 3-3: MS MMS

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	ActionPlanValidationCommandMT	MS	in	Core
UCI 2.3	ActionPlanValidationCommandStatusMT	MS	out	Core
UCI 2.3	ActivityPlanValidationCommandMT	MS	in	Core
UCI 2.3	ActivityPlanValidationCommandStatusMT	MS	out	Core
UCI 2.3	AirSampleCapabilityMT	MS	out	Core
UCI 2.3	AirSampleCapabilityStatusMT	MS	out	Core
UCI 2.3	AMTI_ActivityMT	MS	out	AMTI
UCI 2.3	AMTI_CapabilityStatusMT	MS	out	Core, AMTI
UCI 2.3	AMTI_CommandMT	MS	in	AMTI
UCI 2.3	AMTI_CommandStatusMT	MS	out	AMTI
UCI 2.3	AO_CapabilityMT	MS	out	Core
UCI 2.3	AO_CapabilityStatusMT	MS	out	Core
UCI 2.3	AssessmentRequestMT	MS	in	Store Management
UCI 2.3	AssessmentRequestStatusMT	MS	out	Store Management
UCI 2.3	CargoDeliveryCapabilityMT	MS	out	Core
UCI 2.3	CargoDeliveryCapabilityStatusMT	MS	out	Core
UCI 2.3	COMINT_CapabilityMT	MS	out	Core
UCI 2.3	COMINT_CapabilityStatusMT	MS	out	Core
UCI 2.3	CommAssetEstimationRequestMT	MS	in	Additional Comms Capabilities
UCI 2.3	CommAssetEstimationRequestStatusMT	MS	out	Additional Comms Capabilities
UCI 2.3	CommAssetMT	MS	out	Core
UCI 2.3	CommRelayCapabilityMT	MS	out	Core
UCI 2.3	CommRelayCapabilityStatusMT	MS	out	Core
UCI 2.3	CommScheduleAllocationMT	MS	out	Core
UCI 2.3	CommSystemMT	MS	out	Core
UCI 2.3	CommTerminalActivityMT	MS	out	Additional Comms Capabilities, Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	CommTerminalCapabilityMT	MS	out	Core
UCI 2.3	CommTerminalCapabilityStatusMT	MS	out	Core
UCI 2.3	CommTerminalCommandMT	MS	in	Additional Comms Capabilities
UCI 2.3	CommTerminalCommandStatusMT	MS	out	Additional Comms Capabilities
UCI 2.3	CommTerminalPlanActivationCommandMT	MS	in	Additional Comms Capabilities
UCI 2.3	CommTerminalPlanActivationCommandStatusMT	MS	out	Additional Comms Capabilities
UCI 2.3	CommTerminalPlanMT	MS	in	Additional Comms Capabilities
UCI 2.3	CounterSpaceCapabilityMT	MS	out	Core
UCI 2.3	CounterSpaceCapabilityStatusMT	MS	out	Core
UCI 2.3	DataUpdateRequestMT	MS	in	Core
UCI 2.3	DataUpdateRequestStatusMT	MS	out	Core
UCI 2.3	DLZ_MT	MS	out	Core
UCI 2.3	DLZ_RequestMT	MS	in	Core
UCI 2.3	DLZ_RequestStatusMT	MS	out	Core
UCI 2.3	EA_CapabilityMT	MS	out	Core
UCI 2.3	EA_CapabilityStatusMT	MS	out	Core
UCI 2.3	EntityLostMT	MS	inout	Core
UCI 2.3	EntityMT	MS	inout	Core
UCI 2.3	ESM_ActivityMT	MS	out	ESM
UCI 2.3	ESM_CapabilityMT	MS	out	Core, ESM
UCI 2.3	ESM_CapabilityStatusMT	MS	out	Core
UCI 2.3	ESM_CommandMT	MS	in	ESM
UCI 2.3	ESM_CommandStatusMT	MS	out	ESM
UCI 2.3	GatewayCapabilityMT	MS	out	Additional Comms Capabilities
UCI 2.3	GatewayCapabilityStatusMT	MS	out	Additional Comms Capabilities

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_ActivityPlanMT	MS	in	Core
A-GRA Custom Extension	MA_AMTI_CapabilityMT	MS	out	Core, AMTI
A-GRA Custom Extension	MA_CommAvailableEndpointsMT	MS	out	Core
A-GRA Custom Extension	MA_CommErrorReportMT	MS	out	Core
A-GRA Custom Extension	MA_CommTeamReportMT	MS	out	Core
A-GRA Custom Extension	MA_DataDisseminationPlanActivationComm andMT	MS	in	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanActivationComm andStatusMT	MS	out	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanActivationStatus MT	MS	out	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanMT	MS	in	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanOverrideRequest MT	MS	in	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanOverrideRequest StatusMT	MS	out	Additional Comms Capabilities
A-GRA Custom Extension	MA_EntityMT	MS	out	Store Management
A-GRA Custom Extension	MA_FaultMT	MS	out	Core
A-GRA Custom Extension	MA_GatewayActivityMT	MS	out	Additional Comms Capabilities
A-GRA Custom Extension	MA_GatewayCommandMT	MS	in	Additional Comms Capabilities
A-GRA Custom Extension	MA_GatewayCommandStatusMT	MS	out	Additional Comms Capabilities
A-GRA Custom Extension	MA_MessagingSubscriptionSettingComman dMT	MS	in	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_MessagingSubscriptionSettingCommandStatusMT	MS	out	Core
A-GRA Custom Extension	MA_MessagingSubscriptionStatusMT	MS	out	Core
A-GRA Custom Extension	MA_MissionPlanValidationCommandMT	MS	in	Core
A-GRA Custom Extension	MA_MissionPlanValidationCommandStatusMT	MS	out	Core
A-GRA Custom Extension	MA_PositionReportDetailedMT	MS	out	PNT
A-GRA Custom Extension	MA_RouteActivityPlanMT	MS	in	Core
A-GRA Custom Extension	MA_RoutePlanMT	MS	in	Core
A-GRA Custom Extension	MA_RxDataPayloadMT	MS	out	Core
A-GRA Custom Extension	MA_StrikeActivityMT	MS	out	Core, Store Management
A-GRA Custom Extension	MA_StrikeCapabilityMT	MS	out	Core, Store Management
A-GRA Custom Extension	MA_SystemNotificationMT	MS	in	Core
A-GRA Custom Extension	MA_TaskCommandMT	MS	in	Core
A-GRA Custom Extension	MA_TaskCommandStatusMT	MS	out	Core
A-GRA Custom Extension	MA_TaskMT	MS	in	Core
A-GRA Custom Extension	MA_TaskPlanMT	MS	in	Core
A-GRA Custom Extension	MA_TaskStatusMT	MS	inout	Core
A-GRA Custom Extension	MA_TxDataPayloadCommandMT	MS	in	Core
A-GRA Custom Extension	MA_TxDataPayloadCommandStatusMT	MS	out	Core
A-GRA Custom Extension	MA_WEZ_MT	MS	out	Core
A-GRA Custom Extension	MA_WEZ_RequestMT	MS	in	Core
A-GRA Custom Extension	MA_WEZ_RequestStatusMT	MS	out	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	ObservationMeasurementReportMT	MS	out	Core
UCI 2.3	PO_ActivityMT	MS	out	PO
UCI 2.3	PO_CapabilityMT	MS	out	PO
UCI 2.3	PO_CapabilityStatusMT	MS	out	PO
UCI 2.3	PO_CommandMT	MS	in	PO
UCI 2.3	PO_CommandStatusMT	MS	out	PO
UCI 2.3	QueryDataRequestMT	MS	in	Core
UCI 2.3	QueryDataRequestStatusMT	MS	out	Core
UCI 2.3	RefuelCapabilityMT	MS	out	Core
UCI 2.3	RefuelCapabilityStatusMT	MS	out	Core
UCI 2.3	RouteActivityPlanValidationCommandMT	MS	in	Core
UCI 2.3	RouteActivityPlanValidationCommandStatus MT	MS	out	Core
UCI 2.3	SAR_CapabilityMT	MS	out	Core
UCI 2.3	SAR_CapabilityStatusMT	MS	out	Core
UCI 2.3	ServiceConfigurationChangeRequestMT	MS	in	Core
UCI 2.3	ServiceConfigurationChangeRequestStatus MT	MS	out	Core
UCI 2.3	ServiceConfigurationParamsDataRequestMT	MS	in	Core
UCI 2.3	ServiceConfigurationParamsDataRequestSta tusMT	MS	out	Core
UCI 2.3	ServiceConfigurationParamsMT	MS	out	Core
UCI 2.3	ServiceStatusDataRequestMT	MS	in	Core
UCI 2.3	ServiceStatusDataRequestStatusMT	MS	out	Core
UCI 2.3	ServiceStatusMT	MS	out	Core
UCI 2.3	SMTI_CapabilityMT	MS	out	Core
UCI 2.3	SMTI_CapabilityStatusMT	MS	out	Core
UCI 2.3	StoreManagementCommandMT	MS	in	Core
UCI 2.3	StoreManagementCommandStatusMT	MS	out	Core
UCI 2.3	StoreManagementStatusMT	MS	out	Store Management
UCI 2.3	StrikeCapabilityStatusMT	MS	out	Core, Store Management
UCI 2.3	StrikeConsentRequestMT	MS	out	Core
UCI 2.3	StrikeConsentRequestStatusMT	MS	in	Core
UCI 2.3	StrikeSettingsCommandMT	MS	in	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	StrikeSettingsCommandStatusMT	MS	out	Core
UCI 2.3	SubsystemBIT_CommandMT	MS	in	Core
UCI 2.3	SubsystemBIT_CommandStatusMT	MS	out	Core
UCI 2.3	SubsystemBIT_StatusMT	MS	out	Core
UCI 2.3	SubsystemSettingsCommandMT	MS	in	PNT
UCI 2.3	SubsystemStatusDataRequestMT	MS	in	PNT, Core
UCI 2.3	SubsystemStatusDataRequestStatusMT	MS	out	PNT, Core
UCI 2.3	SubsystemStatusMT	MS	out	Carrier, Core
UCI 2.3	SystemDeploymentCapabilityMT	MS	out	Core
UCI 2.3	SystemDeploymentCapabilityStatusMT	MS	out	Core
UCI 2.3	SystemStatusMT	MS	inout	Core, Carrier
UCI 2.3	TacticalOrderCapabilityMT	MS	out	Core
UCI 2.3	TacticalOrderCapabilityStatusMT	MS	out	Core
UCI 2.3	TaskPlanValidationCommandMT	MS	in	Core
UCI 2.3	TaskPlanValidationCommandStatusMT	MS	out	Core
UCI 2.3	WeatherMT	MS	out	Core
UCI 2.3	WeatherRadarCapabilityMT	MS	out	Core
UCI 2.3	WeatherRadarCapabilityStatusMT	MS	out	Core
UCI 2.3	WeatherRadarObservationMT	MS	out	Weather Radar

3.4 Peer MMS

Table 3-4: Peer MMS

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	AccessAssessmentRequestMT	P2P	inout	Core
UCI 2.3	AccessAssessmentRequestStatusMT	P2P	inout	Core
UCI 2.3	ActionCancelCommandMT	P2P	inout	Core
UCI 2.3	ActionCancelCommandStatusMT	P2P	inout	Core
UCI 2.3	ActionCapabilityStatusMT	P2P	inout	Core
UCI 2.3	ActionPlanValidationCommandMT	P2P	inout	Core
UCI 2.3	ActionPlanValidationCommandStatusMT	P2P	inout	Core
UCI 2.3	ActivityPlanApprovalStatusMT	P2P	inout	Core
UCI 2.3	AirfieldReportMT	P2P	inout	Core
UCI 2.3	AirSampleActivityMT	P2P	inout	Core
UCI 2.3	AirSampleCommandMT	P2P	inout	Core
UCI 2.3	AirSampleCommandStatusMT	P2P	inout	Core
UCI 2.3	AirSampleSettingsCommandMT	P2P	inout	Core
UCI 2.3	AirSampleSettingsCommandStatusMT	P2P	inout	Core
UCI 2.3	AMTI_ActivityMT	P2P	inout	AMTI, Core
UCI 2.3	AMTI_CapabilityStatusMT	P2P	inout	Core, AMTI
UCI 2.3	AMTI_CommandMT	P2P	inout	Core
UCI 2.3	AMTI_CommandStatusMT	P2P	inout	Core
UCI 2.3	AMTI_SettingsCommandMT	P2P	inout	Core
UCI 2.3	AMTI_SettingsCommandStatusMT	P2P	inout	Core
UCI 2.3	AO_ActivityMT	P2P	inout	Core
UCI 2.3	AO_CapabilityMT	P2P	inout	Core
UCI 2.3	AO_CapabilityStatusMT	P2P	inout	Core
UCI 2.3	AO_CommandMT	P2P	inout	Core
UCI 2.3	AO_CommandStatusMT	P2P	inout	Core
UCI 2.3	AO_SettingsCommandMT	P2P	inout	Core
UCI 2.3	AO_SettingsCommandStatusMT	P2P	inout	Core
UCI 2.3	CargoDeliveryCapabilityMT	P2P	inout	Core
UCI 2.3	CargoDeliveryCapabilityStatusMT	P2P	inout	Core
UCI 2.3	COMINT_ActivityMT	P2P	inout	Core
UCI 2.3	COMINT_CapabilityMT	P2P	inout	Core
UCI 2.3	COMINT_CapabilityStatusMT	P2P	inout	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	COMINT_CommandMT	P2P	inout	Core
UCI 2.3	COMINT_CommandStatusMT	P2P	inout	Core
UCI 2.3	COMINT_SettingsCommandMT	P2P	inout	Core
UCI 2.3	COMINT_SettingsCommandStatusMT	P2P	inout	Core
UCI 2.3	CommPointingCommandMT	P2P	inout	Core
UCI 2.3	CommPointingCommandStatusMT	P2P	inout	Core
UCI 2.3	CommRelayActivityMT	P2P	inout	Core
UCI 2.3	CommRelayCommandMT	P2P	inout	Core
UCI 2.3	CommRelayCommandStatusMT	P2P	inout	Core
UCI 2.3	CommRelaySettingsCommandMT	P2P	inout	Core
UCI 2.3	CommRelaySettingsCommandStatusMT	P2P	inout	Core
UCI 2.3	CommTerminalCapabilityMT	P2P	inout	Core
UCI 2.3	CommTerminalCapabilityStatusMT	P2P	inout	Core
UCI 2.3	CommTerminalCommandMT	P2P	inout	Core
UCI 2.3	CommTerminalCommandStatusMT	P2P	inout	Core
UCI 2.3	CommTerminalPlanActivationCommandMT	P2P	inout	Core
UCI 2.3	CommTerminalPlanActivationCommandStatusMT	P2P	inout	Core
UCI 2.3	CommTerminalSettingsCommandMT	P2P	inout	Core
UCI 2.3	CommTerminalSettingsCommandStatusMT	P2P	inout	Core
UCI 2.3	ComponentStatusMT	P2P	inout	Core
UCI 2.3	ControlStatusMT	P2P	inout	Core
UCI 2.3	DLZ_MT	P2P	inout	Core
UCI 2.3	DMPI_CancelCommandMT	P2P	inout	Core
UCI 2.3	DMPI_CancelCommandStatusMT	P2P	inout	Core
UCI 2.3	DoorCommandMT	P2P	inout	Core
UCI 2.3	DoorCommandStatusMT	P2P	inout	Core
UCI 2.3	EA_ActivityMT	P2P	inout	Core
UCI 2.3	EA_CapabilityMT	P2P	inout	Core
UCI 2.3	EA_CapabilityStatusMT	P2P	inout	Core
UCI 2.3	EA_CommandMT	P2P	inout	Core
UCI 2.3	EA_CommandStatusMT	P2P	inout	Core
UCI 2.3	EffectCapabilityStatusMT	P2P	inout	Core
UCI 2.3	EntityMT	P2P	inout	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	ESM_ActivityMT	P2P	inout	Core
UCI 2.3	ESM_CapabilityMT	P2P	inout	Core
UCI 2.3	ESM_CapabilityStatusMT	P2P	inout	Core
UCI 2.3	ESM_CommandMT	P2P	inout	Core
UCI 2.3	ESM_CommandStatusMT	P2P	inout	Core
UCI 2.3	ESM_SettingsCommandMT	P2P	inout	Core
UCI 2.3	ESM_SettingsCommandStatusMT	P2P	inout	Core
UCI 2.3	GatewayCapabilityMT	P2P	inout	Additional Comms Capabilities
UCI 2.3	GatewayCapabilityStatusMT	P2P	inout	Additional Comms Capabilities
UCI 2.3	GatewayCommandMT	P2P	inout	Core
UCI 2.3	GatewayCommandStatusMT	P2P	inout	Core
UCI 2.3	IFF_CapabilityMT	P2P	inout	Core
UCI 2.3	IFF_CapabilityStatusMT	P2P	inout	Core
UCI 2.3	IFF_CommandMT	P2P	inout	Core
UCI 2.3	IFF_CommandStatusMT	P2P	inout	Core
UCI 2.3	IFF_SettingsCommandMT	P2P	inout	Core
UCI 2.3	IFF_SettingsCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_AcceptableLevelOfRiskCommandMT	P2P	inout	ALR
A-GRA Custom Extension	MA_AcceptableLevelOfRiskCommandStatusMT	P2P	inout	ALR
A-GRA Custom Extension	MA_AcceptableLevelOfRiskStatusMT	P2P	inout	ALR
A-GRA Custom Extension	MA_ActionCapabilityMT	P2P	inout	Core
A-GRA Custom Extension	MA_ActionCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_ActionCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_ActionMT	P2P	inout	Core
A-GRA Custom Extension	MA_ActionPlanMT	P2P	inout	Core
A-GRA Custom Extension	MA_ActionPlanValidationMT	P2P	inout	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_ActionStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_ActivityPlanMT	P2P	inout	Core
A-GRA Custom Extension	MA_AMTI_CapabilityMT	P2P	inout	Core, AMTI
A-GRA Custom Extension	MA_ApprovalAuthorityMT	P2P	inout	Core
A-GRA Custom Extension	MA_ApprovalPolicyMT	P2P	inout	Core
A-GRA Custom Extension	MA_ApprovalRequestMT	P2P	inout	Core
A-GRA Custom Extension	MA_ApprovalRequestStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_AssessmentMT	P2P	inout	ALR
A-GRA Custom Extension	MA_AssessmentRequestMT	P2P	inout	ALR
A-GRA Custom Extension	MA_AssessmentRequestStatusMT	P2P	inout	ALR
A-GRA Custom Extension	MA_CAP_ExecutionStatusReportMT	P2P	inout	Core
A-GRA Custom Extension	MA_CapabilitySetMT	P2P	inout	Core
A-GRA Custom Extension	MA_ConstraintPriorityListActivationDataMT	P2P	inout	Core
A-GRA Custom Extension	MA_ConstraintPriorityListActivationStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_ConstraintPriorityListCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_ConstraintPriorityListCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_ConstraintPriorityListMT	P2P	inout	Core
A-GRA Custom Extension	MA_COP_ConfigurationSettingsCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_COP_ConfigurationSettingsCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_COP_ConfigurationSettingsMT	P2P	inout	Core
A-GRA Custom Extension	MA_COP_ConfigurationSettingsRequestMT	P2P	inout	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_COP_ConfigurationSettingsRequestStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_DataDisseminationPlanActivationCommandMT	P2P	inout	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanActivationCommandStatusMT	P2P	inout	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanActivationStatusMT	P2P	inout	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanMT	P2P	inout	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanOverrideRequestMT	P2P	inout	Additional Comms Capabilities
A-GRA Custom Extension	MA_DataDisseminationPlanOverrideRequestStatusMT	P2P	inout	Additional Comms Capabilities
A-GRA Custom Extension	MA_DeconflictionSolutionRequestMT	P2P	inout	Core
A-GRA Custom Extension	MA_DeconflictionSolutionRequestStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_DesignationRequestMT	P2P	inout	Core
A-GRA Custom Extension	MA_DesignationRequestStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_EffectCapabilityMT	P2P	inout	Core
A-GRA Custom Extension	MA_EngagementCriteriaCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_EngagementCriteriaCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_EngagementCriteriaMT	P2P	inout	Core
A-GRA Custom Extension	MA_EngagementCriteriaStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_EscortActivityMT	P2P	inout	Core
A-GRA Custom Extension	MA_EscortCommandMT	P2P	inout	Core
A-GRA Custom	MA_EscortCommandStatusMT	P2P	inout	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
Extension				
A-GRA Custom Extension	MA_ExecutionPriorityListActivationDataMT	P2P	inout	Core
A-GRA Custom Extension	MA_ExecutionPriorityListActivationStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_ExecutionPriorityListCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_ExecutionPriorityListCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_ExecutionPriorityListMT	P2P	inout	Core
A-GRA Custom Extension	MA_FlightActivityMT	P2P	inout	Core
A-GRA Custom Extension	MA_FlightCapabilityMT	P2P	inout	Core
A-GRA Custom Extension	MA_FlightCapabilityStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_FlightCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_FlightCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_GatewayActivityMT	P2P	inout	Additional Comms Capabilities
A-GRA Custom Extension	MA_IgnoreConstraintCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_IgnoreConstraintCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_LeaderUpdateRequestMT	P2P	inout	Core, Bully Leader Election, Max Consensus Leader Election, Static Fitness Score Leader Election
A-GRA Custom Extension	MA_LeaderUpdateRequestStatusMT	P2P	inout	Core, Max Consensus Leader Election, Bully Leader Election, Static Fitness Score Leader Election
A-GRA Custom Extension	MA_MessageAcknowledgmentConfigurationMT	P2P	inout	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_MessageAcknowledgmentConfigurationRequestMT	P2P	inout	Core
A-GRA Custom Extension	MA_MessageAcknowledgmentConfigurationRequestStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_MissionPlanActivationCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_MissionPlanActivationCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_MissionPlanActivationStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_MissionPlanExecutionStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_MissionPlanMT	P2P	inout	Core
A-GRA Custom Extension	MA_NavigationReportMT	P2P	inout	Core
A-GRA Custom Extension	MA_OpCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_OpCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_OperatorRoleMT	P2P	inout	Core
A-GRA Custom Extension	MA_OpLineMT	P2P	inout	Core
A-GRA Custom Extension	MA_OpPlanMT	P2P	inout	Core
A-GRA Custom Extension	MA_OpPointMT	P2P	inout	Core
A-GRA Custom Extension	MA_OpRoutingMT	P2P	inout	Core
A-GRA Custom Extension	MA_OpStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_OpVolumeMT	P2P	inout	Core
A-GRA Custom Extension	MA_OpZoneMT	P2P	inout	Core
A-GRA Custom Extension	MA_PackageManagementCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_PackageManagementCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_PackagePartnerStatusReportMT	P2P	inout	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_PlanModificationRequestMT	P2P	inout	Core
A-GRA Custom Extension	MA_PlanModificationRequestStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_PlanningFunctionSettingsCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_PlanningFunctionSettingsCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_PlatformOverrideStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_PositionReportDetailedMT	P2P	inout	Core
A-GRA Custom Extension	MA_PositionReportMT	P2P	inout	Core
A-GRA Custom Extension	MA_PrioritizationListMT	P2P	inout	Core, ALR
A-GRA Custom Extension	MA_RaftAppendEntriesRequestMT	P2P	inout	Raft Leader Election
A-GRA Custom Extension	MA_RaftAppendEntriesRequestStatusMT	P2P	inout	Raft Leader Election
A-GRA Custom Extension	MA_RaftVoteRequestMT	P2P	inout	Raft Leader Election
A-GRA Custom Extension	MA_RaftVoteRequestStatusMT	P2P	inout	Raft Leader Election
A-GRA Custom Extension	MA_ResponseActivityMT	P2P	inout	Core
A-GRA Custom Extension	MA_ResponseCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_ResponseCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_ResponseMT	P2P	inout	Core
A-GRA Custom Extension	MA_RouteActivityPlanMT	P2P	inout	Core
A-GRA Custom Extension	MA_RouteDeconflictionAlertMT	P2P	inout	Core
A-GRA Custom Extension	MA_RoutePlanMT	P2P	inout	Core
A-GRA Custom Extension	MA_StrikeActivityMT	P2P	inout	Core, Store Management
A-GRA Custom Extension	MA_StrikeCapabilityMT	P2P	inout	Store Management,

Message Type	Message Name	Interface	Direction	Applicable MUCs
				Core
A-GRA Custom Extension	MA_SystemManagementRequestMT	P2P	inout	Core
A-GRA Custom Extension	MA_SystemManagementRequestStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_SystemNotificationMT	P2P	inout	ALR, Core
A-GRA Custom Extension	MA_TaskCommandMT	P2P	inout	Core
A-GRA Custom Extension	MA_TaskCommandStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_TaskMT	P2P	inout	Core
A-GRA Custom Extension	MA_TaskPlanMT	P2P	inout	Core
A-GRA Custom Extension	MA_TaskStatusMT	P2P	inout	Core
A-GRA Custom Extension	MA_WEZ_MT	P2P	inout	Core
UCI 2.3	MissionContingencyAlertMT	P2P	inout	Core
UCI 2.3	MissionPlanApprovalStatusMT	P2P	inout	Core
UCI 2.3	ObservationMeasurementReportMT	P2P	inout	Core
UCI 2.3	OpaqueCapabilityMT	P2P	inout	Core
UCI 2.3	OpaqueCapabilityStatusMT	P2P	inout	Core
UCI 2.3	OperatorMT	P2P	inout	Core
UCI 2.3	PackageMT	P2P	inout	Bully Leader Election, Static Fitness Score Leader Election, Max Consensus Leader Election, Core
UCI 2.3	PackageStatusMT	P2P	inout	Core, Bully Leader Election, Static Fitness Score Leader Election, Max Consensus Leader Election
UCI 2.3	PO_ActivityMT	P2P	inout	PO, Core
UCI 2.3	PO_CapabilityMT	P2P	inout	Core, PO
UCI 2.3	PO_CapabilityStatusMT	P2P	inout	Core, PO

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	PO_CommandMT	P2P	inout	Core
UCI 2.3	PO_CommandStatusMT	P2P	inout	Core
UCI 2.3	PO_SettingsCommandMT	P2P	inout	Core
UCI 2.3	PO_SettingsCommandStatusMT	P2P	inout	Core
UCI 2.3	QueryDataRequestMT	P2P	inout	Core
UCI 2.3	QueryDataRequestStatusMT	P2P	inout	Core
UCI 2.3	RadarAltimeterCapabilityMT	P2P	inout	Core
UCI 2.3	RadarAltimeterCapabilityStatusMT	P2P	inout	Core
UCI 2.3	RadarAltimeterCommandMT	P2P	inout	Core
UCI 2.3	RadarAltimeterCommandStatusMT	P2P	inout	Core
UCI 2.3	RadarAltimeterSettingsCommandMT	P2P	inout	Core
UCI 2.3	RadarAltimeterSettingsCommandStatusMT	P2P	inout	Core
UCI 2.3	RefuelCapabilityMT	P2P	inout	Core
UCI 2.3	RefuelCapabilityStatusMT	P2P	inout	Core
UCI 2.3	RefuelCommandMT	P2P	inout	Core
UCI 2.3	RefuelCommandStatusMT	P2P	inout	Core
UCI 2.3	RefuelSettingsCommandMT	P2P	inout	Core
UCI 2.3	RefuelSettingsCommandStatusMT	P2P	inout	Core
UCI 2.3	RelationshipDesignationMT	P2P	inout	Core
UCI 2.3	ResponsePlanMT	P2P	inout	Core
UCI 2.3	RouteModificationRequestMT	P2P	inout	Core
UCI 2.3	RouteModificationRequestStatusMT	P2P	inout	Core
UCI 2.3	RoutePlanApprovalStatusMT	P2P	inout	Core
UCI 2.3	RoutePlanExecutionStatusMT	P2P	inout	Core
UCI 2.3	SAR_ActivityMT	P2P	inout	Core
UCI 2.3	SAR_CapabilityMT	P2P	inout	Core
UCI 2.3	SAR_CapabilityStatusMT	P2P	inout	Core
UCI 2.3	SAR_CommandMT	P2P	inout	Core
UCI 2.3	SAR_CommandStatusMT	P2P	inout	Core
UCI 2.3	SAR_SettingsCommandMT	P2P	inout	Core
UCI 2.3	SAR_SettingsCommandStatusMT	P2P	inout	Core
UCI 2.3	SMTI_ActivityMT	P2P	inout	Core
UCI 2.3	SMTI_CapabilityMT	P2P	inout	Core
UCI 2.3	SMTI_CapabilityStatusMT	P2P	inout	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	SMTI_CommandMT	P2P	inout	Core
UCI 2.3	SMTI_CommandStatusMT	P2P	inout	Core
UCI 2.3	SMTI_SettingsCommandMT	P2P	inout	Core
UCI 2.3	SMTI_SettingsCommandStatusMT	P2P	inout	Core
UCI 2.3	StoreManagementCommandMT	P2P	inout	Core
UCI 2.3	StoreManagementCommandStatusMT	P2P	inout	Core
UCI 2.3	StoreManagementStatusMT	P2P	inout	Store Management
UCI 2.3	StrikeCapabilityStatusMT	P2P	inout	Core, Store Management
UCI 2.3	StrikeCommandMT	P2P	inout	Core
UCI 2.3	StrikeCommandStatusMT	P2P	inout	Core
UCI 2.3	SubsystemStatusMT	P2P	inout	Core
UCI 2.3	SurvivabilityRiskLevelMT	P2P	inout	ALR
UCI 2.3	SystemDeploymentCapabilityMT	P2P	inout	Core
UCI 2.3	SystemDeploymentCapabilityStatusMT	P2P	inout	Core
UCI 2.3	SystemStatusMT	P2P	inout	Core
UCI 2.3	TacticalOrderCapabilityMT	P2P	inout	Core
UCI 2.3	TacticalOrderCapabilityStatusMT	P2P	inout	Core
UCI 2.3	TaskCancelCommandMT	P2P	inout	Core
UCI 2.3	TaskCancelCommandStatusMT	P2P	inout	Core
UCI 2.3	TaskPlanApprovalStatusMT	P2P	inout	Core
UCI 2.3	TaskPlanExecutionStatusMT	P2P	inout	Core
UCI 2.3	TurretCommandMT	P2P	inout	Core
UCI 2.3	TurretCommandStatusMT	P2P	inout	Core
UCI 2.3	WeatherMT	P2P	inout	Core
UCI 2.3	WeatherRadarActivityMT	P2P	inout	Core
UCI 2.3	WeatherRadarCapabilityMT	P2P	inout	Core
UCI 2.3	WeatherRadarCapabilityStatusMT	P2P	inout	Core
UCI 2.3	WeatherRadarCommandMT	P2P	inout	Core
UCI 2.3	WeatherRadarCommandStatusMT	P2P	inout	Core
UCI 2.3	WeatherRadarSettingsCommandMT	P2P	inout	Core
UCI 2.3	WeatherRadarSettingsCommandStatusMT	P2P	inout	Core

3.5 VI MMS

Table 3-5: VI MMS

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	ActivityPlanExecutionStatusMT	VI	out	Core
UCI 2.3	AirfieldReportMT	VI	out	Core
UCI 2.3	CommTerminalPlanActivationCommandMT	VI	in	Carrier
UCI 2.3	CommTerminalPlanActivationCommandStatusMT	VI	out	Carrier
UCI 2.3	ComponentStatusMT	VI	out	Core
UCI 2.3	ControlRequestMT	VI	in	Core
UCI 2.3	ControlRequestStatusMT	VI	out	Core
UCI 2.3	ControlStatusMT	VI	out	Core
UCI 2.3	ElevationRequestMT	VI	in	MA Terrain Data
UCI 2.3	ElevationRequestStatusMT	VI	out	MA Terrain Data
A-GRA Custom Extension	MA_ActionStatusMT	VI	out	Core
A-GRA Custom Extension	MA_CarrierDeckHandlingCommandMT	VI	out	Carrier
A-GRA Custom Extension	MA_CarrierDeckHandlingCommandStatusMT	VI	in	Carrier
A-GRA Custom Extension	MA_CarrierLaunchReadyStatusMT	VI	in	Carrier
A-GRA Custom Extension	MA_CarrierReportMT	VI	out	Carrier
A-GRA Custom Extension	MA_FaultMT	VI	out	Core
A-GRA Custom Extension	MA_FlightActivityMT	VI	out	Core
A-GRA Custom Extension	MA_FlightCapabilityMT	VI	inout	Core
A-GRA Custom Extension	MA_FlightCapabilityStatusMT	VI	out	Core
A-GRA Custom Extension	MA_FlightCommandMT	VI	in	Core, Carrier
A-GRA Custom Extension	MA_FlightCommandStatusMT	VI	out	Core, Carrier
A-GRA Custom Extension	MA_MissionPlanActivationCommandMT	VI	inout	Core
A-GRA Custom Extension	MA_MissionPlanActivationCommandStatusMT	VI	out	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
A-GRA Custom Extension	MA_MissionPlanActivationStatusMT	VI	out	Core
A-GRA Custom Extension	MA_MissionPlanExecutionStatusMT	VI	out	Core
A-GRA Custom Extension	MA_PositionReportDetailedMT	VI	out	Core
A-GRA Custom Extension	MA_PositionReportMT	VI	out	Carrier
A-GRA Custom Extension	MA_ResponseMT	VI	in	Core
A-GRA Custom Extension	MA_RoutePlanMT	VI	inout	Core
A-GRA Custom Extension	MA_SystemManagementRequestMT	VI	in	Core
A-GRA Custom Extension	MA_SystemManagementRequestStatusMT	VI	out	Core
A-GRA Custom Extension	MA_SystemNotificationMT	VI	inout	Core
A-GRA Custom Extension	MA_TaskCommandMT	VI	in	Core
A-GRA Custom Extension	MA_TaskCommandStatusMT	VI	out	Core
A-GRA Custom Extension	MA_TaskMT	VI	inout	Core
A-GRA Custom Extension	MA_TaskStatusMT	VI	out	Core
A-GRA Custom Extension	MA_NavigationReportMT	VI	out	Core
UCI 2.3	ProductLocationMT	VI	out	Core
UCI 2.3	ProductMetadataMT	VI	out	Core
UCI 2.3	QueryDataRequestMT	VI	in	Core
UCI 2.3	QueryDataRequestStatusMT	VI	out	Core
UCI 2.3	ReferenceFrameMT	VI	out	Carrier
UCI 2.3	ResponsePlanExecutionStatusMT	VI	out	Core
UCI 2.3	RouteActivityPlanExecutionStatusMT	VI	out	Core
UCI 2.3	RoutePlanExecutionStatusMT	VI	out	Core
UCI 2.3	RoutePlanValidationCommandMT	VI	in	Core
UCI 2.3	RoutePlanValidationCommandStatusMT	VI	out	Core
UCI 2.3	RoutePlanValidationMT	VI	out	Core

Message Type	Message Name	Interface	Direction	Applicable MUCs
UCI 2.3	ServiceStatusDataRequestMT	VI	in	Core
UCI 2.3	ServiceStatusDataRequestStatusMT	VI	out	Core
UCI 2.3	ServiceStatusMT	VI	inout	Core
UCI 2.3	SubsystemStatusDataRequestMT	VI	in	Core
UCI 2.3	SubsystemStatusDataRequestStatusMT	VI	out	Core
UCI 2.3	SubsystemStatusMT	VI	inout	Core
UCI 2.3	TaskPlanExecutionStatusMT	VI	out	Core
UCI 2.3	WeatherObservationMT	VI	out	Core

4 MISSION AUTONOMY L1 UCI 2.3 EXTENSION SET

The tables in the following sections provide the specifications for extended UCI 2.3 messages utilized by the A-GRA to communicate Autonomy L1 interface interactions. The tables include both extended messages and message types. Each table includes the message name, the functional description, and fields contained within. Top-level messages include images of the nested message structure. For a better view of the diagram and the message structure, it is strongly recommended to look at the schema in a XML viewer tool.

4.1 C2 Interface

4.1.1 MA_FlightCapabilityMT UCI Extension

MA_FlightCapabilityMT	
Description	Extended to indicate the type of flight capability via the FlightCapabilityEnum and provide per-control mode performance parameters. See the XSD File for more info
Ext. Fields	HSA_CSA_PerformanceProfile : MA_FlightControlModesPerformanceProfileType WaypointFollowingPerformanceProfile : MA_FlightControlModesPerformanceProfileType CurveFollowingPerformanceProfile : MA_FlightControlModesPerformanceProfileType AccelerationLimit : MA_BodyReferenceAccelerationType AccelerationLimitValue : MA_AccelerationLimitPairType BodyReferenceOrientationRate : MA_BodyReferenceOrientationRateType OrientationRateLimits : MA_BodyReferenceOrientationRateType AirspeedPair : PathSegmentSpeedValueType

Table A-4-1: C2 Interface MA_FlightCapabilityMT UCI Extension

HSA_CSA_PerformanceProfile	
Description	Indicates performance profile for HSA_CSA flight control mode.
Base Type	MA_FlightControlModesPerformanceProfileType

Message Structure		
Field Name	Field Type	Field Usage
MinAirspeed	MA_AirspeedLimitType	Repeated
Description	Minimum allowable airspeed given as a function of altitude.	
MaxAirspeed	MA_AirspeedLimitType	Repeated
Description	Maximum allowable airspeed given as a function of altitude.	
BestEnduranceAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum endurance given as a function of altitude.	
BestRangeAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum range given as a function of altitude.	
MinAltitude	AltitudeReferenceType	Optional
Description	Minimum allowable altitude.	
MaxAltitude	AltitudeReferenceType	Optional
Description	Maximum allowable altitude.	
MinAccelerationLimits	MA_AccelerationLimitsType	Repeated
Description	The vehicle's acceleration limits in the current operating domain of the system as a function of time. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
ExcessPowerOrAcceleration	MA_ExcessPowerOrAccelerationType	Optional
Description	Provides either specific excess power or paired acceleration and climb rate data for the platform.	
MaxOrientationLimits	MA_OrientationLimitType	Repeated
Description	Euler Angle Sequence describing the maximum orientation of the vehicle in the order yaw, pitch, roll as a function of airspeed, altitude, and weight.	
MaxOrientationRateLimits	MA_OrientationRateLimitsType	Repeated
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
MaxTurnRate	AngleRateType	Optional
Description	Maximum allowable turn rate in radians/sec.	
MaxDescentRate	MA_SpeedType	Repeated
Description	Maximum allowable descent rate as a function of airspeed, altitude, and weight.	
MaxDeceleration	MA_AccelerationLimitsType	Repeated
Description	Maximum allowable deceleration limits as a function of airspeed, altitude, and weight.	
FuelBurnRate	MA_FuelBurnRateType	Repeated
Description	Fuel burn rate as a function of airspeed, altitude, and weight.	

Table A-4-2: C2 Interface MA_FlightCapabilityMT - HSA_CSA_PerformanceProfile UCI Extension Field

WaypointFollowingPerformanceProfile		
Description	Indicates performance profile for Waypoint Following flight control mode.	
Base Type	MA_FlightControlModesPerformanceProfileType	
Message Structure		
Field Name	Field Type	Field Usage
MinAirspeed	MA_AirspeedLimitType	Repeated
Description	Minimum allowable airspeed given as a function of altitude.	
MaxAirspeed	MA_AirspeedLimitType	Repeated
Description	Maximum allowable airspeed given as a function of altitude.	
BestEnduranceAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum endurance given as a function of altitude.	
BestRangeAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum range given as a function of altitude.	
MinAltitude	AltitudeReferenceType	Optional
Description	Minimum allowable altitude.	
MaxAltitude	AltitudeReferenceType	Optional
Description	Maximum allowable altitude.	
MinAccelerationLimits	MA_AccelerationLimitsType	Repeated
Description	The vehicle's acceleration limits in the current operating domain of the system as a function of time. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
ExcessPowerOrAcceleration	MA_ExcessPowerOrAccelerationType	Optional
Description	Provides either specific excess power or paired acceleration and climb rate data for the platform.	
MaxOrientationLimits	MA_OrientationLimitType	Repeated
Description	Euler Angle Sequence describing the maximum orientation of the vehicle in the order yaw, pitch, roll as a function of airspeed, altitude, and weight.	
MaxOrientationRateLimits	MA_OrientationRateLimitsType	Repeated
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
MaxTurnRate	AngleRateType	Optional
Description	Maximum allowable turn rate in radians/sec.	
MaxDescentRate	MA_SpeedType	Repeated
Description	Maximum allowable descent rate as a function of airspeed, altitude, and weight.	

MaxDeceleration	MA_AccelerationLimitsType	Repeated
Description	Maximum allowable deceleration limits as a function of airspeed, altitude, and weight.	
FuelBurnRate	MA_FuelBurnRateType	Repeated
Description	Fuel burn rate as a function of airspeed, altitude, and weight.	

Table A-4-3: C2 Interface MA_FlightCapabilityMT - WaypointFollowingPerformanceProfile UCI Extension Field

CurveFollowingPerformanceProfile		
Description	Indicates performance profile for Curve Following flight control mode.	
Base Type	MA_FlightControlModesPerformanceProfileType	
Message Structure		
Field Name	Field Type	Field Usage
MinAirspeed	MA_AirspeedLimitType	Repeated
Description	Minimum allowable airspeed given as a function of altitude.	
MaxAirspeed	MA_AirspeedLimitType	Repeated
Description	Maximum allowable airspeed given as a function of altitude.	
BestEnduranceAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum endurance given as a function of altitude.	
BestRangeAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum range given as a function of altitude.	
MinAltitude	AltitudeReferenceType	Optional
Description	Minimum allowable altitude.	
MaxAltitude	AltitudeReferenceType	Optional
Description	Maximum allowable altitude.	
MinAccelerationLimits	MA_AccelerationLimitsType	Repeated
Description	The vehicle's acceleration limits in the current operating domain of the system as a function of time. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
ExcessPowerOrAcceleration	MA_ExcessPowerOrAccelerationType	Optional
Description	Provides either specific excess power or paired acceleration and climb rate data for the platform.	
MaxOrientationLimits	MA_OrientationLimitType	Repeated
Description	Euler Angle Sequence describing the maximum orientation of the vehicle in the order yaw, pitch, roll as a function of airspeed, altitude, and weight.	
MaxOrientationRateLimits	MA_OrientationRateLimitsType	Repeated
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	

MaxTurnRate	AngleRateType	Optional
Description	Maximum allowable turn rate in radians/sec.	
MaxDescentRate	MA_SpeedType	Repeated
Description	Maximum allowable descent rate as a function of airspeed, altitude, and weight.	
MaxDeceleration	MA_AccelerationLimitsType	Repeated
Description	Maximum allowable deceleration limits as a function of airspeed, altitude, and weight.	
FuelBurnRate	MA_FuelBurnRateType	Repeated
Description	Fuel burn rate as a function of airspeed, altitude, and weight.	

Table A-4-4: C2 Interface MA_FlightCapabilityMT - CurveFollowingPerformanceProfile UCI Extension Field

AccelerationLimit		
Description	Specified acceleration limits in body reference or NED coordinate frame.	
Base Type	MA_BodyReferenceAccelerationType	
Message Structure		
Field Name	Field Type	Field Usage
X_Accel	AccelerationType	Required
Description	Body-referenced acceleration component along the longitudinal (x or roll) axis, measured in meters/sec^2	
Y_Accel	AccelerationType	Required
Description	Body-referenced acceleration component along the lateral (y or pitch) axis, measured in meters/sec^2	
Z_Accel	AccelerationType	Required
Description	Body-referenced acceleration component along the vertical (z or yaw) axis, measured in meters/sec^2.	
Timestamp	DateTimeType	Optional
Description	Indicates the time when the acceleration data was measured or last known to be correct. The element can also indicate the time at which a future velocity of a System, Entity, etc. will be achieved.	

Table A-4-5: C2 Interface MA_FlightCapabilityMT - AccelerationLimit UCI Extension Field

AccelerationLimitValue		
Description	Value for the specified acceleration limit, provided either as a set of body referenced orientation rates, or a unitless Mach value.	
Base Type	MA_AccelerationLimitPairType	
Message Structure		
Field Name	Field Type	Field Usage
BodyReferenceOrientationRate	MA_BodyReferenceOrientationRateType	Required
Description	Body reference orientation rates to be paired with the specified acceleration limit.	
MachValue	MachType	Required

Description	Unitless Mach value to be paired with the specified acceleration limit.
-------------	---

Table A-4-6: C2 Interface MA_FlightCapabilityMT - AccelerationLimitValue UCI Extension Field

BodyReferenceOrientationRate		
Description	Body reference orientation rates to be paired with the specified acceleration limit.	
Base Type	MA_BodyReferenceOrientationRateType	
Message Structure		
Field Name	Field Type	Field Usage
RollRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the longitudinal (x or roll) axis, measured in radians/sec.	
PitchRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the lateral (y or pitch) axis, measured in radians/sec.	
YawRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the vertical (z or yaw) axis, measured in radians/sec.	
Timestamp	DateTimeType	Optional
Description	Indicates the time when the velocity data was measured or last known to be correct. The element can also indicate the time at which a future velocity of a System, Entity, etc. will be achieved.	

Table A-4-7: C2 Interface MA_FlightCapabilityMT - BodyReferenceOrientationRate UCI Extension Field

OrientationRateLimits		
Description	Specified orientation rate limits in body reference or NED coordinate frame.	
Base Type	MA_BodyReferenceOrientationRateType	
Message Structure		
Field Name	Field Type	Field Usage
RollRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the longitudinal (x or roll) axis, measured in radians/sec.	
PitchRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the lateral (y or pitch) axis, measured in radians/sec.	
YawRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the vertical (z or yaw) axis, measured in radians/sec.	
Timestamp	DateTimeType	Optional
Description	Indicates the time when the velocity data was measured or last known to be correct. The element can also indicate the time at which a future velocity of a System, Entity,	

	etc. will be achieved.
--	------------------------

Table A-4-8: C2 Interface MA_FlightCapabilityMT - OrientationRateLimits UCI Extension Field

AirspeedPair		
Description	Airspeed pair value for associated orientation rate limit, specified in body reference or NED coordinate frame.	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-9: C2 Interface MA_FlightCapabilityMT - AirspeedPair UCI Extension Field

4.1.2MA_FlightCommandMT UCI Extension

MA_FlightCommandMT	
Description	Message extension included to invoke a flight capability to perform a new flight activity or change and existing flight activity. See the XSD File for more info
Ext. Fields	Command : MA_FlightCommandType Capability : MA_FlightCapabilityCommandType HSA_CSA : MA_HSA_CSA_Type WaypointFollowing : MA_WaypointFollowingType CurveFollowing : MA_CurveControlType Speed : PathSegmentSpeedType Heading : MA_DirectionReferenceType SpeedChoice : MA_HSA_SpeedChoiceType SpeedValue : PathSegmentSpeedValueType CurveFitMethod : MA_CurveFitMethodEnum Reference : MA_HeadingReferenceEnum ControlPoint : MA_CurveFollowingControlPointType RelativeAcceleration : MA_AccelerationChoiceType RelativeVelocity : MA_VelocityChoiceType OrientationRate : MA_OrientationRateChoiceType Direction : MA_DirectionChoiceType Course : MA_DirectionReferenceType

Table A-4-10: C2 Interface MA_FlightCommandMT UCI Extension

Command		
Description	Indicates an instance of a Flight Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate independent Capability CommandStatus message.	
Base Type	MA_FlightCommandType	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_FlightCapabilityCommandType	Required
Description	Indicates a new invocation of a Flight Capability. Generally, if accepted, the command will result in one or more new Flight Activities being created and reported via the Flight Activity message. The request/response interaction terminates as soon as the command is accepted or rejected; this element is not used to interact with an "active" command. Updates and/or additional interaction with the resulting Activity (after the command is accepted) is accomplished via the sibling Activity element.	
Activity	MA_FlightActivityCommandType	Required
Description	Indicates a command to modify an existing Flight Activity (which was previously reported via the Flight Activity message and was marked as "interactive"). The request/response interaction terminates as soon as the modification is accepted or rejected. The modifications are reflected in subsequent Flight Activity messages.	

Table A-4-11: C2 Interface MA_FlightCommandMT - Command UCI Extension Field

Capability		
Description	Indicates a new invocation of a Flight Capability. Generally, if accepted, the command will result in one or more new Flight Activities being created and reported via the Flight Activity message. The request/response interaction terminates as soon as the command is accepted or rejected; this element is not used to interact with an "active" command. Updates and/or additional interaction with the resulting Activity (after the command is accepted) is accomplished via the sibling Activity element.	
Base Type	MA_FlightCapabilityCommandType	
Message Structure		
Field Name	Field Type	Field Usage
Loiter	MA_LoiterType	Optional
Description	Indicates the parameters for a loiter.	
MustFly	MustFlyType	Optional
Description	Indicates the parameters for a must fly.	
Formation	MA_FormationType	Repeated
Description	Indicates the relative positions for the entities in the formation.	
FlightControlMode	MA_FlightControlModesChoiceType	Optional
Description	See annotations in child elements and messages/elements that use this type for	

	details.	
AltitudeStackedMarshal	MA_AltitudeStackedMarshalType	Optional
Description	Indicates kinematics for an altitude stacked marshal.	
Departure	MA_DepartureType	Optional
Description	This element identifies the parameters for a departure/take-off task.	
Recovery	MA_RecoveryType	Optional
Description	This element identifies the parameters for a recovery/land task.	
RoutePlanIntercept	MA_RoutePlanInterceptType	Optional
Description	This element defines the parameters for a Route intercept	
CapabilityID	CapabilityID_Type	Required
Description	Indicates the Capability instance being commanded.	
Ranking	CapabilityCommandRankingType	Required
Description	Indicates the command's rank relative to other commands and rank-related overrides and tailoring.	
TemporalConstraints	CapabilityCommandTemporalConstraintsType	Optional
Description	Indicates temporal constraints for the command. If omitted, the command should be scheduled immediately while satisfying other applicable constraints.	
OverrideRejection	boolean	Optional
Description	Indicates that the Command shall be performed even though it was previously rejected.	
Traceability	TraceabilityType	Optional
Description	C2 sources work at different levels of detail and abstraction, progressing from what to do to how specifically to do it. Inputs from abstract tasking sources and Tasks can be decomposed into discrete, actionable Tasks and/or Capability commands. This element provides traceability to the external tasking or Task from which this Capability command was derived.	
Classification	SecurityInformationType	Optional
Description	This element provides the classification label that the Subsystem should place on messages and other data resulting from the Command.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-12: C2 Interface MA_FlightCommandMT - Capability UCI Extension Field

HSA_CSA	
Description	This message shall be used to provide the ability to command a new flight vector to the Platform.
Base Type	MA_HSA_CSA_Type

Message Structure		
Field Name	Field Type	Field Usage
Altitude	AltitudeReferenceType	Optional
Description	Altitude hold value to be achieved and reference to altitude measurement source.	
Speed	PathSegmentSpeedType	Optional
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Direction	MA_DirectionChoiceType	Optional
Description	Defines heading or course type and reference to hold	

Table A-4-13: C2 Interface MA_FlightCommandMT - HSA_CSA UCI Extension Field

WaypointFollowing		
Description	This message shall be used to provide the ability to send a new waypoint path or segment for the Platform to follow.	
Base Type	MA_WaypointFollowingType	
Message Structure		
Field Name	Field Type	Field Usage
Route	MA_RouteType	Required
Description	Indicates the Paths and Segments that make up the Route to be flown.	

Table A-4-14: C2 Interface MA_FlightCommandMT - WaypointFollowing UCI Extension Field

CurveFollowing		
Description	Indicates the parameters for curve following control.	
Base Type	MA_CurveControlType	
Message Structure		
Field Name	Field Type	Field Usage
CurveSegments	MA_NURBS_PointType	Repeated
Description	Specifies the curve segments as a set of NURBS points.	
AppendCurve	EmptyType	Optional
Description	Specifies this curve will be appended to a previous curve command. This is only valid if the vehicle is currently executing a curve.	
EndOfCurveBehavior	MA_EndOfCurveBehaviorEnum	Optional
Description	Specifies the vehicle behavior at the completion of the curve.	

Table A-4-15: C2 Interface MA_FlightCommandMT - CurveFollowing UCI Extension Field

Speed	
Description	Defines speed type (reference frame) for all speed related fields in this message.
Base Type	PathSegmentSpeedType
Message Structure	

Field Name	Field Type	Field Usage
SpeedChoice	PathSegmentSpeedChoiceType	Optional
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
SpeedOptimization	SpeedOptimizationEnum	Optional
Description	Indicates that the System will vary its speed autonomously according to the specified optimization algorithm.	

Table A-4-16: C2 Interface MA_FlightCommandMT - Speed UCI Extension Field

Heading		
Description	Defines heading type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-17: C2 Interface MA_FlightCommandMT - Heading UCI Extension Field

SpeedChoice		
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
Base Type	MA_HSA_SpeedChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedValue	PathSegmentSpeedValueType	Required
Description	Indicates speed in meters per second (m/s).	
MachValue	MachType	Required
Description	Indicates the speed reference for the associated speed value.	

Table A-4-18: C2 Interface MA_FlightCommandMT - SpeedChoice UCI Extension Field

SpeedValue		
Description	Indicates speed in meters per second (m/s).	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage

Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-19: C2 Interface MA_FlightCommandMT - SpeedValue UCI Extension Field

CurveFitMethod	
Description	Method through which a curve should be fitted to the discretized points in ControlPoint.
Base Type	MA_CurveFitMethodEnum
Message Structure	
Enumeration Literal	Description
B_SPLINE	B-Spline (basis spline) fit.
BEZIER	Bezier curve fit.
CATMULL_ROM	Catmull-Rom spline fit.
NATURAL_CUBIC	Natural Cubic curve fit.

Table A-4-20: C2 Interface MA_FlightCommandMT - CurveFitMethod UCI Extension Field

Reference	
Description	Reference to type of heading or course given.
Base Type	MA_HeadingReferenceEnum
Message Structure	
Enumeration Literal	Description
TRUE_NORTH	Heading value according to Geographic North.
MAGNETIC_NORTH	Heading value according to location where the planet's magnetic field points vertically downward.

Table A-4-21: C2 Interface MA_FlightCommandMT - Reference UCI Extension Field

ControlPoint		
Description	Control Points for the desired discretized curve or spline path.	
Base Type	MA_CurveFollowingControlPointType	
Message Structure		
Field Name	Field Type	Field Usage
Position	PointChoice4D_Type	Required
Description	Physical location of the referenced item in geospatial coordinates. The use of the timestamp in this context represents the time the positional data was last measured. Position data may be specified as either a geospatial point or relative to a separately defined reference frame.	
PositionUncertainty	UncertaintyType	Optional

Description	Uncertainty of the physical location of the referenced item.	
DomainVelocity	Velocity3D_Type	Optional
Description	Vehicle's velocity in the current operating domain of the system. Air vehicle components are in True Air Speed.	
GroundVelocity	Velocity2D_Type	Optional
Description	Representation of the vehicle's ground velocity as directional speed components.	
RelativeVelocity	MA_VelocityChoiceType	Optional
Description	Represents the vehicle's velocity, in units of m/s, in the separately defined reference frame referenced in the sibling Position element. This element should only be used when the RelativePoint choice is selected and the separately defined reference frame is itself moving.	
DomainAcceleration	Acceleration3D_Type	Optional
Description	The vehicle's acceleration in the current operating domain of the system.	
Orientation	OrientationType	Optional
Description	Euler Angle Sequence describing the orientation of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
OrientationRate	MA_OrientationRateChoiceType	Optional
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
RelativeAcceleration	MA_AccelerationChoiceType	Optional
Description		

Table A-4-22: C2 Interface MA_FlightCommandMT - ControlPoint UCI Extension Field

RelativeAcceleration		
Description		
Base Type	MA_AccelerationChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
BodyReferenceAcceleration	MA_BodyReferenceAccelerationType	Required
Description	Body reference accelerations.	
NED_Acceleration	Acceleration3D_Type	Required
Description	Inertial, NED coordinate frame accelerations.	

Table A-4-23: C2 Interface MA_FlightCommandMT - RelativeAcceleration UCI Extension Field

RelativeVelocity	
Description	Represents the vehicle's velocity, in units of m/s, in the separately defined reference frame referenced in the sibling Position element. This element should only be used when the RelativePoint choice is selected and the separately defined reference frame is itself moving.

Base Type	MA_VelocityChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
BodyReferenceVelocity	MA_BodyReferenceVelocityType	Required
Description	Velocity in body reference frame.	
NED_Velocity	Velocity3D_Type	Required
Description	Velocity in North East Down reference frame.	

Table A-4-24: C2 Interface MA_FlightCommandMT - RelativeVelocity UCI Extension Field

OrientationRate		
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
Base Type	MA_OrientationRateChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
BodyReferenceOrientationRate	MA_BodyReferenceOrientationRateType	Required
Description	Orientation rate in body reference.	
NED_OrientationRate	OrientationRateType	Required
Description	Orientation rate in inertial reference.	

Table A-4-25: C2 Interface MA_FlightCommandMT - OrientationRate UCI Extension Field

Direction		
Description	Defines heading or course type and reference to hold	
Base Type	MA_DirectionChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
Heading	MA_DirectionReferenceType	Optional
Description	Defines heading type and reference to hold.	
Course	MA_DirectionReferenceType	Optional
Description	Defines course type and reference to hold.	

Table A-4-26: C2 Interface MA_FlightCommandMT - Direction UCI Extension Field

Course		
Description	Defines course type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage

Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-27: C2 Interface MA_FlightCommandMT - Course UCI Extension Field

4.1.3 MA_FlightCommandStatusMT UCI Extension

MA_FlightCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_FlightCommandStatusMDT CannotComplyDetails : MA_CannotComplyDetailsType Severity : MA_FaultSeverityEnum

Table A-4-28: C2 Interface MA_FlightCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_FlightCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CannotComplyDetails	MA_CannotComplyDetailsType	Optional
Description	Provides detail for why FA cannot comply with the flight command.	
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-29: C2 Interface MA_FlightCommandStatusMT - MessageData UCI Extension Field

CannotComplyDetails		
Description	Provides detail for why FA cannot comply with the flight command.	
Base Type	MA_CannotComplyDetailsType	
Message Structure		
Field Name	Field Type	Field Usage
ValidationResult	MA_ValidationResultEnum	Repeated
Description	In case of flight command rejection, provides the reason for Flight Autonomy rejection. Further details can be provided by Flight Autonomy through the ValidationResultReason. List size for this element is based on "Select All That Apply" condition.	
ValidationResultReason	MA_ValidationResultReasonType	Repeated
Description	In case of flight command rejection, provides additional context for Flight Autonomy rejection.	

Table A-4-30: C2 Interface MA_FlightCommandStatusMT - CannotComplyDetails UCI Extension Field

Severity	
Description	The severity of the fault. This enumeration is modified for Mission Autonomy adaptation.
Base Type	MA_FaultSeverityEnum
Message Structure	
Enumeration Literal	Description
NOMINAL	A fault that carries the nominal level indicates that fault does not impact the current mission but may indicate something that should be checked in maintenance. Faults should be tagged as nominal if they are targeting maintenance. An example might be air filter hasn't been changed in 5000 hours or queue length reached 60% of max.
ADVISORY	A fault that is important but is not a Caution or Warning; this can be a configuration change, a condition that is contributing to a degraded aircraft or subsystem operation, or an anomaly that is being automatically controlled or corrected by a higher level system.
CAUTION	A fault that is indicative of a condition that, without a timely and correct response, could result in equipment damage or failure of mission.
WARNING	A fault that is indicative of a condition requiring immediate response or attention to prevent loss of aircraft, or failure of mission.
FAILED	A fault that carries a failed level indicates the failure of a component which may preclude the use of a capability. Faults should be tagged with failed if the component state will be marked faulted. Failed components may or may not prevent the completion of the mission.

Table A-4-31: C2 Interface MA_FlightCommandStatusMT - Severity UCI Extension Field

4.1.4MA_FlightActivityMT UCI Extension

MA_FlightActivityMT

Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	VehicleCommandState : Activity : MA_FlightActivityType Speed : PathSegmentSpeedValueType Heading : MA_DirectionReferenceType

Table A-4-32: C2 Interface MA_FlightActivityMT UCI Extension

VehicleCommandState		
Description		
Base Type		
Message Structure		
Field Name	Field Type	Field Usage

Table A-4-33: C2 Interface MA_FlightActivityMT - VehicleCommandState UCI Extension Field

Activity		
Description	Indicates the dynamic operational characteristics of an Activity of a System's Flight Capability.	
Base Type	MA_FlightActivityType	
Message Structure		
Field Name	Field Type	Field Usage
ActualEndPoint	MA_EndPointType	Repeated
Description	Indicates end points for the Flight activity. The current end point (the end point the System is currently flying to) is listed first followed by subsequent end points if known. If the Flight Activity was planned and the actual Activity is following the plan, the RouteActivityPlan* messages provide details relative to the plan. For planned Flight Activities against moving targets the actual, dynamically calculated kinematic details can be provided with this element.	
ActualCompletionTime	DateTimeType	Optional
Description	This field specifies the actual time when the Flight Activity completed.	
VehicleCommandState	MA_VehicleCommandStateType	Required
Description	Indicates the currently commanded parameters per the Flight Autonomy's execution of the request FlightCommand.	
CurveFollowingControl	MA_CurveFollowingControlType	Optional
Description	Indicates the curve following parameters, validity and status.	
RoutePlanInterceptStatus	MA_RoutePlanInterceptStatusType	Optional
Description	Status of the executing RoutePlan Intercept.	
ActivityID	ActivityID_Type	Required
Description	Indicates the unique ID of the Activity.	

CapabilityID	CapabilityID_Type	Repeated
Description	Indicates a Capability which the Activity is an instance of. Generally an Activity is an instance of a single Capability. An Activity can be associated with multiple Capabilities when, for example, a Subsystem has distinct Capabilities for automated and manual. In this case, if a manual command is issued while an automated Activity that achieves the desired result already exists, a single Activity represents both Capabilities.	
Interactive	boolean	Required
Description	Indicates whether or not the Activity can be edited/modified via a [Capability]Command...Activity message.	
ActivityState	ActivityStateEnum	Required
Description	Indicates the current state of the Activity its state machine. See enumeration annotations for further details.	
Basis	ActivityBasisEnum	Optional
Description	Indicates the basis of the Activity. See enumerated type annotations for further details. If omitted, a basis of ACTUAL should be assumed.	
ActivityRank	ComparableRankingType	Optional
Description	Indicates the rank of the Activity amongst all other Activities of the Capability and/or Subsystem. This isn't necessarily the same as the Rank associated with the sibling ActivitySource. This element is meant to convey the Subsystem determined relative ranking of all Activities of a Capability category (ESM, EA, etc.). For Subsystems with multiple Capability categories this element is meant to convey relative ranking across all Capability categories. In addition to the rank of the ActivitySource, an Activity's rank can be influenced by Capability priority (see CapabilitySettings), RF_ControlCommands and other factors that influence the Subsystem's internal scheduling and resource allocation.	
ActivityReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling ActivityState element. This element is only expected when the Activity is in a potentially undesirable state such as constrained, failed or completed with less than optimum results.	
Source	ActivitySourceType	Repeated
Description	Indicates an originating "source" of the Activity; the command or other item which invoked this specific Activity of a Capability. A single Activity can fully or partially satisfy Activity sources.	
EstimatedStartTime	DateTimeType	Optional
Description	Indicates the estimated time when the Activity started or is expected to start.	
EstimatedCompletionTime	DateTimeType	Optional
Description	Indicates the estimated time when the Activity will complete.	
EstimatedPercentComplete	PercentType	Optional
Description	Indicates the current estimated percent complete of the Activity.	

Table A-4-34: C2 Interface MA_FlightActivityMT - Activity UCI Extension Field

Speed	
Description	Defines speed type (reference frame) for all speed related fields in this

	message.	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-35: C2 Interface MA_FlightActivityMT - Speed UCI Extension Field

Heading		
Description	Intended heading of the aircraft.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-36: C2 Interface MA_FlightActivityMT - Heading UCI Extension Field

4.1.5 MA_OpVolumeMT UCI Extension

MA_OpVolumeMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_OpVolumeMDT

Table A-4-37: C2 Interface MA_OpVolumeMT UCI Extension

MessageData		
Description	This element represents the details regarding the operational volume.	
Base Type	MA_OpVolumeMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpVolumeID	OpVolumeID_Type	Required
Description	This element represents the unique identifier of the OpVolume associated with this message.	

Category	MA_OpZoneCategoryEnum	Required
Description	This element indicates the type of volume.	
CategoryUniqueData	MA_OpZoneCategoryType	Optional
Description	Contains parameters unique to certain OpZoneCategoryEnum values.	
Volume	MA_OpVolumeChoiceType	Required
Description	This element represents the characteristics of the operational volume.	
SituationalAwareness	boolean	Required
Description	Volume used only for situational awareness. Not used for planning purposes.	
OpDescription	OpDescriptionType	Optional
Description	A human-readable descriptive name with free text remarks.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this operational item to specify what the source or motivation for it originated from. This could be ATO, ACO, etc.	
Source	CreationSourceEnum	Optional
Description	Indicates the source of the information.	
Schedule	ScheduleType	Optional
Description	This element represents a date/time interval associated with the operational item during which the item is in effect.	
AssociatedTime	TimeFunctionType	Repeated
Description	Indicates time related events that are associated to the Op data type such as when activated or when operational. The multiplicity is limited to N-1 options where NONE is an event that has no value, thus removed from list of available options.	
DataLinkIdentifier	DataLinkIdentifierPET	Repeated
Description	List of data link ID. Multiple data link IDs can be reported for the same network type.	
Priority	unsignedInt	Optional
Description	This field represents the priority to be considered when choosing between multiple available points.	
QualifyingTags	QualifyingTagsType	Optional
Description	Provides identity qualifications to augment identification and associated processing of the OpPoint.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
SystemScheduleOverride	SystemScheduleStateType	Repeated
Description	System-specific schedule that will override any part of the main schedule. This allows for system-specific schedule different than main schedule. When adding a SystemScheduleOverride, the child SystemID also must be added to the sibling SystemID list if the sibling list is not empty. The SystemScheduleOverride is independent of time planning. For the system, this override can be done at execution.	

Table A-4-38: C2 Interface MA_OpVolumeMT - MessageData UCI Extension Field

4.1.6MA_TaskMT UCI Extension

MA_TaskMT	
Description	This message specifies a Task that a System will perform against a specific entity or geographical location. Tasks include flight, collection, strike, electronic attack, directed energy, laser designation, cargo delivery and communication relay. They are abstracted to a level of C2 and autonomy derived from UCI operational vignettes. Tasks enable services, operators and other actors to do automated, dynamic, machine-to-machine allocation of Tasks to Systems and subsequent mission planning. If necessary, authorization of Users to Task Systems can be controlled using the Authorization message. See the XSD File for more info
Ext. Fields	TaskType : MA_TaskType TaskPlurality : MA_TaskPluralityEnum ConstraintID : MA_ConstraintID_Type HSA_CSA : MA_HSA_CSA_Type WaypointFollowing : MA_WaypointFollowingType CurveFollowing : MA_CurveControlType Speed : PathSegmentSpeedType Heading : MA_DirectionReferenceType SpeedChoice : MA_HSA_SpeedChoiceType SpeedValue : PathSegmentSpeedValueType CurveFitMethod : MA_CurveFitMethodEnum

Table A-4-39: C2 Interface MA_TaskMT UCI Extension

TaskType		
Description	Identifies the type of this Task instance.	
Base Type	MA_TaskType	
Message Structure		
Field Name	Field Type	Field Usage
AirSample	AirSampleTaskType	Required
Description	Air sample includes direct sampling of the air (SAMPLE) and remote sensing with spectral analysis (SPECTROMETER) with the intent of detecting NBC events.	
AMTI	AMTI_TaskType	Required
Description	Indicates a Task to collect Air Moving Target Indicator (AMTI) data.	
AO	AO_TaskType	Required
Description	Indicates a Task to perform an optical emission such as laser designation.	
CAP	MA_CAP_TaskType	Required
Description	Indicates a Task to perform Combat Air Patrol.	
CargoDelivery	CargoDeliveryTaskType	Required

	Description	Indicates a Task to transfer cargo between locations.
COMINT		COMINT_TaskType Required
	Description	Indicates a Task to provide COMINT.
CommRelay		CommRelayTaskType Required
	Description	Indicates a Task to provide communications relay support.
CounterSpace		CounterSpaceTaskType Required
	Description	Indicates a Task to employ a CounterSpace capability.
Escort		MA_EscortTaskType Required
	Description	Indicates a Task to escort another Entity or System.
EA		EA_TaskType Required
	Description	Indicates a Task to provide electronic attack support to another System. It guides/constrains the EA System by specifying where it should fly, what it should protect and what the threat is.
ESM		ESM_TaskType Required
	Description	Indicates a Task to collect ESM data.
Flight		MA_FlightTaskType Required
	Description	Indicates a Task to effect the flight path/plan of the System.
Jettison		MA_JettisonTaskType Required
	Description	Indicates a Task to a jettisonable weapon from the system.
OrbitChange		OrbitChangeTaskType Required
	Description	Indicates a task to perform an orbit change via a spacecraft maneuver.
OrbitalSurveillance		OrbitalSurveillanceTaskType Required
	Description	Indicates an Orbital Surveillance Task.
OrbitalSurveillanceSensor		OrbitalSurveillanceSensorTaskType Required
	Description	Indicates a task to perform orbital surveillance sensor tasking.
PO		PO_TaskType Required
	Description	Indicates a Task to collect Passive Optical data, imagery and video as well as perform PO search and track capabilities.
Refuel		RefuelTaskType Required
	Description	Indicates a Task for one System to refuel another.
SAR		SAR_TaskType Required
	Description	Indicates a Task to collect a Synthetic Aperture Radar (SAR) image.
SMTI		SMTI_TaskType Required
	Description	Indicates a Task to collect Moving Target Indicator (MTI) data.
Strike		StrikeTaskType Required
	Description	Indicates a Task to kinetically attack/strike, with a weapon that can be released from the System.
SystemDeployment		SystemDeploymentTaskType Required

Description	Indicates a task to perform a deployment or release of a system at a specified location.	
TacticalOrder	TacticalOrderTaskType	Required
Description	Indicates a task to perform a tactical order.	
WeatherRadar	WeatherRadarTaskType	Required
Description	Indicates a task to collect weather radar data.	

Table A-4-40: C2 Interface MA_TaskMT - TaskType UCI Extension Field

TaskPlurality	
Description	Indicates whether the task is meant to be executed by a single entity or as a joint operation. A join operation implies forming a group prior to execution. A single entity could be a single system or a single pre-formed group.
Base Type	MA_TaskPluralityEnum
Message Structure	
Enumeration Literal	Description
UNSPECIFIED	Indicates the task plurality is unspecified, and should be defaulted or determined by the receiving system.
JOINT	Indicates the task is to be executed as a joint task. A group will be formed when this task is assigned.
SINGLE_ENTITY	Indicates the task is to be executed by a single entity. A single entity could be a single system or a single pre-existing group.

Table A-4-41: C2 Interface MA_TaskMT - TaskPlurality UCI Extension Field

ConstraintID		
Description	Indicates any Constraints that apply to the Task (e.g FormationConstraint). A FormationConstraint implies that if a group is formed to execute this task, the referenced Constraint(s) should be applied to that group.	
Base Type	MA_ConstraintID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-42: C2 Interface MA_TaskMT - ConstraintID UCI Extension Field

HSA_CSA	
Description	This message shall be used to provide the ability to command a new flight vector to the Platform.
Base Type	MA_HSA_CSA_Type
Message Structure	

Field Name	Field Type	Field Usage
Altitude	AltitudeReferenceType	Optional
Description	Altitude hold value to be achieved and reference to altitude measurement source.	
Speed	PathSegmentSpeedType	Optional
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Direction	MA_DirectionChoiceType	Optional
Description	Defines heading or course type and reference to hold	

Table A-4-43: C2 Interface MA_TaskMT - HSA_CSA UCI Extension Field

WaypointFollowing		
Description	This message shall be used to provide the ability to send a new waypoint path or segment for the Platform to follow.	
Base Type	MA_WaypointFollowingType	
Message Structure		
Field Name	Field Type	Field Usage
Route	MA_RouteType	Required
Description	Indicates the Paths and Segments that make up the Route to be flown.	

Table A-4-44: C2 Interface MA_TaskMT - WaypointFollowing UCI Extension Field

CurveFollowing		
Description	Indicates the parameters for curve following control.	
Base Type	MA_CurveControlType	
Message Structure		
Field Name	Field Type	Field Usage
CurveSegments	MA_NURBS_PointType	Repeated
Description	Specifies the curve segments as a set of NURBS points.	
AppendCurve	EmptyType	Optional
Description	Specifies this curve will be appended to a previous curve command. This is only valid if the vehicle is currently executing a curve.	
EndOfCurveBehavior	MA_EndOfCurveBehaviorEnum	Optional
Description	Specifies the vehicle behavior at the completion of the curve.	

Table A-4-45: C2 Interface MA_TaskMT - CurveFollowing UCI Extension Field

Speed		
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Base Type	PathSegmentSpeedType	
Message Structure		
Field Name	Field Type	Field Usage

SpeedChoice	PathSegmentSpeedChoiceType	Optional
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
SpeedOptimization	SpeedOptimizationEnum	Optional
Description	Indicates that the System will vary its speed autonomously according to the specified optimization algorithm.	

Table A-4-46: C2 Interface MA_TaskMT - Speed UCI Extension Field

Heading		
Description	Defines heading type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-47: C2 Interface MA_TaskMT - Heading UCI Extension Field

SpeedChoice		
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
Base Type	MA_HSA_SpeedChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedValue	PathSegmentSpeedValueType	Required
Description	Indicates speed in meters per second (m/s).	
MachValue	MachType	Required
Description	Indicates the speed reference for the associated speed value.	

Table A-4-48: C2 Interface MA_TaskMT - SpeedChoice UCI Extension Field

SpeedValue		
Description	Indicates speed in meters per second (m/s).	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	

Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-49: C2 Interface MA_TaskMT - SpeedValue UCI Extension Field

CurveFitMethod	
Description	Method through which a curve should be fitted to the discretized points in ControlPoint.
Base Type	MA_CurveFitMethodEnum
Message Structure	
Enumeration Literal	Description
B_SPLINE	B-Spline (basis spline) fit.
BEZIER	Bezier curve fit.
CATMULL_ROM	Catmull-Rom spline fit.
NATURAL_CUBIC	Natural Cubic curve fit.

Table A-4-50: C2 Interface MA_TaskMT - CurveFitMethod UCI Extension Field

4.1.7 MA_MissionPlanActivationCommandStatusMT UCI Extension

MA_MissionPlanActivationCommandStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	Plans : MA_PlansReferenceType MessageData : MA_MissionPlanActivationCommandStatusMDT ActivationCommandByState : MA_PlanActivationStatusType

Table A-4-51: C2 Interface MA_MissionPlanActivationCommandStatusMT UCI Extension

Plans		
Description	Indicates the Plan or Plans in the sibling CommandState.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	

OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-52: C2 Interface MA_MissionPlanActivationCommandStatusMT - Plans UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanActivationCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	MissionPlanActivationCommandID_Type	Required
Description	The ID of the MissionPlanActivationCommand this status pertains to.	
ActivationStatus	PlanCommandStatusType	Required
Description	Indicates the status of the MissionPlanActivationCommand.	
ActivationCommandByState	MA_PlanActivationStatusType	Repeated
Description	Indicates plans in a given commanded activation state. List size allows for each available PlanActivationCommandState to be represented.	

Table A-4-53: C2 Interface MA_MissionPlanActivationCommandStatusMT - MessageData UCI Extension Field

ActivationCommandByState		
Description	Indicates plans in a given commanded activation state. List size allows for each available PlanActivationCommandState to be represented.	
Base Type	MA_PlanActivationStatusType	
Message Structure		
Field Name	Field Type	Field Usage

PlanActivationCommandState	PlanActivationStateEnum	Required
Description	Indicates an activation command state that one or more *Plans is in.	
Plans	MA_PlansReferenceType	Required
Description	Indicates the Plan or Plans in the sibling CommandState.	

Table A-4-54: C2 Interface MA_MissionPlanActivationCommandStatusMT - ActivationCommandByState UCI Extension Field

4.1.8 MA_MissionPlanMT UCI Extension

MA_MissionPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_MissionPlanMDT

Table A-4-55: C2 Interface MA_MissionPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	Indicates a unique ID assigned to the MissionPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
MissionPlanCommandID	MissionPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which this MissionPlan originated from.	
Applicability	MA_PlanApplicabilityType	Required
Description	Indicates the System or Systems which have a direct relationship with the Mission Plan. See annotations for the underlying type and its child elements for details.	
Window	DateTimeRangeType	Optional
Description	The time window for which the Plan is applicable.	
SubPlans	MA_PlansReferenceBaseType	Optional
Description	Indicates the set of *Plans which are included as part of the MissionPlan. The included SubPlans share the same Applicability as the MissionPlan.	
ExecutionSequence	ExecutionSequenceType	Optional
Description	Indicates the MissionPlan's flow of execution when there are multiple kinematic and action plans. The kinematic and action plans are combined into sets and given unique IDs. An execution flow may be created by linking *ExecutionPlanSets of different types (e.g. OrbitExecutionPlanSet and RouteExecutionPlanSet).	
ParentMissionPlanID	MissionPlanID_Type	Repeated

Description	Indicates a MissionPlan that is the parent of this MissionPlan.	
SubordinateMissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a MissionPlan that is subordinate to this MissionPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	MA_MissionPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	
Remarks	RemarksType	Optional
Description	Indicates information about the mission plan from an operator intended for display. Both short and longer detailed information can be provided.	

Table A-4-56: C2 Interface MA_MissionPlanMT - MessageData UCI Extension Field

4.1.9 MA_PositionReportMT UCI Extension

MA_PositionReportMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_PositionReportMDT

Table A-4-57: C2 Interface MA_PositionReportMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PositionReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	The unique ID of the System corresponding to this PositionReport.	
DisplayName	VisibleString256Type	Optional
Description	This is the free-text, generally human-readable, name of the System or Resource corresponding to this PositionReport. This name isn't necessarily unique.	
Source	SystemSourceEnum	Required
Description	Indicates the source of the data in sibling elements. See enumeration annotations for further details.	
CurrentOperatingDomain	EnvironmentEnum	Required

Description	This enumerated element represents the domain/environment in which the system is currently operating.	
InertialState	MA_InertialStateType	Required
Description	This element represents the inertial state of the system or resource.	
WanderAngle	AngleType	Optional
Description	The angle by which the Inertial Navigation System (INS) rotates the geodetic frame about the vertical axis of the North-East-Down (NED) coordinate frame to avoid the introduction of a singularity at the North pole when it is calculating vehicle location. A rotation from true North towards East is reported as a positive angle.	
MagneticHeading	AngleType	Optional
Description	Indicates the heading in relationship to magnetic North.	

Table A-4-58: C2 Interface MA_PositionReportMT - MessageData UCI Extension Field

4.1.10 MA_TaskPlanMT UCI Extension

MA_TaskPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_TaskPlanMDT

Table A-4-59: C2 Interface MA_TaskPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_TaskPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlanID	TaskPlanID_Type	Required
Description	Indicates a unique ID assigned to the TaskPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	TaskPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the TaskPlan originated from.	
Plan	MA_TaskPlanType	Required
Description	Contains the details of the task allocation plan.	
ForPlanningUseOnly	Boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	

PlanInputs	MA_TaskPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-60: C2 Interface MA_TaskPlanMT - MessageData UCI Extension Field

4.1.11 MA_PackagePartnerStatusReportMT UCI Extension

MA_PackagePartnerStatusReportMT		
Description	This message reports the resulting status of a package change for a PackageManagementCommand for individual entities in a package. See the XSD File for more info	
Ext. Fields	MessageData : MA_PackagePartnerStatusReportMDT	

Table A-4-61: C2 Interface MA_PackagePartnerStatusReportMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PackagePartnerStatusReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command that formed the Package specified in the sibling PackageID element.	
PackageID	PackageID_Type	Required
Description	Indicates the unique ID of the package that this message is reporting a change status for.	
PackageLeaderID	SystemID_Type	Optional
Description	Indicates the unique ID of the system that represents the Package lead.	
PackageStatus	RequestProcessingStateEnum	Required
Description	The status of the Package as a whole.	
ConstraintID	MA_ConstraintID_Type	Repeated
Description	Indicates any constraints that were applied to the original PackageManagementCommand, indicated in the sibling CommandID element.	
SystemStatus	MA_PackagePartnerStatusType	Repeated
Description	The status for an individual system within the package.	
StaticLeadershipFitnessScore	FloatMinMaxType	Optional
Description	Indicates the static leadership fitness score for the partners in the package.	
DynamicLeadershipFitnessScore	MA_PartnerLeadershipFitnessScoreType	Optional
Description	Indicates the dynamic leadership fitness score and determination type for a partner in the package.	

Table A-4-62: C2 Interface MA_PackagePartnerStatusReportMT - MessageData UCI Extension Field

4.1.12 MA_ApprovalRequestMT UCI Extension

MA_ApprovalRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ActivationDetails : MA_MissionPlanActivationDetailsType OpPlanID : MA_OpPlanID_Type MissionPlanActivationApproval : MA_MissionPlanActivationCommandType ApprovalReferences : ApprovalRequestPolicyReferenceType ApprovalItem : ApprovalRequestItemReferenceType ByExecutionPlanSet : MA_ExecutionPlanSetActivationType MessageData : ApprovalRequestMDT BySubPlan : MA_MissionPlanSubplanActivationType OpPlan : MA_OpPlanActivationType

Table A-4-63: C2 Interface MA_ApprovalRequestMT UCI Extension

ActivationDetails		
Description	Indicates the commanded activation details.	
Base Type	MA_MissionPlanActivationDetailsType	
Message Structure		
Field Name	Field Type	Field Usage
ByMissionPlan	MissionPlanActivationType	Required
Description	Indicates simultaneous activation of all sub-*Plans (RoutePlan, RouteActivityPlan for example) of a MissionPlan into the same activation state.	
BySubPlan	MA_MissionPlanSubplanActivationType	Required
Description	Indicates activation by sub-*Plan (RoutePlan or OrbitPlan for example) of the MissionPlan, with potentially different states for each.	
ByExecutionPlanSet	MA_ExecutionPlanSetActivationType	Required
Description	Indicates simultaneous activation of all sub-*Plans (ActivityPlan, RoutePlan for example) of an *ExecutionPlanSet into the same activation state.	

Table A-4-64: C2 Interface MA_ApprovalRequestMT - ActivationDetails UCI Extension Field

OpPlanID	
Description	Indicates the unique ID of the TaskPlan to perform the sibling activation command on.
Base Type	MA_OpPlanID_Type
Message Structure	

Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-65: C2 Interface MA_ApprovalRequestMT - OpPlanID UCI Extension Field

MissionPlanActivationApproval		
Description	Indicates the MissionPlanActivationCommand details that are under review for approval. If more than one instance of this element is given, each should correspond to a different MissionPlanID. For example, if the intent is to transition from one MissionPlan to another, the new MissionPlan can be activated in one instance and the old MissionPlan can be deactivated in another instance. This transition would be subject to approval.	
Base Type	MA_MissionPlanActivationCommandType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	Indicates the unique ID of the MissionPlan whose commanded activation state or states are summarized in the sibling element.	
ActivationDetails	MA_MissionPlanActivationDetailsType	Required
Description	Indicates the commanded activation details.	

Table A-4-66: C2 Interface MA_ApprovalRequestMT - MissionPlanActivationApproval UCI Extension Field

ApprovalReferences		
Description	Indicates the policy that resulted in the ApprovalRequest along with references to the data under review.	
Base Type	ApprovalRequestPolicyReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
ApprovalPolicyID	ApprovalPolicyID_Type	Required
Description	Indicates the unique ID of the ApprovalPolicy that resulted in this ApprovalRequest.	
ApprovalItem	ApprovalRequestItemReferenceType	Required
Description	Indicates the ID of the specific item that is being requested for approval.	

Table A-4-67: C2 Interface MA_ApprovalRequestMT - ApprovalReferences UCI Extension Field

ApprovalItem		
Description	Indicates the ID of the specific item that is being requested for approval.	
Base Type	ApprovalRequestItemReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
PlanApproval	PlanReferenceID_ChoiceType	Required
Description	Indicates the unique ID of the *Plan that is under review for approval.	
RequirementExecutionApproval	ApprovalRequestItemType	Required
Description	Indicates the Requirement, including any associated DMPIs, that is under review for approval to execute.	
MissionPlanActivationApproval	MissionPlanActivationCommandType	Repeated
Description	Indicates the MissionPlanActivationCommand details that are under review for approval. If more than one instance of this element is given, each should correspond to a different MissionPlanID. For example, if the intent is to transition from one MissionPlan to another, the new MissionPlan can be activated in one instance and the old MissionPlan can be deactivated in another instance. This transition would be subject to approval.	

Table A-4-68: C2 Interface MA_ApprovalRequestMT - ApprovalItem UCI Extension Field

ByExecutionPlanSet		
Description	Indicates simultaneous activation of all sub-*Plans (ActivityPlan, RoutePlan for example) of an *ExecutionPlanSet into the same activation state.	
Base Type	MA_ExecutionPlanSetActivationType	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPlanSetID	ExecutionPlanSetID_Type	Required
Description	Indicates the unique ID of the execution plan set.	
CommandType	PlanActivationCommandEnum	Required
Description	Indicates the activation to perform on the associated execution plan set.	

Table A-4-69: C2 Interface MA_ApprovalRequestMT - ByExecutionPlanSet UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	ApprovalRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
Approver	OperatorRoleType	Required
Description	An Operator Role or non-Operator identifier that is allowed to approve the included approval policy and approval item.	

ApprovalReferences	ApprovalRequestPolicyReferenceType	Required
Description	Indicates the policy that resulted in the ApprovalRequest along with references to the data under review.	
RespondBy	DateTimeType	Required
Description	If a response is not received from this approval authority by the given time, the approval policy's default response will be used. This field should be driven based on the timeout specified within the approval policy for approvals of this type.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-70: C2 Interface MA_ApprovalRequestMT - MessageData UCI Extension Field

BySubPlan		
Description	Indicates activation by sub-*Plan (RoutePlan or OrbitPlan for example) of the MissionPlan, with potentially different states for each.	
Base Type	MA_MissionPlanSubplanActivationType	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlan	TaskPlanActivationType	Repeated
Description	Indicates commanded details for activation of a TaskPlan.	
RoutePlan	MA_RoutePlanActivationType	Repeated
Description	Indicates commanded details for activation of a RoutePlan.	
RouteActivityPlan	RouteActivityPlanActivationType	Repeated
Description	Indicates commanded details for activation of a RouteActivityPlan.	
OrbitPlan	OrbitPlanActivationType	Repeated
Description	Indicates commanded details for activation of an OrbitPlan.	
OrbitActivityPlan	OrbitActivityPlanActivationType	Repeated
Description	Indicates commanded details for activation of an OrbitActivityPlan.	
ActivityPlan	ActivityPlanActivationType	Repeated
Description	Indicates commanded details for activation of an ActivityPlan.	
EffectPlan	EffectPlanActivationType	Repeated
Description	Indicates commanded details for activation of an EffectPlan.	
ActionPlan	ActionPlanActivationType	Repeated
Description	Indicates commanded details for activation of an ActionPlan.	
ResponsePlan	ResponsePlanActivationType	Repeated
Description	Indicates commanded details for activation of a ResponsePlan.	

OpPlan	MA_OpPlanActivationType	Repeated
Description	Indicates commanded details for activation of an OpPlan.	

Table A-4-71: C2 Interface MA_ApprovalRequestMT - BySubPlan UCI Extension Field

OpPlan		
Description	Indicates commanded details for activation of an OpPlan.	
Base Type	MA_OpPlanActivationType	
Message Structure		
Field Name	Field Type	Field Usage
OpPlanID	MA_OpPlanID_Type	Required
Description	Indicates the unique ID of the TaskPlan to perform the sibling activation command on.	
CommandType	PlanActivationCommandEnum	Required
Description	Indicates the activation to perform on the associated TaskPlan.	

Table A-4-72: C2 Interface MA_ApprovalRequestMT - OpPlan UCI Extension Field

4.1.13 MA_ResponseActivityMT UCI Extension

MA_ResponseActivityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	RequirementInstantiation : MA_RequirementTemplateInstantiationType ActivatedPlans : MA_PlansReferenceType Activity : MA_ResponseActivityType MessageData : MA_ResponseActivityMDT ResultingPlans : MA_PlansReferenceType OpPlanID : MA_OpPlanID_Type

Table A-4-73: C2 Interface MA_ResponseActivityMT UCI Extension

RequirementInstantiation		
Description	Indicates an independent set of Requirement or Requirements and *Plans that were instantiated for the Response. Subsequent progress in planning and/or execution is given in [Requirement]Plan, [Requirement]Status, MissionPlan*, etc. messages.	
Base Type	MA_RequirementTemplateInstantiationType	
Message Structure		
Field Name	Field Type	Field Usage
RequirementID	RequirementInstanceID_ChoiceType	Repeated
Description	Indicates the unique ID of a Requirement that was instantiated as a result of the Response. Subsequent progress in planning and/or execution of the Requirement should be given in [Requirement]Plan, [Requirement]Status, etc. messages.	

ResultingPlans	MA_PlansReferenceType	Optional
Description	Indicates *Plans that were updated or created to include the sibling Requirements.	

Table A-4-74: C2 Interface MA_ResponseActivityMT - RequirementInstantiation UCI Extension Field

ActivatedPlans		
Description	Indicates *Plans that were activated for the Response.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-75: C2 Interface MA_ResponseActivityMT - ActivatedPlans UCI Extension Field

Activity	
Description	Indicates the dynamic operational characteristics of an Activity of an Response Capability.
Base Type	MA_ResponseActivityType
Message Structure	

Field Name	Field Type	Field Usage
InstantiationTime	DateTimeType	Required
Description	Indicates the time at which the Response was instantiated.	
OptionIndex	unsignedInt	Optional
Description	Indicates the specific Option within the Response that was instantiated.	
RequirementInstantiation	MA_RequirementTemplateInstantiationType	Repeated
Description	Indicates an independent set of Requirement or Requirements and *Plans that were instantiated for the Response. Subsequent progress in planning and/or execution is given in [Requirement]Plan, [Requirement]Status, MissionPlan*, etc. messages.	
ActivatedPlans	MA_PlansReferenceType	Optional
Description	Indicates *Plans that were activated for the Response.	
AlertID	MissionContingencyAlertID_Type	Optional
Description	Indicates a MissionContingencyAlert that was generated for the Response.	
ActivityID	ActivityID_Type	Required
Description	Indicates the unique ID of the Activity.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates a Capability which the Activity is an instance of. Generally an Activity is an instance of a single Capability. An Activity can be associated with multiple Capabilities when, for example, a Subsystem has distinct Capabilities for automated and manual. In this case, if a manual command is issued while an automated Activity that achieves the desired result already exists, a single Activity represents both Capabilities.	
Interactive	boolean	Required
Description	Indicates whether or not the Activity can be edited/modified via a [Capability]Command...Activity message.	
ActivityState	ActivityStateEnum	Required
Description	Indicates the current state of the Activity its state machine. See enumeration annotations for further details.	
Basis	ActivityBasisEnum	Optional
Description	Indicates the basis of the Activity. See enumerated type annotations for further details. If omitted, a basis of ACTUAL should be assumed.	
ActivityRank	ComparableRankingType	Optional
Description	Indicates the rank of the Activity amongst all other Activities of the Capability and/or Subsystem. This isn't necessarily the same as the Rank associated with the sibling ActivitySource. This element is meant to convey the Subsystem determined relative ranking of all Activities of a Capability category (ESM, EA, etc.). For Subsystems with multiple Capability categories this element is meant to convey relative ranking across all Capability categories. In addition to the rank of the ActivitySource, an Activity's rank can be influenced by Capability priority (see CapabilitySettings), RF_ControlCommands and other factors that influence the Subsystem's internal scheduling and resource allocation.	
ActivityReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling ActivityState element. This element is only expected when the Activity is in a	

	potentially undesirable state such as constrained, failed or completed with less than optimum results.	
Source	ActivitySourceType	Repeated
Description	Indicates an originating "source" of the Activity; the command or other item which invoked this specific Activity of a Capability. A single Activity can fully or partially satisfy Activity sources.	
EstimatedStartTime	DateTimeType	Optional
Description	Indicates the estimated time when the Activity started or is expected to start.	
EstimatedCompletionTime	DateTimeType	Optional
Description	Indicates the estimated time when the Activity will complete.	
EstimatedPercentComplete	PercentType	Optional
Description	Indicates the current estimated percent complete of the Activity.	

Table A-4-76: C2 Interface MA_ResponseActivityMT - Activity UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ResponseActivityMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Indicates the System which hosts the Response Capabilities whose Activities are given in this message.	
Activity	MA_ResponseActivityType	Repeated
Description	Indicates the dynamic operational characteristics of an Activity of an Response Capability.	

Table A-4-77: C2 Interface MA_ResponseActivityMT - MessageData UCI Extension Field

ResultingPlans		
Description	Indicates *Plans that were updated or created to include the sibling Requirements.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	

OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-78: C2 Interface MA_ResponseActivityMT - ResultingPlans UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-79: C2 Interface MA_ResponseActivityMT - OpPlanID UCI Extension Field

4.1.14 MA_PackageManagementCommandMT UCI Extension

MA_PackageManagementCommandMT	
Description	This message is used to command one or more entities to form, join or leave a Package.

	See the XSD File for more info
Ext. Fields	MessageData : MA_PackageManagementCommandMDT

Table A-4-80: C2 Interface MA_PackageManagementCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PackageManagementCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
PackageID	PackageID_Type	Required
Description	Indicates the unique identifier of the Package to form, join or leave.	
ParentPackageID	PackageID_Type	Optional
Description	If the sibling PackageID element is a sub-package, indicates the unique identifier of the parent package.	
ChangeType	MA_PackageChangeEnum	Required
Description	Indicates the type of package change to perform.	
SystemID	SystemID_Type	Repeated
Description	Indicates the System(s) commanded to perform a package change.	
ConstraintID	MA_ConstraintID_Type	Repeated
Description	Indicates any Constraints that may apply to this package (e.g FormationConstraint).	
PackageLeaderID	SystemID_Type	Optional
Description	Indicates the System commanded to assume package leader role. Allows for the explicit specification of a leader without needing MA to conduct leader election.	
PackagePartnerMetrics	MA_PartnerMetricsType	Repeated
Description	Indicates the leadership fitness metrics for the partners in the package.	
PackageLeaderElectionMethod	Integer	Required
Description	Specifies which election method/algorithm the package will utilize for electing a Package Leader. Implementors are expected to set a default election method. If blank, the default election method will be used.	

	Integer values and corresponding election methods are as follows: 0 - Bully Election Method. Supports Dynamic Fitness Scores and cases where Leadership Fitness Scores need to be shared as part of an election process. 1- Static Fitness Score Election Method. Supports nomination of a leader assuming leadership fitness scores remain static once they have been defined by MP/C2. 2 - Maximum Consensus Election Method. Supports utilizing consensus algorithms to reach team consensus on the leader while preserving communication bandwidth. 3 - Raft Leader Election Method. Supports leader election using the Raft consensus algorithm, which ensures a distributed and fault-tolerant approach to electing a leader.	
PackageLeadershipFitnessScoreDetermination Method	MA_LeadershipFitnessScoreDeterminationMethodChoiceType	Optional
Description	This field specifies the chosen fitness score determination method to be used for fitness scoring for the package.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-81: C2 Interface MA_PackageManagementCommandMT - MessageData UCI Extension Field

4.1.15 MA_PackageManagementCommandStatusMT UCI Extension

MA_PackageManagementCommandStatusMT	
Description	This message is sent in response to a PackageManagementCommand and indicates if the command was accepted and if not why it was rejected. The resulting status of the Package Change is reported in PackagePartnerStatusReport for each system in the original command. See the XSD File for more info
Ext. Fields	MessageData : MA_PackageManagementCommandStatusMDT

Table A-4-82: C2 Interface MA_PackageManagementCommandStatusMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this

	type for details.	
Base Type	MA_PackageManagementCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-83: C2 Interface MA_PackageManagementCommandStatusMT - MessageData UCI Extension Field

4.1.16 MA_ApprovalRequestStatusMT UCI Extension

MA_ApprovalRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_ApprovalRequestStatusMDT

Table A-4-84: C2 Interface MA_ApprovalRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ApprovalRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApprovalRequestProcessingState	ApprovalStatusEnum	Required
Description	The ApprovalState indicates the current state of the approval for an approval request.	
ApprovalRequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling ApprovalRequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results	

	expected.	
OperatorID	OperatorID_Type	Optional
Description	Indicates the Operator that provided the approval/rejection, if available. This element can be beneficial when systems require two-person integrity.	
ApprovedDMPI_ID	DMPI_ID_Type	Repeated
Description	If the ApprovalRequest was for DMPI approval then this element contains the list of approved DMPIs. If any DMPIs are approved, the sibling ApprovalState will indicate that the request is approved.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-85: C2 Interface MA_ApprovalRequestStatusMT - MessageData UCI Extension Field

4.1.17 MA_TaskCommandStatusMT UCI Extension

MA_TaskCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_TaskCommandStatusMDT

Table A-4-86: C2 Interface MA_TaskCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_TaskCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	

CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-87: C2 Interface MA_TaskCommandStatusMT - MessageData UCI Extension Field

4.1.18 MA_MissionPlanExecutionStatusMT UCI Extension

MA_MissionPlanExecutionStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	ExecutionPlanSetStatus : MA_ExecutionPlanSetExecutionStateType PlanExecutionStatus : MA_MissionPlanExecutionStateType MessageData : MA_MissionPlanExecutionStatusMDT

Table A-4-88: C2 Interface MA_MissionPlanExecutionStatusMT UCI Extension

ExecutionPlanSetStatus		
Description	Indicates the execution state of an execution plan set of the MissionPlan indicated by the sibling MissionPlanID element.	
Base Type	MA_ExecutionPlanSetExecutionStateType	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPlanSetID	ExecutionPlanSetID_Type	Required
Description	Indicates the unique ID of the execution plan set.	
ExecutionPlanSetExecutionState	PlanExecutionStateEnum	Required
Description	The current state of the execution plan set.	

Table A-4-89: C2 Interface MA_MissionPlanExecutionStatusMT - ExecutionPlanSetStatus UCI Extension Field

PlanExecutionStatus		
Description	Indicates the execution state of a MissionPlan of the System indicated by the sibling SystemID element.	
Base Type	MA_MissionPlanExecutionStateType	
Message Structure		
Field Name	Field Type	Field Usage

MissionPlanID	MissionPlanID_Type	Required
Description	The ID of the MissionPlan this status pertains to.	
PlanExecutionState	PlanExecutionStateEnum	Required
Description	The current state of the plan.	
ExecutionPlanSetStatus	MA_ExecutionPlanSetExecutionStateType	Repeated
Description	Indicates the execution state of an execution plan set of the MissionPlan indicated by the sibling MissionPlanID element.	

Table A-4-90: C2 Interface MA_MissionPlanExecutionStatusMT - PlanExecutionStatus UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanExecutionStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	The unique ID of the System whose Plan is being statused.	
Source	SystemSourceEnum	Required
Description	Indicates the source of the data in sibling elements. See enumeration annotations for further details.	
PlanExecutionStatus	MA_MissionPlanExecutionStateType	Repeated
Description	Indicates the execution state of a MissionPlan of the System indicated by the sibling SystemID element.	

Table A-4-91: C2 Interface MA_MissionPlanExecutionStatusMT - MessageData UCI Extension Field

4.1.19 MA_StrikeCapabilityMT UCI Extension

MA_StrikeCapabilityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_StrikeCapabilityMDT

Table A-4-92: C2 Interface MA_StrikeCapabilityMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_StrikeCapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_StrikeCapabilityType	Repeated

Description	Indicates a Strike Capability provided by the Subsystem.	
Carriage	StoreCarriageCapabilityType	Repeated
Description	Optional list of carriage related to the StrikeCapability.	
Verification	StoreVerificationStatusType	Optional
Description	This is a rollup of all verification of each capability in this message.	
LoadoutMnemonic	VisibleString256Type	Optional
Description	Mnemonic representation of the store loadout that the reported strike capabilities and carriage support capabilities are derived from.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.	

Table A-4-93: C2 Interface MA_StrikeCapabilityMT - MessageData UCI Extension Field

4.1.20 MA_LeadershipMetricsMT UCI Extension

MA_LeadershipMetricsMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_LeadershipMetricsMDT

Table A-4-94: C2 Interface MA_LeadershipMetricsMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_LeadershipMetricsMDT	
Message Structure		
Field Name	Field Type	Field Usage
PackagePartnerMetrics	MA_PartnerMetricsType	Repeated
Description	Indicates the leadership fitness metrics for the partners in the package.	
PackageLeaderElectionMethod	Integer	Required
Description	Specifies which election method/algorithm the package will utilize for electing a Package Leader. Implementors are expected to set a default election method. If blank, the default election method will be used. Integer values and corresponding election methods are as follows:	

	0 - Bully Election Method. Supports Dynamic Fitness Scores and cases where Leadership Fitness Scores need to be shared as part of an election process. 1- Static Fitness Score Election Method. Supports nomination of a leader assuming leadership fitness scores remain static once they have been defined by MP/C2. 2 - Maximum Consensus Election Method. Supports utilizing consensus algorithms to reach team consensus on the leader while preserving communication bandwidth. 3 - Raft Leader Election Method. Supports leader election using the Raft consensus algorithm, which ensures a distributed and fault-tolerant approach to electing a leader.
--	---

Table A-4-95: C2 Interface MA_LeadershipMetricsMT - MessageData UCI Extension Field

4.1.21 MA_WEZ_MT UCI Extension

MA_WEZ_MT	
Description	This message represents a single Weapon Engagement Zone (WEZ). The WEZ represents a less dynamic capability than the DLZ for air to air engagements and is not reliant on target state data to be produced. See the XSD File for more info
Ext. Fields	MessageData : MA_WEZ_MDT WEZ_ID : MA_WEZ_ID_Type WEZ_Data : MA_WEZ_DataType RangeTurnAndClose : MA_WeaponRangeType RangeMinimum : MA_WeaponRangeType RangeTurnAndRun : MA_WeaponRangeType RangeProbabilityOfIntercept : MA_WeaponRangeType RangeMaxGuidance : MA_WeaponRangeType RangeOptimal : MA_WeaponRangeType RangeMaxAero : MA_WeaponRangeType

Table A-4-96: C2 Interface MA_WEZ_MT UCI Extension

MessageData		
Description	This represents the characteristics that identify and describe a single Weapon Engagement Zone (WEZ).	
Base Type	MA_WEZ_MDT	
Message Structure		
Field Name	Field Type	Field Usage
WEZ_ID	MA_WEZ_ID_Type	Required
Description	This is an ID to uniquely identify the Weapon Engagement Zone (WEZ).	
WEZ_RequestID	RequestID_Type	Required

Description	Indicates the unique ID of the request message.	
CapabilityID	CapabilityID_Type	Optional
Description	Indicates the weapon Capability instance that this WEZ is associated with.	
GeneratedByWeapon	boolean	Optional
Description	This element indicates if the WEZ was generated using payload algorithms.	
WEZ_Data	MA_WEZ_DataType	Required
Description	Indicates WEZ range calculations for air-to-air engagement assessments.	

Table A-4-97: C2 Interface MA_WEZ_MT - MessageData UCI Extension Field

WEZ_ID		
Description	This is an ID to uniquely identify the Weapon Engagement Zone (WEZ).	
Base Type	MA_WEZ_ID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-98: C2 Interface MA_WEZ_MT - WEZ_ID UCI Extension Field

WEZ_Data		
Description	Indicates WEZ range calculations for air-to-air engagement assessments.	
Base Type	MA_WEZ_DataType	
Message Structure		
Field Name	Field Type	Field Usage
RangeTurnAndClose	MA_WeaponRangeType	Repeated
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-close maneuver RangeTurnAndClose is not applicable to ballistic trajectory targets.	
RangeMinimum	MA_WeaponRangeType	Repeated
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering	

	2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeTurnAndRun	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-run maneuver RangeTurnAndRun is not applicable to ballistic trajectory targets.	
RangeProbabilityOfIntercept	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeMaxGuidance	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeOptimal	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers,	

	Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeMaxAero	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
TimeToRelease	TimeType	Required
Description	The seconds time to activate for the proposed launch store type.	
TimeOfActivation	TimeType	Optional
Description	The time of weapon seeker activation, assuming no platform guidance or weapon errors, for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No post-launch target maneuvers	

Table A-4-99: C2 Interface MA_WEZ_MT - WEZ_Data UCI Extension Field

RangeTurnAndClose		
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-close maneuver RangeTurnAndClose is not applicable to ballistic trajectory targets.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-100: C2 Interface MA_WEZ_MT - RangeTurnAndClose UCI Extension Field

RangeMinimum		
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-101: C2 Interface MA_WEZ_MT - RangeMinimum UCI Extension Field

RangeTurnAndRun		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-run maneuver RangeTurnAndRun is not applicable to ballistic trajectory targets.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-102: C2 Interface MA_WEZ_MT - RangeTurnAndRun UCI Extension Field

RangeProbabilityOfIntercept	
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering

	2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-103: C2 Interface MA_WEZ_MT - RangeProbabilityOfIntercept UCI Extension Field

RangeMaxGuidance		
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-104: C2 Interface MA_WEZ_MT - RangeMaxGuidance UCI Extension Field

RangeOptimal		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers,	

	Note: ballistic trajectory velocity changes are not considered maneuvers.	
Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-105: C2 Interface MA_WEZ_MT - RangeOptimal UCI Extension Field

RangeMaxAero		
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-106: C2 Interface MA_WEZ_MT - RangeMaxAero UCI Extension Field

4.1.22 MA_TaskCommandMT UCI Extension

MA_TaskCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_TaskCommandMDT

Table A-4-107: C2 Interface MA_TaskCommandMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.

Base Type		MA_TaskCommandMDT
Message Structure		
Field Name	Field Type	Field Usage
Command	MA_TaskCommandType	Repeated
Description	Indicates an instance of a Task Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Capability CommandStatus message.	

Table A-4-108: C2 Interface MA_TaskCommandMT - MessageData UCI Extension Field

4.1.23 MA_OpZoneMT UCI Extension

MA_OpZoneMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_OpZoneMDT Category : MA_OpZoneCategoryEnum CategoryUniqueData : MA_OpZoneCategoryType SpeedLimits : MA_OpZoneSpeedLimitsType VehicleConfiguration : MA_VehicleCommandDataType Zone : MA_OpZoneChoiceType GeometryReference : MA_ReferentialOpZoneType ReferenceObjectsFilter : MA_GeoLocatedObjectFilterType OpPointFilter : MA_OpPointFilterType OpLineFilter : MA_OpLineFilterType OpLineCategory : MA_OpLineCategoryEnum OpZoneFilter : MA_OpZoneFilterType OpZoneCategory : MA_OpZoneCategoryEnum OpVolumeFilter : MA_OpVolumeFilterType OpVolumeCategory : MA_OpZoneCategoryEnum DMPI_Filter : MA_DMPI_FilterType SignalReportFilter : MA_SignalReportFilterType OpVolumeFilter : MA_OpVolumeFilterType OpLineFilter : MA_OpLineFilterType OpLineCategory : MA_OpLineCategoryEnum SpeedLimits : MA_OpZoneSpeedLimitsType SignalReportFilter : MA_SignalReportFilterType

	OpPointFilter : MA_OpPointFilterType
	VehicleConfiguration : MA_VehicleCommandDataType
	DMPI_Filter : MA_DMPI_FilterType
	Zone : MA_OpZoneChoiceType
	Category : MA_OpZoneCategoryEnum
	CategoryUniqueData : MA_OpZoneCategoryType
	ReferenceObjectsFilter : MA_GeoLocatedObjectFilterType
	OpVolumeCategory : MA_OpZoneCategoryEnum
	GeometryReference : MA_ReferentialOpZoneType
	OpZoneCategory : MA_OpZoneCategoryEnum
	OpZoneFilter : MA_OpZoneFilterType

Table A-4-109: C2 Interface MA_OpZoneMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpZoneMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpZoneID	OpZoneID_Type	Required
Description	This element represents the unique identifier of the zone associated with this message.	
Category	MA_OpZoneCategoryEnum	Required
Description	This element indicates the type of zone.	
CategoryUniqueData	MA_OpZoneCategoryType	Optional
Description	Contains parameters unique to certain OpZoneCategoryEnum values.	
Zone	MA_OpZoneChoiceType	Required
Description	This element represents the geospatial and temporal characteristics of the OpZone.	
SituationalAwareness	boolean	Required
Description	Zone used only for situational awareness. Not used for planning purposes.	
OpDescription	OpDescriptionType	Optional
Description	A human-readable descriptive name with free text remarks.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this operational item to specify what the source or motivation for it originated from. This could be ATO, ACO, etc.	
Source	CreationSourceEnum	Optional
Description	Indicates the source of the information.	
Schedule	ScheduleType	Optional

Description	This element represents a date/time interval associated with the operational item during which the item is in effect.	
AssociatedTime	TimeFunctionType	Repeated
Description	Indicates time related events that are associated to the Op data type such as when activated or when operational. The multiplicity is limited to N-1 options where NONE is an event that has no value, thus removed from list of available options.	
DataLinkIdentifier	DataLinkIdentifierPET	Repeated
Description	List of data link ID. Multiple data link IDs can be reported for the same network type.	
Priority	unsignedInt	Optional
Description	This field represents the priority to be considered when choosing between multiple available points.	
QualifyingTags	QualifyingTagsType	Optional
Description	Provides identity qualifications to augment identification and associated processing of the OpPoint.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
SystemScheduleOverride	SystemScheduleStateType	Repeated
Description	System-specific schedule that will override any part of the main schedule. This allows for system-specific schedule different than main schedule. When adding a SystemScheduleOverride, the child SystemID also must be added to the sibling SystemID list if the sibling list is not empty. The SystemScheduleOverride is independent of time planning. For the system, this override can be done at execution.	

Table A-4-110: C2 Interface MA_OpZoneMT - MessageData UCI Extension Field

Category	
Description	This element indicates the type of zone.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.

EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.

ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-111: C2 Interface MA_OpZoneMT - Category UCI Extension Field

CategoryUniqueData		
Description	Contains parameters unique to certain OpZoneCategoryEnum values.	
Base Type	MA_OpZoneCategoryType	
Message Structure		
Field Name	Field Type	Field Usage
ConstrainedEntryExit	ConstrainedEntryExitType	Required
Description	Defines boundaries which applicable Systems can only enter and exit through defined edges.	
FilterArea	OpZoneFilterAreaPET	Repeated
Description	Indicates that the OpZone can be a zone filter type.	
Jamming	OpZoneJammingType	Required
Description	Indicates that the OpZone is a jamming control zone.	
KeepIn	IngressEgressType	Required
Description	Defines boundaries to which applicable Systems must stay inside.	

MissileLaunchPoint	OpZoneMissileDataType	Required
Description	Data defining a missile type, related track, and source of launch position.	
NoFire	OpZoneNoFireType	Required
Description	Defines areas where strike impact is restricted. Does not restrict the launch of weapons.	
NoFly	OpZoneNoFlyType	Required
Description	Defines area where flight is restricted. Equivalent to MIL-STD-6016 restricted zone.	
SpeedLimits	MA_OpZoneSpeedLimitsType	Required
Description	Defines area where speeds are restricted.	
VehicleConfiguration	MA_VehicleCommandDataType	Required
Description	Defines vehicle configuration parameters that should change based on the planned location of a vehicle.	
WeaponRestriction	OpZoneWeaponRestrictionType	Required
Description	Set of restricted weapons that cannot be used against a target type and or in a zone.	
WeatherConditions	OpZoneWeatherType	Required
Description	Defines area of weather conditions with potential of mission impact.	

Table A-4-112: C2 Interface MA_OpZoneMT - CategoryUniqueData UCI Extension Field

SpeedLimits		
Description	Defines area where speeds are restricted.	
Base Type	MA_OpZoneSpeedLimitsType	
Message Structure		
Field Name	Field Type	Field Usage
MinSpeedLimit	PathSegmentSpeedValueType	Optional
Description	Indicates the minimum speed limit in meters per second within a zone/region.	
MaxSpeedLimit	PathSegmentSpeedValueType	Optional
Description	Indicates the maximum speed limit in meters per second within a zone/region.	

Table A-4-113: C2 Interface MA_OpZoneMT - SpeedLimits UCI Extension Field

VehicleConfiguration		
Description	Defines vehicle configuration parameters that should change based on the planned location of a vehicle.	
Base Type	MA_VehicleCommandDataType	
Message Structure		
Field Name	Field Type	Field Usage
VehicleAction	VehicleActionEnum	Optional
Description	Defines vehicle actions that can be done along a path segment of a route.	
IFF_Settings	IFF_Type	Optional

Description	If present the IFF settings for this vehicle will be changed along this path segment.	
SurvivabilityMode	VehicleSurvivabilityModeEnum	Optional
Description	Specifies that the vehicle should put itself into a more survivable mode. Different vehicles will have specific behaviors that reduce the signature of the vehicle (doors closed, minimal use of flaps, etc.) If this element is not present then it is assumed that the aircraft being configured has no survivability mode.	
LostCommTimeout	DurationType	Optional
Description	Defines the lost communication contingency timeout. When this timeout value is exceeded, the AV considers that lost communication has occurred and begins to perform contingency measures.	
LOS	boolean	Optional
Description	Use Line Of Sight (LOS) communication as backup contingency.	
LossOfLinkProcessing	VehicleLossOfLinkProcessingEnum	Optional
Description	Specifies whether the vehicle should invoke special Loss of Link processing. This could be turned off if the vehicle is going to be in a known and accepted lost communication situation.	
CommAllocationAction	CommAllocationActionType	Optional
Description	Indicates a change of communication allocation.	
QNH_Setting	PressureType	Optional
Description	Represents the barometric altimeter setting for correct MSL reading, commonly known as QNH, requested. Expressed in kilopascals (kPa).	

Table A-4-114: C2 Interface MA_OpZoneMT - VehicleConfiguration UCI Extension Field

Zone		
Description	This element represents the geospatial and temporal characteristics of the OpZone.	
Base Type	MA_OpZoneChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
GeometrySpecification	OpZoneType	Required
Description	Defines an OpZone geometry	
GeometryReference	MA_ReferentialOpZoneType	Required
Description	Defines an OpZone geometry via reference to other filtered objects	

Table A-4-115: C2 Interface MA_OpZoneMT - Zone UCI Extension Field

GeometryReference		
Description	Defines an OpZone geometry via reference to other filtered objects	
Base Type	MA_ReferentialOpZoneType	
Message Structure		
Field Name	Field Type	Field Usage

ReferenceObjectsFilter	MA_GeoLocatedObjectFilterType	Repeated
Description	The geometry of all objects returned by this filter will be used for the OpZone being defined.	
HorizontalBuffer	DistanceType	Required
Description	The area of the resulting OpZone is the area of the referenced object, expanded by this horizontal buffer along the plane orthogonal to the NED frame's down direction	
MinAltitudeBuffer	DistanceType	Required
Description	The min altitude of the resulting OpZone is the min altitude of the referenced object, decreased by this min altitude buffer	
MaxAltitudeBuffer	DistanceType	Required
Description	The max altitude of the resulting OpZone is the max altitude of the referenced object, increased by this max altitude buffer	

Table A-4-116: C2 Interface MA_OpZoneMT - GeometryReference UCI Extension Field

ReferenceObjectsFilter		
Description	The geometry of all objects returned by this filter will be used for the OpZone being defined.	
Base Type	MA_GeoLocatedObjectFilterType	
Message Structure		
Field Name	Field Type	Field Usage
EntityFilter	EntityFilterType	Optional
Description	Indicates a name/type of Entity required to match the filter. If omitted, any name/type of Entity satisfies the filter.	
SystemFilter	SystemFilterType	Optional
Description	Indicates a name/type of System required to match the filter. If omitted, any name/type of System satisfies the filter.	
OpPointFilter	MA_OpPointFilterType	Optional
Description	Indicates a name/type of OpPoint required to match the filter. If omitted, any name/type of OpPoint satisfies the filter.	
OpLineFilter	MA_OpLineFilterType	Optional
Description	Indicates a name/type of OpLine required to match the filter. If omitted, any name/type of OpLine satisfies the filter.	
OpZoneFilter	MA_OpZoneFilterType	Optional
Description	Indicates a name/type of OpZone required to match the filter. If omitted, any name/type of OpZone satisfies the filter.	
OpVolumeFilter	MA_OpVolumeFilterType	Optional
Description	Indicates a name/type of OpVolume required to match the filter. If omitted, any name/type of OpVolume satisfies the filter.	
DMPI_Filter	MA_DMPI_FilterType	Optional
Description	Indicates a name/type of DMPI required to match the filter. If omitted, any name/type of DMPI satisfies the filter.	

SignalReportFilter	MA_SignalReportFilterType	Optional
Description	Indicates a name/type of SignalReport required to match the filter. If omitted, any name/type of SignalReport satisfies the filter.	

Table A-4-117: C2 Interface MA_OpZoneMT - ReferenceObjectsFilter UCI Extension Field

OpPointFilter		
Description	Indicates a name/type of OpPoint required to match the filter. If omitted, any name/type of OpPoint satisfies the filter.	
Base Type	MA_OpPointFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointID	OpPointID_Type	Repeated
Description	Indicates a specific OpPointID that is required to match the filter. If omitted, any OpPointID satisfies the filter. Multiple instances are logically ORed.	
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint category that is required to match the filter. If omitted, any OpPoint category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpPoint must fall within to satisfy the filter. Multiple instances are logically ORed.Indicates that the OpRouting type is applicable. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-118: C2 Interface MA_OpZoneMT - OpPointFilter UCI Extension Field

OpLineFilter		
Description	Indicates a name/type of OpLine required to match the filter. If omitted, any name/type of OpLine satisfies the filter.	
Base Type	MA_OpLineFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpLineID	OpLineID_Type	Repeated
Description	Indicates a specific OpLineID that is required to match the filter. If omitted, any OpLineID satisfies the filter. Multiple instances are logically ORed.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine category that is required to match the filter. If omitted, any OpLine category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpLine must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-119: C2 Interface MA_OpZoneMT - OpLineFilter UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine category that is required to match the filter. If omitted, any OpLine category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-120: C2 Interface MA_OpZoneMT - OpLineCategory UCI Extension Field

OpZoneFilter		
Description	Indicates a name/type of OpZone required to match the filter. If omitted, any name/type of OpZone satisfies the filter.	
Base Type	MA_OpZoneFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpZoneID	OpZoneID_Type	Repeated
Description	Indicates a specific OpZoneID that is required to match the filter. If omitted, any OpZoneID satisfies the filter. Multiple instances are logically ORed.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone category that is required to match the filter. If omitted, any OpZone category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpZone must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-121: C2 Interface MA_OpZoneMT - OpZoneFilter UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone category that is required to match the filter. If omitted, any OpZone category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.

FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.

ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-122: C2 Interface MA_OpZoneMT - OpZoneCategory UCI Extension Field

OpVolumeFilter		
Description	Indicates a name/type of OpVolume required to match the filter. If omitted, any name/type of OpVolume satisfies the filter.	
Base Type	MA_OpVolumeFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpVolumeID	OpVolumeID_Type	Repeated
Description	Indicates a specific OpVolumeID that is required to match the filter. If omitted, any OpVolumeID satisfies the filter. Multiple instances are logically ORed.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume category that is required to match the filter. If omitted, any OpVolume category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpVolume must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-123: C2 Interface MA_OpZoneMT - OpVolumeFilter UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume category that is required to match the filter. If omitted, any OpVolume category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with

	this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters

	used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-124: C2 Interface MA_OpZoneMT - OpVolumeCategory UCI Extension Field

DMPI_Filter		
Description	Indicates a name/type of DMPI required to match the filter. If omitted, any name/type of DMPI satisfies the filter.	
Base Type	MA_DMPI_FilterType	
Message Structure		
Field Name	Field Type	Field Usage
DMPI_ID	DMPI_ID_Type	Repeated
Description	Indicates a specific DMPI_ID that is required to match the filter. If omitted, any DMPI_ID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the DMPI must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-125: C2 Interface MA_OpZoneMT - DMPI_Filter UCI Extension Field

SignalReportFilter		
Description	Indicates a name/type of SignalReport required to match the filter. If omitted, any name/type of SignalReport satisfies the filter.	
Base Type	MA_SignalReportFilterType	
Message Structure		
Field Name	Field Type	Field Usage
SignalReportID	SignalReportID_Type	Repeated
Description	Indicates a specific SignalReportID that is required to match the filter. If omitted, any SignalReportID satisfies the filter. Multiple instances are logically ORed.	
SystemID	SystemID_Type	Repeated
Description	Indicates a specific source SystemID that is required to match the filter. If omitted, any source SystemID satisfies the filter. Multiple instances are logically ORed.	
SubsystemID	SubsystemID_Type	Repeated
Description	Indicates a specific source SubsystemID that is required to match the filter. If omitted, any source SubsystemID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the SignalReport must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-126: C2 Interface MA_OpZoneMT - SignalReportFilter UCI Extension Field

OpVolumeFilter

Description	Indicates a name/type of OpVolume required to match the filter. If omitted, any name/type of OpVolume satisfies the filter.	
Base Type	MA_OpVolumeFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpVolumeID	OpVolumeID_Type	Repeated
Description	Indicates a specific OpVolumeID that is required to match the filter. If omitted, any OpVolumeID satisfies the filter. Multiple instances are logically ORed.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume category that is required to match the filter. If omitted, any OpVolume category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpVolume must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-127: C2 Interface MA_OpZoneMT - OpVolumeFilter UCI Extension Field

OpLineFilter		
Description	Indicates a name/type of OpLine required to match the filter. If omitted, any name/type of OpLine satisfies the filter.	
Base Type	MA_OpLineFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpLineID	OpLineID_Type	Repeated
Description	Indicates a specific OpLineID that is required to match the filter. If omitted, any OpLineID satisfies the filter. Multiple instances are logically ORed.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine category that is required to match the filter. If omitted, any OpLine category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpLine must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-128: C2 Interface MA_OpZoneMT - OpLineFilter UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine category that is required to match the filter. If omitted, any OpLine category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpLineCategoryEnum

Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-129: C2 Interface MA_OpZoneMT - OpLineCategory UCI Extension Field

SpeedLimits		
Description	Defines area where speeds are restricted.	
Base Type	MA_OpZoneSpeedLimitsType	
Message Structure		
Field Name	Field Type	Field Usage

MinSpeedLimit	PathSegmentSpeedValueType	Optional
Description	Indicates the minimum speed limit in meters per second within a zone/region.	
MaxSpeedLimit	PathSegmentSpeedValueType	Optional
Description	Indicates the maximum speed limit in meters per second within a zone/region.	

Table A-4-130: C2 Interface MA_OpZoneMT - SpeedLimits UCI Extension Field

SignalReportFilter		
Description	Indicates a name/type of SignalReport required to match the filter. If omitted, any name/type of SignalReport satisfies the filter.	
Base Type	MA_SignalReportFilterType	
Message Structure		
Field Name	Field Type	Field Usage
SignalReportID	SignalReportID_Type	Repeated
Description	Indicates a specific SignalReportID that is required to match the filter. If omitted, any SignalReportID satisfies the filter. Multiple instances are logically ORed.	
SystemID	SystemID_Type	Repeated
Description	Indicates a specific source SystemID that is required to match the filter. If omitted, any source SystemID satisfies the filter. Multiple instances are logically ORed.	
SubsystemID	SubsystemID_Type	Repeated
Description	Indicates a specific source SubsystemID that is required to match the filter. If omitted, any source SubsystemID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the SignalReport must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-131: C2 Interface MA_OpZoneMT - SignalReportFilter UCI Extension Field

OpPointFilter		
Description	Indicates a name/type of OpPoint required to match the filter. If omitted, any name/type of OpPoint satisfies the filter.	
Base Type	MA_OpPointFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointID	OpPointID_Type	Repeated
Description	Indicates a specific OpPointID that is required to match the filter. If omitted, any OpPointID satisfies the filter. Multiple instances are logically ORed.	
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint category that is required to match the filter. If omitted, any OpPoint category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated

Description	Indicates a zone the OpPoint must fall within to satisfy the filter. Multiple instances are logically ORed. Indicates that the OpRouting type is applicable. List size for this element is based on there being no category type for OpRouting objects
-------------	--

Table A-4-132: C2 Interface MA_OpZoneMT - OpPointFilter UCI Extension Field

VehicleConfiguration		
Description	Defines vehicle configuration parameters that should change based on the planned location of a vehicle.	
Base Type	MA_VehicleCommandDataType	
Message Structure		
Field Name	Field Type	Field Usage
VehicleAction	VehicleActionEnum	Optional
Description	Defines vehicle actions that can be done along a path segment of a route.	
IFF_Settings	IFF_Type	Optional
Description	If present the IFF settings for this vehicle will be changed along this path segment.	
SurvivabilityMode	VehicleSurvivabilityModeEnum	Optional
Description	Specifies that the vehicle should put itself into a more survivable mode. Different vehicles will have specific behaviors that reduce the signature of the vehicle (doors closed, minimal use of flaps, etc.) If this element is not present then it is assumed that the aircraft being configured has no survivability mode.	
LostCommTimeout	DurationType	Optional
Description	Defines the lost communication contingency timeout. When this timeout value is exceeded, the AV considers that lost communication has occurred and begins to perform contingency measures.	
LOS	boolean	Optional
Description	Use Line Of Sight (LOS) communication as backup contingency.	
LossOfLinkProcessing	VehicleLossOfLinkProcessingEnum	Optional
Description	Specifies whether the vehicle should invoke special Loss of Link processing. This could be turned off if the vehicle is going to be in a known and accepted lost communication situation.	
CommAllocationAction	CommAllocationActionType	Optional
Description	Indicates a change of communication allocation.	
QNH_Setting	PressureType	Optional
Description	Represents the barometric altimeter setting for correct MSL reading, commonly known as QNH, requested. Expressed in kilopascals (kPa).	

Table A-4-133: C2 Interface MA_OpZoneMT - VehicleConfiguration UCI Extension Field

DMPI_Filter	
Description	Indicates a name/type of DMPI required to match the filter. If omitted, any name/type of DMPI satisfies the filter.
Base Type	MA_DMPI_FilterType
Message Structure	

Field Name	Field Type	Field Usage
DMPI_ID	DMPI_ID_Type	Repeated
Description	Indicates a specific DMPI_ID that is required to match the filter. If omitted, any DMPI_ID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the DMPI must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-134: C2 Interface MA_OpZoneMT - DMPI_Filter UCI Extension Field

Zone		
Description	This element represents the geospatial and temporal characteristics of the OpZone.	
Base Type	MA_OpZoneChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
GeometrySpecification	OpZoneType	Required
Description	Defines an OpZone geometry	
GeometryReference	MA_ReferentialOpZoneType	Required
Description	Defines an OpZone geometry via reference to other filtered objects	

Table A-4-135: C2 Interface MA_OpZoneMT - Zone UCI Extension Field

Category	
Description	This element indicates the type of zone.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.

EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.

ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-136: C2 Interface MA_OpZoneMT - Category UCI Extension Field

CategoryUniqueData		
Description	Contains parameters unique to certain OpZoneCategoryEnum values.	
Base Type	MA_OpZoneCategoryType	
Message Structure		
Field Name	Field Type	Field Usage
ConstrainedEntryExit	ConstrainedEntryExitType	Required
Description	Defines boundaries which applicable Systems can only enter and exit through defined edges.	
FilterArea	OpZoneFilterAreaPET	Repeated
Description	Indicates that the OpZone can be a zone filter type.	
Jamming	OpZoneJammingType	Required
Description	Indicates that the OpZone is a jamming control zone.	
KeepIn	IngressEgressType	Required
Description	Defines boundaries to which applicable Systems must stay inside.	
MissileLaunchPoint	OpZoneMissileDataType	Required

Description	Data defining a missile type, related track, and source of launch position.	
NoFire	OpZoneNoFireType	Required
Description	Defines areas where strike impact is restricted. Does not restrict the launch of weapons.	
NoFly	OpZoneNoFlyType	Required
Description	Defines area where flight is restricted. Equivalent to MIL-STD-6016 restricted zone.	
SpeedLimits	MA_OpZoneSpeedLimitsType	Required
Description	Defines area where speeds are restricted.	
VehicleConfiguration	MA_VehicleCommandDataType	Required
Description	Defines vehicle configuration parameters that should change based on the planned location of a vehicle.	
WeaponRestriction	OpZoneWeaponRestrictionType	Required
Description	Set of restricted weapons that cannot be used against a target type and or in a zone.	
WeatherConditions	OpZoneWeatherType	Required
Description	Defines area of weather conditions with potential of mission impact.	

Table A-4-137: C2 Interface MA_OpZoneMT - CategoryUniqueData UCI Extension Field

ReferenceObjectsFilter		
Description	The geometry of all objects returned by this filter will be used for the OpZone being defined.	
Base Type	MA_GeoLocatedObjectFilterType	
Message Structure		
Field Name	Field Type	Field Usage
EntityFilter	EntityFilterType	Optional
Description	Indicates a name/type of Entity required to match the filter. If omitted, any name/type of Entity satisfies the filter.	
SystemFilter	SystemFilterType	Optional
Description	Indicates a name/type of System required to match the filter. If omitted, any name/type of System satisfies the filter.	
OpPointFilter	MA_OpPointFilterType	Optional
Description	Indicates a name/type of OpPoint required to match the filter. If omitted, any name/type of OpPoint satisfies the filter.	
OpLineFilter	MA_OpLineFilterType	Optional
Description	Indicates a name/type of OpLine required to match the filter. If omitted, any name/type of OpLine satisfies the filter.	
OpZoneFilter	MA_OpZoneFilterType	Optional
Description	Indicates a name/type of OpZone required to match the filter. If omitted, any name/type of OpZone satisfies the filter.	
OpVolumeFilter	MA_OpVolumeFilterType	Optional

Description	Indicates a name/type of OpVolume required to match the filter. If omitted, any name/type of OpVolume satisfies the filter.	
DMPI_Filter	MA_DMPI_FilterType	Optional
Description	Indicates a name/type of DMPI required to match the filter. If omitted, any name/type of DMPI satisfies the filter.	
SignalReportFilter	MA_SignalReportFilterType	Optional
Description	Indicates a name/type of SignalReport required to match the filter. If omitted, any name/type of SignalReport satisfies the filter.	

Table A-4-138: C2 Interface MA_OpZoneMT - ReferenceObjectsFilter UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume category that is required to match the filter. If omitted, any OpVolume category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or

	predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in

	OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-139: C2 Interface MA_OpZoneMT - OpVolumeCategory UCI Extension Field

GeometryReference		
Description	Defines an OpZone geometry via reference to other filtered objects	
Base Type	MA_ReferentialOpZoneType	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceObjectsFilter	MA_GeoLocatedObjectFilterType	Repeated
Description	The geometry of all objects returned by this filter will be used for the OpZone being defined.	
HorizontalBuffer	DistanceType	Required
Description	The area of the resulting OpZone is the area of the referenced object, expanded by this horizontal buffer along the plane orthogonal to the NED frame's down direction	
MinAltitudeBuffer	DistanceType	Required
Description	The min altitude of the resulting OpZone is the min altitude of the referenced object, decreased by this min altitude buffer	
MaxAltitudeBuffer	DistanceType	Required
Description	The max altitude of the resulting OpZone is the max altitude of the referenced object, increased by this max altitude buffer	

Table A-4-140: C2 Interface MA_OpZoneMT - GeometryReference UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone category that is required to match the filter. If omitted, any OpZone category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	

Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area

	designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-141: C2 Interface MA_OpZoneMT - OpZoneCategory UCI Extension Field

OpZoneFilter

Description	Indicates a name/type of OpZone required to match the filter. If omitted, any name/type of OpZone satisfies the filter.	
Base Type	MA_OpZoneFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpZoneID	OpZoneID_Type	Repeated
Description	Indicates a specific OpZoneID that is required to match the filter. If omitted, any OpZoneID satisfies the filter. Multiple instances are logically ORED.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone category that is required to match the filter. If omitted, any OpZone category satisfies the filter. Multiple instances are logically ORED. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpZone must fall within to satisfy the filter. Multiple instances are logically ORED.	

Table A-4-142: C2 Interface MA_OpZoneMT - OpZoneFilter UCI Extension Field

4.1.24 MA_NavigationReportMT UCI Extension

MA_NavigationReportMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_NavigationReportMDT

Table A-4-143: C2 Interface MA_NavigationReportMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_NavigationReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Indicates the unique ID of the System corresponding to this NavigationReport.	
Source	SystemSourceEnum	Required
Description	Indicates the source of the data in sibling elements. See enumeration annotations for further details.	
ContingencyLevel	SystemContingencyLevelEnum	Required
Description	Designates the current contingency state of the System. Contingencies can be an indication that the System will/has autonomously modified its means of navigation.	

Endurance	EnduranceType	Required
Description	Indicates the System's remaining endurance. It is expected that at least one of the optional children are populated in this context.	
Playtime	DurationType	Optional
Description	Estimated remaining playtime of operation/mission when taking into account RTB routing, fuel overhead, current fuel usage, current tasking, etc.	
Navigation	NavigationType	Optional
Description	Vehicle navigation method currently employed.	

Table A-4-144: C2 Interface MA_NavigationReportMT - MessageData UCI Extension Field

4.1.25 MA_AcceptableLevelOfRiskCommandMT UCI Extension

MA_AcceptableLevelOfRiskCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_AcceptableLevelOfRiskCommandMDT

Table A-4-145: C2 Interface MA_AcceptableLevelOfRiskCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_AcceptableLevelOfRiskCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
AcceptableRiskSetting	MA_AcceptableLevelOfRiskEnum	Required
Description	This is the acceptable level of risk permitted at the package or vehicle level, which applies to all tasks and actions for the vehicle/package while active.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	Identifies the Package ID or ACP System ID for which the acceptable risk parameter applies. If Package ID is used, this includes all package member System IDs, so a member ACP's System ID does not need to be separately included. This value overrides the AppliesToSystemID in the SurvivabilityRiskLevelMDT message.	
SurvivabilityRiskLevelID	SurvivabilityRiskLevelID_Type	Required
Description	The unique identifier for the Survivability Risk Level that should be active as the default setting.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing	

	command.
--	----------

Table A-4-146: C2 Interface MA_AcceptableLevelOfRiskCommandMT - MessageData UCI Extension Field

4.1.26 MA_ConstraintPriorityListActivationDataMT UCI Extension

MA_ConstraintPriorityListActivationDataMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ConstraintPriorityListActivationDataMDT

Table A-4-147: C2 Interface MA_ConstraintPriorityListActivationDataMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ConstraintPriorityListActivationDataMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConstraintPriorityListActivationDataID	MA_ConstraintPriorityListActivationDataID_Type	Required
Description	The unique identifier for the message.	
DefaultConstraintPriorityListID	MA_ConstraintPriorityListID_Type	Required
Description	Contains the ID of the Constraint Priority List that should be set as the default.	
ListOfApplicableOpConstrainedConstraintPriorityListIDs	MA_ListOfApplicableOpConstrainedConstraintPriorityListIDType	Repeated
Description	When an Package/ACP is within this geozone, the linked Constraint Priority List will be used instead of the default. OpZone and OpVolume IDs can only appear once in this list.	

Table A-4-148: C2 Interface MA_ConstraintPriorityListActivationDataMT - MessageData UCI Extension Field

4.1.27 MA_ConstraintPriorityListCommandMT UCI Extension

MA_ConstraintPriorityListCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ConstraintPriorityListCommandMDT

Table A-4-149: C2 Interface MA_ConstraintPriorityListCommandMT UCI Extension

MessageData

Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ConstraintPriorityListCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConstraintPriorityListActivationDataID	MA_ConstraintPriorityListActivationDataID_Type	Required
Description	This ID of the Activated message that should be active.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. If an ACP is a member of a package, the ACPs SystemID does not need to be in this field as well.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-150: C2 Interface MA_ConstraintPriorityListCommandMT - MessageData UCI Extension Field

4.1.28 MA_ConstraintPriorityListMT UCI Extension

MA_ConstraintPriorityListMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ConstraintPriorityListMDT

Table A-4-151: C2 Interface MA_ConstraintPriorityListMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ConstraintPriorityListMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConstraintPriorityListID	MA_ConstraintPriorityListID_Type	Required
Description	The unique identifier for the message.	
DefaultPriority	unsignedShort	Optional
Description	This field, if set, is the value that would be assigned to any ConstraintType that is not listed in the ListItem field. If this field is not set, the default value of ConstraintTypes not listed the ListItem field would be blank or the highest priority ("above" 0).	

ListItem	MA_ConstraintPriorityListItemType	Repeated
Description	Identifies a constraint type and it's priority in the Constraint Priority List.	

Table A-4-152: C2 Interface MA_ConstraintPriorityListMT - MessageData UCI Extension Field

4.1.29 MA_ExecutionPriorityListActivationDataMT UCI Extension

MA_ExecutionPriorityListActivationDataMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ExecutionPriorityListActivationDataMDT

Table A-4-153: C2 Interface MA_ExecutionPriorityListActivationDataMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ExecutionPriorityListActivationDataMDT	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPriorityListActivationDataID	MA_ExecutionPriorityListActivationDataID_Type	Required
Description	The unique identifier for the message.	
DefaultExecutionPriorityListID	MA_ExecutionPriorityListID_Type	Required
Description	Contains the ID of the message that should be set as the default.	
ListOfApplicableOpConstrainedExecutionPriorityListIDs	MA_ListOfApplicableOpConstrainedExecutionPriorityListIDType	Repeated
Description	When an ACP is within this geozone, the linked message will be used instead of the default. OpZone and OpVolume IDs can only appear once in this list.	

Table A-4-154: C2 Interface MA_ExecutionPriorityListActivationDataMT - MessageData UCI Extension Field

4.1.30 MA_ExecutionPriorityListCommandMT UCI Extension

MA_ExecutionPriorityListCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ExecutionPriorityListCommandMDT

Table A-4-155: C2 Interface MA_ExecutionPriorityListCommandMT UCI Extension

MessageData

Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ExecutionPriorityListCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPriorityListActivationDataID	MA_ExecutionPriorityListActivationDataID_Type	Required
Description	The ID of the Activation Data message that should be used.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. If an ACP is a member of a package, the ACPs SystemID does not need to be in this field as well.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-156: C2 Interface MA_ExecutionPriorityListCommandMT - MessageData UCI Extension Field

4.1.31 MA_ExecutionPriorityListMT UCI Extension

MA_ExecutionPriorityListMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ExecutionPriorityListMDT

Table A-4-157: C2 Interface MA_ExecutionPriorityListMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ExecutionPriorityListMDT	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPriorityListID	MA_ExecutionPriorityListID_Type	Required
Description	The unique identifier for the message.	
ListItem	MA_ExecutionPriorityListItemType	Repeated
Description	Identifies an item (task or action) and its rank in the Execution Priority List.	

Table A-4-158: C2 Interface MA_ExecutionPriorityListMT - MessageData UCI Extension Field

4.1.32 MA_IgnoreConstraintCommandMT UCI Extension

MA_IgnoreConstraintCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_IgnoreConstraintCommandMDT

Table A-4-159: C2 Interface MA_IgnoreConstraintCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_IgnoreConstraintCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceType	RequirementsReferenceType	Required
Description	ID of the task(s) that the command applies to.	
ListOfConstraintsToIgnore	MA_RegionChoiceType	Repeated
Description	Indicates the constraint(s) being overridden.	
IgnoreAllConstraints	boolean	Optional
Description	If True, ignores all constraints.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. If an ACP is a member of a package, the ACPs SystemID does not need to be in this field as well.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-160: C2 Interface MA_IgnoreConstraintCommandMT - MessageData UCI Extension Field

4.1.33 MA_EngagementCriteriaCommandMT UCI Extension

MA_EngagementCriteriaCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_EngagementCriteriaCommandMDT

Table A-4-161: C2 Interface MA_EngagementCriteriaCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_EngagementCriteriaCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
EngagementCriteriaID	MA_EngagementCriteriaID_Type	Required
Description	Contains the ID of the Engagement Criteria message that should be active (for CommandState NEW or Update) or deactivated (for CommandState CANCEL).	
ApplicableRegion	MA_RegionChoiceType	Repeated
Description	The ID(s) of an OpZone/OpVolume or specified zone(s) that defines where this Engagement Criteria is applicable. If this field is not empty, an ACP and the Target must be within this region for the ACP to fire and the weapon to strike the intended target. The MA shall only start an engagement for targets inside of the Region(s).	
TimeValid	DateTimeRangeType	Optional
Description	The time window for which the Engagement Criteria is valid. If this field is left empty, the Engagement Criteria is valid until the Command is canceled or an updated.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. If an ACP is a member of a package, the ACPs SystemID does not need to be in this field as well.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-162: C2 Interface MA_EngagementCriteriaCommandMT - MessageData UCI Extension Field

4.1.34 MA_EngagementCriteriaMT UCI Extension

MA_EngagementCriteriaMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_EngagementCriteriaMDT

Table A-4-163: C2 Interface MA_EngagementCriteriaMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_EngagementCriteriaMDT

Message Structure		
Field Name	Field Type	Field Usage
EngagementCriteriaID	MA_EngagementCriteriaID_Type	Required
Description	The unique identifier for the message.	
IdMatrixCriteria	MA_IdMatrixCriteriaType	Optional
Description	These markers are used to identify an Entity as a Friend, Neutral, or Enemy and which enables or confirms the Entity's Standard Identity type to be set to FRIEND, NEUTRAL, SUSPECT or HOSTILE.	
TargetDesignationCriteria	MA_TargetDesignationCriteriaType	Repeated
Description	This provides a list of criteria that when met can trigger a MA_DesignationRequestMT to be sent to a Target Authority who can use the info in this message to send a MA_DesignationMT that will designate an Entity as a Target.	
TargetAuthorityCriteria	MA_AuthorityCriteriaType	Optional
Description	This provides a list of Authorized Operators that are allowed to set an Entity as a Target and to respond to a StrikeConsentRequestMT. An Entity becomes a Target when a Designation message declares that entity to be a Target. This can also be done by an Action or Task specifying an Entity as a Target (TargetType). The associated Approval Policy will specify which Actions or Tasks make an Entity a Target and who is authorized to command them or approve a response that activates them. MA can send a MA_DesignationRequestMT to Operators identified in the Approval Authority. An Authorized operator can also directly send a MA_DesignationMT. An MA can be an authorized approver if specified, but an MA cannot send a MA_DesignationMT for itself. A Lead can send a MA_DesignationMT to a follower if a C2 has already approved the Target.	
TargetCustodyCriteria	MA_TargetCustodyCriteriaType	Repeated
Description	This describes how the Custody of a Target is confirmed and must be held through a Weapons Engagement with that Target.	
StrikeConsentRequired	boolean	Required
Description	Indicates whether (TRUE) or not (FALSE) the Strike Activities requires consent to transition from the ENABLED state to an ACTIVE state. If TRUE, each Strike Activity would be required to send a StrikeConsentRequestMT to an Authorized Operator (defined in the TargetAuthorityCriteria field) and receive a StrikeConsentRequestStatusMT before each Strike Activity can execute the Strike.	

Table A-4-164: C2 Interface MA_EngagementCriteriaMT - MessageData UCI Extension Field

4.1.35 MA_AcceptableLevelOfRiskCommandStatusMT UCI Extension

MA_AcceptableLevelOfRiskCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_AcceptableLevelOfRiskCommandStatusMDT

Table A-4-165: C2 Interface MA_AcceptableLevelOfRiskCommandStatusMT UCI Extension

MessageData

Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_AcceptableLevelOfRiskCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond with ACCEPTED for the Package or individual ACPs as needed.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-166: C2 Interface MA_AcceptableLevelOfRiskCommandStatusMT - MessageData UCI Extension Field

4.1.36 MA_ConstraintPriorityListActivationStatusMT UCI Extension

MA_ConstraintPriorityListActivationStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ConstraintPriorityListActivationStatusMDT

Table A-4-167: C2 Interface MA_ConstraintPriorityListActivationStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ConstraintPriorityListActivationStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConstraintPriorityListActivationDataID	MA_ConstraintPriorityListActivationDataID_Type	Required
Description	The unique identifier for the CPL Activation Data message.	
ActiveConstraintPriorityListID	MA_ConstraintPriorityListID_Type	Required

Description	The unique identifier for the active Constraint Priority List.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond for the Package or individual ACPs as needed.	

Table A-4-168: C2 Interface MA_ConstraintPriorityListActivationStatusMT - MessageData UCI Extension Field

4.1.37 MA_ConstraintPriorityListCommandStatusMT UCI Extension

MA_ConstraintPriorityListCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ConstraintPriorityListCommandStatusMDT

Table A-4-169: C2 Interface MA_ConstraintPriorityListCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ConstraintPriorityListCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond with ACCEPTED for the Package or individual ACPs as needed.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-170: C2 Interface MA_ConstraintPriorityListCommandStatusMT - MessageData UCI Extension Field

4.1.38 MA_ExecutionPriorityListActivationStatusMT UCI Extension

MA_ExecutionPriorityListActivationStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details.

	See the XSD File for more info
Ext. Fields	MessageData : MA_ExecutionPriorityListActivationStatusMDT

Table A-4-171: C2 Interface MA_ExecutionPriorityListActivationStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ExecutionPriorityListActivationStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPriorityListActivationDataID	MA_ExecutionPriorityListActivationDataID_Type	Required
Description	The unique identifier for the EPL Activation Data message.	
ActiveExecutionPriorityListID	MA_ExecutionPriorityListID_Type	Required
Description	The unique identifier for the active EPL message.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond for the Package or individual ACPs as needed.	

Table A-4-172: C2 Interface MA_ExecutionPriorityListActivationStatusMT - MessageData UCI Extension Field

4.1.39 MA_ExecutionPriorityListCommandStatusMT UCI Extension

MA_ExecutionPriorityListCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details.
	See the XSD File for more info
Ext. Fields	MessageData : MA_ExecutionPriorityListCommandStatusMDT

Table A-4-173: C2 Interface MA_ExecutionPriorityListCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ExecutionPriorityListCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond with ACCEPTED for the Package or individual ACPs as needed.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	

CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-174: C2 Interface MA_ExecutionPriorityListCommandStatusMT - MessageData UCI Extension Field

4.1.40 MA_IgnoreConstraintCommandStatusMT UCI Extension

MA_IgnoreConstraintCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_IgnoreConstraintCommandStatusMDT

Table A-4-175: C2 Interface MA_IgnoreConstraintCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_IgnoreConstraintCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond with ACCEPTED for the Package or individual ACPs as needed.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-176: C2 Interface MA_IgnoreConstraintCommandStatusMT - MessageData UCI Extension Field

4.1.41 MA_EngagementCriteriaStatusMT UCI Extension

MA_EngagementCriteriaStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_EngagementCriteriaStatusMDT

Table A-4-177: C2 Interface MA_EngagementCriteriaStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_EngagementCriteriaStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
EngagementCriteriaID	MA_EngagementCriteriaID_Type	Optional
Description	Contains the ID of the Engagement Criteria message that is currently active. If this field is empty, that means there is no active Engagement Criteria and Engagement is not authorized.	
ApplicableRegion	MA_RegionChoiceType	Repeated
Description	The ID(s) of an OpZone/OpVolume or specified zone(s) that defines where the Engagement Criteria is applicable. If this field is not empty, the ACP must be in this region when it fires, and the calculated weapon impact location of the Target must be within this region. The MA shall only start an engagement for targets inside of the Region(s).	
TimeValid	DateTimeRangeType	Optional
Description	The time window for which the Engagement Criteria is valid. If this field is left empty, the Engagement Criteria is valid until the Command is canceled or an updated.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. If an ACP is a member of a package, the ACPs SystemID does not need to be in the field as well.	

Table A-4-178: C2 Interface MA_EngagementCriteriaStatusMT - MessageData UCI Extension Field

4.1.42 MA_EngagementCriteriaCommandStatusMT UCI Extension

MA_EngagementCriteriaCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_EngagementCriteriaCommandStatusMDT

Table A-4-179: C2 Interface MA_EngagementCriteriaCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_EngagementCriteriaCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond with ACCEPTED for the Package or individual ACPs as needed.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-180: C2 Interface MA_EngagementCriteriaCommandStatusMT - MessageData UCI Extension Field

4.1.43 MA_SystemNotificationMT UCI Extension

MA_SystemNotificationMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_SystemNotificationMDT NotificationDetail : CannotComplyType NotificationDetail : CannotComplyType

Table A-4-181: C2 Interface MA_SystemNotificationMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_SystemNotificationMDT	
Message Structure		
Field Name	Field Type	Field Usage

SystemSubjectIDs	MA_PackageSystemType	Required
Description	Indicates the subject of the Notification, the thing which the Notification is about.	
SystemPerspective	NotificationPerspectiveEnum	Repeated
Description	Indicates a perspective (characteristic, behavior and/or change) of the Subject that is the basis of the Notification. List size for this element is based on "Select All That Apply" condition.	
AssociatedMessage	AssociatedMessageType	Repeated
Description	Indicates a message that is associated with the Notification.	
NotificationDetail	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the unsuccessful processing of the sibling AssociatedMessage element. This element is only expected when the Associated Message processing is not successful	
NotificationID	NotificationID_Type	Required
Description	Indicates the unique ID of the Notification.	
NotificationState	NotificationStateEnum	Required
Description	Indicates the current state within an enumerated state machine that characterizes the life cycle of a notification.	
Timestamp	DateTimeType	Required
Description	The time at which the Notification was originally triggered (ex: event time).	
Source	NotificationSourceType	Required
Description	Indicates the originating source of the Notification.	
Severity	NotificationSeverityEnum	Required
Description	Indicates the overall severity of the notification. Informational notifications are meant to provide informational context of events. Indicates the existence of a hazardous condition requiring immediate action to prevent loss of life, equipment damage, or abortion of the mission. Critical notifications indicate the need for immediate attention.	
AppliesTo	SubjectType	Repeated
Description	Indicates an Asset that the Notification applies to and/or is affected by. Optional when the Notification characterizes the Subject without regard for Assets it might affect. Omission of this element doesn't necessarily mean the Notification isn't applicable to an Asset.	
NotificationNarrative	VisibleString1024Type	Optional
Description	Human readable message for display to an operator.	

Table A-4-182: C2 Interface MA_SystemNotificationMT - MessageData UCI Extension Field

NotificationDetail	
Description	Indicates details regarding the reason for and/or a contributing factor to the unsuccessful processing of the sibling AssociatedMessage element. This element is only expected when the Associated Message processing is not successful
Base Type	CannotComplyType
Message Structure	

Field Name	Field Type	Field Usage
Reason	CannotComplyEnum	Required
Description	Indicates the reason why an action (Task, [Capability]Command, [SupportingCapability]Command, [Capability]Activity, etc.) was rejected, interrupted, unallocated, failed and/or generally can't be completed satisfactorily. See enumeration annotations for further details.	
Description	VisibleString1024Type	Optional
Description	Indicates a human-readable text description of the reason for the "can't comply".	
AssociatedID	ID_Type	Optional
Description	Indicates an ID corresponding to another object that is associated with or the cause of the "can't comply".	

Table A-4-183: C2 Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field

NotificationDetail		
Description	Indicates details regarding the reason for and/or a contributing factor to the unsuccessful processing of the sibling AssociatedMessage element. This element is only expected when the Associated Message processing is not successful	
Base Type	CannotComplyType	
Message Structure		
Field Name	Field Type	Field Usage
Reason	CannotComplyEnum	Required
Description	Indicates the reason why an action (Task, [Capability]Command, [SupportingCapability]Command, [Capability]Activity, etc.) was rejected, interrupted, unallocated, failed and/or generally can't be completed satisfactorily. See enumeration annotations for further details.	
Description	VisibleString1024Type	Optional
Description	Indicates a human-readable text description of the reason for the "can't comply".	
AssociatedID	ID_Type	Optional
Description	Indicates an ID corresponding to another object that is associated with or the cause of the "can't comply".	

Table A-4-184: C2 Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field

4.1.44 MA_EffectCapabilityMT UCI Extension

MA_EffectCapabilityMT	
Description	This message represents the Effect category of UCI Capability. See the XSD File for more info
Ext. Fields	AssociatedTaskType : TaskTypeEnum

Table A-4-185: C2 Interface MA_EffectCapabilityMT UCI Extension

AssociatedTaskType

Description	Indicates a Task type associated with the Effect. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.
Base Type	TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.
AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.
SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.
SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-186: C2 Interface MA_EffectCapabilityMT - AssociatedTaskType UCI Extension Field

4.1.45 MA_ActionCapabilityMT UCI Extension

MA_ActionCapabilityMT	
Description	This message represents the Action category of UCI Capability. See the XSD File for more info

Ext. Fields	AssociatedTaskType : MA_TaskTypeEnum Capability : MA_ActionCapabilityType MessageData : MA_ActionCapabilityMDT
--------------------	--

Table A-4-187: C2 Interface MA_ActionCapabilityMT UCI Extension

AssociatedTaskType	
Description	Indicates a Task type associated with the Action. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.
AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.
CAP	Indicates the task is to execute a Combat Air Patrol.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESCORT	Indicates the task is to escort another entity.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.
SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.
SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-188: C2 Interface MA_ActionCapabilityMT - AssociatedTaskType UCI Extension Field

Capability		
Description	Indicates an installed Action Capability, its configurable characteristics and its controllability.	
Base Type	MA_ActionCapabilityType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityType	MA_ActionTypeEnum	Required
Description	Indicates the type of Action. See enumerated type annotations for further details.	
AssociatedTaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a Task type associated with the Action. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
AssociatedCapabilityType	CapabilityTypeEnum	Repeated
Description	Indicates a Capability type associated with the Action. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CapabilityOptions	ActionCapabilityOptionsType	Required
Description	Indicates the Capability's support for select optional elements in its accepted control interface messages. Support for these elements is expected to vary across Capability implementations but must be known in order to adapt and configure upstream Systems and Services which use the Capability.	
MessageOutput	ActionMessageOutputsEnum	Repeated
Description	Indicates a message that is an output of the Capability. See enumerated type annotations for details. List size for this element is based on "Select All That Apply" condition.	
AcceptedInterface	CapabilityControlInterfacesEnum	Repeated
Description	Indicates an accepted control interface for the Capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CommsRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) communications are required to use the Capability. Omitted is equivalent to FALSE. For example, an unmanned system with no onboard storage would require communications to disseminate the outputs of the Capability.	
CapabilityID	CapabilityID_Type	Required
Description	Indicates the unique ID of this Capability. This ID is used to invoke the Capability via Command messages, report its activity via Activity messages, etc.	
DomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates the domain/environment which the Capability is employed from and the "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	

ProductOutput	ProductOutputType	Repeated
Description	Indicates a Product that can be an output of the Capability.	
PackageOperation	PackageOperationEnum	Optional
Description	Indicates if and how the operation of the Capability can be coordinated with a partner Capability of another System in a multi-System Package. Omitting this element is equivalent to the enumerate NO_PACKAGE_OPERATION. The actual Package configuration including per-Capability partnering between Systems is given in the PackageStatus message. For example, a System that can perform cooperative geolocation could advertise with this element in the ESM_Capability message. A System that can navigate in a swarm with other Systems could advertise with this element in the FlightCapability message.	

Table A-4-189: C2 Interface MA_ActionCapabilityMT - Capability UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActionCapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_ActionCapabilityType	Repeated
Description	Indicates an installed Action Capability, its configurable characteristics and its controllability.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.	

Table A-4-190: C2 Interface MA_ActionCapabilityMT - MessageData UCI Extension Field

4.1.46 MA_AMTI_CapabilityMT UCI Extension

MA_AMTI_CapabilityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_AMTI_CapabilityMDT Capability : MA_AMTI_CapabilityType

Table A-4-191: C2 Interface MA_AMTI_CapabilityMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type

	for details.	
Base Type	MA_AMTI_CapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_AMTI_CapabilityType	Repeated
Description	Indicates an installed AMTI Capability, its configurable characteristics and its controllability.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.	

Table A-4-192: C2 Interface MA_AMTI_CapabilityMT - MessageData UCI Extension Field

Capability		
Description	Indicates an installed AMTI Capability, its configurable characteristics and its controllability.	
Base Type	MA_AMTI_CapabilityType	
Message Structure		
Field Name	Field Type	Field Usage
MT_IIRS_Level	NIIRS_Type	Repeated
Description	Indicates a Moving Target Indication Interpretability Rating Scale level supported by the Capability. See annotations of the underlying type for further details.	
ComponentFieldOfRegard	ComponentFieldOfRegardType	Repeated
Description	Fields of Regard for each component in the capability.	
CapabilityType	AMTI_CapabilityEnum	Required
Description	Indicates the Capability's first tier type in the AMTI taxonomy. For AMTI, the first tier is an indication of the physical area covered. See enumerated type annotations for further details.	
SubCapabilityType	AMTI_SubCapabilityEnum	Repeated
Description	Indicates a SubCapability of the AMTI Capability; the second tier in the taxonomy of AMTI. For AMTI, the second tier is waveform category. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition. The selection of AUTO_SUBCAPABILITY_SELECT still requires the evaluation of all sibling attributes by the Capability.	
CapabilityOptions	AMTI_CapabilityOptionsType	Required
Description	Indicates the Capability's support for select optional elements in its accepted control interface messages. Support for these elements is expected to vary across Capability implementations but must be known in order to adapt and configure upstream Systems	

	and Services which use the Capability.	
SupportedFrequencies	FrequencyRangeType	Repeated
Description	Indicates a frequency range used by the Capability.	
MessageOutput	AMTI_MessageOutputsEnum	Repeated
Description	Indicates a message that is an output of the Capability. See enumerated type annotations for details. List size for this element is based on "Select All That Apply" condition.	
AcceptedInterface	CapabilityControlInterfacesEnum	Repeated
Description	Indicates an accepted control interface for the Capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CommsRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) communications are required to use the Capability. Omitted is equivalent to FALSE. For example, an unmanned system with no onboard storage would require communications to disseminate the outputs of the Capability.	
CapabilityID	CapabilityID_Type	Required
Description	Indicates the unique ID of this Capability. This ID is used to invoke the Capability via Command messages, report its activity via Activity messages, etc.	
DomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates the domain/environment which the Capability is employed from and the "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
ProductOutput	ProductOutputType	Repeated
Description	Indicates a Product that can be an output of the Capability.	
PackageOperation	PackageOperationEnum	Optional
Description	Indicates if and how the operation of the Capability can be coordinated with a partner Capability of another System in a multi-System Package. Omitting this element is equivalent to the enumerate NO_PACKAGE_OPERATION. The actual Package configuration including per-Capability partnering between Systems is given in the PackageStatus message. For example, a System that can perform cooperative geolocation could advertise with this element in the ESM_Capability message. A System that can navigate in a swarm with other Systems could advertise with this element in the FlightCapability message.	

Table A-4-193: C2 Interface MA_AMTI_CapabilityMT - Capability UCI Extension Field

4.1.47 MA_SystemManagementRequestMT UCI Extension

MA_SystemManagementRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_SystemManagementRequestMDT

RequestType : MA_SystemManagementRequestType
 VehicleSettings : MA_VehicleCommandDataType

Table A-4-194: C2 Interface MA_SystemManagementRequestMT UCI Extension

MessageData		
Description	This contains the message data.	
Base Type	MA_SystemManagementRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
AuthorityType	EntityManagementRequestAuthorityEnum	Optional
Description	Indicates whether this SystemManagementRequest is a request to change data or an order that must be followed. Defaults to REQUEST if not filled.	
RequestSource	RequestSourceEnum	Optional
Description	This element indicates the type of service requesting the change. Defaults to AUTOMATIC_INTERNAL if not filled.	
ReferenceSystemID	SystemID_Type	Required
Description	Indicates the system to be acted upon by this message.	
RequestType	MA_SystemManagementRequestType	Repeated
Description	Indicates the type of request to perform on a system.	
UpdateFromControllingUnit	boolean	Optional
Description	Indicates if this SystemManagementRequest came from the system controlling the referenced system. This indicates a higher confidence in the new data.	
Source	SystemMessageIdentifierType	Optional
Description	Indicates the system initiating this request and allows the requesting Service, Activity, or Network to be specified.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-195: C2 Interface MA_SystemManagementRequestMT - MessageData UCI Extension Field

RequestType		
Description	Indicates the type of request to perform on a system.	
Base Type	MA_SystemManagementRequestType	
Message Structure		
Field Name	Field Type	Field Usage
SetMode	MessageModeEnum	Required
Description	Indicates a request to modify the mode of a system.	

SetIdentity	SystemIdentityType	Required
Description	Indicates a request to set the identity of a system.	
SetLink16Metadata	Link16MetadataType	Required
Description	Indicates a request to modify the Link16Metadata of a system.	
SetVoiceControl	VoiceControlType	Required
Description	Set the voice control frequency of a system.	
SetSensorEntityReporting	boolean	Required
Description	When TRUE, indicates an order to report all locally derived sensor, signal, track or Entity data. When FALSE, indicates an order to stop reporting.	
VehicleSettings	MA_VehicleCommandDataType	Required
Description	Indicates a request to modify vehicle settings.	

Table A-4-196: C2 Interface MA_SystemManagementRequestMT - RequestType UCI Extension Field

VehicleSettings		
Description	Indicates a request to modify vehicle settings.	
Base Type	MA_VehicleCommandDataType	
Message Structure		
Field Name	Field Type	Field Usage
VehicleAction	VehicleActionEnum	Optional
Description	Defines vehicle actions that can be done along a path segment of a route.	
IFF_Settings	IFF_Type	Optional
Description	If present the IFF settings for this vehicle will be changed along this path segment.	
SurvivabilityMode	VehicleSurvivabilityModeEnum	Optional
Description	Specifies that the vehicle should put itself into a more survivable mode. Different vehicles will have specific behaviors that reduce the signature of the vehicle (doors closed, minimal use of flaps, etc.) If this element is not present then it is assumed that the aircraft being configured has no survivability mode.	
LostCommTimeout	DurationType	Optional
Description	Defines the lost communication contingency timeout. When this timeout value is exceeded, the AV considers that lost communication has occurred and begins to perform contingency measures.	
LOS	boolean	Optional
Description	Use Line Of Sight (LOS) communication as backup contingency.	
LossOfLinkProcessing	VehicleLossOfLinkProcessingEnum	Optional
Description	Specifies whether the vehicle should invoke special Loss of Link processing. This could be turned off if the vehicle is going to be in a known and accepted lost communication situation.	
CommAllocationAction	CommAllocationActionType	Optional
Description	Indicates a change of communication allocation.	
QNH_Setting	PressureType	Optional

Description	Represents the barometric altimeter setting for correct MSL reading, commonly known as QNH, requested. Expressed in kilopascals (kPa).
-------------	--

Table A-4-197: C2 Interface MA_SystemManagementRequestMT - VehicleSettings UCI Extension Field

4.1.48 MA_SystemManagementRequestStatusMT UCI Extension

MA_SystemManagementRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_SystemManagementRequestStatusMDT

Table A-4-198: C2 Interface MA_SystemManagementRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_SystemManagementRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Indicates the ID of the system responding to the SystemManagementRequest.	
ServiceID	ServiceID_Type	Required
Description	Indicates the ID of the service responding to the SystemManagementRequest.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-199: C2 Interface MA_SystemManagementRequestStatusMT - MessageData UCI Extension Field

4.1.49 MA_RoutePlanMT UCI Extension

MA_RoutePlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info

Ext. Fields	MessageData : MA_RoutePlanMDT
--------------------	-------------------------------

Table A-4-200: C2 Interface MA_RoutePlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_RoutePlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
RoutePlanID	RoutePlanID_Type	Required
Description	Indicates a unique ID assigned to the RoutePlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	RoutePlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the RoutePlan originated from.	
Plan	MA_RoutePlanType	Required
Description	Contains the details of the route plan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	RoutePlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-201: C2 Interface MA_RoutePlanMT - MessageData UCI Extension Field

4.1.50 MA_ActionMT UCI Extension

MA_ActionMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ActionMDT

Table A-4-202: C2 Interface MA_ActionMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_ActionMDT
Message Structure	

Field Name	Field Type	Field Usage
ActionID	ActionID_Type	Required
Description	Indicates a unique ID assigned to the Action. Minor updates to the Action can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new instance with a different child UUID value.	
ActionType	MA_ActionTypeEnum	Required
Description	Indicates the type of Action; the type of behavior to be performed when the Action is executed. An Action is a representation of an operational planning sentence/statement whose most complex form is: 1. Do [ActionType] within [ActionConstraints] to [TargetObject] within [TargetObjectConstraint] to/on/against/toward [SecondaryObject] Many other forms are also possible, including: 2. do [ActionType] 3. do [ActionType] to [TargetObject] 4. do [ActionType] to [TargetObject] doing [TargetObjectConstraint] to [SecondaryObject].	
ActionConstraints	MA_RequirementConstraintsType	Optional
Description	Indicates constraints on the Action. The constraint type used here is common to all Requirement types: Effect, Action, Task, [Capability]Command, Response. Requirement constraints can be 1) given in a [Requirement] message, 2) overridden as a planning input in a [Requirement]PlanCommand message, 3) further refined/overridden during plan creation and reported in a [Requirement]Plan message to inform subsequent planning or execution. See sibling ActionType element annotation for an overall description of Action structure.	
ActionGuidance	RequirementGuidanceType	Optional
Description	Indicates guidance on planning and C2 of the Action.	
TargetObject	IdentityKindInstanceType	Repeated
Description	Indicates the target of the Action; the object the Action will be done to or for. If omitted, the Action places no explicit limitation on which TargetObject it can be done to. See sibling ActionType element annotation for an overall description of Action structure. Note that the term "target" is used in a general sense. For some Requirement types, a more suitable term might be "subject", "point", "location", etc. For example, the "target" of a COVER Action could be a blue/friendly System.	
TargetObjectConstraints	RequirementTargetConstraintsType	Optional
Description	Indicates constraints "on" the TargetObject that must be satisfied before the Action can be done to or for it. See sibling ActionType element annotation for an overall description of Effect structure.	
SecondaryObject	IdentityKindInstanceType	Repeated
Description	Indicates a thing the sibling TargetObject must act on/against/toward to make the	

	Action applicable. See sibling ActionType element annotation for an overall description of Action structure.	
Metadata	RequirementMetadataType	Optional
Description	Indicates traceability and other metadata associated with the Action.	

Table A-4-203: C2 Interface MA_ActionMT - MessageData UCI Extension Field

4.1.51 MA_COP_ConfigurationSettingsCommandStatusMT UCI Extension

MA_COP_ConfigurationSettingsCommandStatusMT	
Description	Command status message in response to MA_COP_ConfigurationSettingsCommand.UCI_PRIMITIVE: Command-2. See the XSD File for more info
Ext. Fields	MessageData : MA_COP_ConfigurationSettingsCommandStatusMDT

Table A-4-204: C2 Interface MA_COP_ConfigurationSettingsCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_COP_ConfigurationSettingsCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-205: C2 Interface MA_COP_ConfigurationSettingsCommandStatusMT - MessageData UCI Extension Field

4.1.52 MA_COP_ConfigurationSettingsRequestStatusMT UCI Extension

MA_COP_ConfigurationSettingsRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type.

	See the XSD File for more info
Ext. Fields	MessageData : MA_COP_ConfigurationSettingsRequestStatusMDT

Table A-4-206: C2 Interface MA_COP_ConfigurationSettingsRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_COP_ConfigurationSettingsRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConfigurationSettings	MA_COP_ConfigurationSettingsMDT	Optional
Description	The configuration settings	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-207: C2 Interface MA_COP_ConfigurationSettingsRequestStatusMT - MessageData UCI Extension Field

4.1.53 MA_COP_ConfigurationSettingsCommandMT UCI Extension

MA_COP_ConfigurationSettingsCommandMT	
Description	Command message to adjust the configuration settings for the COP among ACPs.UCI_PRIMITIVE: Command-2. See the XSD File for more info
Ext. Fields	MessageData : MA_COP_ConfigurationSettingsCommandMDT

Table A-4-208: C2 Interface MA_COP_ConfigurationSettingsCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_COP_ConfigurationSettingsCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage

ApplicableToIDs	MA_PackageSystemType	Required
Description	Indicates the ID of the Package or System being configured.	
COP_LeaderID	SystemID_Type	Repeated
Description	Indicates a prioritized list of unique SystemIDs for leaders for the COP. If not specified, no change to leader requested	
RequestAuthority	MA_COP_ConfigurationAuthorityEnum	Required
Description	Indicates the priority of the request being made. Generally C2 will set this to ORDER and the COP lead will set this to REQUEST	
Configuration	MA_COP_ConfigurationType	Repeated
Description	A list of configuration items.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-209: C2 Interface MA_COP_ConfigurationSettingsCommandMT - MessageData UCI Extension Field

4.1.54 MA_COP_ConfigurationSettingsRequestMT UCI Extension

MA_COP_ConfigurationSettingsRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_COP_ConfigurationSettingsRequestMDT

Table A-4-210: C2 Interface MA_COP_ConfigurationSettingsRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_COP_ConfigurationSettingsRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApplicableToIDs	MA_PackageSystemType	Repeated
Description	Indicates the ID of the Package or System that should respond to the request.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW	

	request, an UPDATE to a request, or a CANCEL of a request.
--	--

Table A-4-211: C2 Interface MA_COP_ConfigurationSettingsRequestMT - MessageData UCI Extension Field

4.1.55 MA_DesignationRequestMT UCI Extension

MA_DesignationRequestMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_DesignationRequestMDT

Table A-4-212: C2 Interface MA_DesignationRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DesignationRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
DesignationData	MA_DesignationDataType	Repeated
Description	Indicates the data for one or more designations.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-213: C2 Interface MA_DesignationRequestMT - MessageData UCI Extension Field

4.1.56 MA_DesignationMT UCI Extension

MA_DesignationMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_DesignationMDT

Table A-4-214: C2 Interface MA_DesignationMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_DesignationMDT
Message Structure	

Field Name	Field Type	Field Usage
DesignationData	MA_DesignationDataType	Repeated
Description	Indicates the data of one or more designations.	

Table A-4-215: C2 Interface MA_DesignationMT - MessageData UCI Extension Field

4.1.57 MA_DesignationRequestStatusMT UCI Extension

MA_DesignationRequestStatusMT	
Description	Reports the current status of a Designation. See the XSD File for more info
Ext. Fields	MessageData : MA_DesignationRequestStatusMDT

Table A-4-216: C2 Interface MA_DesignationRequestStatusMT UCI Extension

MessageData		
Description	See the annotation in the associated message for an overall description of the message and this type.	
Base Type	MA_DesignationRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
DesignationDataStatus	DesignationDataStatusType	Repeated
Description	Indicates the status for one or more designations.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-217: C2 Interface MA_DesignationRequestStatusMT - MessageData UCI Extension Field

4.1.58 MA_AcceptableLevelOfRiskStatusMT UCI Extension

MA_AcceptableLevelOfRiskStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_AcceptableLevelOfRiskStatusMDT

Table A-4-218: C2 Interface MA_AcceptableLevelOfRiskStatusMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.

Base Type	MA_AcceptableLevelOfRiskStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
AcceptableRiskSetting	MA_AcceptableLevelOfRiskEnum	Required
Description	This is the active acceptable level of risk permitted at the package or vehicle level, which applies to all tasks and actions for the vehicle/package while active.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond for the Package or individual ACPs as needed.	
SurvivabilityRiskLevelID	SurvivabilityRiskLevelID_Type	Optional
Description	The unique identifier for the active Survivability Risk Level.	

Table A-4-219: C2 Interface MA_AcceptableLevelOfRiskStatusMT - MessageData UCI Extension Field

4.1.59 MA_CapabilitySetMT UCI Extension

MA_CapabilitySetMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_CapabilitySetMDT

Table A-4-220: C2 Interface MA_CapabilitySetMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CapabilitySetMDT	
Message Structure		
Field Name	Field Type	Field Usage
CapabilitySetID	MA_CapabilitySetID_Type	Required
Description	Indicates the unique ID of the CapabilitySet.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates a Capability that exists in the set.	
ApplicableSystemID	SystemID_Type	Optional
Description	Indicates the System that the CapabilitySet is relevant to.	
MissionPlanID	MissionPlanID_Type	Optional
Description	Indicates the MissionPlan that the CapabilitySet is relevant to.	
MissionID	MissionID_Type	Optional
Description	Indicates the Mission that the CapabilitySet is relevant to.	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional

Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.
-------------	--

Table A-4-221: C2 Interface MA_CapabilitySetMT - MessageData UCI Extension Field

4.1.60 MA_CAP_ExecutionStatusReportMT UCI Extension

MA_CAP_ExecutionStatusReportMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_CAP_ExecutionStatusReportMDT

Table A-4-222: C2 Interface MA_CAP_ExecutionStatusReportMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CAP_ExecutionStatusReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
PackageID	PackageID_Type	Optional
Description	The ID of the package executing the CAP.	
PackageRequirementID	RequirementInstanceID_ChoiceType	Repeated
Description	Contains the unique ID(s) of the package-level requirements associated with the ongoing CAP activity. This will typically be a package-level PROTECT_CAP Action and/or a package-level CAP Task.	
AOI_Coverage	PercentType	Optional
Description	Percent of the Area of Interest (AOI) currently covered by any vehicle's sensors.	
PlanMetrics	MA_CAP_PlanMetrics_Type	Optional
Description	Sensor coverage and time gap metrics of the planned CAP routes over the next racetrack cycle.	
ExecutionStatus	MA_CAP_ExecutionStatus_Type	Repeated
Description	Contains a list of CAP statuses from vehicles executing the CAP.	

Table A-4-223: C2 Interface MA_CAP_ExecutionStatusReportMT - MessageData UCI Extension Field

4.1.61 MA_SystemsNeededRequestMT UCI Extension

MA_SystemsNeededRequestMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info

Ext. Fields	MessageData : MA_SystemsNeededRequestMDT
--------------------	--

Table A-4-224: C2 Interface MA_SystemsNeededRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_SystemsNeededRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
Candidate	MA_SystemCandidateChoiceType	Required
Description	Indicates a list of possible systems that could be used to solve the RequiredTasks.	
ProposedRequirements	RequirementAllocationCommandType	Required
Description	Indicates a proposed Requirement for the System's needed analysis request.	
AssociationConstraint	RequirementAssociationConstraintType	Repeated
Description	Indicates an association between Requirements that is a constraint on how they are allocated and planned.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-225: C2 Interface MA_SystemsNeededRequestMT - MessageData UCI Extension Field

4.1.62 MA_SystemsNeededRequestStatusMT UCI Extension

MA_SystemsNeededRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_SystemsNeededRequestStatusMDT

Table A-4-226: C2 Interface MA_SystemsNeededRequestStatusMT UCI Extension

MessageData		
Description	Indicates the minimum number of systems needed to complete a desired set of tasks.	
Base Type	MA_SystemsNeededRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
IncompletePlanning	IncompleteProcessingType	Repeated

	Description	Indicates planning items that failed to complete. It is used to indicate specific details about why something failed to plan.
Option	SystemsNeededOptionType	Repeated
	Description	Provides results of the command that was performed. Indicates a specific option for satisfying the tasks specified.
RequestID	RequestID_Type	Required
	Description	Indicates the unique ID of the request message corresponding to this status message.
RequestProcessingState	RequestProcessingStateEnum	Required
	Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.
RequestProcessingStateReason	CannotComplyType	Optional
	Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.

Table A-4-227: C2 Interface MA_SystemsNeededRequestStatusMT - MessageData UCI Extension Field

4.1.63 MA_MissionPlanActivationCommandMT UCI Extension

MA_MissionPlanActivationCommandMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	OpPlanID : MA_OpPlanID_Type ApplicableToIDs : MA_PackageSystemType ByExecutionPlanSet : MA_ExecutionPlanSetActivationType MessageData : MA_MissionPlanActivationCommandMDT ActivationDetails : MA_MissionPlanActivationDetailsType Applicability : MA_PlanApplicabilityType OpPlan : MA_OpPlanActivationType Command : MA_MissionPlanActivationCommandType

Table A-4-228: C2 Interface MA_MissionPlanActivationCommandMT UCI Extension

OpPlanID		
Description	Indicates the unique ID of the TaskPlan to perform the sibling activation command on.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional

Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-229: C2 Interface MA_MissionPlanActivationCommandMT - OpPlanID UCI Extension Field

ApplicableToIDs		
Description	Indicates the unique ID of the System (e.g. aircraft, ground-based sensor, ship, satellite, site, etc.) or Package whose Capabilities, performance, position, etc. the plan is based on. If the plan is a fully detailed one that can be activated and executed, this element indicates the System intended/responsible for executing the plan and producing the intended effects. See annotations in sibling element PlannedForID which provide additional context.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-230: C2 Interface MA_MissionPlanActivationCommandMT - ApplicableToIDs UCI Extension Field

ByExecutionPlanSet		
Description	Indicates simultaneous activation of all sub-*Plans (ActivityPlan, RoutePlan for example) of an *ExecutionPlanSet into the same activation state.	
Base Type	MA_ExecutionPlanSetActivationType	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPlanSetID	ExecutionPlanSetID_Type	Required
Description	Indicates the unique ID of the execution plan set.	
CommandType	PlanActivationCommandEnum	Required

Description	Indicates the activation to perform on the associated execution plan set.
-------------	---

Table A-4-231: C2 Interface MA_MissionPlanActivationCommandMT - ByExecutionPlanSet UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanActivationCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	MissionPlanActivationCommandID_Type	Required
Description	The ID of the Mission Plan Activation Command. Used to reference the command when providing status.	
ApprovalManagementCommandID	CommandID_Type	Repeated
Description	Indicates the command(s) that initiated the Activation Approvals for the *Plans identified in the sibling Command element. The approval status can be found by locating the corresponding MissionPlanActivationApprovalStatus with the ID identified here. The ActivationCommand identified in the sibling Command\ActivationDetails should be verified against the ActivationType that is identified in the associated MissionPlanActivationApprovalCommand.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	
Command	MA_MissionPlanActivationCommandType	Repeated
Description	Indicates command or commands to change the activation state of a MissionPlan and/or it subplans or subordinate plans. If more than one instance of this element is given, each should correspond to a different MissionPlanID. For example, if the intent is to transition from one MissionPlan to another, the new MissionPlan can be activated in one instance and the old MissionPlan can be deactivated in another instance.	
Applicability	MA_PlanApplicabilityType	Optional
Description	Indicates the System or Systems who are being commanded to activate a specified plan.	

Table A-4-232: C2 Interface MA_MissionPlanActivationCommandMT - MessageData UCI Extension Field

ActivationDetails		
Description	Indicates the commanded activation details.	
Base Type	MA_MissionPlanActivationDetailsType	
Message Structure		
Field Name	Field Type	Field Usage
ByMissionPlan	MissionPlanActivationType	Required

Description	Indicates simultaneous activation of all sub-*Plans (RoutePlan, RouteActivityPlan for example) of a MissionPlan into the same activation state.	
BySubPlan	MA_MissionPlanSubplanActivationType	Required
Description	Indicates activation by sub-*Plan (RoutePlan or OrbitPlan for example) of the MissionPlan, with potentially different states for each.	
ByExecutionPlanSet	MA_ExecutionPlanSetActivationType	Required
Description	Indicates simultaneous activation of all sub-*Plans (ActivityPlan, RoutePlan for example) of an *ExecutionPlanSet into the same activation state.	

Table A-4-233: C2 Interface MA_MissionPlanActivationCommandMT - ActivationDetails UCI Extension Field

Applicability		
Description	Indicates the System or Systems who are being commanded to activate a specified plan.	
Base Type	MA_PlanApplicabilityType	
Message Structure		
Field Name	Field Type	Field Usage
PlannedForID	SystemID_Type	Optional
Description	Indicates the System which is the intended user of the plan. This type can have multiple meanings, but primarily enables multiple systems, possibly at different levels of warfare or C2 hierarchy levels, to maintain independent plans for the same System identified in the sibling ApplicableToID element. For instance, during planning at the operational level of warfare, a non-tactical planning service may create and simulate execution of plans internally. Such plans would identify the operational level System as the PlannedFor System; they would never be activated or executed by a real world tactical System. Alternatively, the operational level System could have a tactical planning service that is functionally capable and responsible for creating fully detailed plans that can be activated and executed by real world tactical Systems. Such a tactical planning service could be used even if the operational level System does not have control authority over the tactical System at the time the plan is created. Such plans would identify the tactical level System as the PlannedFor System. As a final example, a plan which is intended to be used by the same System which produces its intended effects would have a common SystemID between the sibling PlannedForID and ApplicableToID elements. This element does not replace existing approval policies, authorization or control status and therefore does not automatically imply that the PlannedFor System has any kind of authority over the receiving system.	
ApplicableToIDs	MA_PackageSystemType	Required
Description	Indicates the unique ID of the System (e.g. aircraft, ground-based sensor, ship, satellite, site, etc.) or Package whose Capabilities, performance, position, etc. the plan	

	is based on. If the plan is a fully detailed one that can be activated and executed, this element indicates the System intended/responsible for executing the plan and producing the intended effects. See annotations in sibling element PlannedForID which provide additional context.
--	--

Table A-4-234: C2 Interface MA_MissionPlanActivationCommandMT - Applicability UCI Extension Field

OpPlan		
Description	Indicates commanded details for activation of an OpPlan.	
Base Type	MA_OpPlanActivationType	
Message Structure		
Field Name	Field Type	Field Usage
OpPlanID	MA_OpPlanID_Type	Required
Description	Indicates the unique ID of the TaskPlan to perform the sibling activation command on.	
CommandType	PlanActivationCommandEnum	Required
Description	Indicates the activation to perform on the associated TaskPlan.	

Table A-4-235: C2 Interface MA_MissionPlanActivationCommandMT - OpPlan UCI Extension Field

Command		
Description	Indicates command or commands to change the activation state of a MissionPlan and/or it subplans or subordinate plans. If more than one instance of this element is given, each should correspond to a different MissionPlanID. For example, if the intent is to transition from one MissionPlan to another, the new MissionPlan can be activated in one instance and the old MissionPlan can be deactivated in another instance.	
Base Type	MA_MissionPlanActivationCommandType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	Indicates the unique ID of the MissionPlan whose commanded activation state or states are summarized in the sibling element.	
ActivationDetails	MA_MissionPlanActivationDetailsType	Required
Description	Indicates the commanded activation details.	

Table A-4-236: C2 Interface MA_MissionPlanActivationCommandMT - Command UCI Extension Field

4.1.64 MA_ApprovalAuthorityMT UCI Extension

MA_ApprovalAuthorityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ApprovalAuthorityMDT ApplicableIDs : MA_PackageSystemType

Table A-4-237: C2 Interface MA_ApprovalAuthorityMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ApprovalAuthorityMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApprovalAuthorityID	ApprovalAuthorityID_Type	Required
Description	Indicates associated Approval Authority identifier for applicable system and approval policy.	
ApplicableIDs	MA_PackageSystemType	Repeated
Description	Indicates to which system this Approval Authority applies.	
SystemApprovalPolicy	SystemApprovalPolicyType	Repeated
Description	Indicates an ApprovalPolicy and one or more approval authorities ("approvers").	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-238: C2 Interface MA_ApprovalAuthorityMT - MessageData UCI Extension Field

ApplicableIDs		
Description	Indicates to which system this Approval Authority applies.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-239: C2 Interface MA_ApprovalAuthorityMT - ApplicableIDs UCI Extension Field

4.1.65 MA_ResponseMT UCI Extension

MA_ResponseMT

Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ResponseMDT

Table A-4-240: C2 Interface MA_ResponseMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ResponseMDT	
Message Structure		
Field Name	Field Type	Field Usage
ResponseID	ResponseID_Type	Required
Description	Indicates the unique ID of the Response. Minor updates to the Response can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new instance with a different child UUID value.	
ResponseType	ResponseTypeEnum	Repeated
Description	Indicates the types of Response options included in the message. List size for this element is based on "Select All That Apply" condition.	
ResponseManagementConstraints	RequirementConstraintsType	Optional
Description	Indicates monitoring constraints on the Response. The constraint type used here is common to all Requirement types: Effect, Action, Task, [Capability]Command, Response. Requirement constraints can be 1) given in a [Requirement] message, 2) overridden as a planning input in a [Requirement]PlanCommand message, 3) further refined/overridden during plan creation and reported in a [Requirement]Plan message to inform subsequent planning or execution. See sibling Option element annotation for an overall description of Response structure. Constraints given here aren't conveyed to instantiated Response options for a particular triggering event. The constraints given here apply to Response management (planning, allocation and trigger monitoring prior to a triggering event). Constraints to apply to instantiated Response options, if any, are given elsewhere in the message.	
ResponseManagementGuidance	RequirementGuidanceType	Optional
Description	Indicates guidance on planning and C2 of the Response.	
ResponsePlurality	MA_TaskPluralityEnum	Optional
Description	Indicates whether the response applies a single entity or as a joint condition. A joint condition implies condisation of the response trigger and activation of the response by all associated entities.	

Option	MA_ResponseOptionDetailsType	Repeated
Description	Indicates an Option of the Response. Responses are designed to be flexible. A Response is a set of prioritized Options to address an anticipated triggering event, events or event sequence in the battlespace. Responses are allocated to Systems via a ResponsePlan. When a ResponsePlan is activated, monitoring for the triggering events in the Options begins. When a triggering event happens, the applicable Option(s) are evaluated.	
RequirementsTemplate	MA_RequirementsTemplateType	Repeated
Description	The sibling Option element associates triggering events with a desired Response one of which is to use this element, a Requirements template, to generate or change one or more Requirements messages/objects (Effect, Action, Task, [Capability]Command). An instance of this element is a RequirementsTemplate; it indicates the types of Requirements to generate or update and their details. Each RequirementsTemplate has a unique ID and therefore can be used for multiple Options.	
Metadata	RequirementMetadataType	Optional
Description	Indicates traceability and other metadata associated with the Response.	

Table A-4-241: C2 Interface MA_ResponseMT - MessageData UCI Extension Field

4.1.66 MA_ActionPlanMT UCI Extension

MA_ActionPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ActionPlanMDT

Table A-4-242: C2 Interface MA_ActionPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_ActionPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
ActionPlanID	ActionPlanID_Type	Required
Description	Indicates a unique ID assigned to the ActionPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	ActionPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which this ActionPlan originated from.	
Plan	MA_ActionPlanType	Required
Description	Indicates the details of the ActionPlan.	
ForPlanningUseOnly	boolean	Required

Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	ActionPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-243: C2 Interface MA_ActionPlanMT - MessageData UCI Extension Field

4.1.67 MA_ActivityPlanMT UCI Extension

MA_ActivityPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ActivityPlanMDT

Table A-4-244: C2 Interface MA_ActivityPlanMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActivityPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlanID	ActivityPlanID_Type	Required
Description	Indicates a unique ID assigned to the ActivityPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	ActivityPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which this ActivityPlan originated from.	
Plan	MA_ActivityPlanType	Required
Description	Indicates the details of the ActivityPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is a used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	ActivityPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-245: C2 Interface MA_ActivityPlanMT - MessageData UCI Extension Field

4.1.68 MA_RouteActivityPlanMT UCI Extension

MA_RouteActivityPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RouteActivityPlanMDT

Table A-4-246: C2 Interface MA_RouteActivityPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_RouteActivityPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
RouteActivityPlanID	RouteActivityPlanID_Type	Required
Description	Indicates a unique ID assigned to the RouteActivityPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	RouteActivityPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the RouteActivityPlan originated from.	
Plan	MA_RouteActivityPlanType	Required
Description	Indicates the details of the RouteActivityPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	RouteActivityPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-247: C2 Interface MA_RouteActivityPlanMT - MessageData UCI Extension Field

4.1.69 MA_AssessmentRequestMT UCI Extension

MA_AssessmentRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info

Ext. Fields	MessageData : MA_AssessmentRequestMDT
	Category : MA_AssessmentRequestType

Table A-4-248: C2 Interface MA_AssessmentRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_AssessmentRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
AnalysisRouteID	AnalysisRouteID_Type	Optional
Description	This element indicates the AnalysisRoute to use when performing the Assessment specified in sibling Category.	
RequestFrequencyType	RepeatEnum	Required
Description	Indicates whether this request for assessment is a request for a single reply, or a request for periodic assessments with a corresponding request to cease periodic assessments.	
RequestFrequencyPeriod	DurationType	Optional
Description	If requesting periodic assessments, this field specifies the amount of time that should elapse between the periodic assessments, i.e. the repetition time interval of the assessment.	
ResultsInAssessmentMessage	boolean	Required
Description	If TRUE this element specifies that the response to this message should be an AssessmentRequest and an Assessment message. If FALSE the assessment data that is generated should be bundled inside the response. In some cases there isn't a native message and the results can only be reported via AssessmentRequestStatus.	
Category	MA_AssessmentRequestType	Required
Description	Indicates the assessment category for requested assessment.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-249: C2 Interface MA_AssessmentRequestMT - MessageData UCI Extension Field

Category		
Description	Indicates the assessment category for requested assessment.	
Base Type	MA_AssessmentRequestType	
Message Structure		
Field Name	Field Type	Field Usage

CommPointingPlan	CommPointingPlanRequestType	Required
Description	This element is used to specify that communication requests should be assessed, and a Pointing Plan should be generated based on the requests. The native message is CommPointingPlan.	
CapabilityUtilization	CapabilityUtilizationRequestType	Required
Description	This assessment type is utilized to assess predicted Capability utilization along a mission planned route.	
RouteDeconfliction	RouteDeconflictionRequestType	Required
Description	This element is used to specify that an assessment of the conflicts along a route is requested.	
RouteVulnerabilityMetrics	RouteVulnerabilityMetricsRequestType	Required
Description	This element is used to specify that detection metrics need to be recomputed along a route due to threats. The data generated for detection metrics are different from threat assessments because detection metrics break down the exposure numbers to a much greater detail in order to generate a route than a threat assessment will.	
RouteThreatAssessment	ThreatAssessmentRequestType	Required
Description	This element is used to specify that an assessment of the threat exposure along a route is requested.	
TargetMobility	TargetMobilityRequestType	Required
Description	This element is used to specify that an assessment of the possible zone an Entity could have moved within some given period of time.	
VehicleThreatAssessment	VehicleThreatAssessmentRequestType	Required
Description	This element is used to specify that a threat assessment is being requested for the current position of a vehicle.	
ThreatNominationAssessment	ThreatNominationAssessmentRequestType	Required
Description	This element is used to specify that a threat nomination assessment is being requested for the given mission plans and entities.	
AchievabilityAssessment	AchievabilityAssessmentRequestPET	Required
Description	This element is used to specify that achievability assessment is being requested for the given type of AchievabilityRequest.	
CoverageAssessment	MA_CoverageAssessmentRequestType	Required
Description	This element is used to specify that assessment is being requested for sensor coverage.	

Table A-4-250: C2 Interface MA_AssessmentRequestMT - Category UCI Extension Field

4.1.70 MA_AssessmentRequestStatusMT UCI Extension

MA_AssessmentRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	Assessment : MA_AssessmentType

MessageData : MA_AssessmentRequestStatusMDT

Table A-4-251: C2 Interface MA_AssessmentRequestStatusMT UCI Extension

Assessment		
Description	This element indicates the results of the assessment. It is optional based on whether the assessment request specified that the response should result in native message.	
Base Type	MA_AssessmentType	
Message Structure		
Field Name	Field Type	Field Usage
CommPointingPlan	CommPointingPlanAssessmentType	Required
Description	This element defines the response to a communications pointing plan assessment request.	
CapabilityUtilization	CapabilityUtilizationAssessmentType	Required
Description	This assessment type is utilized to assess predicted capability utilization along a mission planned route.	
RouteDeconfliction	RouteDeconflictionAssessmentType	Required
Description	This element defines the response to a route deconfliction assessment request.	
RouteVulnerabilityMetrics	RouteVulnerabilityMetricsAssessmentType	Required
Description	Indicates the results of assessment of vulnerability along a route.	
RouteThreatAssessment	RouteThreatAssessmentType	Required
Description	Indicates the results of assessment of threats along a route.	
TargetMobility	TargetMobilityAssessmentType	Required
Description	This element defines the response to a target mobility assessment request.	
VehicleThreatAssessment	VehicleThreatAssessmentType	Required
Description	This element defines the response to a vehicle threat assessment request.	
ThreatNominationAssessment	ThreatNominationAssessmentType	Required
Description	This element defines the response to a threat nomination assessment.	
AchievabilityAssessment	AchievabilityAssessmentPET	Required
Description	This element defines the response to an achievability assessment.	
CoverageAssessment	MA_CoverageAssessmentType	Required
Description	This element defines the response to a coverage assessment.	

Table A-4-252: C2 Interface MA_AssessmentRequestStatusMT - Assessment UCI Extension Field

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_AssessmentRequestStatusMDT
Message Structure	

Field Name	Field Type	Field Usage
CompletionStatus	CompletionStatusType	Optional
Description	Intermediate status information for an assessment. Typically populated when sending periodic statuses of PROCESSING, but can also store start and finish times for this assessment.	
Assessment	MA_AssessmentType	Optional
Description	This element indicates the results of the assessment. It is optional based on whether the assessment request specified that the response should result in native message.	
IncompleteAssessment	IncompleteProcessingType	Repeated
Description	This element indicates any assessments that failed to complete. It is used to indicate details about why a specific assessment target failed to process.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-253: C2 Interface MA_AssessmentRequestStatusMT - MessageData UCI Extension Field

4.1.71 MA_AssessmentMT UCI Extension

MA_AssessmentMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_AssessmentMDT Assessment : MA_AssessmentType

Table A-4-254: C2 Interface MA_AssessmentMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_AssessmentMDT	
Message Structure		
Field Name	Field Type	Field Usage

AssessmentID	AssessmentID_Type	Required
Description	This element references the assessment ID.	
AssessmentRequestID	RequestID_Type	Optional
Description	This element is required when the message is generated in response to an AssessmentRequest. It is omitted when the message is generated unsolicited.	
AnalysisRouteID	AnalysisRouteID_Type	Optional
Description	This element indicates the AnalysisRoute that was used to perform the assessment.	
Assessment	MA_AssessmentType	Required
Description	This element indicates the results of the assessment.	

Table A-4-255: C2 Interface MA_AssessmentMT - MessageData UCI Extension Field

Assessment		
Description	This element indicates the results of the assessment.	
Base Type	MA_AssessmentType	
Message Structure		
Field Name	Field Type	Field Usage
CommPointingPlan	CommPointingPlanAssessmentType	Required
Description	This element defines the response to a communications pointing plan assessment request.	
CapabilityUtilization	CapabilityUtilizationAssessmentType	Required
Description	This assessment type is utilized to assess predicted capability utilization along a mission planned route.	
RouteDeconfliction	RouteDeconflictionAssessmentType	Required
Description	This element defines the response to a route deconfliction assessment request.	
RouteVulnerabilityMetrics	RouteVulnerabilityMetricsAssessmentType	Required
Description	Indicates the results of assessment of vulnerability along a route.	
RouteThreatAssessment	RouteThreatAssessmentType	Required
Description	Indicates the results of assessment of threats along a route.	
TargetMobility	TargetMobilityAssessmentType	Required
Description	This element defines the response to a target mobility assessment request.	
VehicleThreatAssessment	VehicleThreatAssessmentType	Required
Description	This element defines the response to a vehicle threat assessment request.	
ThreatNominationAssessment	ThreatNominationAssessmentType	Required
Description	This element defines the response to a threat nomination assessment.	
AchievabilityAssessment	AchievabilityAssessmentPET	Required
Description	This element defines the response to an achievability assessment.	
CoverageAssessment	MA_CoverageAssessmentType	Required
Description	This element defines the response to a coverage assessment.	

Table A-4-256: C2 Interface MA_AssessmentMT - Assessment UCI Extension Field

4.1.72 MA_FlightCapabilityStatusMT UCI Extension

MA_FlightCapabilityStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	Capability : MA_FlightCapabilityType MessageData : MA_FlightCapabilityMDT

Table A-4-257: C2 Interface MA_FlightCapabilityStatusMT UCI Extension

Capability		
Description	Provides a list of the specific Flight Capabilities as defined by the FlightCapabilityEnum.	
Base Type	MA_FlightCapabilityType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityType	MA_FlightCapabilityEnum	Repeated
Description	Indicates the type of Flight capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
FlightCapabilityPerformanceProfile	MA_FlightCapabilityPerformanceProfileType	Optional
Description	Provides per-control mode performance parameters. Enables autonomy commands to properly conform to envelope limits or limit summary values before sending a FlightCommand to the vehicle.	
AcceptedInterface	CapabilityControlInterfacesEnum	Repeated
Description	Indicates an accepted control interface for the Capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CommsRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) communications are required to use the Capability. Omitted is equivalent to FALSE. For example, an unmanned system with no onboard storage would require communications to disseminate the outputs of the Capability.	
CapabilityID	CapabilityID_Type	Required
Description	Indicates the unique ID of this Capability. This ID is used to invoke the Capability via Command messages, report its activity via Activity messages, etc.	
DomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates the domain/environment which the Capability is employed from and the "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
ProductOutput	ProductOutputType	Repeated

Description	Indicates a Product that can be an output of the Capability.	
PackageOperation	PackageOperationEnum	Optional
Description	Indicates if and how the operation of the Capability can be coordinated with a partner Capability of another System in a multi-System Package. Omitting this element is equivalent to the enumerate NO_PACKAGE_OPERATION. The actual Package configuration including per-Capability partnering between Systems is given in the PackageStatus message. For example, a System that can perform cooperative geolocation could advertise with this element in the ESM_Capability message. A System that can navigate in a swarm with other Systems could advertise with this element in the FlightCapability message.	

Table A-4-258: C2 Interface MA_FlightCapabilityStatusMT - Capability UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_FlightCapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_FlightCapabilityType	Repeated
Description	Provides a list of the specific Flight Capabilities as defined by the FlightCapabilityEnum.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.	

Table A-4-259: C2 Interface MA_FlightCapabilityStatusMT - MessageData UCI Extension Field

4.1.73 MA_COP_ConfigurationSettingsMT UCI Extension

MA_COP_ConfigurationSettingsMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_COP_ConfigurationSettingsMDT

Table A-4-260: C2 Interface MA_COP_ConfigurationSettingsMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.

Base Type	MA_COP_ConfigurationSettingsMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApplicableToIDs	MA_PackageSystemType	Required
Description	Indicates the ID of the Package or System with the COP settings.	
COP_LeaderID	SystemID_Type	Optional
Description	Indicates the unique SystemID of the current leader of the COP.	
COP_LeaderBackupID	SystemID_Type	Repeated
Description	Indicates the unique SystemIDs of the backup leaders of the COP.	
COP_FusionCapable	boolean	Required
Description	Indicates if the COP is capable of fusing tracks.	
Configuration	MA_COP_ConfigurationType	Repeated
Description	A list of the configuration items.	

Table A-4-261: C2 Interface MA_COP_ConfigurationSettingsMT - MessageData UCI Extension Field

4.1.74 MA_StrikeActivityMT UCI Extension

MA_StrikeActivityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	ActiveWeaponHSA_CSA : MA_HSA_CSA_Type Direction : MA_DirectionChoiceType MunitionActive : MA_MunitionActiveType MessageData : MA_StrikeActivityMDT ActiveWeaponState : MA_ActiveWeaponStateEnum Activity : MA_StrikeActivityType Course : MA_DirectionReferenceType Heading : MA_DirectionReferenceType Reference : MA_HeadingReferenceEnum

Table A-4-262: C2 Interface MA_StrikeActivityMT UCI Extension

ActiveWeaponHSA_CSA	
Description	Provides the heading/course, speed, and altitude of the munition while the Activity is ACTIVE_*.
Base Type	MA_HSA_CSA_Type
Message Structure	

Field Name	Field Type	Field Usage
Altitude	AltitudeReferenceType	Optional
Description	Altitude hold value to be achieved and reference to altitude measurement source.	
Speed	PathSegmentSpeedType	Optional
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Direction	MA_DirectionChoiceType	Optional
Description	Defines heading or course type and reference to hold	

Table A-4-263: C2 Interface MA_StrikeActivityMT - ActiveWeaponHSA_CSA UCI Extension Field

Direction		
Description	Defines heading or course type and reference to hold	
Base Type	MA_DirectionChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
Heading	MA_DirectionReferenceType	Optional
Description	Defines heading type and reference to hold.	
Course	MA_DirectionReferenceType	Optional
Description	Defines course type and reference to hold.	

Table A-4-264: C2 Interface MA_StrikeActivityMT - Direction UCI Extension Field

MunitionActive		
Description	Data regarding the munition while it is active or in flight.	
Base Type	MA_MunitionActiveType	
Message Structure		
Field Name	Field Type	Field Usage
ActiveWeaponState	MA_ActiveWeaponStateEnum	Repeated
Description	Provides further munition state data detail if the Activity is ENABLED, ACTIVE_* or COMPLETED as reported by the ActivityState. This message can be omitted if ActivityState is DISABLED, FAILED or DELETED. List size for this element is based on "Select All That Apply" condition.	
ActiveWeaponHSA_CSA	MA_HSA_CSA_Type	Optional
Description	Provides the heading/course, speed, and altitude of the munition while the Activity is ACTIVE_*.	

Table A-4-265: C2 Interface MA_StrikeActivityMT - MunitionActive UCI Extension Field

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_StrikeActivityMDT
Message Structure	

Field Name	Field Type	Field Usage
SubsystemID	SubsystemID_Type	Required
Description	Indicates the Subsystem which hosts the Strike Capabilities whose Activities are given in this message.	
Activity	MA_StrikeActivityType	Repeated
Description	Indicates the dynamic operational characteristics of an Activity of a Strike Capability.	

Table A-4-266: C2 Interface MA_StrikeActivityMT - MessageData UCI Extension Field

ActiveWeaponState	
Description	Provides further munition state data detail if the Activity is ENABLED, ACTIVE_* or COMPLETED as reported by the ActivityState. This message can be omitted if ActivityState is DISABLED, FAILED or DELETED. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_ActiveWeaponStateEnum
Message Structure	
Enumeration Literal	Description
TARGETED	Indicates that a target has been selected and the munition has not been released yet. Report with the ENABLED state generated by ActivityStateEnum.
REQUESTED	Indicates the munition has been requested for release. Report with the ENABLED state generated by ActivityStateEnum.
SEEKER_INACTIVE	Indicates the munition has been released but its local seeker has not been activated. Report with the ACTIVE_* state generated by ActivityStateEnum.
SEEKER_ACTIVE	Indicates the munition has been released and its local seeker has been activated. Report with the ACTIVE_* state generated by ActivityStateEnum.
FUZE_INACTIVE	Indicates the munition has been released but its fuze has not been activated. Report with the ACTIVE_* state generated by ActivityStateEnum.
FUZE_ACTIVE	Indicates the munition has been released and its fuze has been activated. Report with the ACTIVE_* state generated by ActivityStateEnum.
NOT_FULLY_AUTONOMOUS	Indicates the munition has been released not fully autonomous and thus not able to guide without datalink or target destination. Report with the ACTIVE_* state generated by ActivityStateEnum.
FULLY_AUTONOMOUS	Indicates the munition has been released and is fully autonomous and able guide without datalink or target destination. Report with the ACTIVE_* state generated by ActivityStateEnum.
DEFEATED	Indicates the munition has been released and but it has been out maneuvered by the assigned target. Report with the COMPLETED state generated by ActivityStateEnum.
TIMED_OUT	Indicates the munition flight has ended, and it did not intercept the assigned target. Report with the COMPLETED state generated by ActivityStateEnum.
SUCCESS	Indicates the munition flight has ended, and it intercepted the assigned target. Report with the COMPLETED state generated by ActivityStateEnum.

Table A-4-267: C2 Interface MA_StrikeActivityMT - ActiveWeaponState UCI Extension Field

Activity

Description	Indicates the dynamic operational characteristics of an Activity of a Strike Capability.	
Base Type	MA_StrikeActivityType	
Message Structure		
Field Name	Field Type	Field Usage
SelectedForKeyLoad	boolean	Required
Description	Key Load indicates the store has been put into a state where it is ready to receive cryptographic keys.	
WeaponArmed	boolean	Required
Description	When true, the weapon is in the armed state.	
ReadyForRelease	boolean	Required
Description	The store has been prepared for launch such that when released the store will function properly.	
SelectedForRelease	boolean	Required
Description	When Master Arm, Release Consent, and any LAR or vehicle Attitude parameters enforced by the carriage are all met, this store will be released.	
SelectedForJettison	boolean	Required
Description	Jettison indicates an ejection from the host system without powering or preparing the delivery vehicle. The store will be in an inert state. When Master Arm, Release Consent, and any LAR or vehicle attitude parameters enforced by the carriage are all met, this store will be jettisoned.	
AssignedTarget	GeoLocatedObjectType	Optional
Description	Indicates the Entity target assigned to the StrikeCapability.	
AO_Code	AO_CodeType	Optional
Description	Indicates the current/set AO/laser PRF and/or PIM code.	
LAR_ID	LAR_ID_Type	Optional
Description	Indicates the ID of the associated LAR and/or LAR_Report associated with the Strike capability.	
ConsentRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) the Activity requires consent to transition from the ENABLED state to an ACTIVE state. This element is required and shall be TRUE for Activities associated with "mother may I" Capabilities.	
ConsentState	ConsentEnum	Optional
Description	Indicates the state of consent for the Activity. This element is required for Activities which require Consent.	
KineticFootprint	EnduranceFootprintType	Optional
Description	The estimated footprint of where the store may fall if released from the current position.	
TargetLockAcquired	boolean	Optional
Description	Indicated whether (TRUE) or not (FALSE) a lock on target has been acquired.	
MunitionActive	MA_MunitionActiveType	Optional

Description	Data regarding the munition while it is active or in flight.	
TimeToRelease	DurationType	Optional
Description	Time interval before strike capability is released.	

Table A-4-268: C2 Interface MA_StrikeActivityMT - Activity UCI Extension Field

Course		
Description	Defines course type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-269: C2 Interface MA_StrikeActivityMT - Course UCI Extension Field

Heading		
Description	Defines heading type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-270: C2 Interface MA_StrikeActivityMT - Heading UCI Extension Field

Reference	
Description	Reference to type of heading or course given.
Base Type	MA_HeadingReferenceEnum
Message Structure	
Enumeration Literal	Description
TRUE_NORTH	Heading value according to Geographic North.
MAGNETIC_NORTH	Heading value according to location where the planet's magnetic field points vertically downward.

Table A-4-271: C2 Interface MA_StrikeActivityMT - Reference UCI Extension Field

4.1.75 MA_OperatorRoleMT UCI Extension

MA_OperatorRoleMT

Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	SystemID : SystemID_Type

Table A-4-272: C2 Interface MA_OperatorRoleMT UCI Extension

SystemID		
Description	Indicates the SystemID that the OperatorRole belongs to. If not populated, it is assumed to be the SystemID specified in the MessageHeader.	
Base Type	SystemID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-273: C2 Interface MA_OperatorRoleMT - SystemID UCI Extension Field

4.1.76 MA_OpPlanMT UCI Extension

MA_OpPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_OpPlanMDT

Table A-4-274: C2 Interface MA_OpPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_OpPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpPlanID	MA_OpPlanID_Type	Required
Description	Indicates a unique ID assigned to the OpPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	MA_OpPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the OpPlan originated from.	

Plan	MA_OpPlanType	Required
Description	Contains the details of the Op* allocation plan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	

Table A-4-275: C2 Interface MA_OpPlanMT - MessageData UCI Extension Field

4.1.77 MA_OpStatusMT UCI Extension

MA_OpStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_OpStatusMDT

Table A-4-276: C2 Interface MA_OpStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ExecutingPackageSystemIDs	MA_PackageSystemType	Required
Description	Identifies the Package ID or ACP System ID whose interpretation of the Op* status is reflected in this message. If Package ID is used, this includes all package member System IDs, so a member ACP's System ID does not need to be separately included.	
CurrentState	OpStateEnum	Required
Description	The state of the schedule (active or inactive) for which the defined schedule timeline applies.	
OpID	OpID_ChoiceType	Required
Description	Indicates the Op* being commanded. Leaving this blank makes the command apply to all Op* IDs	
CommandID	CommandID_Type	Repeated
Description	Indicates the unique ID of the Op* command resulting in this status.	

Table A-4-277: C2 Interface MA_OpStatusMT - MessageData UCI Extension Field

4.1.78 MA_OpCommandMT UCI Extension

MA_OpCommandMT

Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_OpCommandMDT

Table A-4-278: C2 Interface MA_OpCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Command	MA_OpCommandType	Repeated
Description	Indicates an instance of an Op* command. An Op* command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Op* CommandStatus message.	

Table A-4-279: C2 Interface MA_OpCommandMT - MessageData UCI Extension Field

4.1.79 MA_InteroperabilityPolicyMT UCI Extension

MA_InteroperabilityPolicyMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_InteroperabilityPolicyMDT

Table A-4-280: C2 Interface MA_InteroperabilityPolicyMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_InteroperabilityPolicyMDT	
Message Structure		
Field Name	Field Type	Field Usage
InteroperabilityPolicyID	MA_InteroperabilityPolicyID_Type	Required
Description	Indicates the unique ID of the interoperability policy.	
OpPolicy	MA_OpPolicyType	Repeated
Description	Indicates a set of interoperability policies for the handling of OpPoints, OpLines, OpVolumes, etc.	
TimedZone	TimedZoneType	Optional

Description	Indicates the geospatial zone and optionally time/date span or spans when the policy is active. For Op* types, the policy is applicable to 1) the time of Op* instances that lies within the time/date span and 2) the area of Op* instances which falls within the zone. This element supersedes the sibling Expires element.	
Expires	DateTimeType	Optional
Description	Indicates the time and date when the policy expires. The policy is applicable to Op* instances during their existence prior to this time. When the sibling TimedZone element is used, the time spans specified there supersede this element.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of the interoperability policy to specify the source or motivation for this InteroperabilityPolicy such as ATO, ACO, etc.	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-281: C2 Interface MA_InteroperabilityPolicyMT - MessageData UCI Extension Field

4.1.80 MA_AuthorizationMT UCI Extension

MA_AuthorizationMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	UnauthorizedExceptFor : MA_RequirementAuthorizationPermissionsType CapabilityTaxonomy : MA_CapabilityTaxonomyType Opaque : MA_OpaqueEnum AuthorizedExceptFor : MA_RequirementAuthorizationPermissionsType CapabilityCommand : MA_CapabilityTypeEnum CapabilitySettingTypes : MA_CapabilityTypeEnum ByDataActivation : MA_DataActivationAuthorizationType CAP : MA_CAP_CapabilityEnum UnauthorizedExceptFor : MA_PlanActivationPermissionsType AuthorizedExceptFor : MA_PlatformSettingsPermissionsType DataTypes : MA_DataActivationTypeEnum AuthorizedExceptFor : MA_OperatorRequestPermissionsType CommTerminal : MA_CommTerminalEnum ByRequirementExecution : MA_RequirementAuthorizationType ByDataModification : MA_DataModificationAuthorizationType ActivityPlan : MA_ActivityPlanPartsType MessageData : MA_AuthorizationMDT

	AuthorizedArea : MA_AuthorizedZoneChoiceType
	AuthorizedExceptFor : MA_PlanActivationPermissionsType
	ByPlanActivation : MA_PlanAuthorizationType
	AuthorizedExceptFor : MA_DataModificationPermissionsType
	ByPlatformSettingsModification : MA_SettingsModificationAuthorizationType
	UnauthorizedExceptFor : MA_DataModificationPermissionsType
	UnauthorizedExceptFor : MA_OperatorRequestPermissionsType
	RadarAltimeter : MA_RadarAltimeterEnum
	RequestTypes : MA_OperatorRequestTypeEnum
	ByPlanParts : MA_PlanPartsType
	AdditionalPlatformSettingTypes : MA_PlatformSettingPermissionsTypeEnum
	IFF : MA_IFF_Enum
	RequirementTypes : MA_RequirementTaxonomyDetailedType
	UnauthorizedExceptFor : MA_PlatformSettingsPermissionsType
	UserIdentifier : MA_UserType
	ByOperatorRequest : MA_OperatorRequestAuthorizationType

Table A-4-282: C2 Interface MA_AuthorizationMT UCI Extension

UnauthorizedExceptFor		
Description	This element indicates that all requirement types are NOT authorized to be executed with the exception of the enumeration values listed in the permissionsType	
Base Type	MA_RequirementAuthorizationPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
RequirementTypes	MA_RequirementTaxonomyDetailedType	Optional
Description	Indicates the set of Requirements that are authorized or unauthorized to be commanded depending on the parent MA_RequirementAuthorizationType	
AdditionalCapabilityTypes	SupportCapabilityTypeEnum	Repeated
Description	Indicates the set of additional support capabilities that are authorized or unauthorized to be commanded depending on the parent MA_RequirementAuthorizationType. List size for this element is based on "Select All That Apply" condition	

Table A-4-283: C2 Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field

CapabilityTaxonomy		
Description	Indicates specific Capability details/modes that are applicable.	
Base Type	MA_CapabilityTaxonomyType	
Message Structure		
Field Name	Field Type	Field Usage

Action	MA_ActionTypeEnum	Repeated
Description	Indicates an Action Capability. List size for this element is based on "Select All That Apply" condition.	
AirSample	AirSampleCapabilityEnum	Repeated
Description	Indicates an AirSample Capability. List size for this element is based on "Select All That Apply" condition.	
AMTI	AMTI_SpecificDataType	Repeated
Description	Indicates an AMTI Capability and any optional SubCapabilities.	
AO	AO_CapabilityEnum	Repeated
Description	Indicates an AO Capability. List size for this element is based on "Select All That Apply" condition.	
CAP	MA_CAP_CapabilityEnum	Repeated
Description	Indicates a Combat Air Patrol Capability.	
CargoDelivery	CargoDeliverySpecificDataType	Repeated
Description	Indicates a CargoDelivery Capability and any optional SubCapabilities.	
COMINT	COMINT_SpecificDataType	Repeated
Description	Indicates a COMINT Capability and any optional SubCapabilities.	
CommRelay	CommCapabilityEnum	Repeated
Description	Indicates a CommRelay Capability. List size for this element is based on "Select All That Apply" condition.	
CommTerminal	MA_CommTerminalEnum	Optional
Description	Indicates a CommTerminal Capability. List size for this element is based on "Select All That Apply" condition.	
CounterSpace	CS_CapabilityEnum	Optional
Description	Indicates a CounterSpace Capability.	
EA	CapabilityInitiationEnum	Repeated
Description	Indicates an EA Capability. List size for this element is based on "Select All That Apply" condition.	
Effect	EffectTypeEnum	Repeated
Description	Indicates an Effect Capability. List size for this element is based on "Select All That Apply" condition.	
ESM	ESM_SpecificDataType	Repeated
Description	Indicates an ESM Capability and any optional SubCapabilities.	
Flight	FlightCapabilityEnum	Repeated
Description	Indicates a Flight Capability. List size for this element is based on "Select All That Apply" condition.	
IFF	MA_IFF_Enum	Optional
Description	Indicates an IFF Capability. List size for this element is based on "Select All That Apply" condition.	

Opaque	MA_OpaqueEnum	Optional
Description	Indicates an Opaque Capability. List size for this element is based on "Select All That Apply" condition.	
OrbitChange	OrbitChangeCapabilityEnum	Repeated
Description	Indicates an OrbitChange Capability. List size for this element is based on "Select All That Apply" condition.	
OrbitalSurveillance	OrbitalSurveillanceSpecificDataType	Repeated
Description	Indicates an OrbitalSurveillance Capability and any optional SubCapabilities.	
OrbitalSurveillanceSensor	OrbitalSurveillanceSensorCapabilityEnum	Repeated
Description	Indicates an OrbitalSurveillanceSensor Capability. List size for this element is based on "Select All That Apply" condition.	
PO	PO_CapabilityEnum	Repeated
Description	Indicates a PO Capability. List size for this element is based on "Select All That Apply" condition.	
RadarAltimeter	MA_RadarAltimeterEnum	Optional
Description	Indicates a Radar Altimeter Capability. List size for this element is based on "Select All That Apply" condition.	
Refuel	RefuelCapabilityEnum	Repeated
Description	Indicates a Refuel Capability. List size for this element is based on "Select All That Apply" condition.	
Response	ResponseTypeEnum	Repeated
Description	Indicates a Response Capability. List size for this element is based on "Select All That Apply" condition.	
SAR	SAR_SpecificDataType	Repeated
Description	Indicates a SAR Capability and any optional SubCapabilities.	
SMTI	SMTI_SpecificDataType	Repeated
Description	Indicates a SMTI Capability and any optional SubCapabilities.	
Strike	StoreType	Repeated
Description	Indicates a Strike Capability.	
SystemDeployment	SystemDeploymentEnum	Repeated
Description	Indicates a SystemDeployment Capability. List size for this element is based on "Select All That Apply" condition.	
TacticalOrder	TacticalOrderCapabilityEnum	Repeated
Description	Indicates a TacticalOrder Capability. List size for this element is based on "Select All That Apply" condition.	
WeatherRadar	WeatherRadarCapabilityEnum	Optional
Description	Indicates a WeatherRadar Capability.	

Table A-4-284: C2 Interface MA_AuthorizationMT - CapabilityTaxonomy UCI Extension Field

Opaque

Description	Indicates an Opaque Capability. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpaqueEnum
Message Structure	
Enumeration Literal	Description
OPAQUE	Indicates a Opaque Capability.

Table A-4-285: C2 Interface MA_AuthorizationMT - Opaque UCI Extension Field

AuthorizedExceptFor		
Description	This element indicates that all requirement types are authorized to be executed with the exception of the enumeration values listed in the permissionsType	
Base Type	MA_RequirementAuthorizationPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
RequirementTypes	MA_RequirementTaxonomyDetailedType	Optional
Description	Indicates the set of Requirements that are authorized or unauthorized to be commanded depending on the parent MA_RequirementAuthorizationType	
AdditionalCapabilityTypes	SupportCapabilityTypeEnum	Repeated
Description	Indicates the set of additional support capabilities that are authorized or unauthorized to be commanded depending on the parent MA_RequirementAuthorizationType. List size for this element is based on "Select All That Apply" condition	

Table A-4-286: C2 Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field

CapabilityCommand	
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_CapabilityTypeEnum
Message Structure	
Enumeration Literal	Description
ACTION	Indicates an action capability.
AIR_SAMPLE	Indicates an air sampling capability.
AMTI	Indicates an airborne moving target indication (AMTI) capability.
AO	Indicates an active optical capability.
CAP	Indicates a cargo delivery capability.
CARGO_DELIVERY	Indicates a cargo delivery capability.
COMINT	Indicates a Communications Intelligence (COMINT) capability.
COMM_RELAY	Indicates a communications relay capability.
COMM_TERMINAL	Indicates a communications terminal capability

COUNTER_SPACE	Indicates a Counter Space Capability.
EA	Indicates an electronic attack (EA) capability.
EFFECT	Indicates an effect capability.
ESM	Indicates an electronic support measures (ESM) capability.
FLIGHT	Indicates a capability for waypoint-based flight tasks/commands.
IFF	Indicates an Identification Friend or Foe (IFF) capability.
OPAQUE	Indicates a Opaque Capability
ORBIT_CHANGE	Indicates this space system has the ability to change orbits.
ORBITAL_SURVEILLANCE	Indicates a task to perform Orbital Surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates an Orbital Surveillance Sensor Capability.
PO	Indicates a passive optical capability.
RADAR_ALTIMETER	Indicates a Radar Altimeter capability
REFUEL	Indicates a capability to refuel another asset.
RESPONSE	Indicates an response capability.
SAR	Indicates a synthetic aperture radar (SAR) capability.
SMTI	Indicates a surface moving target indication (SMTI) capability.
STRIKE	Indicates a strike capability.
SYSTEM_DEPLOYMENT	Indicates a deployment capability.
TACTICAL_ORDER	Indicates a tactical order capability.
TASK	Indicates a task capability.
WEATHER_RADAR	Indicates a weather radar capability.

Table A-4-287: C2 Interface MA_AuthorizationMT - CapabilityCommand UCI Extension Field

CapabilitySettingTypes	
Description	List size for this element is based on "Select All That Apply" condition
Base Type	MA_CapabilityTypeEnum
Message Structure	
Enumeration Literal	Description
ACTION	Indicates an action capability.
AIR_SAMPLE	Indicates an air sampling capability.
AMTI	Indicates an airborne moving target indication (AMTI) capability.
AO	Indicates an active optical capability.
CAP	Indicates a cargo delivery capability.
CARGO_DELIVERY	Indicates a cargo delivery capability.
COMINT	Indicates a Communications Intelligence (COMINT) capability.
COMM_RELAY	Indicates a communications relay capability.
COMM_TERMINAL	Indicates a communications terminal capability

COUNTER_SPACE	Indicates a Counter Space Capability.
EA	Indicates an electronic attack (EA) capability.
EFFECT	Indicates an effect capability.
ESM	Indicates an electronic support measures (ESM) capability.
FLIGHT	Indicates a capability for waypoint-based flight tasks/commands.
IFF	Indicates an Identification Friend or Foe (IFF) capability.
OPAQUE	Indicates a Opaque Capability
ORBIT_CHANGE	Indicates this space system has the ability to change orbits.
ORBITAL_SURVEILLANCE	Indicates a task to perform Orbital Surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates an Orbital Surveillance Sensor Capability.
PO	Indicates a passive optical capability.
RADAR_ALTIMETER	Indicates a Radar Altimeter capability
REFUEL	Indicates a capability to refuel another asset.
RESPONSE	Indicates an response capability.
SAR	Indicates a synthetic aperture radar (SAR) capability.
SMTI	Indicates a surface moving target indication (SMTI) capability.
STRIKE	Indicates a strike capability.
SYSTEM_DEPLOYMENT	Indicates a deployment capability.
TACTICAL_ORDER	Indicates a tactical order capability.
TASK	Indicates a task capability.
WEATHER_RADAR	Indicates a weather radar capability.

Table A-4-288: C2 Interface MA_AuthorizationMT - CapabilitySettingTypes UCI Extension Field

ByDataActivation		
Description	Indicates which types of data are authorized to be activated.	
Base Type	MA_DataActivationAuthorizationType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedExceptFor	MA_DataActivationPermissionsType	Required
Description	This element indicates that all data types are authorized to be activated with the exception of the enumeration values listed in the permissionType.	
UnauthorizedExceptFor	MA_DataActivationPermissionsType	Required
Description	This element indicates that all data types are NOT authorized to be activated with the exception of the enumeration values listed in the permissionType.	

Table A-4-289: C2 Interface MA_AuthorizationMT - ByDataActivation UCI Extension Field

CAP	
Description	Indicates a Combat Air Patrol Capability.

Base Type	MA_CAP_CapabilityEnum
Message Structure	
Enumeration Literal	Description
COMBAT_AIR_PATROL	Indicates a CAP capability

Table A-4-290: C2 Interface MA_AuthorizationMT - CAP UCI Extension Field

UnauthorizedExceptFor		
Description	This element indicates that all plan types are NOT authorized to be activated with the exception of the enumeration values listed in the permissionsType.	
Base Type	MA_PlanActivationPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
ByMissionPlan	MissionPlanActivationSettingType	Repeated
Description	Indicates the set of ByMissionPlan activation commands that are authorized. List size allows for identifying those MissionPlans whose subordinate MissionPlans are either included in the activation (TRUE) or not (FALSE) via the CommandSubordinatePlans setting.	
ByPlanParts	MA_PlanPartsType	Optional
Description	Indicates which *Plan parts are authorized to be activated.	

Table A-4-291: C2 Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field

AuthorizedExceptFor		
Description	This element indicates that all vehicle setting types are authorized to be modified with the exception of the enumeration values listed in the permissionType.	
Base Type	MA_PlatformSettingsPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilitySettingTypes	MA_CapabilityTypeEnum	Repeated
Description	List size for this element is based on "Select All That Apply" condition	
AdditionalPlatformSettingTypes	MA_PlatformSettingPermissionsTypeEnum	Repeated
Description	List size for this element is based on "Select All That Apply" condition	

Table A-4-292: C2 Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field

DataTypes	
Description	Indicates the set of data type messages that are authorized or unauthorized to be activated depending on the parent MA_DataActivationAuthorizationType. List size for this element is based on "Select All That Apply" condition
Base Type	MA_DataActivationTypeEnum

Message Structure	
Enumeration Literal	Description
COMM_POINTING_COMMAND	See MT type for annotation.
MA_CONSTRAINT_PRIORITY_LIST_COMMAND	See MT type for annotation.
MA_COP_CONFIGURATION_SETTINGS_COMMAND	See MT type for annotation.
MA_ENGAGEMENT_CRITERIA_COMMAND	See MT type for annotation.
MA_EXECUTION_PRIORITY_LIST_COMMAND	See MT type for annotation.
MA_IGNORE_CONSTRAINT_COMMAND	See MT type for annotation.

Table A-4-293: C2 Interface MA_AuthorizationMT - DataTypes UCI Extension Field

AuthorizedExceptFor		
Description	This element indicates that all request types are authorized to be sent with the exception of the enumeration values listed in the permissionType.	
Base Type	MA_OperatorRequestPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
RequestTypes	MA_OperatorRequestTypeEnum	Repeated
Description	Indicates the set of Request Messages that C2 users can send to MA. List size for this element is based on "Select All That Apply" condition	

Table A-4-294: C2 Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field

CommTerminal	
Description	Indicates a CommTerminal Capability. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_CommTerminalEnum
Message Structure	
Enumeration Literal	Description
COMM_TERMINAL	Indicates a Comm Terminal Capability.

Table A-4-295: C2 Interface MA_AuthorizationMT - CommTerminal UCI Extension Field

ByRequirementExecution		
Description	Indicates which Requirement (Effect, Action, Task, [Capability]Command, Response) execution/performance related activities are authorized.	
Base Type	MA_RequirementAuthorizationType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedExceptFor	MA_RequirementAuthorizationPermissionsType	Required
Description	This element indicates that all requirement types are authorized to be executed with the exception of the enumeration values listed in the permissionsType	

UnauthorizedExceptFor	MA_RequirementAuthorizationPermissionsType	Required
Description	This element indicates that all requirement types are NOT authorized to be executed with the exception of the enumeration values listed in the permissionsType	

Table A-4-296: C2 Interface MA_AuthorizationMT - ByRequirementExecution UCI Extension Field

ByDataModification		
Description	Indicates which types of data messages are authorized to be created, modified or deleted.	
Base Type	MA_DataModificationAuthorizationType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedExceptFor	MA_DataModificationPermissionsType	Required
Description	This element indicates that all data types are authorized to be created, modified or deleted with the exception of the enumeration values listed in the permissionType.	
UnauthorizedExceptFor	MA_DataModificationPermissionsType	Required
Description	This element indicates that all data types are NOT authorized to be created, modified or deleted with the exception of the enumeration values listed in the permissionType	

Table A-4-297: C2 Interface MA_AuthorizationMT - ByDataModification UCI Extension Field

ActivityPlan		
Description	Indicates applicable ActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional

	Description	Indicates applicable EffectPlan parts.
ActionPlan	ActionPlanPartsType	Optional
	Description	Indicates applicable ActionPlan parts.
TaskPlan	MA_TaskPlanPartsType	Optional
	Description	Indicates applicable TaskPlan parts.
ResponsePlan	ResponsePlanPartsType	Optional
	Description	Indicates applicable ResponsePlan parts.
OpPlan	MA_OpPlanPartsType	Optional
	Description	Indicates applicable OpPlan parts.

Table A-4-298: C2 Interface MA_AuthorizationMT - ActivityPlan UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_AuthorizationMDT	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizationID	AuthorizationID_Type	Required
Description	Indicates the unique ID of the authorization.	
UserIdentifier	MA_UserType	Required
Description	Indicates the unique ID of the User being granted authorization to task. User types are SystemID, OperatorRoleID, or UserIdentifier	
SystemID	SystemID_Type	Required
Description	Indicates the unique ID of the System which the User, given in the sibling UserIdentifier element, is authorized to task.	
Precedence	unsignedInt	Required
Description	This element indicates the precedence level at which the User is authorized to task the System. The larger the number, the higher the precedence. Any Tasks or Commands created by the User must not exceed this precedence level.	
ByPlanActivation	MA_PlanAuthorizationType	Repeated
Description	Indicates authorization to send Plan Activation commands.	
ByRequirementExecution	MA_RequirementAuthorizationType	Optional
Description	Indicates which Requirement (Effect, Action, Task, [Capability]Command, Response) execution/performance related activities are authorized.	
ByDataModification	MA_DataModificationAuthorizationType	Optional
Description	Indicates which types of data messages are authorized to be created, modified or deleted.	
ByDataActivation	MA_DataActivationAuthorizationType	Optional
Description	Indicates which types of data are authorized to be activated.	

ByOperatorRequest	MA_OperatorRequestAuthorizationType	Optional
Description	Indicates which types of request messages are authorized to be sent.	
PackageAuthorization	boolean	Optional
Description	This element indicates authorization to create, modify and dissolve teams.	
ByPlatformSettingsModification	MA_SettingsModificationAuthorizationType	Optional
Description	This element indicates authorization to send settings commands.	
AuthorizedTime	DateTimeRangeType	Optional
Description	This element indicates the time range during which the Authorization applies. More specifically, this is the time range in which the User must create/submit Tasks in order for them to be allocated to the specified System. If omitted, the Authorization is applicable until removed.	
AuthorizedArea	MA_AuthorizedZoneChoiceType	Optional
Description	This choice type indicates the area over which the authorization applies. It contains either a zone defined in this message or the ID of an existing OpZone	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-299: C2 Interface MA_AuthorizationMT - MessageData UCI Extension Field

AuthorizedArea		
Description	This choice type indicates the area over which the authorization applies. It contains either a zone defined in this message or the ID of an existing OpZone	
Base Type	MA_AuthorizedZoneChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedZone	ZoneType	Required
Description	This element indicates the area over which the authorization applies. More specifically, this is the geospatial zone in which the target of Tasks created by the User must fall in order for them to be allocated to the specified System. If omitted, the Authorization is applicable to all areas.	
AuthorizedOpZoneID	OpZoneID_Type	Required
Description	This element indicates the area defined by an existing OpZone over which the authorization applies. More specifically, this is the geospatial zone in which the target of Tasks created by the User must fall in order for them to be allocated to the specified System. If omitted, the Authorization is applicable to all areas.	

Table A-4-300: C2 Interface MA_AuthorizationMT - AuthorizedArea UCI Extension Field

AuthorizedExceptFor	
Description	This element indicates that all plan types are authorized to be activated with the exception of the enumeration values listed in the permissionsType.

Base Type	MA_PlanActivationPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
ByMissionPlan	MissionPlanActivationSettingType	Repeated
Description	Indicates the set of ByMissionPlan activation commands that are authorized. List size allows for identifying those MissionPlans whose subordinate MissionPlans are either included in the activation (TRUE) or not (FALSE) via the CommandSubordinatePlans setting.	
ByPlanParts	MA_PlanPartsType	Optional
Description	Indicates which *Plan parts are authorized to be activated.	

Table A-4-301: C2 Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field

ByPlanActivation		
Description	Indicates authorization to send Plan Activation commands.	
Base Type	MA_PlanAuthorizationType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedExceptFor	MA_PlanActivationPermissionsType	Required
Description	This element indicates that all plan types are authorized to be activated with the exception of the enumeration values listed in the permissionsType.	
UnauthorizedExceptFor	MA_PlanActivationPermissionsType	Required
Description	This element indicates that all plan types are NOT authorized to be activated with the exception of the enumeration values listed in the permissionsType.	

Table A-4-302: C2 Interface MA_AuthorizationMT - ByPlanActivation UCI Extension Field

AuthorizedExceptFor		
Description	This element indicates that all data types are authorized to be created, modified or deleted with the exception of the enumeration values listed in the permissionType.	
Base Type	MA_DataModificationPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
DataTypes	MA_DataMessageTypeEnum	Repeated
Description	Indicates the set of data type messages that are authorized or unauthorized to be edited, created or deleted depending on the parent MA_DataModificationAuthorizationType.	

Table A-4-303: C2 Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field

ByPlatformSettingsModification	
Description	This element indicates authorization to send settings commands.
Base Type	MA_SettingsModificationAuthorizationType

Message Structure		
Field Name	Field Type	Field Usage
AuthorizedExceptFor	MA_PlatformSettingsPermissionsType	Required
Description	This element indicates that all vehicle setting types are authorized to be modified with the exception of the enumeration values listed in the permissionType.	
UnauthorizedExceptFor	MA_PlatformSettingsPermissionsType	Required
Description	This element indicates that all vehicle setting types are unauthorized to be modified with the exception of the enumeration values listed in the permissionType.	

Table A-4-304: C2 Interface MA_AuthorizationMT - ByPlatformSettingsModification UCI Extension Field

UnauthorizedExceptFor		
Description	This element indicates that all data types are NOT authorized to be created, modified or deleted with the exception of the enumeration values listed in the permissionType	
Base Type	MA_DataModificationPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
DataTypes	MA_DataMessageTypeEnum	Repeated
Description	Indicates the set of data type messages that are authorized or unauthorized to be edited, created or deleted depending on the parent MA_DataModificationAuthorizationType.	

Table A-4-305: C2 Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field

UnauthorizedExceptFor		
Description	This element indicates that all request types are NOT authorized to be sent with the exception of the enumeration values listed in the permissionType.	
Base Type	MA_OperatorRequestPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
RequestTypes	MA_OperatorRequestTypeEnum	Repeated
Description	Indicates the set of Request Messages that C2 users can send to MA. List size for this element is based on "Select All That Apply" condition	

Table A-4-306: C2 Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field

RadarAltimeter	
Description	Indicates a Radar Altimeter Capability. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_RadarAltimeterEnum
Message Structure	
Enumeration Literal	Description
RADAR_ALTIMETER	Indicates a Radar Altimeter Capability.

Table A-4-307: C2 Interface MA_AuthorizationMT - RadarAltimeter UCI Extension Field

RequestTypes	
Description	Indicates the set of Request Messages that C2 users can send to MA. List size for this element is based on "Select All That Apply" condition
Base Type	MA_OperatorRequestTypeEnum
Message Structure	
Enumeration Literal	Description
DATA_RECORD_MANAGEMENT_REQUEST	See MT type for annotation.
MA_ASSESSMENT_REQUEST	See MT type for annotation.
MA_CONTROL_REQUEST	See MT type for annotation.
QUERY_DATA_REQUEST	See MT type for annotation.

Table A-4-308: C2 Interface MA_AuthorizationMT - RequestTypes UCI Extension Field

ByPlanParts		
Description	Indicates which *Plan parts are authorized to be activated.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	

OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-309: C2 Interface MA_AuthorizationMT - ByPlanParts UCI Extension Field

AdditionalPlatformSettingTypes	
Description	List size for this element is based on "Select All That Apply" condition
Base Type	MA_PlatformSettingPermissionsTypeEnum
Message Structure	
Enumeration Literal	Description
MA_ACCEPTABLE_LEVEL_OF_RISK_COMMAND	See MT type for annotation.
MA_SYSTEM_MANAGEMENT_REQUEST	See MT type for annotation.
PLANNING_FUNCTION_SETTINGS_COMMAND	See MT type for annotation.

Table A-4-310: C2 Interface MA_AuthorizationMT - AdditionalPlatformSettingTypes UCI Extension Field

IFF	
Description	Indicates an IFF Capability. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_IFF_Enum
Message Structure	
Enumeration Literal	Description
IFF	Indicates an IFF Capability.

Table A-4-311: C2 Interface MA_AuthorizationMT - IFF UCI Extension Field

RequirementTypes		
Description	Indicates the set of Requirements that are authorized or unauthorized to be commanded depending on the parent MA_RequirementAuthorizationType	
Base Type	MA_RequirementTaxonomyDetailedType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityTaxonomy	MA_CapabilityTaxonomyType	Optional
Description	Indicates specific Capability details/modes that are applicable.	
Effect	EffectTypeEnum	Repeated
Description	Indicates Effects applicable via the Effect* message set. List size for this element is based on "Select All That Apply" condition.	
Action	MA_ActionTypeEnum	Repeated
Description	Indicates Actions applicable via the Action* message set. List size for this element is based on "Select All That Apply" condition.	
Task	MA_TaskTypeEnum	Repeated
Description	Indicates Tasks applicable via the Task* message set. List size for this element is	

	based on "Select All That Apply" condition.	
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates CapabilityCommands applicable via a [Capability]Command message set. List size for this element is based on "Select All That Apply" condition.	
Response	ResponseTypeEnum	Repeated
Description	Indicates Responses applicable via the Response* message set. List size for this element is based on "Select All That Apply" condition.	

Table A-4-312: C2 Interface MA_AuthorizationMT - RequirementTypes UCI Extension Field

UnauthorizedExceptFor		
Description	This element indicates that all vehicle setting types are unauthorized to be modified with the exception of the enumeration values listed in the permissionType.	
Base Type	MA_PlatformSettingsPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilitySettingTypes	MA_CapabilityTypeEnum	Repeated
Description	List size for this element is based on "Select All That Apply" condition	
AdditionalPlatformSettingTypes	MA_PlatformSettingPermissionsTypeEnum	Repeated
Description	List size for this element is based on "Select All That Apply" condition	

Table A-4-313: C2 Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field

UserIdentifier		
Description	Indicates the unique ID of the User being granted authorization to task. User types are SystemID, OperatorRoleID, or UserIdentifier	
Base Type	MA_UserType	
Message Structure		
Field Name	Field Type	Field Usage
OperatorRoleID	OperatorRoleID_Type	Required
Description	This choice type is used in the context of RBAC to specify an operator role to tie a set of authorized permissions to.	
SystemID	SystemID_Type	Required
Description	This choice type is used to specify a system ID to tie a set of authorized permissions to.	
UserIdentifier	UserIdentifierType	Required
Description	This choice type is used to specify a User Identifier to tie a set of authorized permissions to.	

Table A-4-314: C2 Interface MA_AuthorizationMT - UserIdentifier UCI Extension Field

ByOperatorRequest	
Description	Indicates which types of request messages are authorized to be sent.

Base Type	MA_OperatorRequestAuthorizationType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedExceptFor	MA_OperatorRequestPermissionsType	Required
Description	This element indicates that all request types are authorized to be sent with the exception of the enumeration values listed in the permissionType.	
UnauthorizedExceptFor	MA_OperatorRequestPermissionsType	Required
Description	This element indicates that all request types are NOT authorized to be sent with the exception of the enumeration values listed in the permissionType.	

Table A-4-315: C2 Interface MA_AuthorizationMT - ByOperatorRequest UCI Extension Field

4.1.81 MA_OpCommandStatusMT UCI Extension

MA_OpCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_OpCommandStatusMDT

Table A-4-316: C2 Interface MA_OpCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-317: C2 Interface MA_OpCommandStatusMT - MessageData UCI Extension Field

4.1.82 MA_ApprovalPolicyMT UCI Extension

MA_ApprovalPolicyMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	TaskPlan : MA_TaskPlanPartsType OpLineCategory : MA_OpLineCategoryEnum ActivityPlan : MA_ActivityPlanPartsType ApplicablePlanningActivity : MA_PlanPolicyApplicablePlanType OpVolumeCategory : MA_OpZoneCategoryEnum TaskType : MA_TaskTypeEnum OrbitActivityPlan : MA_ActivityPlanPartsType MessageData : MA_ApprovalPolicyMDT OpZoneCategory : MA_OpZoneCategoryEnum ByPlanParts : MA_PlanPartsType CapabilityCommand : MA_CapabilityTypeEnum PlanParts : MA_PlanPartsType Plans : MA_PlanPolicyType RouteActivityPlan : MA_ActivityPlanPartsType OpPlan : MA_OpPlanPartsType PlanActivation : MA_PlanActivationPolicyType

Table A-4-318: C2 Interface MA_ApprovalPolicyMT UCI Extension

TaskPlan		
Description	Indicates applicable TaskPlan parts.	
Base Type	MA_TaskPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
TaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	

Table A-4-319: C2 Interface MA_ApprovalPolicyMT - TaskPlan UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpLineCategoryEnum

Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-320: C2 Interface MA_ApprovalPolicyMT - OpLineCategory UCI Extension Field

ActivityPlan		
Description	Indicates applicable ActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage

CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-321: C2 Interface MA_ApprovalPolicyMT - ActivityPlan UCI Extension Field

ApplicablePlanningActivity		
Description	Indicates the set of planning activities whose generated plans are subject to the sibling *Policy elements.	
Base Type	MA_PlanPolicyApplicablePlanType	
Message Structure		
Field Name	Field Type	Field Usage
PlanType	PlanTypeEnum	Required
Description	Indicates the PlanType that is generated by the planning activity, which is applicable to the associated *Policy elements.	
PlanParts	MA_PlanPartsType	Optional
Description	Indicates the parts of the sibling PlanType that are generated by the planning activity, which is applicable to the associated *Policy elements. If omitted, it indicates all PlanParts are applicable.	

ConstrainingPlans	AutonomousPlanningConstrainingPlansType	Optional
Description	Indicates a set of constraining plans (applicable to same system than the one planned for) that are used in the planning activity, which is applicable to the associated *Policy elements.	
OtherSystemConstrainingPlans	AutonomousPlanningOtherSystemConstrainingPlansType	Repeated
Description	Indicates a set of constraining plans (applicable to different system than the one planned for) that are used in the planning activity, which is applicable to the associated *Policy elements.	

Table A-4-322: C2 Interface MA_ApprovalPolicyMT - ApplicablePlanningActivity UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate

	ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted

	without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-323: C2 Interface MA_ApprovalPolicyMT - OpVolumeCategory UCI Extension Field

TaskType	
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.
AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.
CAP	Indicates the task is to execute a Combat Air Patrol.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESCORT	Indicates the task is to escort another entity.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.

SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.
SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-324: C2 Interface MA_ApprovalPolicyMT - TaskType UCI Extension Field

OrbitActivityPlan		
Description	Indicates applicable OrbitActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-325: C2 Interface MA_ApprovalPolicyMT - OrbitActivityPlan UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ApprovalPolicyMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApprovalPolicyID	ApprovalPolicyID_Type	Required
Description	Indicates the unique ID of the approval policy.	
Plans	MA_PlanPolicyType	Repeated
Description	Indicates a set of approval policies for the results of planning activities.	
PlanActivation	MA_PlanActivationPolicyType	Repeated
Description	Indicates approval policies which govern Plan Activation commands.	
RequirementExecution	RequirementExecutionPolicyType	Optional
Description	Indicates which Requirement (Effect, Action, Task, [Capability]Command, Response) execution/performance related activities require approval.	
TimedZone	TimedZoneType	Optional
Description	Indicates the geospatial zone and optionally time/date span or spans when the policy is active. For task allocation, the policy is applicable to allocations that 1) complete within the time/date span and 2) include Task or Tasks whose target falls within the zone, regardless of when the Task will be executed. For route planning, the policy is applicable to route plans with segments that fall within the zone during the time/date span, regardless of when the route plan was completed or the target of Tasks associated with the segments. For task execution, the policy is applicable to Tasks that 1) are scheduled to complete within the time/date span and 2) have a target which falls within the zone. This element supersedes the sibling Expires element.	
Expires	DateTimeType	Optional
Description	Indicates the time and date when the policy expires. The policy is applicable to task allocation and route planning activities completed prior to this time. The policy is applicable to task execution activities initiated prior to this time. When the sibling TimedZone element is used, the time spans specified there supersede this element.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of the approval policy to specify the source or motivation for this ApprovalPolicy such as ATO, ACO, etc.	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-326: C2 Interface MA_ApprovalPolicyMT - MessageData UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone type applicable to the associated *Plan. List size for

	this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the

	IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are

	defined in the OpZoneWeatherType choice in OpZoneCategoryType.
--	--

Table A-4-327: C2 Interface MA_ApprovalPolicyMT - OpZoneCategory UCI Extension Field

ByPlanParts		
Description	Indicates *Plan parts which the Plan to be activated must contain in order for the Policy to be applicable. If omitted, the Policy is applicable regardless of *Plan parts.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-328: C2 Interface MA_ApprovalPolicyMT - ByPlanParts UCI Extension Field

CapabilityCommand	
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_CapabilityTypeEnum
Message Structure	

Enumeration Literal	Description
ACTION	Indicates an action capability.
AIR_SAMPLE	Indicates an air sampling capability.
AMTI	Indicates an airborne moving target indication (AMTI) capability.
AO	Indicates an active optical capability.
CAP	Indicates a cargo delivery capability.
CARGO_DELIVERY	Indicates a cargo delivery capability.
COMINT	Indicates a Communications Intelligence (COMINT) capability.
COMM_RELAY	Indicates a communications relay capability.
COMM_TERMINAL	Indicates a communications terminal capability
COUNTER_SPACE	Indicates a Counter Space Capability.
EA	Indicates an electronic attack (EA) capability.
EFFECT	Indicates an effect capability.
ESM	Indicates an electronic support measures (ESM) capability.
FLIGHT	Indicates a capability for waypoint-based flight tasks/commands.
IFF	Indicates an Identification Friend or Foe (IFF) capability.
OPAQUE	Indicates a Opaque Capability
ORBIT_CHANGE	Indicates this space system has the ability to change orbits.
ORBITAL_SURVEILLANCE	Indicates a task to perform Orbital Surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates an Orbital Surveillance Sensor Capability.
PO	Indicates a passive optical capability.
RADAR_ALTIMETER	Indicates a Radar Altimeter capability
REFUEL	Indicates a capability to refuel another asset.
RESPONSE	Indicates an response capability.
SAR	Indicates a synthetic aperture radar (SAR) capability.
SMTI	Indicates a surface moving target indication (SMTI) capability.
STRIKE	Indicates a strike capability.
SYSTEM_DEPLOYMENT	Indicates a deployment capability.
TACTICAL_ORDER	Indicates a tactical order capability.
TASK	Indicates a task capability.
WEATHER_RADAR	Indicates a weather radar capability.

Table A-4-329: C2 Interface MA_ApprovalPolicyMT - CapabilityCommand UCI Extension Field

PlanParts	
Description	Indicates the parts of the sibling PlanType that are generated by the planning activity, which is applicable to the associated *Policy elements. If omitted, it indicates all PlanParts are applicable.

Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-330: C2 Interface MA_ApprovalPolicyMT - PlanParts UCI Extension Field

Plans		
Description	Indicates a set of approval policies for the results of planning activities.	
Base Type	MA_PlanPolicyType	
Message Structure		
Field Name	Field Type	Field Usage
ApplicablePlanningActivity	MA_PlanPolicyApplicablePlanType	Repeated
Description	Indicates the set of planning activities whose generated plans are subject to the sibling *Policy elements.	
DefaultPolicy	ApprovalPolicyBaseType	Optional
Description	Indicates the default approval policy for the sibling ApplicablePlanningActivity. The default policy can be overridden in specific conditions as indicated by the ByResultPolicy or ByTriggerPolicy siblings of this element. For example, this element could indicate that approval is required by default for all TaskPlans and then use ByResultPolicy or ByTriggerPolicy siblings to specify conditions when task allocation	

	approval is not required. Alternately, this element could indicate that approval is not required by default and then use ByResultPolicy or ByTriggerPolicy siblings to specify conditions when task allocation approval is required. Creators of this message are expected to carefully avoid creating logically inconsistent ByResultPolicy and ByTriggerPolicy instances and therefore no guidance is given on deconflicting illogical instances. For example, an ApprovalPolicy that indicates approval is not required by default with conflicting ByResultPolicy or ByTriggerPolicy overrides of 1) AUTO_REJECT for DROPPED_TASKS and 2) AUTO_APPROVE for operator triggered DROPPED_TASKS would be considered illogical.	
ByResultPolicy	ByResultPolicyType	Repeated
Description	Indicates approval policies when planning activity results match certain conditions. Conditions specified here are considered to be overrides to the default planning activity approval policy given in the sibling Default element. For example, if the default policy indicates task allocation approval is never required, this element could override the default and require approval whenever a task allocation results in previously allocated Task or Tasks being dropped. See the annotations in the sibling DefaultPolicy element for an overview of how the siblings relate to each other. If multiple instances are given, each should be a different Result instance as indicated by the child Result element.	
ByTriggerPolicy	ByTriggerPolicyType	Repeated
Description	Indicates approval policies for re-plan activities initiated by triggered events, overriding the default approval policy for the planning activity given in the sibling DefaultPolicy element. Additionally, this element allows trigger-specific policies for a specific planning activities. For example, if the default policy indicates route planning approval is never required, this element could override, requiring approval for route plans affecting all Systems triggered by new threats if the route re-plan results in dropped tasks. If multiple instances are given, each should be of a different trigger type as indicated by the child EventTrigger element.	

Table A-4-331: C2 Interface MA_ApprovalPolicyMT - Plans UCI Extension Field

RouteActivityPlan		
Description	Indicates applicable RouteActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	

ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-332: C2 Interface MA_ApprovalPolicyMT - RouteActivityPlan UCI Extension Field

OpPlan		
Description	Indicates applicable OpPlan parts.	
Base Type	MA_OpPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpRouting	EmptyType	Optional
Description	Indicates an OpRouting is applicable to the associated *Plan. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-333: C2 Interface MA_ApprovalPolicyMT - OpPlan UCI Extension Field

PlanActivation	
Description	Indicates approval policies which govern Plan Activation commands.
Base Type	MA_PlanActivationPolicyType

Message Structure		
Field Name	Field Type	Field Usage
ByMissionPlan	MissionPlanActivationSettingType	Repeated
Description	Indicates the set of ByMissionPlan activation commands that are applicable to the sibling Policy element. List size allows for identifying those MissionPlans whose subordinate MissionPlans are either included in the activation (TRUE) or not (FALSE) via the CommandSubordinatePlans setting.	
BySubPlan	SubPlanActivationSettingType	Repeated
Description	Indicates the set of BySubPlan activation commands that are applicable to the sibling Policy element.	
ByPlanParts	MA_PlanPartsType	Optional
Description	Indicates *Plan parts which the Plan to be activated must contain in order for the Policy to be applicable. If omitted, the Policy is applicable regardless of *Plan parts.	
Policy	ApprovalPolicyBaseType	Optional
Description	Indicates the approval policy for the sibling applicable activation activities.	

Table A-4-334: C2 Interface MA_ApprovalPolicyMT - PlanActivation UCI Extension Field

4.1.83 MA_ActionCommandMT UCI Extension

MA_ActionCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	ActionConstraintOverride : MA_ActionConstraintType RequiredAllocation : MA_RequirementAllocationConstraintType System : MA_SystemFilterType PreferredAllocation : MA_RequirementAllocationConstraintType Analytic : MA_AnalyticConstraintsType Designation : MA_DesignationFilterType AssessedObject : MA_AssetFilterType Characteristics : MA_EntityComparativeType Allocation : MA_AllocationChoiceType ConstraintOverride : MA_RequirementConstraintsType Allocation : MA_RequirementAllocationParametersType AccessAssessmentThreshold : MA_AccessAssessmentFilterType Command : MA_ActionCommandType ExcludedRequirementTypes : MA_RequirementTaxonomyType Kinematic : MA_RequirementKinematicConstraintsType EngagementParameters : MA_EngagementParametersType Subject : MA_AssetFilterType

MessageData : MA_ActionCommandMDT
 AllowedRequirementTypes : MA_RequirementTaxonomyType
 Entity : MA_EntityFilterType

Table A-4-335: C2 Interface MA_ActionCommandMT UCI Extension

ActionConstraintOverride		
Description	Indicates refined/overridden values of constraints for the Action. Added to allow similar override options in direct commanding as is available in planning.	
Base Type	MA_ActionConstraintType	
Message Structure		
Field Name	Field Type	Field Usage
TargetObject	IdentityKindInstanceType	Repeated
Description	Indicates the target of the Action; the object the Action will be done to or for. If omitted, the Action places no explicit limitation on which TargetObject it can be done to. See sibling ActionType element annotation for an overall description of Action structure. Note that the term "target" is used in a general sense. For some Requirement types, a more suitable term might be "subject", "point", "location", etc. For example, the "target" of a COVER Action could be a blue/friendly System.	
TargetObjectConstraints	RequirementTargetConstraintsType	Optional
Description	Indicates constraints "on" the TargetObject that must be satisfied before the Action can be done to or for it. See sibling ActionType element annotation for an overall description of Effect structure.	
SecondaryObject	IdentityKindInstanceType	Repeated
Description	Indicates a thing the sibling TargetObject must act on/against/toward to make the Action applicable. See sibling ActionType element annotation for an overall description of Action structure.	
PerTargetEngagementParameters	MA_EngagementParametersOrDefaultChoiceType	Repeated
Description	Indicates a command to change the engagement parameters corresponding to an ongoing tactic. This field is meant to be used on a per target basis. Setting this field overrides the engagement parameters sent in MA_Action, and Activity modification by ChangeEngagement, and any previous audibles that modified MA_EngagementParameters for the sibling TargetObject.	

Table A-4-336: C2 Interface MA_ActionCommandMT - ActionConstraintOverride UCI Extension Field

RequiredAllocation	
Description	Indicates the system and optionally Capability that the Requirement (Effect, Action, Task, [Capability]Command, Response) MUST be allocated to during the allocation process. The system can be an explicit UCI System or implied UCI System (by Identity, hosted Capability, kinematics, etc.) in which case the associated UCI System must be determined as part of the allocation process. If multiple child elements are given: 1) allocation to any one of the associated Systems is the minimum expectation, 2) decomposition of the Requirement into multiple child Requirements allocated across the associated Systems is acceptable, 3) there is no expectation that each associated System must

	perform the Requirement. This element allows the Requirement creator to force an allocation to a specific system at the risk of 1) a less than optimal overall solution or 2) failure of the Requirement being allocated despite availability of another suitable system.	
Base Type	MA_RequirementAllocationConstraintType	
Message Structure		
Field Name	Field Type	Field Usage
Allocation	MA_AllocationChoiceType	Required
Description	Indicates the type of Allocation, either by direct assignment of SystemIDs or by PackageID definition for delegation.	
Identity	IdentityType	Repeated
Description	Indicates a kind/type or instance of platform/system that is the target of the allocation constraint. For example, this element could be used to allocate a Requirement to any fighter aircraft platform, or a specific kind of fighter aircraft, or a specific tail number of aircraft, or an aircraft with an aircrew member with a certain voice call sign.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates the CapabilityID of the Capability that is the target of the allocation constraint. If multiple required Capabilities are given: 1) allocation to any one of the Capabilities is the minimum expectation, 2) decomposition of the Requirement into multiple child Requirements allocated across the multiple required Capabilities is acceptable, 3) there is no expectation that each Capability must perform the Requirement.	

Table A-4-337: C2 Interface MA_ActionCommandMT - RequiredAllocation UCI Extension Field

System		
Description	Indicates a filter on characteristics of a System asset. The asset filter is satisfied if a match is found in this element OR the sibling Entity element.	
Base Type	MA_SystemFilterType	
Message Structure		
Field Name	Field Type	Field Usage
Characteristics	MA_SystemComparativeType	Repeated
Description	This element indicates a System filter requiring a variable logical comparator test between a value in a System-associated message and the value given here. Multiple instances are logically ANDed.	
SystemID	SystemID_Type	Repeated
Description	Indicates a specific SystemID that is required to match the filter. If omitted, any SystemID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the System must fall within to satisfy the clause. Multiple instances are logically ORed.	
OrbitalFilter	OrbitalFiltersQueryType	Repeated
Description	Indicates a zone the System must fall within to satisfy the clause. Multiple instances are logically ORed.	

Table A-4-338: C2 Interface MA_ActionCommandMT - System UCI Extension Field

PreferredAllocation		
Description		Indicates the system and optionally Capability that the Requirement (Effect, Action, Task, [Capability]Command, Response) should be allocated to during the allocation process. The system can be an explicit UCI System or implied UCI System (by Identity, hosted Capability, kinematics, etc.) in which case the associated UCI System must be determined as part of the allocation process. If multiple child elements are given: 1) allocation to any one of the associated Systems is the minimum expectation, 2) decomposition of the Requirement into multiple child Requirements allocated across the associated Systems is acceptable, 3) there is no expectation that each associated System must perform the Requirement. This element allows the Requirement creator to suggest an allocation to a specific system at the risk of 1) a less than optimal overall solution or 2) failure of the Requirement being allocated despite availability of another suitable system.
Base Type		MA_RequirementAllocationConstraintType
Message Structure		
Field Name	Field Type	Field Usage
Allocation	MA_AllocationChoiceType	Required
Description	Indicates the type of Allocation, either by direct assignment of SystemIDs or by PackageID definition for delegation.	
Identity	IdentityType	Repeated
Description	Indicates a kind/type or instance of platform/system that is the target of the allocation constraint. For example, this element could be used to allocate a Requirement to any fighter aircraft platform, or a specific kind of fighter aircraft, or a specific tail number of aircraft, or an aircraft with an aircrew member with a certain voice call sign.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates the CapabilityID of the Capability that is the target of the allocation constraint. If multiple required Capabilities are given: 1) allocation to any one of the Capabilities is the minimum expectation, 2) decomposition of the Requirement into multiple child Requirements allocated across the multiple required Capabilities is acceptable, 3) there is no expectation that each Capability must perform the Requirement.	

Table A-4-339: C2 Interface MA_ActionCommandMT - PreferredAllocation UCI Extension Field

Analytic		
Description		Indicates a constraint in the form of an analytic measure that the Requirement must satisfy when planned/executed.
Base Type		MA_AnalyticConstraintsType
Message Structure		
Field Name	Field Type	Field Usage
OpConstraint	OpConstraintWeightingType	Repeated
Description	Indicates an operational constraint to achieve. The multiplicity is based on the list of available OpConstraintEnums.	
RiskSetting	SurvivabilityRiskSettingType	Repeated

Description	Identifies the Risk Level constraint for each provided RiskPrioritization (max of 4).	
AccessAssessmentThreshold	MA_AccessAssessmentFilterType	Optional
Description	Indicates access assessment analysis event thresholds.	
RF_TaskPerformance	RF_TaskPerformanceType	Optional
Description	Mission specific RF performance objective.	

Table A-4-340: C2 Interface MA_ActionCommandMT - Analytic UCI Extension Field

Designation		
Description	Indicates a type of Entity designation, established by the Designation message, required to satisfy the filter.	
Base Type	MA_DesignationFilterType	
Message Structure		
Field Name	Field Type	Field Usage
DesignationType	DesignationEnum	Repeated
Description	Indicates a type of designation required to match the filter. List size for this element is based on "Select All That Apply" condition.	
DesignationObjective	MA_RequirementTaxonomyType	Optional
Description	Indicates objective or objectives that the designation must include to match the filter. When omitted, the designation objective is irrelevant for the filter.	

Table A-4-341: C2 Interface MA_ActionCommandMT - Designation UCI Extension Field

AssessedObject		
Description	Indicates Assessed Objects of the AccessAssessment that are required to match the filter. If omitted, any Assessed Object satisfies the filter.	
Base Type	MA_AssetFilterType	
Message Structure		
Field Name	Field Type	Field Usage
System	MA_SystemFilterType	Optional
Description	Indicates a filter on characteristics of a System asset. The asset filter is satisfied if a match is found in this element OR the sibling Entity element.	
Entity	MA_EntityFilterType	Optional
Description	Indicates a filter on characteristics of an Entity asset. The asset filter is satisfied if a match is found in this element OR the sibling System element.	

Table A-4-342: C2 Interface MA_ActionCommandMT - AssessedObject UCI Extension Field

Characteristics	
Description	This element indicates an Entity filter requiring a variable logical comparator test between a value in an Entity-associated message and the value given here. Multiple instances are logically ANDed.
Base Type	MA_EntityComparativeType
Message Structure	

Field Name	Field Type	Field Usage
Characteristic	MA_EntityCharacteristicType	Required
Description	Indicates a characteristic/element value to be used to compare to the corresponding value of the Entity or related message.	
Comparator	EqualityExpressionEnum	Required
Description	Indicates the logical comparator to use when comparing the target (Entity or related message) Characteristic to the Response Characteristic. The logical expression is: (target Characteristic) (Comparator) (Response Characteristic). When the logical expression is TRUE then the parent TargetClause instance is TRUE.	

Table A-4-343: C2 Interface MA_ActionCommandMT - Characteristics UCI Extension Field

Allocation		
Description	Indicates the type of Allocation, either by direct assignment of SystemIDs or by PackageID definition for delegation.	
Base Type	MA_AllocationChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Repeated
Description	Indicates the SystemID(s) of the System that is the target of the allocation constraint.	
PackageID	PackageID_Type	Required
Description	Indicates the unique ID of the package for delegation of Systems.	

Table A-4-344: C2 Interface MA_ActionCommandMT - Allocation UCI Extension Field

ConstraintOverride		
Description	Indicates refined/overridden values of constraints for the Action. Added to allow similar override options in direct commanding as is available in planning.	
Base Type	MA_RequirementConstraintsType	
Message Structure		
Field Name	Field Type	Field Usage
Rank	ComparableRankingType	Optional
Description	Indicates a constraint in the form of the Rank of the associated Requirement (Effect, Action, Task, [Capability]Command or Response).	
InterruptLowerRank	boolean	Optional
Description	Indicates whether a) an in-work/planned item or items of a lower rank should be interrupted/replanned in order to address this item (TRUE) or b) this item should be simply queued/planned according to rank without interrupting in-work/planned items (FALSE). For example, a Task being added to an existing TaskPlan (TaskPlanCommand constrained by an existing TaskPlan) would potentially cause unlocked Tasks of lower rank in the existing TaskPlan to be unallocated if 1) this element indicated TRUE and 2)	

		the lower ranked Tasks prevented the higher ranked Task from being allocated.
Allocation		MA_RequirementAllocationParametersType Optional
	Description	Indicates allocation related constraints which can vary by Requirement at the discretion of the creator.
Timing		RequirementTimingType Repeated
	Description	Indicates a temporal constraint on the Requirement. Allows for defining for each timing type (RequirementTimingEnum).
Kinematic		MA_RequirementKinematicConstraintsType Repeated
	Description	Indicates a constraint in the form of kinematic position of Requirement actor or actors. When more than one is given they are logically ANDed.
Dependency		RequirementDependencyType Repeated
	Description	Indicates a constraint in the form of a temporal dependency between Requirements; between Effect, Action, Task, [Capability]Command or Commands or Response. If more than one is given, they are logically ANDed. For example, a pre-strike image collection (PO Task) might be required several minutes prior to a strike (Strike Task) to determine combat ID and target coordinates. A post-strike image collection (PO Task) might be required several minutes after the strike to inform battle damage assessment. The dependency between the three Tasks can be established with this element. Assuming the Strike Task is the most difficult to plan/coordinate, the other two Tasks would likely each have dependencies on the Strike Task in order to orchestrate the desired "look-shoot-look" sequence.
MaxProductDisseminationClassificationLevel		DataProductClassificationLevelType Optional
	Description	Indicates the maximum allowed classification level of the networks that the allocated system can disseminate products to for this task. The allocated system must have a dissemination route for data at this classification or lower. For example, when trying to collect data to hand-off to an unclassified system or network, the allocated system has to be able to generate products at no higher than the specified level and have the authority to disseminate on a network at no higher than the specified classification level.
Analytic		MA_AnalyticConstraintsType Optional
	Description	Indicates a constraint in the form of an analytic measure that the Requirement must satisfy when planned/executed.
AcceptableClassificationLevel		SecurityInformationType Optional
	Description	Indicates a constraint on the highest acceptable classification level at which the Response can be planned and executed.

CommsRequired	boolean	Optional
Description	Indicates whether or not communications are required when executing the Requirement. In this context, "required" means the creator or a Requirement considers communications as necessary for C2 and/or Product dissemination related to this Requirement, independent of the type of vehicle that it is allocated to. This element may result in consideration of communications allocations during Requirement allocation.	
AllowedRequirementTypes	MA_RequirementTaxonomyType	Optional
Description	Indicates other types of Requirements that can be decomposed from, used to plan, used to implement, inherited from traced parents or otherwise associated with the subject Requirement.	
ExcludedRequirementTypes	MA_RequirementTaxonomyType	Optional
Description	Indicates other types of Requirements that cannot be decomposed from, used to plan, used to implement, inherited from traced parents or otherwise be associated with the subject Requirement.	
ConstraintsNarrative	VisibleString1024Type	Optional
Description	Free-text explanation of sibling constraints, additional extraordinary constraints, etc.	
AllowedDomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates an allowed domain/environment which the Requirement can be employed from and allowed "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
ExcludedDomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates an excluded domain/environment which the Requirement can't be employed from an excluded "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
EngagementParameters	MA_EngagementParametersType	Optional
Description	Provides engagement parameters that this requirement should adhere to.	

Table A-4-345: C2 Interface MA_ActionCommandMT - ConstraintOverride UCI Extension Field

Allocation		
Description	Indicates allocation related constraints which can vary by Requirement at the discretion of the creator.	
Base Type	MA_RequirementAllocationParametersType	
Message Structure		
Field Name	Field Type	Field Usage
RequiredAllocation	MA_RequirementAllocationConstraintType	Optional
Description	Indicates the system and optionally Capability that the Requirement (Effect, Action, Task, [Capability]Command, Response) MUST be allocated to during the allocation process. The system can be an explicit UCI System or implied UCI System (by Identity, hosted Capability, kinematics, etc.) in which case the associated UCI System	

	must be determined as part of the allocation process. If multiple child elements are given: 1) allocation to any one of the associated Systems is the minimum expectation, 2) decomposition of the Requirement into multiple child Requirements allocated across the associated Systems is acceptable, 3) there is no expectation that each associated System must perform the Requirement. This element allows the Requirement creator to force an allocation to a specific system at the risk of 1) a less than optimal overall solution or 2) failure of the Requirement being allocated despite availability of another suitable system.	
PreferredAllocation	MA_RequirementAllocationConstraintType	Optional
Description	Indicates the system and optionally Capability that the Requirement (Effect, Action, Task, [Capability]Command, Response) should be allocated to during the allocation process. The system can be an explicit UCI System or implied UCI System (by Identity, hosted Capability, kinematics, etc.) in which case the associated UCI System must be determined as part of the allocation process. If multiple child elements are given: 1) allocation to any one of the associated Systems is the minimum expectation, 2) decomposition of the Requirement into multiple child Requirements allocated across the associated Systems is acceptable, 3) there is no expectation that each associated System must perform the Requirement. This element allows the Requirement creator to suggest an allocation to a specific system at the risk of 1) a less than optimal overall solution or 2) failure of the Requirement being allocated despite availability of another suitable system.	

Table A-4-346: C2 Interface MA_ActionCommandMT - Allocation UCI Extension Field

AccessAssessmentThreshold		
Description	Indicates access assessment analysis event thresholds.	
Base Type	MA_AccessAssessmentFilterType	
Message Structure		
Field Name	Field Type	Field Usage
AssessmentName	VisibleString32Type	Repeated
Description	Indicates a name/type of AccessAssessment algorithm required to match the filter. If omitted, any name/type of AccessAssessment algorithm satisfies the filter.	
AssessedCapabilities	CapabilityTaxonomyUniversalType	Optional
Description	Indicates assessed Capabilities of the AccessAssessment that are required to match the filter. If omitted, any assessed Capability satisfies the filter.	
Subject	MA_AssetFilterType	Optional
Description	Indicates Subjects of the AccessAssessment that are required to match the filter. If omitted, any Subject satisfies the filter.	
AssessedObject	MA_AssetFilterType	Optional
Description	Indicates Assessed Objects of the AccessAssessment that are required to match the filter. If omitted, any Assessed Object satisfies the filter.	
AccessEvent	AccessEventFilterType	Repeated
Description	Indicates Access Event details necessary to match the filter. If omitted, any Access Event satisfies the filter. Multiple instances are logically ORed.	

Table A-4-347: C2 Interface MA_ActionCommandMT - AccessAssessmentThreshold UCI Extension Field

Command

Description	Indicates an instance of an Action Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Capability CommandStatus message.	
Base Type	MA_ActionCommandType	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_ActionCapabilityCommandType	Required
Description	Indicates a new invocation of an Action Capability. Generally, if accepted, the command will result in one or more new Action Activities being created and reported via the ActionActivity message. The request/response interaction terminates as soon as the command is accepted or rejected; this element is not used to interact with an "active" command. Updates and/or additional interaction with the resulting Activity (after the command is accepted) is accomplished via the sibling Activity element.	
Activity	MA_ActivityCommandBaseType	Required
Description	Indicates a command to modify an existing Action Activity (which was previously reported via the ActionActivity message and was marked as "interactive"). The request/response interaction terminates as soon as the modification is accepted or rejected. The modifications are reflected in subsequent ActionActivity messages.	

Table A-4-348: C2 Interface MA_ActionCommandMT - Command UCI Extension Field

ExcludedRequirementTypes		
Description	Indicates other types of Requirements that cannot be decomposed from, used to plan, used to implement, inherited from traced parents or otherwise be associated with the subject Requirement.	
Base Type	MA_RequirementTaxonomyType	
Message Structure		
Field Name	Field Type	Field Usage
Effect	EffectTypeEnum	Repeated
Description	Indicates Effects applicable via the Effect* message set. List size for this element is based on "Select All That Apply" condition.	
Action	MA_ActionTypeEnum	Repeated
Description	Indicates Actions applicable via the Action* message set. List size for this element is based on "Select All That Apply" condition.	
Task	MA_TaskTypeEnum	Repeated
Description	Indicates Tasks applicable via the Task* message set. List size for this element is based on "Select All That Apply" condition.	
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates CapabilityCommands applicable via a [Capability]Command message set. List size for this element is based on "Select All That Apply" condition.	
Response	ResponseTypeEnum	Repeated

Description	Indicates Responses applicable via the Response* message set. List size for this element is based on "Select All That Apply" condition.
-------------	---

Table A-4-349: C2 Interface MA_ActionCommandMT - ExcludedRequirementTypes UCI Extension Field

Kinematic		
Description	Indicates a constraint in the form of kinematic position of Requirement actor or actors. When more than one is given they are logically ANDed.	
Base Type	MA_RequirementKinematicConstraintsType	
Message Structure		
Field Name	Field Type	Field Usage
ApplicableObject	RequirementObjectEnum	Required
Description	Indicates which Requirement actor the sibling kinematic constraints are applicable to.	
Geo	GeoFiltersQueryType	Repeated
Description	This element gives a geographical filter to the query.	
Orbital	OrbitalFiltersQueryType	Repeated
Description	This element gives an orbital filter to the query.	
LookAngleConstraints	AnglePairType	Optional
Description	The angle from true north to the line-of-sight vector from the platform to the target tangent plane.	

Table A-4-350: C2 Interface MA_ActionCommandMT - Kinematic UCI Extension Field

EngagementParameters		
Description	Provides engagement parameters that this requirement should adhere to.	
Base Type	MA_EngagementParametersType	
Message Structure		
Field Name	Field Type	Field Usage
InterceptTactic	MA_InterceptTacticChoiceType	Optional
Description	The type of intercept tactic to be employed. Used in combination with shot parameters to define tactics like Skate or Banzai.	
ShotParameters	MA_ShotParametersType	Optional
Description	Provides shot parameters that this requirement should adhere to.	
EnableTargetRecalculation	boolean	Optional
Description	This field specifies that MA should recalculate optimal targets during the engagement.	

Table A-4-351: C2 Interface MA_ActionCommandMT - EngagementParameters UCI Extension Field

Subject	
Description	Indicates Subjects of the AccessAssessment that are required to match the filter. If omitted, any Subject satisfies the filter.
Base Type	MA_AssetFilterType
Message Structure	

Field Name	Field Type	Field Usage
System	MA_SystemFilterType	Optional
Description	Indicates a filter on characteristics of a System asset. The asset filter is satisfied if a match is found in this element OR the sibling Entity element.	
Entity	MA_EntityFilterType	Optional
Description	Indicates a filter on characteristics of an Entity asset. The asset filter is satisfied if a match is found in this element OR the sibling System element.	

Table A-4-352: C2 Interface MA_ActionCommandMT - Subject UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActionCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Command	MA_ActionCommandType	Repeated
Description	Indicates an instance of an Action Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Capability CommandStatus message.	

Table A-4-353: C2 Interface MA_ActionCommandMT - MessageData UCI Extension Field

AllowedRequirementTypes		
Description	Indicates other types of Requirements that can be decomposed from, used to plan, used to implement, inherited from traced parents or otherwise associated with the subject Requirement.	
Base Type	MA_RequirementTaxonomyType	
Message Structure		
Field Name	Field Type	Field Usage
Effect	EffectTypeEnum	Repeated
Description	Indicates Effects applicable via the Effect* message set. List size for this element is based on "Select All That Apply" condition.	
Action	MA_ActionTypeEnum	Repeated
Description	Indicates Actions applicable via the Action* message set. List size for this element is based on "Select All That Apply" condition.	
Task	MA_TaskTypeEnum	Repeated
Description	Indicates Tasks applicable via the Task* message set. List size for this element is based on "Select All That Apply" condition.	
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates CapabilityCommands applicable via a [Capability]Command message set. List size for this element is based on "Select All That Apply" condition.	

Response	ResponseTypeEnum	Repeated
Description	Indicates Responses applicable via the Response* message set. List size for this element is based on "Select All That Apply" condition.	

Table A-4-354: C2 Interface MA_ActionCommandMT - AllowedRequirementTypes UCI Extension Field

Entity		
Description	Indicates a filter on characteristics of an Entity asset. The asset filter is satisfied if a match is found in this element OR the sibling System element.	
Base Type	MA_EntityFilterType	
Message Structure		
Field Name	Field Type	Field Usage
Designation	MA_DesignationFilterType	Optional
Description	Indicates a type of Entity designation, established by the Designation message, required to satisfy the filter.	
Characteristics	MA_EntityComparativeType	Repeated
Description	This element indicates an Entity filter requiring a variable logical comparator test between a value in an Entity-associated message and the value given here. Multiple instances are logically ANDed.	
EntityID	EntityID_Type	Repeated
Description	Indicates a specific EntityID that is required to match the filter. If omitted, any EntityID satisfies the filter. Multiple instances are logically ORed.	
Source	EntitySourceEnum	Repeated
Description	Indicates an Entity source that is required to match the filter. If omitted, any Entity source satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the Entity must fall within to satisfy the filter. Multiple instances are logically ORed.	
OrbitalFilter	OrbitalFiltersQueryType	Repeated
Description	Indicates a zone the Entity must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-355: C2 Interface MA_ActionCommandMT - Entity UCI Extension Field

4.1.84 MA_ActionCommandStatusMT UCI Extension

MA_ActionCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ActionCommandStatusMDT

Table A-4-356: C2 Interface MA_ActionCommandStatusMT UCI Extension

MessageData

Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActionCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-357: C2 Interface MA_ActionCommandStatusMT - MessageData UCI Extension Field

4.1.85 MA_MissionPlanActivationStatusMT UCI Extension

MA_MissionPlanActivationStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	OpPlanID : MA_OpPlanID_Type MessageData : MA_MissionPlanActivationStatusMDT Plans : MA_PlansReferenceBaseType SubPlanActivationState : MA_PlanActivationStateType

Table A-4-358: C2 Interface MA_MissionPlanActivationStatusMT UCI Extension

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional

Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-359: C2 Interface MA_MissionPlanActivationStatusMT - OpPlanID UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanActivationStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	The ID of the MissionPlan this status pertains to.	
PlanActivationState	PlanActivationStateEnum	Required
Description	Indicates the activation state of the MissionPlan.	
SubPlanActivationState	MA_PlanActivationStateType	Repeated
Description	Indicates the activation state of a SubPlan or SubPlans of the associated MissionPlan. An instance of this element should include all of the SubPlans in a given state; the cardinality is based in the number of states in the associated activation state enumerated type.	

Table A-4-360: C2 Interface MA_MissionPlanActivationStatusMT - MessageData UCI Extension Field

Plans		
Description	Indicates the Plan or Plans in the sibling ActivationState.	
Base Type	MA_PlansReferenceBaseType	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	

RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-361: C2 Interface MA_MissionPlanActivationStatusMT - Plans UCI Extension Field

SubPlanActivationState		
Description	Indicates the activation state of a SubPlan or SubPlans of the associated MissionPlan. An instance of this element should include all of the SubPlans in a given state; the cardinality is based in the number of states in the associated activation state enumerated type.	
Base Type	MA_PlanActivationStateType	
Message Structure		
Field Name	Field Type	Field Usage
ActivationState	PlanActivationStateEnum	Required
Description	Indicates an activation state that one or more *Plans is in.	
Plans	MA_PlansReferenceBaseType	Required
Description	Indicates the Plan or Plans in the sibling ActivationState.	

Table A-4-362: C2 Interface MA_MissionPlanActivationStatusMT - SubPlanActivationState UCI Extension Field

4.1.86 MA_ActionStatusMT UCI Extension

MA_ActionStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	Traceability : MA_RequirementStatusTraceabilityType Plans : MA_PlansReferenceType OpPlanID : MA_OpPlanID_Type MessageData : MA_ActionStatusMDT ExecutingSystemOrPackage : MA_PackageSystemType

Table A-4-363: C2 Interface MA_ActionStatusMT UCI Extension

Traceability		
Description		Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.
Base Type		MA_RequirementStatusTraceabilityType
Message Structure		
Field Name	Field Type	Field Usage
Plans	MA_PlansReferenceType	Optional
Description	Indicates *Plans the Requirement is associated with.	
PlannedActivityID	PlannedActivityID_Type	Repeated
Description	Indicates a specific Planned Activity the Requirement is associated with.	
CapabilityID	CapabilityID_Type	Repeated
Description	Identifies a specific Capability the Requirement is associated with.	
CommandID	CommandID_Type	Repeated
Description	Indicates the ID of an associated [Capability]Command.	
ActivityID	ActivityID_Type	Repeated
Description	Indicates the ID of an associated actual/executing/executed Activity.	

Table A-4-364: C2 Interface MA_ActionStatusMT - Traceability UCI Extension Field

Plans		
Description		Indicates *Plans the Requirement is associated with.
Base Type		MA_PlansReferenceType
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated

Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-365: C2 Interface MA_ActionStatusMT - Plans UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-366: C2 Interface MA_ActionStatusMT - OpPlanID UCI Extension Field

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.

Base Type	MA_ActionStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ActionID	ActionID_Type	Required
Description	Indicates the unique ID of the Action whose execution status is given by sibling elements.	
ExecutingSystemOrPackage	MA_PackageSystemType	Required
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
ExecutionState	RequirementExecutionStateEnum	Required
Description	Identifies the state of the Requirement.	
ExecutionStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling State element. This element is only expected when the State is in a potentially undesirable state such as failed or completed with less than optimum results. It is strongly encouraged for transitions to failed or dropped.	
ActualTiming	RequirementTimingType	Repeated
Description	Indicates actual timing status for the Requirement. Allows for defining for each timing type (RequirementTimingEnum).	
PercentCompleted	PercentType	Optional
Description	Percentage of assigned Requirement completion. The percentage increments until the Requirement has COMPLETED or FAILED. A percent complete of 0 indicates the Requirement has not yet begun execution, and a failed Requirement may have any percentage between 1 - 99.	
Traceability	MA_RequirementStatusTraceabilityType	Optional
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.	
Metrics	MetricsType	Optional
Description	Specifies the actual metrics associated with the Requirements.	

Table A-4-367: C2 Interface MA_ActionStatusMT - MessageData UCI Extension Field

ExecutingSystemOrPackage

Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-368: C2 Interface MA_ActionStatusMT - ExecutingSystemOrPackage UCI Extension Field

4.1.87 MA_CarrierReportMT UCI Extension

MA_CarrierReportMT	
Description	See the annotation in the associated message carrier status. See the XSD File for more info
Ext. Fields	LaunchCoordinates : MA_CarrierRunwayCoordinatesType Runway : MA_CarrierRunwayType CarrierReportID : MA_CarrierReportID_Type Direction : MA_AngleRelativeType Catapult : MA_CatapultType Information : MA_CarrierInformationType CatapultID : MA_CatapultID_Type MessageData : MA_CarrierReportMDT LandingCoordinates : MA_CarrierRunwayCoordinatesType Direction : MA_AngleRelativeType

Table A-4-369: C2 Interface MA_CarrierReportMT UCI Extension

LaunchCoordinates	
Description	Specifies the start coordinates of the catapult used for Launch.
Base Type	MA_CarrierRunwayCoordinatesType
Message Structure	

Field Name	Field Type	Field Usage
Start	Point3D_RelativeType	Required
Description	The waypoint at the start of the runway.	
Threshold	Point3D_RelativeType	Optional
Description	The waypoint at the nearest point of the runway.	
Limit	Point3D_RelativeType	Optional
Description	The waypoint at the furthest point of the runway.	

Table A-4-370: C2 Interface MA_CarrierReportMT - LaunchCoordinates UCI Extension Field

Runway		
Description	Contains details of the runway used for landing.	
Base Type	MA_CarrierRunwayType	
Message Structure		
Field Name	Field Type	Field Usage
RunwayID	RunwayID_Type	Required
Description	Indicates the unique ID for this Runway. Route paths may reference this runway for takeoff or landing paths.	
Direction	MA_AngleRelativeType	Optional
Description	Indicates offset angle to reference frame in radians.	
AvailableLength	DistanceType	Optional
Description	Indicates available length of runway in meters.	
Glideslope	AngleQuarterType	Optional
Description	Indicates glideslope for runway in radians.	
GCA	EmptyType	Optional
Description	Indicates Ground-Controlled Approach service is a available on runway when field is present.	
ILS	EmptyType	Optional
Description	Indicates Instrument Landing Systems service is a available on runway when field is present.	
ApproachLighting	ApproachLightingEnum	Optional
Description	Indicates available approach lighting on runway according to MIL-STD-6016.	
LandingCoordinates	MA_CarrierRunwayCoordinatesType	Optional
Description	Specifies the coordinates of the runway when used for landings.	
DefaultRunwayUsageDetails	RunwayUsageDetailsType	Optional
Description	Specifies terms for using a runway. These details can be used in the decision process when choosing a runway.	

Table A-4-371: C2 Interface MA_CarrierReportMT - Runway UCI Extension Field

CarrierReportID

Description	Indicates a unique ID, assigned to this carrier report message.	
Base Type	MA_CarrierReportID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-372: C2 Interface MA_CarrierReportMT - CarrierReportID UCI Extension Field

Direction		
Description	Indicates offset angle to refence frame in radians.	
Base Type	MA_AngleRelativeType	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceFrameID	ReferenceFrameID_Type	Required
Description	UUID of the reference frame object that this relative angle applies to.	
OffsetAngle	AngleType	Optional
Description	Offset angle relative to the reference frame origin.	

Table A-4-373: C2 Interface MA_CarrierReportMT - Direction UCI Extension Field

Catapult		
Description	Contains details of each catapult for launching.	
Base Type	MA_CatapultType	
Message Structure		
Field Name	Field Type	Field Usage
CatapultID	MA_CatapultID_Type	Required
Description	Indicates the unique ID for this catapult. Route paths may reference this catapult for launch paths.	
Direction	MA_AngleRelativeType	Optional
Description	Indicates offset angle to refence frame in radians.	
AvailableLength	DistanceType	Optional
Description	Indicates available length of runway in meters.	
LaunchCoordinates	MA_CarrierRunwayCoordinatesType	Optional
Description	Specifies the start coordinates of the catapult used for Launch.	

Table A-4-374: C2 Interface MA_CarrierReportMT - Catapult UCI Extension Field

Information

Description	Contains information about an Carrier.	
Base Type	MA_CarrierInformationType	
Message Structure		
Field Name	Field Type	Field Usage
CrashService	CrashServiceEnum	Optional
Description	Indicates availability of crash service on Carrier.	
Runway	MA_CarrierRunwayType	Optional
Description	Contains details of the runway used for landing.	
Catapult	MA_CatapultType	Repeated
Description	Contains details of each catapult for launching.	

Table A-4-375: C2 Interface MA_CarrierReportMT - Information UCI Extension Field

CatapultID		
Description	Indicates the unique ID for this catapult. Route paths may reference this catapult for launch paths.	
Base Type	MA_CatapultID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-376: C2 Interface MA_CarrierReportMT - CatapultID UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CarrierReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
CarrierReportID	MA_CarrierReportID_Type	Required
Description	Indicates a unique ID, assigned to this carrier report message.	
CarrierID	SystemID_Type	Required
Description	Indicates a unique ID, assigned to this carrier report message.	
IdentityReferenceID	CarrierReferenceID_ChoiceType	Required
Description	Indicates whether message is self-reported or reported by third party.	
Information	MA_CarrierInformationType	Optional

Description	Contains information about an Carrier.
-------------	--

Table A-4-377: C2 Interface MA_CarrierReportMT - MessageData UCI Extension Field

LandingCoordinates		
Description	Specifies the coordinates of the runway when used for landings.	
Base Type	MA_CarrierRunwayCoordinatesType	
Message Structure		
Field Name	Field Type	Field Usage
Start	Point3D_RelativeType	Required
Description	The waypoint at the start of the runway.	
Threshold	Point3D_RelativeType	Optional
Description	The waypoint at the nearest point of the runway.	
Limit	Point3D_RelativeType	Optional
Description	The waypoint at the furthest point of the runway.	

Table A-4-378: C2 Interface MA_CarrierReportMT - LandingCoordinates UCI Extension Field

Direction		
Description	Indicates offset angle to refence frame in radians.	
Base Type	MA_AngleRelativeType	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceFrameID	ReferenceFrameID_Type	Required
Description	UUID of the reference frame object that this relative angle applies to.	
OffsetAngle	AngleType	Optional
Description	Offset angle relative to the reference frame origin.	

Table A-4-379: C2 Interface MA_CarrierReportMT - Direction UCI Extension Field

4.1.88 MA_CarrierStateMT UCI Extension

MA_CarrierStateMT	
Description	See the annotation in the associated message carrier state. See the XSD File for more info
Ext. Fields	CarrierStateID : MA_CarrierStateID_Type CatapultID : MA_CatapultID_Type Catapult : MA_CatapultType Runway : MA_CarrierRunwayType Information : MA_CarrierStateInformationType MessageData : MA_CarrierStateMDT

Table A-4-380: C2 Interface MA_CarrierStateMT UCI Extension

CarrierStateID		
Description	Indicates a unique ID, assigned to this carrier state message.	
Base Type	MA_CarrierStateID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-381: C2 Interface MA_CarrierStateMT - CarrierStateID UCI Extension Field

CatapultID		
Description	Indicates the unique ID for this catapult. Route paths may reference this catapult for launch paths.	
Base Type	MA_CatapultID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-382: C2 Interface MA_CarrierStateMT - CatapultID UCI Extension Field

Catapult		
Description	Contains details of each catapult for launching.	
Base Type	MA_CatapultType	
Message Structure		
Field Name	Field Type	Field Usage
CatapultID	MA_CatapultID_Type	Required
Description	Indicates the unique ID for this catapult. Route paths may reference this catapult for launch paths.	
Direction	MA_AngleRelativeType	Optional
Description	Indicates offset angle to reference frame in radians.	
AvailableLength	DistanceType	Optional
Description	Indicates available length of runway in meters.	

LaunchCoordinates	MA_CarrierRunwayCoordinatesType	Optional
Description	Specifies the start coordinates of the catapult used for Launch.	

Table A-4-383: C2 Interface MA_CarrierStateMT - Catapult UCI Extension Field

Runway		
Description	Contains details of the runway used for landing.	
Base Type	MA_CarrierRunwayType	
Message Structure		
Field Name	Field Type	Field Usage
RunwayID	RunwayID_Type	Required
Description	Indicates the unique ID for this Runway. Route paths may reference this runway for takeoff or landing paths.	
Direction	MA_AngleRelativeType	Optional
Description	Indicates offset angle to refence frame in radians.	
AvailableLength	DistanceType	Optional
Description	Indicates available length of runway in meters.	
Glideslope	AngleQuarterType	Optional
Description	Indicates glideslope for runway in radians.	
GCA	EmptyType	Optional
Description	Indicates Ground-Controlled Approach service is a available on runway when field is present.	
ILS	EmptyType	Optional
Description	Indicates Instrument Landing Systems service is a available on runway when field is present.	
ApproachLighting	ApproachLightingEnum	Optional
Description	Indicates available approach lighting on runway according to MIL-STD-6016.	
LandingCoordinates	MA_CarrierRunwayCoordinatesType	Optional
Description	Specifies the coordinates of the runway when used for landings.	
DefaultRunwayUsageDetails	RunwayUsageDetailsType	Optional
Description	Specifies terms for using a runway. These details can be used in the decision process when choosing a runway.	

Table A-4-384: C2 Interface MA_CarrierStateMT - Runway UCI Extension Field

Information		
Description	Contains information about an Carrier.	
Base Type	MA_CarrierStateInformationType	
Message Structure		
Field Name	Field Type	Field Usage
Operational	EmptyType	Optional

	Description	Indicates Carrier is operational if present.
AirRaidState	AirRaidStateEnum	Optional
	Description	Indicated air raid state of Carrier according to MIL-STD-6016.
Contamination	AirfieldContaminationType	Optional
	Description	Contains contamination details about a Carrier.
SHORADEZ_Active	EmptyType	Optional
	Description	Indicates the SHORADEZ (Short Range Air Defense Engagement Zone) is active The zone is known by context.
Runway	MA_CarrierRunwayStateType	Optional
	Description	Contains details of the runway used for landing.
Catapult	MA_CatapultStateType	Repeated
	Description	Contains details of each catapult for launching.
QNH_Setting	PressureType	Optional
	Description	Indicates atmospheric pressure of an Carrier in kilopascals.

Table A-4-385: C2 Interface MA_CarrierStateMT - Information UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CarrierStateMDT	
Message Structure		
Field Name	Field Type	Field Usage
CarrierStateID	MA_CarrierStateID_Type	Required
Description	Indicates a unique ID, assigned to this carrier state message.	
CarrierID	SystemID_Type	Required
Description	Indicates a unique ID, assigned to this carrier state message.	
IdentityReferenceID	CarrierReferenceID_ChoiceType	Required
Description	Indicates whether message is self-reported or reported by third party.	
ObservationTime	DateTimeType	Required
Description	Indicates the observation time of carrier state.	
Information	MA_CarrierStateInformationType	Optional
Description	Contains information about an Carrier.	
Weather	WeatherAreaDataType	Optional
Description	Contains weather details about a carrier. The wind in the WindData element provides wind information at ground level of the carrier.	
DepartureCase	MA_CaseTypeEnum	Optional
Description	This is the Case which indicates visibility level which impacts the departure routing	
RecoveryCase	MA_CaseTypeEnum	Optional

Description	This is the Case which indicates visibility level which impacts the recovery routing	
DepartureReferenceRadial	AngleType	Optional
Description	This is the Reference Radial used by ACPs departing the carrier.	
CarrierStores	AirfieldStoresPET	Repeated
Description	Contains details about stores available on an Carrier.	

Table A-4-386: C2 Interface MA_CarrierStateMT - MessageData UCI Extension Field

4.1.89 MA_PositionReportDetailedMT UCI Extension

MA_PositionReportDetailedMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	PositionReportData : MA_PositionReportDataType MessageData : MA_PositionReportDetailedMDT

Table A-4-387: C2 Interface MA_PositionReportDetailedMT UCI Extension

PositionReportData		
Description	If multiple instances are given, each should be of a different navigation solution type as indicated by the child element.	
Base Type	MA_PositionReportDataType	
Message Structure		
Field Name	Field Type	Field Usage
PositionSource	PositionSourceID_ChoiceType	Required
Description	The source of the positional data.	
ComponentID	ComponentID_Type	Optional
Description	The ID of the specific component within the subsystem that is the source of this data. This can be used if multiple redundant INS/GPS units are represented as a single subsystem.	
NavigationSolutionState	NavigationSolutionStateEnum	Required
Description	The navigation solution state indicates what sensor inputs the navigation unit is using to generate its kinematic solution.	
FigureOfMerit	BytePositiveType	Optional
Description	A FOM is typically calculated as the root-sum-square of the estimated errors contributing to the solution accuracy. Example criteria include: a. GPS receiver state (e.g., carrier tracking, code tracking, acquisition) b. Carrier to noise ratio	

	c. Satellite geometry (DOP value) d. Satellite range accuracy (URA value) e. Ionospheric measurement or modeling error f. Receiver aiding used g. Kalman filter error estimates. The resultant FOM is presented as a numerical value from 1 to 9, where 1 indicates the best navigation performance.	
Kinematics	MA_DetailedKinematicsType	Required
Description	The kinematic state of the vehicle.	
KinematicsError	DetailedKinematicsErrorType	Required
Description	Indicates the covariance matrix of the vehicle, containing detailed kinematic errors of the position, velocity, and orientation. See the DetailedKinematicsErrorType element annotations for details.	
SolutionCorrections	NavigationSolutionCorrectionsType	Optional
Description	This element contains the corrections applied by the measurement unit to the reported values.	

Table A-4-388: C2 Interface MA_PositionReportDetailedMT - PositionReportData UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PositionReportDetailedMDT	
Message Structure		
Field Name	Field Type	Field Usage
PositionReportData	MA_PositionReportDataType	Repeated
Description	If multiple instances are given, each should be of a different navigation solution type as indicated by the child element.	

Table A-4-389: C2 Interface MA_PositionReportDetailedMT - MessageData UCI Extension Field

4.1.90 MA_PrioritizationListMT UCI Extension

MA_PrioritizationListMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ListType : MA_PrioritizationListEnum ListItem : MA_PrioritizationListItemType

MessageData : MA_PrioritizationListMDT
--

Table A-4-390: C2 Interface MA_PrioritizationListMT UCI Extension

ListType	
Description	Indicates the type of prioritization list. For example, battlespace objects can be prioritized differently for targeting vs. protection as indicated by enumerates given in this element.
Base Type	MA_PrioritizationListEnum
Message Structure	
Enumeration Literal	Description
THREAT_TARGET_PRIORITIZATION_LIST	A prioritized list of battlespace objects or areas that are prioritized by an operational or tactical planner. For planning purposes, the ListItem associated with this enumeration could include, for example, an entity, a signal, a point or region.
CRITICAL_ASSET_LIST	A prioritized list of battlespace objects or areas that are prioritized by the joint force commander to be defended with the resources available. Critical assets are generally specific assets of such extraordinary importance that their loss or degradation would have a significant and debilitating effect on operations or the mission. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system or a point.
JIPTL	The Joint Integrated Prioritization Target List (JPITL) is a prioritized list of targets and associated data approved by the Joint Forces Commander or designated representative. An approved JIPTL is the central product of the target development cycle. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity or a system.
JIPTL_NOMINATION	A product of the target development phase is the JPITL nomination list. Targeters determine this list during the objectives, effects, and guidance phase and analyze which targets should be struck (or otherwise affected) to accomplish them. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity or a system.
JOINT_TARGET_LIST	A consolidated list of selected targets considered to have military significance in the combatant commander's area of responsibility. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system, a point, or area.
MISSION_TARGET_LIST	The list of battlespace targets that are considered to have military significance and are required for the successful completion of the mission. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system, a point, or area.
NO_STRIKE_LIST	A list of battlespace objects characterized as protected from the effects of military operations under international law or Engagement Criteria. Attacking these may violate Law of Armed Conflict (LOAC) or Engagement Criteria or interfere with friendly relations with indigenous personnel or governments. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system, a point, or area.

RESTRICTED_TARGET_LIST	A list of targets that have specific restrictions imposed upon them. Actions on restricted targets are prohibited until coordinated and approved by the establishing authority. Targets are restricted because certain types of actions against them may have negative political, cultural, or propaganda implications, or may interfere with projected friendly operations. The Restricted Target List (RTL) is nominated by elements of the joint force and approved by the JFC. Targets on this list may only be struck with JFC or higher approval. Actions taken by an opponent may remove a target from the RTL. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system, a point, or area.
DEFENDED_ASSET_LIST	The Defended Asset List (DAL) is a listing of those assets from the critical asset list prioritized by the joint force commander to be defended with the resources available. Critical assets that are reinforced with additional protection capabilities or capabilities from other combat power elements become part of the DAL. It represents what can be protected, by priority. The DAL allows commanders to apply finite protection capabilities to the most valuable assets.
PLATFORM_TARGET_LIST	A list of active entity platform targets that meet custody requirements. This list type is used in support of presenting a shot queue prioritization list with List Item of EntityID in accordance with the mission common operating picture.

Table A-4-391: C2 Interface MA_PrioritizationListMT - ListType UCI Extension Field

ListItem		
Description	Indicates an item in a prioritization list of the sibling ListType.	
Base Type	MA_PrioritizationListItemType	
Message Structure		
Field Name	Field Type	Field Usage
Subject	IdentityKindInstanceType	Required
Description	Indicates the subject of the prioritization list item.	
Priority	PrioritizationType	Repeated
Description	Indicates the priority of the item. If priority for any child PriorityType is given, then omitted PriorityTypes for the sibling Subject have no/zero priority. No duplicates allowed; at most one instance of each of the child PriorityTypes is allowed. If the child PriorityType is not used, only one instance is allowed.	
ProbabilityOfKill	PercentType	Optional
Description	Indicates the probability of kill, in a percentage where a value of 100.0 = 100%, of a selected target with an available capability.	
ObjectCorrelation	ObjectCorrelationType	Optional
Description	Object Correlation contains a description of the correlation of this object with another object as well as whether the correlating system has C2 responsibilities or not, to indicate a rough level of confidence in the information.	

Table A-4-392: C2 Interface MA_PrioritizationListMT - ListItem UCI Extension Field

MessageData	
Description	See annotations in child elements and messages/elements that use this type

	for details.	
Base Type	MA_PrioritizationListMDT	
Message Structure		
Field Name	Field Type	Field Usage
PrioritizationListID	PrioritizationListID_Type	Required
Description	Indicates the unique ID of the prioritization list.	
ListType	MA_PrioritizationListEnum	Required
Description	Indicates the type of prioritization list. For example, battlespace objects can be prioritized differently for targeting vs. protection as indicated by enumerates given in this element.	
ListItem	MA_PrioritizationListItemType	Repeated
Description	Indicates an item in a prioritization list of the sibling ListType.	
OpOrderTraceability	OrderTraceabilityType	Repeated
Description	Indicates an operational order which this PrioritizationList is traceable to. This does not mean ranking. This element refers to a Planning Order, Commander's Intent, or other Order that came from a higher echelon. The higher echelon is identified by the OrderSourceID.	
OpDescription	OpDescriptionType	Optional
Description	Indicates a human readable description of the purpose of the prioritization list.	
ApplicableSystemID	SystemID_Type	Repeated
Description	One or more Systems to which the prioritization applies. If omitted, the prioritization applies to all Systems.	
ApplicableServiceID	ServiceID_Type	Repeated
Description	One or more Services to which the mission response list applies. If omitted, the settings apply to all Services of the Systems given in the sibling ApplicableSystemID.	
ApplicableZone	ZoneType	Optional
Description	Zones to which the prioritization applies.	
Schedule	ScheduleType	Optional
Description	Scheduled times to which the prioritization applies.	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-393: C2 Interface MA_PrioritizationListMT - MessageData UCI Extension Field

4.1.91 MA_ResponsePlanCommandStatusMT UCI Extension

MA_ResponsePlanCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details.

	See the XSD File for more info
Ext. Fields	MessageData : MA_ResponsePlanCommandStatusMDT AssociatedPlans : MA_PlanReferenceType AllocationResult : MA_ResponsePlanningResultType OpPlanID : MA_OpPlanID_Type

Table A-4-394: C2 Interface MA_ResponsePlanCommandStatusMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_ResponsePlanCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	ResponsePlanCommandID_Type	Required
Description	The unique ID of the ResponsePlanCommand this status applies to.	
PlanningStatus	PlanCommandStatusType	Required
Description	Indicates the status of the *PlanCommand.	
AllocationResult	MA_ResponsePlanningResultType	Repeated
Description	Indicates allocation results per Response.	
ResultingPlanID	ResponsePlanID_Type	Repeated
Description	This element indicates the unique ID or IDs of any ResponsePlans that were generated.	

Table A-4-395: C2 Interface MA_ResponsePlanCommandStatusMT - MessageData UCI Extension Field

AssociatedPlans		
Description	Indicates *Plan associated with the sibling PlanningResult element. If the sibling PlanningResult indicates the Requirement was/remained allocated then this element indicates the specific *Plan it is/remains allocated in. If the PlanningResult indicates the Requirement was DEALLOCATED then this element indicates the constraining *Plan it was DEALLOCATED from. This element isn't expected when the PlanningResult indicates UNALLOCATED.	
Base Type	MA_PlanReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Optional
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Optional
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Optional

Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Optional
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Optional
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Optional
Description	Indicates a reference to a RouteActivityPlan.	
CommScheduleAllocationID	CommScheduleAllocationID_Type	Optional
Description	Indicates a reference to a Comms allocation.	
ActivityPlanID	ActivityPlanID_Type	Optional
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Optional
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Optional
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Optional
Description	Indicates a reference to a ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Optional
Description	Indicates a reference to an OpPlan.	

Table A-4-396: C2 Interface MA_ResponsePlanCommandStatusMT - AssociatedPlans UCI Extension Field

AllocationResult		
Description	Indicates allocation results per Response.	
Base Type	MA_ResponsePlanningResultType	
Message Structure		
Field Name	Field Type	Field Usage
ResponseID	ResponseID_Type	Required
Description	Unique object identifier for the Response whose planning results are given by sibling elements.	
PlanningResult	PlanningResultEnum	Required
Description	Indicates the outcome of attempting to allocate or plan activities for the Requirement.	
SystemID	SystemID_Type	Required
Description	Indicates the SystemID of the System whose *Plan are associated with the sibling PlanningResult element.	
AssociatedPlans	MA_PlanReferenceType	Optional
Description	Indicates *Plan associated with the sibling PlanningResult element. If the sibling PlanningResult indicates the Requirement was/remained allocated then this element indicates the specific *Plan it is/remains allocated in. If the PlanningResult indicates the Requirement was DEALLOCATED then this element indicates the constraining	

	*Plan it was DEALLOCATED from. This element isn't expected when the PlanningResult indicates UNALLOCATED.	
NotAllocatedReason	UnallocatedReasonType	Repeated
Description	Indicates a reason why the Requirement wasn't allocated or reallocated. If the sibling PlanningResult element indicates the Requirement was left not allocated then this element indicates why. Multiple instances of this element can provide the reason for each System that was attempted and even many reasons for each. If the PlanningResult indicates the Requirement was allocated then this element can still be used to indicate reasons for failed attempts to allocate to other Systems or plan, prior to the successful allocation.	

Table A-4-397: C2 Interface MA_ResponsePlanCommandStatusMT - AllocationResult UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-398: C2 Interface MA_ResponsePlanCommandStatusMT - OpPlanID UCI Extension Field

4.1.92 MA_ResponsePlanCommandMT UCI Extension

MA_ResponsePlanCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ResponsePlanCommandMDT

Table A-4-399: C2 Interface MA_ResponsePlanCommandMT UCI Extension

MessageData	
Description	Indicates the data being conveyed by the message.
Base Type	MA_ResponsePlanCommandMDT

Message Structure		
Field Name	Field Type	Field Usage
CommandID	ResponsePlanCommandID_Type	Required
Description	The unique ID of the command. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	
ParentPlanCommandID	ResponsePlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which this ResponsePlanCommand originated from.	
Inputs	ResponsePlanInputsType	Required
Description	Indicates data and references to be used to create the ResponsePlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	

Table A-4-400: C2 Interface MA_ResponsePlanCommandMT - MessageData UCI Extension Field

4.1.93 MA_PlanningFunctionSettingsCommandMT UCI Extension

MA_PlanningFunctionSettingsCommandMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	AutonomousPlanningAction : MA_PlanningAllowedEscalationType OpPlan : MA_OpPlanPartsType AutonomousPlanningResponseChoice : MA_MissionPlanningAutonomyResponseChoiceType MissionPlanningAutonomy : MA_MissionPlanningAutonomySettingType OrbitActivityPlan : MA_ActivityPlanPartsType RouteActivityPlan : MA_ActivityPlanPartsType ByResultSetting : MA_MissionPlanningAutonomySettingByResultType PlanningAllowed : MA_PlanningAllowedType OutputPlanParts : MA_PlanPartsType AllowedType : MA_PlanningAllowedType AutonomousAction : MA_MissionPlanningByResultAutonomousActionType MessageData : MA_PlanningFunctionSettingsCommandMDT

ActivityPlan : MA_ActivityPlanPartsType
TaskPlan : MA_TaskPlanPartsType

Table A-4-401: C2 Interface MA_PlanningFunctionSettingsCommandMT UCI Extension

AutonomousPlanningAction		
Description	This element indicates the allowed autonomous mission planning for the ancestor Trigger. It also indicates the expected MissionContingencyAlert for the ancestor Trigger; whenever autonomous mission planning is allowed and triggered, a MissionContingencyAlert is expected.	
Base Type	MA_PlanningAllowedEscalationType	
Message Structure		
Field Name	Field Type	Field Usage
AutonomousPlanningActionID	AutonomousPlanningActionID_Type	Required
Description	Assigns a unique ID to an allowed planning action. This ID can be reference in *Plans, alerts, etc. that result when the planning action is triggered.	
ByResultSetting	MA_MissionPlanningAutonomySettingByResultType	Repeated
Description	This element allows control of the escalation of the autonomous replanning. If the autonomous function indicated by the sibling AllowedType leads to a "by result" trigger described here, then additional autonomous planning is allowed as described here. For example, if Tasks are dropped as a result of initial autonomous replanning then this element can be used to enable/disable a secondary "escalated" planning iteration that includes global Task allocation. If omitted, the sibling AllowedType is allowed regardless of result.	
AllowedType	MA_PlanningAllowedType	Required
Description	This element defines the mission planning type that is allowed to be autonomously triggered.	

Table A-4-402: C2 Interface MA_PlanningFunctionSettingsCommandMT - AutonomousPlanningAction UCI Extension Field

OpPlan		
Description	Indicates applicable OpPlan parts.	
Base Type	MA_OpPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	

OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpRouting	EmptyType	Optional
Description	Indicates an OpRouting is applicable to the associated *Plan. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-403: C2 Interface MA_PlanningFunctionSettingsCommandMT - OpPlan UCI Extension Field

AutonomousPlanningResponseChoice		
Description	Indicates the autonomous mission planning type or types allowed for the sibling Trigger.	
Base Type	MA_MissionPlanningAutonomyResponseChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
AutonomousPlanningAction	MA_PlanningAllowedEscalationType	Repeated
Description	This element indicates the allowed autonomous mission planning for the ancestor Trigger. It also indicates the expected MissionContingencyAlert for the ancestor Trigger; whenever autonomous mission planning is allowed and triggered, a MissionContingencyAlert is expected.	
AlertOnly	EmptyType	Required
Description	This element indicates that autonomous mission planning isn't allowed for the ancestor Trigger but a MissionContingencyAlert is expected.	

Table A-4-404: C2 Interface MA_PlanningFunctionSettingsCommandMT - AutonomousPlanningResponseChoice UCI Extension Field

MissionPlanningAutonomy		
Description	Indicates commanded settings for autonomous mission planning capabilities of the System.	
Base Type	MA_MissionPlanningAutonomySettingType	
Message Structure		
Field Name	Field Type	Field Usage
Trigger	PlanningByCaseTriggerType	Required
Description	Indicates an allowed trigger for autonomous planning.	
AutonomousPlanningResponseChoice	MA_MissionPlanningAutonomyResponseChoiceType	Required
Description	Indicates the autonomous mission planning type or types allowed for the sibling Trigger.	
PlanningProcessID	PlanningProcessID_Type	Optional
Description	Indicates the unique ID of a planning process which the settings are applicable to. If omitted, the setting is applicable to all processes of the corresponding System.	
MinimumResponseInterval	DurationType	Optional

Description	Indicates the minimum time interval between autonomous responses for the sibling Trigger. In other words, regardless of when and how frequently the Trigger occurs, the sibling Response shouldn't be initiated until the minimum time duration given here after the previous Response.
-------------	---

Table A-4-405: C2 Interface MA_PlanningFunctionSettingsCommandMT - MissionPlanningAutonomy UCI Extension Field

OrbitActivityPlan		
Description	Indicates applicable OrbitActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-406: C2 Interface MA_PlanningFunctionSettingsCommandMT - OrbitActivityPlan UCI Extension Field

RouteActivityPlan	
Description	Indicates applicable RouteActivityPlan parts.

Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-407: C2 Interface MA_PlanningFunctionSettingsCommandMT - RouteActivityPlan UCI Extension Field

ByResultSetting	
Description	This element allows control of the escalation of the autonomous replanning. If the autonomous function indicated by the sibling AllowedType leads to a "by result" trigger described here, then additional autonomous planning is allowed as described here. For example, if Tasks are dropped as a result of initial autonomous replanning then this element can be used to enable/disable a secondary "escalated" planning iteration that includes global Task allocation. If omitted, the sibling AllowedType is allowed regardless of result.
Base Type	MA_MissionPlanningAutonomySettingByResultType
Message Structure	

Field Name	Field Type	Field Usage
Trigger	PlanningByResultTriggerType	Required
Description	Indicates a trigger based on the results of a previously initiated autonomous mission planning function.	
AutonomousAction	MA_MissionPlanningByResultAutonomousActionType	Required
Description	Indicates the action or actions allowed for the sibling trigger.	

Table A-4-408: C2 Interface MA_PlanningFunctionSettingsCommandMT - ByResultSetting UCI Extension Field

PlanningAllowed		
Description	This element defines the mission planning type to be triggered. If multiple instances are given, each should be of a different planning type as indicated by the child element.	
Base Type	MA_PlanningAllowedType	
Message Structure		
Field Name	Field Type	Field Usage
PlanAheadDuration	DurationType	Required
Description	Required duration in the future when the Plan should start. Existing *Plan will continue during this time. This duration should account for everything that must happen from replan initiation to new plan activation.	
PlanningProcessID	PlanningProcessID_Type	Required
Description	Indicates the unique ID of the planning process whose autonomous invocation is described the sibling elements. Planning process are declared in the ControlStatus message.	
ConstrainingPlans	AutonomousPlanningConstrainingPlansType	Optional
Description	Indicates existing types of *Plans that can be used as constraints when invoking the planning process indicated by the sibling PlanningProcessID. The types of *Plans indicated here should be consistent with those supported by the planning process as indicated in the ControlStatus message.	
OtherSystemConstrainingPlans	AutonomousPlanningOtherSystemConstrainingPlansType	Repeated
Description	Indicates existing plans of another System that constrain planning. One for each descendant ConstraintUsage.	
OutputPlanParts	MA_PlanPartsType	Optional
Description	Indicates the specific Plan parts of the sibling PlanningType that the System can produce and include in the output Plan. The child choice in this element should match the sibling PlanningType. When omitted, the System can produce all of the Plan parts for the sibling PlanningType.	
ResultsInMissionPlan	boolean	Required
Description	In some cases, the commanding service or HMI may not want to receive the planning process summarized in a MissionPlan message. If TRUE, the results will be published in individual *Plan messages and summarized in a published MissionPlan message. If FALSE, the results will be published in individual *Plan messages without a summary MissionPlan message.	
ForPlanningUseOnly	boolean	Required

Description	Indicates the state to use for the corresponding element in the *PlanCommand when invoking the planning process.
-------------	--

Table A-4-409: C2 Interface MA_PlanningFunctionSettingsCommandMT - PlanningAllowed UCI Extension Field

OutputPlanParts		
Description	Indicates the specific Plan parts of the sibling PlanningType that the System can produce and include in the output Plan. The child choice in this element should match the sibling PlanningType. When omitted, the System can produce all of the Plan parts for the sibling PlanningType.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-410: C2 Interface MA_PlanningFunctionSettingsCommandMT - OutputPlanParts UCI Extension Field

AllowedType	
Description	This element defines the mission planning type that is allowed to be autonomously triggered.
Base Type	MA_PlanningAllowedType
Message Structure	

Field Name	Field Type	Field Usage
PlanAheadDuration	DurationType	Required
Description	Required duration in the future when the Plan should start. Existing *Plan will continue during this time. This duration should account for everything that must happen from replan initiation to new plan activation.	
PlanningProcessID	PlanningProcessID_Type	Required
Description	Indicates the unique ID of the planning process whose autonomous invocation is described the sibling elements. Planning process are declared in the ControlStatus message.	
ConstrainingPlans	AutonomousPlanningConstrainingPlansType	Optional
Description	Indicates existing types of *Plans that can be used as constraints when invoking the planning process indicated by the sibling PlanningProcessID. The types of *Plans indicated here should be consistent with those supported by the planning process as indicated in the ControlStatus message.	
OtherSystemConstrainingPlans	AutonomousPlanningOtherSystemConstrainingPlansType	Repeated
Description	Indicates existing plans of another System that constrain planning. One for each descendant ConstraintUsage.	
OutputPlanParts	MA_PlanPartsType	Optional
Description	Indicates the specific Plan parts of the sibling PlanningType that the System can produce and include in the output Plan. The child choice in this element should match the sibling PlanningType. When omitted, the System can produce all of the Plan parts for the sibling PlanningType.	
ResultsInMissionPlan	boolean	Required
Description	In some cases, the commanding service or HMI may not want to receive the planning process summarized in a MissionPlan message. If TRUE, the results will be published in individual *Plan messages and summarized in a published MissionPlan message. If FALSE, the results will be published in individual *Plan messages without a summary MissionPlan message.	
ForPlanningUseOnly	boolean	Required
Description	Indicates the state to use for the corresponding element in the *PlanCommand when invoking the planning process.	

Table A-4-411: C2 Interface MA_PlanningFunctionSettingsCommandMT - AllowedType UCI Extension Field

AutonomousAction		
Description	Indicates the action or actions allowed for the sibling trigger.	
Base Type	MA_MissionPlanningByResultAutonomousActionType	
Message Structure		
Field Name	Field Type	Field Usage
PlanningAllowed	MA_PlanningAllowedType	Repeated
Description	This element defines the mission planning type to be triggered. If multiple instances are given, each should be of a different planning type as indicated by the child element.	
AlertOnly	EmptyType	Required

Description	This element indicates that autonomous mission planning isn't allowed for the ancestor Trigger but a MissionContingencyAlert is expected.
-------------	---

Table A-4-412: C2 Interface MA_PlanningFunctionSettingsCommandMT - AutonomousAction UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the PlanningFunctionSettingsCommand message.	
Base Type	MA_PlanningFunctionSettingsCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Indicates the unique ID of the System whose planning functions settings are being commanded/changed.	
TransitionDroppedToFailed	boolean	Required
Description	This element specifies whether or not dropped Tasks that cannot be reallocated within the System can be automatically transitioned to the FAILED state for higher level interaction.	
PlanningInterface	PlanInterfaceCommandType	Repeated
Description	Indicates commanded settings for planning interfaces. If multiple instances of this element are given, each should be of a different type of *Plan as enumerated by the child PlanType element.	
MissionPlanningAutonomy	MA_MissionPlanningAutonomySettingType	Repeated
Description	Indicates commanded settings for autonomous mission planning capabilities of the System.	
PlanActivationAutonomy	PlanActivationAutonomyType	Optional
Description	Indicates commanded settings for autonomous plan activation capabilities of the System.	
RoutePlanningContingencyPath	ContingencyPathAutonomyType	Repeated
Description	Indicates commanded route planning settings for the autonomous generation of contingency paths along the primary path. If multiple instances are given, each must be of a different path type as indicated by the child element.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-413: C2 Interface MA_PlanningFunctionSettingsCommandMT - MessageData UCI Extension Field

ActivityPlan	
Description	Indicates applicable ActivityPlan parts.

Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-414: C2 Interface MA_PlanningFunctionSettingsCommandMT - ActivityPlan UCI Extension Field

TaskPlan		
Description	Indicates applicable TaskPlan parts.	
Base Type	MA_TaskPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
TaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	

Table A-4-415: C2 Interface MA_PlanningFunctionSettingsCommandMT - TaskPlan UCI Extension Field

4.1.94 MA_PlanningFunctionSettingsCommandStatusMT UCI Extension

MA_PlanningFunctionSettingsCommandStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_PlanningFunctionSettingsCommandStatusMDT

Table A-4-416: C2 Interface MA_PlanningFunctionSettingsCommandStatusMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the PlanningFunctionSettingsCommandStatus message.	
Base Type	MA_PlanningFunctionSettingsCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-417: C2 Interface MA_PlanningFunctionSettingsCommandStatusMT - MessageData UCI Extension Field

4.1.95 MA_OpLineMT UCI Extension

MA_OpLineMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	Category : MA_OpLineCategoryEnum AppliesToIDs : MA_PackageSystemType MessageData : MA_OpLineMDT

Table A-4-418: C2 Interface MA_OpLineMT UCI Extension

Category	
Description	This element indicates the type of operational line.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-419: C2 Interface MA_OpLineMT - Category UCI Extension Field

AppliesToIDs	
Description	One or more systems to which this item applies. If omitted, item applies to all

	systems.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-420: C2 Interface MA_OpLineMT - AppliesToIDs UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpLineMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpLineID	OpLineID_Type	Required
Description	Indicates the unique ID of the OpLine.	
Category	MA_OpLineCategoryEnum	Required
Description	This element indicates the type of operational line.	
Line	OpLineType	Required
Description	Indicates the geometric description of the OpLine. In practice, operational lines can be geometric lines, areas or in some cases volumes.	
OpDescription	OpDescriptionType	Optional
Description	A human-readable descriptive name with free text remarks.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this operational item to specify what the source or motivation for it originated from. This could be ATO, ACO, etc.	
Source	CreationSourceEnum	Optional
Description	Indicates the source of the information.	
Schedule	ScheduleType	Optional
Description	This element represents a date/time interval associated with the operational item during which the item is in effect.	
AssociatedTime	TimeFunctionType	Repeated

Description	Indicates time related events that are associated to the Op data type such as when activated or when operational. The multiplicity is limited to N-1 options where NONE is an event that has no value, thus removed from list of available options.	
DataLinkIdentifier	DataLinkIdentifierPET	Repeated
Description	List of data link ID. Multiple data link IDs can be reported for the same network type.	
Priority	unsignedInt	Optional
Description	This field represents the priority to be considered when choosing between multiple available points.	
QualifyingTags	QualifyingTagsType	Optional
Description	Provides identity qualifications to augment identification and associated processing of the OpPoint.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
SystemScheduleOverride	SystemScheduleStateType	Repeated
Description	System-specific schedule that will override any part of the main schedule. This allows for system-specific schedule different than main schedule. When adding a SystemScheduleOverride, the child SystemID also must be added to the sibling SystemID list if the sibling list is not empty. The SystemScheduleOverride is independent of time planning. For the system, this override can be done at execution.	

Table A-4-421: C2 Interface MA_OpLineMT - MessageData UCI Extension Field

4.1.96 MA_MissionPlanCommandMT UCI Extension

MA_MissionPlanCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	Inputs : MA_MissionPlanInputsType ActivityPlan : MA_ActivityPlanPartsType ProposedRequirements : MA_RequirementAllocationCommandType RouteActivityPlan : MA_ActivityPlanPartsType ProposedResponse : MA_ResponseAllocationType OrbitActivityPlan : MA_ActivityPlanPartsType ProposedTaskPlan : MA_TaskPlanConstraintType ProposedTask : MA_TaskAllocationType MessageData : MA_MissionPlanCommandMDT TaskType : MA_TaskTypeEnum ProposedEffect : MA_EffectAllocationType PlanningCandidate : MA_RequirementPlanningCandidateType ProposedAction : MA_ActionAllocationType OutputPlanType : MA_PlanPartsType

ProposedRequirementPlans : MA_RequirementPlanConstraintType
 CapabilityCommand : MA_CapabilityTypeEnum

Table A-4-422: C2 Interface MA_MissionPlanCommandMT UCI Extension

Inputs		
Description	Indicates data and references to other messages and their data to be used to create the MissionPlan.	
Base Type	MA_MissionPlanInputsType	
Message Structure		
Field Name	Field Type	Field Usage
PlanningCandidate	MA_RequirementPlanningCandidateType	Repeated
Description	Indicates specific Systems to consider and plan for along with System-specific planning constraints. If omitted, all Tiers and all Systems at and below those that the planning process is applicable to shall be planned. A System is a planning "candidate" because its plan may or may not change as a result of the command; zero to one Plans per *Plan type will potentially be created for each candidate.	
ProposedRequirementPlans	MA_RequirementPlanConstraintType	Optional
Description	Indicates an existing [Requirement]Plan of the System superior to the sibling PlanningCandidates that provides a proposed "requirement deck" to allocate amongst the candidates. This element can be supplemented with additional Requirements from the sibling ProposedRequirements element.	
ProposedRequirements	MA_RequirementAllocationCommandType	Optional
Description	Indicates a proposed Requirement for the planning process. A Requirement given here is added to any Requirements provided in the sibling ProposedRequirementPlans and constraining *Plans of the sibling PlanningCandidates to create the full set of Requirements to be considered by the planning process. A Requirement given here overrides the same Requirement in the sibling ProposedRequirementPlan. An empty list here, combined with no sibling ProposedRequirementPlans is considered a command to deallocate previously allocated Requirements.	
AssociationConstraint	RequirementAssociationConstraintType	Repeated
Description	Indicates an association between Requirements that is a constraint on how they are allocated and planned.	
ResultsInMissionPlan	boolean	Required
Description	In some cases, the commanding service or HMI may not want to receive the planning process summarized in a MissionPlan message. For example, if MissionPlanCommand is being used to produce a combination of plans (such as a RoutePlan and RouteActivityPlan) for a portion of a sortie, with no immediate intent of producing a full mission plan for the whole sortie, then the results could be published without creating a MissionPlan message. If TRUE, the results will be published in individual *Plan messages and summarized in a published MissionPlan message. If FALSE, the results will be published in individual *Plan messages without a summary MissionPlan message.	
OutputPlanType	MA_PlanPartsType	Optional
Description	Indicates a type of Plan that is required as an output of the MissionPlanCommand. When populated, this element must match or be a subset of the *Plans associated with the planning process (sibling PlanningProcessID) as advertised in	

	PlanningFunction*messages. This element is optional when all *Plan outputs of the process are required.	
PlanningProcessID	PlanningProcessID_Type	Required
Description	Indicates the unique ID of the planning process invoked by the *PlanCommand.	
PlanInitiation	PlanInitiationSourceEnum	Required
Description	This element indicates whether the Plan was initiated autonomously from a planning service, was operator initiated or edited, or was created externally.	
PlanningDataSource	PlanningDataSourceEnum	Required
Description	Indicates the category of messages to use as the source for System position, Capability, status, etc. data to use as the basis for the plan.	
ReplanReason	MA_ReplanReasonType	Optional
Description	Indicates the reason for the replan. This element is used during live operations and/or operation with autonomous planning, contingency management, etc.	
EnvironmentOverride	MA_MissionEnvironmentConstraintType	Repeated
Description	Indicates a selective override of an item in the mission environment world state to use/used in the Plan.	
OpConstraint	OpConstraintWeightingType	Repeated
Description	Further constrain a Mission Plan to an operational constraint that indicates how much the constraint should play a role in the planning process. The multiplicity is based on the list of available OpConstraintEnums.	
SpecialInstructionsID	FileLocationID_Type	Optional
Description	Free-text explanation of any extraordinary instructions at the plan level.	

Table A-4-423: C2 Interface MA_MissionPlanCommandMT - Inputs UCI Extension Field

ActivityPlan		
Description	Indicates applicable ActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	

ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-424: C2 Interface MA_MissionPlanCommandMT - ActivityPlan UCI Extension Field

ProposedRequirements		
Description	Indicates a proposed Requirement for the planning process. A Requirement given here is added to any Requirements provided in the sibling ProposedRequirementPlans and constraining *Plans of the sibling PlanningCandidates to create the full set of Requirements to be considered by the planning process. A Requirement given here overrides the same Requirement in the sibling ProposedRequirementPlan. An empty list here, combined with no sibling ProposedRequirementPlans is considered a command to deallocate previously allocated Requirements.	
Base Type	MA_RequirementAllocationCommandType	
Message Structure		
Field Name	Field Type	Field Usage
ProposedEffect	MA_EffectAllocationType	Repeated
Description	Indicates a proposed Effect.	
ProposedAction	MA_ActionAllocationType	Repeated
Description	Indicates a proposed Action.	
ProposedTask	MA_TaskAllocationType	Repeated
Description	Indicates a proposed Task.	
ProposedResponse	MA_ResponseAllocationType	Repeated
Description	Indicates a proposed Response.	

Table A-4-425: C2 Interface MA_MissionPlanCommandMT - ProposedRequirements UCI Extension Field

RouteActivityPlan	
Description	Indicates applicable RouteActivityPlan parts.
Base Type	MA_ActivityPlanPartsType

Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-426: C2 Interface MA_MissionPlanCommandMT - RouteActivityPlan UCI Extension Field

ProposedResponse		
Description	Indicates a proposed Response.	
Base Type	MA_ResponseAllocationType	
Message Structure		
Field Name	Field Type	Field Usage
ResponseID	ResponseID_Type	Required
Description	Indicates the unique ID of the allocated or to-be allocated Response.	
Locked	boolean	Optional
Description	Indicates whether the Requirement's allocation can be modified/removed in subsequent planning steps and/or replans.	

ConstraintOverride	MA_RequirementConstraintsType	Optional
Description	Indicates refined/overridden values of constraints for the Requirement. Constraints can be refined/overridden in inputs (*PlanCommand) and/or outputs (*Plan) of planning processes. Values given in this element refine/override those in the associated [Requirement] message. Reasons for constraint overrides include refinement based on the allocated System, multi-Requirement coordination, etc. Requirement constraints can be 1) given in a [Requirement] message, 2) overridden as a planning input in a [Requirement]PlanCommand message, 3) further refined/overridden during plan creation and reported in a [Requirement]Plan message to inform subsequent planning or execution.	
OtherOverride	RequirementAllocationDetailsType	Optional
Description	Indicates special/override values for miscellaneous [Requirement] message elements not included in the sibling ConstraintOverride element.	

Table A-4-427: C2 Interface MA_MissionPlanCommandMT - ProposedResponse UCI Extension Field

OrbitActivityPlan		
Description	Indicates applicable OrbitActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional

Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-428: C2 Interface MA_MissionPlanCommandMT - OrbitActivityPlan UCI Extension Field

ProposedTaskPlan		
Description	Indicates a proposed TaskPlan.	
Base Type	MA_TaskPlanConstraintType	
Message Structure		
Field Name	Field Type	Field Usage
AllocationPlanID	TaskPlanID_Type	Optional
Description	Indicates the unique ID of the TaskPlan being referenced. When omitted, the current/active TaskPlan for the System is implied.	
ChangeableAllocations	PlanChangeableConstraintsEnum	Required
Description	Indicates which kinds/categories of allocations in the TaskPlan indicated by the sibling AllocationPlanID are considered changeable. The exact definition of "changeable" is left to particular Services and/or Systems to develop according to their requirements. A lenient interpretation would equate "changeable" with "deallocation allowed" thereby giving a System and/or planning Service freedom to deallocate any changeable allocations from the constraining plan in order to optimize a new *Plan for new and/or unchangeable allocations. Those unallocated Tasks would then be dealt with in subsequent planning steps/iterations. With this definition, an "unchangeable" allocation item is "System/vehicle constrained" and therefore the new *Plan being developed should avoid changes that would cause the item to be unallocated. A stricter interpretation might additionally require that any temporal constraints of an unchangeable allocation item from the constraining TaskPlan be unchanged as a result of the new *Plan being developed. In a System of Systems with inter-*Plan temporal dependencies, this stricter interpretation could reduce automated replanning chain reactions.	
TaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a type of Task in the TaskPlan referenced by the sibling AllocationPlanID element that constrains the new *Plan. If any are given, only allocations associated with those Task types are constraints. If omitted, allocations associated with all Task types are constraints. List size for this element is based on "Select All That Apply" condition.	

Table A-4-429: C2 Interface MA_MissionPlanCommandMT - ProposedTaskPlan UCI Extension Field

ProposedTask		
Description	Indicates a proposed Task.	
Base Type	MA_TaskAllocationType	
Message Structure		
Field Name	Field Type	Field Usage
TaskID	TaskID_Type	Required
Description	Indicates the unique ID of the allocated or to-be allocated Task.	

Table A-4-430: C2 Interface MA_MissionPlanCommandMT - ProposedTask UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	MissionPlanCommandID_Type	Required
Description	The ID of the Mission Plan Command. Used to reference the command when providing status.	
ParentMissionPlanCommandID	MissionPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which this MissionPlanCommand originated from. For example, a MissionPlan sent to a System might have as a parent the MissionPlanCommand sent from the operator/commander one level above to the task allocator/planner at that level.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	
Inputs	MA_MissionPlanInputsType	Required
Description	Indicates data and references to other messages and their data to be used to create the MissionPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	

Table A-4-431: C2 Interface MA_MissionPlanCommandMT - MessageData UCI Extension Field

TaskType	
Description	Indicates a type of Task in the TaskPlan referenced by the sibling AllocationPlanID element that constrains the new *Plan. If any are given, only allocations associated with those Task types are constraints. If omitted, allocations associated with all Task types are constraints. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.

AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.
CAP	Indicates the task is to execute a Combat Air Patrol.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESCORT	Indicates the task is to escort another entity.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.
SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.
SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-432: C2 Interface MA_MissionPlanCommandMT - TaskType UCI Extension Field

ProposedEffect		
Description	Indicates a proposed Effect.	
Base Type	MA_EffectAllocationType	
Message Structure		
Field Name	Field Type	Field Usage
EffectID	EffectID_Type	Required
Description	Indicates the unique ID of the allocated or to-be allocated Effect.	
Locked	boolean	Optional
Description	Indicates whether the Requirement's allocation can be modified/removed in subsequent planning steps and/or replans.	
ConstraintOverride	MA_RequirementConstraintsType	Optional
Description	Indicates refined/overridden values of constraints for the Requirement. Constraints can be refined/overridden in inputs (*PlanCommand) and/or outputs (*Plan) of planning	

	processes. Values given in this element refine/override those in the associated [Requirement] message. Reasons for constraint overrides include refinement based on the allocated System, multi-Requirement coordination, etc. Requirement constraints can be 1) given in a [Requirement] message, 2) overridden as a planning input in a [Requirement]PlanCommand message, 3) further refined/overridden during plan creation and reported in a [Requirement]Plan message to inform subsequent planning or execution.	
OtherOverride	RequirementAllocationDetailsType	Optional
Description	Indicates special/override values for miscellaneous [Requirement] message elements not included in the sibling ConstraintOverride element.	

Table A-4-433: C2 Interface MA_MissionPlanCommandMT - ProposedEffect UCI Extension Field

PlanningCandidate		
Description	Indicates specific Systems to consider and plan for along with System-specific planning constraints. If omitted, all Tiers and all Systems at and below those that the planning process is applicable to shall be planned. A System is a planning "candidate" because its plan may or may not change as a result of the command; zero to one Plans per *Plan type will potentially be created for each candidate.	
Base Type	MA_RequirementPlanningCandidateType	
Message Structure		
Field Name	Field Type	Field Usage
RouteGuideline	PlanningGuidelineType	Optional
Description	This element specifies high-level route guidelines that were or should be used for the plan that are not specified or implied by Requirements.	
OrbitGuideline	OrbitGuidelineType	Optional
Description	This element specifies high-level orbit guidelines that were or should be used for the plan that are not specified or implied Requirements.	
SystemID	SystemID_Type	Required
Description	The SystemID of the System to plan for.	
ConstrainingPlans	MA_ConstrainingPlansType	Optional
Description	Indicates existing plans of the System associated with the sibling SystemID that constrain the *Plan or *PlanCommand.	
OtherSystemConstrainingPlans	MA_OtherSystemConstrainingPlansType	Repeated
Description	Indicates existing plans of another System that constrain the *Plan or *PlanCommand.	

Table A-4-434: C2 Interface MA_MissionPlanCommandMT - PlanningCandidate UCI Extension Field

ProposedAction		
Description	Indicates a proposed Action.	
Base Type	MA_ActionAllocationType	
Message Structure		
Field Name	Field Type	Field Usage

ActionID	ActionID_Type	Required
Description	Indicates the unique ID of the allocated or to-be allocated Action.	
Locked	boolean	Optional
Description	Indicates whether the Requirement's allocation can be modified/removed in subsequent planning steps and/or replans.	
ConstraintOverride	MA_RequirementConstraintsType	Optional
Description	Indicates refined/overridden values of constraints for the Requirement. Constraints can be refined/overridden in inputs (*PlanCommand) and/or outputs (*Plan) of planning processes. Values given in this element refine/override those in the associated [Requirement] message. Reasons for constraint overrides include refinement based on the allocated System, multi-Requirement coordination, etc. Requirement constraints can be 1) given in a [Requirement] message, 2) overridden as a planning input in a [Requirement]PlanCommand message, 3) further refined/overridden during plan creation and reported in a [Requirement]Plan message to inform subsequent planning or execution.	
OtherOverride	RequirementAllocationDetailsType	Optional
Description	Indicates special/override values for miscellaneous [Requirement] message elements not included in the sibling ConstraintOverride element.	

Table A-4-435: C2 Interface MA_MissionPlanCommandMT - ProposedAction UCI Extension Field

OutputPlanType		
Description	Indicates a type of Plan that is required as an output of the MissionPlanCommand. When populated, this element must match or be a subset of the *Plans associated with the planning process (sibling PlanningProcessID) as advertised in PlanningFunction*messages. This element is optional when all *Plan outputs of the process are required.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	

ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-436: C2 Interface MA_MissionPlanCommandMT - OutputPlanType UCI Extension Field

ProposedRequirementPlans		
Description	Indicates an existing [Requirement]Plan of the System superior to the sibling PlanningCandidates that provides a proposed "requirement deck" to allocate amongst the candidates. This element can be supplemented with additional Requirements from the sibling ProposedRequirements element.	
Base Type	MA_RequirementPlanConstraintType	
Message Structure		
Field Name	Field Type	Field Usage
ProposedEffectPlan	EffectPlanConstraintType	Optional
Description	Indicates a proposed EffectPlan.	
ProposedActionPlan	ActionPlanConstraintType	Optional
Description	Indicates a proposed ActionPlan.	
ProposedTaskPlan	MA_TaskPlanConstraintType	Optional
Description	Indicates a proposed TaskPlan.	
ProposedResponsePlan	ResponsePlanConstraintType	Optional
Description	Indicates a proposed ResponsePlan.	

Table A-4-437: C2 Interface MA_MissionPlanCommandMT - ProposedRequirementPlans UCI Extension Field

CapabilityCommand	
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_CapabilityTypeEnum
Message Structure	
Enumeration Literal	Description
ACTION	Indicates an action capability.
AIR_SAMPLE	Indicates an air sampling capability.
AMTI	Indicates an airborne moving target indication (AMTI) capability.
AO	Indicates an active optical capability.

CAP	Indicates a cargo delivery capability.
CARGO_DELIVERY	Indicates a cargo delivery capability.
COMINT	Indicates a Communications Intelligence (COMINT) capability.
COMM_RELAY	Indicates a communications relay capability.
COMM_TERMINAL	Indicates a communications terminal capability
COUNTER_SPACE	Indicates a Counter Space Capability.
EA	Indicates an electronic attack (EA) capability.
EFFECT	Indicates an effect capability.
ESM	Indicates an electronic support measures (ESM) capability.
FLIGHT	Indicates a capability for waypoint-based flight tasks/commands.
IFF	Indicates an Identification Friend or Foe (IFF) capability.
OPAQUE	Indicates a Opaque Capability
ORBIT_CHANGE	Indicates this space system has the ability to change orbits.
ORBITAL_SURVEILLANCE	Indicates a task to perform Orbital Surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates an Orbital Surveillance Sensor Capability.
PO	Indicates a passive optical capability.
RADAR_ALTIMETER	Indicates a Radar Altimeter capability
REFUEL	Indicates a capability to refuel another asset.
RESPONSE	Indicates an response capability.
SAR	Indicates a synthetic aperture radar (SAR) capability.
SMTI	Indicates a surface moving target indication (SMTI) capability.
STRIKE	Indicates a strike capability.
SYSTEM_DEPLOYMENT	Indicates a deployment capability.
TACTICAL_ORDER	Indicates a tactical order capability.
TASK	Indicates a task capability.
WEATHER_RADAR	Indicates a weather radar capability.

Table A-4-438: C2 Interface MA_MissionPlanCommandMT - CapabilityCommand UCI Extension Field

4.1.97 MA_MissionPlanCommandStatusMT UCI Extension

MA_MissionPlanCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	AllocationResult : MA_RequirementPlanningResultType ResultingPlanIdentifier : MA_PlansReferenceType OpPlanID : MA_OpPlanID_Type OpPlanID : MA_OpPlanID_Type

MessageData : MA_MissionPlanCommandStatusMDT
AssociatedPlans : MA_PlanReferenceType

Table A-4-439: C2 Interface MA_MissionPlanCommandStatusMT UCI Extension

AllocationResult		
Description	Indicates allocation results per Requirement.	
Base Type	MA_RequirementPlanningResultType	
Message Structure		
Field Name	Field Type	Field Usage
RequirementID	RequirementInstanceID_ChoiceType	Required
Description	Unique object identifier for the Requirement whose planning results are given by sibling elements.	
PlanningResult	PlanningResultEnum	Required
Description	Indicates the outcome of attempting to allocate or plan activities for the Requirement.	
SystemID	SystemID_Type	Required
Description	Indicates the SystemID of the System whose *Plan are associated with the sibling PlanningResult element.	
AssociatedPlans	MA_PlanReferenceType	Optional
Description	Indicates *Plan associated with the sibling PlanningResult element. If the sibling PlanningResult indicates the Requirement was/remained allocated then this element indicates the specific *Plan it is/remains allocated in. If the PlanningResult indicates the Requirement was DEALLOCATED then this element indicates the constraining *Plan it was DEALLOCATED from. This element isn't expected when the PlanningResult indicates UNALLOCATED.	
NotAllocatedReason	UnallocatedReasonType	Repeated
Description	Indicates a reason why the Requirement wasn't allocated or reallocated. If the sibling PlanningResult element indicates the Requirement was left not allocated then this element indicates why. Multiple instances of this element can provide the reason for each System that was attempted and even many reasons for each. If the PlanningResult indicates the Requirement was allocated then this element can still be used to indicate reasons for failed attempts to allocate to other Systems or plan, prior to the successful allocation.	

Table A-4-440: C2 Interface MA_MissionPlanCommandStatusMT - AllocationResult UCI Extension Field

ResultingPlanIdentifier		
Description	This element indicates the unique ID or IDs of any *Plans that were generated.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated

Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-441: C2 Interface MA_MissionPlanCommandStatusMT - ResultingPlanIdentifier UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-442: C2 Interface MA_MissionPlanCommandStatusMT - OpPlanID UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-443: C2 Interface MA_MissionPlanCommandStatusMT - OpPlanID UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	MissionPlanCommandID_Type	Required
Description	The unique ID of the MissionPlanCommand this status applies to.	
PlanningStatus	PlanCommandStatusType	Required
Description	Indicates the status of the *PlanCommand.	
AllocationResult	MA_RequirementPlanningResultType	Repeated
Description	Indicates allocation results per Requirement.	
ResultingPlanIdentifier	MA_PlansReferenceType	Optional
Description	This element indicates the unique ID or IDs of any *Plans that were generated.	

Table A-4-444: C2 Interface MA_MissionPlanCommandStatusMT - MessageData UCI Extension Field

AssociatedPlans	
Description	Indicates *Plan associated with the sibling PlanningResult element. If the sibling PlanningResult indicates the Requirement was/remained allocated then this element indicates the specific *Plan it is/remains allocated in. If the PlanningResult indicates the Requirement was DEALLOCATED then this element indicates the constraining *Plan it was DEALLOCATED from. This element isn't expected when the PlanningResult indicates UNALLOCATED.

Base Type	MA_PlanReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Optional
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Optional
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Optional
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Optional
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Optional
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Optional
Description	Indicates a reference to a RouteActivityPlan.	
CommScheduleAllocationID	CommScheduleAllocationID_Type	Optional
Description	Indicates a reference to a Comms allocation.	
ActivityPlanID	ActivityPlanID_Type	Optional
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Optional
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Optional
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Optional
Description	Indicates a reference to a ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Optional
Description	Indicates a reference to an OpPlan.	

Table A-4-445: C2 Interface MA_MissionPlanCommandStatusMT - AssociatedPlans UCI Extension Field

4.1.98 MA_PlanningFunctionStatusMT UCI Extension

MA_PlanningFunctionStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	AutonomousPlanningAction : MA_PlanningAllowedEscalationType PlanningAllowed : MA_PlanningAllowedType

ActivityPlan : MA_ActivityPlanPartsType
 TaskPlan : MA_TaskPlanPartsType
 ByResultSetting : MA_MissionPlanningAutonomySettingByResultType
 RouteActivityPlan : MA_ActivityPlanPartsType
 OpZoneCategory : MA_OpZoneCategoryEnum
 MessageData : MA_PlanningFunctionStatusMDT
 OpPlan : MA_OpPlanPartsType
 OpLineCategory : MA_OpLineCategoryEnum
 AutonomousPlanningResponseChoice : MA_MissionPlanningAutonomyResponseChoiceType
 OrbitActivityPlan : MA_ActivityPlanPartsType
 TaskType : MA_TaskTypeEnum
 OutputPlanParts : MA_PlanPartsType
 AllowedType : MA_PlanningAllowedType
 OpVolumeCategory : MA_OpZoneCategoryEnum
 CapabilityCommand : MA_CapabilityTypeEnum
 AutonomousAction : MA_MissionPlanningByResultAutonomousActionType
 MissionPlanningAutonomy : MA_MissionPlanningAutonomySettingType

Table A-4-446: C2 Interface MA_PlanningFunctionStatusMT UCI Extension

AutonomousPlanningAction		
Description		This element indicates the allowed autonomous mission planning for the ancestor Trigger. It also indicates the expected MissionContingencyAlert for the ancestor Trigger; whenever autonomous mission planning is allowed and triggered, a MissionContingencyAlert is expected.
Base Type		MA_PlanningAllowedEscalationType
Message Structure		
Field Name	Field Type	Field Usage
AutonomousPlanningActionID	AutonomousPlanningActionID_Type	Required
Description	Assigns a unique ID to an allowed planning action. This ID can be reference in *Plans, alerts, etc. that result when the planning action is triggered.	
ByResultSetting	MA_MissionPlanningAutonomySettingByResultType	Repeated
Description	This element allows control of the escalation of the autonomous replanning. If the autonomous function indicated by the sibling AllowedType leads to a "by result" trigger described here, then additional autonomous planning is allowed as described here. For example, if Tasks are dropped as a result of initial autonomous replanning then this element can be used to enable/disable a secondary "escalated" planning iteration that includes global Task allocation. If omitted, the sibling AllowedType is allowed regardless of result.	
AllowedType	MA_PlanningAllowedType	Required
Description	This element defines the mission planning type that is allowed to be autonomously triggered.	

Table A-4-447: C2 Interface MA_PlanningFunctionStatusMT - AutonomousPlanningAction UCI Extension Field

PlanningAllowed		
Description	This element defines the mission planning type to be triggered. If multiple instances are given, each should be of a different planning type as indicated by the child element.	
Base Type	MA_PlanningAllowedType	
Message Structure		
Field Name	Field Type	Field Usage
PlanAheadDuration	DurationType	Required
Description	Required duration in the future when the Plan should start. Existing *Plan will continue during this time. This duration should account for everything that must happen from replan initiation to new plan activation.	
PlanningProcessID	PlanningProcessID_Type	Required
Description	Indicates the unique ID of the planning process whose autonomous invocation is described the sibling elements. Planning process are declared in the ControlStatus message.	
ConstrainingPlans	AutonomousPlanningConstrainingPlansType	Optional
Description	Indicates existing types of *Plans that can be used as constraints when invoking the planning process indicated by the sibling PlanningProcessID. The types of *Plans indicated here should be consistent with those supported by the planning process as indicated in the ControlStatus message.	
OtherSystemConstrainingPlans	AutonomousPlanningOtherSystemConstrainingPlansType	Repeated
Description	Indicates existing plans of another System that constrain planning. One for each descendant ConstraintUsage.	
OutputPlanParts	MA_PlanPartsType	Optional
Description	Indicates the specific Plan parts of the sibling PlanningType that the System can produce and include in the output Plan. The child choice in this element should match the sibling PlanningType. When omitted, the System can produce all of the Plan parts for the sibling PlanningType.	
ResultsInMissionPlan	boolean	Required
Description	In some cases, the commanding service or HMI may not want to receive the planning process summarized in a MissionPlan message. If TRUE, the results will be published in individual *Plan messages and summarized in a published MissionPlan message. If FALSE, the results will be published in individual *Plan messages without a summary MissionPlan message.	
ForPlanningUseOnly	boolean	Required
Description	Indicates the state to use for the corresponding element in the *PlanCommand when invoking the planning process.	

Table A-4-448: C2 Interface MA_PlanningFunctionStatusMT - PlanningAllowed UCI Extension Field

ActivityPlan	
Description	Indicates applicable ActivityPlan parts.
Base Type	MA_ActivityPlanPartsType

Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-449: C2 Interface MA_PlanningFunctionStatusMT - ActivityPlan UCI Extension Field

TaskPlan		
Description	Indicates applicable TaskPlan parts.	
Base Type	MA_TaskPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
TaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	

Table A-4-450: C2 Interface MA_PlanningFunctionStatusMT - TaskPlan UCI Extension Field

ByResultSetting

Description	This element allows control of the escalation of the autonomous replanning. If the autonomous function indicated by the sibling AllowedType leads to a "by result" trigger described here, then additional autonomous planning is allowed as described here. For example, if Tasks are dropped as a result of initial autonomous replanning then this element can be used to enable/disable a secondary "escalated" planning iteration that includes global Task allocation. If omitted, the sibling AllowedType is allowed regardless of result.	
Base Type	MA_MissionPlanningAutonomySettingByResultType	
Message Structure		
Field Name	Field Type	Field Usage
Trigger	PlanningByResultTriggerType	Required
Description	Indicates a trigger based on the results of a previously initiated autonomous mission planning function.	
AutonomousAction	MA_MissionPlanningByResultAutonomousActionType	Required
Description	Indicates the action or actions allowed for the sibling trigger.	

Table A-4-451: C2 Interface MA_PlanningFunctionStatusMT - ByResultSetting UCI Extension Field

RouteActivityPlan		
Description	Indicates applicable RouteActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional

	Description	Indicates applicable ActionPlan parts.
TaskPlan	MA_TaskPlanPartsType	Optional
	Description	Indicates applicable TaskPlan parts.
ResponsePlan	ResponsePlanPartsType	Optional
	Description	Indicates applicable ResponsePlan parts.
OpPlan	MA_OpPlanPartsType	Optional
	Description	Indicates applicable OpPlan parts.

Table A-4-452: C2 Interface MA_PlanningFunctionStatusMT - RouteActivityPlan UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground

	within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.

SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-453: C2 Interface MA_PlanningFunctionStatusMT - OpZoneCategory UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the PlanningFunctionStatus message.	
Base Type	MA_PlanningFunctionStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Indicates the unique ID of the System whose planning function status is being reported.	
TransitionDroppedToFailed	boolean	Required
Description	This element specifies whether or not dropped Tasks that cannot be reallocated within the System will be automatically transitioned to the FAILED state for higher level interaction.	
PlanningInterface	PlanningInterfaceType	Repeated
Description	Indicates a currently enabled planning interface of the System. If multiple instances of this element are given, each should be of a different type of *Plan as enumerated by the child PlanType element.	
MissionPlanningAutonomy	MA_MissionPlanningAutonomySettingType	Repeated
Description	Indicates currently enabled autonomous mission planning capabilities of the System.	
PlanActivationAutonomy	PlanActivationAutonomyType	Optional
Description	Indicates current enabled autonomous plan activation capabilities of the System.	
RoutePlanningContingencyPath	ContingencyPathAutonomyType	Repeated
Description	Indicates current route planning settings for the autonomous generation of contingency paths along the primary path. If multiple instances are given, each must be of a different path type as indicated by the child element.	

Table A-4-454: C2 Interface MA_PlanningFunctionStatusMT - MessageData UCI Extension Field

OpPlan		
Description	Indicates applicable OpPlan parts.	
Base Type	MA_OpPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpRouting	EmptyType	Optional
Description	Indicates an OpRouting is applicable to the associated *Plan. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-455: C2 Interface MA_PlanningFunctionStatusMT - OpPlan UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.

TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-456: C2 Interface MA_PlanningFunctionStatusMT - OpLineCategory UCI Extension Field

AutonomousPlanningResponseChoice		
Description	Indicates the autonomous mission planning type or types allowed for the sibling Trigger.	
Base Type	MA_MissionPlanningAutonomyResponseChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
AutonomousPlanningAction	MA_PlanningAllowedEscalationType	Repeated
Description	This element indicates the allowed autonomous mission planning for the ancestor Trigger. It also indicates the expected MissionContingencyAlert for the ancestor Trigger; whenever autonomous mission planning is allowed and triggered, a MissionContingencyAlert is expected.	
AlertOnly	EmptyType	Required
Description	This element indicates that autonomous mission planning isn't allowed for the ancestor Trigger but a MissionContingencyAlert is expected.	

Table A-4-457: C2 Interface MA_PlanningFunctionStatusMT - AutonomousPlanningResponseChoice UCI Extension Field

OrbitActivityPlan	
Description	Indicates applicable OrbitActivityPlan parts.
Base Type	MA_ActivityPlanPartsType
Message Structure	

Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-458: C2 Interface MA_PlanningFunctionStatusMT - OrbitActivityPlan UCI Extension Field

TaskType	
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.
AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.

CAP	Indicates the task is to execute a Combat Air Patrol.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESCORT	Indicates the task is to escort another entity.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.
SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.
SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-459: C2 Interface MA_PlanningFunctionStatusMT - TaskType UCI Extension Field

OutputPlanParts		
Description	Indicates the specific Plan parts of the sibling PlanningType that the System can produce and include in the output Plan. The child choice in this element should match the sibling PlanningType. When omitted, the System can produce all of the Plan parts for the sibling PlanningType.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional

Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-460: C2 Interface MA_PlanningFunctionStatusMT - OutputPlanParts UCI Extension Field

AllowedType		
Description	This element defines the mission planning type that is allowed to be autonomously triggered.	
Base Type	MA_PlanningAllowedType	
Message Structure		
Field Name	Field Type	Field Usage
PlanAheadDuration	DurationType	Required
Description	Required duration in the future when the Plan should start. Existing *Plan will continue during this time. This duration should account for everything that must happen from replan initiation to new plan activation.	
PlanningProcessID	PlanningProcessID_Type	Required
Description	Indicates the unique ID of the planning process whose autonomous invocation is described the sibling elements. Planning process are declared in the ControlStatus message.	
ConstrainingPlans	AutonomousPlanningConstrainingPlansType	Optional
Description	Indicates existing types of *Plans that can be used as constraints when invoking the planning process indicated by the sibling PlanningProcessID. The types of *Plans indicated here should be consistent with those supported by the planning process as indicated in the ControlStatus message.	
OtherSystemConstrainingPlans	AutonomousPlanningOtherSystemConstrainingPlansType	Repeated
Description	Indicates existing plans of another System that constrain planning. One for each descendant ConstraintUsage.	
OutputPlanParts	MA_PlanPartsType	Optional
Description	Indicates the specific Plan parts of the sibling PlanningType that the System can produce and include in the output Plan. The child choice in this element should match the sibling PlanningType. When omitted, the System can produce all of the	

	Plan parts for the sibling PlanningType.	
ResultsInMissionPlan	boolean	Required
Description	In some cases, the commanding service or HMI may not want to receive the planning process summarized in a MissionPlan message. If TRUE, the results will be published in individual *Plan messages and summarized in a published MissionPlan message. If FALSE, the results will be published in individual *Plan messages without a summary MissionPlan message.	
ForPlanningUseOnly	boolean	Required
Description	Indicates the state to use for the corresponding element in the *PlanCommand when invoking the planning process.	

Table A-4-461: C2 Interface MA_PlanningFunctionStatusMT - AllowedType UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.

GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.

SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-462: C2 Interface MA_PlanningFunctionStatusMT - OpVolumeCategory UCI Extension Field

CapabilityCommand	
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_CapabilityTypeEnum
Message Structure	
Enumeration Literal	Description
ACTION	Indicates an action capability.
AIR_SAMPLE	Indicates an air sampling capability.
AMTI	Indicates an airborne moving target indication (AMTI) capability.
AO	Indicates an active optical capability.
CAP	Indicates a cargo delivery capability.
CARGO_DELIVERY	Indicates a cargo delivery capability.
COMINT	Indicates a Communications Intelligence (COMINT) capability.
COMM_RELAY	Indicates a communications relay capability.
COMM_TERMINAL	Indicates a communications terminal capability
COUNTER_SPACE	Indicates a Counter Space Capability.
EA	Indicates an electronic attack (EA) capability.
EFFECT	Indicates an effect capability.
ESM	Indicates an electronic support measures (ESM) capability.
FLIGHT	Indicates a capability for waypoint-based flight tasks/commands.
IFF	Indicates an Identification Friend or Foe (IFF) capability.
OPAQUE	Indicates a Opaque Capability
ORBIT_CHANGE	Indicates this space system has the ability to change orbits.
ORBITAL_SURVEILLANCE	Indicates a task to perform Orbital Surveillance.

ORBITAL_SURVEILLANCE_SENSOR	Indicates an Orbital Surveillance Sensor Capability.
PO	Indicates a passive optical capability.
RADAR_ALTIMETER	Indicates a Radar Altimeter capability
REFUEL	Indicates a capability to refuel another asset.
RESPONSE	Indicates an response capability.
SAR	Indicates a synthetic aperture radar (SAR) capability.
SMTI	Indicates a surface moving target indication (SMTI) capability.
STRIKE	Indicates a strike capability.
SYSTEM_DEPLOYMENT	Indicates a deployment capability.
TACTICAL_ORDER	Indicates a tactical order capability.
TASK	Indicates a task capability.
WEATHER_RADAR	Indicates a weather radar capability.

Table A-4-463: C2 Interface MA_PlanningFunctionStatusMT - CapabilityCommand UCI Extension Field

AutonomousAction		
Description	Indicates the action or actions allowed for the sibling trigger.	
Base Type	MA_MissionPlanningByResultAutonomousActionType	
Message Structure		
Field Name	Field Type	Field Usage
PlanningAllowed	MA_PlanningAllowedType	Repeated
Description	This element defines the mission planning type to be triggered. If multiple instances are given, each should be of a different planning type as indicated by the child element.	
AlertOnly	EmptyType	Required
Description	This element indicates that autonomous mission planning isn't allowed for the ancestor Trigger but a MissionContingencyAlert is expected.	

Table A-4-464: C2 Interface MA_PlanningFunctionStatusMT - AutonomousAction UCI Extension Field

MissionPlanningAutonomy		
Description	Indicates currently enabled autonomous mission planning capabilities of the System.	
Base Type	MA_MissionPlanningAutonomySettingType	
Message Structure		
Field Name	Field Type	Field Usage
Trigger	PlanningByCaseTriggerType	Required
Description	Indicates an allowed trigger for autonomous planning.	
AutonomousPlanningResponseChoice	MA_MissionPlanningAutonomyResponseChoiceType	Required
Description	Indicates the autonomous mission planning type or types allowed for the sibling Trigger.	

PlanningProcessID	PlanningProcessID_Type	Optional
Description	Indicates the unique ID of a planning process which the settings are applicable to. If omitted, the setting is applicable to all processes of the corresponding System.	
MinimumResponseInterval	DurationType	Optional
Description	Indicates the minimum time interval between autonomous responses for the sibling Trigger. In other words, regardless of when and how frequently the Trigger occurs, the sibling Response shouldn't be initiated until the minimum time duration given here after the previous Response.	

Table A-4-465: C2 Interface MA_PlanningFunctionStatusMT - MissionPlanningAutonomy UCI Extension Field

4.1.99 MA_OpPointMT UCI Extension

MA_OpPointMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_OpPointMDT AppliesToIDs : MA_PackageSystemType

Table A-4-466: C2 Interface MA_OpPointMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpPointMDT	
Message Structure		
Field Name	Field Type	Field Usage
Category	OpPointCategoriesType	Required
Description	This element indicates the type of operational point.	
CategoryUniqueData	OpPointCategoriesUniqueDataType	Optional
Description	This element indicates the unique data for the type of operational point.	
OpPointID	OpPointID_Type	Required
Description	This element represents the unique identifier of the point associated with this message.	
PointChoice	OpPointChoiceType	Required
Description	Choice of either geospatial or relative position of the OpPoint.	
SystemConfiguration	SystemConfigurationType	Repeated
Description	Indicates a System which the OpPoint is applicable for and its planned configuration/state upon arriving at the OpPoint. If omitted, the OpPoint applies to all Systems.	
TurnDirection	RelativeDirectionEnum	Optional

Description	This field provides the turn direction for orbit.	
IngressConstraint	AnglePairType	Optional
Description	When present this field constrains the vehicle ingress path toward the OpPoint. The allowable ingress range is defined clockwise from Min to Max.	
SafeAltitude	SafeAltitudeType	Optional
Description	This field specifies a set of safe minimum approach altitudes and an emergency safe altitude. This field also specifies the cylindrical area, defined by a center point and radius, where the altitudes apply. This field defines minimum approach altitude and emergency safe altitude consistent with standard FAA instrument approach chart definitions (using UCI standard data types).	
OpDescription	OpDescriptionType	Optional
Description	A human-readable descriptive name with free text remarks.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this operational item to specify what the source or motivation for it originated from. This could be ATO, ACO, etc.	
Source	CreationSourceEnum	Optional
Description	Indicates the source of the information.	
Schedule	ScheduleType	Optional
Description	This element represents a date/time interval associated with the operational item during which the item is in effect.	
AssociatedTime	TimeFunctionType	Repeated
Description	Indicates time related events that are associated to the Op data type such as when activated or when operational. The multiplicity is limited to N-1 options where NONE is an event that has no value, thus removed from list of available options.	
DataLinkIdentifier	DataLinkIdentifierPET	Repeated
Description	List of data link ID. Multiple data link IDs can be reported for the same network type.	
Priority	unsignedInt	Optional
Description	This field represents the priority to be considered when choosing between multiple available points.	
QualifyingTags	QualifyingTagsType	Optional
Description	Provides identity qualifications to augment identification and associated processing of the OpPoint.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
SystemScheduleOverride	SystemScheduleStateType	Repeated
Description	System-specific schedule that will override any part of the main schedule. This allows for system-specific schedule different than main schedule. When adding a SystemScheduleOverride, the child SystemID also must be added to the sibling SystemID list if the sibling list is not empty. The SystemScheduleOverride is independent of time planning. For the system, this override can be done at execution.	

Table A-4-467: C2 Interface MA_OpPointMT - MessageData UCI Extension Field

AppliesToIDs		
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-468: C2 Interface MA_OpPointMT - AppliesToIDs UCI Extension Field

4.1.100MA_OpRoutingMT UCI Extension

MA_OpRoutingMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ApplicableToIDs : MA_PackageSystemType MessageData : MA_OpRoutingMDT

Table A-4-469: C2 Interface MA_OpRoutingMT UCI Extension

ApplicableToIDs		
Description	One or more Systems to which the routing constraints apply. If omitted, the constraints apply to all Systems.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	

SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-470: C2 Interface MA_OpRoutingMT - ApplicableToIDs UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpRoutingMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpRoutingID	OpRoutingID_Type	Required
Description	The unique identifier of the set of routing constraints during operation associated with this message.	
DefaultBlueSeparation	SeparationParametersType	Optional
Description	Indicates default minimum geospatial separation to be maintained when planning or analyzing routes or manually navigating. The separation is between the planned/navigated route and other routes or conflicting items. This is the default separation. It can be overridden in specific cases by the sibling element.	
DefaultRedSeparation	SeparationParametersType	Optional
Description	Indicates default minimum geospatial separation to be maintained when planning or analyzing routes or manually navigating. The separation is between the planned/navigated route and other routes or conflicting items. This is the default separation. It can be overridden in specific cases by the sibling element.	
SpecificBlueSeparation	SpecificBlueSeparationType	Repeated
Description	Defines parameters to use when deconflicting blue player routes or generating routes to ensure proper separation from other blue players. These parameters apply at the vehicle type level.	
SpecificRedSeparation	SpecificRedSeparationType	Repeated
Description	Defines parameters to use when deconflicting blue player routes or generating routes to ensure proper separation from other red players. These parameters apply at the vehicle type level.	
OpDescription	OpDescriptionType	Optional
Description	Represents the name and description of the set of associated routing constraints.	
ApplicableToIDs	MA_PackageSystemType	Repeated
Description	One or more Systems to which the routing constraints apply. If omitted, the constraints apply to all Systems.	
ApplicableZone	ZoneType	Optional
Description	Indicates the geospatial zone in which the routing constraints apply.	
Schedule	ScheduleType	Optional
Description	Indicates the time schedule during which the routing constraints apply.	
MissionTraceability	MissionTraceabilityType	Optional

Description	Allows the creator of this zone to specify what the source or motivation for this zone originated from. This could be ATO, ACO, etc.
-------------	--

Table A-4-471: C2 Interface MA_OpRoutingMT - MessageData UCI Extension Field

4.1.101 MA_PlanningFunctionMT UCI Extension

MA_PlanningFunctionMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	Process : MA_MissionPlanProcessDescriptionType RouteActivityPlan : MA_ActivityPlanPartsType ActivityPlan : MA_ActivityPlanPartsType OpVolumeCategory : MA_OpZoneCategoryEnum MissionPlan : MA_MissionPlanProcessType MessageData : MA_PlanningFunctionMDT PlanningInterfaceDetails : MA_PlanningInterfaceDetailsType TaskPlan : MA_TaskPlanPartsType OrbitActivityPlan : MA_ActivityPlanPartsType OpZoneCategory : MA_OpZoneCategoryEnum Output : MA_PlanPartsType CapabilityCommand : MA_CapabilityTypeEnum TaskType : MA_TaskTypeEnum OpLineCategory : MA_OpLineCategoryEnum OpPlan : MA_OpPlanPartsType

Table A-4-472: C2 Interface MA_PlanningFunctionMT UCI Extension

Process		
Description	Indicates details of a MissionPlan-related planning process.	
Base Type	MA_MissionPlanProcessDescriptionType	
Message Structure		
Field Name	Field Type	Field Usage
Output	MA_PlanPartsType	Required
Description	Indicates a type of Plan output by the planning process and the Parts that can be included.	
PlanningProcessID	PlanningProcessID_Type	Required
Description	Indicates the unique ID of a planning process invocable through a *PlanCommand message/interface.	
ValidationSupported	SupportedFunctionEnum	Repeated

Description	Indicates whether this process supports validation via the *PlanValidationCommand messages. List size for this element is based on "Select All That Apply" condition.	
ApplicableTo	PlanningApplicabilitySystemType	Repeated
Description	Indicates a type or instance, of System or Capabilities, that the planning process is applicable to; a System the process can create the specified *Plan type or types for.	
Supports	ApplicabilityType	Repeated
Description	Indicates a type or instance of System, Capabilities or existing *Plans which the planning process can develop support for in the new *Plan. For example, the sibling ApplicableTo element could indicate the planning process can plan electronic attack routes. This element can then indicate the type or instance of Systems, Capabilities or *Plan types that can be supported by the electronic attack route/plan.	
PlanningTriggers	MissionPlanningByCaseTriggerEnum	Repeated
Description	Indicates the set of triggers that the System is able to monitor to autonomously initiate the planning process. List size for this element is based on "Select All That Apply" condition.	

Table A-4-473: C2 Interface MA_PlanningFunctionMT - Process UCI Extension Field

RouteActivityPlan		
Description	Indicates applicable RouteActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	

TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-474: C2 Interface MA_PlanningFunctionMT - RouteActivityPlan UCI Extension Field

ActivityPlan		
Description	Indicates applicable ActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-475: C2 Interface MA_PlanningFunctionMT - ActivityPlan UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.

KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.

WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.
---------------------------	--

Table A-4-476: C2 Interface MA_PlanningFunctionMT - OpVolumeCategory UCI Extension Field

MissionPlan		
Description	Indicates details of MissionPlan-related planning processes.	
Base Type	MA_MissionPlanProcessType	
Message Structure		
Field Name	Field Type	Field Usage
DefaultPlanningProcessID	PlanningProcessID_Type	Required
Description	Indicates which one of the sibling Process elements is the default.	
Process	MA_MissionPlanProcessDescriptionType	Repeated
Description	Indicates details of a MissionPlan-related planning process.	

Table A-4-477: C2 Interface MA_PlanningFunctionMT - MissionPlan UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the PlanningFunction message.	
Base Type	MA_PlanningFunctionMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanningFunctionID	PlanningFunctionID_Type	Required
Description	Indicates a unique ID, assigned to this PlanningFunction.	
SystemID	SystemID_Type	Required
Description	Indicates the unique ID of the System whose planning functions are being reported.	
PlanningInterfaces	PlanningInterfacesType	Repeated
Description	Indicates planning interfaces supported by the System. A supported interface isn't necessarily enabled currently; see the PlanningStatus message for current status/configuration of control interfaces advertised here.	
PlanningInterfaceDetails	MA_PlanningInterfaceDetailsType	Optional
Description	This element is used to describe the details of planning interfaces/messages, specifically *PlanCommand interfaces of a System. It provides discoverability of distinct planning process instances along with the functional scope and output *Plan type or types. A planning interface/process described here can only be invoked when the sibling Interfaces element indicates it is enabled. Planning processes are dynamically discoverable because Systems tend to have widely varying planning functionality. Decomposing planning into discrete processes allows planning functionality to be distributed across a service oriented system of systems. Making planning processes discoverable encourages planning-related services at multiple levels in a C2 hierarchy to adapt to and simultaneously support Systems with different planning functionality and	

	processes.
PlanActivationAutonomyDetails	SupportedPlanActivationAutonomyType Optional
Description	Indicates capabilities of the System to perform plan activation autonomously. Plan activations can be performed either at the MissionPlan or SubPlan level.
ScoringInterfaceDetails	PlanScoringProcessType Optional
Description	This element is used to describe the details of scoring interfaces/messages summarized in the sibling Interfaces element. It provides discoverability of distinct scoring process instances along with the functional scope. A scoring interface/process described here can only be invoked when the sibling Interfaces ActivationState element indicates it is enabled. Plan Scoring processes are dynamically discoverable because Systems tend to have varying scoring algorithms. Decomposing plan scoring into discrete processes allows scoring functionality to be distributed across a service oriented system of systems.

Table A-4-478: C2 Interface MA_PlanningFunctionMT - MessageData UCI Extension Field

PlanningInterfaceDetails		
Description	This element is used to describe the details of planning interfaces/messages, specifically *PlanCommand interfaces of a System. It provides discoverability of distinct planning process instances along with the functional scope and output *Plan type or types. A planning interface/process described here can only be invoked when the sibling Interfaces element indicates it is enabled.	
	Planning processes are dynamically discoverable because Systems tend to have widely varying planning functionality. Decomposing planning into discrete processes allows planning functionality to be distributed across a service oriented system of systems. Making planning processes discoverable encourages planning-related services at multiple levels in a C2 hierarchy to adapt to and simultaneously support Systems with different planning functionality and processes.	
Base Type	MA_PlanningInterfaceDetailsType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlan	MA_MissionPlanProcessType	Optional
Description	Indicates details of MissionPlan-related planning processes.	
TaskPlan	TaskPlanProcessType	Optional
Description	Indicates details of TaskPlan-related planning processes.	
RoutePlan	RoutePlanProcessType	Optional
Description	Indicates details of RoutePlan-related planning processes.	
RouteActivityPlan	ActivityPlanProcessType	Optional

Description	Indicates details of RouteActivityPlan-related planning processes.	
ActivityPlan	ActivityPlanProcessType	Optional
Description	Indicates details of ActivityPlan-related planning processes.	
OrbitPlan	OrbitPlanProcessType	Optional
Description	Indicates details of OrbitPlan-related planning processes.	
OrbitActivityPlan	ActivityPlanProcessType	Optional
Description	Indicates details of OrbitActivityPlan-related planning processes.	
EffectPlan	EffectPlanProcessType	Optional
Description	Indicates details of EffectPlan-related planning processes.	
ActionPlanProcess	ActionPlanProcessType	Optional
Description	Indicates details of ActionPlan-related planning processes.	
ResponsePlanProcess	ResponsePlanProcessType	Optional
Description	Indicates details of ResponsePlan-related planning processes.	

Table A-4-479: C2 Interface MA_PlanningFunctionMT - PlanningInterfaceDetails UCI Extension Field

TaskPlan		
Description	Indicates applicable TaskPlan parts.	
Base Type	MA_TaskPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
TaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	

Table A-4-480: C2 Interface MA_PlanningFunctionMT - TaskPlan UCI Extension Field

OrbitActivityPlan		
Description	Indicates applicable OrbitActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional

	Description	Indicates VehicleSettings are applicable to the *ActivityPlan.
CommsUsage	EmptyType	Optional
	Description	Indicates Comms usage is applicable to the *ActivityPlan.
ProductTasks	EmptyType	Optional
	Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.
EffectPlan	EffectPlanPartsType	Optional
	Description	Indicates applicable EffectPlan parts.
ActionPlan	ActionPlanPartsType	Optional
	Description	Indicates applicable ActionPlan parts.
TaskPlan	MA_TaskPlanPartsType	Optional
	Description	Indicates applicable TaskPlan parts.
ResponsePlan	ResponsePlanPartsType	Optional
	Description	Indicates applicable ResponsePlan parts.
OpPlan	MA_OpPlanPartsType	Optional
	Description	Indicates applicable OpPlan parts.

Table A-4-481: C2 Interface MA_PlanningFunctionMT - OrbitActivityPlan UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.

FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.

ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-482: C2 Interface MA_PlanningFunctionMT - OpZoneCategory UCI Extension Field

Output		
Description	Indicates a type of Plan output by the planning process and the Parts that can be included.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	

EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-483: C2 Interface MA_PlanningFunctionMT - Output UCI Extension Field

CapabilityCommand	
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_CapabilityTypeEnum
Message Structure	
Enumeration Literal	Description
ACTION	Indicates an action capability.
AIR_SAMPLE	Indicates an air sampling capability.
AMTI	Indicates an airborne moving target indication (AMTI) capability.
AO	Indicates an active optical capability.
CAP	Indicates a cargo delivery capability.
CARGO_DELIVERY	Indicates a cargo delivery capability.
COMINT	Indicates a Communications Intelligence (COMINT) capability.
COMM_RELAY	Indicates a communications relay capability.
COMM_TERMINAL	Indicates a communications terminal capability
COUNTER_SPACE	Indicates a Counter Space Capability.
EA	Indicates an electronic attack (EA) capability.
EFFECT	Indicates an effect capability.
ESM	Indicates an electronic support measures (ESM) capability.
FLIGHT	Indicates a capability for waypoint-based flight tasks/commands.
IFF	Indicates an Identification Friend or Foe (IFF) capability.
OPAQUE	Indicates a Opaque Capability
ORBIT_CHANGE	Indicates this space system has the ability to change orbits.
ORBITAL_SURVEILLANCE	Indicates a task to perform Orbital Surveillance.

ORBITAL_SURVEILLANCE_SENSOR	Indicates an Orbital Surveillance Sensor Capability.
PO	Indicates a passive optical capability.
RADAR_ALTIMETER	Indicates a Radar Altimeter capability
REFUEL	Indicates a capability to refuel another asset.
RESPONSE	Indicates an response capability.
SAR	Indicates a synthetic aperture radar (SAR) capability.
SMTI	Indicates a surface moving target indication (SMTI) capability.
STRIKE	Indicates a strike capability.
SYSTEM_DEPLOYMENT	Indicates a deployment capability.
TACTICAL_ORDER	Indicates a tactical order capability.
TASK	Indicates a task capability.
WEATHER_RADAR	Indicates a weather radar capability.

Table A-4-484: C2 Interface MA_PlanningFunctionMT - CapabilityCommand UCI Extension Field

TaskType	
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.
AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.
CAP	Indicates the task is to execute a Combat Air Patrol.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESCORT	Indicates the task is to escort another entity.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.

PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.
SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.
SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-485: C2 Interface MA_PlanningFunctionMT - TaskType UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.

DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-486: C2 Interface MA_PlanningFunctionMT - OpLineCategory UCI Extension Field

OpPlan		
Description	Indicates applicable OpPlan parts.	
Base Type	MA_OpPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpRouting	EmptyType	Optional
Description	Indicates an OpRouting is applicable to the associated *Plan. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-487: C2 Interface MA_PlanningFunctionMT - OpPlan UCI Extension Field

4.1.102MA_TaskStatusMT UCI Extension

MA_TaskStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	Plans : MA_PlansReferenceType OpPlanID : MA_OpPlanID_Type

ExecutingSystemOrPackage : MA_PackageSystemType
 MessageData : MA_TaskStatusMDT
 Traceability : MA_RequirementStatusTraceabilityType

Table A-4-488: C2 Interface MA_TaskStatusMT UCI Extension

Plans		
Description	Indicates *Plans the Requirement is associated with.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-489: C2 Interface MA_TaskStatusMT - Plans UCI Extension Field

OpPlanID	
Description	Indicates a reference to an OpPlan.
Base Type	MA_OpPlanID_Type

Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-490: C2 Interface MA_TaskStatusMT - OpPlanID UCI Extension Field

ExecutingSystemOrPackage		
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-491: C2 Interface MA_TaskStatusMT - ExecutingSystemOrPackage UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_TaskStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
TaskID	TaskID_Type	Required
Description	Indicates the unique ID of the Task whose execution status is being reported.	

ExecutingSystemOrPackage	MA_PackageSystemType	Required
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
ExecutionState	RequirementExecutionStateEnum	Required
Description	Identifies the state of the Requirement.	
ExecutionStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling State element. This element is only expected when the State is in a potentially undesirable state such as failed or completed with less than optimum results. It is strongly encouraged for transitions to failed or dropped.	
ActualTiming	RequirementTimingType	Repeated
Description	Indicates actual timing status for the Requirement. Allows for defining for each timing type (RequirementTimingEnum).	
PercentCompleted	PercentType	Optional
Description	Percentage of assigned Requirement completion. The percentage increments until the Requirement has COMPLETED or FAILED. A percent complete of 0 indicates the Requirement has not yet begun execution, and a failed Requirement may have any percentage between 1 - 99.	
Traceability	MA_RequirementStatusTraceabilityType	Optional
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.	
Metrics	MetricsType	Optional
Description	Specifies the actual metrics associated with the Requirements.	

Table A-4-492: C2 Interface MA_TaskStatusMT - MessageData UCI Extension Field

Traceability	
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for

	architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.	
Base Type	MA_RequirementStatusTraceabilityType	
Message Structure		
Field Name	Field Type	Field Usage
Plans	MA_PlansReferenceType	Optional
Description	Indicates *Plans the Requirement is associated with.	
PlannedActivityID	PlannedActivityID_Type	Repeated
Description	Indicates a specific Planned Activity the Requirement is associated with.	
CapabilityID	CapabilityID_Type	Repeated
Description	Identifies a specific Capability the Requirement is associated with.	
CommandID	CommandID_Type	Repeated
Description	Indicates the ID of an associated [Capability]Command.	
ActivityID	ActivityID_Type	Repeated
Description	Indicates the ID of an associated actual/executing/executed Activity.	

Table A-4-493: C2 Interface MA_TaskStatusMT - Traceability UCI Extension Field

4.1.103MA_PlanModificationRequestMT UCI Extension

MA_PlanModificationRequestMT	
Description	Indicates the contents of the PlanModificationRequest message details, and also includes the message header. See the XSD File for more info
Ext. Fields	SubPlansAdditions : MA_PlansReferenceBaseType SubPlansRetractions : MA_PlansReferenceBaseType SubPlansModification : MA_SubPlansModificationType PlanModificationDetails : MA_PlanModificationDetailsType MessageData : MA_PlanModificationRequestMDT Plans : MA_PlansReferenceType OpPlanID : MA_OpPlanID_Type

Table A-4-494: C2 Interface MA_PlanModificationRequestMT UCI Extension

SubPlansAdditions	
Description	Indicates an additional set of *Plans which are included as part of the MissionPlan. The included SubPlans share the same Applicability as the MissionPlan.

Base Type	MA_PlansReferenceBaseType	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-495: C2 Interface MA_PlanModificationRequestMT - SubPlansAdditions UCI Extension Field

SubPlansRetractions		
Description	Indicates the removal of set of *Plans which are included as part of the MissionPlan.	
Base Type	MA_PlansReferenceBaseType	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	

RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-496: C2 Interface MA_PlanModificationRequestMT - SubPlansRetractions UCI Extension Field

SubPlansModification		
Description	Indicates a change in the set of *Plans which are included as part of the MissionPlan. See annotations for the underlying type and its child elements for details.	
Base Type	MA_SubPlansModificationType	
Message Structure		
Field Name	Field Type	Field Usage
SubPlansAdditions	MA_PlansReferenceBaseType	Optional
Description	Indicates an additional set of *Plans which are included as part of the MissionPlan. The included SubPlans share the same Applicability as the MissionPlan.	
SubPlansRetractions	MA_PlansReferenceBaseType	Optional
Description	Indicates the removal of set of *Plans which are included as part of the MissionPlan.	

Table A-4-497: C2 Interface MA_PlanModificationRequestMT - SubPlansModification UCI Extension Field

PlanModificationDetails		
Description	Specifies details of the plan modification.	
Base Type	MA_PlanModificationDetailsType	
Message Structure		
Field Name	Field Type	Field Usage
ForPlanningUseOnly	boolean	Optional
Description	When TRUE, indicates the *Plan is a used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality,	

	be subject to approvals, be activated, etc.	
WindowModification	PlanWindowModificationTypeChoiceType	Optional
Description	Specifies an absolute time Window or alternatively a TimeOffset by which the Plan's, or set of Plans', Windows should be shifted.	
ApplicabilityModification	PlanApplicabilityModificationType	Optional
Description	Indicates a change in the System or Systems which have a direct relationship with the Mission Plan. See annotations for the underlying type and its child elements for details.	
SubPlansModification	MA_SubPlansModificationType	Optional
Description	Indicates a change in the set of *Plans which are included as part of the MissionPlan. See annotations for the underlying type and its child elements for details.	
HierarchyModification	HierarchyModificationType	Optional
Description	Indicates a change in the hierarchy of the set of MissionPlans.	
ExecutionSequenceModification	ExecutionSequenceReplaceOrModifyChoiceType	Optional
Description	Indicates a change in the execution sequence of the set of *Plans.	
RequirementAllocationLock	RequirementAllocationLockDetailsType	Optional
Description	Indicates a requested change in Allocated Requirements to Lock or Unlock.	

Table A-4-498: C2 Interface MA_PlanModificationRequestMT - PlanModificationDetails UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PlanModificationRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
Source	PlanInitiationSourceEnum	Required
Description	Source of the plan modification request.	
Plans	MA_PlansReferenceType	Required
Description	Indicates the Plan, or set of Plans, for which this Plan Modification Request is applicable.	
PlanModificationDetails	MA_PlanModificationDetailsType	Required
Description	Specifies details of the plan modification.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-499: C2 Interface MA_PlanModificationRequestMT - MessageData UCI Extension Field

Plans		
Description	Indicates the Plan, or set of Plans, for which this Plan Modification Request is applicable.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-500: C2 Interface MA_PlanModificationRequestMT - Plans UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been	

	made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-501: C2 Interface MA_PlanModificationRequestMT - OpPlanID UCI Extension Field

4.1.104 MA_PlanModificationRequestStatusMT UCI Extension

MA_PlanModificationRequestStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_PlanModificationRequestStatusMDT

Table A-4-502: C2 Interface MA_PlanModificationRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PlanModificationRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-503: C2 Interface MA_PlanModificationRequestStatusMT - MessageData UCI Extension Field

4.1.105 MA_MessageAcknowledgmentConfigurationRequestMT UCI Extension

MA_MessageAcknowledgmentConfigurationRequestMT	
Description	See annotations in child elements and messages/elements that use this type for details.

	See the XSD File for more info
Ext. Fields	MessageData : MA_MessageAcknowledgmentConfigurationRequestMDT

Table A-4-504: C2 Interface MA_MessageAcknowledgmentConfigurationRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_MessageAcknowledgmentConfigurationRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
DefaultGroupMessageFreq	DurationType	Optional
Description	This will override the current DefaultGroupMessageFreq setting.	
DefaultMessagesToAck	MA_AckMessageEnum	Repeated
Description	This will override the current DefaultMessageToAck setting.	
RequestedReceiverSpecificSetting	MA_AckReceiverSpecificConfigType	Optional
Description	This is an individual configuration settings that is being requested to be configured.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-505: C2 Interface MA_MessageAcknowledgmentConfigurationRequestMT - MessageData UCI Extension Field

4.1.106 MA_MessageAcknowledgmentConfigurationMT UCI Extension

MA_MessageAcknowledgmentConfigurationMT	
Description	See annotations in child elements and messages/elements that use this type for details.
	See the XSD File for more info
Ext. Fields	MessageData : MA_MessageAcknowledgmentConfigurationMDT

Table A-4-506: C2 Interface MA_MessageAcknowledgmentConfigurationMT UCI Extension

MessageData

Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_MessageAcknowledgmentConfigurationMDT	
Message Structure		
Field Name	Field Type	Field Usage
DefaultGroupMessageFreq	DurationType	Optional
Description	If set, this provides the frequency at which the Grouped Acknowledgment message is set at. If not set there is no grouping.	
DefaultMessagesToAck	MA_AckMessageEnum	Repeated
Description	If set, the list of messages that an Acknowledgment message will be sent for when received. If not set all messages of the type will be responded to.	
ReceiverSpecificSettings	MA_AckReceiverSpecificConfigType	Repeated
Description	This is the list of individual configuration settings that a remote system is configured. Values in this will override the Default settings.	
ConfigurationSupported	boolean	Required
Description	If FALSE, the publisher does not support grouping, they expect acknowledgments for messages covered by this configuration, and will reject all configuration requests. If TRUE, the publisher supports individual configurations, grouping, and the other items in this collection of messages.	

Table A-4-507: C2 Interface MA_MessageAcknowledgmentConfigurationMT - MessageData UCI Extension Field

4.1.107 MA_MessageAcknowledgmentConfigurationRequestStatusMT UCI Extension

MA_MessageAcknowledgmentConfigurationRequestStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_MessageAcknowledgmentConfigurationRequestStatusMDT

Table A-4-508: C2 Interface MA_MessageAcknowledgmentConfigurationRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_MessageAcknowledgmentConfigurationRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required

Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-509: C2 Interface MA_MessageAcknowledgmentConfigurationRequestStatusMT - MessageData UCI Extension Field

4.1.108MA_ResponseCommandMT UCI Extension

MA_ResponseCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ResponseCommandMDT

Table A-4-510: C2 Interface MA_ResponseCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ResponseCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Command	MA_ResponseCommandType	Repeated
Description	Indicates an instance of an Response Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Capability CommandStatus message.	

Table A-4-511: C2 Interface MA_ResponseCommandMT - MessageData UCI Extension Field

4.1.109MA_ResponseCommandStatusMT UCI Extension

MA_ResponseCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ResponseCommandStatusMDT

Table A-4-512: C2 Interface MA_ResponseCommandStatusMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_ResponseCommandStatusMDT

Message Structure		
Field Name	Field Type	Field Usage
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-513: C2 Interface MA_ResponseCommandStatusMT - MessageData UCI Extension Field

4.1.110MA_PlatformOverrideCommandStatusMT UCI Extension

MA_PlatformOverrideCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_PlatformOverrideCommandStatusMDT

Table A-4-514: C2 Interface MA_PlatformOverrideCommandStatusMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_PlatformOverrideCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	

CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-515: C2 Interface MA_PlatformOverrideCommandStatusMT - MessageData UCI Extension Field

4.1.111 MA_PlatformOverrideCommandMT UCI Extension

MA_PlatformOverrideCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_PlatformOverrideCommandMDT

Table A-4-516: C2 Interface MA_PlatformOverrideCommandMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_PlatformOverrideCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Applicability	MA_PlanApplicabilityType	Required
Description	Indicates the System or Systems which have a direct relationship with a global command. See annotations for the underlying type and its child elements for details.	
PlatformOverrideCommand	MA_PlatformDefaultAndOverrideDataType	Required
Description	Indicates a request to override a platform setting in existing plans and commands.	
ExpirationTime	DateTimeType	Optional
Description	Optionally indicates a prescribed expiration time for the platform override command. If not populated, then the command is indefinite until commanded off or expires due to the ApplicableZone(s) being exited.	
ApplicableZoneID	OpZoneID_Type	Repeated
Description	Optionally indicates a zone(s) within which the override is applicable. If not populated, then the command is valid throughout the operating area.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-517: C2 Interface MA_PlatformOverrideCommandMT - MessageData UCI Extension Field

4.1.112MA_GatewayActivityMT UCI Extension

MA_GatewayActivityMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ObjectState : ObjectStateEnum MessageData : MA_GatewayActivityMDT

Table A-4-518: C2 Interface MA_GatewayActivityMT UCI Extension

ObjectState	
Description	Indicates the state of the internal software object that the data in the message is based upon. The state of the software object is determined by the publisher. The publisher could be the original/master publisher or an intermediary re-publisher such as a persistence/data manager. This element is not a commanded CRUD operation. It is not an indication of the state of an instance of a message. It is not a mechanism for partial, incremental, or fragmentary publication of a message. It is a signal from a publisher to subscribers. For REMOVED state, in particular, some subscribers will mirror the publisher and treat the message as if the object no longer exists, but others, such as mission recorders, might not (in order to support retaining historical records of activity, for example).
Base Type	ObjectStateEnum
Message Structure	
Enumeration Literal	Description
NEW	Indicates the internal software object corresponding to this message currently exists and this message is the first publication corresponding to the object.
UPDATED	Indicates the internal software object corresponding to this message currently exists and has been updated since the last publication of the message; this publication of the message may contain updates.
REMOVED	Indicates the internal software object corresponding to this message no longer exists; there should be no further publications of this message corresponding to the object.

Table A-4-519: C2 Interface MA_GatewayActivityMT - ObjectState UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_GatewayActivityMDT	
Message Structure		
Field Name	Field Type	Field Usage
GatewayServiceID	ServiceID_Type	Required
Description	This element represents the ServiceID of the Gateway Service that sent this message.	

Activity	MA_GatewayActivityType	Repeated
Description	Indicates the dynamic operational characteristics of an Activity of a GatewayCapability.	

Table A-4-520: C2 Interface MA_GatewayActivityMT - MessageData UCI Extension Field

4.1.113 MA_DataDisseminationPlanOverrideRequestMT UCI Extension

MA_DataDisseminationPlanOverrideRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanOverrideRequestMDT

Table A-4-521: C2 Interface MA_DataDisseminationPlanOverrideRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanOverrideRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
AllocatedToSystemIDs	MA_PackageSystemType	Repeated
Description	Indicates the unique ID of the system(s) or package that is the recipient of this command.	
AllocatedToServiceID	ServiceID_Type	Optional
Description	Indicates the unique ID of the service that is the recipient of this command.	
Request	MA_DataDisseminationPlanOverrideRequestType	Repeated
Description	Indicates an instance of a data plan override request. A data plan override request message can have multiple request instances to allow a sequence of related requests in a single coherent message. Each request instance reports status via a separate, independent DataPlanOverrideRequestStatus message.	

Table A-4-522: C2 Interface MA_DataDisseminationPlanOverrideRequestMT - MessageData UCI Extension Field

4.1.114 MA_DataDisseminationPlanOverrideRequestStatusMT UCI Extension

MA_DataDisseminationPlanOverrideRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanOverrideRequestStatusMDT

Table A-4-523: C2 Interface MA_DataDisseminationPlanOverrideRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanOverrideRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MA_DataDisseminationPlanID_Type	Required
Description	Indicates the unique ID of the DataDisseminationPlan that this override modification status applies to.	
EffectivityActivationStatus	DataPlanEffectivityActivationStatusType	Repeated
Description	This element indicates the status of pre-mission planned Data-Link gateway settings. It is used to indicate details about specific planned effectivity activations.	
OperatorModificationStatus	OperatorGatewayDesignationStatusType	Repeated
Description	This element indicates the status of operator designations. It is used to indicate details about specific designation configurations.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-524: C2 Interface MA_DataDisseminationPlanOverrideRequestStatusMT - MessageData UCI Extension Field

4.1.115MA_DataDisseminationPlanMT UCI Extension

MA_DataDisseminationPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	ObjectState : ObjectStateEnum MessageData : MA_DataDisseminationPlanMDT

Table A-4-525: C2 Interface MA_DataDisseminationPlanMT UCI Extension

ObjectState	
Description	Indicates the state of the internal software object that the data in the message is based upon. The state of the software object is determined by the publisher. The publisher could be the original/master publisher or an intermediary re-publisher such as a persistence/data manager. This element is not a

	commanded CRUD operation. It is not an indication of the state of an instance of a message. It is not a mechanism for partial, incremental, or fragmentary publication of a message. It is a signal from a publisher to subscribers. For REMOVED state, in particular, some subscribers will mirror the publisher and treat the message as if the object no longer exists, but others, such as mission recorders, might not (in order to support retaining historical records of activity, for example).
Base Type	ObjectStateEnum
Message Structure	
Enumeration Literal	Description
NEW	Indicates the internal software object corresponding to this message currently exists and this message is the first publication corresponding to the object.
UPDATED	Indicates the internal software object corresponding to this message currently exists and has been updated since the last publication of the message; this publication of the message may contain updates.
REMOVED	Indicates the internal software object corresponding to this message no longer exists; there should be no further publications of this message corresponding to the object.

Table A-4-526: C2 Interface MA_DataDisseminationPlanMT - ObjectState UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MA_DataDisseminationPlanID_Type	Required
Description	Indicates the unique ID of the DataDisseminationPlan.	
AssociatedPlanID	MA_DataDisseminationPlanID_Type	Repeated
Description	Indicates the unique ID of a DataDisseminationPlan that is a parent to this one.	
Applicability	MA_PlanApplicabilityType	Repeated
Description	Indicates the System or Systems which have a direct relationship with the DataDisseminationPlan. See annotations for the underlying type and its child elements for details. If Applicability is not defined then it indicates this DataDisseminationPlan applies to ALL systems.	
IER	MA_CommIER_Planned_Type	Repeated
Description	Indicates a planned Information Exchange Requirement (IER). An IER can reflect the information needs of local or remote Systems or third party Systems coordinating on behalf of other Systems. The planned assignment of an IER to comms resources is given in the sibling Effectivity element.	
IER_DesiredService	MA_CommIER_DesiredServicesType	Repeated
Description	Defines the desired service constraints for an IER (Information Exchange Requirement), allowing multi-constrained solutions. All child elements are optional; when omitted software should apply no explicit bound for that metric.	

RateGroup	MA_CommRateGroupType	Repeated
Description	Indicates a RateGroup that can be associated with an IER to configure its transmit rate.	
Effectivity	MA_CommDataDisseminationEffectivityType	Repeated
Description	Indicates a DataDisseminationPlan "effectivity set" of items that are used together.	
Vector	MA_CommVectorPlannedType	Repeated
Description	Indicates a planned Vector. A vector describes a logical connection between nodes initiating on a specific NetworkLink (comms resource).	
DistributionGroup	MA_DistributionGroupType	Repeated
Description	Indicates a grouping of tiles or node groups and associated ip address.	
DistributionGroupMembership	MA_DistributionGroupMembershipType	Repeated
Description	Indicates a system's membership to a multicast group.	
Gateway	MA_GatewayReferenceType	Repeated
Description	Indicates a planned Gateway local to the system for which this DataDisseminationPlan is applicable to, with a summary of its Capability to be used for dissemination of IERs in the DataDisseminationPlan.	
Trigger	MA_CommTriggerType	Repeated
Description	Signifies available triggers which would automatically invoke this DataDisseminationPlan or parts within this DataDisseminationPlan. These Triggers that can be associated with activation of an Effectivity by using the TriggerID.	

Table A-4-527: C2 Interface MA_DataDisseminationPlanMT - MessageData UCI Extension Field

4.1.116MA_DataDisseminationPlanActivationCommandMT UCI Extension

MA_DataDisseminationPlanActivationCommandMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanActivationCommandMDT

Table A-4-528: C2 Interface MA_DataDisseminationPlanActivationCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanActivationCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MA_DataDisseminationPlanID_Type	Required
Description	The DataDisseminationPlan that this command pertains to.	

CommandedState	PlanActivationCommandEnum	Required
Description	Indicates the activation to perform on the associated DataDisseminationPlan. See enumerate annotations for further details.	
Applicability	MA_PackageSystemType	Repeated
Description	The System or Package IDs, that this message applies to. A lead is able to respond with ACCEPTED for the Package or individual Systems as needed.	
EffectivityActivation	MA_DataDisseminationPlanEffectivityActivationType	Repeated
Description	Indicates an Effectivity of the DataDisseminationPlan to activate.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-529: C2 Interface MA_DataDisseminationPlanActivationCommandMT - MessageData UCI Extension Field

4.1.117 MA_DataDisseminationPlanActivationCommandStatusMT UCI Extension

MA_DataDisseminationPlanActivationCommandStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanActivationCommandStatusMDT

Table A-4-530: C2 Interface MA_DataDisseminationPlanActivationCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanActivationCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional

Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.
-------------	---

Table A-4-531: C2 Interface MA_DataDisseminationPlanActivationCommandStatusMT - MessageData UCI Extension Field

4.1.118MA_DataDisseminationPlanActivationStatusMT UCI Extension

MA_DataDisseminationPlanActivationStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanActivationStatusMDT

Table A-4-532: C2 Interface MA_DataDisseminationPlanActivationStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanActivationStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MA_DataDisseminationPlanID_Type	Required
Description	The ID of the DataDisseminationPlan this status pertains to.	
ActivationState	PlanActivationStateEnum	Required
Description	Indicates the activation state of the associated DataDisseminationPlan.	
StateReason	MA_CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling ActivationState element.	
EffectivityActivationState	MA_DataDisseminationPlanEffectivityStateType	Repeated
Description	Indicates the activation state of an Effectivity of the associated DataDisseminationPlan.	
OverrideModificationState	MA_OvriderModificationStatusType	Repeated
Description	This element indicates the status of operator designations. It is used to indicate details about specific designation configurations.	

Table A-4-533: C2 Interface MA_DataDisseminationPlanActivationStatusMT - MessageData UCI Extension Field

4.1.119MA_PlatformOverrideStatusMT UCI Extension

MA_PlatformOverrideStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info

Ext. Fields	MessageData : MA_PlatformOverrideStatusMDT
--------------------	--

Table A-4-534: C2 Interface MA_PlatformOverrideStatusMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_PlatformOverrideStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlatformOverrideStatus	MA_PlatformDefaultAndOverrideDataType	Repeated
Description	Indicates the current platform override setting(s) applied.	
ActiveOverrides	boolean	Required
Description	When TRUE, indicates one or more overrides are active. When FALSE, indicates no overrides are active.	
ExecutingSystemOrPackage	MA_PackageSystemType	Required
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
ExecutionState	RequirementExecutionStateEnum	Required
Description	Identifies the state of the Requirement.	
ExecutionStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling State element. This element is only expected when the State is in a potentially undesirable state such as failed or completed with less than optimum results. It is strongly encouraged for transitions to failed or dropped.	
ActualTiming	RequirementTimingType	Repeated
Description	Indicates actual timing status for the Requirement. Allows for defining for each timing type (RequirementTimingEnum).	
PercentCompleted	PercentType	Optional
Description	Percentage of assigned Requirement completion. The percentage increments until the Requirement has COMPLETED or FAILED. A percent complete of 0 indicates the Requirement has not yet begun execution, and a failed Requirement may have any percentage between 1 - 99.	
Traceability	MA_RequirementStatusTraceabilityType	Optional
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically	

	without *Plans or [Capability]Commands.	
Metrics	MetricsType	Optional
Description	Specifies the actual metrics associated with the Requirements.	

Table A-4-535: C2 Interface MA_PlatformOverrideStatusMT - MessageData UCI Extension Field

4.2 Peer Interface

4.2.1 MA_WEZ_MT UCI Extension

MA_WEZ_MT	
Description	This message represents a single Weapon Engagement Zone (WEZ). The WEZ represents a less dynamic capability than the DLZ for air to air engagements and is not reliant on target state data to be produced. See the XSD File for more info
Ext. Fields	MessageData : MA_WEZ_MDT WEZ_ID : MA_WEZ_ID_Type WEZ_Data : MA_WEZ_DataType RangeTurnAndClose : MA_WeaponRangeType RangeMinimum : MA_WeaponRangeType RangeTurnAndRun : MA_WeaponRangeType RangeProbabilityOfIntercept : MA_WeaponRangeType RangeMaxGuidance : MA_WeaponRangeType RangeOptimal : MA_WeaponRangeType RangeMaxAero : MA_WeaponRangeType

Table A-4-536: Peer Interface MA_WEZ_MT UCI Extension

MessageData		
Description	This represents the characteristics that identify and describe a single Weapon Engagement Zone (WEZ).	
Base Type	MA_WEZ_MDT	
Message Structure		
Field Name	Field Type	Field Usage
WEZ_ID	MA_WEZ_ID_Type	Required
Description	This is an ID to uniquely identify the Weapon Engagement Zone (WEZ).	
WEZ_RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
CapabilityID	CapabilityID_Type	Optional
Description	Indicates the weapon Capability instance that this WEZ is associated with.	

GeneratedByWeapon	boolean	Optional
Description	This element indicates if the WEZ was generated using payload algorithms.	
WEZ_Data	MA_WEZ_DataType	Required
Description	Indicates WEZ range calculations for air-to-air engagement assessments.	

Table A-4-537: Peer Interface MA_WEZ_MT - MessageData UCI Extension Field

WEZ_ID		
Description	This is an ID to uniquely identify the Weapon Engagement Zone (WEZ).	
Base Type	MA_WEZ_ID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-538: Peer Interface MA_WEZ_MT - WEZ_ID UCI Extension Field

WEZ_Data		
Description	Indicates WEZ range calculations for air-to-air engagement assessments.	
Base Type	MA_WEZ_DataType	
Message Structure		
Field Name	Field Type	Field Usage
RangeTurnAndClose	MA_WeaponRangeType	Repeated
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-close maneuver RangeTurnAndClose is not applicable to ballistic trajectory targets.	
RangeMinimum	MA_WeaponRangeType	Repeated
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers	

	Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeTurnAndRun	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-run maneuver RangeTurnAndRun is not applicable to ballistic trajectory targets.	
RangeProbabilityOfIntercept	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeMaxGuidance	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeOptimal	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeMaxAero	MA_WeaponRangeType	Repeated

Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
TimeToRelease	TimeType	Required
Description	The seconds time to activate for the proposed launch store type.	
TimeOfActivation	TimeType	Optional
Description	The time of weapon seeker activation, assuming no platform guidance or weapon errors, for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No post-launch target maneuvers	

Table A-4-539: Peer Interface MA_WEZ_MT - WEZ_Data UCI Extension Field

RangeTurnAndClose		
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-close maneuver RangeTurnAndClose is not applicable to ballistic trajectory targets.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-540: Peer Interface MA_WEZ_MT - RangeTurnAndClose UCI Extension Field

RangeMinimum	
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for:

	1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-541: Peer Interface MA_WEZ_MT - RangeMinimum UCI Extension Field

RangeTurnAndRun		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-run maneuver RangeTurnAndRun is not applicable to ballistic trajectory targets.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-542: Peer Interface MA_WEZ_MT - RangeTurnAndRun UCI Extension Field

RangeProbabilityOfIntercept		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers	

	Note: ballistic trajectory velocity changes are not considered maneuvers.	
Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-543: Peer Interface MA_WEZ_MT - RangeProbabilityOfIntercept UCI Extension Field

RangeMaxGuidance		
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-544: Peer Interface MA_WEZ_MT - RangeMaxGuidance UCI Extension Field

RangeOptimal		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
Base Type	MA_WeaponRangeType	

Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-545: Peer Interface MA_WEZ_MT - RangeOptimal UCI Extension Field

RangeMaxAero		
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-546: Peer Interface MA_WEZ_MT - RangeMaxAero UCI Extension Field

4.2.2MA_COP_ConfigurationSettingsRequestStatusMT UCI Extension

MA_COP_ConfigurationSettingsRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_COP_ConfigurationSettingsRequestStatusMDT

Table A-4-547: Peer Interface MA_COP_ConfigurationSettingsRequestStatusMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_COP_ConfigurationSettingsRequestStatusMDT

Message Structure		
Field Name	Field Type	Field Usage
ConfigurationSettings	MA_COP_ConfigurationSettingsMDT	Optional
Description	The configuration settings	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-548: Peer Interface MA_COP_ConfigurationSettingsRequestStatusMT - MessageData UCI Extension Field

4.2.3 MA_COP_ConfigurationSettingsRequestMT UCI Extension

MA_COP_ConfigurationSettingsRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_COP_ConfigurationSettingsRequestMDT

Table A-4-549: Peer Interface MA_COP_ConfigurationSettingsRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_COP_ConfigurationSettingsRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApplicableToIDs	MA_PackageSystemType	Repeated
Description	Indicates the ID of the Package or System that should respond to the request.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-550: Peer Interface MA_COP_ConfigurationSettingsRequestMT - MessageData UCI Extension Field

4.2.4 MA_SystemNotificationMT UCI Extension

MA_SystemNotificationMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_SystemNotificationMDT NotificationDetail : CannotComplyType NotificationDetail : CannotComplyType

Table A-4-551: Peer Interface MA_SystemNotificationMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_SystemNotificationMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemSubjectIDs	MA_PackageSystemType	Required
Description	Indicates the subject of the Notification, the thing which the Notification is about.	
SystemPerspective	NotificationPerspectiveEnum	Repeated
Description	Indicates a perspective (characteristic, behavior and/or change) of the Subject that is the basis of the Notification. List size for this element is based on "Select All That Apply" condition.	
AssociatedMessage	AssociatedMessageType	Repeated
Description	Indicates a message that is associated with the Notification.	
NotificationDetail	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the unsuccessful processing of the sibling AssociatedMessage element. This element is only expected when the Associated Message processing is not successful	
NotificationID	NotificationID_Type	Required
Description	Indicates the unique ID of the Notification.	
NotificationState	NotificationStateEnum	Required
Description	Indicates the current state within an enumerated state machine that characterizes the life cycle of a notification.	
Timestamp	DateTimeType	Required
Description	The time at which the Notification was originally triggered (ex: event time).	
Source	NotificationSourceType	Required
Description	Indicates the originating source of the Notification.	
Severity	NotificationSeverityEnum	Required

Description	Indicates the overall severity of the notification. Informational notifications are meant to provide informational context of events. Indicates the existence of a hazardous condition requiring immediate action to prevent loss of life, equipment damage, or abortion of the mission. Critical notifications indicate the need for immediate attention.	
AppliesTo	SubjectType	Repeated
Description	Indicates an Asset that the Notification applies to and/or is affected by. Optional when the Notification characterizes the Subject without regard for Assets it might affect. Omission of this element doesn't necessarily mean the Notification isn't applicable to an Asset.	
NotificationNarrative	VisibleString1024Type	Optional
Description	Human readable message for display to an operator.	

Table A-4-552: Peer Interface MA_SystemNotificationMT - MessageData UCI Extension Field

NotificationDetail		
Description	Indicates details regarding the reason for and/or a contributing factor to the unsuccessful processing of the sibling AssociatedMessage element. This element is only expected when the Associated Message processing is not successful	
Base Type	CannotComplyType	
Message Structure		
Field Name	Field Type	Field Usage
Reason	CannotComplyEnum	Required
Description	Indicates the reason why an action (Task, [Capability]Command, [SupportingCapability]Command, [Capability]Activity, etc.) was rejected, interrupted, unallocated, failed and/or generally can't be completed satisfactorily. See enumeration annotations for further details.	
Description	VisibleString1024Type	Optional
Description	Indicates a human-readable text description of the reason for the "can't comply".	
AssociatedID	ID_Type	Optional
Description	Indicates an ID corresponding to another object that is associated with or the cause of the "can't comply".	

Table A-4-553: Peer Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field

NotificationDetail		
Description	Indicates details regarding the reason for and/or a contributing factor to the unsuccessful processing of the sibling AssociatedMessage element. This element is only expected when the Associated Message processing is not successful	
Base Type	CannotComplyType	
Message Structure		
Field Name	Field Type	Field Usage
Reason	CannotComplyEnum	Required
Description	Indicates the reason why an action (Task, [Capability]Command,	

	[SupportingCapability]Command, [Capability]Activity, etc.) was rejected, interrupted, unallocated, failed and/or generally can't be completed satisfactorily. See enumeration annotations for further details.	
Description	VisibleString1024Type	Optional
Description	Indicates a human-readable text description of the reason for the "can't comply".	
AssociatedID	ID_Type	Optional
Description	Indicates an ID corresponding to another object that is associated with or the cause of the "can't comply".	

Table A-4-554: Peer Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field

4.2.5 MA_COP_ConfigurationSettingsCommandMT UCI Extension

MA_COP_ConfigurationSettingsCommandMT	
Description	Command message to adjust the configuration settings for the COP among ACPs. UCI_PRIMITIVE: Command-2. See the XSD File for more info
Ext. Fields	MessageData : MA_COP_ConfigurationSettingsCommandMDT

Table A-4-555: Peer Interface MA_COP_ConfigurationSettingsCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_COP_ConfigurationSettingsCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApplicableToIDs	MA_PackageSystemType	Required
Description	Indicates the ID of the Package or System being configured.	
COP_LeaderID	SystemID_Type	Repeated
Description	Indicates a prioritized list of unique SystemIDs for leaders for the COP. If not specified, no change to leader requested	
RequestAuthority	MA_COP_ConfigurationAuthorityEnum	Required
Description	Indicates the priority of the request being made. Generally C2 will set this to ORDER and the COP lead will set this to REQUEST	
Configuration	MA_COP_ConfigurationType	Repeated
Description	A list of configuration items.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing	

	command.
--	----------

Table A-4-556: Peer Interface MA_COP_ConfigurationSettingsCommandMT - MessageData UCI Extension Field

4.2.6 MA_EngagementCriteriaCommandStatusMT UCI Extension

MA_EngagementCriteriaCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_EngagementCriteriaCommandStatusMDT

Table A-4-557: Peer Interface MA_EngagementCriteriaCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_EngagementCriteriaCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond with ACCEPTED for the Package or individual ACPs as needed.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-558: Peer Interface MA_EngagementCriteriaCommandStatusMT - MessageData UCI Extension Field

4.2.7 MA_EngagementCriteriaCommandMT UCI Extension

MA_EngagementCriteriaCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_EngagementCriteriaCommandMDT

Table A-4-559: Peer Interface MA_EngagementCriteriaCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_EngagementCriteriaCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
EngagementCriteriaID	MA_EngagementCriteriaID_Type	Required
Description	Contains the ID of the Engagement Criteria message that should be active (for CommandState NEW or Update) or deactivated (for CommandState CANCEL).	
ApplicableRegion	MA_RegionChoiceType	Repeated
Description	The ID(s) of an OpZone/OpVolume or specified zone(s) that defines where this Engagement Criteria is applicable. If this field is not empty, an ACP and the Target must be within this region for the ACP to fire and the weapon to strike the intended target. The MA shall only start an engagement for targets inside of the Region(s).	
TimeValid	DateTimeRangeType	Optional
Description	The time window for which the Engagement Criteria is valid. If this field is left empty, the Engagement Criteria is valid until the Command is canceled or an updated.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. If an ACP is a member of a package, the ACPs SystemID does not need to be in this field as well.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-560: Peer Interface MA_EngagementCriteriaCommandMT - MessageData UCI Extension Field

4.2.8 MA_COP_ConfigurationSettingsCommandStatusMT UCI Extension

MA_COP_ConfigurationSettingsCommandStatusMT	
Description	Command status message in response to MA_COP_ConfigurationSettingsCommand.UCI_PRIMITIVE: Command-2. See the XSD File for more info
Ext. Fields	MessageData : MA_COP_ConfigurationSettingsCommandStatusMDT

Table A-4-561: Peer Interface MA_COP_ConfigurationSettingsCommandStatusMT UCI Extension

MessageData

Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_COP_ConfigurationSettingsCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-562: Peer Interface MA_COP_ConfigurationSettingsCommandStatusMT - MessageData UCI Extension Field

4.2.9 MA_DesignationRequestStatusMT UCI Extension

MA_DesignationRequestStatusMT	
Description	Reports the current status of a Designation. See the XSD File for more info
Ext. Fields	MessageData : MA_DesignationRequestStatusMDT

Table A-4-563: Peer Interface MA_DesignationRequestStatusMT UCI Extension

MessageData		
Description	See the annotation in the associated message for an overall description of the message and this type.	
Base Type	MA_DesignationRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
DesignationDataStatus	DesignationDataStatusType	Repeated
Description	Indicates the status for one or more designations.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW	

	request, an UPDATE to a request, or a CANCEL of a request.
--	--

Table A-4-564: Peer Interface MA_DesignationRequestStatusMT - MessageData UCI Extension Field

4.2.10 MA_EngagementCriteriaStatusMT UCI Extension

MA_EngagementCriteriaStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_EngagementCriteriaStatusMDT

Table A-4-565: Peer Interface MA_EngagementCriteriaStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_EngagementCriteriaStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
EngagementCriteriaID	MA_EngagementCriteriaID_Type	Optional
Description	Contains the ID of the Engagement Criteria message that is currently active. If this field is empty, that means there is no active Engagement Criteria and Engagement is not authorized.	
ApplicableRegion	MA_RegionChoiceType	Repeated
Description	The ID(s) of an OpZone/OpVolume or specified zone(s) that defines where the Engagement Criteria is applicable. If this field is not empty, the ACP must be in this region when it fires, and the calculated weapon impact location of the Target must be within this region. The MA shall only start an engagement for targets inside of the Region(s).	
TimeValid	DateTimeRangeType	Optional
Description	The time window for which the Engagement Criteria is valid. If this field is left empty, the Engagement Criteria is valid until the Command is canceled or an updated.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. If an ACP is a member of a package, the ACPs SystemID does not need to be in the field as well.	

Table A-4-566: Peer Interface MA_EngagementCriteriaStatusMT - MessageData UCI Extension Field

4.2.11 MA_AcceptableLevelOfRiskStatusMT UCI Extension

MA_AcceptableLevelOfRiskStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_AcceptableLevelOfRiskStatusMDT

Table A-4-567: Peer Interface MA_AcceptableLevelOfRiskStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_AcceptableLevelOfRiskStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
AcceptableRiskSetting	MA_AcceptableLevelOfRiskEnum	Required
Description	This is the active acceptable level of risk permitted at the package or vehicle level, which applies to all tasks and actions for the vehicle/package while active.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond for the Package or individual ACPs as needed.	
SurvivabilityRiskLevelID	SurvivabilityRiskLevelID_Type	Optional
Description	The unique identifier for the active Survivability Risk Level.	

Table A-4-568: Peer Interface MA_AcceptableLevelOfRiskStatusMT - MessageData UCI Extension Field

4.2.12 MA_DesignationRequestMT UCI Extension

MA_DesignationRequestMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_DesignationRequestMDT

Table A-4-569: Peer Interface MA_DesignationRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DesignationRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
DesignationData	MA_DesignationDataType	Repeated
Description	Indicates the data for one or more designations.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-570: Peer Interface MA_DesignationRequestMT - MessageData UCI Extension Field

4.2.13 MA_RaftVoteRequestMT UCI Extension

MA_RaftVoteRequestMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RaftVoteRequestMDT

Table A-4-571: Peer Interface MA_RaftVoteRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_RaftVoteRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
PackageID	PackageID_Type	Required
Description	The unique ID of the package that this vote request applies to.	
CandidateID	SystemID_Type	Required
Description	The unique ID of the candidate requesting a vote.	
Term	unsignedInt	Required
Description	The candidate's term.	
LastLogIndex	unsignedInt	Optional
Description	The index of the candidate's last log entry.	
LastLogTerm	unsignedInt	Optional
Description	The term of the candidate's last log entry.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-572: Peer Interface MA_RaftVoteRequestMT - MessageData UCI Extension Field

4.2.14 MA_RaftVoteRequestStatusMT UCI Extension

MA_RaftVoteRequestStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RaftVoteRequestStatusMDT

Table A-4-573: Peer Interface MA_RaftVoteRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_RaftVoteRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
Term	unsignedInt	Required
Description	The candidate's current term.	
VoteGranted	boolean	Required
Description	Indicates whether the candidate received a vote from the follower.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-574: Peer Interface MA_RaftVoteRequestStatusMT - MessageData UCI Extension Field

4.2.15 MA_RaftAppendEntriesRequestMT UCI Extension

MA_RaftAppendEntriesRequestMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RaftAppendEntriesRequestMDT

Table A-4-575: Peer Interface MA_RaftAppendEntriesRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_RaftAppendEntriesRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
PackageID	PackageID_Type	Required
Description	The unique ID of the package that this request applies to.	

LeaderID	SystemID_Type	Required
Description	The unique ID of the current leader system.	
Term	unsignedInt	Required
Description	The leader's current term.	
PrevLogIndex	unsignedInt	Optional
Description	The index of the log entry immediately preceding new ones.	
PrevLogTerm	unsignedInt	Optional
Description	The term of the PrevLogIndex entry.	
LogEntry	MA_RaftLogEntryType	Repeated
Description	Log entries to store. For heartbeat, no log entry is included.	
LeaderCommit	unsignedInt	Optional
Description	The leader's commit index, which is the highest log entry index that the leader has committed and has been replicated on a majority of the nodes.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-576: Peer Interface MA_RaftAppendEntriesRequestMT - MessageData UCI Extension Field

4.2.16 MA_RaftAppendEntriesRequestStatusMT UCI Extension

MA_RaftAppendEntriesRequestStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RaftAppendEntriesRequestStatusMDT

Table A-4-577: Peer Interface MA_RaftAppendEntriesRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_RaftAppendEntriesRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
Term	unsignedInt	Required
Description	The follower's current term, returned to the leader.	
Success	boolean	Optional
Description	Indicates whether the follower has a log entry matching PrevLogIndex and PrevLogTerm.	

RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-578: Peer Interface MA_RaftAppendEntriesRequestStatusMT - MessageData UCI Extension Field

4.2.17 MA_CAP_ExecutionStatusReportMT UCI Extension

MA_CAP_ExecutionStatusReportMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_CAP_ExecutionStatusReportMDT

Table A-4-579: Peer Interface MA_CAP_ExecutionStatusReportMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CAP_ExecutionStatusReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
PackageID	PackageID_Type	Optional
Description	The ID of the package executing the CAP.	
PackageRequirementID	RequirementInstanceID_ChoiceType	Repeated
Description	Contains the unique ID(s) of the package-level requirements associated with the ongoing CAP activity. This will typically be a package-level PROTECT_CAP Action and/or a package-level CAP Task.	
AOI_Coverage	PercentType	Optional
Description	Percent of the Area of Interest (AOI) currently covered by any vehicle's sensors.	
PlanMetrics	MA_CAP_PlanMetrics_Type	Optional
Description	Sensor coverage and time gap metrics of the planned CAP routes over the next racetrack cycle.	
ExecutionStatus	MA_CAP_ExecutionStatus_Type	Repeated
Description	Contains a list of CAP statuses from vehicles executing the CAP.	

Table A-4-580: Peer Interface MA_CAP_ExecutionStatusReportMT - MessageData UCI Extension Field

4.2.18 MA_MissionPlanMT UCI Extension

MA_MissionPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_MissionPlanMDT

Table A-4-581: Peer Interface MA_MissionPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	Indicates a unique ID assigned to the MissionPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
MissionPlanCommandID	MissionPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which this MissionPlan originated from.	
Applicability	MA_PlanApplicabilityType	Required
Description	Indicates the System or Systems which have a direct relationship with the Mission Plan. See annotations for the underlying type and its child elements for details.	
Window	DateTimeRangeType	Optional
Description	The time window for which the Plan is applicable.	
SubPlans	MA_PlansReferenceBaseType	Optional
Description	Indicates the set of *Plans which are included as part of the MissionPlan. The included SubPlans share the same Applicability as the MissionPlan.	
ExecutionSequence	ExecutionSequenceType	Optional
Description	Indicates the MissionPlan's flow of execution when there are multiple kinematic and action plans. The kinematic and action plans are combined into sets and given unique IDs. An execution flow may be created by linking *ExecutionPlanSets of different types (e.g. OrbitExecutionPlanSet and RouteExecutionPlanSet).	
ParentMissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a MissionPlan that is the parent of this MissionPlan.	
SubordinateMissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a MissionPlan that is subordinate to this MissionPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned.	

	*Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	MA_MissionPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	
Remarks	RemarksType	Optional
Description	Indicates information about the mission plan from an operator intended for display. Both short and longer detailed information can be provided.	

Table A-4-582: Peer Interface MA_MissionPlanMT - MessageData UCI Extension Field

4.2.19 MA_ActionPlanMT UCI Extension

MA_ActionPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ActionPlanMDT

Table A-4-583: Peer Interface MA_ActionPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_ActionPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
ActionPlanID	ActionPlanID_Type	Required
Description	Indicates a unique ID assigned to the ActionPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	ActionPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which this ActionPlan originated from.	
Plan	MA_ActionPlanType	Required
Description	Indicates the details of the ActionPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	ActionPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-584: Peer Interface MA_ActionPlanMT - MessageData UCI Extension Field

4.2.20 MA_TaskPlanMT UCI Extension

MA_TaskPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_TaskPlanMDT

Table A-4-585: Peer Interface MA_TaskPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_TaskPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlanID	TaskPlanID_Type	Required
Description	Indicates a unique ID assigned to the TaskPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	TaskPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the TaskPlan originated from.	
Plan	MA_TaskPlanType	Required
Description	Contains the details of the task allocation plan.	
ForPlanningUseOnly	Boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	MA_TaskPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-586: Peer Interface MA_TaskPlanMT - MessageData UCI Extension Field

4.2.21 MA_RoutePlanMT UCI Extension

MA_RoutePlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RoutePlanMDT

Table A-4-587: Peer Interface MA_RoutePlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_RoutePlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
RoutePlanID	RoutePlanID_Type	Required
Description	Indicates a unique ID assigned to the RoutePlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	RoutePlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the RoutePlan originated from.	
Plan	MA_RoutePlanType	Required
Description	Contains the details of the route plan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	RoutePlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-588: Peer Interface MA_RoutePlanMT - MessageData UCI Extension Field

4.2.22 MA_ActivityPlanMT UCI Extension

MA_ActivityPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ActivityPlanMDT

Table A-4-589: Peer Interface MA_ActivityPlanMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActivityPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage

ActivityPlanID	ActivityPlanID_Type	Required
Description	Indicates a unique ID assigned to the ActivityPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	ActivityPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which this ActivityPlan originated from.	
Plan	MA_ActivityPlanType	Required
Description	Indicates the details of the ActivityPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is a used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	ActivityPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-590: Peer Interface MA_ActivityPlanMT - MessageData UCI Extension Field

4.2.23 MA_RouteActivityPlanMT UCI Extension

MA_RouteActivityPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RouteActivityPlanMDT

Table A-4-591: Peer Interface MA_RouteActivityPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_RouteActivityPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
RouteActivityPlanID	RouteActivityPlanID_Type	Required
Description	Indicates a unique ID assigned to the RouteActivityPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	RouteActivityPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the RouteActivityPlan originated from.	
Plan	MA_RouteActivityPlanType	Required

Description	Indicates the details of the RouteActivityPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	RouteActivityPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-592: Peer Interface MA_RouteActivityPlanMT - MessageData UCI Extension Field

4.2.24 MA_ActionMT UCI Extension

MA_ActionMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ActionMDT

Table A-4-593: Peer Interface MA_ActionMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActionMDT	
Message Structure		
Field Name	Field Type	Field Usage
ActionID	ActionID_Type	Required
Description	Indicates a unique ID assigned to the Action. Minor updates to the Action can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new instance with a different child UUID value.	
ActionType	MA_ActionTypeEnum	Required
Description	Indicates the type of Action; the type of behavior to be performed when the Action is executed. An Action is a representation of an operational planning sentence/statement whose most complex form is: 1. Do [ActionType] within [ActionConstraints] to [TargetObject] within [TargetObjectConstraint] to/on/against/toward [SecondaryObject] Many other forms are also possible, including: 2. do [ActionType]	

	3. do [ActionType] to [TargetObject] 4. do [ActionType] to [TargetObject] doing [TargetObjectConstraint] to [SecondaryObject].	
ActionConstraints	MA_RequirementConstraintsType	Optional
Description	Indicates constraints on the Action. The constraint type used here is common to all Requirement types: Effect, Action, Task, [Capability]Command, Response. Requirement constraints can be 1) given in a [Requirement] message, 2) overridden as a planning input in a [Requirement]PlanCommand message, 3) further refined/overridden during plan creation and reported in a [Requirement]Plan message to inform subsequent planning or execution. See sibling ActionType element annotation for an overall description of Action structure.	
ActionGuidance	RequirementGuidanceType	Optional
Description	Indicates guidance on planning and C2 of the Action.	
TargetObject	IdentityKindInstanceType	Repeated
Description	Indicates the target of the Action; the object the Action will be done to or for. If omitted, the Action places no explicit limitation on which TargetObject it can be done to. See sibling ActionType element annotation for an overall description of Action structure. Note that the term "target" is used in a general sense. For some Requirement types, a more suitable term might be "subject", "point", "location", etc. For example, the "target" of a COVER Action could be a blue/friendly System.	
TargetObjectConstraints	RequirementTargetConstraintsType	Optional
Description	Indicates constraints "on" the TargetObject that must be satisfied before the Action can be done to or for it. See sibling ActionType element annotation for an overall description of Effect structure.	
SecondaryObject	IdentityKindInstanceType	Repeated
Description	Indicates a thing the sibling TargetObject must act on/against/toward to make the Action applicable. See sibling ActionType element annotation for an overall description of Action structure.	
Metadata	RequirementMetadataType	Optional
Description	Indicates traceability and other metadata associated with the Action.	

Table A-4-594: Peer Interface MA_ActionMT - MessageData UCI Extension Field

4.2.25 MA_ResponseMT UCI Extension

MA_ResponseMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ResponseMDT

Table A-4-595: Peer Interface MA_ResponseMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.

Base Type	MA_ResponseMDT	
Message Structure		
Field Name	Field Type	Field Usage
ResponseID	ResponseID_Type	Required
Description	Indicates the unique ID of the Response. Minor updates to the Response can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new instance with a different child UUID value.	
ResponseType	ResponseTypeEnum	Repeated
Description	Indicates the types of Response options included in the message. List size for this element is based on "Select All That Apply" condition.	
ResponseManagementConstraints	RequirementConstraintsType	Optional
Description	Indicates monitoring constraints on the Response. The constraint type used here is common to all Requirement types: Effect, Action, Task, [Capability]Command, Response. Requirement constraints can be 1) given in a [Requirement] message, 2) overridden as a planning input in a [Requirement]PlanCommand message, 3) further refined/overridden during plan creation and reported in a [Requirement]Plan message to inform subsequent planning or execution. See sibling Option element annotation for an overall description of Response structure. Constraints given here aren't conveyed to instantiated Response options for a particular triggering event. The constraints given here apply to Response management (planning, allocation and trigger monitoring prior to a triggering event). Constraints to apply to instantiated Response options, if any, are given elsewhere in the message.	
ResponseManagementGuidance	RequirementGuidanceType	Optional
Description	Indicates guidance on planning and C2 of the Response.	
ResponsePlurality	MA_TaskPluralityEnum	Optional
Description	Indicates whether the response applies a single entity or as a joint condition. A joint condition implies condiseration of the response trigger and activation of the response by all associated entities.	
Option	MA_ResponseOptionDetailsType	Repeated
Description	Indicates an Option of the Response. Responses are designed to be flexible. A Response is a set of prioritized Options to address an anticipated triggering event, events or event sequence in the battlespace. Responses are allocated to Systems via a ResponsePlan. When a ResponsePlan is activated, monitoring for the triggering events in the Options begins. When a triggering event happens, the applicable Option(s) are evaluated.	
RequirementsTemplate	MA_RequirementsTemplateType	Repeated
Description	The sibling Option element associates triggering events with a desired Response one of which is to use this element, a Requirements template, to	

	generate or change one or more Requirements messages/objects (Effect, Action, Task, [Capability]Command). An instance of this element is a RequirementsTemplate; it indicates the types of Requirements to generate or update and their details. Each RequirementsTemplate has a unique ID and therefore can be used for multiple Options.	
Metadata	RequirementMetadataType	Optional
Description	Indicates traceability and other metadata associated with the Response.	

Table A-4-596: Peer Interface MA_ResponseMT - MessageData UCI Extension Field

4.2.26 MA_OpVolumeMT UCI Extension

MA_OpVolumeMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_OpVolumeMDT

Table A-4-597: Peer Interface MA_OpVolumeMT UCI Extension

MessageData		
Description	This element represents the details regarding the operational volume.	
Base Type	MA_OpVolumeMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpVolumeID	OpVolumeID_Type	Required
Description	This element represents the unique identifier of the OpVolume associated with this message.	
Category	MA_OpZoneCategoryEnum	Required
Description	This element indicates the type of volume.	
CategoryUniqueData	MA_OpZoneCategoryType	Optional
Description	Contains parameters unique to certain OpZoneCategoryEnum values.	
Volume	MA_OpVolumeChoiceType	Required
Description	This element represents the characteristics of the operational volume.	
SituationalAwareness	boolean	Required
Description	Volume used only for situational awareness. Not used for planning purposes.	
OpDescription	OpDescriptionType	Optional
Description	A human-readable descriptive name with free text remarks.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this operational item to specify what the source or motivation for it originated from. This could be ATO, ACO, etc.	
Source	CreationSourceEnum	Optional

	Description	Indicates the source of the information.	
Schedule		ScheduleType	Optional
	Description	This element represents a date/time interval associated with the operational item during which the item is in effect.	
AssociatedTime		TimeFunctionType	Repeated
	Description	Indicates time related events that are associated to the Op data type such as when activated or when operational. The multiplicity is limited to N-1 options where NONE is an event that has no value, thus removed from list of available options.	
DataLinkIdentifier		DataLinkIdentifierPET	Repeated
	Description	List of data link ID. Multiple data link IDs can be reported for the same network type.	
Priority		unsignedInt	Optional
	Description	This field represents the priority to be considered when choosing between multiple available points.	
QualifyingTags		QualifyingTagsType	Optional
	Description	Provides identity qualifications to augment identification and associated processing of the OpPoint.	
AppliesToIDs		MA_PackageSystemType	Repeated
	Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
SystemScheduleOverride		SystemScheduleStateType	Repeated
	Description	System-specific schedule that will override any part of the main schedule. This allows for system-specific schedule different than main schedule. When adding a SystemScheduleOverride, the child SystemID also must be added to the sibling SystemID list if the sibling list is not empty. The SystemScheduleOverride is independent of time planning. For the system, this override can be done at execution.	

Table A-4-598: Peer Interface MA_OpVolumeMT - MessageData UCI Extension Field

4.2.27 MA_ApprovalAuthorityMT UCI Extension

MA_ApprovalAuthorityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ApprovalAuthorityMDT ApplicableIDs : MA_PackageSystemType

Table A-4-599: Peer Interface MA_ApprovalAuthorityMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ApprovalAuthorityMDT	
Message Structure		
Field Name	Field Type	Field Usage

ApprovalAuthorityID	ApprovalAuthorityID_Type	Required
Description	Indicates associated Approval Authority identifier for applicable system and approval policy.	
ApplicableIDs	MA_PackageSystemType	Repeated
Description	Indicates to which system this Approval Authority applies.	
SystemApprovalPolicy	SystemApprovalPolicyType	Repeated
Description	Indicates an ApprovalPolicy and one or more approval authorities ("approvers").	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-600: Peer Interface MA_ApprovalAuthorityMT - MessageData UCI Extension Field

ApplicableIDs		
Description	Indicates to which system this Approval Authority applies.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-601: Peer Interface MA_ApprovalAuthorityMT - ApplicableIDs UCI Extension Field

4.2.28 MA_CapabilitySetMT UCI Extension

MA_CapabilitySetMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_CapabilitySetMDT

Table A-4-602: Peer Interface MA_CapabilitySetMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type

	for details.	
Base Type	MA_CapabilitySetMDT	
Message Structure		
Field Name	Field Type	Field Usage
CapabilitySetID	MA_CapabilitySetID_Type	Required
Description	Indicates the unique ID of the CapabilitySet.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates a Capability that exists in the set.	
ApplicableSystemID	SystemID_Type	Optional
Description	Indicates the System that the CapabilitySet is relevant to.	
MissionPlanID	MissionPlanID_Type	Optional
Description	Indicates the MissionPlan that the CapabilitySet is relevant to.	
MissionID	MissionID_Type	Optional
Description	Indicates the Mission that the CapabilitySet is relevant to.	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-603: Peer Interface MA_CapabilitySetMT - MessageData UCI Extension Field

4.2.29 MA_MissionPlanActivationCommandStatusMT UCI Extension

MA_MissionPlanActivationCommandStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	Plans : MA_PlansReferenceType MessageData : MA_MissionPlanActivationCommandStatusMDT ActivationCommandByState : MA_PlanActivationStatusType

Table A-4-604: Peer Interface MA_MissionPlanActivationCommandStatusMT UCI Extension

Plans		
Description	Indicates the Plan or Plans in the sibling CommandState.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated

Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-605: Peer Interface MA_MissionPlanActivationCommandStatusMT - Plans UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanActivationCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	MissionPlanActivationCommandID_Type	Required
Description	The ID of the MissionPlanActivationCommand this status pertains to.	
ActivationStatus	PlanCommandStatusType	Required
Description	Indicates the status of the MissionPlanActivationCommand.	
ActivationCommandByState	MA_PlanActivationStatusType	Repeated
Description	Indicates plans in a given commanded activation state. List size allows for each available PlanActivationCommandState to be represented.	

Table A-4-606: Peer Interface MA_MissionPlanActivationCommandStatusMT - MessageData UCI Extension Field

ActivationCommandByState

Description	Indicates plans in a given commanded activation state. List size allows for each available PlanActivationCommandState to be represented.	
Base Type	MA_PlanActivationStatusType	
Message Structure		
Field Name	Field Type	Field Usage
PlanActivationCommandState	PlanActivationStateEnum	Required
Description	Indicates an activation command state that one or more *Plans is in.	
Plans	MA_PlansReferenceType	Required
Description	Indicates the Plan or Plans in the sibling CommandState.	

Table A-4-607: Peer Interface MA_MissionPlanActivationCommandStatusMT - ActivationCommandByState UCI Extension Field

4.2.30 MA_MissionPlanExecutionStatusMT UCI Extension

MA_MissionPlanExecutionStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	ExecutionPlanSetStatus : MA_ExecutionPlanSetExecutionStateType PlanExecutionStatus : MA_MissionPlanExecutionStateType MessageData : MA_MissionPlanExecutionStatusMDT

Table A-4-608: Peer Interface MA_MissionPlanExecutionStatusMT UCI Extension

ExecutionPlanSetStatus		
Description	Indicates the execution state of an execution plan set of the MissionPlan indicated by the sibling MissionPlanID element.	
Base Type	MA_ExecutionPlanSetExecutionStateType	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPlanSetID	ExecutionPlanSetID_Type	Required
Description	Indicates the unique ID of the execution plan set.	
ExecutionPlanSetExecutionState	PlanExecutionStateEnum	Required
Description	The current state of the execution plan set.	

Table A-4-609: Peer Interface MA_MissionPlanExecutionStatusMT - ExecutionPlanSetStatus UCI Extension Field

PlanExecutionStatus	
Description	Indicates the execution state of a MissionPlan of the System indicated by the sibling SystemID element.
Base Type	MA_MissionPlanExecutionStateType
Message Structure	

Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	The ID of the MissionPlan this status pertains to.	
PlanExecutionState	PlanExecutionStateEnum	Required
Description	The current state of the plan.	
ExecutionPlanSetStatus	MA_ExecutionPlanSetExecutionStateType	Repeated
Description	Indicates the execution state of an execution plan set of the MissionPlan indicated by the sibling MissionPlanID element.	

Table A-4-610: Peer Interface MA_MissionPlanExecutionStatusMT - PlanExecutionStatus UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanExecutionStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	The unique ID of the System whose Plan is being statused.	
Source	SystemSourceEnum	Required
Description	Indicates the source of the data in sibling elements. See enumeration annotations for further details.	
PlanExecutionStatus	MA_MissionPlanExecutionStateType	Repeated
Description	Indicates the execution state of a MissionPlan of the System indicated by the sibling SystemID element.	

Table A-4-611: Peer Interface MA_MissionPlanExecutionStatusMT - MessageData UCI Extension Field

4.2.31 MA_ConstraintPriorityListActivationStatusMT UCI Extension

MA_ConstraintPriorityListActivationStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ConstraintPriorityListActivationStatusMDT

Table A-4-612: Peer Interface MA_ConstraintPriorityListActivationStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ConstraintPriorityListActivationStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage

ConstraintPriorityListActivationDataID	MA_ConstraintPriorityListActivationDataID_Type	Required
Description	The unique identifier for the CPL Activation Data message.	
ActiveConstraintPriorityListID	MA_ConstraintPriorityListID_Type	Required
Description	The unique identifier for the active Constraint Priority List.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond for the Package or individual ACPs as needed.	

Table A-4-613: Peer Interface MA_ConstraintPriorityListActivationStatusMT - MessageData UCI Extension Field

4.2.32 MA_ConstraintPriorityListCommandMT UCI Extension

MA_ConstraintPriorityListCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ConstraintPriorityListCommandMDT

Table A-4-614: Peer Interface MA_ConstraintPriorityListCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ConstraintPriorityListCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConstraintPriorityListActivationDataID	MA_ConstraintPriorityListActivationDataID_Type	Required
Description	This ID of the Activated message that should be active.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. If an ACP is a member of a package, the ACPs SystemID does not need to be in this field as well.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-615: Peer Interface MA_ConstraintPriorityListCommandMT - MessageData UCI Extension Field

4.2.33 MA_ConstraintPriorityListCommandStatusMT UCI Extension

MA_ConstraintPriorityListCommandStatusMT
--

Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ConstraintPriorityListCommandStatusMDT

Table A-4-616: Peer Interface MA_ConstraintPriorityListCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ConstraintPriorityListCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond with ACCEPTED for the Package or individual ACPs as needed.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-617: Peer Interface MA_ConstraintPriorityListCommandStatusMT - MessageData UCI Extension Field

4.2.34 MA_EscortCommandMT UCI Extension

MA_EscortCommandMT	
Description	This message is the Escort form of the general UCI Capability Command. It is used to manually invoke a Escort Capability to perform a new Escort Activity or change an existing interactive Escort Activity. It differs from a Escort Task because it is intended for direct interaction with the host of the Capability, not a planning Service, and therefore is not expected to impact the route of the host System or otherwise interrupt the planned MissionPlan. Additionally, Capability Commands are intended to allow multiple clients to use a single Capability as a shared resource; see the Control* series of messages. Capability Commands can be used in parallel with Tasks, but are generally deferential to them. However, exceptions are allowed and even expected; the relationship between Tasks and Capability Commands is not rigidly dictated by the UCI schema. Several mechanisms are provided in other messages to tailor the relationship and relative importance of Tasks and [Capability]Commands including Capability precedence, Task rank, [Capability]Command rank, [Capability]Activity rank and control Authorization.

	See the XSD File for more info
Ext. Fields	MessageData : MA_EscortCommandMDT

Table A-4-618: Peer Interface MA_EscortCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_EscortCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Command	MA_EscortCommandType	Repeated
Description	Indicates an instance of an Escort Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Capability CommandStatus message.	

Table A-4-619: Peer Interface MA_EscortCommandMT - MessageData UCI Extension Field

4.2.35 MA_EscortCommandStatusMT UCI Extension

MA_EscortCommandStatusMT	
Description	This message indicates the result of an EscortCommand. This message will reflect whether the command was received, accepted and/or rejected. This message will only be used to status the command until the recipient determines whether or not it can be started or scheduled. The details of the specific activity or activities that result from the command will report status via the EscortActivity message. See the XSD File for more info
Ext. Fields	MessageData : MA_EscortCommandStatusMDT

Table A-4-620: Peer Interface MA_EscortCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_EscortCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	

CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-621: Peer Interface MA_EscortCommandStatusMT - MessageData UCI Extension Field

4.2.36 MA_ExecutionPriorityListActivationStatusMT UCI Extension

MA_ExecutionPriorityListActivationStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ExecutionPriorityListActivationStatusMDT

Table A-4-622: Peer Interface MA_ExecutionPriorityListActivationStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ExecutionPriorityListActivationStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPriorityListActivationDataID	MA_ExecutionPriorityListActivationDataID_Type	Required
Description	The unique identifier for the EPL Activation Data message.	
ActiveExecutionPriorityListID	MA_ExecutionPriorityListID_Type	Required
Description	The unique identifier for the active EPL message.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond for the Package or individual ACPs as needed.	

Table A-4-623: Peer Interface MA_ExecutionPriorityListActivationStatusMT - MessageData UCI Extension Field

4.2.37 MA_ExecutionPriorityListCommandMT UCI Extension

MA_ExecutionPriorityListCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info

Ext. Fields	MessageData : MA_ExecutionPriorityListCommandMDT
--------------------	--

Table A-4-624: Peer Interface MA_ExecutionPriorityListCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ExecutionPriorityListCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPriorityListActivationDataID	MA_ExecutionPriorityListActivationDataID_Type	Required
Description	The ID of the Activation Data message that should be used.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. If an ACP is a member of a package, the ACPs SystemID does not need to be in this field as well.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-625: Peer Interface MA_ExecutionPriorityListCommandMT - MessageData UCI Extension Field

4.2.38 MA_ExecutionPriorityListCommandStatusMT UCI Extension

MA_ExecutionPriorityListCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ExecutionPriorityListCommandStatusMDT

Table A-4-626: Peer Interface MA_ExecutionPriorityListCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ExecutionPriorityListCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to	

	respond with ACCEPTED for the Package or individual ACPs as needed.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-627: Peer Interface MA_ExecutionPriorityListCommandStatusMT - MessageData UCI Extension Field

4.2.39 MA_FlightActivityMT UCI Extension

MA_FlightActivityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	VehicleCommandState : Activity : MA_FlightActivityType Speed : PathSegmentSpeedValueType Heading : MA_DirectionReferenceType

Table A-4-628: Peer Interface MA_FlightActivityMT UCI Extension

VehicleCommandState		
Description		
Base Type		
Message Structure		
Field Name	Field Type	Field Usage

Table A-4-629: Peer Interface MA_FlightActivityMT - VehicleCommandState UCI Extension Field

Activity		
Description	Indicates the dynamic operational characteristics of an Activity of a System's Flight Capability.	
Base Type	MA_FlightActivityType	
Message Structure		
Field Name	Field Type	Field Usage
ActualEndPoint	MA_EndPointType	Repeated

Description	Indicates end points for the Flight activity. The current end point (the end point the System is currently flying to) is listed first followed by subsequent end points if known. If the Flight Activity was planned and the actual Activity is following the plan, the RouteActivityPlan* messages provide details relative to the plan. For planned Flight Activities against moving targets the actual, dynamically calculated kinematic details can be provided with this element.	
ActualCompletionTime	DateTimeType	Optional
Description	This field specifies the actual time when the Flight Activity completed.	
VehicleCommandState	MA_VehicleCommandStateType	Required
Description	Indicates the currently commanded parameters per the Flight Autonomy's execution of the request FlightCommand.	
CurveFollowingControl	MA_CurveFollowingControlType	Optional
Description	Indicates the curve following parameters, validity and status.	
RoutePlanInterceptStatus	MA_RoutePlanInterceptStatusType	Optional
Description	Status of the executing RoutePlan Intercept.	
ActivityID	ActivityID_Type	Required
Description	Indicates the unique ID of the Activity.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates a Capability which the Activity is an instance of. Generally an Activity is an instance of a single Capability. An Activity can be associated with multiple Capabilities when, for example, a Subsystem has distinct Capabilities for automated and manual. In this case, if a manual command is issued while an automated Activity that achieves the desired result already exists, a single Activity represents both Capabilities.	
Interactive	boolean	Required
Description	Indicates whether or not the Activity can be edited/modified via a [Capability]Command...Activity message.	
ActivityState	ActivityStateEnum	Required
Description	Indicates the current state of the Activity its state machine. See enumeration annotations for further details.	
Basis	ActivityBasisEnum	Optional
Description	Indicates the basis of the Activity. See enumerated type annotations for further details. If omitted, a basis of ACTUAL should be assumed.	
ActivityRank	ComparableRankingType	Optional
Description	Indicates the rank of the Activity amongst all other Activities of the Capability and/or Subsystem. This isn't necessarily the same as the Rank associated with the sibling ActivitySource. This element is meant to convey the Subsystem determined relative ranking of all Activities of a Capability category (ESM, EA, etc.). For Subsystems with multiple Capability categories this element is meant to convey relative ranking across all Capability categories. In addition to the rank of the ActivitySource, an Activity's rank can be influenced by Capability priority (see CapabilitySettings), RF_ControlCommands and other factors that influence the Subsystem's internal scheduling and resource allocation.	
ActivityReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling	

	ActivityState element. This element is only expected when the Activity is in a potentially undesirable state such as constrained, failed or completed with less than optimum results.	
Source	ActivitySourceType	Repeated
Description	Indicates an originating "source" of the Activity; the command or other item which invoked this specific Activity of a Capability. A single Activity can fully or partially satisfy Activity sources.	
EstimatedStartTime	DateTimeType	Optional
Description	Indicates the estimated time when the Activity started or is expected to start.	
EstimatedCompletionTime	DateTimeType	Optional
Description	Indicates the estimated time when the Activity will complete.	
EstimatedPercentComplete	PercentType	Optional
Description	Indicates the current estimated percent complete of the Activity.	

Table A-4-630: Peer Interface MA_FlightActivityMT - Activity UCI Extension Field

Speed		
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-631: Peer Interface MA_FlightActivityMT - Speed UCI Extension Field

Heading		
Description	Intended heading of the aircraft.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-632: Peer Interface MA_FlightActivityMT - Heading UCI Extension Field

4.2.40 MA_FlightCommandMT UCI Extension

MA_FlightCommandMT	
Description	Message extension included to invoke a flight capability to perform a new flight activity or change and existing flight activity. See the XSD File for more info
Ext. Fields	Command : MA_FlightCommandType Capability : MA_FlightCapabilityCommandType HSA_CSA : MA_HSA_CSA_Type WaypointFollowing : MA_WaypointFollowingType CurveFollowing : MA_CurveControlType Speed : PathSegmentSpeedType Heading : MA_DirectionReferenceType SpeedChoice : MA_HSA_SpeedChoiceType SpeedValue : PathSegmentSpeedValueType CurveFitMethod : MA_CurveFitMethodEnum Reference : MA_HeadingReferenceEnum ControlPoint : MA_CurveFollowingControlPointType RelativeAcceleration : MA_AccelerationChoiceType RelativeVelocity : MA_VelocityChoiceType OrientationRate : MA_OrientationRateChoiceType Direction : MA_DirectionChoiceType Course : MA_DirectionReferenceType

Table A-4-633: Peer Interface MA_FlightCommandMT UCI Extension

Command		
Description	Indicates an instance of a Flight Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate independent Capability CommandStatus message.	
Base Type	MA_FlightCommandType	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_FlightCapabilityCommandType	Required
Description	Indicates a new invocation of a Flight Capability. Generally, if accepted, the command will result in one or more new Flight Activities being created and reported via the Flight Activity message. The request/response interaction terminates as soon as the command is accepted or rejected; this element is not used to interact with an "active" command. Updates and/or additional interaction with the resulting Activity (after the command is accepted) is accomplished via the sibling Activity element.	

Activity	MA_FlightActivityCommandType	Required
Description	Indicates a command to modify an existing Flight Activity (which was previously reported via the Flight Activity message and was marked as "interactive"). The request/response interaction terminates as soon as the modification is accepted or rejected. The modifications are reflected in subsequent Flight Activity messages.	

Table A-4-634: Peer Interface MA_FlightCommandMT - Command UCI Extension Field

Capability		
Description	Indicates a new invocation of a Flight Capability. Generally, if accepted, the command will result in one or more new Flight Activities being created and reported via the Flight Activity message. The request/response interaction terminates as soon as the command is accepted or rejected; this element is not used to interact with an "active" command. Updates and/or additional interaction with the resulting Activity (after the command is accepted) is accomplished via the sibling Activity element.	
Base Type	MA_FlightCapabilityCommandType	
Message Structure		
Field Name	Field Type	Field Usage
Loiter	MA_LoiterType	Optional
Description	Indicates the parameters for a loiter.	
MustFly	MustFlyType	Optional
Description	Indicates the parameters for a must fly.	
Formation	MA_FormationType	Repeated
Description	Indicates the relative positions for the entities in the formation.	
FlightControlMode	MA_FlightControlModesChoiceType	Optional
Description	See annotations in child elements and messages/elements that use this type for details.	
AltitudeStackedMarshall	MA_AltitudeStackedMarshallType	Optional
Description	Indicates kinematics for an altitude stacked marshal.	
Departure	MA_DepartureType	Optional
Description	This element identifies the parameters for a departure/take-off task.	
Recovery	MA_RecoveryType	Optional
Description	This element identifies the parameters for a recovery/land task.	
RoutePlanIntercept	MA_RoutePlanInterceptType	Optional
Description	This element defines the parameters for a Route intercept	
CapabilityID	CapabilityID_Type	Required
Description	Indicates the Capability instance being commanded.	
Ranking	CapabilityCommandRankingType	Required
Description	Indicates the command's rank relative to other commands and rank-related overrides and tailoring.	

TemporalConstraints	CapabilityCommandTemporalConstraintsType	Optional
Description	Indicates temporal constraints for the command. If omitted, the command should be scheduled immediately while satisfying other applicable constraints.	
OverrideRejection	boolean	Optional
Description	Indicates that the Command shall be performed even though it was previously rejected.	
Traceability	TraceabilityType	Optional
Description	C2 sources work at different levels of detail and abstraction, progressing from what to do to how specifically to do it. Inputs from abstract tasking sources and Tasks can be decomposed into discrete, actionable Tasks and/or Capability commands. This element provides traceability to the external tasking or Task from which this Capability command was derived.	
Classification	SecurityInformationType	Optional
Description	This element provides the classification label that the Subsystem should place on messages and other data resulting from the Command.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-635: Peer Interface MA_FlightCommandMT - Capability UCI Extension Field

HSA_CSA		
Description	This message shall be used to provide the ability to command a new flight vector to the Platform.	
Base Type	MA_HSA_CSA_Type	
Message Structure		
Field Name	Field Type	Field Usage
Altitude	AltitudeReferenceType	Optional
Description	Altitude hold value to be achieved and reference to altitude measurement source.	
Speed	PathSegmentSpeedType	Optional
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Direction	MA_DirectionChoiceType	Optional
Description	Defines heading or course type and reference to hold	

Table A-4-636: Peer Interface MA_FlightCommandMT - HSA_CSA UCI Extension Field

WaypointFollowing	
Description	This message shall be used to provide the ability to send a new waypoint path or segment for the Platform to follow.
Base Type	MA_WaypointFollowingType

Message Structure		
Field Name	Field Type	Field Usage
Route	MA_RouteType	Required
Description	Indicates the Paths and Segments that make up the Route to be flown.	

Table A-4-637: Peer Interface MA_FlightCommandMT - WaypointFollowing UCI Extension Field

CurveFollowing		
Description	Indicates the parameters for curve following control.	
Base Type	MA_CurveControlType	
Message Structure		
Field Name	Field Type	Field Usage
CurveSegments	MA_NURBS_PointType	Repeated
Description	Specifies the curve segments as a set of NURBS points.	
AppendCurve	EmptyType	Optional
Description	Specifies this curve will be appended to a previous curve command. This is only valid if the vehicle is currently executing a curve.	
EndOfCurveBehavior	MA_EndOfCurveBehaviorEnum	Optional
Description	Specifies the vehicle behavior at the completion of the curve.	

Table A-4-638: Peer Interface MA_FlightCommandMT - CurveFollowing UCI Extension Field

Speed		
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Base Type	PathSegmentSpeedType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedChoice	PathSegmentSpeedChoiceType	Optional
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
SpeedOptimization	SpeedOptimizationEnum	Optional
Description	Indicates that the System will vary its speed autonomously according to the specified optimization algorithm.	

Table A-4-639: Peer Interface MA_FlightCommandMT - Speed UCI Extension Field

Heading	
Description	Defines heading type and reference to hold.
Base Type	MA_DirectionReferenceType
Message Structure	

Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-640: Peer Interface MA_FlightCommandMT - Heading UCI Extension Field

SpeedChoice		
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
Base Type	MA_HSA_SpeedChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedValue	PathSegmentSpeedValueType	Required
Description	Indicates speed in meters per second (m/s).	
MachValue	MachType	Required
Description	Indicates the speed reference for the associated speed value.	

Table A-4-641: Peer Interface MA_FlightCommandMT - SpeedChoice UCI Extension Field

SpeedValue		
Description	Indicates speed in meters per second (m/s).	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-642: Peer Interface MA_FlightCommandMT - SpeedValue UCI Extension Field

CurveFitMethod	
Description	Method through which a curve should be fitted to the discretized points in ControlPoint.
Base Type	MA_CurveFitMethodEnum
Message Structure	
Enumeration Literal	Description
B_SPLINE	B-Spline (basis spline) fit.

BEZIER	Bezier curve fit.
CATMULL_ROM	Catmull-Rom spline fit.
NATURAL_CUBIC	Natural Cubic curve fit.

Table A-4-643: Peer Interface MA_FlightCommandMT - CurveFitMethod UCI Extension Field

Reference	
Description	Reference to type of heading or course given.
Base Type	MA_HeadingReferenceEnum
Message Structure	
Enumeration Literal	Description
TRUE_NORTH	Heading value according to Geographic North.
MAGNETIC_NORTH	Heading value according to location where the planet's magnetic field points vertically downward.

Table A-4-644: Peer Interface MA_FlightCommandMT - Reference UCI Extension Field

ControlPoint		
Description	Control Points for the desired discretized curve or spline path.	
Base Type	MA_CurveFollowingControlPointType	
Message Structure		
Field Name	Field Type	Field Usage
Position	PointChoice4D_Type	Required
Description	Physical location of the referenced item in geospatial coordinates. The use of the timestamp in this context represents the time the positional data was last measured. Position data may be specified as either a geospatial point or relative to a separately defined reference frame.	
PositionUncertainty	UncertaintyType	Optional
Description	Uncertainty of the physical location of the referenced item.	
DomainVelocity	Velocity3D_Type	Optional
Description	Vehicle's velocity in the current operating domain of the system. Air vehicle components are in True Air Speed.	
GroundVelocity	Velocity2D_Type	Optional
Description	Representation of the vehicle's ground velocity as directional speed components.	
RelativeVelocity	MA_VelocityChoiceType	Optional
Description	Represents the vehicle's velocity, in units of m/s, in the separately defined reference frame referenced in the sibling Position element. This element should only be used when the RelativePoint choice is selected and the seperately defined reference frame is itself moving.	
DomainAcceleration	Acceleration3D_Type	Optional
Description	The vehicle's acceleration in the current operating domain of the system.	
Orientation	OrientationType	Optional

Description	Euler Angle Sequence describing the orientation of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
OrientationRate	MA_OrientationRateChoiceType	Optional
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
RelativeAcceleration	MA_AccelerationChoiceType	Optional
Description		

Table A-4-645: Peer Interface MA_FlightCommandMT - ControlPoint UCI Extension Field

RelativeAcceleration		
Description		
Base Type	MA_AccelerationChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
BodyReferenceAcceleration	MA_BodyReferenceAccelerationType	Required
Description	Body reference accelerations.	
NED_Acceleration	Acceleration3D_Type	Required
Description	Inertial, NED coordinate frame accelerations.	

Table A-4-646: Peer Interface MA_FlightCommandMT - RelativeAcceleration UCI Extension Field

RelativeVelocity		
Description	Represents the vehicle's velocity, in units of m/s, in the separately defined reference frame referenced in the sibling Position element. This element should only be used when the RelativePoint choice is selected and the seperately defined reference frame is itself moving.	
Base Type	MA_VelocityChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
BodyReferenceVelocity	MA_BodyReferenceVelocityType	Required
Description	Velocity in body reference frame.	
NED_Velocity	Velocity3D_Type	Required
Description	Velocity in North East Down reference frame.	

Table A-4-647: Peer Interface MA_FlightCommandMT - RelativeVelocity UCI Extension Field

OrientationRate		
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
Base Type	MA_OrientationRateChoiceType	

Message Structure		
Field Name	Field Type	Field Usage
BodyReferenceOrientationRate	MA_BodyReferenceOrientationRateType	Required
Description	Orientation rate in body reference.	
NED_OrientationRate	OrientationRateType	Required
Description	Orientation rate in inertial reference.	

Table A-4-648: Peer Interface MA_FlightCommandMT - OrientationRate UCI Extension Field

Direction		
Description	Defines heading or course type and reference to hold	
Base Type	MA_DirectionChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
Heading	MA_DirectionReferenceType	Optional
Description	Defines heading type and reference to hold.	
Course	MA_DirectionReferenceType	Optional
Description	Defines course type and reference to hold.	

Table A-4-649: Peer Interface MA_FlightCommandMT - Direction UCI Extension Field

Course		
Description	Defines course type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-650: Peer Interface MA_FlightCommandMT - Course UCI Extension Field

4.2.41 MA_FlightCommandStatusMT UCI Extension

MA_FlightCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_FlightCommandStatusMDT CannotComplyDetails : MA_CannotComplyDetailsType Severity : MA_FaultSeverityEnum

Table A-4-651: Peer Interface MA_FlightCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_FlightCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CannotComplyDetails	MA_CannotComplyDetailsType	Optional
Description	Provides detail for why FA cannot comply with the flight command.	
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-652: Peer Interface MA_FlightCommandStatusMT - MessageData UCI Extension Field

CannotComplyDetails		
Description	Provides detail for why FA cannot comply with the flight command.	
Base Type	MA_CannotComplyDetailsType	
Message Structure		
Field Name	Field Type	Field Usage
ValidationResult	MA_ValidationResultEnum	Repeated
Description	In case of flight command rejection, provides the reason for Flight Autonomy rejection. Further details can be provided by Flight Autonomy through the ValidationResultReason. List size for this element is based on "Select All That Apply" condition.	
ValidationResultReason	MA_ValidationResultReasonType	Repeated
Description	In case of flight command rejection, provides additional context for Flight Autonomy rejection.	

Table A-4-653: Peer Interface MA_FlightCommandStatusMT - CannotComplyDetails UCI Extension Field

Severity	
Description	The severity of the fault. This enumeration is modified for Mission Autonomy adaptation.
Base Type	MA_FaultSeverityEnum
Message Structure	
Enumeration Literal	Description
NOMINAL	A fault that carries the nominal level indicates that fault does not impact the current mission but may indicate something that should be checked in maintenance. Faults should be tagged as nominal if they are targeting maintenance. An example might be air filter hasn't been changed in 5000 hours or queue length reached 60% of max.
ADVISORY	A fault that is important but is not a Caution or Warning; this can be a configuration change, a condition that is contributing to a degraded aircraft or subsystem operation, or an anomaly that is being automatically controlled or corrected by a higher level system.
CAUTION	A fault that is indicative of a condition that, without a timely and correct response, could result in equipment damage or failure of mission.
WARNING	A fault that is indicative of a condition requiring immediate response or attention to prevent loss of aircraft, or failure of mission.
FAILED	A fault that carries a failed level indicates the failure of a component which may preclude the use of a capability. Faults should be tagged with failed if the component state will be marked faulted. Failed components may or may not prevent the completion of the mission.

Table A-4-654: Peer Interface MA_FlightCommandStatusMT - Severity UCI Extension Field

4.2.42 MA_IgnoreConstraintCommandMT UCI Extension

MA_IgnoreConstraintCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_IgnoreConstraintCommandMDT

Table A-4-655: Peer Interface MA_IgnoreConstraintCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_IgnoreConstraintCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceType	RequirementsReferenceType	Required
Description	ID of the task(s) that the command applies to.	

ListOfConstraintsToIgnore	MA_RegionChoiceType	Repeated
Description	Indicates the constraint(s) being overridden.	
IgnoreAllConstraints	boolean	Optional
Description	If True, ignores all constraints.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. If an ACP is a member of a package, the ACPs SystemID does not need to be in this field as well.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-656: Peer Interface MA_IgnoreConstraintCommandMT - MessageData UCI Extension Field

4.2.43 MA_IgnoreConstraintCommandStatusMT UCI Extension

MA_IgnoreConstraintCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_IgnoreConstraintCommandStatusMDT

Table A-4-657: Peer Interface MA_IgnoreConstraintCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_IgnoreConstraintCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond with ACCEPTED for the Package or individual ACPs as needed.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	

CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-658: Peer Interface MA_IgnoreConstraintCommandStatusMT - MessageData UCI Extension Field

4.2.44 MA_LeaderUpdateRequestMT UCI Extension

MA_LeaderUpdateRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_LeaderUpdateRequestMDT

Table A-4-659: Peer Interface MA_LeaderUpdateRequestMT UCI Extension

MessageData		
Description	The message data relating to LeaderUpdateRequest message specifically.	
Base Type	MA_LeaderUpdateRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
Status	MA_NominationEnum	Required
Description	The related status of this message, whether it is a nomination or an assignment.	
Request	MA_LeaderUpdateRequestSetType	Required
Description	Indicates the details of the request.	
StaticLeadershipFitnessScore	MA_PartnerLeadershipFitnessScoreType	Repeated
Description	Indicates the static leadership fitness score for the partners in the package, which can be shared to trigger a change in leader from another System.	
DynamicLeadershipFitnessScore	MA_PartnerLeadershipFitnessScoreType	Optional
Description	Indicates the dynamic leadership fitness score and determination type for a partner in the package.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-660: Peer Interface MA_LeaderUpdateRequestMT - MessageData UCI Extension Field

4.2.45 MA_LeaderUpdateRequestStatusMT UCI Extension

MA_LeaderUpdateRequestStatusMT

Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_LeaderUpdateRequestStatusMDT

Table A-4-661: Peer Interface MA_LeaderUpdateRequestStatusMT UCI Extension

MessageData		
Description	The message data relating to LeaderUpdateRequestStatus specifically.	
Base Type	MA_LeaderUpdateRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApplicableIDs	MA_LeaderUpdateRequestSetType	Required
Description	The unique IDs of the systems, packages or tasks applicable to the original request message. The status of the message can be found at the RequestProcessingState enum.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-662: Peer Interface MA_LeaderUpdateRequestStatusMT - MessageData UCI Extension Field

4.2.46 MA_AcceptableLevelOfRiskCommandMT UCI Extension

MA_AcceptableLevelOfRiskCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_AcceptableLevelOfRiskCommandMDT

Table A-4-663: Peer Interface MA_AcceptableLevelOfRiskCommandMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_AcceptableLevelOfRiskCommandMDT

Message Structure		
Field Name	Field Type	Field Usage
AcceptableRiskSetting	MA_AcceptableLevelOfRiskEnum	Required
Description	This is the acceptable level of risk permitted at the package or vehicle level, which applies to all tasks and actions for the vehicle/package while active.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	Identifies the Package ID or ACP System ID for which the acceptable risk parameter applies. If Package ID is used, this includes all package member System IDs, so a member ACP's System ID does not need to be separately included. This value overrides the AppliesToSystemID in the SurvivabilityRiskLevelMDT message.	
SurvivabilityRiskLevelID	SurvivabilityRiskLevelID_Type	Required
Description	The unique identifier for the Survivability Risk Level that should be active as the default setting.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-664: Peer Interface MA_AcceptableLevelOfRiskCommandMT - MessageData UCI Extension Field

4.2.47 MA_AcceptableLevelOfRiskCommandStatusMT UCI Extension

MA_AcceptableLevelOfRiskCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_AcceptableLevelOfRiskCommandStatusMDT

Table A-4-665: Peer Interface MA_AcceptableLevelOfRiskCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_AcceptableLevelOfRiskCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
AppliesToIDs	MA_PackageSystemType	Repeated
Description	The IDs, Package or ACP, that this message applies to. A lead is able to respond with ACCEPTED for the Package or individual ACPs as needed.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	

CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-666: Peer Interface MA_AcceptableLevelOfRiskCommandStatusMT - MessageData UCI Extension Field

4.2.48 MA_MissionPlanActivationCommandMT UCI Extension

MA_MissionPlanActivationCommandMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	OpPlanID : MA_OpPlanID_Type ApplicableToIDs : MA_PackageSystemType ByExecutionPlanSet : MA_ExecutionPlanSetActivationType MessageData : MA_MissionPlanActivationCommandMDT ActivationDetails : MA_MissionPlanActivationDetailsType Applicability : MA_PlanApplicabilityType OpPlan : MA_OpPlanActivationType Command : MA_MissionPlanActivationCommandType

Table A-4-667: Peer Interface MA_MissionPlanActivationCommandMT UCI Extension

OpPlanID		
Description	Indicates the unique ID of the TaskPlan to perform the sibling activation command on.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal	

	digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-668: Peer Interface MA_MissionPlanActivationCommandMT - OpPlanID UCI Extension Field

ApplicableToIDs		
Description	Indicates the unique ID of the System (e.g. aircraft, ground-based sensor, ship, satellite, site, etc.) or Package whose Capabilities, performance, position, etc. the plan is based on. If the plan is a fully detailed one that can be activated and executed, this element indicates the System intended/responsible for executing the plan and producing the intended effects. See annotations in sibling element PlannedForID which provide additional context.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-669: Peer Interface MA_MissionPlanActivationCommandMT - ApplicableToIDs UCI Extension Field

ByExecutionPlanSet		
Description	Indicates simultaneous activation of all sub-*Plans (ActivityPlan, RoutePlan for example) of an *ExecutionPlanSet into the same activation state.	
Base Type	MA_ExecutionPlanSetActivationType	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPlanSetID	ExecutionPlanSetID_Type	Required
Description	Indicates the unique ID of the execution plan set.	
CommandType	PlanActivationCommandEnum	Required
Description	Indicates the activation to perform on the associated execution plan set.	

Table A-4-670: Peer Interface MA_MissionPlanActivationCommandMT - ByExecutionPlanSet UCI Extension Field

MessageData	
Description	Indicates the data being conveyed by the message.
Base Type	MA_MissionPlanActivationCommandMDT

Message Structure		
Field Name	Field Type	Field Usage
CommandID	MissionPlanActivationCommandID_Type	Required
Description	The ID of the Mission Plan Activation Command. Used to reference the command when providing status.	
ApprovalManagementCommandID	CommandID_Type	Repeated
Description	Indicates the command(s) that initiated the Activation Approvals for the *Plans identified in the sibling Command element. The approval status can be found by locating the corresponding MissionPlanActivationApprovalStatus with the ID identified here. The ActivationCommand identified in the sibling Command\ActivationDetails should be verified against the ActivationType that is identified in the associated MissionPlanActivationApprovalCommand.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	
Command	MA_MissionPlanActivationCommandType	Repeated
Description	Indicates command or commands to change the activation state of a MissionPlan and/or its subplans or subordinate plans. If more than one instance of this element is given, each should correspond to a different MissionPlanID. For example, if the intent is to transition from one MissionPlan to another, the new MissionPlan can be activated in one instance and the old MissionPlan can be deactivated in another instance.	
Applicability	MA_PlanApplicabilityType	Optional
Description	Indicates the System or Systems who are being commanded to activate a specified plan.	

Table A-4-671: Peer Interface MA_MissionPlanActivationCommandMT - MessageData UCI Extension Field

ActivationDetails		
Description	Indicates the commanded activation details.	
Base Type	MA_MissionPlanActivationDetailsType	
Message Structure		
Field Name	Field Type	Field Usage
ByMissionPlan	MissionPlanActivationType	Required
Description	Indicates simultaneous activation of all sub-*Plans (RoutePlan, RouteActivityPlan for example) of a MissionPlan into the same activation state.	
BySubPlan	MA_MissionPlanSubplanActivationType	Required
Description	Indicates activation by sub-*Plan (RoutePlan or OrbitPlan for example) of the MissionPlan, with potentially different states for each.	
ByExecutionPlanSet	MA_ExecutionPlanSetActivationType	Required

Description	Indicates simultaneous activation of all sub-*Plans (ActivityPlan, RoutePlan for example) of an *ExecutionPlanSet into the same activation state.
-------------	---

Table A-4-672: Peer Interface MA_MissionPlanActivationCommandMT - ActivationDetails UCI Extension Field

Applicability		
Description	Indicates the System or Systems who are being commanded to activate a specified plan.	
Base Type	MA_PlanApplicabilityType	
Message Structure		
Field Name	Field Type	Field Usage
PlannedForID	SystemID_Type	Optional
Description	Indicates the System which is the intended user of the plan. This type can have multiple meanings, but primarily enables multiple systems, possibly at different levels of warfare or C2 hierarchy levels, to maintain independent plans for the same System identified in the sibling ApplicableToID element. For instance, during planning at the operational level of warfare, a non-tactical planning service may create and simulate execution of plans internally. Such plans would identify the operational level System as the PlannedFor System; they would never be activated or executed by a real world tactical System. Alternatively, the operational level System could have a tactical planning service that is functionally capable and responsible for creating fully detailed plans that can be activated and executed by real world tactical Systems. Such a tactical planning service could be used even if the operational level System does not have control authority over the tactical System at the time the plan is created. Such plans would identify the tactical level System as the PlannedFor System. As a final example, a plan which is intended to be used by the same System which produces its intended effects would have a common SystemID between the sibling PlannedForID and ApplicableToID elements. This element does not replace existing approval policies, authorization or control status and therefore does not automatically imply that the PlannedFor System has any kind of authority over the receiving system.	
ApplicableToIDs	MA_PackageSystemType	Required
Description	Indicates the unique ID of the System (e.g. aircraft, ground-based sensor, ship, satellite, site, etc.) or Package whose Capabilities, performance, position, etc. the plan is based on. If the plan is a fully detailed one that can be activated and executed, this element indicates the System intended/responsible for executing the plan and producing the intended effects. See annotations in sibling element PlannedForID which provide additional context.	

Table A-4-673: Peer Interface MA_MissionPlanActivationCommandMT - Applicability UCI Extension Field

OpPlan

Description	Indicates commanded details for activation of an OpPlan.	
Base Type	MA_OpPlanActivationType	
Message Structure		
Field Name	Field Type	Field Usage
OpPlanID	MA_OpPlanID_Type	Required
Description	Indicates the unique ID of the TaskPlan to perform the sibling activation command on.	
CommandType	PlanActivationCommandEnum	Required
Description	Indicates the activation to perform on the associated TaskPlan.	

Table A-4-674: Peer Interface MA_MissionPlanActivationCommandMT - OpPlan UCI Extension Field

Command		
Description	Indicates command or commands to change the activation state of a MissionPlan and/or it subplans or subordinate plans. If more than one instance of this element is given, each should correspond to a different MissionPlanID. For example, if the intent is to transition from one MissionPlan to another, the new MissionPlan can be activated in one instance and the old MissionPlan can be deactivated in another instance.	
Base Type	MA_MissionPlanActivationCommandType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	Indicates the unique ID of the MissionPlan whose commanded activation state or states are summarized in the sibling element.	
ActivationDetails	MA_MissionPlanActivationDetailsType	Required
Description	Indicates the commanded activation details.	

Table A-4-675: Peer Interface MA_MissionPlanActivationCommandMT - Command UCI Extension Field

4.2.49 MA_OpZoneMT UCI Extension

MA_OpZoneMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_OpZoneMDT Category : MA_OpZoneCategoryEnum CategoryUniqueData : MA_OpZoneCategoryType SpeedLimits : MA_OpZoneSpeedLimitsType VehicleConfiguration : MA_VehicleCommandDataType Zone : MA_OpZoneChoiceType

GeometryReference : MA_ReferentialOpZoneType
 ReferenceObjectsFilter : MA_GeoLocatedObjectFilterType
 OpPointFilter : MA_OpPointFilterType
 OpLineFilter : MA_OpLineFilterType
 OpLineCategory : MA_OpLineCategoryEnum
 OpZoneFilter : MA_OpZoneFilterType
 OpZoneCategory : MA_OpZoneCategoryEnum
 OpVolumeFilter : MA_OpVolumeFilterType
 OpVolumeCategory : MA_OpZoneCategoryEnum
 DMPI_Filter : MA_DMPI_FilterType
 SignalReportFilter : MA_SignalReportFilterType
 OpVolumeFilter : MA_OpVolumeFilterType
 OpLineFilter : MA_OpLineFilterType
 OpLineCategory : MA_OpLineCategoryEnum
 SpeedLimits : MA_OpZoneSpeedLimitsType
 SignalReportFilter : MA_SignalReportFilterType
 OpPointFilter : MA_OpPointFilterType
 VehicleConfiguration : MA_VehicleCommandDataType
 DMPI_Filter : MA_DMPI_FilterType
 Zone : MA_OpZoneChoiceType
 Category : MA_OpZoneCategoryEnum
 CategoryUniqueData : MA_OpZoneCategoryType
 ReferenceObjectsFilter : MA_GeoLocatedObjectFilterType
 OpVolumeCategory : MA_OpZoneCategoryEnum
 GeometryReference : MA_ReferentialOpZoneType
 OpZoneCategory : MA_OpZoneCategoryEnum
 OpZoneFilter : MA_OpZoneFilterType

Table A-4-676: Peer Interface MA_OpZoneMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpZoneMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpZoneID	OpZoneID_Type	Required
Description	This element represents the unique identifier of the zone associated with this message.	

Category	MA_OpZoneCategoryEnum	Required
Description	This element indicates the type of zone.	
CategoryUniqueData	MA_OpZoneCategoryType	Optional
Description	Contains parameters unique to certain OpZoneCategoryEnum values.	
Zone	MA_OpZoneChoiceType	Required
Description	This element represents the geospatial and temporal characteristics of the OpZone.	
SituationalAwareness	boolean	Required
Description	Zone used only for situational awareness. Not used for planning purposes.	
OpDescription	OpDescriptionType	Optional
Description	A human-readable descriptive name with free text remarks.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this operational item to specify what the source or motivation for it originated from. This could be ATO, ACO, etc.	
Source	CreationSourceEnum	Optional
Description	Indicates the source of the information.	
Schedule	ScheduleType	Optional
Description	This element represents a date/time interval associated with the operational item during which the item is in effect.	
AssociatedTime	TimeFunctionType	Repeated
Description	Indicates time related events that are associated to the Op data type such as when activated or when operational. The multiplicity is limited to N-1 options where NONE is an event that has no value, thus removed from list of available options.	
DataLinkIdentifier	DataLinkIdentifierPET	Repeated
Description	List of data link ID. Multiple data link IDs can be reported for the same network type.	
Priority	unsignedInt	Optional
Description	This field represents the priority to be considered when choosing between multiple available points.	
QualifyingTags	QualifyingTagsType	Optional
Description	Provides identity qualifications to augment identification and associated processing of the OpPoint.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
SystemScheduleOverride	SystemScheduleStateType	Repeated
Description	System-specific schedule that will override any part of the main schedule. This allows for system-specific schedule different than main schedule. When adding a SystemScheduleOverride, the child SystemID also must be added to the sibling SystemID list if the sibling list is not empty. The SystemScheduleOverride is independent of time planning. For the system, this override can be done at execution.	

Table A-4-677: Peer Interface MA_OpZoneMT - MessageData UCI Extension Field

Category

Description	This element indicates the type of zone.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the

	IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are

	defined in the OpZoneWeatherType choice in OpZoneCategoryType.
--	--

Table A-4-678: Peer Interface MA_OpZoneMT - Category UCI Extension Field

CategoryUniqueData		
Description	Contains parameters unique to certain OpZoneCategoryEnum values.	
Base Type	MA_OpZoneCategoryType	
Message Structure		
Field Name	Field Type	Field Usage
ConstrainedEntryExit	ConstrainedEntryExitType	Required
Description	Defines boundaries which applicable Systems can only enter and exit through defined edges.	
FilterArea	OpZoneFilterAreaPET	Repeated
Description	Indicates that the OpZone can be a zone filter type.	
Jamming	OpZoneJammingType	Required
Description	Indicates that the OpZone is a jamming control zone.	
KeepIn	IngressEgressType	Required
Description	Defines boundaries to which applicable Systems must stay inside.	
MissileLaunchPoint	OpZoneMissileDataType	Required
Description	Data defining a missile type, related track, and source of launch position.	
NoFire	OpZoneNoFireType	Required
Description	Defines areas where strike impact is restricted. Does not restrict the launch of weapons.	
NoFly	OpZoneNoFlyType	Required
Description	Defines area where flight is restricted. Equivalent to MIL-STD-6016 restricted zone.	
SpeedLimits	MA_OpZoneSpeedLimitsType	Required
Description	Defines area where speeds are restricted.	
VehicleConfiguration	MA_VehicleCommandDataType	Required
Description	Defines vehicle configuration parameters that should change based on the planned location of a vehicle.	
WeaponRestriction	OpZoneWeaponRestrictionType	Required
Description	Set of restricted weapons that cannot be used against a target type and or in a zone.	
WeatherConditions	OpZoneWeatherType	Required
Description	Defines area of weather conditions with potential of mission impact.	

Table A-4-679: Peer Interface MA_OpZoneMT - CategoryUniqueData UCI Extension Field

SpeedLimits	
Description	Defines area where speeds are restricted.
Base Type	MA_OpZoneSpeedLimitsType

Message Structure		
Field Name	Field Type	Field Usage
MinSpeedLimit	PathSegmentSpeedValueType	Optional
Description	Indicates the minimum speed limit in meters per second within a zone/region.	
MaxSpeedLimit	PathSegmentSpeedValueType	Optional
Description	Indicates the maximum speed limit in meters per second within a zone/region.	

Table A-4-680: Peer Interface MA_OpZoneMT - SpeedLimits UCI Extension Field

VehicleConfiguration		
Description	Defines vehicle configuration parameters that should change based on the planned location of a vehicle.	
Base Type	MA_VehicleCommandDataType	
Message Structure		
Field Name	Field Type	Field Usage
VehicleAction	VehicleActionEnum	Optional
Description	Defines vehicle actions that can be done along a path segment of a route.	
IFF_Settings	IFF_Type	Optional
Description	If present the IFF settings for this vehicle will be changed along this path segment.	
SurvivabilityMode	VehicleSurvivabilityModeEnum	Optional
Description	Specifies that the vehicle should put itself into a more survivable mode. Different vehicles will have specific behaviors that reduce the signature of the vehicle (doors closed, minimal use of flaps, etc.) If this element is not present then it is assumed that the aircraft being configured has no survivability mode.	
LostCommTimeout	DurationType	Optional
Description	Defines the lost communication contingency timeout. When this timeout value is exceeded, the AV considers that lost communication has occurred and begins to perform contingency measures.	
LOS	boolean	Optional
Description	Use Line Of Sight (LOS) communication as backup contingency.	
LossOfLinkProcessing	VehicleLossOfLinkProcessingEnum	Optional
Description	Specifies whether the vehicle should invoke special Loss of Link processing. This could be turned off if the vehicle is going to be in a known and accepted lost communication situation.	
CommAllocationAction	CommAllocationActionType	Optional
Description	Indicates a change of communication allocation.	
QNH_Setting	PressureType	Optional
Description	Represents the barometric altimeter setting for correct MSL reading, commonly known as QNH, requested. Expressed in kilopascals (kPa).	

Table A-4-681: Peer Interface MA_OpZoneMT - VehicleConfiguration UCI Extension Field

Zone

Description	This element represents the geospatial and temporal characteristics of the OpZone.	
Base Type	MA_OpZoneChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
GeometrySpecification	OpZoneType	Required
Description	Defines an OpZone geometry	
GeometryReference	MA_ReferentialOpZoneType	Required
Description	Defines an OpZone geometry via reference to other filtered objects	

Table A-4-682: Peer Interface MA_OpZoneMT - Zone UCI Extension Field

GeometryReference		
Description	Defines an OpZone geometry via reference to other filtered objects	
Base Type	MA_ReferentialOpZoneType	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceObjectsFilter	MA_GeoLocatedObjectFilterType	Repeated
Description	The geometry of all objects returned by this filter will be used for the OpZone being defined.	
HorizontalBuffer	DistanceType	Required
Description	The area of the resulting OpZone is the area of the referenced object, expanded by this horizontal buffer along the plane orthogonal to the NED frame's down direction	
MinAltitudeBuffer	DistanceType	Required
Description	The min altitude of the resulting OpZone is the min altitude of the referenced object, decreased by this min altitude buffer	
MaxAltitudeBuffer	DistanceType	Required
Description	The max altitude of the resulting OpZone is the max altitude of the referenced object, increased by this max altitude buffer	

Table A-4-683: Peer Interface MA_OpZoneMT - GeometryReference UCI Extension Field

ReferenceObjectsFilter		
Description	The geometry of all objects returned by this filter will be used for the OpZone being defined.	
Base Type	MA_GeoLocatedObjectFilterType	
Message Structure		
Field Name	Field Type	Field Usage
EntityFilter	EntityFilterType	Optional
Description	Indicates a name/type of Entity required to match the filter. If omitted, any name/type of Entity satisfies the filter.	

SystemFilter	SystemFilterType	Optional
Description	Indicates a name/type of System required to match the filter. If omitted, any name/type of System satisfies the filter.	
OpPointFilter	MA_OpPointFilterType	Optional
Description	Indicates a name/type of OpPoint required to match the filter. If omitted, any name/type of OpPoint satisfies the filter.	
OpLineFilter	MA_OpLineFilterType	Optional
Description	Indicates a name/type of OpLine required to match the filter. If omitted, any name/type of OpLine satisfies the filter.	
OpZoneFilter	MA_OpZoneFilterType	Optional
Description	Indicates a name/type of OpZone required to match the filter. If omitted, any name/type of OpZone satisfies the filter.	
OpVolumeFilter	MA_OpVolumeFilterType	Optional
Description	Indicates a name/type of OpVolume required to match the filter. If omitted, any name/type of OpVolume satisfies the filter.	
DMPI_Filter	MA_DMPI_FilterType	Optional
Description	Indicates a name/type of DMPI required to match the filter. If omitted, any name/type of DMPI satisfies the filter.	
SignalReportFilter	MA_SignalReportFilterType	Optional
Description	Indicates a name/type of SignalReport required to match the filter. If omitted, any name/type of SignalReport satisfies the filter.	

Table A-4-684: Peer Interface MA_OpZoneMT - ReferenceObjectsFilter UCI Extension Field

OpPointFilter		
Description	Indicates a name/type of OpPoint required to match the filter. If omitted, any name/type of OpPoint satisfies the filter.	
Base Type	MA_OpPointFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointID	OpPointID_Type	Repeated
Description	Indicates a specific OpPointID that is required to match the filter. If omitted, any OpPointID satisfies the filter. Multiple instances are logically ORed.	
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint category that is required to match the filter. If omitted, any OpPoint category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpPoint must fall within to satisfy the filter. Multiple instances are logically ORed.Indicates that the OpRouting type is applicable. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-685: Peer Interface MA_OpZoneMT - OpPointFilter UCI Extension Field

OpLineFilter		
Description	Indicates a name/type of OpLine required to match the filter. If omitted, any name/type of OpLine satisfies the filter.	
Base Type	MA_OpLineFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpLineID	OpLineID_Type	Repeated
Description	Indicates a specific OpLineID that is required to match the filter. If omitted, any OpLineID satisfies the filter. Multiple instances are logically ORed.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine category that is required to match the filter. If omitted, any OpLine category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpLine must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-686: Peer Interface MA_OpZoneMT - OpLineFilter UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine category that is required to match the filter. If omitted, any OpLine category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure

	coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-687: Peer Interface MA_OpZoneMT - OpLineCategory UCI Extension Field

OpZoneFilter		
Description	Indicates a name/type of OpZone required to match the filter. If omitted, any name/type of OpZone satisfies the filter.	
Base Type	MA_OpZoneFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpZoneID	OpZoneID_Type	Repeated
Description	Indicates a specific OpZoneID that is required to match the filter. If omitted, any OpZoneID satisfies the filter. Multiple instances are logically ORed.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone category that is required to match the filter. If omitted, any OpZone category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpZone must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-688: Peer Interface MA_OpZoneMT - OpZoneFilter UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone category that is required to match the filter. If omitted, any OpZone category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum

Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.

MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-689: Peer Interface MA_OpZoneMT - OpZoneCategory UCI Extension Field

OpVolumeFilter

Description	Indicates a name/type of OpVolume required to match the filter. If omitted, any name/type of OpVolume satisfies the filter.	
Base Type	MA_OpVolumeFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpVolumeID	OpVolumeID_Type	Repeated
Description	Indicates a specific OpVolumeID that is required to match the filter. If omitted, any OpVolumeID satisfies the filter. Multiple instances are logically ORed.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume category that is required to match the filter. If omitted, any OpVolume category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpVolume must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-690: Peer Interface MA_OpZoneMT - OpVolumeFilter UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume category that is required to match the filter. If omitted, any OpVolume category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined

	dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.

REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-691: Peer Interface MA_OpZoneMT - OpVolumeCategory UCI Extension Field

DMPI_Filter		
Description	Indicates a name/type of DMPI required to match the filter. If omitted, any name/type of DMPI satisfies the filter.	
Base Type	MA_DMPI_FilterType	
Message Structure		
Field Name	Field Type	Field Usage
DMPI_ID	DMPI_ID_Type	Repeated
Description	Indicates a specific DMPI_ID that is required to match the filter. If omitted, any DMPI_ID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the DMPI must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-692: Peer Interface MA_OpZoneMT - DMPI_Filter UCI Extension Field

SignalReportFilter	
Description	Indicates a name/type of SignalReport required to match the filter. If omitted, any name/type of SignalReport satisfies the filter.
Base Type	MA_SignalReportFilterType

Message Structure		
Field Name	Field Type	Field Usage
SignalReportID	SignalReportID_Type	Repeated
Description	Indicates a specific SignalReportID that is required to match the filter. If omitted, any SignalReportID satisfies the filter. Multiple instances are logically ORed.	
SystemID	SystemID_Type	Repeated
Description	Indicates a specific source SystemID that is required to match the filter. If omitted, any source SystemID satisfies the filter. Multiple instances are logically ORed.	
SubsystemID	SubsystemID_Type	Repeated
Description	Indicates a specific source SubsystemID that is required to match the filter. If omitted, any source SubsystemID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the SignalReport must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-693: Peer Interface MA_OpZoneMT - SignalReportFilter UCI Extension Field

OpVolumeFilter		
Description	Indicates a name/type of OpVolume required to match the filter. If omitted, any name/type of OpVolume satisfies the filter.	
Base Type	MA_OpVolumeFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpVolumeID	OpVolumeID_Type	Repeated
Description	Indicates a specific OpVolumeID that is required to match the filter. If omitted, any OpVolumeID satisfies the filter. Multiple instances are logically ORed.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume category that is required to match the filter. If omitted, any OpVolume category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpVolume must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-694: Peer Interface MA_OpZoneMT - OpVolumeFilter UCI Extension Field

OpLineFilter		
Description	Indicates a name/type of OpLine required to match the filter. If omitted, any name/type of OpLine satisfies the filter.	
Base Type	MA_OpLineFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpLineID	OpLineID_Type	Repeated

Description	Indicates a specific OpLineID that is required to match the filter. If omitted, any OpLineID satisfies the filter. Multiple instances are logically ORed.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine category that is required to match the filter. If omitted, any OpLine category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpLine must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-695: Peer Interface MA_OpZoneMT - OpLineFilter UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine category that is required to match the filter. If omitted, any OpLine category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.

DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-696: Peer Interface MA_OpZoneMT - OpLineCategory UCI Extension Field

SpeedLimits		
Description	Defines area where speeds are restricted.	
Base Type	MA_OpZoneSpeedLimitsType	
Message Structure		
Field Name	Field Type	Field Usage
MinSpeedLimit	PathSegmentSpeedValueType	Optional
Description	Indicates the minimum speed limit in meters per second within a zone/region.	
MaxSpeedLimit	PathSegmentSpeedValueType	Optional
Description	Indicates the maximum speed limit in meters per second within a zone/region.	

Table A-4-697: Peer Interface MA_OpZoneMT - SpeedLimits UCI Extension Field

SignalReportFilter		
Description	Indicates a name/type of SignalReport required to match the filter. If omitted, any name/type of SignalReport satisfies the filter.	
Base Type	MA_SignalReportFilterType	
Message Structure		
Field Name	Field Type	Field Usage
SignalReportID	SignalReportID_Type	Repeated
Description	Indicates a specific SignalReportID that is required to match the filter. If omitted, any SignalReportID satisfies the filter. Multiple instances are logically ORed.	
SystemID	SystemID_Type	Repeated
Description	Indicates a specific source SystemID that is required to match the filter. If omitted, any source SystemID satisfies the filter. Multiple instances are logically ORed.	
SubsystemID	SubsystemID_Type	Repeated
Description	Indicates a specific source SubsystemID that is required to match the filter. If omitted, any source SubsystemID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the SignalReport must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-698: Peer Interface MA_OpZoneMT - SignalReportFilter UCI Extension Field

OpPointFilter		
Description	Indicates a name/type of OpPoint required to match the filter. If omitted, any name/type of OpPoint satisfies the filter.	
Base Type	MA_OpPointFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointID	OpPointID_Type	Repeated
Description	Indicates a specific OpPointID that is required to match the filter. If omitted, any OpPointID satisfies the filter. Multiple instances are logically ORed.	
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint category that is required to match the filter. If omitted, any OpPoint category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpPoint must fall within to satisfy the filter. Multiple instances are logically ORed.Indicates that the OpRouting type is applicable. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-699: Peer Interface MA_OpZoneMT - OpPointFilter UCI Extension Field

VehicleConfiguration		
Description	Defines vehicle configuration parameters that should change based on the planned location of a vehicle.	
Base Type	MA_VehicleCommandDataType	
Message Structure		
Field Name	Field Type	Field Usage
VehicleAction	VehicleActionEnum	Optional
Description	Defines vehicle actions that can be done along a path segment of a route.	
IFF_Settings	IFF_Type	Optional
Description	If present the IFF settings for this vehicle will be changed along this path segment.	
SurvivabilityMode	VehicleSurvivabilityModeEnum	Optional
Description	Specifies that the vehicle should put itself into a more survivable mode. Different vehicles will have specific behaviors that reduce the signature of the vehicle (doors closed, minimal use of flaps, etc.) If this element is not present then it is assumed that the aircraft being configured has no survivability mode.	
LostCommTimeout	DurationType	Optional
Description	Defines the lost communication contingency timeout. When this timeout value is exceeded, the AV considers that lost communication has occurred and begins to perform contingency measures.	
LOS	boolean	Optional
Description	Use Line Of Sight (LOS) communication as backup contingency.	

LossOfLinkProcessing	VehicleLossOfLinkProcessingEnum	Optional
Description	Specifies whether the vehicle should invoke special Loss of Link processing. This could be turned off if the vehicle is going to be in a known and accepted lost communication situation.	
CommAllocationAction	CommAllocationActionType	Optional
Description	Indicates a change of communication allocation.	
QNH_Setting	PressureType	Optional
Description	Represents the barometric altimeter setting for correct MSL reading, commonly known as QNH, requested. Expressed in kilopascals (kPa).	

Table A-4-700: Peer Interface MA_OpZoneMT - VehicleConfiguration UCI Extension Field

DMPI_Filter		
Description	Indicates a name/type of DMPI required to match the filter. If omitted, any name/type of DMPI satisfies the filter.	
Base Type	MA_DMPI_FilterType	
Message Structure		
Field Name	Field Type	Field Usage
DMPI_ID	DMPI_ID_Type	Repeated
Description	Indicates a specific DMPI_ID that is required to match the filter. If omitted, any DMPI_ID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the DMPI must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-701: Peer Interface MA_OpZoneMT - DMPI_Filter UCI Extension Field

Zone		
Description	This element represents the geospatial and temporal characteristics of the OpZone.	
Base Type	MA_OpZoneChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
GeometrySpecification	OpZoneType	Required
Description	Defines an OpZone geometry	
GeometryReference	MA_ReferentialOpZoneType	Required
Description	Defines an OpZone geometry via reference to other filtered objects	

Table A-4-702: Peer Interface MA_OpZoneMT - Zone UCI Extension Field

Category		
Description	This element indicates the type of zone.	
Base Type	MA_OpZoneCategoryEnum	

Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.

MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-703: Peer Interface MA_OpZoneMT - Category UCI Extension Field

CategoryUniqueData

Description	Contains parameters unique to certain OpZoneCategoryEnum values.	
Base Type	MA_OpZoneCategoryType	
Message Structure		
Field Name	Field Type	Field Usage
ConstrainedEntryExit	ConstrainedEntryExitType	Required
Description	Defines boundaries which applicable Systems can only enter and exit through defined edges.	
FilterArea	OpZoneFilterAreaPET	Repeated
Description	Indicates that the OpZone can be a zone filter type.	
Jamming	OpZoneJammingType	Required
Description	Indicates that the OpZone is a jamming control zone.	
KeepIn	IngressEgressType	Required
Description	Defines boundaries to which applicable Systems must stay inside.	
MissileLaunchPoint	OpZoneMissileDataType	Required
Description	Data defining a missile type, related track, and source of launch position.	
NoFire	OpZoneNoFireType	Required
Description	Defines areas where strike impact is restricted. Does not restrict the launch of weapons.	
NoFly	OpZoneNoFlyType	Required
Description	Defines area where flight is restricted. Equivalent to MIL-STD-6016 restricted zone.	
SpeedLimits	MA_OpZoneSpeedLimitsType	Required
Description	Defines area where speeds are restricted.	
VehicleConfiguration	MA_VehicleCommandDataType	Required
Description	Defines vehicle configuration parameters that should change based on the planned location of a vehicle.	
WeaponRestriction	OpZoneWeaponRestrictionType	Required
Description	Set of restricted weapons that cannot be used against a target type and or in a zone.	
WeatherConditions	OpZoneWeatherType	Required
Description	Defines area of weather conditions with potential of mission impact.	

Table A-4-704: Peer Interface MA_OpZoneMT - CategoryUniqueData UCI Extension Field

ReferenceObjectsFilter		
Description	The geometry of all objects returned by this filter will be used for the OpZone being defined.	
Base Type	MA_GeoLocatedObjectFilterType	
Message Structure		
Field Name	Field Type	Field Usage
EntityFilter	EntityFilterType	Optional

	Description	Indicates a name/type of Entity required to match the filter. If omitted, any name/type of Entity satisfies the filter.
SystemFilter	SystemFilterType	Optional
	Description	Indicates a name/type of System required to match the filter. If omitted, any name/type of System satisfies the filter.
OpPointFilter	MA_OpPointFilterType	Optional
	Description	Indicates a name/type of OpPoint required to match the filter. If omitted, any name/type of OpPoint satisfies the filter.
OpLineFilter	MA_OpLineFilterType	Optional
	Description	Indicates a name/type of OpLine required to match the filter. If omitted, any name/type of OpLine satisfies the filter.
OpZoneFilter	MA_OpZoneFilterType	Optional
	Description	Indicates a name/type of OpZone required to match the filter. If omitted, any name/type of OpZone satisfies the filter.
OpVolumeFilter	MA_OpVolumeFilterType	Optional
	Description	Indicates a name/type of OpVolume required to match the filter. If omitted, any name/type of OpVolume satisfies the filter.
DMPI_Filter	MA_DMPI_FilterType	Optional
	Description	Indicates a name/type of DMPI required to match the filter. If omitted, any name/type of DMPI satisfies the filter.
SignalReportFilter	MA_SignalReportFilterType	Optional
	Description	Indicates a name/type of SignalReport required to match the filter. If omitted, any name/type of SignalReport satisfies the filter.

Table A-4-705: Peer Interface MA_OpZoneMT - ReferenceObjectsFilter UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume category that is required to match the filter. If omitted, any OpVolume category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.

DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.

NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-706: Peer Interface MA_OpZoneMT - OpVolumeCategory UCI Extension Field

GeometryReference		
Description	Defines an OpZone geometry via reference to other filtered objects	
Base Type	MA_ReferentialOpZoneType	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceObjectsFilter	MA_GeoLocatedObjectFilterType	Repeated
Description	The geometry of all objects returned by this filter will be used for the OpZone being defined.	
HorizontalBuffer	DistanceType	Required
Description	The area of the resulting OpZone is the area of the referenced object, expanded by this horizontal buffer along the plane orthogonal to the NED frame's down direction	

MinAltitudeBuffer	DistanceType	Required
Description	The min altitude of the resulting OpZone is the min altitude of the referenced object, decreased by this min altitude buffer	
MaxAltitudeBuffer	DistanceType	Required
Description	The max altitude of the resulting OpZone is the max altitude of the referenced object, increased by this max altitude buffer	

Table A-4-707: Peer Interface MA_OpZoneMT - GeometryReference UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone category that is required to match the filter. If omitted, any OpZone category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate

	ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted

	without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-708: Peer Interface MA_OpZoneMT - OpZoneCategory UCI Extension Field

OpZoneFilter		
Description	Indicates a name/type of OpZone required to match the filter. If omitted, any name/type of OpZone satisfies the filter.	
Base Type	MA_OpZoneFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpZoneID	OpZoneID_Type	Repeated
Description	Indicates a specific OpZoneID that is required to match the filter. If omitted, any OpZoneID satisfies the filter. Multiple instances are logically ORed.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone category that is required to match the filter. If omitted, any OpZone category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpZone must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-709: Peer Interface MA_OpZoneMT - OpZoneFilter UCI Extension Field

4.2.50 MA_PositionReportMT UCI Extension

MA_PositionReportMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_PositionReportMDT

Table A-4-710: Peer Interface MA_PositionReportMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type

	for details.	
Base Type	MA_PositionReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	The unique ID of the System corresponding to this PositionReport.	
DisplayName	VisibleString256Type	Optional
Description	This is the free-text, generally human-readable, name of the System or Resource corresponding to this PositionReport. This name isn't necessarily unique.	
Source	SystemSourceEnum	Required
Description	Indicates the source of the data in sibling elements. See enumeration annotations for further details.	
CurrentOperatingDomain	EnvironmentEnum	Required
Description	This enumerated element represents the domain/environment in which the system is currently operating.	
InertialState	MA_InertialStateType	Required
Description	This element represents the inertial state of the system or resource.	
WanderAngle	AngleType	Optional
Description	The angle by which the Inertial Navigation System (INS) rotates the geodetic frame about the vertical axis of the North-East-Down (NED) coordinate frame to avoid the introduction of a singularity at the North pole when it is calculating vehicle location. A rotation from true North towards East is reported as a positive angle.	
MagneticHeading	AngleType	Optional
Description	Indicates the heading in relationship to magnetic North.	

Table A-4-711: Peer Interface MA_PositionReportMT - MessageData UCI Extension Field

4.2.51 MA_PackageManagementCommandMT UCI Extension

MA_PackageManagementCommandMT	
Description	This message is used to command one or more entities to form, join or leave a Package. See the XSD File for more info
Ext. Fields	MessageData : MA_PackageManagementCommandMDT

Table A-4-712: Peer Interface MA_PackageManagementCommandMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_PackageManagementCommandMDT
Message Structure	

Field Name	Field Type	Field Usage
PackageID	PackageID_Type	Required
Description	Indicates the unique identifier of the Package to form, join or leave.	
ParentPackageID	PackageID_Type	Optional
Description	If the sibling PackageID element is a sub-package, indicates the unique identifier of the parent package.	
ChangeType	MA_PackageChangeEnum	Required
Description	Indicates the type of package change to perform.	
SystemID	SystemID_Type	Repeated
Description	Indicates the System(s) commanded to perform a package change.	
ConstraintID	MA_ConstraintID_Type	Repeated
Description	Indicates any Constraints that may apply to this package (e.g FormationConstraint).	
PackageLeaderID	SystemID_Type	Optional
Description	Indicates the System commanded to assume package leader role. Allows for the explicit specification of a leader without needing MA to conduct leader election.	
PackagePartnerMetrics	MA_PartnerMetricsType	Repeated
Description	Indicates the leadership fitness metrics for the partners in the package.	
PackageLeaderElectionMethod	Integer	Required
Description	Specifies which election method/algorithm the package will utilize for electing a Package Leader. Implementors are expected to set a default election method. If blank, the default election method will be used. Integer values and corresponding election methods are as follows: 0 - Bully Election Method. Supports Dynamic Fitness Scores and cases where Leadership Fitness Scores need to be shared as part of an election process. 1- Static Fitness Score Election Method. Supports nomination of a leader assuming leadership fitness scores remain static once they have been defined by MP/C2. 2 - Maximum Consensus Election Method. Supports utilizing	

	consensus algorithms to reach team consensus on the leader while preserving communication bandwidth. 3 - Raft Leader Election Method. Supports leader election using the Raft consensus algorithm, which ensures a distributed and fault-tolerant approach to electing a leader.	
PackageLeadershipFitnessScoreDeterminationMethod	MA_LeadershipFitnessScoreDeterminationMethodChoiceType	Optional
Description	This field specifies the chosen fitness score determination method to be used for fitness scoring for the package.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-713: Peer Interface MA_PackageManagementCommandMT - MessageData UCI Extension Field

4.2.52 MA_PackageManagementCommandStatusMT UCI Extension

MA_PackageManagementCommandStatusMT	
Description	This message is sent in response to a PackageManagementCommand and indicates if the command was accepted and if not why it was rejected. The resulting status of the Package Change is reported in PackagePartnerStatusReport for each system in the original command. See the XSD File for more info
Ext. Fields	MessageData : MA_PackageManagementCommandStatusMDT

Table A-4-714: Peer Interface MA_PackageManagementCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PackageManagementCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to	

	communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-715: Peer Interface MA_PackageManagementCommandStatusMT - MessageData UCI Extension Field

4.2.53 MA_PackagePartnerStatusReportMT UCI Extension

MA_PackagePartnerStatusReportMT	
Description	This message reports the resulting status of a package change for a PackageManagementCommand for individual entities in a package. See the XSD File for more info
Ext. Fields	MessageData : MA_PackagePartnerStatusReportMDT

Table A-4-716: Peer Interface MA_PackagePartnerStatusReportMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PackagePartnerStatusReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command that formed the Package specified in the sibling PackageID element.	
PackageID	PackageID_Type	Required
Description	Indicates the unique ID of the package that this message is reporting a change status for.	
PackageLeaderID	SystemID_Type	Optional
Description	Indicates the unique ID of the system that represents the Package lead.	
PackageStatus	RequestProcessingStateEnum	Required
Description	The status of the Package as a whole.	
ConstraintID	MA_ConstraintID_Type	Repeated
Description	Indicates any constraints that were applied to the original PackageManagementCommand, indicated in the sibling CommandID element.	
SystemStatus	MA_PackagePartnerStatusType	Repeated
Description	The status for an individual system within the package.	
StaticLeadershipFitnessScore	FloatMinMaxType	Optional

Description	Indicates the static leadership fitness score for the partners in the package.	
DynamicLeadershipFitnessScore	MA_PartnerLeadershipFitnessScoreType	Optional
Description	Indicates the dynamic leadership fitness score and determination type for a partner in the package.	

Table A-4-717: Peer Interface MA_PackagePartnerStatusReportMT - MessageData UCI Extension Field

4.2.54 MA_SystemManagementRequestMT UCI Extension

MA_SystemManagementRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_SystemManagementRequestMDT RequestType : MA_SystemManagementRequestType VehicleSettings : MA_VehicleCommandDataType

Table A-4-718: Peer Interface MA_SystemManagementRequestMT UCI Extension

MessageData		
Description	This contains the message data.	
Base Type	MA_SystemManagementRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
AuthorityType	EntityManagementRequestAuthorityEnum	Optional
Description	Indicates whether this SystemManagementRequest is a request to change data or an order that must be followed. Defaults to REQUEST if not filled.	
RequestSource	RequestSourceEnum	Optional
Description	This element indicates the type of service requesting the change. Defaults to AUTOMATIC_INTERNAL if not filled.	
ReferenceSystemID	SystemID_Type	Required
Description	Indicates the system to be acted upon by this message.	
RequestType	MA_SystemManagementRequestType	Repeated
Description	Indicates the type of request to perform on a system.	
UpdateFromControllingUnit	boolean	Optional
Description	Indicates if this SystemManagementRequest came from the system controlling the referenced system. This indicates a higher confidence in the new data.	
Source	SystemMessageIdentifierType	Optional
Description	Indicates the system initiating this request and allows the requesting Service, Activity, or Network to be specified.	
RequestID	RequestID_Type	Required

Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-719: Peer Interface MA_SystemManagementRequestMT - MessageData UCI Extension Field

RequestType		
Description	Indicates the type of request to perform on a system.	
Base Type	MA_SystemManagementRequestType	
Message Structure		
Field Name	Field Type	Field Usage
SetMode	MessageModeEnum	Required
Description	Indicates a request to modify the mode of a system.	
SetIdentity	SystemIdentityType	Required
Description	Indicates a request to set the identity of a system.	
SetLink16Metadata	Link16MetadataType	Required
Description	Indicates a request to modify the Link16Metadata of a system.	
SetVoiceControl	VoiceControlType	Required
Description	Set the voice control frequency of a system.	
SetSensorEntityReporting	boolean	Required
Description	When TRUE, indicates an order to report all locally derived sensor, signal, track or Entity data. When FALSE, indicates an order to stop reporting.	
VehicleSettings	MA_VehicleCommandDataType	Required
Description	Indicates a request to modify vehicle settings.	

Table A-4-720: Peer Interface MA_SystemManagementRequestMT - RequestType UCI Extension Field

VehicleSettings		
Description	Indicates a request to modify vehicle settings.	
Base Type	MA_VehicleCommandDataType	
Message Structure		
Field Name	Field Type	Field Usage
VehicleAction	VehicleActionEnum	Optional
Description	Defines vehicle actions that can be done along a path segment of a route.	
IFF_Settings	IFF_Type	Optional
Description	If present the IFF settings for this vehicle will be changed along this path segment.	
SurvivabilityMode	VehicleSurvivabilityModeEnum	Optional
Description	Specifies that the vehicle should put itself into a more survivable mode. Different vehicles will have specific behaviors that reduce the signature of the vehicle (doors closed, minimal use of flaps, etc.) If this element is not present then it is assumed that	

	the aircraft being configured has no survivability mode.	
LostCommTimeout	DurationType	Optional
Description	Defines the lost communication contingency timeout. When this timeout value is exceeded, the AV considers that lost communication has occurred and begins to perform contingency measures.	
LOS	boolean	Optional
Description	Use Line Of Sight (LOS) communication as backup contingency.	
LossOfLinkProcessing	VehicleLossOfLinkProcessingEnum	Optional
Description	Specifies whether the vehicle should invoke special Loss of Link processing. This could be turned off if the vehicle is going to be in a known and accepted lost communication situation.	
CommAllocationAction	CommAllocationActionType	Optional
Description	Indicates a change of communication allocation.	
QNH_Setting	PressureType	Optional
Description	Represents the barometric altimeter setting for correct MSL reading, commonly known as QNH, requested. Expressed in kilopascals (kPa).	

Table A-4-721: Peer Interface MA_SystemManagementRequestMT - VehicleSettings UCI Extension Field

4.2.55 MA_SystemManagementRequestStatusMT UCI Extension

MA_SystemManagementRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_SystemManagementRequestStatusMDT

Table A-4-722: Peer Interface MA_SystemManagementRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_SystemManagementRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Indicates the ID of the system responding to the SystemManagementRequest.	
ServiceID	ServiceID_Type	Required
Description	Indicates the ID of the service responding to the SystemManagementRequest.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	

RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-723: Peer Interface MA_SystemManagementRequestStatusMT - MessageData UCI Extension Field

4.2.56 MA_AMTI_CapabilityMT UCI Extension

MA_AMTI_CapabilityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_AMTI_CapabilityMDT Capability : MA_AMTI_CapabilityType

Table A-4-724: Peer Interface MA_AMTI_CapabilityMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_AMTI_CapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_AMTI_CapabilityType	Repeated
Description	Indicates an installed AMTI Capability, its configurable characteristics and its controllability.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.	

Table A-4-725: Peer Interface MA_AMTI_CapabilityMT - MessageData UCI Extension Field

Capability	
Description	Indicates an installed AMTI Capability, its configurable characteristics and its controllability.
Base Type	MA_AMTI_CapabilityType

Message Structure		
Field Name	Field Type	Field Usage
MT_IIRS_Level	NIIRS_Type	Repeated
Description	Indicates a Moving Target Indication Interpretability Rating Scale level supported by the Capability. See annotations of the underlying type for further details.	
ComponentFieldOfRegard	ComponentFieldOfRegardType	Repeated
Description	Fields of Regard for each component in the capability.	
CapabilityType	AMTI_CapabilityEnum	Required
Description	Indicates the Capability's first tier type in the AMTI taxonomy. For AMTI, the first tier is an indication of the physical area covered. See enumerated type annotations for further details.	
SubCapabilityType	AMTI_SubCapabilityEnum	Repeated
Description	Indicates a SubCapability of the AMTI Capability; the second tier in the taxonomy of AMTI. For AMTI, the second tier is waveform category. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition. The selection of AUTO_SUBCAPABILITY_SELECT still requires the evaluation of all sibling attributes by the Capability.	
CapabilityOptions	AMTI_CapabilityOptionsType	Required
Description	Indicates the Capability's support for select optional elements in its accepted control interface messages. Support for these elements is expected to vary across Capability implementations but must be known in order to adapt and configure upstream Systems and Services which use the Capability.	
SupportedFrequencies	FrequencyRangeType	Repeated
Description	Indicates a frequency range used by the Capability.	
MessageOutput	AMTI_MessageOutputsEnum	Repeated
Description	Indicates a message that is an output of the Capability. See enumerated type annotations for details. List size for this element is based on "Select All That Apply" condition.	
AcceptedInterface	CapabilityControlInterfacesEnum	Repeated
Description	Indicates an accepted control interface for the Capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CommsRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) communications are required to use the Capability. Omitted is equivalent to FALSE. For example, an unmanned system with no onboard storage would require communications to disseminate the outputs of the Capability.	
CapabilityID	CapabilityID_Type	Required
Description	Indicates the unique ID of this Capability. This ID is used to invoke the Capability via Command messages, report its activity via Activity messages, etc.	
DomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates the domain/environment which the Capability is employed from and the "target" domain/environment. See enumerated type annotations for further details. List	

	size for this element is based on "Select All That Apply" condition.	
ProductOutput	ProductOutputType	Repeated
Description	Indicates a Product that can be an output of the Capability.	
PackageOperation	PackageOperationEnum	Optional
Description	Indicates if and how the operation of the Capability can be coordinated with a partner Capability of another System in a multi-System Package. Omitting this element is equivalent to the enumerate NO_PACKAGE_OPERATION. The actual Package configuration including per-Capability partnering between Systems is given in the PackageStatus message. For example, a System that can perform cooperative geolocation could advertise with this element in the ESM_Capability message. A System that can navigate in a swarm with other Systems could advertise with this element in the FlightCapability message.	

Table A-4-726: Peer Interface MA_AMTI_CapabilityMT - Capability UCI Extension Field

4.2.57 MA_ActionCapabilityMT UCI Extension

MA_ActionCapabilityMT	
Description	This message represents the Action category of UCI Capability. See the XSD File for more info
Ext. Fields	AssociatedTaskType : MA_TaskTypeEnum Capability : MA_ActionCapabilityType MessageData : MA_ActionCapabilityMDT

Table A-4-727: Peer Interface MA_ActionCapabilityMT UCI Extension

AssociatedTaskType	
Description	Indicates a Task type associated with the Action. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.
AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.
CAP	Indicates the task is to execute a Combat Air Patrol.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.

EA	Indicates the task is to employ an electronic attack capability.
ESCORT	Indicates the task is to escort another entity.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.
SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.
SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-728: Peer Interface MA_ActionCapabilityMT - AssociatedTaskType UCI Extension Field

Capability		
Description	Indicates an installed Action Capability, its configurable characteristics and its controllability.	
Base Type	MA_ActionCapabilityType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityType	MA_ActionTypeEnum	Required
Description	Indicates the type of Action. See enumerated type annotations for further details.	
AssociatedTaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a Task type associated with the Action. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
AssociatedCapabilityType	CapabilityTypeEnum	Repeated
Description	Indicates a Capability type associated with the Action. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CapabilityOptions	ActionCapabilityOptionsType	Required
Description	Indicates the Capability's support for select optional elements in its accepted control interface messages. Support for these elements is expected to vary across Capability implementations but must be known in order to adapt and configure upstream Systems and Services which use the Capability.	

MessageOutput	ActionMessageOutputsEnum	Repeated
Description	Indicates a message that is an output of the Capability. See enumerated type annotations for details. List size for this element is based on "Select All That Apply" condition.	
AcceptedInterface	CapabilityControlInterfacesEnum	Repeated
Description	Indicates an accepted control interface for the Capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CommsRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) communications are required to use the Capability. Omitted is equivalent to FALSE. For example, an unmanned system with no onboard storage would require communications to disseminate the outputs of the Capability.	
CapabilityID	CapabilityID_Type	Required
Description	Indicates the unique ID of this Capability. This ID is used to invoke the Capability via Command messages, report its activity via Activity messages, etc.	
DomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates the domain/environment which the Capability is employed from and the "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
ProductOutput	ProductOutputType	Repeated
Description	Indicates a Product that can be an output of the Capability.	
PackageOperation	PackageOperationEnum	Optional
Description	Indicates if and how the operation of the Capability can be coordinated with a partner Capability of another System in a multi-System Package. Omitting this element is equivalent to the enumerate NO_PACKAGE_OPERATION. The actual Package configuration including per-Capability partnering between Systems is given in the PackageStatus message. For example, a System that can perform cooperative geolocation could advertise with this element in the ESM_Capability message. A System that can navigate in a swarm with other Systems could advertise with this element in the FlightCapability message.	

Table A-4-729: Peer Interface MA_ActionCapabilityMT - Capability UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActionCapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_ActionCapabilityType	Repeated
Description	Indicates an installed Action Capability, its configurable characteristics and its controllability.	
AvailableMDF	MDF_Type	Repeated

Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.
-------------	---

Table A-4-730: Peer Interface MA_ActionCapabilityMT - MessageData UCI Extension Field

4.2.58 MA_ApprovalRequestMT UCI Extension

MA_ApprovalRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ActivationDetails : MA_MissionPlanActivationDetailsType OpPlanID : MA_OpPlanID_Type MissionPlanActivationApproval : MA_MissionPlanActivationCommandType ApprovalReferences : ApprovalRequestPolicyReferenceType ApprovalItem : ApprovalRequestItemReferenceType ByExecutionPlanSet : MA_ExecutionPlanSetActivationType MessageData : ApprovalRequestMDT BySubPlan : MA_MissionPlanSubplanActivationType OpPlan : MA_OpPlanActivationType

Table A-4-731: Peer Interface MA_ApprovalRequestMT UCI Extension

ActivationDetails		
Description	Indicates the commanded activation details.	
Base Type	MA_MissionPlanActivationDetailsType	
Message Structure		
Field Name	Field Type	Field Usage
ByMissionPlan	MissionPlanActivationType	Required
Description	Indicates simultaneous activation of all sub-*Plans (RoutePlan, RouteActivityPlan for example) of a MissionPlan into the same activation state.	
BySubPlan	MA_MissionPlanSubplanActivationType	Required
Description	Indicates activation by sub-*Plan (RoutePlan or OrbitPlan for example) of the MissionPlan, with potentially different states for each.	
ByExecutionPlanSet	MA_ExecutionPlanSetActivationType	Required
Description	Indicates simultaneous activation of all sub-*Plans (ActivityPlan, RoutePlan for example) of an *ExecutionPlanSet into the same activation state.	

Table A-4-732: Peer Interface MA_ApprovalRequestMT - ActivationDetails UCI Extension Field

OpPlanID		
Description	Indicates the unique ID of the TaskPlan to perform the sibling activation command on.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-733: Peer Interface MA_ApprovalRequestMT - OpPlanID UCI Extension Field

MissionPlanActivationApproval		
Description	Indicates the MissionPlanActivationCommand details that are under review for approval. If more than one instance of this element is given, each should correspond to a different MissionPlanID. For example, if the intent is to transition from one MissionPlan to another, the new MissionPlan can be activated in one instance and the old MissionPlan can be deactivated in another instance. This transition would be subject to approval.	
Base Type	MA_MissionPlanActivationCommandType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	Indicates the unique ID of the MissionPlan whose commanded activation state or states are summarized in the sibling element.	
ActivationDetails	MA_MissionPlanActivationDetailsType	Required
Description	Indicates the commanded activation details.	

Table A-4-734: Peer Interface MA_ApprovalRequestMT - MissionPlanActivationApproval UCI Extension Field

ApprovalReferences		
Description	Indicates the policy that resulted in the ApprovalRequest along with references to the data under review.	
Base Type	ApprovalRequestPolicyReferenceType	
Message Structure		
Field Name	Field Type	Field Usage

ApprovalPolicyID	ApprovalPolicyID_Type	Required
Description	Indicates the unique ID of the ApprovalPolicy that resulted in this ApprovalRequest.	
ApprovalItem	ApprovalRequestItemReferenceType	Required
Description	Indicates the ID of the specific item that is being requested for approval.	

Table A-4-735: Peer Interface MA_ApprovalRequestMT - ApprovalReferences UCI Extension Field

ApprovalItem		
Description	Indicates the ID of the specific item that is being requested for approval.	
Base Type	ApprovalRequestItemReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
PlanApproval	PlanReferenceID_ChoiceType	Required
Description	Indicates the unique ID of the *Plan that is under review for approval.	
RequirementExecutionApproval	ApprovalRequestItemType	Required
Description	Indicates the Requirement, including any associated DMPIs, that is under review for approval to execute.	
MissionPlanActivationApproval	MissionPlanActivationCommandType	Repeated
Description	Indicates the MissionPlanActivationCommand details that are under review for approval. If more than one instance of this element is given, each should correspond to a different MissionPlanID. For example, if the intent is to transition from one MissionPlan to another, the new MissionPlan can be activated in one instance and the old MissionPlan can be deactivated in another instance. This transition would be subject to approval.	

Table A-4-736: Peer Interface MA_ApprovalRequestMT - ApprovalItem UCI Extension Field

ByExecutionPlanSet		
Description	Indicates simultaneous activation of all sub-*Plans (ActivityPlan, RoutePlan for example) of an *ExecutionPlanSet into the same activation state.	
Base Type	MA_ExecutionPlanSetActivationType	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPlanSetID	ExecutionPlanSetID_Type	Required
Description	Indicates the unique ID of the execution plan set.	
CommandType	PlanActivationCommandEnum	Required
Description	Indicates the activation to perform on the associated execution plan set.	

Table A-4-737: Peer Interface MA_ApprovalRequestMT - ByExecutionPlanSet UCI Extension Field

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	ApprovalRequestMDT

Message Structure		
Field Name	Field Type	Field Usage
Approver	OperatorRoleType	Required
Description	An Operator Role or non-Operator identifier that is allowed to approve the included approval policy and approval item.	
ApprovalReferences	ApprovalRequestPolicyReferenceType	Required
Description	Indicates the policy that resulted in the ApprovalRequest along with references to the data under review.	
RespondBy	DateTimeType	Required
Description	If a response is not received from this approval authority by the given time, the approval policy's default response will be used. This field should be driven based on the timeout specified within the approval policy for approvals of this type.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-738: Peer Interface MA_ApprovalRequestMT - MessageData UCI Extension Field

BySubPlan		
Description	Indicates activation by sub-*Plan (RoutePlan or OrbitPlan for example) of the MissionPlan, with potentially different states for each.	
Base Type	MA_MissionPlanSubplanActivationType	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlan	TaskPlanActivationType	Repeated
Description	Indicates commanded details for activation of a TaskPlan.	
RoutePlan	MA_RoutePlanActivationType	Repeated
Description	Indicates commanded details for activation of a RoutePlan.	
RouteActivityPlan	RouteActivityPlanActivationType	Repeated
Description	Indicates commanded details for activation of a RouteActivityPlan.	
OrbitPlan	OrbitPlanActivationType	Repeated
Description	Indicates commanded details for activation of an OrbitPlan.	
OrbitActivityPlan	OrbitActivityPlanActivationType	Repeated
Description	Indicates commanded details for activation of an OrbitActivityPlan.	
ActivityPlan	ActivityPlanActivationType	Repeated
Description	Indicates commanded details for activation of an ActivityPlan.	
EffectPlan	EffectPlanActivationType	Repeated
Description	Indicates commanded details for activation of an EffectPlan.	

ActionPlan	ActionPlanActivationType	Repeated
Description	Indicates commanded details for activation of an ActionPlan.	
ResponsePlan	ResponsePlanActivationType	Repeated
Description	Indicates commanded details for activation of a ResponsePlan.	
OpPlan	MA_OpPlanActivationType	Repeated
Description	Indicates commanded details for activation of an OpPlan.	

Table A-4-739: Peer Interface MA_ApprovalRequestMT - BySubPlan UCI Extension Field

OpPlan		
Description	Indicates commanded details for activation of an OpPlan.	
Base Type	MA_OpPlanActivationType	
Message Structure		
Field Name	Field Type	Field Usage
OpPlanID	MA_OpPlanID_Type	Required
Description	Indicates the unique ID of the TaskPlan to perform the sibling activation command on.	
CommandType	PlanActivationCommandEnum	Required
Description	Indicates the activation to perform on the associated TaskPlan.	

Table A-4-740: Peer Interface MA_ApprovalRequestMT - OpPlan UCI Extension Field

4.2.59 MA_ApprovalRequestStatusMT UCI Extension

MA_ApprovalRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_ApprovalRequestStatusMDT

Table A-4-741: Peer Interface MA_ApprovalRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ApprovalRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApprovalRequestProcessingState	ApprovalStatusEnum	Required
Description	The ApprovalState indicates the current state of the approval for an approval request.	
ApprovalRequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling ApprovalRequestProcessingState element. This element is	

	only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	
OperatorID	OperatorID_Type	Optional
Description	Indicates the Operator that provided the approval/rejection, if available. This element can be beneficial when systems require two-person integrity.	
ApprovedDMPI_ID	DMPI_ID_Type	Repeated
Description	If the ApprovalRequest was for DMPI approval then this element contains the list of approved DMPIs. If any DMPIs are approved, the sibling ApprovalState will indicate that the request is approved.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-742: Peer Interface MA_ApprovalRequestStatusMT - MessageData UCI Extension Field

4.2.60 MA_EffectCapabilityMT UCI Extension

MA_EffectCapabilityMT	
Description	This message represents the Effect category of UCI Capability. See the XSD File for more info
Ext. Fields	AssociatedTaskType : TaskTypeEnum

Table A-4-743: Peer Interface MA_EffectCapabilityMT UCI Extension

AssociatedTaskType	
Description	Indicates a Task type associated with the Effect. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.
Base Type	TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.

AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.
SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.
SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-744: Peer Interface MA_EffectCapabilityMT - AssociatedTaskType UCI Extension Field

4.2.61 MA_FlightCapabilityMT UCI Extension

MA_FlightCapabilityMT	
Description	Extended to indicate the type of flight capability via the FlightCapabilityEnum and provide per-control mode performance parameters. See the XSD File for more info
Ext. Fields	HSA_CSA_PerformanceProfile : MA_FlightControlModesPerformanceProfileType WaypointFollowingPerformanceProfile : MA_FlightControlModesPerformanceProfileType CurveFollowingPerformanceProfile : MA_FlightControlModesPerformanceProfileType AccelerationLimit : MA_BodyReferenceAccelerationType AccelerationLimitValue : MA_AccelerationLimitPairType BodyReferenceOrientationRate : MA_BodyReferenceOrientationRateType OrientationRateLimits : MA_BodyReferenceOrientationRateType AirspeedPair : PathSegmentSpeedValueType

Table A-4-745: Peer Interface MA_FlightCapabilityMT UCI Extension

HSA_CSA_PerformanceProfile		
Description	Indicates performance profile for HSA_CSA flight control mode.	
Base Type	MA_FlightControlModesPerformanceProfileType	
Message Structure		
Field Name	Field Type	Field Usage
MinAirspeed	MA_AirspeedLimitType	Repeated
Description	Minimum allowable airspeed given as a function of altitude.	
MaxAirspeed	MA_AirspeedLimitType	Repeated
Description	Maximum allowable airspeed given as a function of altitude.	
BestEnduranceAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum endurance given as a function of altitude.	
BestRangeAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum range given as a function of altitude.	
MinAltitude	AltitudeReferenceType	Optional
Description	Minimum allowable altitude.	
MaxAltitude	AltitudeReferenceType	Optional
Description	Maximum allowable altitude.	
MinAccelerationLimits	MA_AccelerationLimitsType	Repeated
Description	The vehicle's acceleration limits in the current operating domain of the system as a function of time. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
ExcessPowerOrAcceleration	MA_ExcessPowerOrAccelerationType	Optional
Description	Provides either specific excess power or paired acceleration and climb rate data for the platform.	
MaxOrientationLimits	MA_OrientationLimitType	Repeated
Description	Euler Angle Sequence describing the maximum orientation of the vehicle in the order yaw, pitch, roll as a function of airspeed, altitude, and weight.	
MaxOrientationRateLimits	MA_OrientationRateLimitsType	Repeated
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
MaxTurnRate	AngleRateType	Optional
Description	Maximum allowable turn rate in radians/sec.	
MaxDescentRate	MA_SpeedType	Repeated
Description	Maximum allowable descent rate as a function of airspeed, altitude, and weight.	
MaxDeceleration	MA_AccelerationLimitsType	Repeated

Description	Maximum allowable deceleration limits as a function of airspeed, altitude, and weight.	
FuelBurnRate	MA_FuelBurnRateType	Repeated
Description	Fuel burn rate as a function of airspeed, altitude, and weight.	

Table A-4-746: Peer Interface MA_FlightCapabilityMT - HSA_CSA_PerformanceProfile UCI Extension Field

WaypointFollowingPerformanceProfile		
Description	Indicates performance profile for Waypoint Following flight control mode.	
Base Type	MA_FlightControlModesPerformanceProfileType	
Message Structure		
Field Name	Field Type	Field Usage
MinAirspeed	MA_AirspeedLimitType	Repeated
Description	Minimum allowable airspeed given as a function of altitude.	
MaxAirspeed	MA_AirspeedLimitType	Repeated
Description	Maximum allowable airspeed given as a function of altitude.	
BestEnduranceAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum endurance given as a function of altitude.	
BestRangeAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum range given as a function of altitude.	
MinAltitude	AltitudeReferenceType	Optional
Description	Minimum allowable altitude.	
MaxAltitude	AltitudeReferenceType	Optional
Description	Maximum allowable altitude.	
MinAccelerationLimits	MA_AccelerationLimitsType	Repeated
Description	The vehicle's acceleration limits in the current operating domain of the system as a function of time. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
ExcessPowerOrAcceleration	MA_ExcessPowerOrAccelerationType	Optional
Description	Provides either specific excess power or paired acceleration and climb rate data for the platform.	
MaxOrientationLimits	MA_OrientationLimitType	Repeated
Description	Euler Angle Sequence describing the maximum orientation of the vehicle in the order yaw, pitch, roll as a function of airspeed, altitude, and weight.	
MaxOrientationRateLimits	MA_OrientationRateLimitsType	Repeated
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
MaxTurnRate	AngleRateType	Optional

Description	Maximum allowable turn rate in radians/sec.	
MaxDescentRate	MA_SpeedType	Repeated
Description	Maximum allowable descent rate as a function of airspeed, altitude, and weight.	
MaxDeceleration	MA_AccelerationLimitsType	Repeated
Description	Maximum allowable deceleration limits as a function of airspeed, altitude, and weight.	
FuelBurnRate	MA_FuelBurnRateType	Repeated
Description	Fuel burn rate as a function of airspeed, altitude, and weight.	

Table A-4-747: Peer Interface MA_FlightCapabilityMT - WaypointFollowingPerformanceProfile UCI Extension Field

CurveFollowingPerformanceProfile		
Description	Indicates performance profile for Curve Following flight control mode.	
Base Type	MA_FlightControlModesPerformanceProfileType	
Message Structure		
Field Name	Field Type	Field Usage
MinAirspeed	MA_AirspeedLimitType	Repeated
Description	Minimum allowable airspeed given as a function of altitude.	
MaxAirspeed	MA_AirspeedLimitType	Repeated
Description	Maximum allowable airspeed given as a function of altitude.	
BestEnduranceAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum endurance given as a function of altitude.	
BestRangeAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum range given as a function of altitude.	
MinAltitude	AltitudeReferenceType	Optional
Description	Minimum allowable altitude.	
MaxAltitude	AltitudeReferenceType	Optional
Description	Maximum allowable altitude.	
MinAccelerationLimits	MA_AccelerationLimitsType	Repeated
Description	The vehicle's acceleration limits in the current operating domain of the system as a function of time. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
ExcessPowerOrAcceleration	MA_ExcessPowerOrAccelerationType	Optional
Description	Provides either specific excess power or paired acceleration and climb rate data for the platform.	
MaxOrientationLimits	MA_OrientationLimitType	Repeated
Description	Euler Angle Sequence describing the maximum orientation of the vehicle in the order yaw, pitch, roll as a function of airspeed, altitude, and weight.	
MaxOrientationRateLimits	MA_OrientationRateLimitsType	Repeated

Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
MaxTurnRate	AngleRateType	Optional
Description	Maximum allowable turn rate in radians/sec.	
MaxDescentRate	MA_SpeedType	Repeated
Description	Maximum allowable descent rate as a function of airspeed, altitude, and weight.	
MaxDeceleration	MA_AccelerationLimitsType	Repeated
Description	Maximum allowable deceleration limits as a function of airspeed, altitude, and weight.	
FuelBurnRate	MA_FuelBurnRateType	Repeated
Description	Fuel burn rate as a function of airspeed, altitude, and weight.	

Table A-4-748: Peer Interface MA_FlightCapabilityMT - CurveFollowingPerformanceProfile UCI Extension Field

AccelerationLimit		
Description	Specified acceleration limits in body reference or NED coordinate frame.	
Base Type	MA_BodyReferenceAccelerationType	
Message Structure		
Field Name	Field Type	Field Usage
X_Accel	AccelerationType	Required
Description	Body-referenced acceleration component along the longitudinal (x or roll) axis, measured in meters/sec^2	
Y_Accel	AccelerationType	Required
Description	Body-referenced acceleration component along the lateral (y or pitch) axis, measured in meters/sec^2	
Z_Accel	AccelerationType	Required
Description	Body-referenced acceleration component along the vertical (z or yaw) axis, measured in meters/sec^2.	
Timestamp	DateTimeType	Optional
Description	Indicates the time when the acceleration data was measured or last known to be correct. The element can also indicate the time at which a future velocity of a System, Entity, etc. will be achieved.	

Table A-4-749: Peer Interface MA_FlightCapabilityMT - AccelerationLimit UCI Extension Field

AccelerationLimitValue		
Description	Value for the specified acceleration limit, provided either as a set of body referenced orientation rates, or a unitless Mach value.	
Base Type	MA_AccelerationLimitPairType	
Message Structure		
Field Name	Field Type	Field Usage

BodyReferenceOrientationRate	MA_BodyReferenceOrientationRateType	Required
Description	Body reference orientation rates to be paired with the specified acceleration limit.	
MachValue	MachType	Required
Description	Unitless Mach value to be paired with the specified acceleration limit.	

Table A-4-750: Peer Interface MA_FlightCapabilityMT - AccelerationLimitValue UCI Extension Field

BodyReferenceOrientationRate		
Description	Body reference orientation rates to be paired with the specified acceleration limit.	
Base Type	MA_BodyReferenceOrientationRateType	
Message Structure		
Field Name	Field Type	Field Usage
RollRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the longitudinal (x or roll) axis, measured in radians/sec.	
PitchRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the lateral (y or pitch) axis, measured in radians/sec.	
YawRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the vertical (z or yaw) axis, measured in radians/sec.	
Timestamp	DateTimeType	Optional
Description	Indicates the time when the velocity data was measured or last known to be correct. The element can also indicate the time at which a future velocity of a System, Entity, etc. will be achieved.	

Table A-4-751: Peer Interface MA_FlightCapabilityMT - BodyReferenceOrientationRate UCI Extension Field

OrientationRateLimits		
Description	Specified orientation rate limits in body reference or NED coordinate frame.	
Base Type	MA_BodyReferenceOrientationRateType	
Message Structure		
Field Name	Field Type	Field Usage
RollRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the longitudinal (x or roll) axis, measured in radians/sec.	
PitchRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the lateral (y or pitch) axis, measured in radians/sec.	
YawRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the vertical (z or yaw) axis, measured	

	in radians/sec.	
Timestamp	DateTimeType	Optional
Description	Indicates the time when the velocity data was measured or last known to be correct. The element can also indicate the time at which a future velocity of a System, Entity, etc. will be achieved.	

Table A-4-752: Peer Interface MA_FlightCapabilityMT - OrientationRateLimits UCI Extension Field

AirspeedPair		
Description	Airspeed pair value for associated orientation rate limit, specified in body reference or NED coordinate frame.	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-753: Peer Interface MA_FlightCapabilityMT - AirspeedPair UCI Extension Field

4.2.62 MA_FlightCapabilityStatusMT UCI Extension

MA_FlightCapabilityStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	Capability : MA_FlightCapabilityType MessageData : MA_FlightCapabilityMDT

Table A-4-754: Peer Interface MA_FlightCapabilityStatusMT UCI Extension

Capability		
Description	Provides a list of the specific Flight Capabilities as defined by the FlightCapabilityEnum.	
Base Type	MA_FlightCapabilityType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityType	MA_FlightCapabilityEnum	Repeated
Description	Indicates the type of Flight capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
FlightCapabilityPerformanceProfile	MA_FlightCapabilityPerformanceProfileType	Optional
Description	Provides per-control mode performance parameters. Enables autonomy commands to properly conform to envelope limits or limit summary values	

	before sending a FlightCommand to the vehicle.	
AcceptedInterface	CapabilityControlInterfacesEnum	Repeated
Description	Indicates an accepted control interface for the Capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CommsRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) communications are required to use the Capability. Omitted is equivalent to FALSE. For example, an unmanned system with no onboard storage would require communications to disseminate the outputs of the Capability.	
CapabilityID	CapabilityID_Type	Required
Description	Indicates the unique ID of this Capability. This ID is used to invoke the Capability via Command messages, report its activity via Activity messages, etc.	
DomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates the domain/environment which the Capability is employed from and the "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
ProductOutput	ProductOutputType	Repeated
Description	Indicates a Product that can be an output of the Capability.	
PackageOperation	PackageOperationEnum	Optional
Description	Indicates if and how the operation of the Capability can be coordinated with a partner Capability of another System in a multi-System Package. Omitting this element is equivalent to the enumerate NO_PACKAGE_OPERATION. The actual Package configuration including per-Capability partnering between Systems is given in the PackageStatus message. For example, a System that can perform cooperative geolocation could advertise with this element in the ESM_Capability message. A System that can navigate in a swarm with other Systems could advertise with this element in the FlightCapability message.	

Table A-4-755: Peer Interface MA_FlightCapabilityStatusMT - Capability UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_FlightCapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_FlightCapabilityType	Repeated
Description	Provides a list of the specific Flight Capabilities as defined by the FlightCapabilityEnum.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are	

	generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.
--	---

Table A-4-756: Peer Interface MA_FlightCapabilityStatusMT - MessageData UCI Extension Field

4.2.63 MA_TaskMT UCI Extension

MA_TaskMT	
Description	This message specifies a Task that a System will perform against a specific entity or geographical location. Tasks include flight, collection, strike, electronic attack, directed energy, laser designation, cargo delivery and communication relay. They are abstracted to a level of C2 and autonomy derived from UCI operational vignettes. Tasks enable services, operators and other actors to do automated, dynamic, machine-to-machine allocation of Tasks to Systems and subsequent mission planning. If necessary, authorization of Users to Task Systems can be controlled using the Authorization message. See the XSD File for more info
Ext. Fields	TaskType : MA_TaskType TaskPlurality : MA_TaskPluralityEnum ConstraintID : MA_ConstraintID_Type HSA_CSA : MA_HSA_CSA_Type WaypointFollowing : MA_WaypointFollowingType CurveFollowing : MA_CurveControlType Speed : PathSegmentSpeedType Heading : MA_DirectionReferenceType SpeedChoice : MA_HSA_SpeedChoiceType SpeedValue : PathSegmentSpeedValueType CurveFitMethod : MA_CurveFitMethodEnum

Table A-4-757: Peer Interface MA_TaskMT UCI Extension

TaskType		
Description	Identifies the type of this Task instance.	
Base Type	MA_TaskType	
Message Structure		
Field Name	Field Type	Field Usage
AirSample	AirSampleTaskType	Required
Description	Air sample includes direct sampling of the air (SAMPLE) and remote sensing with spectral analysis (SPECTROMETER) with the intent of detecting NBC events.	
AMTI	AMTI_TaskType	Required
Description	Indicates a Task to collect Air Moving Target Indicator (AMTI) data.	
AO	AO_TaskType	Required

	Description	Indicates a Task to perform an optical emission such as laser designation.
CAP	MA_CAP_TaskType	Required
	Description	Indicates a Task to perform Combat Air Patrol.
CargoDelivery	CargoDeliveryTaskType	Required
	Description	Indicates a Task to transfer cargo between locations.
COMINT	COMINT_TaskType	Required
	Description	Indicates a Task to provide COMINT.
CommRelay	CommRelayTaskType	Required
	Description	Indicates a Task to provide communications relay support.
CounterSpace	CounterSpaceTaskType	Required
	Description	Indicates a Task to employ a CounterSpace capability.
Escort	MA_EscortTaskType	Required
	Description	Indicates a Task to escort another Entity or System.
EA	EA_TaskType	Required
	Description	Indicates a Task to provide electronic attack support to another System. It guides/constrains the EA System by specifying where it should fly, what it should protect and what the threat is.
ESM	ESM_TaskType	Required
	Description	Indicates a Task to collect ESM data.
Flight	MA_FlightTaskType	Required
	Description	Indicates a Task to effect the flight path/plan of the System.
Jettison	MA_JettisonTaskType	Required
	Description	Indicates a Task to a jettisonable weapon from the system.
OrbitChange	OrbitChangeTaskType	Required
	Description	Indicates a task to perform an orbit change via a spacecraft maneuver.
OrbitalSurveillance	OrbitalSurveillanceTaskType	Required
	Description	Indicates an Orbital Surveillance Task.
OrbitalSurveillanceSensor	OrbitalSurveillanceSensorTaskType	Required
	Description	Indicates a task to perform orbital surveillance sensor tasking.
PO	PO_TaskType	Required
	Description	Indicates a Task to collect Passive Optical data, imagery and video as well as perform PO search and track capabilities.
Refuel	RefuelTaskType	Required
	Description	Indicates a Task for one System to refuel another.
SAR	SAR_TaskType	Required
	Description	Indicates a Task to collect a Synthetic Aperture Radar (SAR) image.
SMTI	SMTI_TaskType	Required

Description	Indicates a Task to collect Moving Target Indicator (MTI) data.	
Strike	StrikeTaskType	Required
Description	Indicates a Task to kinetically attack/strike, with a weapon that can be released from the System.	
SystemDeployment	SystemDeploymentTaskType	Required
Description	Indicates a task to perform a deployment or release of a system at a specified location.	
TacticalOrder	TacticalOrderTaskType	Required
Description	Indicates a task to perform a tactical order.	
WeatherRadar	WeatherRadarTaskType	Required
Description	Indicates a task to collect weather radar data.	

Table A-4-758: Peer Interface MA_TaskMT - TaskType UCI Extension Field

TaskPlurality	
Description	Indicates whether the task is meant to be executed by a single entity or as a joint operation. A join operation implies forming a group prior to execution. A single entity could be a single system or a single pre-formed group.
Base Type	MA_TaskPluralityEnum
Message Structure	
Enumeration Literal	Description
UNSPECIFIED	Indicates the task plurality is unspecified, and should be defaulted or determined by the receiving system.
JOINT	Indicates the task is to be executed as a joint task. A group will be formed when this task is assigned.
SINGLE_ENTITY	Indicates the task is to be executed by a single entity. A single entity could be a single system or a single pre-existing group.

Table A-4-759: Peer Interface MA_TaskMT - TaskPlurality UCI Extension Field

ConstraintID		
Description	Indicates any Constraints that apply to the Task (e.g FormationConstraint). A FormationConstraint implies that if a group is formed to execute this task, the referenced Constraint(s) should be applied to that group.	
Base Type	MA_ConstraintID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-760: Peer Interface MA_TaskMT - ConstraintID UCI Extension Field

HSA_CSA		
Description	This message shall be used to provide the ability to command a new flight vector to the Platform.	
Base Type	MA_HSA_CSA_Type	
Message Structure		
Field Name	Field Type	Field Usage
Altitude	AltitudeReferenceType	Optional
Description	Altitude hold value to be achieved and reference to altitude measurement source.	
Speed	PathSegmentSpeedType	Optional
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Direction	MA_DirectionChoiceType	Optional
Description	Defines heading or course type and reference to hold	

Table A-4-761: Peer Interface MA_TaskMT - HSA_CSA UCI Extension Field

WaypointFollowing		
Description	This message shall be used to provide the ability to send a new waypoint path or segment for the Platform to follow.	
Base Type	MA_WaypointFollowingType	
Message Structure		
Field Name	Field Type	Field Usage
Route	MA_RouteType	Required
Description	Indicates the Paths and Segments that make up the Route to be flown.	

Table A-4-762: Peer Interface MA_TaskMT - WaypointFollowing UCI Extension Field

CurveFollowing		
Description	Indicates the parameters for curve following control.	
Base Type	MA_CurveControlType	
Message Structure		
Field Name	Field Type	Field Usage
CurveSegments	MA_NURBS_PointType	Repeated
Description	Specifies the curve segments as a set of NURBS points.	
AppendCurve	EmptyType	Optional
Description	Specifies this curve will be appended to a previous curve command. This is only valid if the vehicle is currently executing a curve.	
EndOfCurveBehavior	MA_EndOfCurveBehaviorEnum	Optional
Description	Specifies the vehicle behavior at the completion of the curve.	

Table A-4-763: Peer Interface MA_TaskMT - CurveFollowing UCI Extension Field

Speed

Description	Defines speed type (reference frame) for all speed related fields in this message.	
Base Type	PathSegmentSpeedType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedChoice	PathSegmentSpeedChoiceType	Optional
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
SpeedOptimization	SpeedOptimizationEnum	Optional
Description	Indicates that the System will vary its speed autonomously according to the specified optimization algorithm.	

Table A-4-764: Peer Interface MA_TaskMT - Speed UCI Extension Field

Heading		
Description	Defines heading type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-765: Peer Interface MA_TaskMT - Heading UCI Extension Field

SpeedChoice		
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
Base Type	MA_HSA_SpeedChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedValue	PathSegmentSpeedValueType	Required
Description	Indicates speed in meters per second (m/s).	
MachValue	MachType	Required
Description	Indicates the speed reference for the associated speed value.	

Table A-4-766: Peer Interface MA_TaskMT - SpeedChoice UCI Extension Field

SpeedValue	
Description	Indicates speed in meters per second (m/s).

Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-767: Peer Interface MA_TaskMT - SpeedValue UCI Extension Field

CurveFitMethod	
Description	Method through which a curve should be fitted to the discretized points in ControlPoint.
Base Type	MA_CurveFitMethodEnum
Message Structure	
Enumeration Literal	Description
B_SPLINE	B-Spline (basis spline) fit.
BEZIER	Bezier curve fit.
CATMULL_ROM	Catmull-Rom spline fit.
NATURAL_CUBIC	Natural Cubic curve fit.

Table A-4-768: Peer Interface MA_TaskMT - CurveFitMethod UCI Extension Field

4.2.64 MA_NavigationReportMT UCI Extension

MA_NavigationReportMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_NavigationReportMDT

Table A-4-769: Peer Interface MA_NavigationReportMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_NavigationReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Indicates the unique ID of the System corresponding to this NavigationReport.	

Source	SystemSourceEnum	Required
Description	Indicates the source of the data in sibling elements. See enumeration annotations for further details.	
ContingencyLevel	SystemContingencyLevelEnum	Required
Description	Designates the current contingency state of the System. Contingencies can be an indication that the System will/has autonomously modified its means of navigation.	
Endurance	EnduranceType	Required
Description	Indicates the System's remaining endurance. It is expected that at least one of the optional children are populated in this context.	
Playtime	DurationType	Optional
Description	Estimated remaining playtime of operation/mission when taking into account RTB routing, fuel overhead, current fuel usage, current tasking, etc.	
Navigation	NavigationType	Optional
Description	Vehicle navigation method currently employed.	

Table A-4-770: Peer Interface MA_NavigationReportMT - MessageData UCI Extension Field

4.2.65 MA_StrikeActivityMT UCI Extension

MA_StrikeActivityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	ActiveWeaponHSA_CSA : MA_HSA_CSA_Type Direction : MA_DirectionChoiceType MunitionActive : MA_MunitionActiveType MessageData : MA_StrikeActivityMDT ActiveWeaponState : MA_ActiveWeaponStateEnum Activity : MA_StrikeActivityType Course : MA_DirectionReferenceType Heading : MA_DirectionReferenceType Reference : MA_HeadingReferenceEnum

Table A-4-771: Peer Interface MA_StrikeActivityMT UCI Extension

ActiveWeaponHSA_CSA		
Description	Provides the heading/course, speed, and altitude of the munition while the Activity is ACTIVE_*.	
Base Type	MA_HSA_CSA_Type	
Message Structure		
Field Name	Field Type	Field Usage
Altitude	AltitudeReferenceType	Optional

Description	Altitude hold value to be achieved and reference to altitude measurement source.	
Speed	PathSegmentSpeedType	Optional
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Direction	MA_DirectionChoiceType	Optional
Description	Defines heading or course type and reference to hold	

Table A-4-772: Peer Interface MA_StrikeActivityMT - ActiveWeaponHSA_CSA UCI Extension Field

Direction		
Description	Defines heading or course type and reference to hold	
Base Type	MA_DirectionChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
Heading	MA_DirectionReferenceType	Optional
Description	Defines heading type and reference to hold.	
Course	MA_DirectionReferenceType	Optional
Description	Defines course type and reference to hold.	

Table A-4-773: Peer Interface MA_StrikeActivityMT - Direction UCI Extension Field

MunitionActive		
Description	Data regarding the munition while it is active or in flight.	
Base Type	MA_MunitionActiveType	
Message Structure		
Field Name	Field Type	Field Usage
ActiveWeaponState	MA_ActiveWeaponStateEnum	Repeated
Description	Provides further munition state data detail if the Activity is ENABLED, ACTIVE_* or COMPLETED as reported by the ActivityState. This message can be omitted if ActivityState is DISABLED, FAILED or DELETED. List size for this element is based on "Select All That Apply" condition.	
ActiveWeaponHSA_CSA	MA_HSA_CSA_Type	Optional
Description	Provides the heading/course, speed, and altitude of the munition while the Activity is ACTIVE_*.	

Table A-4-774: Peer Interface MA_StrikeActivityMT - MunitionActive UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_StrikeActivityMDT	
Message Structure		
Field Name	Field Type	Field Usage
SubsystemID	SubsystemID_Type	Required

Description	Indicates the Subsystem which hosts the Strike Capabilities whose Activities are given in this message.	
Activity	MA_StrikeActivityType	Repeated
Description	Indicates the dynamic operational characteristics of an Activity of a Strike Capability.	

Table A-4-775: Peer Interface MA_StrikeActivityMT - MessageData UCI Extension Field

ActiveWeaponState	
Description	Provides further munition state data detail if the Activity is ENABLED, ACTIVE_* or COMPLETED as reported by the ActivityState. This message can be omitted if ActivityState is DISABLED, FAILED or DELETED. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_ActiveWeaponStateEnum
Message Structure	
Enumeration Literal	Description
TARGETED	Indicates that a target has been selected and the munition has not been released yet. Report with the ENABLED state generated by ActivityStateEnum.
REQUESTED	Indicates the munition has been requested for release. Report with the ENABLED state generated by ActivityStateEnum.
SEEKER_INACTIVE	Indicates the munition has been released but its local seeker has not been activated. Report with the ACTIVE_* state generated by ActivityStateEnum.
SEEKER_ACTIVE	Indicates the munition has been released and its local seeker has been activated. Report with the ACTIVE_* state generated by ActivityStateEnum.
FUZE_INACTIVE	Indicates the munition has been released but its fuze has not been activated. Report with the ACTIVE_* state generated by ActivityStateEnum.
FUZE_ACTIVE	Indicates the munition has been released and its fuze has been activated. Report with the ACTIVE_* state generated by ActivityStateEnum.
NOT_FULLY_AUTONOMOUS	Indicates the munition has been released not fully autonomous and thus not able to guide without datalink or target destination. Report with the ACTIVE_* state generated by ActivityStateEnum.
FULLY_AUTONOMOUS	Indicates the munition has been released and is fully autonomous and able guide without datalink or target destination. Report with the ACTIVE_* state generated by ActivityStateEnum.
DEFEATED	Indicates the munition has been released and but it has been out maneuvered by the assigned target. Report with the COMPLETED state generated by ActivityStateEnum.
TIMED_OUT	Indicates the munition flight has ended, and it did not intercept the assigned target. Report with the COMPLETED state generated by ActivityStateEnum.
SUCCESS	Indicates the munition flight has ended, and it intercepted the assigned target. Report with the COMPLETED state generated by ActivityStateEnum.

Table A-4-776: Peer Interface MA_StrikeActivityMT - ActiveWeaponState UCI Extension Field

Activity	
Description	Indicates the dynamic operational characteristics of an Activity of a Strike Capability.
Base Type	MA_StrikeActivityType

Message Structure		
Field Name	Field Type	Field Usage
SelectedForKeyLoad	boolean	Required
Description	Key Load indicates the store has been put into a state where it is ready to receive cryptographic keys.	
WeaponArmed	boolean	Required
Description	When true, the weapon is in the armed state.	
ReadyForRelease	boolean	Required
Description	The store has been prepared for launch such that when released the store will function properly.	
SelectedForRelease	boolean	Required
Description	When Master Arm, Release Consent, and any LAR or vehicle Attitude parameters enforced by the carriage are all met, this store will be released.	
SelectedForJettison	boolean	Required
Description	Jettison indicates an ejection from the host system without powering or preparing the delivery vehicle. The store will be in an inert state. When Master Arm, Release Consent, and any LAR or vehicle attitude parameters enforced by the carriage are all met, this store will be jettisoned.	
AssignedTarget	GeoLocatedObjectType	Optional
Description	Indicates the Entity target assigned to the StrikeCapability.	
AO_Code	AO_CodeType	Optional
Description	Indicates the current/set AO/laser PRF and/or PIM code.	
LAR_ID	LAR_ID_Type	Optional
Description	Indicates the ID of the associated LAR and/or LAR_Report associated with the Strike capability.	
ConsentRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) the Activity requires consent to transition from the ENABLED state to an ACTIVE state. This element is required and shall be TRUE for Activities associated with "mother may I" Capabilities.	
ConsentState	ConsentEnum	Optional
Description	Indicates the state of consent for the Activity. This element is required for Activities which require Consent.	
KineticFootprint	EnduranceFootprintType	Optional
Description	The estimated footprint of where the store may fall if released from the current position.	
TargetLockAcquired	boolean	Optional
Description	Indicated whether (TRUE) or not (FALSE) a lock on target has been acquired.	
MunitionActive	MA_MunitionActiveType	Optional
Description	Data regarding the munition while it is active or in flight.	
TimeToRelease	DurationType	Optional

Description	Time interval before strike capability is released.
-------------	---

Table A-4-777: Peer Interface MA_StrikeActivityMT - Activity UCI Extension Field

Course		
Description	Defines course type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-778: Peer Interface MA_StrikeActivityMT - Course UCI Extension Field

Heading		
Description	Defines heading type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-779: Peer Interface MA_StrikeActivityMT - Heading UCI Extension Field

Reference	
Description	Reference to type of heading or course given.
Base Type	MA_HeadingReferenceEnum
Message Structure	
Enumeration Literal	Description
TRUE_NORTH	Heading value according to Geographic North.
MAGNETIC_NORTH	Heading value according to location where the planet's magnetic field points vertically downward.

Table A-4-780: Peer Interface MA_StrikeActivityMT - Reference UCI Extension Field

4.2.66 MA_StrikeCapabilityMT UCI Extension

MA_StrikeCapabilityMT	
Description	See annotations in child elements and messages/elements that use this type for details.

	See the XSD File for more info
Ext. Fields	MessageData : MA_StrikeCapabilityMDT

Table A-4-781: Peer Interface MA_StrikeCapabilityMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_StrikeCapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_StrikeCapabilityType	Repeated
Description	Indicates a Strike Capability provided by the Subsystem.	
Carriage	StoreCarriageCapabilityType	Repeated
Description	Optional list of carriage related to the StrikeCapability.	
Verification	StoreVerificationStatusType	Optional
Description	This is a rollup of all verification of each capability in this message.	
LoadoutMnemonic	VisibleString256Type	Optional
Description	Mnemonic representation of the store loadout that the reported strike capabilities and carriage support capabilities are derived from.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.	

Table A-4-782: Peer Interface MA_StrikeCapabilityMT - MessageData UCI Extension Field

4.2.67 MA_TaskCommandMT UCI Extension

MA_TaskCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details.
	See the XSD File for more info
Ext. Fields	MessageData : MA_TaskCommandMDT

Table A-4-783: Peer Interface MA_TaskCommandMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.

Base Type	MA_TaskCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Command	MA_TaskCommandType	Repeated
Description	Indicates an instance of a Task Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Capability CommandStatus message.	

Table A-4-784: Peer Interface MA_TaskCommandMT - MessageData UCI Extension Field

4.2.68 MA_TaskCommandStatusMT UCI Extension

MA_TaskCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_TaskCommandStatusMDT

Table A-4-785: Peer Interface MA_TaskCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_TaskCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-786: Peer Interface MA_TaskCommandStatusMT - MessageData UCI Extension Field

4.2.69 MA_COP_ConfigurationSettingsMT UCI Extension

MA_COP_ConfigurationSettingsMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_COP_ConfigurationSettingsMDT

Table A-4-787: Peer Interface MA_COP_ConfigurationSettingsMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_COP_ConfigurationSettingsMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApplicableToIDs	MA_PackageSystemType	Required
Description	Indicates the ID of the Package or System with the COP settings.	
COP_LeaderID	SystemID_Type	Optional
Description	Indicates the unique SystemID of the current leader of the COP.	
COP_LeaderBackupID	SystemID_Type	Repeated
Description	Indicates the unique SystemIDs of the backup leaders of the COP.	
COP_FusionCapable	boolean	Required
Description	Indicates if the COP is capable of fusing tracks.	
Configuration	MA_COP_ConfigurationType	Repeated
Description	A list of the configuration items.	

Table A-4-788: Peer Interface MA_COP_ConfigurationSettingsMT - MessageData UCI Extension Field

4.2.70 MA_OpCommandMT UCI Extension

MA_OpCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_OpCommandMDT

Table A-4-789: Peer Interface MA_OpCommandMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type

	for details.	
Base Type	MA_OpCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Command	MA_OpCommandType	Repeated
Description	Indicates an instance of an Op* command. An Op* command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Op* CommandStatus message.	

Table A-4-790: Peer Interface MA_OpCommandMT - MessageData UCI Extension Field

4.2.71 MA_OpCommandStatusMT UCI Extension

MA_OpCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_OpCommandStatusMDT

Table A-4-791: Peer Interface MA_OpCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-792: Peer Interface MA_OpCommandStatusMT - MessageData UCI Extension Field

4.2.72 MA_DeconflictionSolutionRequestStatusMT UCI Extension

MA_DeconflictionSolutionRequestStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_DeconflictionSolutionRequestStatusMDT

Table A-4-793: Peer Interface MA_DeconflictionSolutionRequestStatusMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_DeconflictionSolutionRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConflictID	MA_ConflictID_Type	Repeated
Description	List of conflict identifiers this message applies to	
RoutePlanID	RoutePlanID_Type	Optional
Description	A reference to the specific route plan being responded to	
DeconflictionProposalStatus	MA_DeconflictionProposalStatusEnum	Optional
Description	Indicates the status of response to the referenced proposed route plan	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-794: Peer Interface MA_DeconflictionSolutionRequestStatusMT - MessageData UCI Extension Field

4.2.73 MA_OpPlanMT UCI Extension

MA_OpPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_OpPlanMDT

Table A-4-795: Peer Interface MA_OpPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_OpPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpPlanID	MA_OpPlanID_Type	Required
Description	Indicates a unique ID assigned to the OpPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	MA_OpPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the OpPlan originated from.	
Plan	MA_OpPlanType	Required
Description	Contains the details of the Op* allocation plan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	

Table A-4-796: Peer Interface MA_OpPlanMT - MessageData UCI Extension Field

4.2.74 MA_RouteDeconflictionAlertMT UCI Extension

MA_RouteDeconflictionAlertMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RouteDeconflictionAlertMDT

Table A-4-797: Peer Interface MA_RouteDeconflictionAlertMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_RouteDeconflictionAlertMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConflictID	MA_ConflictID_Type	Required
Description	Indicates a unique identifier ID related to the path conflict for future reference	
ConflictData	MA_RouteDeconflictionAlertDataType	Repeated
Description	Conflict meta data providing relevant route IDs and location(s) of the conflict.	

Resolved	boolean	Required
Description	This element specifies whether this route conflict was resolved or not.	
ConflictPoint	Point2D_Type	Repeated
Description	This element identifies the location where a route conflict occurs.	

Table A-4-798: Peer Interface MA_RouteDeconflictionAlertMT - MessageData UCI Extension Field

4.2.75 MA_OpStatusMT UCI Extension

MA_OpStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_OpStatusMDT

Table A-4-799: Peer Interface MA_OpStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ExecutingPackageSystemIDs	MA_PackageSystemType	Required
Description	Identifies the Package ID or ACP System ID whose interpretation of the Op* status is reflected in this message. If Package ID is used, this includes all package member System IDs, so a member ACP's System ID does not need to be separately included.	
CurrentState	OpStateEnum	Required
Description	The state of the schedule (active or inactive) for which the defined schedule timeline applies.	
OpID	OpID_ChoiceType	Required
Description	Indicates the Op* being commanded. Leaving this blank makes the command apply to all Op* IDs	
CommandID	CommandID_Type	Repeated
Description	Indicates the unique ID of the Op* command resulting in this status.	

Table A-4-800: Peer Interface MA_OpStatusMT - MessageData UCI Extension Field

4.2.76 MA_DeconflictionSolutionRequestMT UCI Extension

MA_DeconflictionSolutionRequestMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info

Ext. Fields	MessageData : MA_DeconflictionSolutionRequestMDT
--------------------	--

Table A-4-801: Peer Interface MA_DeconflictionSolutionRequestMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_DeconflictionSolutionRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConflictID	MA_ConflictID_Type	Repeated
Description	List of conflict identifiers this message applies to	
ConflictStatus	MA_ConflictStatusEnum	Required
Description	Indicates the status of the current conflict	
Plan	MA_RoutePlanMDT	Required
Description	Contains the details of the proposed route plan.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-802: Peer Interface MA_DeconflictionSolutionRequestMT - MessageData UCI Extension Field

4.2.77 MA_PrioritizationListMT UCI Extension

MA_PrioritizationListMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ListType : MA_PrioritizationListEnum ListItem : MA_PrioritizationListItemType MessageData : MA_PrioritizationListMDT

Table A-4-803: Peer Interface MA_PrioritizationListMT UCI Extension

ListType	
Description	Indicates the type of prioritization list. For example, battlespace objects can be prioritized differently for targeting vs. protection as indicated by enumerates given in this element.
Base Type	MA_PrioritizationListEnum
Message Structure	
Enumeration Literal	Description

THREAT_TARGET_PRIORITIZATION_LIST	A prioritized list of battlespace objects or areas that are prioritized by an operational or tactical planner. For planning purposes, the ListItem associated with this enumeration could include, for example, an entity, a signal, a point or region.
CRITICAL_ASSET_LIST	A prioritized list of battlespace objects or areas that are prioritized by the joint force commander to be defended with the resources available. Critical assets are generally specific assets of such extraordinary importance that their loss or degradation would have a significant and debilitating effect on operations or the mission. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system or a point.
JIPTL	The Joint Integrated Prioritization Target List (JPITL) is a prioritized list of targets and associated data approved by the Joint Forces Commander or designated representative. An approved JIPTL is the central product of the target development cycle. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity or a system.
JIPTL_NOMINATION	A product of the target development phase is the JPITL nomination list. Targeters determine this list during the objectives, effects, and guidance phase and analyze which targets should be struck (or otherwise affected) to accomplish them. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity or a system.
JOINT_TARGET_LIST	A consolidated list of selected targets considered to have military significance in the combatant commander's area of responsibility. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system, a point, or area.
MISSION_TARGET_LIST	The list of battlespace targets that are considered to have military significance and are required for the successful completion of the mission. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system, a point, or area.
NO_STRIKE_LIST	A list of battlespace objects characterized as protected from the effects of military operations under international law or Engagement Criteria. Attacking these may violate Law of Armed Conflict (LOAC) or Engagement Criteria or interfere with friendly relations with indigenous personnel or governments. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system, a point, or area.
RESTRICTED_TARGET_LIST	A list of targets that have specific restrictions imposed upon them. Actions on restricted targets are prohibited until coordinated and approved by the establishing authority. Targets are restricted because certain types of actions against them may have negative political, cultural, or propaganda implications, or may interfere with projected friendly operations. The Restricted Target List (RTL) is nominated by elements of the joint force and approved by the JFC. Targets on this list may only be struck with JFC or higher approval. Actions taken by an opponent may remove a target from the RTL. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system, a point, or area.
DEFENDED_ASSET_LIST	The Defended Asset List (DAL) is a listing of those assets from the critical asset list prioritized by the joint force commander to be

	defended with the resources available. Critical assets that are reinforced with additional protection capabilities or capabilities from other combat power elements become part of the DAL. It represents what can be protected, by priority. The DAL allows commanders to apply finite protection capabilities to the most valuable assets.
PLATFORM_TARGET_LIST	A list of active entity platform targets that meet custody requirements. This list type is used in support of presenting a shot queue prioritization list with List Item of EntityID in accordance with the mission common operating picture.

Table A-4-804: Peer Interface MA_PrioritizationListMT - ListType UCI Extension Field

ListItem		
Description	Indicates an item in a prioritization list of the sibling ListType.	
Base Type	MA_PrioritizationListItemType	
Message Structure		
Field Name	Field Type	Field Usage
Subject	IdentityKindInstanceType	Required
Description	Indicates the subject of the prioritization list item.	
Priority	PrioritizationType	Repeated
Description	Indicates the priority of the item. If priority for any child PriorityType is given, then omitted PriorityTypes for the sibling Subject have no/zero priority. No duplicates allowed; at most one instance of each of the child PriorityTypes is allowed. If the child PriorityType is not used, only one instance is allowed.	
ProbabilityOfKill	PercentType	Optional
Description	Indicates the probability of kill, in a percentage where a value of 100.0 = 100%, of a selected target with an available capability.	
ObjectCorrelation	ObjectCorrelationType	Optional
Description	Object Correlation contains a description of the correlation of this object with another object as well as whether the correlating system has C2 responsibilities or not, to indicate a rough level of confidence in the information.	

Table A-4-805: Peer Interface MA_PrioritizationListMT - ListItem UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PrioritizationListMDT	
Message Structure		
Field Name	Field Type	Field Usage
PrioritizationListID	PrioritizationListID_Type	Required
Description	Indicates the unique ID of the prioritization list.	
ListType	MA_PrioritizationListEnum	Required
Description	Indicates the type of prioritization list. For example, battlespace objects can be prioritized differently for targeting vs. protection as indicated by enumerates given in	

	this element.	
ListItem	MA_PrioritizationListItemType	Repeated
Description	Indicates an item in a prioritization list of the sibling ListType.	
OpOrderTraceability	OrderTraceabilityType	Repeated
Description	Indicates an operational order which this PrioritizationList is traceable to. This does not mean ranking. This element refers to a Planning Order, Commander's Intent, or other Order that came from a higher echelon. The higher echelon is identified by the OrderSourceID.	
OpDescription	OpDescriptionType	Optional
Description	Indicates a human readable description of the purpose of the prioritization list.	
ApplicableSystemID	SystemID_Type	Repeated
Description	One or more Systems to which the prioritization applies. If omitted, the prioritization applies to all Systems.	
ApplicableServiceID	ServiceID_Type	Repeated
Description	One or more Services to which the mission response list applies. If omitted, the settings apply to all Services of the Systems given in the sibling ApplicableSystemID.	
ApplicableZone	ZoneType	Optional
Description	Zones to which the prioritization applies.	
Schedule	ScheduleType	Optional
Description	Scheduled times to which the prioritization applies.	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-806: Peer Interface MA_PrioritizationListMT - MessageData UCI Extension Field

4.2.78 MA_MissionPlanActivationStatusMT UCI Extension

MA_MissionPlanActivationStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	OpPlanID : MA_OpPlanID_Type MessageData : MA_MissionPlanActivationStatusMDT Plans : MA_PlansReferenceBaseType SubPlanActivationState : MA_PlanActivationStateType

Table A-4-807: Peer Interface MA_MissionPlanActivationStatusMT UCI Extension

OpPlanID	
Description	Indicates a reference to an OpPlan.

Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-808: Peer Interface MA_MissionPlanActivationStatusMT - OpPlanID UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanActivationStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	The ID of the MissionPlan this status pertains to.	
PlanActivationState	PlanActivationStateEnum	Required
Description	Indicates the activation state of the MissionPlan.	
SubPlanActivationState	MA_PlanActivationStateType	Repeated
Description	Indicates the activation state of a SubPlan or SubPlans of the associated MissionPlan. An instance of this element should include all of the SubPlans in a given state; the cardinality is based in the number of states in the associated activation state enumerated type.	

Table A-4-809: Peer Interface MA_MissionPlanActivationStatusMT - MessageData UCI Extension Field

Plans		
Description	Indicates the Plan or Plans in the sibling ActivationState.	
Base Type	MA_PlansReferenceBaseType	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	

OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-810: Peer Interface MA_MissionPlanActivationStatusMT - Plans UCI Extension Field

SubPlanActivationState		
Description	Indicates the activation state of a SubPlan or SubPlans of the associated MissionPlan. An instance of this element should include all of the SubPlans in a given state; the cardinality is based in the number of states in the associated activation state enumerated type.	
Base Type	MA_PlanActivationStateType	
Message Structure		
Field Name	Field Type	Field Usage
ActivationState	PlanActivationStateEnum	Required
Description	Indicates an activation state that one or more *Plans is in.	
Plans	MA_PlansReferenceBaseType	Required
Description	Indicates the Plan or Plans in the sibling ActivationState.	

Table A-4-811: Peer Interface MA_MissionPlanActivationStatusMT - SubPlanActivationState UCI Extension Field

4.2.79 MA_ActionCommandMT UCI Extension

MA_ActionCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	ActionConstraintOverride : MA_ActionConstraintType

	RequiredAllocation : MA_RequirementAllocationConstraintType System : MA_SystemFilterType PreferredAllocation : MA_RequirementAllocationConstraintType Analytic : MA_AnalyticConstraintsType Designation : MA_DesignationFilterType AssessedObject : MA_AssetFilterType Characteristics : MA_EntityComparativeType Allocation : MA_AllocationChoiceType ConstraintOverride : MA_RequirementConstraintsType Allocation : MA_RequirementAllocationParametersType AccessAssessmentThreshold : MA_AccessAssessmentFilterType Command : MA_ActionCommandType ExcludedRequirementTypes : MA_RequirementTaxonomyType Kinematic : MA_RequirementKinematicConstraintsType EngagementParameters : MA_EngagementParametersType Subject : MA_AssetFilterType MessageData : MA_ActionCommandMDT AllowedRequirementTypes : MA_RequirementTaxonomyType Entity : MA_EntityFilterType
--	---

Table A-4-812: Peer Interface MA_ActionCommandMT UCI Extension

ActionConstraintOverride		
Description		Indicates refined/overridden values of constraints for the Action. Added to allow similar override options in direct commanding as is available in planning.
Base Type		MA_ActionConstraintType
Message Structure		
Field Name	Field Type	Field Usage
TargetObject	IdentityKindInstanceType	Repeated
Description	Indicates the target of the Action; the object the Action will be done to or for. If omitted, the Action places no explicit limitation on which TargetObject it can be done to. See sibling ActionType element annotation for an overall description of Action structure. Note that the term "target" is used in a general sense. For some Requirement types, a more suitable term might be "subject", "point", "location", etc. For example, the "target" of a COVER Action could be a blue/friendly System.	
TargetObjectConstraints	RequirementTargetConstraintsType	Optional
Description	Indicates constraints "on" the TargetObject that must be satisfied before the Action can be done to or for it. See sibling ActionType element annotation for an overall description of Effect structure.	
SecondaryObject	IdentityKindInstanceType	Repeated

Description	Indicates a thing the sibling TargetObject must act on/against/toward to make the Action applicable. See sibling ActionType element annotation for an overall description of Action structure.	
PerTargetEngagementParameters	MA_EngagementParametersOrDefaultChoiceType	Repeated
Description	Indicates a command to change the engagement parameters corresponding to an ongoing tactic. This field is meant to be used on a per target basis. Setting this field overrides the engagement parameters sent in MA_Action, and Activity modification by ChangeEngagement, and any previous audibles that modified MA_EngagementParameters for the sibling TargetObject.	

Table A-4-813: Peer Interface MA_ActionCommandMT - ActionConstraintOverride UCI Extension Field

RequiredAllocation		
Description	Indicates the system and optionally Capability that the Requirement (Effect, Action, Task, [Capability]Command, Response) MUST be allocated to during the allocation process. The system can be an explicit UCI System or implied UCI System (by Identity, hosted Capability, kinematics, etc.) in which case the associated UCI System must be determined as part of the allocation process. If multiple child elements are given: 1) allocation to any one of the associated Systems is the minimum expectation, 2) decomposition of the Requirement into multiple child Requirements allocated across the associated Systems is acceptable, 3) there is no expectation that each associated System must perform the Requirement. This element allows the Requirement creator to force an allocation to a specific system at the risk of 1) a less than optimal overall solution or 2) failure of the Requirement being allocated despite availability of another suitable system.	
Base Type	MA_RequirementAllocationConstraintType	
Message Structure		
Field Name	Field Type	Field Usage
Allocation	MA_AllocationChoiceType	Required
Description	Indicates the type of Allocation, either by direct assignment of SystemIDs or by PackageID definition for delegation.	
Identity	IdentityType	Repeated
Description	Indicates a kind/type or instance of platform/system that is the target of the allocation constraint. For example, this element could be used to allocate a Requirement to any fighter aircraft platform, or a specific kind of fighter aircraft, or a specific tail number of aircraft, or an aircraft with an aircrew member with a certain voice call sign.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates the CapabilityID of the Capability that is the target of the allocation constraint. If multiple required Capabilities are given: 1) allocation to any one of the Capabilities is the minimum expectation, 2) decomposition of the Requirement into multiple child Requirements allocated across the multiple required Capabilities is acceptable, 3) there is no expectation that each Capability must perform the Requirement.	

Table A-4-814: Peer Interface MA_ActionCommandMT - RequiredAllocation UCI Extension Field

System	
Description	Indicates a filter on characteristics of a System asset. The asset filter is

	satisfied if a match is found in this element OR the sibling Entity element.	
Base Type	MA_SystemFilterType	
Message Structure		
Field Name	Field Type	Field Usage
Characteristics	MA_SystemComparativeType	Repeated
Description	This element indicates a System filter requiring a variable logical comparator test between a value in a System-associated message and the value given here. Multiple instances are logically ANDed.	
SystemID	SystemID_Type	Repeated
Description	Indicates a specific SystemID that is required to match the filter. If omitted, any SystemID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the System must fall within to satisfy the clause. Multiple instances are logically ORed.	
OrbitalFilter	OrbitalFiltersQueryType	Repeated
Description	Indicates a zone the System must fall within to satisfy the clause. Multiple instances are logically ORed.	

Table A-4-815: Peer Interface MA_ActionCommandMT - System UCI Extension Field

PreferredAllocation		
Description	Indicates the system and optionally Capability that the Requirement (Effect, Action, Task, [Capability]Command, Response) should be allocated to during the allocation process. The system can be an explicit UCI System or implied UCI System (by Identity, hosted Capability, kinematics, etc.) in which case the associated UCI System must be determined as part of the allocation process. If multiple child elements are given: 1) allocation to any one of the associated Systems is the minimum expectation, 2) decomposition of the Requirement into multiple child Requirements allocated across the associated Systems is acceptable, 3) there is no expectation that each associated System must perform the Requirement. This element allows the Requirement creator to suggest an allocation to a specific system at the risk of 1) a less than optimal overall solution or 2) failure of the Requirement being allocated despite availability of another suitable system.	
Base Type	MA_RequirementAllocationConstraintType	
Message Structure		
Field Name	Field Type	Field Usage
Allocation	MA_AllocationChoiceType	Required
Description	Indicates the type of Allocation, either by direct assignment of SystemIDs or by PackageID definition for delegation.	
Identity	IdentityType	Repeated
Description	Indicates a kind/type or instance of platform/system that is the target of the allocation constraint. For example, this element could be used to allocate a Requirement to any fighter aircraft platform, or a specific kind of fighter aircraft, or a specific tail number of	

	aircraft, or an aircraft with an aircrew member with a certain voice call sign.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates the CapabilityID of the Capability that is the target of the allocation constraint. If multiple required Capabilities are given: 1) allocation to any one of the Capabilities is the minimum expectation, 2) decomposition of the Requirement into multiple child Requirements allocated across the multiple required Capabilities is acceptable, 3) there is no expectation that each Capability must perform the Requirement.	

Table A-4-816: Peer Interface MA_ActionCommandMT - PreferredAllocation UCI Extension Field

Analytic		
Description	Indicates a constraint in the form of an analytic measure that the Requirement must satisfy when planned/executed.	
Base Type	MA_AnalyticConstraintsType	
Message Structure		
Field Name	Field Type	Field Usage
OpConstraint	OpConstraintWeightingType	Repeated
Description	Indicates an operational constraint to achieve. The multiplicity is based on the list of available OpConstraintEnums.	
RiskSetting	SurvivabilityRiskSettingType	Repeated
Description	Identifies the Risk Level constraint for each provided RiskPrioritization (max of 4).	
AccessAssessmentThreshold	MA_AccessAssessmentFilterType	Optional
Description	Indicates access assessment analysis event thresholds.	
RF_TaskPerformance	RF_TaskPerformanceType	Optional
Description	Mission specific RF performance objective.	

Table A-4-817: Peer Interface MA_ActionCommandMT - Analytic UCI Extension Field

Designation		
Description	Indicates a type of Entity designation, established by the Designation message, required to satisfy the filter.	
Base Type	MA_DesignationFilterType	
Message Structure		
Field Name	Field Type	Field Usage
DesignationType	DesignationEnum	Repeated
Description	Indicates a type of designation required to match the filter. List size for this element is based on "Select All That Apply" condition.	
DesignationObjective	MA_RequirementTaxonomyType	Optional
Description	Indicates objective or objectives that the designation must include to match the filter. When omitted, the designation objective is irrelevant for the filter.	

Table A-4-818: Peer Interface MA_ActionCommandMT - Designation UCI Extension Field

AssessedObject

Description	Indicates Assessed Objects of the AccessAssessment that are required to match the filter. If omitted, any Assessed Object satisfies the filter.	
Base Type	MA_AssetFilterType	
Message Structure		
Field Name	Field Type	Field Usage
System	MA_SystemFilterType	Optional
Description	Indicates a filter on characteristics of a System asset. The asset filter is satisfied if a match is found in this element OR the sibling Entity element.	
Entity	MA_EntityFilterType	Optional
Description	Indicates a filter on characteristics of an Entity asset. The asset filter is satisfied if a match is found in this element OR the sibling System element.	

Table A-4-819: Peer Interface MA_ActionCommandMT - AssessedObject UCI Extension Field

Characteristics		
Description	This element indicates an Entity filter requiring a variable logical comparator test between a value in an Entity-associated message and the value given here. Multiple instances are logically ANDed.	
Base Type	MA_EntityComparativeType	
Message Structure		
Field Name	Field Type	Field Usage
Characteristic	MA_EntityCharacteristicType	Required
Description	Indicates a characteristic/element value to be used to compare to the corresponding value of the Entity or related message.	
Comparator	EqualityExpressionEnum	Required
Description	Indicates the logical comparator to use when comparing the target (Entity or related message) Characteristic to the Response Characteristic. The logical expression is: (target Characteristic) (Comparator) (Response Characteristic). When the logical expression is TRUE then the parent TargetClause instance is TRUE.	

Table A-4-820: Peer Interface MA_ActionCommandMT - Characteristics UCI Extension Field

Allocation		
Description	Indicates the type of Allocation, either by direct assignment of SystemIDs or by PackageID definition for delegation.	
Base Type	MA_AllocationChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Repeated
Description	Indicates the SystemID(s) of the System that is the target of the allocation constraint.	
PackageID	PackageID_Type	Required
Description	Indicates the unique ID of the package for delegation of Systems.	

Table A-4-821: Peer Interface MA_ActionCommandMT - Allocation UCI Extension Field

ConstraintOverride		
Description		Indicates refined/overridden values of constraints for the Action. Added to allow similar override options in direct commanding as is available in planning.
Base Type		MA_RequirementConstraintsType
Message Structure		
Field Name	Field Type	Field Usage
Rank	ComparableRankingType	Optional
Description	Indicates a constraint in the form of the Rank of the associated Requirement (Effect, Action, Task, [Capability]Command or Response).	
InterruptLowerRank	boolean	Optional
Description	Indicates whether a) an in-work/planned item or items of a lower rank should be interrupted/replanned in order to address this item (TRUE) or b) this item should be simply queued/planned according to rank without interrupting in-work/planned items (FALSE). For example, a Task being added to an existing TaskPlan (TaskPlanCommand constrained by an existing TaskPlan) would potentially cause unlocked Tasks of lower rank in the existing TaskPlan to be unallocated if 1) this element indicated TRUE and 2) the lower ranked Tasks prevented the higher ranked Task from being allocated.	
Allocation	MA_RequirementAllocationParametersType	Optional
Description	Indicates allocation related constraints which can vary by Requirement at the discretion of the creator.	
Timing	RequirementTimingType	Repeated
Description	Indicates a temporal constraint on the Requirement. Allows for defining for each timing type (RequirementTimingEnum).	
Kinematic	MA_RequirementKinematicConstraintsType	Repeated
Description	Indicates a constraint in the form of kinematic position of Requirement actor or actors. When more than one is given they are logically ANDed.	
Dependency	RequirementDependencyType	Repeated
Description	Indicates a constraint in the form of a temporal dependency between Requirements; between Effect, Action, Task, [Capability]Command or Commands or Response. If more than one is given, they are logically ANDed. For example, a pre-strike image collection (PO Task) might be required several minutes prior to a strike (Strike Task) to determine combat ID and target coordinates. A post-strike image collection (PO Task) might be required several minutes after the strike to inform battle damage assessment. The dependency between the three Tasks can be established with this element. Assuming the Strike Task is the most difficult to plan/coordinate, the other two Tasks would likely each have dependencies on the Strike Task in	

	order to orchestrate the desired "look-shoot-look" sequence.	
MaxProductDisseminationClassificationLevel	DataProductClassificationLevelType	Optional
Description	Indicates the maximum allowed classification level of the networks that the allocated system can disseminate products to for this task. The allocated system must have a dissemination route for data at this classification or lower. For example, when trying to collect data to hand-off to an unclassified system or network, the allocated system has to be able to generate products at no higher than the specified level and have the authority to disseminate on a network at no higher than the specified classification level.	
Analytic	MA_AnalyticConstraintsType	Optional
Description	Indicates a constraint in the form of an analytic measure that the Requirement must satisfy when planned/executed.	
AcceptableClassificationLevel	SecurityInformationType	Optional
Description	Indicates a constraint on the highest acceptable classification level at which the Response can be planned and executed.	
CommsRequired	boolean	Optional
Description	Indicates whether or not communications are required when executing the Requirement. In this context, "required" means the creator or a Requirement considers communications as necessary for C2 and/or Product dissemination related to this Requirement, independent of the type of vehicle that it is allocated to. This element may result in consideration of communications allocations during Requirement allocation.	
AllowedRequirementTypes	MA_RequirementTaxonomyType	Optional
Description	Indicates other types of Requirements that can be decomposed from, used to plan, used to implement, inherited from traced parents or otherwise associated with the subject Requirement.	
ExcludedRequirementTypes	MA_RequirementTaxonomyType	Optional
Description	Indicates other types of Requirements that cannot be decomposed from, used to plan, used to implement, inherited from traced parents or otherwise be associated with the subject Requirement.	
ConstraintsNarrative	VisibleString1024Type	Optional
Description	Free-text explanation of sibling constraints, additional extraordinary constraints, etc.	
AllowedDomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates an allowed domain/environment which the Requirement can be employed from and allowed "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
ExcludedDomainPairing	EnvironmentPairingEnum	Repeated

Description	Indicates an excluded domain/environment which the Requirement can't be employed from an excluded "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
EngagementParameters	MA_EngagementParametersType	Optional
Description	Provides engagement parameters that this requirement should adhere to.	

Table A-4-822: Peer Interface MA_ActionCommandMT - ConstraintOverride UCI Extension Field

Allocation		
Description	Indicates allocation related constraints which can vary by Requirement at the discretion of the creator.	
Base Type	MA_RequirementAllocationParametersType	
Message Structure		
Field Name	Field Type	Field Usage
RequiredAllocation	MA_RequirementAllocationConstraintType	Optional
Description	Indicates the system and optionally Capability that the Requirement (Effect, Action, Task, [Capability]Command, Response) MUST be allocated to during the allocation process. The system can be an explicit UCI System or implied UCI System (by Identity, hosted Capability, kinematics, etc.) in which case the associated UCI System must be determined as part of the allocation process. If multiple child elements are given: 1) allocation to any one of the associated Systems is the minimum expectation, 2) decomposition of the Requirement into multiple child Requirements allocated across the associated Systems is acceptable, 3) there is no expectation that each associated System must perform the Requirement. This element allows the Requirement creator to force an allocation to a specific system at the risk of 1) a less than optimal overall solution or 2) failure of the Requirement being allocated despite availability of another suitable system.	
PreferredAllocation	MA_RequirementAllocationConstraintType	Optional
Description	Indicates the system and optionally Capability that the Requirement (Effect, Action, Task, [Capability]Command, Response) should be allocated to during the allocation process. The system can be an explicit UCI System or implied UCI System (by Identity, hosted Capability, kinematics, etc.) in which case the associated UCI System must be determined as part of the allocation process. If multiple child elements are given: 1) allocation to any one of the associated Systems is the minimum expectation, 2) decomposition of the Requirement into multiple child Requirements allocated across the associated Systems is acceptable, 3) there is no expectation that each associated System must perform the Requirement. This element allows the Requirement creator to suggest an allocation to a specific system at the risk of 1) a less than optimal overall solution or 2) failure of the Requirement being allocated despite availability of another suitable system.	

Table A-4-823: Peer Interface MA_ActionCommandMT - Allocation UCI Extension Field

AccessAssessmentThreshold	
Description	Indicates access assessment analysis event thresholds.
Base Type	MA_AccessAssessmentFilterType
Message Structure	

Field Name	Field Type	Field Usage
AssessmentName	VisibleString32Type	Repeated
Description	Indicates a name/type of AccessAssessment algorithm required to match the filter. If omitted, any name/type of AccessAssessment algorithm satisfies the filter.	
AssessedCapabilities	CapabilityTaxonomyUniversalType	Optional
Description	Indicates assessed Capabilities of the AccessAssessment that are required to match the filter. If omitted, any assessed Capability satisfies the filter.	
Subject	MA_AssetFilterType	Optional
Description	Indicates Subjects of the AccessAssessment that are required to match the filter. If omitted, any Subject satisfies the filter.	
AssessedObject	MA_AssetFilterType	Optional
Description	Indicates Assessed Objects of the AccessAssessment that are required to match the filter. If omitted, any Assessed Object satisfies the filter.	
AccessEvent	AccessEventFilterType	Repeated
Description	Indicates Access Event details necessary to match the filter. If omitted, any Access Event satisfies the filter. Multiple instances are logically ORed.	

Table A-4-824: Peer Interface MA_ActionCommandMT - AccessAssessmentThreshold UCI Extension Field

Command		
Description	Indicates an instance of an Action Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Capability CommandStatus message.	
Base Type	MA_ActionCommandType	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_ActionCapabilityCommandType	Required
Description	Indicates a new invocation of an Action Capability. Generally, if accepted, the command will result in one or more new Action Activities being created and reported via the ActionActivity message. The request/response interaction terminates as soon as the command is accepted or rejected; this element is not used to interact with an "active" command. Updates and/or additional interaction with the resulting Activity (after the command is accepted) is accomplished via the sibling Activity element.	
Activity	MA_ActivityCommandBaseType	Required
Description	Indicates a command to modify an existing Action Activity (which was previously reported via the ActionActivity message and was marked as "interactive"). The request/response interaction terminates as soon as the modification is accepted or rejected. The modifications are reflected in subsequent ActionActivity messages.	

Table A-4-825: Peer Interface MA_ActionCommandMT - Command UCI Extension Field

ExcludedRequirementTypes	
Description	Indicates other types of Requirements that cannot be decomposed from, used to plan, used to implement, inherited from traced parents or otherwise be

	associated with the subject Requirement.	
Base Type	MA_RequirementTaxonomyType	
Message Structure		
Field Name	Field Type	Field Usage
Effect	EffectTypeEnum	Repeated
Description	Indicates Effects applicable via the Effect* message set. List size for this element is based on "Select All That Apply" condition.	
Action	MA_ActionTypeEnum	Repeated
Description	Indicates Actions applicable via the Action* message set. List size for this element is based on "Select All That Apply" condition.	
Task	MA_TaskTypeEnum	Repeated
Description	Indicates Tasks applicable via the Task* message set. List size for this element is based on "Select All That Apply" condition.	
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates CapabilityCommands applicable via a [Capability]Command message set. List size for this element is based on "Select All That Apply" condition.	
Response	ResponseTypeEnum	Repeated
Description	Indicates Responses applicable via the Response* message set. List size for this element is based on "Select All That Apply" condition.	

Table A-4-826: Peer Interface MA_ActionCommandMT - ExcludedRequirementTypes UCI Extension Field

Kinematic		
Description	Indicates a constraint in the form of kinematic position of Requirement actor or actors. When more than one is given they are logically ANDed.	
Base Type	MA_RequirementKinematicConstraintsType	
Message Structure		
Field Name	Field Type	Field Usage
ApplicableObject	RequirementObjectEnum	Required
Description	Indicates which Requirement actor the sibling kinematic constraints are applicable to.	
Geo	GeoFiltersQueryType	Repeated
Description	This element gives a geographical filter to the query.	
Orbital	OrbitalFiltersQueryType	Repeated
Description	This element gives an orbital filter to the query.	
LookAngleConstraints	AnglePairType	Optional
Description	The angle from true north to the line-of-sight vector from the platform to the target tangent plane.	

Table A-4-827: Peer Interface MA_ActionCommandMT - Kinematic UCI Extension Field

EngagementParameters	
Description	Provides engagement parameters that this requirement should adhere to.

Base Type	MA_EngagementParametersType	
Message Structure		
Field Name	Field Type	Field Usage
InterceptTactic	MA_InterceptTacticChoiceType	Optional
Description	The type of intercept tactic to be employed. Used in combination with shot parameters to define tactics like Skate or Banzai.	
ShotParameters	MA_ShotParametersType	Optional
Description	Provides shot parameters that this requirement should adhere to.	
EnableTargetRecalculation	boolean	Optional
Description	This field specifies that MA should recalculate optimal targets during the engagement.	

Table A-4-828: Peer Interface MA_ActionCommandMT - EngagementParameters UCI Extension Field

Subject		
Description	Indicates Subjects of the AccessAssessment that are required to match the filter. If omitted, any Subject satisfies the filter.	
Base Type	MA_AssetFilterType	
Message Structure		
Field Name	Field Type	Field Usage
System	MA_SystemFilterType	Optional
Description	Indicates a filter on characteristics of a System asset. The asset filter is satisfied if a match is found in this element OR the sibling Entity element.	
Entity	MA_EntityFilterType	Optional
Description	Indicates a filter on characteristics of an Entity asset. The asset filter is satisfied if a match is found in this element OR the sibling System element.	

Table A-4-829: Peer Interface MA_ActionCommandMT - Subject UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActionCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Command	MA_ActionCommandType	Repeated
Description	Indicates an instance of an Action Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Capability CommandStatus message.	

Table A-4-830: Peer Interface MA_ActionCommandMT - MessageData UCI Extension Field

AllowedRequirementTypes	
Description	Indicates other types of Requirements that can be decomposed from, used to

	plan, used to implement, inherited from traced parents or otherwise associated with the subject Requirement.	
Base Type	MA_RequirementTaxonomyType	
Message Structure		
Field Name	Field Type	Field Usage
Effect	EffectTypeEnum	Repeated
Description	Indicates Effects applicable via the Effect* message set. List size for this element is based on "Select All That Apply" condition.	
Action	MA_ActionTypeEnum	Repeated
Description	Indicates Actions applicable via the Action* message set. List size for this element is based on "Select All That Apply" condition.	
Task	MA_TaskTypeEnum	Repeated
Description	Indicates Tasks applicable via the Task* message set. List size for this element is based on "Select All That Apply" condition.	
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates CapabilityCommands applicable via a [Capability]Command message set. List size for this element is based on "Select All That Apply" condition.	
Response	ResponseTypeEnum	Repeated
Description	Indicates Responses applicable via the Response* message set. List size for this element is based on "Select All That Apply" condition.	

Table A-4-831: Peer Interface MA_ActionCommandMT - AllowedRequirementTypes UCI Extension Field

Entity		
Description	Indicates a filter on characteristics of an Entity asset. The asset filter is satisfied if a match is found in this element OR the sibling System element.	
Base Type	MA_EntityFilterType	
Message Structure		
Field Name	Field Type	Field Usage
Designation	MA_DesignationFilterType	Optional
Description	Indicates a type of Entity designation, established by the Designation message, required to satisfy the filter.	
Characteristics	MA_EntityComparativeType	Repeated
Description	This element indicates an Entity filter requiring a variable logical comparator test between a value in an Entity-associated message and the value given here. Multiple instances are logically ANDed.	
EntityID	EntityID_Type	Repeated
Description	Indicates a specific EntityID that is required to match the filter. If omitted, any EntityID satisfies the filter. Multiple instances are logically ORed.	
Source	EntitySourceEnum	Repeated
Description	Indicates an Entity source that is required to match the filter. If omitted, any Entity source satisfies the filter. Multiple instances are logically ORed. List size for this	

	element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the Entity must fall within to satisfy the filter. Multiple instances are logically ORed.	
OrbitalFilter	OrbitalFiltersQueryType	Repeated
Description	Indicates a zone the Entity must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-832: Peer Interface MA_ActionCommandMT - Entity UCI Extension Field

4.2.80 MA_ActionCommandStatusMT UCI Extension

MA_ActionCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ActionCommandStatusMDT

Table A-4-833: Peer Interface MA_ActionCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActionCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-834: Peer Interface MA_ActionCommandStatusMT - MessageData UCI Extension Field

4.2.81 MA_ActionStatusMT UCI Extension

MA_ActionStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	Traceability : MA_RequirementStatusTraceabilityType Plans : MA_PlansReferenceType OpPlanID : MA_OpPlanID_Type MessageData : MA_ActionStatusMDT ExecutingSystemOrPackage : MA_PackageSystemType

Table A-4-835: Peer Interface MA_ActionStatusMT UCI Extension

Traceability		
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture.	
	For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.	
Base Type	MA_RequirementStatusTraceabilityType	
Message Structure		
Field Name	Field Type	Field Usage
Plans	MA_PlansReferenceType	Optional
Description	Indicates *Plans the Requirement is associated with.	
PlannedActivityID	PlannedActivityID_Type	Repeated
Description	Indicates a specific Planned Activity the Requirement is associated with.	
CapabilityID	CapabilityID_Type	Repeated
Description	Identifies a specific Capability the Requirement is associated with.	
CommandID	CommandID_Type	Repeated
Description	Indicates the ID of an associated [Capability]Command.	
ActivityID	ActivityID_Type	Repeated
Description	Indicates the ID of an associated actual/executing/executed Activity.	

Table A-4-836: Peer Interface MA_ActionStatusMT - Traceability UCI Extension Field

Plans		
Description	Indicates *Plans the Requirement is associated with.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-837: Peer Interface MA_ActionStatusMT - Plans UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new	

	version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-838: Peer Interface MA_ActionStatusMT - OpPlanID UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActionStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ActionID	ActionID_Type	Required
Description	Indicates the unique ID of the Action whose execution status is given by sibling elements.	
ExecutingSystemOrPackage	MA_PackageSystemType	Required
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
ExecutionState	RequirementExecutionStateEnum	Required
Description	Identifies the state of the Requirement.	
ExecutionStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling State element. This element is only expected when the State is in a potentially undesirable state such as failed or completed with less than optimum results. It is strongly encouraged for transitions to failed or dropped.	
ActualTiming	RequirementTimingType	Repeated
Description	Indicates actual timing status for the Requirement. Allows for defining for each timing type (RequirementTimingEnum).	
PercentCompleted	PercentType	Optional
Description	Percentage of assigned Requirement completion. The percentage increments until the Requirement has COMPLETED or FAILED. A percent complete of 0 indicates the Requirement has not yet begun execution, and a failed Requirement may have any percentage between 1 - 99.	
Traceability	MA_RequirementStatusTraceabilityType	Optional
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture.	

	For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.	
Metrics	MetricsType	Optional
Description	Specifies the actual metrics associated with the Requirements.	

Table A-4-839: Peer Interface MA_ActionStatusMT - MessageData UCI Extension Field

ExecutingSystemOrPackage		
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-840: Peer Interface MA_ActionStatusMT - ExecutingSystemOrPackage UCI Extension Field

4.2.82 MA_AssessmentMT UCI Extension

MA_AssessmentMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_AssessmentMDT Assessment : MA_AssessmentType

Table A-4-841: Peer Interface MA_AssessmentMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type

	for details.	
Base Type	MA_AssessmentMDT	
Message Structure		
Field Name	Field Type	Field Usage
AssessmentID	AssessmentID_Type	Required
Description	This element references the assessment ID.	
AssessmentRequestID	RequestID_Type	Optional
Description	This element is required when the message is generated in response to an AssessmentRequest. It is omitted when the message is generated unsolicited.	
AnalysisRouteID	AnalysisRouteID_Type	Optional
Description	This element indicates the AnalysisRoute that was used to perform the assessment.	
Assessment	MA_AssessmentType	Required
Description	This element indicates the results of the assessment.	

Table A-4-842: Peer Interface MA_AssessmentMT - MessageData UCI Extension Field

Assessment		
Description	This element indicates the results of the assessment.	
Base Type	MA_AssessmentType	
Message Structure		
Field Name	Field Type	Field Usage
CommPointingPlan	CommPointingPlanAssessmentType	Required
Description	This element defines the response to a communications pointing plan assessment request.	
CapabilityUtilization	CapabilityUtilizationAssessmentType	Required
Description	This assessment type is utilized to assess predicted capability utilization along a mission planned route.	
RouteDeconfliction	RouteDeconflictionAssessmentType	Required
Description	This element defines the response to a route deconfliction assessment request.	
RouteVulnerabilityMetrics	RouteVulnerabilityMetricsAssessmentType	Required
Description	Indicates the results of assessment of vulnerability along a route.	
RouteThreatAssessment	RouteThreatAssessmentType	Required
Description	Indicates the results of assessment of threats along a route.	
TargetMobility	TargetMobilityAssessmentType	Required
Description	This element defines the response to a target mobility assessment request.	
VehicleThreatAssessment	VehicleThreatAssessmentType	Required
Description	This element defines the response to a vehicle threat assessment request.	
ThreatNominationAssessment	ThreatNominationAssessmentType	Required

Description	This element defines the response to a threat nomination assessment.	
AchievabilityAssessment	AchievabilityAssessmentPET	Required
Description	This element defines the response to an achievability assessment.	
CoverageAssessment	MA_CoverageAssessmentType	Required
Description	This element defines the response to a coverage assessment.	

Table A-4-843: Peer Interface MA_AssessmentMT - Assessment UCI Extension Field

4.2.83 MA_AssessmentRequestMT UCI Extension

MA_AssessmentRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_AssessmentRequestMDT Category : MA_AssessmentRequestType

Table A-4-844: Peer Interface MA_AssessmentRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_AssessmentRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
AnalysisRouteID	AnalysisRouteID_Type	Optional
Description	This element indicates the AnalysisRoute to use when performing the Assessment specified in sibling Category.	
RequestFrequencyType	RepeatEnum	Required
Description	Indicates whether this request for assessment is a request for a single reply, or a request for periodic assessments with a corresponding request to cease periodic assessments.	
RequestFrequencyPeriod	DurationType	Optional
Description	If requesting periodic assessments, this field specifies the amount of time that should elapse between the periodic assessments, i.e. the repetition time interval of the assessment.	
ResultsInAssessmentMessage	boolean	Required
Description	If TRUE this element specifies that the response to this message should be an AssessmentRequest and an Assessment message. If FALSE the assessment data that is generated should be bundled inside the response. In some cases there isn't a native message and the results can only be reported via AssessmentRequestStatus.	
Category	MA_AssessmentRequestType	Required

Description	Indicates the assessment category for requested assessment.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-845: Peer Interface MA_AssessmentRequestMT - MessageData UCI Extension Field

Category		
Description	Indicates the assessment category for requested assessment.	
Base Type	MA_AssessmentRequestType	
Message Structure		
Field Name	Field Type	Field Usage
CommPointingPlan	CommPointingPlanRequestType	Required
Description	This element is used to specify that communication requests should be assessed, and a Pointing Plan should be generated based on the requests. The native message is CommPointingPlan.	
CapabilityUtilization	CapabilityUtilizationRequestType	Required
Description	This assessment type is utilized to assess predicted Capability utilization along a mission planned route.	
RouteDeconfliction	RouteDeconflictionRequestType	Required
Description	This element is used to specify that an assessment of the conflicts along a route is requested.	
RouteVulnerabilityMetrics	RouteVulnerabilityMetricsRequestType	Required
Description	This element is used to specify that detection metrics need to be recomputed along a route due to threats. The data generated for detection metrics are different from threat assessments because detection metrics break down the exposure numbers to a much greater detail in order to generate a route than a threat assessment will.	
RouteThreatAssessment	ThreatAssessmentRequestType	Required
Description	This element is used to specify that an assessment of the threat exposure along a route is requested.	
TargetMobility	TargetMobilityRequestType	Required
Description	This element is used to specify that an assessment of the possible zone an Entity could have moved within some given period of time.	
VehicleThreatAssessment	VehicleThreatAssessmentRequestType	Required
Description	This element is used to specify that a threat assessment is being requested for the current position of a vehicle.	
ThreatNominationAssessment	ThreatNominationAssessmentRequestType	Required
Description	This element is used to specify that a threat nomination assessment is being requested for the given mission plans and entities.	
AchievabilityAssessment	AchievabilityAssessmentRequestPET	Required

Description	This element is used to specify that achievability assessment is being requested for the given type of AchievabilityRequest.	
CoverageAssessment	MA_CoverageAssessmentRequestType	Required
Description	This element is used to specify that assessment is being requested for sensor coverage.	

Table A-4-846: Peer Interface MA_AssessmentRequestMT - Category UCI Extension Field

4.2.84 MA_AssessmentRequestStatusMT UCI Extension

MA_AssessmentRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	Assessment : MA_AssessmentType MessageData : MA_AssessmentRequestStatusMDT

Table A-4-847: Peer Interface MA_AssessmentRequestStatusMT UCI Extension

Assessment		
Description	This element indicates the results of the assessment. It is optional based on whether the assessment request specified that the response should result in native message.	
Base Type	MA_AssessmentType	
Message Structure		
Field Name	Field Type	Field Usage
CommPointingPlan	CommPointingPlanAssessmentType	Required
Description	This element defines the response to a communications pointing plan assessment request.	
CapabilityUtilization	CapabilityUtilizationAssessmentType	Required
Description	This assessment type is utilized to assess predicted capability utilization along a mission planned route.	
RouteDeconfliction	RouteDeconflictionAssessmentType	Required
Description	This element defines the response to a route deconfliction assessment request.	
RouteVulnerabilityMetrics	RouteVulnerabilityMetricsAssessmentType	Required
Description	Indicates the results of assessment of vulnerability along a route.	
RouteThreatAssessment	RouteThreatAssessmentType	Required
Description	Indicates the results of assessment of threats along a route.	
TargetMobility	TargetMobilityAssessmentType	Required
Description	This element defines the response to a target mobility assessment request.	
VehicleThreatAssessment	VehicleThreatAssessmentType	Required
Description	This element defines the response to a vehicle threat assessment request.	

ThreatNominationAssessment	ThreatNominationAssessmentType	Required
Description	This element defines the response to a threat nomination assessment.	
AchievabilityAssessment	AchievabilityAssessmentPET	Required
Description	This element defines the response to an achievability assessment.	
CoverageAssessment	MA_CoverageAssessmentType	Required
Description	This element defines the response to a coverage assessment.	

Table A-4-848: Peer Interface MA_AssessmentRequestStatusMT - Assessment UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_AssessmentRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CompletionStatus	CompletionStatusType	Optional
Description	Intermediate status information for an assessment. Typically populated when sending periodic statuses of PROCESSING, but can also store start and finish times for this assessment.	
Assessment	MA_AssessmentType	Optional
Description	This element indicates the results of the assessment. It is optional based on whether the assessment request specified that the response should result in native message.	
IncompleteAssessment	IncompleteProcessingType	Repeated
Description	This element indicates any assessments that failed to complete. It is used to indicate details about why a specific assessment target failed to process.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-849: Peer Interface MA_AssessmentRequestStatusMT - MessageData UCI Extension Field

4.2.85 MA_OperatorRoleMT UCI Extension

MA_OperatorRoleMT	
Description	See the annotation in the associated message for an overall description of the message and

	this type.
	See the XSD File for more info
Ext. Fields	SystemID : SystemID_Type

Table A-4-850: Peer Interface MA_OperatorRoleMT UCI Extension

SystemID		
Description	Indicates the SystemID that the OperatorRole belongs to. If not populated, it is assumed to be the SystemID specified in the MessageHeader.	
Base Type	SystemID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-851: Peer Interface MA_OperatorRoleMT - SystemID UCI Extension Field

4.2.86 MA_ActionPlanValidationMT UCI Extension

MA_ActionPlanValidationMT	
Description	See annotations in child elements and messages/elements that use this type for details.
	See the XSD File for more info
Ext. Fields	AllocationResult : MA_ActionPlanningResultType OpPlanID : MA_OpPlanID_Type MessageData : MA_ActionPlanValidationMDT AssociatedPlans : MA_PlanReferenceType

Table A-4-852: Peer Interface MA_ActionPlanValidationMT UCI Extension

AllocationResult		
Description	Indicates allocation results per Action. This element is only expected when the ActionPlan was found to be invalid and the associated ActionPlanValidationCommand indicated "modify to validate" was allowed.	
Base Type	MA_ActionPlanningResultType	
Message Structure		
Field Name	Field Type	Field Usage
ActionID	ActionID_Type	Required
Description	Unique object identifier for the Action whose planning results are given by sibling elements.	

PlanningResult	PlanningResultEnum	Required
Description	Indicates the outcome of attempting to allocate or plan activities for the Requirement.	
SystemID	SystemID_Type	Required
Description	Indicates the SystemID of the System whose *Plan are associated with the sibling PlanningResult element.	
AssociatedPlans	MA_PlanReferenceType	Optional
Description	Indicates *Plan associated with the sibling PlanningResult element. If the sibling PlanningResult indicates the Requirement was/remained allocated then this element indicates the specific *Plan it is/remains allocated in. If the PlanningResult indicates the Requirement was DEALLOCATED then this element indicates the constraining *Plan it was DEALLOCATED from. This element isn't expected when the PlanningResult indicates UNALLOCATED.	
NotAllocatedReason	UnallocatedReasonType	Repeated
Description	Indicates a reason why the Requirement wasn't allocated or reallocated. If the sibling PlanningResult element indicates the Requirement was left not allocated then this element indicates why. Multiple instances of this element can provide the reason for each System that was attempted and even many reasons for each. If the PlanningResult indicates the Requirement was allocated then this element can still be used to indicate reasons for failed attempts to allocate to other Systems or plan, prior to the successful allocation.	

Table A-4-853: Peer Interface MA_ActionPlanValidationMT - AllocationResult UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-854: Peer Interface MA_ActionPlanValidationMT - OpPlanID UCI Extension Field

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.

Base Type	MA_ActionPlanValidationMDT	
Message Structure		
Field Name	Field Type	Field Usage
ActionPlanValidationID	ActionPlanValidationID_Type	Required
Description	The ID of this ActionPlanValidation message.	
PlanID	ActionPlanID_Type	Required
Description	The ID of the Plan this status pertains to.	
Validator	ValidatorType	Required
Description	The ID of the Validator responsible for this Status message.	
ValidationState	PlanValidationStateEnum	Required
Description	Indicates the determined validation state of the plan. The variables a given planning service, operator or system considers when validating a plan varies. Different variables might be considered for a single given System depending on the level of detail of the plan. The scope and meaning of "valid" comes from context of the services, operator and systems creating the plan. The value in this element can change during validation processing. The final validity determination is given when the sibling ValidationStatus element reaches an end state.	
CompletionStatus	CompletionStatusType	Optional
Description	Indicates actual and predicted metrics for completion of the validation process.	
IncompleteItem	IncompleteProcessingType	Repeated
Description	Indicates items associated with command processing that failed to complete. For example if a particular required Capability wasn't available, it could be referenced here. This element/type is highly flexible. It can reference almost any message/concept in UCI as a planning issue. The wide range of messages/concepts it can reference makes it 1) difficult to use as a basis for software/services to resolve the issue but 2) an excellent general method for processing algorithms to convey issues to operators. This element shouldn't be used to report processing issues/results that are more directly indicated by other processing status elements. For example, for planning processing, other elements focus specifically on per-Requirement allocation results therefore this element shouldn't be used for per-Requirement allocation results.	
InvalidAllocation	ActionAllocationInvalidType	Repeated
Description	Indicates an Action whose allocation was found to be invalid. If the associated ActionPlanValidationCommand indicated "modify to validate", results of attempts to modify the allocation can be found in sibling elements.	
AllocationResult	MA_ActionPlanningResultType	Repeated
Description	Indicates allocation results per Action. This element is only expected when the ActionPlan was found to be invalid and the associated ActionPlanValidationCommand indicated "modify to validate" was allowed.	
ModifiedPlanID	ActionPlanID_Type	Repeated
Description	Indicates a modified, valid version of the evaluated ActionPlan. This element should only be given when the evaluated ActionPlan was found to be invalid, the ActionPlanValidationCommand indicated "modify to validate" and the modifications resulted in a valid ActionPlan.	

Table A-4-855: Peer Interface MA_ActionPlanValidationMT - MessageData UCI Extension Field

AssociatedPlans		
Description	Indicates *Plan associated with the sibling PlanningResult element. If the sibling PlanningResult indicates the Requirement was/remained allocated then this element indicates the specific *Plan it is/remains allocated in. If the PlanningResult indicates the Requirement was DEALLOCATED then this element indicates the constraining *Plan it was DEALLOCATED from. This element isn't expected when the PlanningResult indicates UNALLOCATED.	
Base Type	MA_PlanReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Optional
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Optional
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Optional
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Optional
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Optional
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Optional
Description	Indicates a reference to a RouteActivityPlan.	
CommScheduleAllocationID	CommScheduleAllocationID_Type	Optional
Description	Indicates a reference to a Comms allocation.	
ActivityPlanID	ActivityPlanID_Type	Optional
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Optional
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Optional
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Optional
Description	Indicates a reference to a ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Optional
Description	Indicates a reference to an OpPlan.	

Table A-4-856: Peer Interface MA_ActionPlanValidationMT - AssociatedPlans UCI Extension Field

4.2.87 MA_ApprovalPolicyMT UCI Extension

MA_ApprovalPolicyMT

Description	See the annotation in the associated message for an overall description of the message and this type.
	See the XSD File for more info
Ext. Fields	TaskPlan : MA_TaskPlanPartsType OpLineCategory : MA_OpLineCategoryEnum ActivityPlan : MA_ActivityPlanPartsType ApplicablePlanningActivity : MA_PlanPolicyApplicablePlanType OpVolumeCategory : MA_OpZoneCategoryEnum TaskType : MA_TaskTypeEnum OrbitActivityPlan : MA_ActivityPlanPartsType MessageData : MA_ApprovalPolicyMDT OpZoneCategory : MA_OpZoneCategoryEnum ByPlanParts : MA_PlanPartsType CapabilityCommand : MA_CapabilityTypeEnum PlanParts : MA_PlanPartsType Plans : MA_PlanPolicyType RouteActivityPlan : MA_ActivityPlanPartsType OpPlan : MA_OpPlanPartsType PlanActivation : MA_PlanActivationPolicyType

Table A-4-857: Peer Interface MA_ApprovalPolicyMT UCI Extension

TaskPlan		
Description	Indicates applicable TaskPlan parts.	
Base Type	MA_TaskPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
TaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	

Table A-4-858: Peer Interface MA_ApprovalPolicyMT - TaskPlan UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.

FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-859: Peer Interface MA_ApprovalPolicyMT - OpLineCategory UCI Extension Field

ActivityPlan		
Description	Indicates applicable ActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	

SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-860: Peer Interface MA_ApprovalPolicyMT - ActivityPlan UCI Extension Field

ApplicablePlanningActivity		
Description	Indicates the set of planning activities whose generated plans are subject to the sibling *Policy elements.	
Base Type	MA_PlanPolicyApplicablePlanType	
Message Structure		
Field Name	Field Type	Field Usage
PlanType	PlanTypeEnum	Required
Description	Indicates the PlanType that is generated by the planning activity, which is applicable to the associated *Policy elements.	
PlanParts	MA_PlanPartsType	Optional
Description	Indicates the parts of the sibling PlanType that are generated by the planning activity, which is applicable to the associated *Policy elements. If omitted, it indicates all PlanParts are applicable.	
ConstrainingPlans	AutonomousPlanningConstrainingPlansType	Optional
Description	Indicates a set of constraining plans (applicable to same system than the one planned for) that are used in the planning activity, which is applicable to the associated *Policy elements.	

OtherSystemConstrainingPlans	AutonomousPlanningOtherSystemConstrainingPlansType	Repeated
Description	Indicates a set of constraining plans (applicable to different system than the one planned for) that are used in the planning activity, which is applicable to the associated *Policy elements.	

Table A-4-861: Peer Interface MA_ApprovalPolicyMT - ApplicablePlanningActivity UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense

	systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are

	defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-862: Peer Interface MA_ApprovalPolicyMT - OpVolumeCategory UCI Extension Field

TaskType	
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.
AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.
CAP	Indicates the task is to execute a Combat Air Patrol.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESCORT	Indicates the task is to escort another entity.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.
SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.

SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-863: Peer Interface MA_ApprovalPolicyMT - TaskType UCI Extension Field

OrbitActivityPlan		
Description	Indicates applicable OrbitActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-864: Peer Interface MA_ApprovalPolicyMT - OrbitActivityPlan UCI Extension Field

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.

Base Type	MA_ApprovalPolicyMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApprovalPolicyID	ApprovalPolicyID_Type	Required
Description	Indicates the unique ID of the approval policy.	
Plans	MA_PlanPolicyType	Repeated
Description	Indicates a set of approval policies for the results of planning activities.	
PlanActivation	MA_PlanActivationPolicyType	Repeated
Description	Indicates approval policies which govern Plan Activation commands.	
RequirementExecution	RequirementExecutionPolicyType	Optional
Description	Indicates which Requirement (Effect, Action, Task, [Capability]Command, Response) execution/performance related activities require approval.	
TimedZone	TimedZoneType	Optional
Description	Indicates the geospatial zone and optionally time/date span or spans when the policy is active. For task allocation, the policy is applicable to allocations that 1) complete within the time/date span and 2) include Task or Tasks whose target falls within the zone, regardless of when the Task will be executed. For route planning, the policy is applicable to route plans with segments that fall within the zone during the time/date span, regardless of when the route plan was completed or the target of Tasks associated with the segments. For task execution, the policy is applicable to Tasks that 1) are scheduled to complete within the time/date span and 2) have a target which falls within the zone. This element supersedes the sibling Expires element.	
Expires	DateTimeType	Optional
Description	Indicates the time and date when the policy expires. The policy is applicable to task allocation and route planning activities completed prior to this time. The policy is applicable to task execution activities initiated prior to this time. When the sibling TimedZone element is used, the time spans specified there supersede this element.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of the approval policy to specify the source or motivation for this ApprovalPolicy such as ATO, ACO, etc.	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-865: Peer Interface MA_ApprovalPolicyMT - MessageData UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	

Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area

	designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-866: Peer Interface MA_ApprovalPolicyMT - OpZoneCategory UCI Extension Field

ByPlanParts

Description	Indicates *Plan parts which the Plan to be activated must contain in order for the Policy to be applicable. If omitted, the Policy is applicable regardless of *Plan parts.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-867: Peer Interface MA_ApprovalPolicyMT - ByPlanParts UCI Extension Field

CapabilityCommand	
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_CapabilityTypeEnum
Message Structure	
Enumeration Literal	Description
ACTION	Indicates an action capability.
AIR_SAMPLE	Indicates an air sampling capability.
AMTI	Indicates an airborne moving target indication (AMTI) capability.

AO	Indicates an active optical capability.
CAP	Indicates a cargo delivery capability.
CARGO_DELIVERY	Indicates a cargo delivery capability.
COMINT	Indicates a Communications Intelligence (COMINT) capability.
COMM_RELAY	Indicates a communications relay capability.
COMM_TERMINAL	Indicates a communications terminal capability
COUNTER_SPACE	Indicates a Counter Space Capability.
EA	Indicates an electronic attack (EA) capability.
EFFECT	Indicates an effect capability.
ESM	Indicates an electronic support measures (ESM) capability.
FLIGHT	Indicates a capability for waypoint-based flight tasks/commands.
IFF	Indicates an Identification Friend or Foe (IFF) capability.
OPAQUE	Indicates a Opaque Capability
ORBIT_CHANGE	Indicates this space system has the ability to change orbits.
ORBITAL_SURVEILLANCE	Indicates a task to perform Orbital Surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates an Orbital Surveillance Sensor Capability.
PO	Indicates a passive optical capability.
RADAR_ALTIMETER	Indicates a Radar Altimeter capability
REFUEL	Indicates a capability to refuel another asset.
RESPONSE	Indicates an response capability.
SAR	Indicates a synthetic aperture radar (SAR) capability.
SMTI	Indicates a surface moving target indication (SMTI) capability.
STRIKE	Indicates a strike capability.
SYSTEM_DEPLOYMENT	Indicates a deployment capability.
TACTICAL_ORDER	Indicates a tactical order capability.
TASK	Indicates a task capability.
WEATHER_RADAR	Indicates a weather radar capability.

Table A-4-868: Peer Interface MA_ApprovalPolicyMT - CapabilityCommand UCI Extension Field

PlanParts		
Description	Indicates the parts of the sibling PlanType that are generated by the planning activity, which is applicable to the associated *Policy elements. If omitted, it indicates all PlanParts are applicable.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional

Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-869: Peer Interface MA_ApprovalPolicyMT - PlanParts UCI Extension Field

Plans		
Description	Indicates a set of approval policies for the results of planning activities.	
Base Type	MA_PlanPolicyType	
Message Structure		
Field Name	Field Type	Field Usage
ApplicablePlanningActivity	MA_PlanPolicyApplicablePlanType	Repeated
Description	Indicates the set of planning activities whose generated plans are subject to the sibling *Policy elements.	
DefaultPolicy	ApprovalPolicyBaseType	Optional
Description	Indicates the default approval policy for the sibling ApplicablePlanningActivity. The default policy can be overridden in specific conditions as indicated by the ByResultPolicy or ByTriggerPolicy siblings of this element. For example, this element could indicate that approval is required by default for all TaskPlans and then use ByResultPolicy or ByTriggerPolicy siblings to specify conditions when task allocation approval is not required. Alternately, this element could indicate that approval is not required by default and then use ByResultPolicy or ByTriggerPolicy siblings to specify conditions when task allocation approval is required. Creators of this message are expected to carefully avoid creating logically inconsistent ByResultPolicy and ByTriggerPolicy instances and therefore no guidance is given on deconflicting illogical instances. For example, an ApprovalPolicy that indicates approval is not required by	

	default with conflicting ByResultPolicy or ByTriggerPolicy overrides of 1) AUTO_REJECT for DROPPED_TASKS and 2) AUTO_APPROVE for operator triggered DROPPED_TASKS would be considered illogical.	
ByResultPolicy	ByResultPolicyType	Repeated
Description	Indicates approval policies when planning activity results match certain conditions. Conditions specified here are considered to be overrides to the default planning activity approval policy given in the sibling Default element. For example, if the default policy indicates task allocation approval is never required, this element could override the default and require approval whenever a task allocation results in previously allocated Task or Tasks being dropped. See the annotations in the sibling DefaultPolicy element for an overview of how the siblings relate to each other. If multiple instances are given, each should be a different Result instance as indicated by the child Result element.	
ByTriggerPolicy	ByTriggerPolicyType	Repeated
Description	Indicates approval policies for re-plan activities initiated by triggered events, overriding the default approval policy for the planning activity given in the sibling DefaultPolicy element. Additionally, this element allows trigger-specific policies for a specific planning activities. For example, if the default policy indicates route planning approval is never required, this element could override, requiring approval for route plans affecting all Systems triggered by new threats if the route re-plan results in dropped tasks. If multiple instances are given, each should be of a different trigger type as indicated by the child EventTrigger element.	

Table A-4-870: Peer Interface MA_ApprovalPolicyMT - Plans UCI Extension Field

RouteActivityPlan		
Description	Indicates applicable RouteActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional

	Description	Indicates applicable EffectPlan parts.
ActionPlan	ActionPlanPartsType	Optional
	Description	Indicates applicable ActionPlan parts.
TaskPlan	MA_TaskPlanPartsType	Optional
	Description	Indicates applicable TaskPlan parts.
ResponsePlan	ResponsePlanPartsType	Optional
	Description	Indicates applicable ResponsePlan parts.
OpPlan	MA_OpPlanPartsType	Optional
	Description	Indicates applicable OpPlan parts.

Table A-4-871: Peer Interface MA_ApprovalPolicyMT - RouteActivityPlan UCI Extension Field

OpPlan		
Description	Indicates applicable OpPlan parts.	
Base Type	MA_OpPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpRouting	EmptyType	Optional
Description	Indicates an OpRouting is applicable to the associated *Plan. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-872: Peer Interface MA_ApprovalPolicyMT - OpPlan UCI Extension Field

PlanActivation		
Description	Indicates approval policies which govern Plan Activation commands.	
Base Type	MA_PlanActivationPolicyType	
Message Structure		
Field Name	Field Type	Field Usage
ByMissionPlan	MissionPlanActivationSettingType	Repeated

Description	Indicates the set of ByMissionPlan activation commands that are applicable to the sibling Policy element. List size allows for identifying those MissionPlans whose subordinate MissionPlans are either included in the activation (TRUE) or not (FALSE) via the CommandSubordinatePlans setting.	
BySubPlan	SubPlanActivationSettingType	Repeated
Description	Indicates the set of BySubPlan activation commands that are applicable to the sibling Policy element.	
ByPlanParts	MA_PlanPartsType	Optional
Description	Indicates *Plan parts which the Plan to be activated must contain in order for the Policy to be applicable. If omitted, the Policy is applicable regardless of *Plan parts.	
Policy	ApprovalPolicyBaseType	Optional
Description	Indicates the approval policy for the sibling applicable activation activities.	

Table A-4-873: Peer Interface MA_ApprovalPolicyMT - PlanActivation UCI Extension Field

4.2.88 MA_OpLineMT UCI Extension

MA_OpLineMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	Category : MA_OpLineCategoryEnum AppliesToIDs : MA_PackageSystemType MessageData : MA_OpLineMDT

Table A-4-874: Peer Interface MA_OpLineMT UCI Extension

Category	
Description	This element indicates the type of operational line.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they

	are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-875: Peer Interface MA_OpLineMT - Category UCI Extension Field

AppliesToIDs		
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-876: Peer Interface MA_OpLineMT - AppliesToIDs UCI Extension Field

MessageData	
Description	See annotations in child elements and messages/elements that use this type

	for details.	
Base Type	MA_OpLineMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpLineID	OpLineID_Type	Required
Description	Indicates the unique ID of the OpLine.	
Category	MA_OpLineCategoryEnum	Required
Description	This element indicates the type of operational line.	
Line	OpLineType	Required
Description	Indicates the geometric description of the OpLine. In practice, operational lines can be geometric lines, areas or in some cases volumes.	
OpDescription	OpDescriptionType	Optional
Description	A human-readable descriptive name with free text remarks.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this operational item to specify what the source or motivation for it originated from. This could be ATO, ACO, etc.	
Source	CreationSourceEnum	Optional
Description	Indicates the source of the information.	
Schedule	ScheduleType	Optional
Description	This element represents a date/time interval associated with the operational item during which the item is in effect.	
AssociatedTime	TimeFunctionType	Repeated
Description	Indicates time related events that are associated to the Op data type such as when activated or when operational. The multiplicity is limited to N-1 options where NONE is an event that has no value, thus removed from list of available options.	
DataLinkIdentifier	DataLinkIdentifierPET	Repeated
Description	List of data link ID. Multiple data link IDs can be reported for the same network type.	
Priority	unsignedInt	Optional
Description	This field represents the priority to be considered when choosing between multiple available points.	
QualifyingTags	QualifyingTagsType	Optional
Description	Provides identity qualifications to augment identification and associated processing of the OpPoint.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
SystemScheduleOverride	SystemScheduleStateType	Repeated
Description	System-specific schedule that will override any part of the main schedule. This allows for system-specific schedule different than main schedule. When adding a SystemScheduleOverride, the child SystemID also must be added to the sibling SystemID list if the sibling list is not empty. The SystemScheduleOverride is	

	independent of time planning. For the system, this override can be done at execution.
--	---

Table A-4-877: Peer Interface MA_OpLineMT - MessageData UCI Extension Field

4.2.89 MA_OpPointMT UCI Extension

MA_OpPointMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_OpPointMDT AppliesToIDs : MA_PackageSystemType

Table A-4-878: Peer Interface MA_OpPointMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpPointMDT	
Message Structure		
Field Name	Field Type	Field Usage
Category	OpPointCategoriesType	Required
Description	This element indicates the type of operational point.	
CategoryUniqueData	OpPointCategoriesUniqueDataType	Optional
Description	This element indicates the unique data for the type of operational point.	
OpPointID	OpPointID_Type	Required
Description	This element represents the unique identifier of the point associated with this message.	
PointChoice	OpPointChoiceType	Required
Description	Choice of either geospatial or relative position of the OpPoint.	
SystemConfiguration	SystemConfigurationType	Repeated
Description	Indicates a System which the OpPoint is applicable for and its planned configuration/state upon arriving at the OpPoint. If omitted, the OpPoint applies to all Systems.	
TurnDirection	RelativeDirectionEnum	Optional
Description	This field provides the turn direction for orbit.	
IngressConstraint	AnglePairType	Optional
Description	When present this field constrains the vehicle ingress path toward the OpPoint. The allowable ingress range is defined clockwise from Min to Max.	
SafeAltitude	SafeAltitudeType	Optional
Description	This field specifies a set of safe minimum approach altitudes and an emergency safe altitude. This field also specifies the cylindrical area, defined by a center point and	

	radius, where the altitudes apply. This field defines minimum approach altitude and emergency safe altitude consistent with standard FAA instrument approach chart definitions (using UCI standard data types).	
OpDescription	OpDescriptionType	Optional
Description	A human-readable descriptive name with free text remarks.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this operational item to specify what the source or motivation for it originated from. This could be ATO, ACO, etc.	
Source	CreationSourceEnum	Optional
Description	Indicates the source of the information.	
Schedule	ScheduleType	Optional
Description	This element represents a date/time interval associated with the operational item during which the item is in effect.	
AssociatedTime	TimeFunctionType	Repeated
Description	Indicates time related events that are associated to the Op data type such as when activated or when operational. The multiplicity is limited to N-1 options where NONE is an event that has no value, thus removed from list of available options.	
DataLinkIdIdentifier	DataLinkIdIdentifierPET	Repeated
Description	List of data link ID. Multiple data link IDs can be reported for the same network type.	
Priority	unsignedInt	Optional
Description	This field represents the priority to be considered when choosing between multiple available points.	
QualifyingTags	QualifyingTagsType	Optional
Description	Provides identity qualifications to augment identification and associated processing of the OpPoint.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
SystemScheduleOverride	SystemScheduleStateType	Repeated
Description	System-specific schedule that will override any part of the main schedule. This allows for system-specific schedule different than main schedule. When adding a SystemScheduleOverride, the child SystemID also must be added to the sibling SystemID list if the sibling list is not empty. The SystemScheduleOverride is independent of time planning. For the system, this override can be done at execution.	

Table A-4-879: Peer Interface MA_OpPointMT - MessageData UCI Extension Field

AppliesToIDs		
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage

ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-880: Peer Interface MA_OpPointMT - AppliesToIDs UCI Extension Field

4.2.90 MA_OpRoutingMT UCI Extension

MA_OpRoutingMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ApplicableToIDs : MA_PackageSystemType MessageData : MA_OpRoutingMDT

Table A-4-881: Peer Interface MA_OpRoutingMT UCI Extension

ApplicableToIDs		
Description	One or more Systems to which the routing constraints apply. If omitted, the constraints apply to all Systems.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-882: Peer Interface MA_OpRoutingMT - ApplicableToIDs UCI Extension Field

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.

Base Type	MA_OpRoutingMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpRoutingID	OpRoutingID_Type	Required
Description	The unique identifier of the set of routing constraints during operation associated with this message.	
DefaultBlueSeparation	SeparationParametersType	Optional
Description	Indicates default minimum geospatial separation to be maintained when planning or analyzing routes or manually navigating. The separation is between the planned/navigated route and other routes or conflicting items. This is the default separation. It can be overridden in specific cases by the sibling element.	
DefaultRedSeparation	SeparationParametersType	Optional
Description	Indicates default minimum geospatial separation to be maintained when planning or analyzing routes or manually navigating. The separation is between the planned/navigated route and other routes or conflicting items. This is the default separation. It can be overridden in specific cases by the sibling element.	
SpecificBlueSeparation	SpecificBlueSeparationType	Repeated
Description	Defines parameters to use when deconflicting blue player routes or generating routes to ensure proper separation from other blue players. These parameters apply at the vehicle type level.	
SpecificRedSeparation	SpecificRedSeparationType	Repeated
Description	Defines parameters to use when deconflicting blue player routes or generating routes to ensure proper separation from other red players. These parameters apply at the vehicle type level.	
OpDescription	OpDescriptionType	Optional
Description	Represents the name and description of the set of associated routing constraints.	
ApplicableToIDs	MA_PackageSystemType	Repeated
Description	One or more Systems to which the routing constraints apply. If omitted, the constraints apply to all Systems.	
ApplicableZone	ZoneType	Optional
Description	Indicates the geospatial zone in which the routing constraints apply.	
Schedule	ScheduleType	Optional
Description	Indicates the time schedule during which the routing constraints apply.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this zone to specify what the source or motivation for this zone originated from. This could be ATO, ACO, etc.	

Table A-4-883: Peer Interface MA_OpRoutingMT - MessageData UCI Extension Field

4.2.91 MA_PlanningFunctionSettingsCommandMT UCI Extension

MA_PlanningFunctionSettingsCommandMT	
Description	See the annotation in the associated message for an overall description of the message and

	this type.
	See the XSD File for more info
Ext. Fields	AutonomousPlanningAction : MA_PlanningAllowedEscalationType OpPlan : MA_OpPlanPartsType AutonomousPlanningResponseChoice : MA_MissionPlanningAutonomyResponseChoiceType MissionPlanningAutonomy : MA_MissionPlanningAutonomySettingType OrbitActivityPlan : MA_ActivityPlanPartsType RouteActivityPlan : MA_ActivityPlanPartsType ByResultSetting : MA_MissionPlanningAutonomySettingByResultType PlanningAllowed : MA_PlanningAllowedType OutputPlanParts : MA_PlanPartsType AllowedType : MA_PlanningAllowedType AutonomousAction : MA_MissionPlanningByResultAutonomousActionType MessageData : MA_PlanningFunctionSettingsCommandMDT ActivityPlan : MA_ActivityPlanPartsType TaskPlan : MA_TaskPlanPartsType

Table A-4-884: Peer Interface MA_PlanningFunctionSettingsCommandMT UCI Extension

AutonomousPlanningAction		
Description	This element indicates the allowed autonomous mission planning for the ancestor Trigger. It also indicates the expected MissionContingencyAlert for the ancestor Trigger; whenever autonomous mission planning is allowed and triggered, a MissionContingencyAlert is expected.	
Base Type	MA_PlanningAllowedEscalationType	
Message Structure		
Field Name	Field Type	Field Usage
AutonomousPlanningActionID	AutonomousPlanningActionID_Type	Required
Description	Assigns a unique ID to an allowed planning action. This ID can be reference in *Plans, alerts, etc. that result when the planning action is triggered.	
ByResultSetting	MA_MissionPlanningAutonomySettingByResultType	Repeated
Description	This element allows control of the escalation of the autonomous replanning. If the autonomous function indicated by the sibling AllowedType leads to a "by result" trigger described here, then additional autonomous planning is allowed as described here. For example, if Tasks are dropped as a result of initial autonomous replanning then this element can be used to enable/disable a secondary "escalated" planning iteration that includes global Task allocation. If omitted, the sibling AllowedType is allowed regardless of result.	
AllowedType	MA_PlanningAllowedType	Required
Description	This element defines the mission planning type that is allowed to be autonomously triggered.	

Table A-4-885: Peer Interface MA_PlanningFunctionSettingsCommandMT - AutonomousPlanningAction UCI Extension Field

OpPlan		
Description	Indicates applicable OpPlan parts.	
Base Type	MA_OpPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpRouting	EmptyType	Optional
Description	Indicates an OpRouting is applicable to the associated *Plan. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-886: Peer Interface MA_PlanningFunctionSettingsCommandMT - OpPlan UCI Extension Field

AutonomousPlanningResponseChoice		
Description	Indicates the autonomous mission planning type or types allowed for the sibling Trigger.	
Base Type	MA_MissionPlanningAutonomyResponseChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
AutonomousPlanningAction	MA_PlanningAllowedEscalationType	Repeated
Description	This element indicates the allowed autonomous mission planning for the ancestor Trigger. It also indicates the expected MissionContingencyAlert for the ancestor Trigger; whenever autonomous mission planning is allowed and triggered, a MissionContingencyAlert is expected.	
AlertOnly	EmptyType	Required
Description	This element indicates that autonomous mission planning isn't allowed for the ancestor Trigger but a MissionContingencyAlert is expected.	

Table A-4-887: Peer Interface MA_PlanningFunctionSettingsCommandMT - AutonomousPlanningResponseChoice UCI Extension Field

MissionPlanningAutonomy

Description	Indicates commanded settings for autonomous mission planning capabilities of the System.	
Base Type	MA_MissionPlanningAutonomySettingType	
Message Structure		
Field Name	Field Type	Field Usage
Trigger	PlanningByCaseTriggerType	Required
Description	Indicates an allowed trigger for autonomous planning.	
AutonomousPlanningResponseChoice	MA_MissionPlanningAutonomyResponseChoiceType	Required
Description	Indicates the autonomous mission planning type or types allowed for the sibling Trigger.	
PlanningProcessID	PlanningProcessID_Type	Optional
Description	Indicates the unique ID of a planning process which the settings are applicable to. If omitted, the setting is applicable to all processes of the corresponding System.	
MinimumResponseInterval	DurationType	Optional
Description	Indicates the minimum time interval between autonomous responses for the sibling Trigger. In other words, regardless of when and how frequently the Trigger occurs, the sibling Response shouldn't be initiated until the minimum time duration given here after the previous Response.	

Table A-4-888: Peer Interface MA_PlanningFunctionSettingsCommandMT - MissionPlanningAutonomy UCI Extension Field

OrbitActivityPlan		
Description	Indicates applicable OrbitActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	

EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-889: Peer Interface MA_PlanningFunctionSettingsCommandMT - OrbitActivityPlan UCI Extension Field

RouteActivityPlan		
Description	Indicates applicable RouteActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	

ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-890: Peer Interface MA_PlanningFunctionSettingsCommandMT - RouteActivityPlan UCI Extension Field

ByResultSetting		
Description	This element allows control of the escalation of the autonomous replanning. If the autonomous function indicated by the sibling AllowedType leads to a "by result" trigger described here, then additional autonomous planning is allowed as described here. For example, if Tasks are dropped as a result of initial autonomous replanning then this element can be used to enable/disable a secondary "escalated" planning iteration that includes global Task allocation. If omitted, the sibling AllowedType is allowed regardless of result.	
Base Type	MA_MissionPlanningAutonomySettingByResultType	
Message Structure		
Field Name	Field Type	Field Usage
Trigger	PlanningByResultTriggerType	Required
Description	Indicates a trigger based on the results of a previously initiated autonomous mission planning function.	
AutonomousAction	MA_MissionPlanningByResultAutonomousActionType	Required
Description	Indicates the action or actions allowed for the sibling trigger.	

Table A-4-891: Peer Interface MA_PlanningFunctionSettingsCommandMT - ByResultSetting UCI Extension Field

PlanningAllowed		
Description	This element defines the mission planning type to be triggered. If multiple instances are given, each should be of a different planning type as indicated by the child element.	
Base Type	MA_PlanningAllowedType	
Message Structure		
Field Name	Field Type	Field Usage
PlanAheadDuration	DurationType	Required
Description	Required duration in the future when the Plan should start. Existing *Plan will continue during this time. This duration should account for everything that must happen from replan initiation to new plan activation.	
PlanningProcessID	PlanningProcessID_Type	Required
Description	Indicates the unique ID of the planning process whose autonomous invocation is described the sibling elements. Planning process are declared in the ControlStatus message.	
ConstrainingPlans	AutonomousPlanningConstrainingPlansType	Optional
Description	Indicates existing types of *Plans that can be used as constraints when invoking the planning process indicated by the sibling PlanningProcessID. The types of	

	*Plans indicated here should be consistent with those supported by the planning process as indicated in the ControlStatus message.	
OtherSystemConstrainingPlans	AutonomousPlanningOtherSystemConstrainingPlansType	Repeated
Description	Indicates existing plans of another System that constrain planning. One for each descendant ConstraintUsage.	
OutputPlanParts	MA_PlanPartsType	Optional
Description	Indicates the specific Plan parts of the sibling PlanningType that the System can produce and include in the output Plan. The child choice in this element should match the sibling PlanningType. When omitted, the System can produce all of the Plan parts for the sibling PlanningType.	
ResultsInMissionPlan	boolean	Required
Description	In some cases, the commanding service or HMI may not want to receive the planning process summarized in a MissionPlan message. If TRUE, the results will be published in individual *Plan messages and summarized in a published MissionPlan message. If FALSE, the results will be published in individual *Plan messages without a summary MissionPlan message.	
ForPlanningUseOnly	boolean	Required
Description	Indicates the state to use for the corresponding element in the *PlanCommand when invoking the planning process.	

Table A-4-892: Peer Interface MA_PlanningFunctionSettingsCommandMT - PlanningAllowed UCI Extension Field

OutputPlanParts		
Description	Indicates the specific Plan parts of the sibling PlanningType that the System can produce and include in the output Plan. The child choice in this element should match the sibling PlanningType. When omitted, the System can produce all of the Plan parts for the sibling PlanningType.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	

ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-893: Peer Interface MA_PlanningFunctionSettingsCommandMT - OutputPlanParts UCI Extension Field

AllowedType		
Description	This element defines the mission planning type that is allowed to be autonomously triggered.	
Base Type	MA_PlanningAllowedType	
Message Structure		
Field Name	Field Type	Field Usage
PlanAheadDuration	DurationType	Required
Description	Required duration in the future when the Plan should start. Existing *Plan will continue during this time. This duration should account for everything that must happen from replan initiation to new plan activation.	
PlanningProcessID	PlanningProcessID_Type	Required
Description	Indicates the unique ID of the planning process whose autonomous invocation is described the sibling elements. Planning process are declared in the ControlStatus message.	
ConstrainingPlans	AutonomousPlanningConstrainingPlansType	Optional
Description	Indicates existing types of *Plans that can be used as constraints when invoking the planning process indicated by the sibling PlanningProcessID. The types of *Plans indicated here should be consistent with those supported by the planning process as indicated in the ControlStatus message.	
OtherSystemConstrainingPlans	AutonomousPlanningOtherSystemConstrainingPlansType	Repeated
Description	Indicates existing plans of another System that constrain planning. One for each descendant ConstraintUsage.	
OutputPlanParts	MA_PlanPartsType	Optional
Description	Indicates the specific Plan parts of the sibling PlanningType that the System can produce and include in the output Plan. The child choice in this element should match the sibling PlanningType. When omitted, the System can produce all of the Plan parts for the sibling PlanningType.	
ResultsInMissionPlan	boolean	Required
Description	In some cases, the commanding service or HMI may not want to receive the planning process summarized in a MissionPlan message. If TRUE, the results will be published in individual *Plan messages and summarized in a published MissionPlan message. If FALSE, the results will be published in individual *Plan	

	messages without a summary MissionPlan message.	
ForPlanningUseOnly	boolean	Required
Description	Indicates the state to use for the corresponding element in the *PlanCommand when invoking the planning process.	

Table A-4-894: Peer Interface MA_PlanningFunctionSettingsCommandMT - AllowedType UCI Extension Field

AutonomousAction		
Description	Indicates the action or actions allowed for the sibling trigger.	
Base Type	MA_MissionPlanningByResultAutonomousActionType	
Message Structure		
Field Name	Field Type	Field Usage
PlanningAllowed	MA_PlanningAllowedType	Repeated
Description	This element defines the mission planning type to be triggered. If multiple instances are given, each should be of a different planning type as indicated by the child element.	
AlertOnly	EmptyType	Required
Description	This element indicates that autonomous mission planning isn't allowed for the ancestor Trigger but a MissionContingencyAlert is expected.	

Table A-4-895: Peer Interface MA_PlanningFunctionSettingsCommandMT - AutonomousAction UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the PlanningFunctionSettingsCommand message.	
Base Type	MA_PlanningFunctionSettingsCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Indicates the unique ID of the System whose planning functions settings are being commanded/changed.	
TransitionDroppedToFailed	boolean	Required
Description	This element specifies whether or not dropped Tasks that cannot be reallocated within the System can be automatically transitioned to the FAILED state for higher level interaction.	
PlanningInterface	PlanInterfaceCommandType	Repeated
Description	Indicates commanded settings for planning interfaces. If multiple instances of this element are given, each should be of a different type of *Plan as enumerated by the child PlanType element.	
MissionPlanningAutonomy	MA_MissionPlanningAutonomySettingType	Repeated
Description	Indicates commanded settings for autonomous mission planning capabilities of the System.	
PlanActivationAutonomy	PlanActivationAutonomyType	Optional

Description	Indicates commanded settings for autonomous plan activation capabilities of the System.	
RoutePlanningContingencyPath	ContingencyPathAutonomyType	Repeated
Description	Indicates commanded route planning settings for the autonomous generation of contingency paths along the primary path. If multiple instances are given, each must be of a different path type as indicated by the child element.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-896: Peer Interface MA_PlanningFunctionSettingsCommandMT - MessageData UCI Extension Field

ActivityPlan		
Description	Indicates applicable ActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	

ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-897: Peer Interface MA_PlanningFunctionSettingsCommandMT - ActivityPlan UCI Extension Field

TaskPlan		
Description	Indicates applicable TaskPlan parts.	
Base Type	MA_TaskPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
TaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	

Table A-4-898: Peer Interface MA_PlanningFunctionSettingsCommandMT - TaskPlan UCI Extension Field

4.2.92 MA_PlanningFunctionSettingsCommandStatusMT UCI Extension

MA_PlanningFunctionSettingsCommandStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_PlanningFunctionSettingsCommandStatusMDT

Table A-4-899: Peer Interface MA_PlanningFunctionSettingsCommandStatusMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the PlanningFunctionSettingsCommandStatus message.	
Base Type	MA_PlanningFunctionSettingsCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	

CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-900: Peer Interface MA_PlanningFunctionSettingsCommandStatusMT - MessageData UCI Extension Field

4.2.93 MA_ResponseActivityMT UCI Extension

MA_ResponseActivityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	RequirementInstantiation : MA_RequirementTemplateInstantiationType ActivatedPlans : MA_PlansReferenceType Activity : MA_ResponseActivityType MessageData : MA_ResponseActivityMDT ResultingPlans : MA_PlansReferenceType OpPlanID : MA_OpPlanID_Type

Table A-4-901: Peer Interface MA_ResponseActivityMT UCI Extension

RequirementInstantiation		
Description	Indicates an independent set of Requirement or Requirements and *Plans that were instantiated for the Response. Subsequent progress in planning and/or execution is given in [Requirement]Plan, [Requirement]Status, MissionPlan*, etc. messages.	
Base Type	MA_RequirementTemplateInstantiationType	
Message Structure		
Field Name	Field Type	Field Usage
RequirementID	RequirementInstanceID_ChoiceType	Repeated
Description	Indicates the unique ID of a Requirement that was instantiated as a result of the Response. Subsequent progress in planning and/or execution of the Requirement should be given in [Requirement]Plan, [Requirement]Status, etc. messages.	
ResultingPlans	MA_PlansReferenceType	Optional
Description	Indicates *Plans that were updated or created to include the sibling Requirements.	

Table A-4-902: Peer Interface MA_ResponseActivityMT - RequirementInstantiation UCI Extension Field

ActivatedPlans		
Description	Indicates *Plans that were activated for the Response.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage

MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-903: Peer Interface MA_ResponseActivityMT - ActivatedPlans UCI Extension Field

Activity		
Description	Indicates the dynamic operational characteristics of an Activity of an Response Capability.	
Base Type	MA_ResponseActivityType	
Message Structure		
Field Name	Field Type	Field Usage
InstantiationTime	DateTimeType	Required
Description	Indicates the time at which the Response was instantiated.	
OptionIndex	unsignedInt	Optional
Description	Indicates the specific Option within the Response that was instantiated.	
RequirementInstantiation	MA_RequirementTemplateInstantiationType	Repeated
Description	Indicates an independent set of Requirement or Requirements and *Plans that were instantiated for the Response. Subsequent progress in planning and/or execution is given in [Requirement]Plan, [Requirement]Status, MissionPlan*, etc. messages.	

ActivatedPlans	MA_PlansReferenceType	Optional
Description	Indicates *Plans that were activated for the Response.	
AlertID	MissionContingencyAlertID_Type	Optional
Description	Indicates a MissionContingencyAlert that was generated for the Response.	
ActivityID	ActivityID_Type	Required
Description	Indicates the unique ID of the Activity.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates a Capability which the Activity is an instance of. Generally an Activity is an instance of a single Capability. An Activity can be associated with multiple Capabilities when, for example, a Subsystem has distinct Capabilities for automated and manual. In this case, if a manual command is issued while an automated Activity that achieves the desired result already exists, a single Activity represents both Capabilities.	
Interactive	boolean	Required
Description	Indicates whether or not the Activity can be edited/modified via a [Capability]Command...Activity message.	
ActivityState	ActivityStateEnum	Required
Description	Indicates the current state of the Activity its state machine. See enumeration annotations for further details.	
Basis	ActivityBasisEnum	Optional
Description	Indicates the basis of the Activity. See enumerated type annotations for further details. If omitted, a basis of ACTUAL should be assumed.	
ActivityRank	ComparableRankingType	Optional
Description	Indicates the rank of the Activity amongst all other Activities of the Capability and/or Subsystem. This isn't necessarily the same as the Rank associated with the sibling ActivitySource. This element is meant to convey the Subsystem determined relative ranking of all Activities of a Capability category (ESM, EA, etc.). For Subsystems with multiple Capability categories this element is meant to convey relative ranking across all Capability categories. In addition to the rank of the ActivitySource, an Activity's rank can be influenced by Capability priority (see CapabilitySettings), RF_ControlCommands and other factors that influence the Subsystem's internal scheduling and resource allocation.	
ActivityReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling ActivityState element. This element is only expected when the Activity is in a potentially undesirable state such as constrained, failed or completed with less than optimum results.	
Source	ActivitySourceType	Repeated
Description	Indicates an originating "source" of the Activity; the command or other item which invoked this specific Activity of a Capability. A single Activity can fully or partially satisfy Activity sources.	
EstimatedStartTime	DateTimeType	Optional
Description	Indicates the estimated time when the Activity started or is expected to start.	
EstimatedCompletionTime	DateTimeType	Optional

Description	Indicates the estimated time when the Activity will complete.	
EstimatedPercentComplete	PercentType	Optional
Description	Indicates the current estimated percent complete of the Activity.	

Table A-4-904: Peer Interface MA_ResponseActivityMT - Activity UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ResponseActivityMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Indicates the System which hosts the Response Capabilities whose Activities are given in this message.	
Activity	MA_ResponseActivityType	Repeated
Description	Indicates the dynamic operational characteristics of an Activity of an Response Capability.	

Table A-4-905: Peer Interface MA_ResponseActivityMT - MessageData UCI Extension Field

ResultingPlans		
Description	Indicates *Plans that were updated or created to include the sibling Requirements.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	

EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-906: Peer Interface MA_ResponseActivityMT - ResultingPlans UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-907: Peer Interface MA_ResponseActivityMT - OpPlanID UCI Extension Field

4.2.94 MA_TaskStatusMT UCI Extension

MA_TaskStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	Plans : MA_PlansReferenceType OpPlanID : MA_OpPlanID_Type ExecutingSystemOrPackage : MA_PackageSystemType MessageData : MA_TaskStatusMDT Traceability : MA_RequirementStatusTraceabilityType

Table A-4-908: Peer Interface MA_TaskStatusMT UCI Extension

Plans		
Description	Indicates *Plans the Requirement is associated with.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-909: Peer Interface MA_TaskStatusMT - Plans UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new	

	version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-910: Peer Interface MA_TaskStatusMT - OpPlanID UCI Extension Field

ExecutingSystemOrPackage		
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-911: Peer Interface MA_TaskStatusMT - ExecutingSystemOrPackage UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_TaskStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
TaskID	TaskID_Type	Required
Description	Indicates the unique ID of the Task whose execution status is being reported.	
ExecutingSystemOrPackage	MA_PackageSystemType	Required
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	

ExecutionState	RequirementExecutionStateEnum	Required
Description	Identifies the state of the Requirement.	
ExecutionStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling State element. This element is only expected when the State is in a potentially undesirable state such as failed or completed with less than optimum results. It is strongly encouraged for transitions to failed or dropped.	
ActualTiming	RequirementTimingType	Repeated
Description	Indicates actual timing status for the Requirement. Allows for defining for each timing type (RequirementTimingEnum).	
PercentCompleted	PercentType	Optional
Description	Percentage of assigned Requirement completion. The percentage increments until the Requirement has COMPLETED or FAILED. A percent complete of 0 indicates the Requirement has not yet begun execution, and a failed Requirement may have any percentage between 1 - 99.	
Traceability	MA_RequirementStatusTraceabilityType	Optional
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.	
Metrics	MetricsType	Optional
Description	Specifies the actual metrics associated with the Requirements.	

Table A-4-912: Peer Interface MA_TaskStatusMT - MessageData UCI Extension Field

Traceability	
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.

Base Type	MA_RequirementStatusTraceabilityType	
Message Structure		
Field Name	Field Type	Field Usage
Plans	MA_PlansReferenceType	Optional
Description	Indicates *Plans the Requirement is associated with.	
PlannedActivityID	PlannedActivityID_Type	Repeated
Description	Indicates a specific Planned Activity the Requirement is associated with.	
CapabilityID	CapabilityID_Type	Repeated
Description	Identifies a specific Capability the Requirement is associated with.	
CommandID	CommandID_Type	Repeated
Description	Indicates the ID of an associated [Capability]Command.	
ActivityID	ActivityID_Type	Repeated
Description	Indicates the ID of an associated actual/executing/executed Activity.	

Table A-4-913: Peer Interface MA_TaskStatusMT - Traceability UCI Extension Field

4.2.95 MA_PlanModificationRequestMT UCI Extension

MA_PlanModificationRequestMT	
Description	Indicates the contents of the PlanModificationRequest message details, and also includes the message header. See the XSD File for more info
Ext. Fields	SubPlansAdditions : MA_PlansReferenceBaseType SubPlansRetractions : MA_PlansReferenceBaseType SubPlansModification : MA_SubPlansModificationType PlanModificationDetails : MA_PlanModificationDetailsType MessageData : MA_PlanModificationRequestMDT Plans : MA_PlansReferenceType OpPlanID : MA_OpPlanID_Type

Table A-4-914: Peer Interface MA_PlanModificationRequestMT UCI Extension

SubPlansAdditions		
Description	Indicates an additional set of *Plans which are included as part of the MissionPlan. The included SubPlans share the same Applicability as the MissionPlan.	
Base Type	MA_PlansReferenceBaseType	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlanID	TaskPlanID_Type	Repeated

Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-915: Peer Interface MA_PlanModificationRequestMT - SubPlansAdditions UCI Extension Field

SubPlansRetractions		
Description	Indicates the removal of set of *Plans which are included as part of the MissionPlan.	
Base Type	MA_PlansReferenceBaseType	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	

ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-916: Peer Interface MA_PlanModificationRequestMT - SubPlansRetractions UCI Extension Field

SubPlansModification		
Description	Indicates a change in the set of *Plans which are included as part of the MissionPlan. See annotations for the underlying type and its child elements for details.	
Base Type	MA_SubPlansModificationType	
Message Structure		
Field Name	Field Type	Field Usage
SubPlansAdditions	MA_PlansReferenceBaseType	Optional
Description	Indicates an additional set of *Plans which are included as part of the MissionPlan. The included SubPlans share the same Applicability as the MissionPlan.	
SubPlansRetractions	MA_PlansReferenceBaseType	Optional
Description	Indicates the removal of set of *Plans which are included as part of the MissionPlan.	

Table A-4-917: Peer Interface MA_PlanModificationRequestMT - SubPlansModification UCI Extension Field

PlanModificationDetails		
Description	Specifies details of the plan modification.	
Base Type	MA_PlanModificationDetailsType	
Message Structure		
Field Name	Field Type	Field Usage
ForPlanningUseOnly	boolean	Optional
Description	When TRUE, indicates the *Plan is a used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
WindowModification	PlanWindowModificationTypeChoiceType	Optional
Description	Specifies an absolute time Window or alternatively a TimeOffset by which the Plan's, or set of Plans', Windows should be shifted.	

ApplicabilityModification	PlanApplicabilityModificationType	Optional
Description	Indicates a change in the System or Systems which have a direct relationship with the Mission Plan. See annotations for the underlying type and its child elements for details.	
SubPlansModification	MA_SubPlansModificationType	Optional
Description	Indicates a change in the set of *Plans which are included as part of the MissionPlan. See annotations for the underlying type and its child elements for details.	
HierarchyModification	HierarchyModificationType	Optional
Description	Indicates a change in the hierarchy of the set of MissionPlans.	
ExecutionSequenceModification	ExecutionSequenceReplaceOrModifyChoiceType	Optional
Description	Indicates a change in the execution sequence of the set of *Plans.	
RequirementAllocationLock	RequirementAllocationLockDetailsType	Optional
Description	Indicates a requested change in Allocated Requirements to Lock or Unlock.	

Table A-4-918: Peer Interface MA_PlanModificationRequestMT - PlanModificationDetails UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PlanModificationRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
Source	PlanInitiationSourceEnum	Required
Description	Source of the plan modification request.	
Plans	MA_PlansReferenceType	Required
Description	Indicates the Plan, or set of Plans, for which this Plan Modification Request is applicable.	
PlanModificationDetails	MA_PlanModificationDetailsType	Required
Description	Specifies details of the plan modification.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-919: Peer Interface MA_PlanModificationRequestMT - MessageData UCI Extension Field

Plans	
Description	Indicates the Plan, or set of Plans, for which this Plan Modification Request is applicable.
Base Type	MA_PlansReferenceType

Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-920: Peer Interface MA_PlanModificationRequestMT - Plans UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal	

	digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-921: Peer Interface MA_PlanModificationRequestMT - OpPlanID UCI Extension Field

4.2.96 MA_PlanModificationRequestStatusMT UCI Extension

MA_PlanModificationRequestStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_PlanModificationRequestStatusMDT

Table A-4-922: Peer Interface MA_PlanModificationRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PlanModificationRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-923: Peer Interface MA_PlanModificationRequestStatusMT - MessageData UCI Extension Field

4.2.97 MA_ConstraintPriorityListActivationDataMT UCI Extension

MA_ConstraintPriorityListActivationDataMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ConstraintPriorityListActivationDataMDT

Table A-4-924: Peer Interface MA_ConstraintPriorityListActivationDataMT UCI Extension

MessageData

Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ConstraintPriorityListActivationDataMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConstraintPriorityListActivationDataID	MA_ConstraintPriorityListActivationDataID_Type	Required
Description	The unique identifier for the message.	
DefaultConstraintPriorityListID	MA_ConstraintPriorityListID_Type	Required
Description	Contains the ID of the Constraint Priority List that should be set as the default.	
ListOfApplicableOpConstrainedConstraintPriorityListIDs	MA_ListOfApplicableOpConstrainedConstraintPriorityListIDType	Repeated
Description	When an Package/ACP is within this geozone, the linked Constraint Priority List will be used instead of the default. OpZone and OpVolume IDs can only appear once in this list.	

Table A-4-925: Peer Interface MA_ConstraintPriorityListActivationDataMT - MessageData UCI Extension Field

4.2.98 MA_ConstraintPriorityListMT UCI Extension

MA_ConstraintPriorityListMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ConstraintPriorityListMDT

Table A-4-926: Peer Interface MA_ConstraintPriorityListMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ConstraintPriorityListMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConstraintPriorityListID	MA_ConstraintPriorityListID_Type	Required
Description	The unique identifier for the message.	
DefaultPriority	unsignedShort	Optional
Description	This field, if set, is the value that would be assigned to any ConstraintType that is not listed in the ListItem field. If this field is not set, the default value of ConstraintTypes not listed the ListItem field would be blank or the highest priority ("above" 0).	
ListItem	MA_ConstraintPriorityListItemType	Repeated

Description	Identifies a constraint type and it's priority in the Constraint Priority List.
-------------	---

Table A-4-927: Peer Interface MA_ConstraintPriorityListMT - MessageData UCI Extension Field

4.2.99 MA_EscortActivityMT UCI Extension

MA_EscortActivityMT	
Description	This message indicates the combined in-work and to-do list of the Escort Capability of a Subsystem of a System. In general, a [Capability]Activity message describes what invoked Capabilities are doing. It is generally a complete, coherent snapshot of all Activities of a Subsystem for an entire Capability category (such as ESM, AirSample, EA, etc.). In other words, an Activity is the dynamic, per-use/per-invocation status of a Capability. An Activity is an abstraction that includes 1) the autonomous (MDF-driven or MissionPlan-driven) activity of a Capability, 2) the activity resulting from manual commands (EscortCommand) from an Operator or Capability management Service, 3) currently in-work Escort, 4) Escort scheduled for the future and 5) Escort that was scheduled and/or attempted but couldn't be completed due to resource limitations or other reasons. A single EscortCommand or other triggering event can result in multiple activities within the EscortActivity message. See the XSD File for more info
Ext. Fields	MessageData : MA_EscortActivityMDT

Table A-4-928: Peer Interface MA_EscortActivityMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_EscortActivityMDT	
Message Structure		
Field Name	Field Type	Field Usage
SubsystemID	SubsystemID_Type	Required
Description	Indicates the Subsystem which hosts the Escort Capabilities whose Activities are given in this message.	
Activity	MA_EscortActivityType	Repeated
Description	Indicates the dynamic operational characteristics of an Activity of an Escort Capability.	

Table A-4-929: Peer Interface MA_EscortActivityMT - MessageData UCI Extension Field

4.2.100 MA_PositionReportDetailedMT UCI Extension

MA_PositionReportDetailedMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	PositionReportData : MA_PositionReportDataType MessageData : MA_PositionReportDetailedMDT

Table A-4-930: Peer Interface MA_PositionReportDetailedMT UCI Extension

PositionReportData		
Description	If multiple instances are given, each should be of a different navigation solution type as indicated by the child element.	
Base Type	MA_PositionReportDataType	
Message Structure		
Field Name	Field Type	Field Usage
PositionSource	PositionSourceID_ChoiceType	Required
Description	The source of the positional data.	
ComponentID	ComponentID_Type	Optional
Description	The ID of the specific component within the subsystem that is the source of this data. This can be used if multiple redundant INS/GPS units are represented as a single subsystem.	
NavigationSolutionState	NavigationSolutionStateEnum	Required
Description	The navigation solution state indicates what sensor inputs the navigation unit is using to generate its kinematic solution.	
FigureOfMerit	BytePositiveType	Optional
Description	A FOM is typically calculated as the root-sum-square of the estimated errors contributing to the solution accuracy. Example criteria include: a. GPS receiver state (e.g., carrier tracking, code tracking, acquisition) b. Carrier to noise ratio c. Satellite geometry (DOP value) d. Satellite range accuracy (URA value) e. Ionospheric measurement or modeling error f. Receiver aiding used g. Kalman filter error estimates. The resultant FOM is presented as a numerical value from 1 to 9, where 1 indicates the best navigation performance.	
Kinematics	MA_DetailedKinematicsType	Required
Description	The kinematic state of the vehicle.	
KinematicsError	DetailedKinematicsErrorType	Required
Description	Indicates the covariance matrix of the vehicle, containing detailed kinematic errors of the position, velocity, and orientation. See the DetailedKinematicsErrorType element annotations for details.	

SolutionCorrections	NavigationSolutionCorrectionsType	Optional
Description	This element contains the corrections applied by the measurement unit to the reported values.	

Table A-4-931: Peer Interface MA_PositionReportDetailedMT - PositionReportData UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PositionReportDetailedMDT	
Message Structure		
Field Name	Field Type	Field Usage
PositionReportData	MA_PositionReportDataType	Repeated
Description	If multiple instances are given, each should be of a different navigation solution type as indicated by the child element.	

Table A-4-932: Peer Interface MA_PositionReportDetailedMT - MessageData UCI Extension Field

4.2.101 MA_EngagementCriteriaMT UCI Extension

MA_EngagementCriteriaMT		
Description	See annotations in child elements and messages/elements that use this type for details.	
	See the XSD File for more info	
Ext. Fields	MessageData : MA_EngagementCriteriaMDT	

Table A-4-933: Peer Interface MA_EngagementCriteriaMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_EngagementCriteriaMDT	
Message Structure		
Field Name	Field Type	Field Usage
EngagementCriteriaID	MA_EngagementCriteriaID_Type	Required
Description	The unique identifier for the message.	
IdMatrixCriteria	MA_IdMatrixCriteriaType	Optional
Description	These markers are used to identify an Entity as a Friend, Neutral, or Enemy and which enables or confirms the Entity's Standard Identity type to be set to FRIEND, NEUTRAL, SUSPECT or HOSTILE.	
TargetDesignationCriteria	MA_TargetDesignationCriteriaType	Repeated
Description	This provides a list of criteria that when met can trigger a MA_DesignationRequestMT to be sent to a Target Authority who can use the info in this message to send a MA_DesignationMT that will designate an Entity as a Target.	
TargetAuthorityCriteria	MA_AuthorityCriteriaType	Optional

Description	This provides a list of Authorized Operators that are allowed to set an Entity as a Target and to respond to a StrikeConsentRequestMT. An Entity becomes a Target when a Designation message declares that entity to be a Target. This can also be done by an Action or Task specifying an Entity as a Target (TargetType). The associated Approval Policy will specify which Actions or Tasks make an Entity a Target and who is authorized to command them or approve a response that activates them. MA can send a MA_DesignationRequestMT to Operators identified in the Approval Authority. An Authorized operator can also directly send a MA_DesignationMT. An MA can be an authorized approver if specified, but an MA cannot send a MA_DesignationMT for itself. A Lead can send a MA_DesignationMT to a follower if a C2 has already approved the Target.	
TargetCustodyCriteria	MA_TargetCustodyCriteriaType	Repeated
Description	This describes how the Custody of a Target is confirmed and must be held through a Weapons Engagement with that Target.	
StrikeConsentRequired	boolean	Required
Description	Indicates whether (TRUE) or not (FALSE) the Strike Activities requires consent to transition from the ENABLED state to an ACTIVE state. If TRUE, each Strike Activity would be required to send a StrikeConsentRequestMT to an Authorized Operator (defined in the TargetAuthorityCriteria field) and receive a StrikeConsentRequestStatusMT before each Strike Activity can execute the Strike.	

Table A-4-934: Peer Interface MA_EngagementCriteriaMT - MessageData UCI Extension Field

4.2.102MA_ExecutionPriorityListMT UCI Extension

MA_ExecutionPriorityListMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ExecutionPriorityListMDT

Table A-4-935: Peer Interface MA_ExecutionPriorityListMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ExecutionPriorityListMDT	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPriorityListID	MA_ExecutionPriorityListID_Type	Required
Description	The unique identifier for the message.	
ListItem	MA_ExecutionPriorityListItemType	Repeated
Description	Identifies an item (task or action) and its rank in the Execution Priority List.	

Table A-4-936: Peer Interface MA_ExecutionPriorityListMT - MessageData UCI Extension Field

4.2.103MA_ExecutionPriorityListActivationDataMT UCI Extension

MA_ExecutionPriorityListActivationDataMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ExecutionPriorityListActivationDataMDT

Table A-4-937: Peer Interface MA_ExecutionPriorityListActivationDataMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ExecutionPriorityListActivationDataMDT	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPriorityListActivationDataID	MA_ExecutionPriorityListActivationDataID_Type	Required
Description	The unique identifier for the message.	
DefaultExecutionPriorityListID	MA_ExecutionPriorityListID_Type	Required
Description	Contains the ID of the message that should be set as the default.	
ListOfApplicableOpConstrainedExecutionPriorityListIDs	MA_ListOfApplicableOpConstrainedExecutionPriorityListIDType	Repeated
Description	When an ACP is within this geozone, the linked message will be used instead of the default. OpZone and OpVolume IDs can only appear once in this list.	

Table A-4-938: Peer Interface MA_ExecutionPriorityListActivationDataMT - MessageData UCI Extension Field

4.2.104MA_MessageAcknowledgmentConfigurationMT UCI Extension

MA_MessageAcknowledgmentConfigurationMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_MessageAcknowledgmentConfigurationMDT

Table A-4-939: Peer Interface MA_MessageAcknowledgmentConfigurationMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_MessageAcknowledgmentConfigurationMDT

Message Structure		
Field Name	Field Type	Field Usage
DefaultGroupMessageFreq	DurationType	Optional
Description	If set, this provides the frequency at which the Grouped Acknowledgment message is set at. If not set there is no grouping.	
DefaultMessagesToAck	MA_AckMessageEnum	Repeated
Description	If set, the list of messages that an Acknowledgment message will be sent for when received. If not set all messages of the type will be responded to.	
ReceiverSpecificSettings	MA_AckReceiverSpecificConfigType	Repeated
Description	This is the list of individual configuration settings that a remote system is configured. Values in this will override the Default settings.	
ConfigurationSupported	boolean	Required
Description	If FALSE, the publisher does not support grouping, they expect acknowledgments for messages covered by this configuration, and will reject all configuration requests. If TRUE, the publisher supports individual configurations, grouping, and the other items in this collection of messages.	

Table A-4-940: Peer Interface MA_MessageAcknowledgmentConfigurationMT - MessageData UCI Extension Field

4.2.105 MA_MessageAcknowledgmentConfigurationRequestMT UCI Extension

MA_MessageAcknowledgmentConfigurationRequestMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_MessageAcknowledgmentConfigurationRequestMDT

Table A-4-941: Peer Interface MA_MessageAcknowledgmentConfigurationRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_MessageAcknowledgmentConfigurationRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
DefaultGroupMessageFreq	DurationType	Optional
Description	This will override the current DefaultGroupMessageFreq setting.	
DefaultMessagesToAck	MA_AckMessageEnum	Repeated
Description	This will override the current DefaultMessageToAck setting.	
RequestedReceiverSpecificSetting	MA_AckReceiverSpecificConfigType	Optional
Description	This is an individual configuration settings that is being requested to be configured.	

RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-942: Peer Interface MA_MessageAcknowledgmentConfigurationRequestMT - MessageData UCI Extension Field

4.2.106MA_MessageAcknowledgmentConfigurationRequestStatusMT UCI Extension

MA_MessageAcknowledgmentConfigurationRequestStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_MessageAcknowledgmentConfigurationRequestStatusMDT

Table A-4-943: Peer Interface MA_MessageAcknowledgmentConfigurationRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_MessageAcknowledgmentConfigurationRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-944: Peer Interface MA_MessageAcknowledgmentConfigurationRequestStatusMT - MessageData UCI Extension Field

4.2.107MA_ResponseCommandMT UCI Extension

MA_ResponseCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ResponseCommandMDT

Table A-4-945: Peer Interface MA_ResponseCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ResponseCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Command	MA_ResponseCommandType	Repeated
Description	Indicates an instance of an Response Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Capability CommandStatus message.	

Table A-4-946: Peer Interface MA_ResponseCommandMT - MessageData UCI Extension Field

4.2.108MA_ResponseCommandStatusMT UCI Extension

MA_ResponseCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ResponseCommandStatusMDT

Table A-4-947: Peer Interface MA_ResponseCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ResponseCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	
CommandID	CommandID_Type	Required

Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-948: Peer Interface MA_ResponseCommandStatusMT - MessageData UCI Extension Field

4.2.109 MA_PlatformOverrideStatusMT UCI Extension

MA_PlatformOverrideStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_PlatformOverrideStatusMDT

Table A-4-949: Peer Interface MA_PlatformOverrideStatusMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_PlatformOverrideStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlatformOverrideStatus	MA_PlatformDefaultAndOverrideDataType	Repeated
Description	Indicates the current platform override setting(s) applied.	
ActiveOverrides	boolean	Required
Description	When TRUE, indicates one or more overrides are active. When FALSE, indicates no overrides are active.	
ExecutingSystemOrPackage	MA_PackageSystemType	Required
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
ExecutionState	RequirementExecutionStateEnum	Required
Description	Identifies the state of the Requirement.	
ExecutionStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling State element. This element is only expected when the State is in a potentially	

	undesirable state such as failed or completed with less than optimum results. It is strongly encouraged for transitions to failed or dropped.	
ActualTiming	RequirementTimingType	Repeated
Description	Indicates actual timing status for the Requirement. Allows for defining for each timing type (RequirementTimingEnum).	
PercentCompleted	PercentType	Optional
Description	Percentage of assigned Requirement completion. The percentage increments until the Requirement has COMPLETED or FAILED. A percent complete of 0 indicates the Requirement has not yet begun execution, and a failed Requirement may have any percentage between 1 - 99.	
Traceability	MA_RequirementStatusTraceabilityType	Optional
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.	
Metrics	MetricsType	Optional
Description	Specifies the actual metrics associated with the Requirements.	

Table A-4-950: Peer Interface MA_PlatformOverrideStatusMT - MessageData UCI Extension Field

4.2.110MA_GatewayActivityMT UCI Extension

MA_GatewayActivityMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ObjectState : ObjectStateEnum MessageData : MA_GatewayActivityMDT

Table A-4-951: Peer Interface MA_GatewayActivityMT UCI Extension

ObjectState	
Description	Indicates the state of the internal software object that the data in the message is based upon. The state of the software object is determined by the publisher. The publisher could be the original/master publisher or an intermediary re-publisher such as a persistence/data manager. This element is not a commanded CRUD operation. It is not an indication of the state of an instance of a message. It is not a mechanism for partial, incremental, or fragmentary publication of a message. It is a signal from a publisher to subscribers. For

	REMOVED state, in particular, some subscribers will mirror the publisher and treat the message as if the object no longer exists, but others, such as mission recorders, might not (in order to support retaining historical records of activity, for example).
Base Type	ObjectStateEnum
Message Structure	
Enumeration Literal	Description
NEW	Indicates the internal software object corresponding to this message currently exists and this message is the first publication corresponding to the object.
UPDATED	Indicates the internal software object corresponding to this message currently exists and has been updated since the last publication of the message; this publication of the message may contain updates.
REMOVED	Indicates the internal software object corresponding to this message no longer exists; there should be no further publications of this message corresponding to the object.

Table A-4-952: Peer Interface MA_GatewayActivityMT - ObjectState UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_GatewayActivityMDT	
Message Structure		
Field Name	Field Type	Field Usage
GatewayServiceID	ServiceID_Type	Required
Description	This element represents the ServiceID of the Gateway Service that sent this message.	
Activity	MA_GatewayActivityType	Repeated
Description	Indicates the dynamic operational characteristics of an Activity of a GatewayCapability.	

Table A-4-953: Peer Interface MA_GatewayActivityMT - MessageData UCI Extension Field

4.2.111 MA_DataDisseminationPlanOverrideRequestMT UCI Extension

MA_DataDisseminationPlanOverrideRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanOverrideRequestMDT

Table A-4-954: Peer Interface MA_DataDisseminationPlanOverrideRequestMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_DataDisseminationPlanOverrideRequestMDT

Message Structure		
Field Name	Field Type	Field Usage
AllocatedToSystemIDs	MA_PackageSystemType	Repeated
Description	Indicates the unique ID of the system(s) or package that is the recipient of this command.	
AllocatedToServiceID	ServiceID_Type	Optional
Description	Indicates the unique ID of the service that is the recipient of this command.	
Request	MA_DataDisseminationPlanOverrideRequestType	Repeated
Description	Indicates an instance of a data plan override request. A data plan override request message can have multiple request instances to allow a sequence of related requests in a single coherent message. Each request instance reports status via a separate, independent DataPlanOverrideRequestStatus message.	

Table A-4-955: Peer Interface MA_DataDisseminationPlanOverrideRequestMT - MessageData UCI Extension Field

4.2.112MA_DataDisseminationPlanOverrideRequestStatusMT UCI Extension

MA_DataDisseminationPlanOverrideRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanOverrideRequestStatusMDT

Table A-4-956: Peer Interface MA_DataDisseminationPlanOverrideRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanOverrideRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MA_DataDisseminationPlanID_Type	Required
Description	Indicates the unique ID of the DataDisseminationPlan that this override modification status applies to.	
EffectivityActivationStatus	DataPlanEffectivityActivationStatusType	Repeated
Description	This element indicates the status of pre-mission planned Data-Link gateway settings. It is used to indicate details about specific planned effectivity activations.	
OperatorModificationStatus	OperatorGatewayDesignationStatusType	Repeated
Description	This element indicates the status of operator designations. It is used to indicate details about specific designation configurations.	
RequestID	RequestID_Type	Required

Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-957: Peer Interface MA_DataDisseminationPlanOverrideRequestStatusMT - MessageData UCI Extension Field

4.2.113MA_DataDisseminationPlanActivationCommandStatusMT UCI Extension

MA_DataDisseminationPlanActivationCommandStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanActivationCommandStatusMDT

Table A-4-958: Peer Interface MA_DataDisseminationPlanActivationCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanActivationCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-959: Peer Interface MA_DataDisseminationPlanActivationCommandStatusMT - MessageData UCI Extension Field

4.2.114 MA_DataDisseminationPlanActivationCommandMT UCI Extension

MA_DataDisseminationPlanActivationCommandMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanActivationCommandMDT

Table A-4-960: Peer Interface MA_DataDisseminationPlanActivationCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanActivationCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MA_DataDisseminationPlanID_Type	Required
Description	The DataDisseminationPlan that this command pertains to.	
CommandedState	PlanActivationCommandEnum	Required
Description	Indicates the activation to perform on the associated DataDisseminationPlan. See enumerate annotations for further details.	
Applicability	MA_PackageSystemType	Repeated
Description	The System or Package IDs, that this message applies to. A lead is able to respond with ACCEPTED for the Package or individual Systems as needed.	
EffectivityActivation	MA_DataDisseminationPlanEffectivityActivationType	Repeated
Description	Indicates an Effectivity of the DataDisseminationPlan to activate.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-961: Peer Interface MA_DataDisseminationPlanActivationCommandMT - MessageData UCI Extension Field

4.2.115 MA_DataDisseminationPlanMT UCI Extension

MA_DataDisseminationPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info

Ext. Fields	ObjectState : ObjectStateEnum
	MessageData : MA_DataDisseminationPlanMDT

Table A-4-962: Peer Interface MA_DataDisseminationPlanMT UCI Extension

ObjectState	
Description	Indicates the state of the internal software object that the data in the message is based upon. The state of the software object is determined by the publisher. The publisher could be the original/master publisher or an intermediary re-publisher such as a persistence/data manager. This element is not a commanded CRUD operation. It is not an indication of the state of an instance of a message. It is not a mechanism for partial, incremental, or fragmentary publication of a message. It is a signal from a publisher to subscribers. For REMOVED state, in particular, some subscribers will mirror the publisher and treat the message as if the object no longer exists, but others, such as mission recorders, might not (in order to support retaining historical records of activity, for example).
Base Type	ObjectStateEnum
Message Structure	
Enumeration Literal	Description
NEW	Indicates the internal software object corresponding to this message currently exists and this message is the first publication corresponding to the object.
UPDATED	Indicates the internal software object corresponding to this message currently exists and has been updated since the last publication of the message; this publication of the message may contain updates.
REMOVED	Indicates the internal software object corresponding to this message no longer exists; there should be no further publications of this message corresponding to the object.

Table A-4-963: Peer Interface MA_DataDisseminationPlanMT - ObjectState UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MA_DataDisseminationPlanID_Type	Required
Description	Indicates the unique ID of the DataDisseminationPlan.	
AssociatedPlanID	MA_DataDisseminationPlanID_Type	Repeated
Description	Indicates the unique ID of a DataDisseminationPlan that is a parent to this one.	
Applicability	MA_PlanApplicabilityType	Repeated
Description	Indicates the System or Systems which have a direct relationship with the DataDisseminationPlan. See annotations for the underlying type and its child elements for details. If Applicability is not defined then it indicates this DataDisseminationPlan applies to ALL systems.	

IER	MA_CommIER_Planned_Type	Repeated
Description	Indicates a planned Information Exchange Requirement (IER). An IER can reflect the information needs of local or remote Systems or third party Systems coordinating on behalf of other Systems. The planned assignment of an IER to comms resources is given in the sibling Effectivity element.	
IER_DesiredService	MA_CommIER_DesiredServicesType	Repeated
Description	Defines the desired service constraints for an IER (Information Exchange Requirement), allowing multi-constrained solutions. All child elements are optional; when omitted software should apply no explicit bound for that metric.	
RateGroup	MA_CommRateGroupType	Repeated
Description	Indicates a RateGroup that can be associated with an IER to configure its transmit rate.	
Effectivity	MA_CommDataDisseminationEffectivityType	Repeated
Description	Indicates a DataDisseminationPlan "effectivity set" of items that are used together.	
Vector	MA_CommVectorPlannedType	Repeated
Description	Indicates a planned Vector. A vector describes a logical connection between nodes initiating on a specific NetworkLink (comms resource).	
DistributionGroup	MA_DistributionGroupType	Repeated
Description	Indicates a grouping of tiles or node groups and associated ip address.	
DistributionGroupMembership	MA_DistributionGroupMembershipType	Repeated
Description	Indicates a system's membership to a multicast group.	
Gateway	MA_GatewayReferenceType	Repeated
Description	Indicates a planned Gateway local to the system for which this DataDisseminationPlan is applicable to, with a summary of its Capability to be used for dissemination of IERs in the DataDisseminationPlan.	
Trigger	MA_CommTriggerType	Repeated
Description	Signifies available triggers which would automatically invoke this DataDisseminationPlan or parts within this DataDisseminationPlan. These Triggers that can be associated with activation of an Effectivity by using the TriggerID.	

Table A-4-964: Peer Interface MA_DataDisseminationPlanMT - MessageData UCI Extension Field

4.2.116MA_DataDisseminationPlanActivationStatusMT UCI Extension

MA_DataDisseminationPlanActivationStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanActivationStatusMDT

Table A-4-965: Peer Interface MA_DataDisseminationPlanActivationStatusMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type

	for details.	
Base Type	MA_DataDisseminationPlanActivationStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MA_DataDisseminationPlanID_Type	Required
Description	The ID of the DataDisseminationPlan this status pertains to.	
ActivationState	PlanActivationStateEnum	Required
Description	Indicates the activation state of the associated DataDisseminationPlan.	
StateReason	MA_CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling ActivationState element.	
EffectivityActivationState	MA_DataDisseminationPlanEffectivityStateType	Repeated
Description	Indicates the activation state of an Effectivity of the associated DataDisseminationPlan.	
OverrideModificationState	MA_OverriderModificationStatusType	Repeated
Description	This element indicates the status of operator designations. It is used to indicate details about specific designation configurations.	

Table A-4-966: Peer Interface MA_DataDisseminationPlanActivationStatusMT - MessageData UCI Extension Field

4.3 Mission Plan Interface

4.3.1 MA_EffectCapabilityMT UCI Extension

MA_EffectCapabilityMT	
Description	This message represents the Effect category of UCI Capability. See the XSD File for more info
Ext. Fields	AssociatedTaskType : TaskTypeEnum

Table A-4-967: Mission Plan Interface MA_EffectCapabilityMT UCI Extension

AssociatedTaskType	
Description	Indicates a Task type associated with the Effect. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.
Base Type	TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.
AO	Indicates the task is to employ an Active Optical capability.

CARGO_DELIVERY	Indicates the task is to deliver cargo.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.
SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.
SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-968: Mission Plan Interface MA_EffectCapabilityMT - AssociatedTaskType UCI Extension Field

4.3.2MA_EntityMT UCI Extension

MA_EntityMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ObjectState : ObjectStateEnum MessageData : MA_EntityMDT

Table A-4-969: Mission Plan Interface MA_EntityMT UCI Extension

ObjectState	
Description	Indicates the state of the internal software object that the data in the message is based upon. The state of the software object is determined by the publisher. The publisher could be the original/master publisher or an intermediary re-publisher such as a persistence/data manager. This element is not a commanded CRUD operation. It is not an indication of the state of an instance of a message. It is not a mechanism for partial, incremental, or fragmentary publication of a message. It is a signal from a publisher to subscribers. For

	REMOVED state, in particular, some subscribers will mirror the publisher and treat the message as if the object no longer exists, but others, such as mission recorders, might not (in order to support retaining historical records of activity, for example).
Base Type	ObjectStateEnum
Message Structure	
Enumeration Literal	Description
NEW	Indicates the internal software object corresponding to this message currently exists and this message is the first publication corresponding to the object.
UPDATED	Indicates the internal software object corresponding to this message currently exists and has been updated since the last publication of the message; this publication of the message may contain updates.
REMOVED	Indicates the internal software object corresponding to this message no longer exists; there should be no further publications of this message corresponding to the object.

Table A-4-970: Mission Plan Interface MA_EntityMT - ObjectState UCI Extension Field

MessageData		
Description	Defines the characteristics of this Entity.	
Base Type	MA_EntityMDT	
Message Structure		
Field Name	Field Type	Field Usage
EntityID	EntityID_Type	Required
Description	This element represents the unique identifier of the entity.	
CreationTimestamp	DateTimeSigmaType	Required
Description	Indicates the time at which the Entity was initially detected and/or created.	
Source	EntitySourceType	Required
Description	Indicates the System and other details regarding the Source of the Entity. Summarizes the creation and correlation ancestry of the Entity. A given Entity has a single source but could be the result of fusion of multiple Entity children.	
EntityStatus	EntityStatusEnum	Required
Description	Indicates the status of an Entity. This includes early status (POTENTIAL, TENTATIVE), active status (CONFIRMED), inactive status (DROP_PENDING), end status (DROPPED, DESTROYED), or unknown status (MISSING, UNKNOWN, GHOST).	
OperationalStatus	OB_OperationalStatusEnum	Optional
Description	Indicates the degree to which the real world asset which the Entity represents is ready to perform the overall operational mission or missions for which it was organized and equipped. An Entity with this element specified will generally have an xOB contributor reference which can be used to query for additional xOB data that isn't duplicated in Entity. Thus, for example, when an enum value of "O" is used refer to available xOB OperationalStatus elements.	
Identity	EntityIdentityType	Required

	Description	This element represents the identity of the Entity. In UCI, Entity and therefore this element are abstracted to a level comparable to MIL-STD-6016 J3.X messages. In particular, the identity taxonomy used in this element is derived directly from MIL-STD-6016. It is left to applications using UCI to enforce compatibility with the portions of MIL-STD-6016 referenced herein.
SiteEntityID	EntityID_Type	Repeated
	Description	Indicates the unique ID of an Entity that is a part of this Site Entity. When omitted, the Entity is not a Site. When one or more are given, this Entity is a Site.
Mobility	MobilityEnum	Optional
	Description	Indicates the mobility of the Entity. Omission is equivalent to the enumerate UNDETERMINED.
Kinematics	KinematicsType	Optional
	Description	Indicates the current kinematic information for the Entity. "Current" is subjective and varies widely by application. For example, some Service might only consider directly sensed kinematic information as current and always report extrapolated data in the sibling EstimatedKinematics element. Another Service might have "staleness" criteria which allows current kinematics to be extrapolated for some period of time before being considered stale. When the staleness criteria are met, that Service might then continue to extrapolate but report the continued extrapolation in the sibling EstimatedKinematics element while freezing this element in a "last-known-good" kinematic state.
EstimatedKinematics	KinematicsType	Optional
	Description	This element indicates extrapolated or otherwise estimated kinematics for the Entity.
DownLocation	Point2D_Type	Optional
	Description	When present, indicates the Entity is in a "down" state (damaged, broken or otherwise not operating) and the last known location is given. The child Timestamp element, when given, indicates the time at which the Entity entered the down state.
PlatformStatus	PlatformStatusType	Optional
	Description	General status information about the asset.
WeaponState	MA_WeaponStateType	Optional
	Description	State of the weapon flyout.
SignalSummary	EntitySignalSummaryType	Repeated
	Description	Indicates a summary of an RF Signal from the Entity.
PulseDataID	PulseDataID_Type	Repeated
	Description	Indicates the unique ID of a PulseData collection associated with the Entity.
MeasurementID	MeasurementID_Type	Repeated
	Description	Indicates the unique ID of a Measurement within an Observation Measurement Report associated with the Entity.
Strength	StrengthType	Optional
	Description	Specifies the strength for the Entity. When omitted, a single object/entity should be assumed.
ActivityAgainst	ActivityAgainstType	Repeated
	Description	This element indicates an activity, that isn't otherwise represented by UCI Tasks,

	Capability commands, etc. being performed on/against the Entity.	
ActivityBy	ActivityByType	Repeated
Description	This element indicates an activity, that isn't otherwise represented by UCI Tasks, Capability commands, etc. being performed by the Entity.	
Endurance	EnduranceType	Optional
Description	Indicates the Entity's remaining endurance.	
VoiceControl	VoiceControlType	Optional
Description	This type contains the connection data needed to communicate with a vehicle using voice radios.	
AssociatedID	ID_Type	Repeated
Description	This element indicates an association (not a fusion or derivation relationship) between this Entity and another UCI message or object. For example, an Entity could be associated with an OpPoint. Data content of the Entity and the associated message/object is maintained independently.	
RemoveInfo	EntityRemoveInfoType	Optional
Description	Indicates supplementary information regarding an Entity whose ObjectState indicates REMOVED.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates a capability of the Entity.	
OrbitalKinematics	OrbitalKinematicsChoiceType	Optional
Description	Indicates the current single-position orbital kinematic information for the Entity in the form of a single Cartesian state vector of position and velocity that together with its time (epoch) uniquely determine the trajectory of an orbiting body in space. Requires selection of the frame of reference and should, in general, only be propagated using the same model used for the orbit determination. Optionally includes a covariance matrix that contains information about the uncertainties associated with the solution of the element corrections. "Current" is subjective and varies widely by application. For example, some Service might only consider directly sensed kinematic information as current and always report extrapolated data in the sibling EstimatedOrbitalKinematics element. Another Service might have "staleness" criteria which allows current kinematics to be extrapolated for some period of time before being considered stale. When the staleness criteria are met, that Service might then continue to extrapolate but report the continued extrapolation in the sibling EstimatedOrbitalKinematics element while freezing this element in a "last-known-good" kinematic state.	
OrbitalKinematicsParameters	OrbitalSingleVectorParametersType	Optional
Description	Indicates the parameters used in the Propagation Model for the Entity. If the OrbitalKinematics are relative to another object (Reference Object), these parameters only relate to this entity. If it is necessary to capture the parameters for the Reference Object, those parameters should be captured in the Entity message for that Reference Object, and the Reference Object's EntityID should be specified in the ReferenceAsset element of the sibling OrbitalKinematics.	
EstimatedOrbitalKinematics	OrbitalKinematicsChoiceType	Optional
Description	This element indicates extrapolated or otherwise estimated single-position orbital kinematics for the Entity.	

Table A-4-971: Mission Plan Interface MA_EntityMT - MessageData UCI Extension Field

4.3.3MA_ActionCapabilityMT UCI Extension

MA_ActionCapabilityMT	
Description	This message represents the Action category of UCI Capability. See the XSD File for more info
Ext. Fields	AssociatedTaskType : MA_TaskTypeEnum Capability : MA_ActionCapabilityType MessageData : MA_ActionCapabilityMDT

Table A-4-972: Mission Plan Interface MA_ActionCapabilityMT UCI Extension

AssociatedTaskType	
Description	Indicates a Task type associated with the Action. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.
AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.
CAP	Indicates the task is to execute a Combat Air Patrol.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESCORT	Indicates the task is to escort another entity.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.

SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.
SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-973: Mission Plan Interface MA_ActionCapabilityMT - AssociatedTaskType UCI Extension Field

Capability		
Description	Indicates an installed Action Capability, its configurable characteristics and its controllability.	
Base Type	MA_ActionCapabilityType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityType	MA_ActionTypeEnum	Required
Description	Indicates the type of Action. See enumerated type annotations for further details.	
AssociatedTaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a Task type associated with the Action. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
AssociatedCapabilityType	CapabilityTypeEnum	Repeated
Description	Indicates a Capability type associated with the Action. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CapabilityOptions	ActionCapabilityOptionsType	Required
Description	Indicates the Capability's support for select optional elements in its accepted control interface messages. Support for these elements is expected to vary across Capability implementations but must be known in order to adapt and configure upstream Systems and Services which use the Capability.	
MessageOutput	ActionMessageOutputsEnum	Repeated
Description	Indicates a message that is an output of the Capability. See enumerated type annotations for details. List size for this element is based on "Select All That Apply" condition.	
AcceptedInterface	CapabilityControlInterfacesEnum	Repeated
Description	Indicates an accepted control interface for the Capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CommsRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) communications are required to use the Capability. Omitted is equivalent to FALSE. For example, an unmanned system with no onboard storage would require communications to disseminate the outputs of the Capability.	

CapabilityID	CapabilityID_Type	Required
Description	Indicates the unique ID of this Capability. This ID is used to invoke the Capability via Command messages, report its activity via Activity messages, etc.	
DomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates the domain/environment which the Capability is employed from and the "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
ProductOutput	ProductOutputType	Repeated
Description	Indicates a Product that can be an output of the Capability.	
PackageOperation	PackageOperationEnum	Optional
Description	Indicates if and how the operation of the Capability can be coordinated with a partner Capability of another System in a multi-System Package. Omitting this element is equivalent to the enumerate NO_PACKAGE_OPERATION. The actual Package configuration including per-Capability partnering between Systems is given in the PackageStatus message. For example, a System that can perform cooperative geolocation could advertise with this element in the ESM_Capability message. A System that can navigate in a swarm with other Systems could advertise with this element in the FlightCapability message.	

Table A-4-974: Mission Plan Interface MA_ActionCapabilityMT - Capability UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActionCapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_ActionCapabilityType	Repeated
Description	Indicates an installed Action Capability, its configurable characteristics and its controllability.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.	

Table A-4-975: Mission Plan Interface MA_ActionCapabilityMT - MessageData UCI Extension Field

4.3.4 MA_ActionMT UCI Extension

MA_ActionMT	
Description	See annotations in child elements and messages/elements that use this type for details.

	See the XSD File for more info
Ext. Fields	MessageData : MA_ActionMDT

Table A-4-976: Mission Plan Interface MA_ActionMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActionMDT	
Message Structure		
Field Name	Field Type	Field Usage
ActionID	ActionID_Type	Required
Description	Indicates a unique ID assigned to the Action. Minor updates to the Action can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new instance with a different child UUID value.	
ActionType	MA_ActionTypeEnum	Required
Description	Indicates the type of Action; the type of behavior to be performed when the Action is executed. An Action is a representation of an operational planning sentence/statement whose most complex form is: 1. Do [ActionType] within [ActionConstraints] to [TargetObject] within [TargetObjectConstraint] to/on/against/toward [SecondaryObject] Many other forms are also possible, including: 2. do [ActionType] 3. do [ActionType] to [TargetObject] 4. do [ActionType] to [TargetObject] doing [TargetObjectConstraint] to [SecondaryObject].	
ActionConstraints	MA_RequirementConstraintsType	Optional
Description	Indicates constraints on the Action. The constraint type used here is common to all Requirement types: Effect, Action, Task, [Capability]Command, Response. Requirement constraints can be 1) given in a [Requirement] message, 2) overridden as a planning input in a [Requirement]PlanCommand message, 3) further refined/overridden during plan creation and reported in a [Requirement]Plan message to inform subsequent planning or execution. See sibling ActionType element annotation for an overall description of Action structure.	
ActionGuidance	RequirementGuidanceType	Optional
Description	Indicates guidance on planning and C2 of the Action.	
TargetObject	IdentityKindInstanceType	Repeated
Description	Indicates the target of the Action; the object the Action will be done to or for. If omitted, the Action places no explicit limitation on which TargetObject it can be done to. See	

	sibling ActionType element annotation for an overall description of Action structure. Note that the term "target" is used in a general sense. For some Requirement types, a more suitable term might be "subject", "point", "location", etc. For example, the "target" of a COVER Action could be a blue/friendly System.	
TargetObjectConstraints	RequirementTargetConstraintsType	Optional
Description	Indicates constraints "on" the TargetObject that must be satisfied before the Action can be done to or for it. See sibling ActionType element annotation for an overall description of Effect structure.	
SecondaryObject	IdentityKindInstanceType	Repeated
Description	Indicates a thing the sibling TargetObject must act on/against/toward to make the Action applicable. See sibling ActionType element annotation for an overall description of Action structure.	
Metadata	RequirementMetadataType	Optional
Description	Indicates traceability and other metadata associated with the Action.	

Table A-4-977: Mission Plan Interface MA_ActionMT - MessageData UCI Extension Field

4.3.5 MA_ActionPlanMT UCI Extension

MA_ActionPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ActionPlanMDT

Table A-4-978: Mission Plan Interface MA_ActionPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_ActionPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
ActionPlanID	ActionPlanID_Type	Required
Description	Indicates a unique ID assigned to the ActionPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	ActionPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which this ActionPlan originated from.	
Plan	MA_ActionPlanType	Required
Description	Indicates the details of the ActionPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other	

	messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.
PlanInputs	ActionPlanInputsType Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.

Table A-4-979: Mission Plan Interface MA_ActionPlanMT - MessageData UCI Extension Field

4.3.6 MA_ActivityPlanMT UCI Extension

MA_ActivityPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ActivityPlanMDT

Table A-4-980: Mission Plan Interface MA_ActivityPlanMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActivityPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlanID	ActivityPlanID_Type	Required
Description	Indicates a unique ID assigned to the ActivityPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	ActivityPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which this ActivityPlan originated from.	
Plan	MA_ActivityPlanType	Required
Description	Indicates the details of the ActivityPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is a used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	ActivityPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-981: Mission Plan Interface MA_ActivityPlanMT - MessageData UCI Extension Field

4.3.7 MA_AMTI_CapabilityMT UCI Extension

MA_AMTI_CapabilityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_AMTI_CapabilityMDT Capability : MA_AMTI_CapabilityType

Table A-4-982: Mission Plan Interface MA_AMTI_CapabilityMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_AMTI_CapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_AMTI_CapabilityType	Repeated
Description	Indicates an installed AMTI Capability, its configurable characteristics and its controllability.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.	

Table A-4-983: Mission Plan Interface MA_AMTI_CapabilityMT - MessageData UCI Extension Field

Capability		
Description	Indicates an installed AMTI Capability, its configurable characteristics and its controllability.	
Base Type	MA_AMTI_CapabilityType	
Message Structure		
Field Name	Field Type	Field Usage
MT_IIRS_Level	NIIRS_Type	Repeated
Description	Indicates a Moving Target Indication Interpretability Rating Scale level supported by the Capability. See annotations of the underlying type for further details.	
ComponentFieldOfRegard	ComponentFieldOfRegardType	Repeated
Description	Fields of Regard for each component in the capability.	
CapabilityType	AMTI_CapabilityEnum	Required

Description	Indicates the Capability's first tier type in the AMTI taxonomy. For AMTI, the first tier is an indication of the physical area covered. See enumerated type annotations for further details.	
SubCapabilityType	AMTI_SubCapabilityEnum	Repeated
Description	Indicates a SubCapability of the AMTI Capability; the second tier in the taxonomy of AMTI. For AMTI, the second tier is waveform category. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition. The selection of AUTO_SUBCAPABILITY_SELECT still requires the evaluation of all sibling attributes by the Capability.	
CapabilityOptions	AMTI_CapabilityOptionsType	Required
Description	Indicates the Capability's support for select optional elements in its accepted control interface messages. Support for these elements is expected to vary across Capability implementations but must be known in order to adapt and configure upstream Systems and Services which use the Capability.	
SupportedFrequencies	FrequencyRangeType	Repeated
Description	Indicates a frequency range used by the Capability.	
MessageOutput	AMTI_MessageOutputsEnum	Repeated
Description	Indicates a message that is an output of the Capability. See enumerated type annotations for details. List size for this element is based on "Select All That Apply" condition.	
AcceptedInterface	CapabilityControlInterfacesEnum	Repeated
Description	Indicates an accepted control interface for the Capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CommsRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) communications are required to use the Capability. Omitted is equivalent to FALSE. For example, an unmanned system with no onboard storage would require communications to disseminate the outputs of the Capability.	
CapabilityID	CapabilityID_Type	Required
Description	Indicates the unique ID of this Capability. This ID is used to invoke the Capability via Command messages, report its activity via Activity messages, etc.	
DomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates the domain/environment which the Capability is employed from and the "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
ProductOutput	ProductOutputType	Repeated
Description	Indicates a Product that can be an output of the Capability.	
PackageOperation	PackageOperationEnum	Optional
Description	Indicates if and how the operation of the Capability can be coordinated with a partner Capability of another System in a multi-System Package. Omitting this element is equivalent to the enumerate NO_PACKAGE_OPERATION. The actual Package configuration including per-Capability partnering between Systems is given in the PackageStatus message. For example, a System that can perform cooperative geolocation could advertise with this element in the ESM_Capability message. A	

	System that can navigate in a swarm with other Systems could advertise with this element in the FlightCapability message.
--	---

Table A-4-984: Mission Plan Interface MA_AMTI_CapabilityMT - Capability UCI Extension Field

4.3.8 MA_ApprovalAuthorityMT UCI Extension

MA_ApprovalAuthorityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ApprovalAuthorityMDT ApplicableIDs : MA_PackageSystemType

Table A-4-985: Mission Plan Interface MA_ApprovalAuthorityMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ApprovalAuthorityMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApprovalAuthorityID	ApprovalAuthorityID_Type	Required
Description	Indicates associated Approval Authority identifier for applicable system and approval policy.	
ApplicableIDs	MA_PackageSystemType	Repeated
Description	Indicates to which system this Approval Authority applies.	
SystemApprovalPolicy	SystemApprovalPolicyType	Repeated
Description	Indicates an ApprovalPolicy and one or more approval authorities ("approvers").	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-986: Mission Plan Interface MA_ApprovalAuthorityMT - MessageData UCI Extension Field

ApplicableIDs		
Description	Indicates to which system this Approval Authority applies.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required

Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-987: Mission Plan Interface MA_ApprovalAuthorityMT - ApplicableIDs UCI Extension Field

4.3.9MA_ApprovalPolicyMT UCI Extension

MA_ApprovalPolicyMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	TaskPlan : MA_TaskPlanPartsType OpLineCategory : MA_OpLineCategoryEnum ActivityPlan : MA_ActivityPlanPartsType ApplicablePlanningActivity : MA_PlanPolicyApplicablePlanType OpVolumeCategory : MA_OpZoneCategoryEnum TaskType : MA_TaskTypeEnum OrbitActivityPlan : MA_ActivityPlanPartsType MessageData : MA_ApprovalPolicyMDT OpZoneCategory : MA_OpZoneCategoryEnum ByPlanParts : MA_PlanPartsType CapabilityCommand : MA_CapabilityTypeEnum PlanParts : MA_PlanPartsType Plans : MA_PlanPolicyType RouteActivityPlan : MA_ActivityPlanPartsType OpPlan : MA_OpPlanPartsType PlanActivation : MA_PlanActivationPolicyType

Table A-4-988: Mission Plan Interface MA_ApprovalPolicyMT UCI Extension

TaskPlan		
Description	Indicates applicable TaskPlan parts.	
Base Type	MA_TaskPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage

TaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	

Table A-4-989: Mission Plan Interface MA_ApprovalPolicyMT - TaskPlan UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier

	admin recoveries.
--	-------------------

Table A-4-990: Mission Plan Interface MA_ApprovalPolicyMT - OpLineCategory UCI Extension Field

ActivityPlan		
Description	Indicates applicable ActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-991: Mission Plan Interface MA_ApprovalPolicyMT - ActivityPlan UCI Extension Field

ApplicablePlanningActivity	
Description	Indicates the set of planning activities whose generated plans are subject to the sibling *Policy elements.
Base Type	MA_PlanPolicyApplicablePlanType

Message Structure		
Field Name	Field Type	Field Usage
PlanType	PlanTypeEnum	Required
Description	Indicates the PlanType that is generated by the planning activity, which is applicable to the associated *Policy elements.	
PlanParts	MA_PlanPartsType	Optional
Description	Indicates the parts of the sibling PlanType that are generated by the planning activity, which is applicable to the associated *Policy elements. If omitted, it indicates all PlanParts are applicable.	
ConstrainingPlans	AutonomousPlanningConstrainingPlansType	Optional
Description	Indicates a set of constraining plans (applicable to same system than the one planned for) that are used in the planning activity, which is applicable to the associated *Policy elements.	
OtherSystemConstrainingPlans	AutonomousPlanningOtherSystemConstrainingPlansType	Repeated
Description	Indicates a set of constraining plans (applicable to different system than the one planned for) that are used in the planning activity, which is applicable to the associated *Policy elements.	

Table A-4-992: Mission Plan Interface MA_ApprovalPolicyMT - ApplicablePlanningActivity UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with

	fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.

SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-993: Mission Plan Interface MA_ApprovalPolicyMT - OpVolumeCategory UCI Extension Field

TaskType	
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.
AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.
CAP	Indicates the task is to execute a Combat Air Patrol.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESCORT	Indicates the task is to escort another entity.

ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.
SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.
SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-994: Mission Plan Interface MA_ApprovalPolicyMT - TaskType UCI Extension Field

OrbitActivityPlan		
Description	Indicates applicable OrbitActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	

ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-995: Mission Plan Interface MA_ApprovalPolicyMT - OrbitActivityPlan UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ApprovalPolicyMDT	
Message Structure		
Field Name	Field Type	Field Usage
ApprovalPolicyID	ApprovalPolicyID_Type	Required
Description	Indicates the unique ID of the approval policy.	
Plans	MA_PlanPolicyType	Repeated
Description	Indicates a set of approval policies for the results of planning activities.	
PlanActivation	MA_PlanActivationPolicyType	Repeated
Description	Indicates approval policies which govern Plan Activation commands.	
RequirementExecution	RequirementExecutionPolicyType	Optional
Description	Indicates which Requirement (Effect, Action, Task, [Capability]Command, Response) execution/performance related activities require approval.	
TimedZone	TimedZoneType	Optional
Description	Indicates the geospatial zone and optionally time/date span or spans when the policy is active. For task allocation, the policy is applicable to allocations that 1) complete within the time/date span and 2) include Task or Tasks whose target falls within the zone, regardless of when the Task will be executed. For route planning, the policy is applicable to route plans with segments that fall within the zone during the time/date span, regardless of when the route plan was completed or the target of Tasks associated with the segments. For task execution, the policy is applicable to Tasks that 1) are scheduled to complete within the time/date span and 2) have a target which falls within the zone. This element supersedes the sibling Expires element.	
Expires	DateTimeType	Optional
Description	Indicates the time and date when the policy expires. The policy is applicable to task allocation and route planning activities completed prior to this time. The policy is applicable to task execution activities initiated prior to this time. When the sibling TimedZone element is used, the time spans specified there supersede this element.	
MissionTraceability	MissionTraceabilityType	Optional

Description	Allows the creator of the approval policy to specify the source or motivation for this ApprovalPolicy such as ATO, ACO, etc.	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-996: Mission Plan Interface MA_ApprovalPolicyMT - MessageData UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate

	ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted

	without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-997: Mission Plan Interface MA_ApprovalPolicyMT - OpZoneCategory UCI Extension Field

ByPlanParts		
Description	Indicates *Plan parts which the Plan to be activated must contain in order for the Policy to be applicable. If omitted, the Policy is applicable regardless of *Plan parts.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional

Description	Indicates applicable OpPlan parts.
-------------	------------------------------------

Table A-4-998: Mission Plan Interface MA_ApprovalPolicyMT - ByPlanParts UCI Extension Field

CapabilityCommand	
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_CapabilityTypeEnum
Message Structure	
Enumeration Literal	Description
ACTION	Indicates an action capability.
AIR_SAMPLE	Indicates an air sampling capability.
AMTI	Indicates an airborne moving target indication (AMTI) capability.
AO	Indicates an active optical capability.
CAP	Indicates a cargo delivery capability.
CARGO_DELIVERY	Indicates a cargo delivery capability.
COMINT	Indicates a Communications Intelligence (COMINT) capability.
COMM_RELAY	Indicates a communications relay capability.
COMM_TERMINAL	Indicates a communications terminal capability
COUNTER_SPACE	Indicates a Counter Space Capability.
EA	Indicates an electronic attack (EA) capability.
EFFECT	Indicates an effect capability.
ESM	Indicates an electronic support measures (ESM) capability.
FLIGHT	Indicates a capability for waypoint-based flight tasks/commands.
IFF	Indicates an Identification Friend or Foe (IFF) capability.
OPAQUE	Indicates a Opaque Capability
ORBIT_CHANGE	Indicates this space system has the ability to change orbits.
ORBITAL_SURVEILLANCE	Indicates a task to perform Orbital Surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates an Orbital Surveillance Sensor Capability.
PO	Indicates a passive optical capability.
RADAR_ALTIMETER	Indicates a Radar Altimeter capability
REFUEL	Indicates a capability to refuel another asset.
RESPONSE	Indicates an response capability.
SAR	Indicates a synthetic aperture radar (SAR) capability.
SMTI	Indicates a surface moving target indication (SMTI) capability.
STRIKE	Indicates a strike capability.
SYSTEM_DEPLOYMENT	Indicates a deployment capability.

TACTICAL_ORDER	Indicates a tactical order capability.
TASK	Indicates a task capability.
WEATHER_RADAR	Indicates a weather radar capability.

Table A-4-999: Mission Plan Interface MA_ApprovalPolicyMT - CapabilityCommand UCI Extension Field

PlanParts		
Description	Indicates the parts of the sibling PlanType that are generated by the planning activity, which is applicable to the associated *Policy elements. If omitted, it indicates all PlanParts are applicable.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-1000: Mission Plan Interface MA_ApprovalPolicyMT - PlanParts UCI Extension Field

Plans	
Description	Indicates a set of approval policies for the results of planning activities.
Base Type	MA_PlanPolicyType
Message Structure	

Field Name	Field Type	Field Usage
ApplicablePlanningActivity	MA_PlanPolicyApplicablePlanType	Repeated
Description	Indicates the set of planning activities whose generated plans are subject to the sibling *Policy elements.	
DefaultPolicy	ApprovalPolicyBaseType	Optional
Description	Indicates the default approval policy for the sibling ApplicablePlanningActivity. The default policy can be overridden in specific conditions as indicated by the ByResultPolicy or ByTriggerPolicy siblings of this element. For example, this element could indicate that approval is required by default for all TaskPlans and then use ByResultPolicy or ByTriggerPolicy siblings to specify conditions when task allocation approval is not required. Alternately, this element could indicate that approval is not required by default and then use ByResultPolicy or ByTriggerPolicy siblings to specify conditions when task allocation approval is required. Creators of this message are expected to carefully avoid creating logically inconsistent ByResultPolicy and ByTriggerPolicy instances and therefore no guidance is given on deconflicting illogical instances. For example, an ApprovalPolicy that indicates approval is not required by default with conflicting ByResultPolicy or ByTriggerPolicy overrides of 1) AUTO_REJECT for DROPPED_TASKS and 2) AUTO_APPROVE for operator triggered DROPPED_TASKS would be considered illogical.	
ByResultPolicy	ByResultPolicyType	Repeated
Description	Indicates approval policies when planning activity results match certain conditions. Conditions specified here are considered to be overrides to the default planning activity approval policy given in the sibling Default element. For example, if the default policy indicates task allocation approval is never required, this element could override the default and require approval whenever a task allocation results in previously allocated Task or Tasks being dropped. See the annotations in the sibling DefaultPolicy element for an overview of how the siblings relate to each other. If multiple instances are given, each should be a different Result instance as indicated by the child Result element.	
ByTriggerPolicy	ByTriggerPolicyType	Repeated
Description	Indicates approval policies for re-plan activities initiated by triggered events, overriding the default approval policy for the planning activity given in the sibling DefaultPolicy element. Additionally, this element allows trigger-specific policies for a specific planning activities. For example, if the default policy indicates route planning approval is never required, this element could override, requiring approval for route plans affecting all Systems triggered by new threats if the route re-plan results in dropped tasks. If multiple instances are given, each should be of a different trigger type as indicated by the child EventTrigger element.	

Table A-4-1001: Mission Plan Interface MA_ApprovalPolicyMT - Plans UCI Extension Field

RouteActivityPlan		
Description	Indicates applicable RouteActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this	

	element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-1002: Mission Plan Interface MA_ApprovalPolicyMT - RouteActivityPlan UCI Extension Field

OpPlan		
Description	Indicates applicable OpPlan parts.	
Base Type	MA_OpPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated

Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpRouting	EmptyType	Optional
Description	Indicates an OpRouting is applicable to the associated *Plan. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-1003: Mission Plan Interface MA_ApprovalPolicyMT - OpPlan UCI Extension Field

PlanActivation		
Description	Indicates approval policies which govern Plan Activation commands.	
Base Type	MA_PlanActivationPolicyType	
Message Structure		
Field Name	Field Type	Field Usage
ByMissionPlan	MissionPlanActivationSettingType	Repeated
Description	Indicates the set of ByMissionPlan activation commands that are applicable to the sibling Policy element. List size allows for identifying those MissionPlans whose subordinate MissionPlans are either included in the activation (TRUE) or not (FALSE) via the CommandSubordinatePlans setting.	
BySubPlan	SubPlanActivationSettingType	Repeated
Description	Indicates the set of BySubPlan activation commands that are applicable to the sibling Policy element.	
ByPlanParts	MA_PlanPartsType	Optional
Description	Indicates *Plan parts which the Plan to be activated must contain in order for the Policy to be applicable. If omitted, the Policy is applicable regardless of *Plan parts.	
Policy	ApprovalPolicyBaseType	Optional
Description	Indicates the approval policy for the sibling applicable activation activities.	

Table A-4-1004: Mission Plan Interface MA_ApprovalPolicyMT - PlanActivation UCI Extension Field

4.3.10 MA_AssessmentMT UCI Extension

MA_AssessmentMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_AssessmentMDT Assessment : MA_AssessmentType

Table A-4-1005: Mission Plan Interface MA_AssessmentMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_AssessmentMDT

Message Structure		
Field Name	Field Type	Field Usage
AssessmentID	AssessmentID_Type	Required
Description	This element references the assessment ID.	
AssessmentRequestID	RequestID_Type	Optional
Description	This element is required when the message is generated in response to an AssessmentRequest. It is omitted when the message is generated unsolicited.	
AnalysisRouteID	AnalysisRouteID_Type	Optional
Description	This element indicates the AnalysisRoute that was used to perform the assessment.	
Assessment	MA_AssessmentType	Required
Description	This element indicates the results of the assessment.	

Table A-4-1006: Mission Plan Interface MA_AssessmentMT - MessageData UCI Extension Field

Assessment		
Description	This element indicates the results of the assessment.	
Base Type	MA_AssessmentType	
Message Structure		
Field Name	Field Type	Field Usage
CommPointingPlan	CommPointingPlanAssessmentType	Required
Description	This element defines the response to a communications pointing plan assessment request.	
CapabilityUtilization	CapabilityUtilizationAssessmentType	Required
Description	This assessment type is utilized to assess predicted capability utilization along a mission planned route.	
RouteDeconfliction	RouteDeconflictionAssessmentType	Required
Description	This element defines the response to a route deconfliction assessment request.	
RouteVulnerabilityMetrics	RouteVulnerabilityMetricsAssessmentType	Required
Description	Indicates the results of assessment of vulnerability along a route.	
RouteThreatAssessment	RouteThreatAssessmentType	Required
Description	Indicates the results of assessment of threats along a route.	
TargetMobility	TargetMobilityAssessmentType	Required
Description	This element defines the response to a target mobility assessment request.	
VehicleThreatAssessment	VehicleThreatAssessmentType	Required
Description	This element defines the response to a vehicle threat assessment request.	
ThreatNominationAssessment	ThreatNominationAssessmentType	Required
Description	This element defines the response to a threat nomination assessment.	
AchievabilityAssessment	AchievabilityAssessmentPET	Required
Description	This element defines the response to an achievability assessment.	

CoverageAssessment	MA_CoverageAssessmentType	Required
Description	This element defines the response to a coverage assessment.	

Table A-4-1007: Mission Plan Interface MA_AssessmentMT - Assessment UCI Extension Field

4.3.11 MA_AuthorizationMT UCI Extension

MA_AuthorizationMT	
Description	See annotations in child elements and messages/elements that use this type for details.
	See the XSD File for more info
Ext. Fields	UnauthorizedExceptFor : MA_RequirementAuthorizationPermissionsType CapabilityTaxonomy : MA_CapabilityTaxonomyType Opaque : MA_OpaqueEnum AuthorizedExceptFor : MA_RequirementAuthorizationPermissionsType CapabilityCommand : MA_CapabilityTypeEnum CapabilitySettingTypes : MA_CapabilityTypeEnum ByDataActivation : MA_DataActivationAuthorizationType CAP : MA_CAP_CapabilityEnum UnauthorizedExceptFor : MA_PlanActivationPermissionsType AuthorizedExceptFor : MA_PlatformSettingsPermissionsType DataTypes : MA_DataActivationTypeEnum AuthorizedExceptFor : MA_OperatorRequestPermissionsType CommTerminal : MA_CommTerminalEnum ByRequirementExecution : MA_RequirementAuthorizationType ByDataModification : MA_DataModificationAuthorizationType ActivityPlan : MA_ActivityPlanPartsType MessageData : MA_AuthorizationMDT AuthorizedArea : MA_AuthorizedZoneChoiceType AuthorizedExceptFor : MA_PlanActivationPermissionsType ByPlanActivation : MA_PlanAuthorizationType AuthorizedExceptFor : MA_DataModificationPermissionsType ByPlatformSettingsModification : MA_SettingsModificationAuthorizationType UnauthorizedExceptFor : MA_DataModificationPermissionsType UnauthorizedExceptFor : MA_OperatorRequestPermissionsType RadarAltimeter : MA_RadarAltimeterEnum RequestTypes : MA_OperatorRequestTypeEnum ByPlanParts : MA_PlanPartsType AdditionalPlatformSettingTypes : MA_PlatformSettingPermissionsTypeEnum

	IFF : MA_IFF_Enum
	RequirementTypes : MA_RequirementTaxonomyDetailedType
	UnauthorizedExceptFor : MA_PlatformSettingsPermissionsType
	UserIdentifier : MA_UserType
	ByOperatorRequest : MA_OperatorRequestAuthorizationType

Table A-4-1008: Mission Plan Interface MA_AuthorizationMT UCI Extension

UnauthorizedExceptFor		
Description	This element indicates that all requirement types are NOT authorized to be executed with the exception of the enumeration values listed in the permissionsType	
Base Type	MA_RequirementAuthorizationPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
RequirementTypes	MA_RequirementTaxonomyDetailedType	Optional
Description	Indicates the set of Requirements that are authorized or unauthorized to be commanded depending on the parent MA_RequirementAuthorizationType	
AdditionalCapabilityTypes	SupportCapabilityTypeEnum	Repeated
Description	Indicates the set of additional support capabilities that are authorized or unauthorized to be commanded depending on the parent MA_RequirementAuthorizationType. List size for this element is based on "Select All That Apply" condition	

Table A-4-1009: Mission Plan Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field

CapabilityTaxonomy		
Description	Indicates specific Capability details/modes that are applicable.	
Base Type	MA_CapabilityTaxonomyType	
Message Structure		
Field Name	Field Type	Field Usage
Action	MA_ActionTypeEnum	Repeated
Description	Indicates an Action Capability. List size for this element is based on "Select All That Apply" condition.	
AirSample	AirSampleCapabilityEnum	Repeated
Description	Indicates an AirSample Capability. List size for this element is based on "Select All That Apply" condition.	
AMTI	AMTI_SpecificDataType	Repeated
Description	Indicates an AMTI Capability and any optional SubCapabilities.	
AO	AO_CapabilityEnum	Repeated
Description	Indicates an AO Capability. List size for this element is based on "Select All That Apply" condition.	
CAP	MA_CAP_CapabilityEnum	Repeated

	Description	Indicates a Combat Air Patrol Capability.	
CargoDelivery		CargoDeliverySpecificDataType	Repeated
	Description	Indicates a CargoDelivery Capability and any optional SubCapabilities.	
COMINT		COMINT_SpecificDataType	Repeated
	Description	Indicates a COMINT Capability and any optional SubCapabilities.	
CommRelay		CommCapabilityEnum	Repeated
	Description	Indicates a CommRelay Capability. List size for this element is based on "Select All That Apply" condition.	
CommTerminal		MA_CommTerminalEnum	Optional
	Description	Indicates a CommTerminal Capability. List size for this element is based on "Select All That Apply" condition.	
CounterSpace		CS_CapabilityEnum	Optional
	Description	Indicates a CounterSpace Capability.	
EA		CapabilityInitiationEnum	Repeated
	Description	Indicates an EA Capability. List size for this element is based on "Select All That Apply" condition.	
Effect		EffectTypeEnum	Repeated
	Description	Indicates an Effect Capability. List size for this element is based on "Select All That Apply" condition.	
ESM		ESM_SpecificDataType	Repeated
	Description	Indicates an ESM Capability and any optional SubCapabilities.	
Flight		FlightCapabilityEnum	Repeated
	Description	Indicates a Flight Capability. List size for this element is based on "Select All That Apply" condition.	
IFF		MA_IFF_Enum	Optional
	Description	Indicates an IFF Capability. List size for this element is based on "Select All That Apply" condition.	
Opaque		MA_OpaqueEnum	Optional
	Description	Indicates an Opaque Capability. List size for this element is based on "Select All That Apply" condition.	
OrbitChange		OrbitChangeCapabilityEnum	Repeated
	Description	Indicates an OrbitChange Capability. List size for this element is based on "Select All That Apply" condition.	
OrbitalSurveillance		OrbitalSurveillanceSpecificDataType	Repeated
	Description	Indicates an OrbitalSurveillance Capability and any optional SubCapabilities.	
OrbitalSurveillanceSensor		OrbitalSurveillanceSensorCapabilityEnum	Repeated
	Description	Indicates an OrbitalSurveillanceSensor Capability. List size for this element is based on "Select All That Apply" condition.	
PO		PO_CapabilityEnum	Repeated

	Description	Indicates a PO Capability. List size for this element is based on "Select All That Apply" condition.
RadarAltimeter	MA_RadarAltimeterEnum	Optional
	Description	Indicates a Radar Altimeter Capability. List size for this element is based on "Select All That Apply" condition.
Refuel	RefuelCapabilityEnum	Repeated
	Description	Indicates a Refuel Capability. List size for this element is based on "Select All That Apply" condition.
Response	ResponseTypeEnum	Repeated
	Description	Indicates a Response Capability. List size for this element is based on "Select All That Apply" condition.
SAR	SAR_SpecificDataType	Repeated
	Description	Indicates a SAR Capability and any optional SubCapabilities.
SMTI	SMTI_SpecificDataType	Repeated
	Description	Indicates a SMTI Capability and any optional SubCapabilities.
Strike	StoreType	Repeated
	Description	Indicates a Strike Capability.
SystemDeployment	SystemDeploymentEnum	Repeated
	Description	Indicates a SystemDeployment Capability. List size for this element is based on "Select All That Apply" condition.
TacticalOrder	TacticalOrderCapabilityEnum	Repeated
	Description	Indicates a TacticalOrder Capability. List size for this element is based on "Select All That Apply" condition.
WeatherRadar	WeatherRadarCapabilityEnum	Optional
	Description	Indicates a WeatherRadar Capability.

Table A-4-1010: Mission Plan Interface MA_AuthorizationMT - CapabilityTaxonomy UCI Extension Field

Opaque	
Description	Indicates an Opaque Capability. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpaqueEnum
Message Structure	
Enumeration Literal	Description
OPAQUE	Indicates a Opaque Capability.

Table A-4-1011: Mission Plan Interface MA_AuthorizationMT - Opaque UCI Extension Field

AuthorizedExceptFor	
Description	This element indicates that all requirement types are authorized to be executed with the exception of the enumeration values listed in the permissionsType
Base Type	MA_RequirementAuthorizationPermissionsType

Message Structure		
Field Name	Field Type	Field Usage
RequirementTypes	MA_RequirementTaxonomyDetailedType	Optional
Description	Indicates the set of Requirements that are authorized or unauthorized to be commanded depending on the parent MA_RequirementAuthorizationType	
AdditionalCapabilityTypes	SupportCapabilityTypeEnum	Repeated
Description	Indicates the set of additional support capabilities that are authorized or unauthorized to be commanded depending on the parent MA_RequirementAuthorizationType. List size for this element is based on "Select All That Apply" condition	

Table A-4-1012: Mission Plan Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field

CapabilityCommand	
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_CapabilityTypeEnum
Message Structure	
Enumeration Literal	Description
ACTION	Indicates an action capability.
AIR_SAMPLE	Indicates an air sampling capability.
AMTI	Indicates an airborne moving target indication (AMTI) capability.
AO	Indicates an active optical capability.
CAP	Indicates a cargo delivery capability.
CARGO_DELIVERY	Indicates a cargo delivery capability.
COMINT	Indicates a Communications Intelligence (COMINT) capability.
COMM_RELAY	Indicates a communications relay capability.
COMM_TERMINAL	Indicates a communications terminal capability
COUNTER_SPACE	Indicates a Counter Space Capability.
EA	Indicates an electronic attack (EA) capability.
EFFECT	Indicates an effect capability.
ESM	Indicates an electronic support measures (ESM) capability.
FLIGHT	Indicates a capability for waypoint-based flight tasks/commands.
IFF	Indicates an Identification Friend or Foe (IFF) capability.
OPAQUE	Indicates a Opaque Capability
ORBIT_CHANGE	Indicates this space system has the ability to change orbits.
ORBITAL_SURVEILLANCE	Indicates a task to perform Orbital Surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates an Orbital Surveillance Sensor Capability.
PO	Indicates a passive optical capability.

RADAR_ALTITUDE	Indicates a Radar Altimeter capability
REFUEL	Indicates a capability to refuel another asset.
RESPONSE	Indicates an response capability.
SAR	Indicates a synthetic aperture radar (SAR) capability.
SMTI	Indicates a surface moving target indication (SMTI) capability.
STRIKE	Indicates a strike capability.
SYSTEM_DEPLOYMENT	Indicates a deployment capability.
TACTICAL_ORDER	Indicates a tactical order capability.
TASK	Indicates a task capability.
WEATHER_RADAR	Indicates a weather radar capability.

Table A-4-1013: Mission Plan Interface MA_AuthorizationMT - CapabilityCommand UCI Extension Field

CapabilitySettingTypes	
Description	List size for this element is based on "Select All That Apply" condition
Base Type	MA_CapabilityTypeEnum
Message Structure	
Enumeration Literal	Description
ACTION	Indicates an action capability.
AIR_SAMPLE	Indicates an air sampling capability.
AMTI	Indicates an airborne moving target indication (AMTI) capability.
AO	Indicates an active optical capability.
CAP	Indicates a cargo delivery capability.
CARGO_DELIVERY	Indicates a cargo delivery capability.
COMINT	Indicates a Communications Intelligence (COMINT) capability.
COMM_RELAY	Indicates a communications relay capability.
COMM_TERMINAL	Indicates a communications terminal capability
COUNTER_SPACE	Indicates a Counter Space Capability.
EA	Indicates an electronic attack (EA) capability.
EFFECT	Indicates an effect capability.
ESM	Indicates an electronic support measures (ESM) capability.
FLIGHT	Indicates a capability for waypoint-based flight tasks/commands.
IFF	Indicates an Identification Friend or Foe (IFF) capability.
OPAQUE	Indicates a Opaque Capability
ORBIT_CHANGE	Indicates this space system has the ability to change orbits.
ORBITAL_SURVEILLANCE	Indicates a task to perform Orbital Surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates an Orbital Surveillance Sensor Capability.
PO	Indicates a passive optical capability.

RADAR_ALTITUDE	Indicates a Radar Altimeter capability
REFUEL	Indicates a capability to refuel another asset.
RESPONSE	Indicates an response capability.
SAR	Indicates a synthetic aperture radar (SAR) capability.
SMTI	Indicates a surface moving target indication (SMTI) capability.
STRIKE	Indicates a strike capability.
SYSTEM_DEPLOYMENT	Indicates a deployment capability.
TACTICAL_ORDER	Indicates a tactical order capability.
TASK	Indicates a task capability.
WEATHER_RADAR	Indicates a weather radar capability.

Table A-4-1014: Mission Plan Interface MA_AuthorizationMT - CapabilitySettingTypes UCI Extension Field

ByDataActivation		
Description	Indicates which types of data are authorized to be activated.	
Base Type	MA_DataActivationAuthorizationType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedExceptFor	MA_DataActivationPermissionsType	Required
Description	This element indicates that all data types are authorized to be activated with the exception of the enumeration values listed in the permissionType.	
UnauthorizedExceptFor	MA_DataActivationPermissionsType	Required
Description	This element indicates that all data types are NOT authorized to be activated with the exception of the enumeration values listed in the permissionType.	

Table A-4-1015: Mission Plan Interface MA_AuthorizationMT - ByDataActivation UCI Extension Field

CAP	
Description	Indicates a Combat Air Patrol Capability.
Base Type	MA_CAP_CapabilityEnum
Message Structure	
Enumeration Literal	Description
COMBAT_AIR_PATROL	Indicates a CAP capability

Table A-4-1016: Mission Plan Interface MA_AuthorizationMT - CAP UCI Extension Field

UnauthorizedExceptFor		
Description	This element indicates that all plan types are NOT authorized to be activated with the exception of the enumeration values listed in the permissionsType.	
Base Type	MA_PlanActivationPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage

ByMissionPlan	MissionPlanActivationSettingType	Repeated
Description	Indicates the set of ByMissionPlan activation commands that are authorized. List size allows for identifying those MissionPlans whose subordinate MissionPlans are either included in the activation (TRUE) or not (FALSE) via the CommandSubordinatePlans setting.	
ByPlanParts	MA_PlanPartsType	Optional
Description	Indicates which *Plan parts are authorized to be activated.	

Table A-4-1017: Mission Plan Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field

AuthorizedExceptFor		
Description	This element indicates that all vehicle setting types are authorized to be modified with the exception of the enumeration values listed in the permissionType.	
Base Type	MA_PlatformSettingsPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilitySettingTypes	MA_CapabilityTypeEnum	Repeated
Description	List size for this element is based on "Select All That Apply" condition	
AdditionalPlatformSettingTypes	MA_PlatformSettingPermissionsTypeEnum	Repeated
Description	List size for this element is based on "Select All That Apply" condition	

Table A-4-1018: Mission Plan Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field

DataTypes	
Description	Indicates the set of data type messages that are authorized or unauthorized to be activated depending on the parent MA_DataActivationAuthorizationType. List size for this element is based on "Select All That Apply" condition
Base Type	MA_DataActivationTypeEnum
Message Structure	
Enumeration Literal	Description
COMM_POINTING_COMMAND	See MT type for annotation.
MA_CONSTRAINT_PRIORITY_LIST_COMMAND	See MT type for annotation.
MA_COP_CONFIGURATION_SETTINGS_COMMAND	See MT type for annotation.
MA_ENGAGEMENT_CRITERIA_COMMAND	See MT type for annotation.
MA_EXECUTION_PRIORITY_LIST_COMMAND	See MT type for annotation.
MA_IGNORE_CONSTRAINT_COMMAND	See MT type for annotation.

Table A-4-1019: Mission Plan Interface MA_AuthorizationMT - DataTypes UCI Extension Field

AuthorizedExceptFor	
Description	This element indicates that all request types are authorized to be sent with the

	exception of the enumeration values listed in the permissionType.	
Base Type	MA_OperatorRequestPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
RequestTypes	MA_OperatorRequestTypeEnum	Repeated
Description	Indicates the set of Request Messages that C2 users can send to MA. List size for this element is based on "Select All That Apply" condition	

Table A-4-1020: Mission Plan Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field

CommTerminal	
Description	Indicates a CommTerminal Capability. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_CommTerminalEnum
Message Structure	
Enumeration Literal	Description
COMM_TERMINAL	Indicates a Comm Terminal Capability.

Table A-4-1021: Mission Plan Interface MA_AuthorizationMT - CommTerminal UCI Extension Field

ByRequirementExecution		
Description	Indicates which Requirement (Effect, Action, Task, [Capability]Command, Response) execution/performance related activities are authorized.	
Base Type	MA_RequirementAuthorizationType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedExceptFor	MA_RequirementAuthorizationPermissionsType	Required
Description	This element indicates that all requirement types are authorized to be executed with the exception of the enumeration values listed in the permissionsType	
UnauthorizedExceptFor	MA_RequirementAuthorizationPermissionsType	Required
Description	This element indicates that all requirement types are NOT authorized to be executed with the exception of the enumeration values listed in the permissionsType	

Table A-4-1022: Mission Plan Interface MA_AuthorizationMT - ByRequirementExecution UCI Extension Field

ByDataModification		
Description	Indicates which types of data messages are authorized to be created, modified or deleted.	
Base Type	MA_DataModificationAuthorizationType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedExceptFor	MA_DataModificationPermissionsType	Required
Description	This element indicates that all data types are authorized to be created, modified or	

	deleted with the exception of the enumeration values listed in the permissionType.	
UnauthorizedExceptFor	MA_DataModificationPermissionsType	Required
Description	This element indicates that all data types are NOT authorized to be created, modified or deleted with the exception of the enumeration values listed in the permissionType	

Table A-4-1023: Mission Plan Interface MA_AuthorizationMT - ByDataModification UCI Extension Field

ActivityPlan		
Description	Indicates applicable ActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-1024: Mission Plan Interface MA_AuthorizationMT - ActivityPlan UCI Extension Field

MessageData	
Description	See annotations in child elements and messages/elements that use this

	type for details.	
Base Type	MA_AuthorizationMDT	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizationID	AuthorizationID_Type	Required
Description	Indicates the unique ID of the authorization.	
UserIdentifier	MA_UserType	Required
Description	Indicates the unique ID of the User being granted authorization to task. User types are SystemID, OperatorRoleID, or UserIdentifier	
SystemID	SystemID_Type	Required
Description	Indicates the unique ID of the System which the User, given in the sibling UserIdentifier element, is authorized to task.	
Precedence	unsignedInt	Required
Description	This element indicates the precedence level at which the User is authorized to task the System. The larger the number, the higher the precedence. Any Tasks or Commands created by the User must not exceed this precedence level.	
ByPlanActivation	MA_PlanAuthorizationType	Repeated
Description	Indicates authorization to send Plan Activation commands.	
ByRequirementExecution	MA_RequirementAuthorizationType	Optional
Description	Indicates which Requirement (Effect, Action, Task, [Capability]Command, Response) execution/performance related activities are authorized.	
ByDataModification	MA_DataModificationAuthorizationType	Optional
Description	Indicates which types of data messages are authorized to be created, modified or deleted.	
ByDataActivation	MA_DataActivationAuthorizationType	Optional
Description	Indicates which types of data are authorized to be activated.	
ByOperatorRequest	MA_OperatorRequestAuthorizationType	Optional
Description	Indicates which types of request messages are authorized to be sent.	
PackageAuthorization	boolean	Optional
Description	This element indicates authorization to create, modify and dissolve teams.	
ByPlatformSettingsModification	MA_SettingsModificationAuthorizationType	Optional
Description	This element indicates authorization to send settings commands.	
AuthorizedTime	DateTimeRangeType	Optional
Description	This element indicates the time range during which the Authorization applies. More specifically, this is the time range in which the User must create/submit Tasks in order for them to be allocated to the specified System. If omitted, the Authorization is applicable until removed.	
AuthorizedArea	MA_AuthorizedZoneChoiceType	Optional
Description	This choice type indicates the area over which the authorization applies. It	

	contains either a zone defined in this message or the ID of an existing OpZone	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-1025: Mission Plan Interface MA_AuthorizationMT - MessageData UCI Extension Field

AuthorizedArea		
Description	This choice type indicates the area over which the authorization applies. It contains either a zone defined in this message or the ID of an existing OpZone	
Base Type	MA_AuthorizedZoneChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedZone	ZoneType	Required
Description	This element indicates the area over which the authorization applies. More specifically, this is the geospatial zone in which the target of Tasks created by the User must fall in order for them to be allocated to the specified System. If omitted, the Authorization is applicable to all areas.	
AuthorizedOpZoneID	OpZoneID_Type	Required
Description	This element indicates the area defined by an existing OpZone over which the authorization applies. More specifically, this is the geospatial zone in which the target of Tasks created by the User must fall in order for them to be allocated to the specified System. If omitted, the Authorization is applicable to all areas.	

Table A-4-1026: Mission Plan Interface MA_AuthorizationMT - AuthorizedArea UCI Extension Field

AuthorizedExceptFor		
Description	This element indicates that all plan types are authorized to be activated with the exception of the enumeration values listed in the permissionsType.	
Base Type	MA_PlanActivationPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
ByMissionPlan	MissionPlanActivationSettingType	Repeated
Description	Indicates the set of ByMissionPlan activation commands that are authorized. List size allows for identifying those MissionPlans whose subordinate MissionPlans are either included in the activation (TRUE) or not (FALSE) via the CommandSubordinatePlans setting.	
ByPlanParts	MA_PlanPartsType	Optional
Description	Indicates which *Plan parts are authorized to be activated.	

Table A-4-1027: Mission Plan Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field

ByPlanActivation

Description	Indicates authorization to send Plan Activation commands.	
Base Type	MA_PlanAuthorizationType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedExceptFor	MA_PlanActivationPermissionsType	Required
Description	This element indicates that all plan types are authorized to be activated with the exception of the enumeration values listed in the permissionsType.	
UnauthorizedExceptFor	MA_PlanActivationPermissionsType	Required
Description	This element indicates that all plan types are NOT authorized to be activated with the exception of the enumeration values listed in the permissionsType.	

Table A-4-1028: Mission Plan Interface MA_AuthorizationMT - ByPlanActivation UCI Extension Field

AuthorizedExceptFor		
Description	This element indicates that all data types are authorized to be created, modified or deleted with the exception of the enumeration values listed in the permissionType.	
Base Type	MA_DataModificationPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
DataTypes	MA_DataMessageTypeEnum	Repeated
Description	Indicates the set of data type messages that are authorized or unauthorized to be edited, created or deleted depending on the parent MA_DataModificationAuthorizationType.	

Table A-4-1029: Mission Plan Interface MA_AuthorizationMT - AuthorizedExceptFor UCI Extension Field

ByPlatformSettingsModification		
Description	This element indicates authorization to send settings commands.	
Base Type	MA_SettingsModificationAuthorizationType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedExceptFor	MA_PlatformSettingsPermissionsType	Required
Description	This element indicates that all vehicle setting types are authorized to be modified with the exception of the enumeration values listed in the permissionType.	
UnauthorizedExceptFor	MA_PlatformSettingsPermissionsType	Required
Description	This element indicates that all vehicle setting types are unauthorized to be modified with the exception of the enumeration values listed in the permissionType.	

Table A-4-1030: Mission Plan Interface MA_AuthorizationMT - ByPlatformSettingsModification UCI Extension Field

UnauthorizedExceptFor	
Description	This element indicates that all data types are NOT authorized to be created, modified or deleted with the exception of the enumeration values listed in the

	permissionType	
Base Type	MA_DataModificationPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
DataTypes	MA_DataMessageTypeEnum	Repeated
Description	Indicates the set of data type messages that are authorized or unauthorized to be edited, created or deleted depending on the parent MA_DataModificationAuthorizationType.	

Table A-4-1031: Mission Plan Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field

UnauthorizedExceptFor		
Description	This element indicates that all request types are NOT authorized to be sent with the exception of the enumeration values listed in the permissionType.	
Base Type	MA_OperatorRequestPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
RequestTypes	MA_OperatorRequestTypeEnum	Repeated
Description	Indicates the set of Request Messages that C2 users can send to MA. List size for this element is based on "Select All That Apply" condition	

Table A-4-1032: Mission Plan Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field

RadarAltimeter	
Description	Indicates a Radar Altimeter Capability. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_RadarAltimeterEnum
Message Structure	
Enumeration Literal	Description
RADAR_ALTIMETER	Indicates a Radar Altimeter Capability.

Table A-4-1033: Mission Plan Interface MA_AuthorizationMT - RadarAltimeter UCI Extension Field

RequestTypes	
Description	Indicates the set of Request Messages that C2 users can send to MA. List size for this element is based on "Select All That Apply" condition
Base Type	MA_OperatorRequestTypeEnum
Message Structure	
Enumeration Literal	Description
DATA_RECORD_MANAGEMENT_REQUEST	See MT type for annotation.
MA_ASSESSMENT_REQUEST	See MT type for annotation.
MA_CONTROL_REQUEST	See MT type for annotation.

QUERY_DATA_REQUEST	See MT type for annotation.
--------------------	-----------------------------

Table A-4-1034: Mission Plan Interface MA_AuthorizationMT - RequestTypes UCI Extension Field

ByPlanParts		
Description	Indicates which *Plan parts are authorized to be activated.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-1035: Mission Plan Interface MA_AuthorizationMT - ByPlanParts UCI Extension Field

AdditionalPlatformSettingTypes	
Description	List size for this element is based on "Select All That Apply" condition
Base Type	MA_PlatformSettingPermissionsTypeEnum
Message Structure	
Enumeration Literal	Description
MA_ACCEPTABLE_LEVEL_OF_RISK_COMMAND	See MT type for annotation.
MA_SYSTEM_MANAGEMENT_REQUEST	See MT type for annotation.

PLANNING_FUNCTION_SETTINGS_COMMAND	See MT type for annotation.
---	-----------------------------

Table A-4-1036: Mission Plan Interface MA_AuthorizationMT - AdditionalPlatformSettingTypes UCI Extension Field

IFF	
Description	Indicates an IFF Capability. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_IFF_Enum
Message Structure	
Enumeration Literal	Description
IFF	Indicates an IFF Capability.

Table A-4-1037: Mission Plan Interface MA_AuthorizationMT - IFF UCI Extension Field

RequirementTypes		
Description	Indicates the set of Requirements that are authorized or unauthorized to be commanded depending on the parent MA_RequirementAuthorizationType	
Base Type	MA_RequirementTaxonomyDetailedType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityTaxonomy	MA_CapabilityTaxonomyType	Optional
Description	Indicates specific Capability details/modes that are applicable.	
Effect	EffectTypeEnum	Repeated
Description	Indicates Effects applicable via the Effect* message set. List size for this element is based on "Select All That Apply" condition.	
Action	MA_ActionTypeEnum	Repeated
Description	Indicates Actions applicable via the Action* message set. List size for this element is based on "Select All That Apply" condition.	
Task	MA_TaskTypeEnum	Repeated
Description	Indicates Tasks applicable via the Task* message set. List size for this element is based on "Select All That Apply" condition.	
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates CapabilityCommands applicable via a [Capability]Command message set. List size for this element is based on "Select All That Apply" condition.	
Response	ResponseTypeEnum	Repeated
Description	Indicates Responses applicable via the Response* message set. List size for this element is based on "Select All That Apply" condition.	

Table A-4-1038: Mission Plan Interface MA_AuthorizationMT - RequirementTypes UCI Extension Field

UnauthorizedExceptFor	
Description	This element indicates that all vehicle setting types are unauthorized to be modified with the exception of the enumeration values listed in the permissionType.

Base Type	MA_PlatformSettingsPermissionsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilitySettingTypes	MA_CapabilityTypeEnum	Repeated
Description	List size for this element is based on "Select All That Apply" condition	
AdditionalPlatformSettingTypes	MA_PlatformSettingPermissionsTypeEnum	Repeated
Description	List size for this element is based on "Select All That Apply" condition	

Table A-4-1039: Mission Plan Interface MA_AuthorizationMT - UnauthorizedExceptFor UCI Extension Field

UserIdentifier		
Description	Indicates the unique ID of the User being granted authorization to task. User types are SystemID, OperatorRoleID, or UserIdentifier	
Base Type	MA_UserType	
Message Structure		
Field Name	Field Type	Field Usage
OperatorRoleID	OperatorRoleID_Type	Required
Description	This choice type is used in the context of RBAC to specify an operator role to tie a set of authorized permissions to.	
SystemID	SystemID_Type	Required
Description	This choice type is used to specify a system ID to tie a set of authorized permissions to.	
UserIdentifier	UserIdentifierType	Required
Description	This choice type is used to specify a User Identifier to tie a set of authorized permissions to.	

Table A-4-1040: Mission Plan Interface MA_AuthorizationMT - UserIdentifier UCI Extension Field

ByOperatorRequest		
Description	Indicates which types of request messages are authorized to be sent.	
Base Type	MA_OperatorRequestAuthorizationType	
Message Structure		
Field Name	Field Type	Field Usage
AuthorizedExceptFor	MA_OperatorRequestPermissionsType	Required
Description	This element indicates that all request types are authorized to be sent with the exception of the enumeration values listed in the permissionType.	
UnauthorizedExceptFor	MA_OperatorRequestPermissionsType	Required
Description	This element indicates that all request types are NOT authorized to be sent with the exception of the enumeration values listed in the permissionType.	

Table A-4-1041: Mission Plan Interface MA_AuthorizationMT - ByOperatorRequest UCI Extension Field

4.3.12 MA_CapabilitySetMT UCI Extension

MA_CapabilitySetMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_CapabilitySetMDT

Table A-4-1042: Mission Plan Interface MA_CapabilitySetMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CapabilitySetMDT	
Message Structure		
Field Name	Field Type	Field Usage
CapabilitySetID	MA_CapabilitySetID_Type	Required
Description	Indicates the unique ID of the CapabilitySet.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates a Capability that exists in the set.	
ApplicableSystemID	SystemID_Type	Optional
Description	Indicates the System that the CapabilitySet is relevant to.	
MissionPlanID	MissionPlanID_Type	Optional
Description	Indicates the MissionPlan that the CapabilitySet is relevant to.	
MissionID	MissionID_Type	Optional
Description	Indicates the Mission that the CapabilitySet is relevant to.	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-1043: Mission Plan Interface MA_CapabilitySetMT - MessageData UCI Extension Field

4.3.13 MA_CarrierReportMT UCI Extension

MA_CarrierReportMT	
Description	See the annotation in the associated message carrier status. See the XSD File for more info
Ext. Fields	LaunchCoordinates : MA_CarrierRunwayCoordinatesType Runway : MA_CarrierRunwayType

	CarrierReportID : MA_CarrierReportID_Type
	Direction : MA_AngleRelativeType
	Catapult : MA_CatapultType
	Information : MA_CarrierInformationType
	CatapultID : MA_CatapultID_Type
	MessageData : MA_CarrierReportMDT
	LandingCoordinates : MA_CarrierRunwayCoordinatesType
	Direction : MA_AngleRelativeType

Table A-4-1044: Mission Plan Interface MA_CarrierReportMT UCI Extension

LaunchCoordinates		
Description	Specifies the start coordinates of the catapult used for Launch.	
Base Type	MA_CarrierRunwayCoordinatesType	
Message Structure		
Field Name	Field Type	Field Usage
Start	Point3D_RelativeType	Required
Description	The waypoint at the start of the runway.	
Threshold	Point3D_RelativeType	Optional
Description	The waypoint at the nearest point of the runway.	
Limit	Point3D_RelativeType	Optional
Description	The waypoint at the furthest point of the runway.	

Table A-4-1045: Mission Plan Interface MA_CarrierReportMT - LaunchCoordinates UCI Extension Field

Runway		
Description	Contains details of the runway used for landing.	
Base Type	MA_CarrierRunwayType	
Message Structure		
Field Name	Field Type	Field Usage
RunwayID	RunwayID_Type	Required
Description	Indicates the unique ID for this Runway. Route paths may reference this runway for takeoff or landing paths.	
Direction	MA_AngleRelativeType	Optional
Description	Indicates offset angle to reference frame in radians.	
AvailableLength	DistanceType	Optional
Description	Indicates available length of runway in meters.	
Glideslope	AngleQuarterType	Optional
Description	Indicates glideslope for runway in radians.	
GCA	EmptyType	Optional

	Description	Indicates Ground-Controlled Approach service is available on runway when field is present.
ILS	EmptyType	Optional
	Description	Indicates Instrument Landing Systems service is available on runway when field is present.
ApproachLighting	ApproachLightingEnum	Optional
	Description	Indicates available approach lighting on runway according to MIL-STD-6016.
LandingCoordinates	MA_CarrierRunwayCoordinatesType	Optional
	Description	Specifies the coordinates of the runway when used for landings.
DefaultRunwayUsageDetails	RunwayUsageDetailsType	Optional
	Description	Specifies terms for using a runway. These details can be used in the decision process when choosing a runway.

Table A-4-1046: Mission Plan Interface MA_CarrierReportMT - Runway UCI Extension Field

CarrierReportID		
Description	Indicates a unique ID, assigned to this carrier report message.	
Base Type	MA_CarrierReportID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1047: Mission Plan Interface MA_CarrierReportMT - CarrierReportID UCI Extension Field

Direction		
Description	Indicates offset angle to reference frame in radians.	
Base Type	MA_AngleRelativeType	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceFrameID	ReferenceFrameID_Type	Required
Description	UUID of the reference frame object that this relative angle applies to.	
OffsetAngle	AngleType	Optional
Description	Offset angle relative to the reference frame origin.	

Table A-4-1048: Mission Plan Interface MA_CarrierReportMT - Direction UCI Extension Field

Catapult	
Description	Contains details of each catapult for launching.

Base Type	MA_CatapultType	
Message Structure		
Field Name	Field Type	Field Usage
CatapultID	MA_CatapultID_Type	Required
Description	Indicates the unique ID for this catapult. Route paths may reference this catapult for launch paths.	
Direction	MA_AngleRelativeType	Optional
Description	Indicates offset angle to reference frame in radians.	
AvailableLength	DistanceType	Optional
Description	Indicates available length of runway in meters.	
LaunchCoordinates	MA_CarrierRunwayCoordinatesType	Optional
Description	Specifies the start coordinates of the catapult used for Launch.	

Table A-4-1049: Mission Plan Interface MA_CarrierReportMT - Catapult UCI Extension Field

Information		
Description	Contains information about an Carrier.	
Base Type	MA_CarrierInformationType	
Message Structure		
Field Name	Field Type	Field Usage
CrashService	CrashServiceEnum	Optional
Description	Indicates availability of crash service on Carrier.	
Runway	MA_CarrierRunwayType	Optional
Description	Contains details of the runway used for landing.	
Catapult	MA_CatapultType	Repeated
Description	Contains details of each catapult for launching.	

Table A-4-1050: Mission Plan Interface MA_CarrierReportMT - Information UCI Extension Field

CatapultID		
Description	Indicates the unique ID for this catapult. Route paths may reference this catapult for launch paths.	
Base Type	MA_CatapultID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1051: Mission Plan Interface MA_CarrierReportMT - CatapultID UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CarrierReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
CarrierReportID	MA_CarrierReportID_Type	Required
Description	Indicates a unique ID, assigned to this carrier report message.	
CarrierID	SystemID_Type	Required
Description	Indicates a unique ID, assigned to this carrier report message.	
IdentityReferenceID	CarrierReferenceID_ChoiceType	Required
Description	Indicates whether message is self-reported or reported by third party.	
Information	MA_CarrierInformationType	Optional
Description	Contains information about an Carrier.	

Table A-4-1052: Mission Plan Interface MA_CarrierReportMT - MessageData UCI Extension Field

LandingCoordinates		
Description	Specifies the coordinates of the runway when used for landings.	
Base Type	MA_CarrierRunwayCoordinatesType	
Message Structure		
Field Name	Field Type	Field Usage
Start	Point3D_RelativeType	Required
Description	The waypoint at the start of the runway.	
Threshold	Point3D_RelativeType	Optional
Description	The waypoint at the nearest point of the runway.	
Limit	Point3D_RelativeType	Optional
Description	The waypoint at the furthest point of the runway.	

Table A-4-1053: Mission Plan Interface MA_CarrierReportMT - LandingCoordinates UCI Extension Field

Direction		
Description	Indicates offset angle to reference frame in radians.	
Base Type	MA_AngleRelativeType	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceFrameID	ReferenceFrameID_Type	Required
Description	UUID of the reference frame object that this relative angle applies to.	

OffsetAngle	AngleType	Optional
Description	Offset angle relative to the reference frame origin.	

Table A-4-1054: Mission Plan Interface MA_CarrierReportMT - Direction UCI Extension Field

4.3.14 MA_CarrierStateMT UCI Extension

MA_CarrierStateMT	
Description	See the annotation in the associated message carrier state. See the XSD File for more info
Ext. Fields	CarrierStateID : MA_CarrierStateID_Type CatapultID : MA_CatapultID_Type Catapult : MA_CatapultType Runway : MA_CarrierRunwayType Information : MA_CarrierStateInformationType MessageData : MA_CarrierStateMDT

Table A-4-1055: Mission Plan Interface MA_CarrierStateMT UCI Extension

CarrierStateID		
Description	Indicates a unique ID, assigned to this carrier state message.	
Base Type	MA_CarrierStateID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1056: Mission Plan Interface MA_CarrierStateMT - CarrierStateID UCI Extension Field

CatapultID		
Description	Indicates the unique ID for this catapult. Route paths may reference this catapult for launch paths.	
Base Type	MA_CatapultID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional

Description	Human readable text label with content meaningful to human operators.
-------------	---

Table A-4-1057: Mission Plan Interface MA_CarrierStateMT - CatapultID UCI Extension Field

Catapult		
Description	Contains details of each catapult for launching.	
Base Type	MA_CatapultType	
Message Structure		
Field Name	Field Type	Field Usage
CatapultID	MA_CatapultID_Type	Required
Description	Indicates the unique ID for this catapult. Route paths may reference this catapult for launch paths.	
Direction	MA_AngleRelativeType	Optional
Description	Indicates offset angle to reference frame in radians.	
AvailableLength	DistanceType	Optional
Description	Indicates available length of runway in meters.	
LaunchCoordinates	MA_CarrierRunwayCoordinatesType	Optional
Description	Specifies the start coordinates of the catapult used for Launch.	

Table A-4-1058: Mission Plan Interface MA_CarrierStateMT - Catapult UCI Extension Field

Runway		
Description	Contains details of the runway used for landing.	
Base Type	MA_CarrierRunwayType	
Message Structure		
Field Name	Field Type	Field Usage
RunwayID	RunwayID_Type	Required
Description	Indicates the unique ID for this Runway. Route paths may reference this runway for takeoff or landing paths.	
Direction	MA_AngleRelativeType	Optional
Description	Indicates offset angle to refence frame in radians.	
AvailableLength	DistanceType	Optional
Description	Indicates available length of runway in meters.	
Glideslope	AngleQuarterType	Optional
Description	Indicates glideslope for runway in radians.	
GCA	EmptyType	Optional
Description	Indicates Ground-Controlled Approach service is a available on runway when field is present.	
ILS	EmptyType	Optional
Description	Indicates Instrument Landing Systems service is a available on runway when field is present.	

ApproachLighting	ApproachLightingEnum	Optional
Description	Indicates available approach lighting on runway according to MIL-STD-6016.	
LandingCoordinates	MA_CarrierRunwayCoordinatesType	Optional
Description	Specifies the coordinates of the runway when used for landings.	
DefaultRunwayUsageDetails	RunwayUsageDetailsType	Optional
Description	Specifies terms for using a runway. These details can be used in the decision process when choosing a runway.	

Table A-4-1059: Mission Plan Interface MA_CarrierStateMT - Runway UCI Extension Field

Information		
Description	Contains information about an Carrier.	
Base Type	MA_CarrierStateInformationType	
Message Structure		
Field Name	Field Type	Field Usage
Operational	EmptyType	Optional
Description	Indicates Carrier is operational if present.	
AirRaidState	AirRaidStateEnum	Optional
Description	Indicated air raid state of Carrier according to MIL-STD-6016.	
Contamination	AirfieldContaminationType	Optional
Description	Contains contamination details about a Carrier.	
SHORADEZ_Active	EmptyType	Optional
Description	Indicates the SHORADEZ (Short Range Air Defense Engagement Zone) is active The zone is known by context.	
Runway	MA_CarrierRunwayStateType	Optional
Description	Contains details of the runway used for landing.	
Catapult	MA_CatapultStateType	Repeated
Description	Contains details of each catapult for launching.	
QNH_Setting	PressureType	Optional
Description	Indicates atmospheric pressure of an Carrier in kilopascals.	

Table A-4-1060: Mission Plan Interface MA_CarrierStateMT - Information UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CarrierStateMDT	
Message Structure		
Field Name	Field Type	Field Usage
CarrierStateID	MA_CarrierStateID_Type	Required

Description	Indicates a unique ID, assigned to this carrier state message.	
CarrierID	SystemID_Type	Required
Description	Indicates a unique ID, assigned to this carrier state message.	
IdentityReferenceID	CarrierReferenceID_ChoiceType	Required
Description	Indicates whether message is self-reported or reported by third party.	
ObservationTime	DateTimeType	Required
Description	Indicates the observation time of carrier state.	
Information	MA_CarrierStateInformationType	Optional
Description	Contains information about an Carrier.	
Weather	WeatherAreaDataType	Optional
Description	Contains weather details about a carrier. The wind in the WindData element provides wind information at ground level of the carrier.	
DepartureCase	MA_CaseTypeEnum	Optional
Description	This is the Case which indicates visibility level which impacts the departure routing	
RecoveryCase	MA_CaseTypeEnum	Optional
Description	This is the Case which indicates visibility level which impacts the recovery routing	
DepartureReferenceRadial	AngleType	Optional
Description	This is the Reference Radial used by ACPs departing the carrier.	
CarrierStores	AirfieldStoresPET	Repeated
Description	Contains details about stores available on an Carrier.	

Table A-4-1061: Mission Plan Interface MA_CarrierStateMT - MessageData UCI Extension Field

4.3.15 MA_ConstraintPriorityListActivationDataMT UCI Extension

MA_ConstraintPriorityListActivationDataMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ConstraintPriorityListActivationDataMDT

Table A-4-1062: Mission Plan Interface MA_ConstraintPriorityListActivationDataMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ConstraintPriorityListActivationDataMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConstraintPriorityListActivationDataID	MA_ConstraintPriorityListActivationDataID_Type	Required

	Description	The unique identifier for the message.	
DefaultConstraintPriorityListID		MA_ConstraintPriorityListID_Type	Required
	Description	Contains the ID of the Constraint Priority List that should be set as the default.	
ListOfApplicableOpConstrainedConstraintPriorityListIDs		MA_ListOfApplicableOpConstrainedConstraintPriorityListIDType	Repeated
	Description	When an Package/ACP is within this geozone, the linked Constraint Priority List will be used instead of the default. OpZone and OpVolume IDs can only appear once in this list.	

Table A-4-1063: Mission Plan Interface MA_ConstraintPriorityListActivationDataMT - MessageData UCI Extension Field

4.3.16 MA_ConstraintPriorityListMT UCI Extension

MA_ConstraintPriorityListMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ConstraintPriorityListMDT

Table A-4-1064: Mission Plan Interface MA_ConstraintPriorityListMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ConstraintPriorityListMDT	
Message Structure		
Field Name	Field Type	Field Usage
ConstraintPriorityListID	MA_ConstraintPriorityListID_Type	Required
Description	The unique identifier for the message.	
DefaultPriority	unsignedShort	Optional
Description	This field, if set, is the value that would be assigned to any ConstraintType that is not listed in the ListItem field. If this field is not set, the default value of ConstraintTypes not listed the ListItem field would be blank or the highest priority ("above" 0).	
ListItem	MA_ConstraintPriorityListItemType	Repeated
Description	Identifies a constraint type and it's priority in the Constraint Priority List.	

Table A-4-1065: Mission Plan Interface MA_ConstraintPriorityListMT - MessageData UCI Extension Field

4.3.17 MA_DesignationMT UCI Extension

MA_DesignationMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info

Ext. Fields	MessageData : MA_DesignationMDT
--------------------	---------------------------------

Table A-4-1066: Mission Plan Interface MA_DesignationMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DesignationMDT	
Message Structure		
Field Name	Field Type	Field Usage
DesignationData	MA_DesignationDataType	Repeated
Description	Indicates the data of one or more designations.	

Table A-4-1067: Mission Plan Interface MA_DesignationMT - MessageData UCI Extension Field

4.3.18 MA_ExecutionPriorityListActivationDataMT UCI Extension

MA_ExecutionPriorityListActivationDataMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ExecutionPriorityListActivationDataMDT

Table A-4-1068: Mission Plan Interface MA_ExecutionPriorityListActivationDataMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ExecutionPriorityListActivationDataMDT	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPriorityListActivationDataID	MA_ExecutionPriorityListActivationDataID_Type	Required
Description	The unique identifier for the message.	
DefaultExecutionPriorityListID	MA_ExecutionPriorityListID_Type	Required
Description	Contains the ID of the message that should be set as the default.	
ListOfApplicableOpConstrainedExecutionPriorityListIDs	MA_ListOfApplicableOpConstrainedExecutionPriorityListIDType	Repeated
Description	When an ACP is within this geozone, the linked message will be used instead of the default. OpZone and OpVolume IDs can only appear once in this list.	

Table A-4-1069: Mission Plan Interface MA_ExecutionPriorityListActivationDataMT - MessageData UCI Extension Field

4.3.19 MA_ExecutionPriorityListMT UCI Extension

MA_ExecutionPriorityListMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ExecutionPriorityListMDT

Table A-4-1070: Mission Plan Interface MA_ExecutionPriorityListMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ExecutionPriorityListMDT	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPriorityListID	MA_ExecutionPriorityListID_Type	Required
Description	The unique identifier for the message.	
ListItem	MA_ExecutionPriorityListItemType	Repeated
Description	Identifies an item (task or action) and its rank in the Execution Priority List.	

Table A-4-1071: Mission Plan Interface MA_ExecutionPriorityListMT - MessageData UCI Extension Field

4.3.20 MA_FlightCapabilityMT UCI Extension

MA_FlightCapabilityMT	
Description	Extended to indicate the type of flight capability via the FlightCapabilityEnum and provide per-control mode performance parameters. See the XSD File for more info
Ext. Fields	HSA_CSA_PerformanceProfile : MA_FlightControlModesPerformanceProfileType WaypointFollowingPerformanceProfile : MA_FlightControlModesPerformanceProfileType CurveFollowingPerformanceProfile : MA_FlightControlModesPerformanceProfileType AccelerationLimit : MA_BodyReferenceAccelerationType AccelerationLimitValue : MA_AccelerationLimitPairType BodyReferenceOrientationRate : MA_BodyReferenceOrientationRateType OrientationRateLimits : MA_BodyReferenceOrientationRateType AirspeedPair : PathSegmentSpeedValueType

Table A-4-1072: Mission Plan Interface MA_FlightCapabilityMT UCI Extension

HSA_CSA_PerformanceProfile	
Description	Indicates performance profile for HSA_CSA flight control mode.

Base Type	MA_FlightControlModesPerformanceProfileType	
Message Structure		
Field Name	Field Type	Field Usage
MinAirspeed	MA_AirspeedLimitType	Repeated
Description	Minimum allowable airspeed given as a function of altitude.	
MaxAirspeed	MA_AirspeedLimitType	Repeated
Description	Maximum allowable airspeed given as a function of altitude.	
BestEnduranceAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum endurance given as a function of altitude.	
BestRangeAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum range given as a function of altitude.	
MinAltitude	AltitudeReferenceType	Optional
Description	Minimum allowable altitude.	
MaxAltitude	AltitudeReferenceType	Optional
Description	Maximum allowable altitude.	
MinAccelerationLimits	MA_AccelerationLimitsType	Repeated
Description	The vehicle's acceleration limits in the current operating domain of the system as a function of time. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
ExcessPowerOrAcceleration	MA_ExcessPowerOrAccelerationType	Optional
Description	Provides either specific excess power or paired acceleration and climb rate data for the platform.	
MaxOrientationLimits	MA_OrientationLimitType	Repeated
Description	Euler Angle Sequence describing the maximum orientation of the vehicle in the order yaw, pitch, roll as a function of airspeed, altitude, and weight.	
MaxOrientationRateLimits	MA_OrientationRateLimitsType	Repeated
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
MaxTurnRate	AngleRateType	Optional
Description	Maximum allowable turn rate in radians/sec.	
MaxDescentRate	MA_SpeedType	Repeated
Description	Maximum allowable descent rate as a function of airspeed, altitude, and weight.	
MaxDeceleration	MA_AccelerationLimitsType	Repeated
Description	Maximum allowable deceleration limits as a function of airspeed, altitude, and weight.	
FuelBurnRate	MA_FuelBurnRateType	Repeated

Description	Fuel burn rate as a function of airspeed, altitude, and weight.
-------------	---

Table A-4-1073: Mission Plan Interface MA_FlightCapabilityMT - HSA_CSA_PerformanceProfile UCI Extension Field

WaypointFollowingPerformanceProfile		
Description	Indicates performance profile for Waypoint Following flight control mode.	
Base Type	MA_FlightControlModesPerformanceProfileType	
Message Structure		
Field Name	Field Type	Field Usage
MinAirspeed	MA_AirspeedLimitType	Repeated
Description	Minimum allowable airspeed given as a function of altitude.	
MaxAirspeed	MA_AirspeedLimitType	Repeated
Description	Maximum allowable airspeed given as a function of altitude.	
BestEnduranceAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum endurance given as a function of altitude.	
BestRangeAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum range given as a function of altitude.	
MinAltitude	AltitudeReferenceType	Optional
Description	Minimum allowable altitude.	
MaxAltitude	AltitudeReferenceType	Optional
Description	Maximum allowable altitude.	
MinAccelerationLimits	MA_AccelerationLimitsType	Repeated
Description	The vehicle's acceleration limits in the current operating domain of the system as a function of time. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
ExcessPowerOrAcceleration	MA_ExcessPowerOrAccelerationType	Optional
Description	Provides either specific excess power or paired acceleration and climb rate data for the platform.	
MaxOrientationLimits	MA_OrientationLimitType	Repeated
Description	Euler Angle Sequence describing the maximum orientation of the vehicle in the order yaw, pitch, roll as a function of airspeed, altitude, and weight.	
MaxOrientationRateLimits	MA_OrientationRateLimitsType	Repeated
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
MaxTurnRate	AngleRateType	Optional
Description	Maximum allowable turn rate in radians/sec.	
MaxDescentRate	MA_SpeedType	Repeated

Description	Maximum allowable descent rate as a function of airspeed, altitude, and weight.	
MaxDeceleration	MA_AccelerationLimitsType	Repeated
Description	Maximum allowable deceleration limits as a function of airspeed, altitude, and weight.	
FuelBurnRate	MA_FuelBurnRateType	Repeated
Description	Fuel burn rate as a function of airspeed, altitude, and weight.	

Table A-4-1074: Mission Plan Interface MA_FlightCapabilityMT - WaypointFollowingPerformanceProfile UCI Extension Field

CurveFollowingPerformanceProfile		
Description	Indicates performance profile for Curve Following flight control mode.	
Base Type	MA_FlightControlModesPerformanceProfileType	
Message Structure		
Field Name	Field Type	Field Usage
MinAirspeed	MA_AirspeedLimitType	Repeated
Description	Minimum allowable airspeed given as a function of altitude.	
MaxAirspeed	MA_AirspeedLimitType	Repeated
Description	Maximum allowable airspeed given as a function of altitude.	
BestEnduranceAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum endurance given as a function of altitude.	
BestRangeAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum range given as a function of altitude.	
MinAltitude	AltitudeReferenceType	Optional
Description	Minimum allowable altitude.	
MaxAltitude	AltitudeReferenceType	Optional
Description	Maximum allowable altitude.	
MinAccelerationLimits	MA_AccelerationLimitsType	Repeated
Description	The vehicle's acceleration limits in the current operating domain of the system as a function of time. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
ExcessPowerOrAcceleration	MA_ExcessPowerOrAccelerationType	Optional
Description	Provides either specific excess power or paired acceleration and climb rate data for the platform.	
MaxOrientationLimits	MA_OrientationLimitType	Repeated
Description	Euler Angle Sequence describing the maximum orientation of the vehicle in the order yaw, pitch, roll as a function of airspeed, altitude, and weight.	
MaxOrientationRateLimits	MA_OrientationRateLimitsType	Repeated
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may	

	utilize an unbounded number of time indices to form dynamically feasible trajectories.	
MaxTurnRate	AngleRateType	Optional
Description	Maximum allowable turn rate in radians/sec.	
MaxDescentRate	MA_SpeedType	Repeated
Description	Maximum allowable descent rate as a function of airspeed, altitude, and weight.	
MaxDeceleration	MA_AccelerationLimitsType	Repeated
Description	Maximum allowable deceleration limits as a function of airspeed, altitude, and weight.	
FuelBurnRate	MA_FuelBurnRateType	Repeated
Description	Fuel burn rate as a function of airspeed, altitude, and weight.	

Table A-4-1075: Mission Plan Interface MA_FlightCapabilityMT - CurveFollowingPerformanceProfile UCI Extension Field

AccelerationLimit		
Description	Specified acceleration limits in body reference or NED coordinate frame.	
Base Type	MA_BodyReferenceAccelerationType	
Message Structure		
Field Name	Field Type	Field Usage
X_Accel	AccelerationType	Required
Description	Body-referenced acceleration component along the longitudinal (x or roll) axis, measured in meters/sec^2	
Y_Accel	AccelerationType	Required
Description	Body-referenced acceleration component along the lateral (y or pitch) axis, measured in meters/sec^2	
Z_Accel	AccelerationType	Required
Description	Body-referenced acceleration component along the vertical (z or yaw) axis, measured in meters/sec^2.	
Timestamp	DateTimeType	Optional
Description	Indicates the time when the acceleration data was measured or last known to be correct. The element can also indicate the time at which a future velocity of a System, Entity, etc. will be achieved.	

Table A-4-1076: Mission Plan Interface MA_FlightCapabilityMT - AccelerationLimit UCI Extension Field

AccelerationLimitValue		
Description	Value for the specified acceleration limit, provided either as a set of body referenced orientation rates, or a unitless Mach value.	
Base Type	MA_AccelerationLimitPairType	
Message Structure		
Field Name	Field Type	Field Usage
BodyReferenceOrientationRate	MA_BodyReferenceOrientationRateType	Required
Description	Body reference orientation rates to be paired with the specified acceleration limit.	

MachValue	MachType	Required
Description	Unitless Mach value to be paired with the specified acceleration limit.	

Table A-4-1077: Mission Plan Interface MA_FlightCapabilityMT - AccelerationLimitValue UCI Extension Field

BodyReferenceOrientationRate		
Description	Body reference orientation rates to be paired with the specified acceleration limit.	
Base Type	MA_BodyReferenceOrientationRateType	
Message Structure		
Field Name	Field Type	Field Usage
RollRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the longitudinal (x or roll) axis, measured in radians/sec.	
PitchRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the lateral (y or pitch) axis, measured in radians/sec.	
YawRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the vertical (z or yaw) axis, measured in radians/sec.	
Timestamp	DateTimeType	Optional
Description	Indicates the time when the velocity data was measured or last known to be correct. The element can also indicate the time at which a future velocity of a System, Entity, etc. will be achieved.	

Table A-4-1078: Mission Plan Interface MA_FlightCapabilityMT - BodyReferenceOrientationRate UCI Extension Field

OrientationRateLimits		
Description	Specified orientation rate limits in body reference or NED coordinate frame.	
Base Type	MA_BodyReferenceOrientationRateType	
Message Structure		
Field Name	Field Type	Field Usage
RollRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the longitudinal (x or roll) axis, measured in radians/sec.	
PitchRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the lateral (y or pitch) axis, measured in radians/sec.	
YawRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the vertical (z or yaw) axis, measured in radians/sec.	
Timestamp	DateTimeType	Optional

Description	Indicates the time when the velocity data was measured or last known to be correct. The element can also indicate the time at which a future velocity of a System, Entity, etc. will be achieved.
-------------	---

Table A-4-1079: Mission Plan Interface MA_FlightCapabilityMT - OrientationRateLimits UCI Extension Field

AirspeedPair		
Description	Airspeed pair value for associated orientation rate limit, specified in body reference or NED coordinate frame.	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-1080: Mission Plan Interface MA_FlightCapabilityMT - AirspeedPair UCI Extension Field

4.3.21 MA_InteroperabilityPolicyMT UCI Extension

MA_InteroperabilityPolicyMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_InteroperabilityPolicyMDT

Table A-4-1081: Mission Plan Interface MA_InteroperabilityPolicyMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_InteroperabilityPolicyMDT	
Message Structure		
Field Name	Field Type	Field Usage
InteroperabilityPolicyID	MA_InteroperabilityPolicyID_Type	Required
Description	Indicates the unique ID of the interoperability policy.	
OpPolicy	MA_OpPolicyType	Repeated
Description	Indicates a set of interoperability policies for the handling of OpPoints, OpLines, OpVolumes, etc.	
TimedZone	TimedZoneType	Optional
Description	Indicates the geospatial zone and optionally time/date span or spans when the policy is active. For Op* types, the policy is applicable to 1) the time of Op* instances that	

	lies within the time/date span and 2) the area of Op* instances which falls within the zone. This element supersedes the sibling Expires element.	
Expires	DateTimeType	Optional
Description	Indicates the time and date when the policy expires. The policy is applicable to Op* instances during their existence prior to this time. When the sibling TimedZone element is used, the time spans specified there supersede this element.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of the interoperability policy to specify the source or motivation for this InteroperabilityPolicy such as ATO, ACO, etc.	
DataRecordInstanceID	DataRecordInstanceID_Type	Optional
Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-1082: Mission Plan Interface MA_InteroperabilityPolicyMT - MessageData UCI Extension Field

4.3.22 MA_LeadershipMetricsMT UCI Extension

MA_LeadershipMetricsMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_LeadershipMetricsMDT

Table A-4-1083: Mission Plan Interface MA_LeadershipMetricsMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_LeadershipMetricsMDT	
Message Structure		
Field Name	Field Type	Field Usage
PackagePartnerMetrics	MA_PartnerMetricsType	Repeated
Description	Indicates the leadership fitness metrics for the partners in the package.	
PackageLeaderElectionMethod	Integer	Required
Description	Specifies which election method/algorithm the package will utilize for electing a Package Leader. Implementors are expected to set a default election method. If blank, the default election method will be used. Integer values and corresponding election methods are as follows: 0 - Bully Election Method. Supports Dynamic Fitness Scores and cases where	

	Leadership Fitness Scores need to be shared as part of an election process. 1- Static Fitness Score Election Method. Supports nomination of a leader assuming leadership fitness scores remain static once they have been defined by MP/C2. 2 - Maximum Consensus Election Method. Supports utilizing consensus algorithms to reach team consensus on the leader while preserving communication bandwidth. 3 - Raft Leader Election Method. Supports leader election using the Raft consensus algorithm, which ensures a distributed and fault-tolerant approach to electing a leader.
--	--

Table A-4-1084: Mission Plan Interface MA_LeadershipMetricsMT - MessageData UCI Extension Field

4.3.23 MA_MissionPlanMT UCI Extension

MA_MissionPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_MissionPlanMDT

Table A-4-1085: Mission Plan Interface MA_MissionPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	Indicates a unique ID assigned to the MissionPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
MissionPlanCommandID	MissionPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which this MissionPlan originated from.	
Applicability	MA_PlanApplicabilityType	Required
Description	Indicates the System or Systems which have a direct relationship with the Mission Plan. See annotations for the underlying type and its child elements for details.	
Window	DateTimeRangeType	Optional
Description	The time window for which the Plan is applicable.	
SubPlans	MA_PlansReferenceBaseType	Optional
Description	Indicates the set of *Plans which are included as part of the MissionPlan. The included SubPlans share the same Applicability as the MissionPlan.	
ExecutionSequence	ExecutionSequenceType	Optional
Description	Indicates the MissionPlan's flow of execution when there are multiple kinematic and	

	action plans. The kinematic and action plans are combined into sets and given unique IDs. An execution flow may be created by linking *ExecutionPlanSets of different types (e.g. OrbitExecutionPlanSet and RouteExecutionPlanSet).	
ParentMissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a MissionPlan that is the parent of this MissionPlan.	
SubordinateMissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a MissionPlan that is subordinate to this MissionPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	MA_MissionPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	
Remarks	RemarksType	Optional
Description	Indicates information about the mission plan from an operator intended for display. Both short and longer detailed information can be provided.	

Table A-4-1086: Mission Plan Interface MA_MissionPlanMT - MessageData UCI Extension Field

4.3.24 MA_OperatorRoleMT UCI Extension

MA_OperatorRoleMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	SystemID : SystemID_Type

Table A-4-1087: Mission Plan Interface MA_OperatorRoleMT UCI Extension

SystemID		
Description	Indicates the SystemID that the OperatorRole belongs to. If not populated, it is assumed to be the SystemID specified in the MessageHeader.	
Base Type	SystemID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1088: Mission Plan Interface MA_OperatorRoleMT - SystemID UCI Extension Field

4.3.25 MA_OpLineMT UCI Extension

MA_OpLineMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	Category : MA_OpLineCategoryEnum AppliesToIDs : MA_PackageSystemType MessageData : MA_OpLineMDT

Table A-4-1089: Mission Plan Interface MA_OpLineMT UCI Extension

Category	
Description	This element indicates the type of operational line.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying

	through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-1090: Mission Plan Interface MA_OpLineMT - Category UCI Extension Field

AppliesToIDs		
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-1091: Mission Plan Interface MA_OpLineMT - AppliesToIDs UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpLineMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpLineID	OpLineID_Type	Required
Description	Indicates the unique ID of the OpLine.	
Category	MA_OpLineCategoryEnum	Required
Description	This element indicates the type of operational line.	
Line	OpLineType	Required
Description	Indicates the geometric description of the OpLine. In practice, operational lines can be	

	geometric lines, areas or in some cases volumes.	
OpDescription	OpDescriptionType	Optional
Description	A human-readable descriptive name with free text remarks.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this operational item to specify what the source or motivation for it originated from. This could be ATO, ACO, etc.	
Source	CreationSourceEnum	Optional
Description	Indicates the source of the information.	
Schedule	ScheduleType	Optional
Description	This element represents a date/time interval associated with the operational item during which the item is in effect.	
AssociatedTime	TimeFunctionType	Repeated
Description	Indicates time related events that are associated to the Op data type such as when activated or when operational. The multiplicity is limited to N-1 options where NONE is an event that has no value, thus removed from list of available options.	
DataLinkIdentifier	DataLinkIdentifierPET	Repeated
Description	List of data link ID. Multiple data link IDs can be reported for the same network type.	
Priority	unsignedInt	Optional
Description	This field represents the priority to be considered when choosing between multiple available points.	
QualifyingTags	QualifyingTagsType	Optional
Description	Provides identity qualifications to augment identification and associated processing of the OpPoint.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
SystemScheduleOverride	SystemScheduleStateType	Repeated
Description	System-specific schedule that will override any part of the main schedule. This allows for system-specific schedule different than main schedule. When adding a SystemScheduleOverride, the child SystemID also must be added to the sibling SystemID list if the sibling list is not empty. The SystemScheduleOverride is independent of time planning. For the system, this override can be done at execution.	

Table A-4-1092: Mission Plan Interface MA_OpLineMT - MessageData UCI Extension Field

4.3.26 MA_OpPlanMT UCI Extension

MA_OpPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_OpPlanMDT

Table A-4-1093: Mission Plan Interface MA_OpPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_OpPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpPlanID	MA_OpPlanID_Type	Required
Description	Indicates a unique ID assigned to the OpPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	MA_OpPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the OpPlan originated from.	
Plan	MA_OpPlanType	Required
Description	Contains the details of the Op* allocation plan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	

Table A-4-1094: Mission Plan Interface MA_OpPlanMT - MessageData UCI Extension Field

4.3.27 MA_OpPointMT UCI Extension

MA_OpPointMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_OpPointMDT AppliesToIDs : MA_PackageSystemType

Table A-4-1095: Mission Plan Interface MA_OpPointMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpPointMDT	
Message Structure		
Field Name	Field Type	Field Usage
Category	OpPointCategoriesType	Required
Description	This element indicates the type of operational point.	

CategoryUniqueData	OpPointCategoriesUniqueDataType	Optional
Description	This element indicates the unique data for the type of operational point.	
OpPointID	OpPointID_Type	Required
Description	This element represents the unique identifier of the point associated with this message.	
PointChoice	OpPointChoiceType	Required
Description	Choice of either geospatial or relative position of the OpPoint.	
SystemConfiguration	SystemConfigurationType	Repeated
Description	Indicates a System which the OpPoint is applicable for and its planned configuration/state upon arriving at the OpPoint. If omitted, the OpPoint applies to all Systems.	
TurnDirection	RelativeDirectionEnum	Optional
Description	This field provides the turn direction for orbit.	
IngressConstraint	AnglePairType	Optional
Description	When present this field constrains the vehicle ingress path toward the OpPoint. The allowable ingress range is defined clockwise from Min to Max.	
SafeAltitude	SafeAltitudeType	Optional
Description	This field specifies a set of safe minimum approach altitudes and an emergency safe altitude. This field also specifies the cylindrical area, defined by a center point and radius, where the altitudes apply. This field defines minimum approach altitude and emergency safe altitude consistent with standard FAA instrument approach chart definitions (using UCI standard data types).	
OpDescription	OpDescriptionType	Optional
Description	A human-readable descriptive name with free text remarks.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this operational item to specify what the source or motivation for it originated from. This could be ATO, ACO, etc.	
Source	CreationSourceEnum	Optional
Description	Indicates the source of the information.	
Schedule	ScheduleType	Optional
Description	This element represents a date/time interval associated with the operational item during which the item is in effect.	
AssociatedTime	TimeFunctionType	Repeated
Description	Indicates time related events that are associated to the Op data type such as when activated or when operational. The multiplicity is limited to N-1 options where NONE is an event that has no value, thus removed from list of available options.	
DataLinkIdentifier	DataLinkIdentifierPET	Repeated
Description	List of data link ID. Multiple data link IDs can be reported for the same network type.	
Priority	unsignedInt	Optional
Description	This field represents the priority to be considered when choosing between multiple available points.	

QualifyingTags	QualifyingTagsType	Optional
Description	Provides identity qualifications to augment identification and associated processing of the OpPoint.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
SystemScheduleOverride	SystemScheduleStateType	Repeated
Description	System-specific schedule that will override any part of the main schedule. This allows for system-specific schedule different than main schedule. When adding a SystemScheduleOverride, the child SystemID also must be added to the sibling SystemID list if the sibling list is not empty. The SystemScheduleOverride is independent of time planning. For the system, this override can be done at execution.	

Table A-4-1096: Mission Plan Interface MA_OpPointMT - MessageData UCI Extension Field

AppliesToIDs		
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-1097: Mission Plan Interface MA_OpPointMT - AppliesToIDs UCI Extension Field

4.3.28 MA_OpRoutingMT UCI Extension

MA_OpRoutingMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ApplicableToIDs : MA_PackageSystemType MessageData : MA_OpRoutingMDT

Table A-4-1098: Mission Plan Interface MA_OpRoutingMT UCI Extension

ApplicableToIDs	
Description	One or more Systems to which the routing constraints apply. If omitted, the

	constraints apply to all Systems.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-1099: Mission Plan Interface MA_OpRoutingMT - ApplicableToIDs UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpRoutingMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpRoutingID	OpRoutingID_Type	Required
Description	The unique identifier of the set of routing constraints during operation associated with this message.	
DefaultBlueSeparation	SeparationParametersType	Optional
Description	Indicates default minimum geospatial separation to be maintained when planning or analyzing routes or manually navigating. The separation is between the planned/navigated route and other routes or conflicting items. This is the default separation. It can be overridden in specific cases by the sibling element.	
DefaultRedSeparation	SeparationParametersType	Optional
Description	Indicates default minimum geospatial separation to be maintained when planning or analyzing routes or manually navigating. The separation is between the planned/navigated route and other routes or conflicting items. This is the default separation. It can be overridden in specific cases by the sibling element.	
SpecificBlueSeparation	SpecificBlueSeparationType	Repeated
Description	Defines parameters to use when deconflicting blue player routes or generating routes to ensure proper separation from other blue players. These parameters apply at the vehicle type level.	
SpecificRedSeparation	SpecificRedSeparationType	Repeated
Description	Defines parameters to use when deconflicting blue player routes or generating routes to ensure proper separation from other red players. These parameters apply at the vehicle type level.	

OpDescription	OpDescriptionType	Optional
Description	Represents the name and description of the set of associated routing constraints.	
ApplicableToIDs	MA_PackageSystemType	Repeated
Description	One or more Systems to which the routing constraints apply. If omitted, the constraints apply to all Systems.	
ApplicableZone	ZoneType	Optional
Description	Indicates the geospatial zone in which the routing constraints apply.	
Schedule	ScheduleType	Optional
Description	Indicates the time schedule during which the routing constraints apply.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this zone to specify what the source or motivation for this zone originated from. This could be ATO, ACO, etc.	

Table A-4-1100: Mission Plan Interface MA_OpRoutingMT - MessageData UCI Extension Field

4.3.29 MA_OpVolumeMT UCI Extension

MA_OpVolumeMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_OpVolumeMDT

Table A-4-1101: Mission Plan Interface MA_OpVolumeMT UCI Extension

MessageData		
Description	This element represents the details regarding the operational volume.	
Base Type	MA_OpVolumeMDT	
Message Structure		
Field Name	Field Type	Field Usage
OpVolumeID	OpVolumeID_Type	Required
Description	This element represents the unique identifier of the OpVolume associated with this message.	
Category	MA_OpZoneCategoryEnum	Required
Description	This element indicates the type of volume.	
CategoryUniqueData	MA_OpZoneCategoryType	Optional
Description	Contains parameters unique to certain OpZoneCategoryEnum values.	
Volume	MA_OpVolumeChoiceType	Required
Description	This element represents the characteristics of the operational volume.	
SituationalAwareness	boolean	Required
Description	Volume used only for situational awareness. Not used for planning purposes.	

OpDescription	OpDescriptionType	Optional
Description	A human-readable descriptive name with free text remarks.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this operational item to specify what the source or motivation for it originated from. This could be ATO, ACO, etc.	
Source	CreationSourceEnum	Optional
Description	Indicates the source of the information.	
Schedule	ScheduleType	Optional
Description	This element represents a date/time interval associated with the operational item during which the item is in effect.	
AssociatedTime	TimeFunctionType	Repeated
Description	Indicates time related events that are associated to the Op data type such as when activated or when operational. The multiplicity is limited to N-1 options where NONE is an event that has no value, thus removed from list of available options.	
DataLinkIdentifier	DataLinkIdentifierPET	Repeated
Description	List of data link ID. Multiple data link IDs can be reported for the same network type.	
Priority	unsignedInt	Optional
Description	This field represents the priority to be considered when choosing between multiple available points.	
QualifyingTags	QualifyingTagsType	Optional
Description	Provides identity qualifications to augment identification and associated processing of the OpPoint.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
SystemScheduleOverride	SystemScheduleStateType	Repeated
Description	System-specific schedule that will override any part of the main schedule. This allows for system-specific schedule different than main schedule. When adding a SystemScheduleOverride, the child SystemID also must be added to the sibling SystemID list if the sibling list is not empty. The SystemScheduleOverride is independent of time planning. For the system, this override can be done at execution.	

Table A-4-1102: Mission Plan Interface MA_OpVolumeMT - MessageData UCI Extension Field

4.3.30 MA_OpZoneMT UCI Extension

MA_OpZoneMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_OpZoneMDT Category : MA_OpZoneCategoryEnum CategoryUniqueData : MA_OpZoneCategoryType

SpeedLimits : MA_OpZoneSpeedLimitsType
 VehicleConfiguration : MA_VehicleCommandDataType
 Zone : MA_OpZoneChoiceType
 GeometryReference : MA_ReferentialOpZoneType
 ReferenceObjectsFilter : MA_GeoLocatedObjectFilterType
 OpPointFilter : MA_OpPointFilterType
 OpLineFilter : MA_OpLineFilterType
 OpLineCategory : MA_OpLineCategoryEnum
 OpZoneFilter : MA_OpZoneFilterType
 OpZoneCategory : MA_OpZoneCategoryEnum
 OpVolumeFilter : MA_OpVolumeFilterType
 OpVolumeCategory : MA_OpZoneCategoryEnum
 DMPI_Filter : MA_DMPI_FilterType
 SignalReportFilter : MA_SignalReportFilterType
 OpVolumeFilter : MA_OpVolumeFilterType
 OpLineFilter : MA_OpLineFilterType
 OpLineCategory : MA_OpLineCategoryEnum
 SpeedLimits : MA_OpZoneSpeedLimitsType
 SignalReportFilter : MA_SignalReportFilterType
 OpPointFilter : MA_OpPointFilterType
 VehicleConfiguration : MA_VehicleCommandDataType
 DMPI_Filter : MA_DMPI_FilterType
 Zone : MA_OpZoneChoiceType
 Category : MA_OpZoneCategoryEnum
 CategoryUniqueData : MA_OpZoneCategoryType
 ReferenceObjectsFilter : MA_GeoLocatedObjectFilterType
 OpVolumeCategory : MA_OpZoneCategoryEnum
 GeometryReference : MA_ReferentialOpZoneType
 OpZoneCategory : MA_OpZoneCategoryEnum
 OpZoneFilter : MA_OpZoneFilterType

Table A-4-1103: Mission Plan Interface MA_OpZoneMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_OpZoneMDT	
Message Structure		
Field Name	Field Type	Field Usage

OpZoneID	OpZoneID_Type	Required
Description	This element represents the unique identifier of the zone associated with this message.	
Category	MA_OpZoneCategoryEnum	Required
Description	This element indicates the type of zone.	
CategoryUniqueData	MA_OpZoneCategoryType	Optional
Description	Contains parameters unique to certain OpZoneCategoryEnum values.	
Zone	MA_OpZoneChoiceType	Required
Description	This element represents the geospatial and temporal characteristics of the OpZone.	
SituationalAwareness	boolean	Required
Description	Zone used only for situational awareness. Not used for planning purposes.	
OpDescription	OpDescriptionType	Optional
Description	A human-readable descriptive name with free text remarks.	
MissionTraceability	MissionTraceabilityType	Optional
Description	Allows the creator of this operational item to specify what the source or motivation for it originated from. This could be ATO, ACO, etc.	
Source	CreationSourceEnum	Optional
Description	Indicates the source of the information.	
Schedule	ScheduleType	Optional
Description	This element represents a date/time interval associated with the operational item during which the item is in effect.	
AssociatedTime	TimeFunctionType	Repeated
Description	Indicates time related events that are associated to the Op data type such as when activated or when operational. The multiplicity is limited to N-1 options where NONE is an event that has no value, thus removed from list of available options.	
DataLinkIdentifier	DataLinkIdentifierPET	Repeated
Description	List of data link ID. Multiple data link IDs can be reported for the same network type.	
Priority	unsignedInt	Optional
Description	This field represents the priority to be considered when choosing between multiple available points.	
QualifyingTags	QualifyingTagsType	Optional
Description	Provides identity qualifications to augment identification and associated processing of the OpPoint.	
AppliesToIDs	MA_PackageSystemType	Repeated
Description	One or more systems to which this item applies. If omitted, item applies to all systems.	
SystemScheduleOverride	SystemScheduleStateType	Repeated
Description	System-specific schedule that will override any part of the main schedule. This allows for system-specific schedule different than main schedule. When adding a SystemScheduleOverride, the child SystemID also must be added to the sibling SystemID list if the sibling list is not empty. The SystemScheduleOverride is	

	independent of time planning. For the system, this override can be done at execution.
--	---

Table A-4-1104: Mission Plan Interface MA_OpZoneMT - MessageData UCI Extension Field

Category	
Description	This element indicates the type of zone.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in

	OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType

	choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-1105: Mission Plan Interface MA_OpZoneMT - Category UCI Extension Field

CategoryUniqueData		
Description	Contains parameters unique to certain OpZoneCategoryEnum values.	
Base Type	MA_OpZoneCategoryType	
Message Structure		
Field Name	Field Type	Field Usage
ConstrainedEntryExit	ConstrainedEntryExitType	Required
Description	Defines boundaries which applicable Systems can only enter and exit through defined edges.	
FilterArea	OpZoneFilterAreaPET	Repeated
Description	Indicates that the OpZone can be a zone filter type.	
Jamming	OpZoneJammingType	Required
Description	Indicates that the OpZone is a jamming control zone.	
KeepIn	IngressEgressType	Required
Description	Defines boundaries to which applicable Systems must stay inside.	
MissileLaunchPoint	OpZoneMissileDataType	Required
Description	Data defining a missile type, related track, and source of launch position.	
NoFire	OpZoneNoFireType	Required
Description	Defines areas where strike impact is restricted. Does not restrict the launch of weapons.	
NoFly	OpZoneNoFlyType	Required
Description	Defines area where flight is restricted. Equivalent to MIL-STD-6016 restricted zone.	
SpeedLimits	MA_OpZoneSpeedLimitsType	Required
Description	Defines area where speeds are restricted.	
VehicleConfiguration	MA_VehicleCommandDataType	Required
Description	Defines vehicle configuration parameters that should change based on the planned location of a vehicle.	
WeaponRestriction	OpZoneWeaponRestrictionType	Required
Description	Set of restricted weapons that cannot be used against a target type and or in a zone.	
WeatherConditions	OpZoneWeatherType	Required
Description	Defines area of weather conditions with potential of mission impact.	

Table A-4-1106: Mission Plan Interface MA_OpZoneMT - CategoryUniqueData UCI Extension Field

SpeedLimits

Description	Defines area where speeds are restricted.	
Base Type	MA_OpZoneSpeedLimitsType	
Message Structure		
Field Name	Field Type	Field Usage
MinSpeedLimit	PathSegmentSpeedValueType	Optional
Description	Indicates the minimum speed limit in meters per second within a zone/region.	
MaxSpeedLimit	PathSegmentSpeedValueType	Optional
Description	Indicates the maximum speed limit in meters per second within a zone/region.	

Table A-4-1107: Mission Plan Interface MA_OpZoneMT - SpeedLimits UCI Extension Field

VehicleConfiguration		
Description	Defines vehicle configuration parameters that should change based on the planned location of a vehicle.	
Base Type	MA_VehicleCommandDataType	
Message Structure		
Field Name	Field Type	Field Usage
VehicleAction	VehicleActionEnum	Optional
Description	Defines vehicle actions that can be done along a path segment of a route.	
IFF_Settings	IFF_Type	Optional
Description	If present the IFF settings for this vehicle will be changed along this path segment.	
SurvivabilityMode	VehicleSurvivabilityModeEnum	Optional
Description	Specifies that the vehicle should put itself into a more survivable mode. Different vehicles will have specific behaviors that reduce the signature of the vehicle (doors closed, minimal use of flaps, etc.) If this element is not present then it is assumed that the aircraft being configured has no survivability mode.	
LostCommTimeout	DurationType	Optional
Description	Defines the lost communication contingency timeout. When this timeout value is exceeded, the AV considers that lost communication has occurred and begins to perform contingency measures.	
LOS	boolean	Optional
Description	Use Line Of Sight (LOS) communication as backup contingency.	
LossOfLinkProcessing	VehicleLossOfLinkProcessingEnum	Optional
Description	Specifies whether the vehicle should invoke special Loss of Link processing. This could be turned off if the vehicle is going to be in a known and accepted lost communication situation.	
CommAllocationAction	CommAllocationActionType	Optional
Description	Indicates a change of communication allocation.	
QNH_Setting	PressureType	Optional
Description	Represents the barometric altimeter setting for correct MSL reading, commonly known as QNH, requested. Expressed in kilopascals (kPa).	

Table A-4-1108: Mission Plan Interface MA_OpZoneMT - VehicleConfiguration UCI Extension Field

Zone		
Description	This element represents the geospatial and temporal characteristics of the OpZone.	
Base Type	MA_OpZoneChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
GeometrySpecification	OpZoneType	Required
Description	Defines an OpZone geometry	
GeometryReference	MA_ReferentialOpZoneType	Required
Description	Defines an OpZone geometry via reference to other filtered objects	

Table A-4-1109: Mission Plan Interface MA_OpZoneMT - Zone UCI Extension Field

GeometryReference		
Description	Defines an OpZone geometry via reference to other filtered objects	
Base Type	MA_ReferentialOpZoneType	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceObjectsFilter	MA_GeoLocatedObjectFilterType	Repeated
Description	The geometry of all objects returned by this filter will be used for the OpZone being defined.	
HorizontalBuffer	DistanceType	Required
Description	The area of the resulting OpZone is the area of the referenced object, expanded by this horizontal buffer along the plane orthogonal to the NED frame's down direction	
MinAltitudeBuffer	DistanceType	Required
Description	The min altitude of the resulting OpZone is the min altitude of the referenced object, decreased by this min altitude buffer	
MaxAltitudeBuffer	DistanceType	Required
Description	The max altitude of the resulting OpZone is the max altitude of the referenced object, increased by this max altitude buffer	

Table A-4-1110: Mission Plan Interface MA_OpZoneMT - GeometryReference UCI Extension Field

ReferenceObjectsFilter		
Description	The geometry of all objects returned by this filter will be used for the OpZone being defined.	
Base Type	MA_GeoLocatedObjectFilterType	
Message Structure		
Field Name	Field Type	Field Usage
EntityFilter	EntityFilterType	Optional

	Description	Indicates a name/type of Entity required to match the filter. If omitted, any name/type of Entity satisfies the filter.
SystemFilter		SystemFilterType Optional
	Description	Indicates a name/type of System required to match the filter. If omitted, any name/type of System satisfies the filter.
OpPointFilter		MA_OpPointFilterType Optional
	Description	Indicates a name/type of OpPoint required to match the filter. If omitted, any name/type of OpPoint satisfies the filter.
OpLineFilter		MA_OpLineFilterType Optional
	Description	Indicates a name/type of OpLine required to match the filter. If omitted, any name/type of OpLine satisfies the filter.
OpZoneFilter		MA_OpZoneFilterType Optional
	Description	Indicates a name/type of OpZone required to match the filter. If omitted, any name/type of OpZone satisfies the filter.
OpVolumeFilter		MA_OpVolumeFilterType Optional
	Description	Indicates a name/type of OpVolume required to match the filter. If omitted, any name/type of OpVolume satisfies the filter.
DMPI_Filter		MA_DMPI_FilterType Optional
	Description	Indicates a name/type of DMPI required to match the filter. If omitted, any name/type of DMPI satisfies the filter.
SignalReportFilter		MA_SignalReportFilterType Optional
	Description	Indicates a name/type of SignalReport required to match the filter. If omitted, any name/type of SignalReport satisfies the filter.

Table A-4-1111: Mission Plan Interface MA_OpZoneMT - ReferenceObjectsFilter UCI Extension Field

OpPointFilter		
Description	Indicates a name/type of OpPoint required to match the filter. If omitted, any name/type of OpPoint satisfies the filter.	
Base Type	MA_OpPointFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointID	OpPointID_Type	Repeated
Description	Indicates a specific OpPointID that is required to match the filter. If omitted, any OpPointID satisfies the filter. Multiple instances are logically ORed.	
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint category that is required to match the filter. If omitted, any OpPoint category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpPoint must fall within to satisfy the filter. Multiple instances are logically ORed.Indicates that the OpRouting type is applicable. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-1112: Mission Plan Interface MA_OpZoneMT - OpPointFilter UCI Extension Field

OpLineFilter		
Description	Indicates a name/type of OpLine required to match the filter. If omitted, any name/type of OpLine satisfies the filter.	
Base Type	MA_OpLineFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpLineID	OpLineID_Type	Repeated
Description	Indicates a specific OpLineID that is required to match the filter. If omitted, any OpLineID satisfies the filter. Multiple instances are logically ORed.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine category that is required to match the filter. If omitted, any OpLine category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpLine must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-1113: Mission Plan Interface MA_OpZoneMT - OpLineFilter UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine category that is required to match the filter. If omitted, any OpLine category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with

	other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-1114: Mission Plan Interface MA_OpZoneMT - OpLineCategory UCI Extension Field

OpZoneFilter		
Description	Indicates a name/type of OpZone required to match the filter. If omitted, any name/type of OpZone satisfies the filter.	
Base Type	MA_OpZoneFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpZoneID	OpZoneID_Type	Repeated
Description	Indicates a specific OpZoneID that is required to match the filter. If omitted, any OpZoneID satisfies the filter. Multiple instances are logically ORed.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone category that is required to match the filter. If omitted, any OpZone category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpZone must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-1115: Mission Plan Interface MA_OpZoneMT - OpZoneFilter UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone category that is required to match the filter. If omitted, any OpZone category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply"

	condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the

	IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are

	defined in the OpZoneWeatherType choice in OpZoneCategoryType.
--	--

Table A-4-1116: Mission Plan Interface MA_OpZoneMT - OpZoneCategory UCI Extension Field

OpVolumeFilter		
Description	Indicates a name/type of OpVolume required to match the filter. If omitted, any name/type of OpVolume satisfies the filter.	
Base Type	MA_OpVolumeFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpVolumeID	OpVolumeID_Type	Repeated
Description	Indicates a specific OpVolumeID that is required to match the filter. If omitted, any OpVolumeID satisfies the filter. Multiple instances are logically ORed.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume category that is required to match the filter. If omitted, any OpVolume category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpVolume must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-1117: Mission Plan Interface MA_OpZoneMT - OpVolumeFilter UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume category that is required to match the filter. If omitted, any OpVolume category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.

EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.

ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-1118: Mission Plan Interface MA_OpZoneMT - OpVolumeCategory UCI Extension Field

DMPI_Filter		
Description	Indicates a name/type of DMPI required to match the filter. If omitted, any name/type of DMPI satisfies the filter.	
Base Type	MA_DMPI_FilterType	
Message Structure		
Field Name	Field Type	Field Usage
DMPI_ID	DMPI_ID_Type	Repeated
Description	Indicates a specific DMPI_ID that is required to match the filter. If omitted, any DMPI_ID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the DMPI must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-1119: Mission Plan Interface MA_OpZoneMT - DMPI_Filter UCI Extension Field

SignalReportFilter

Description	Indicates a name/type of SignalReport required to match the filter. If omitted, any name/type of SignalReport satisfies the filter.	
Base Type	MA_SignalReportFilterType	
Message Structure		
Field Name	Field Type	Field Usage
SignalReportID	SignalReportID_Type	Repeated
Description	Indicates a specific SignalReportID that is required to match the filter. If omitted, any SignalReportID satisfies the filter. Multiple instances are logically ORed.	
SystemID	SystemID_Type	Repeated
Description	Indicates a specific source SystemID that is required to match the filter. If omitted, any source SystemID satisfies the filter. Multiple instances are logically ORed.	
SubsystemID	SubsystemID_Type	Repeated
Description	Indicates a specific source SubsystemID that is required to match the filter. If omitted, any source SubsystemID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the SignalReport must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-1120: Mission Plan Interface MA_OpZoneMT - SignalReportFilter UCI Extension Field

OpVolumeFilter		
Description	Indicates a name/type of OpVolume required to match the filter. If omitted, any name/type of OpVolume satisfies the filter.	
Base Type	MA_OpVolumeFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpVolumeID	OpVolumeID_Type	Repeated
Description	Indicates a specific OpVolumeID that is required to match the filter. If omitted, any OpVolumeID satisfies the filter. Multiple instances are logically ORed.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume category that is required to match the filter. If omitted, any OpVolume category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpVolume must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-1121: Mission Plan Interface MA_OpZoneMT - OpVolumeFilter UCI Extension Field

OpLineFilter	
Description	Indicates a name/type of OpLine required to match the filter. If omitted, any name/type of OpLine satisfies the filter.
Base Type	MA_OpLineFilterType

Message Structure		
Field Name	Field Type	Field Usage
OpLineID	OpLineID_Type	Repeated
Description	Indicates a specific OpLineID that is required to match the filter. If omitted, any OpLineID satisfies the filter. Multiple instances are logically ORed.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine category that is required to match the filter. If omitted, any OpLine category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpLine must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-1122: Mission Plan Interface MA_OpZoneMT - OpLineFilter UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine category that is required to match the filter. If omitted, any OpLine category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of

	battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-1123: Mission Plan Interface MA_OpZoneMT - OpLineCategory UCI Extension Field

SpeedLimits		
Description	Defines area where speeds are restricted.	
Base Type	MA_OpZoneSpeedLimitsType	
Message Structure		
Field Name	Field Type	Field Usage
MinSpeedLimit	PathSegmentSpeedValueType	Optional
Description	Indicates the minimum speed limit in meters per second within a zone/region.	
MaxSpeedLimit	PathSegmentSpeedValueType	Optional
Description	Indicates the maximum speed limit in meters per second within a zone/region.	

Table A-4-1124: Mission Plan Interface MA_OpZoneMT - SpeedLimits UCI Extension Field

SignalReportFilter		
Description	Indicates a name/type of SignalReport required to match the filter. If omitted, any name/type of SignalReport satisfies the filter.	
Base Type	MA_SignalReportFilterType	
Message Structure		
Field Name	Field Type	Field Usage
SignalReportID	SignalReportID_Type	Repeated
Description	Indicates a specific SignalReportID that is required to match the filter. If omitted, any SignalReportID satisfies the filter. Multiple instances are logically ORed.	
SystemID	SystemID_Type	Repeated
Description	Indicates a specific source SystemID that is required to match the filter. If omitted, any source SystemID satisfies the filter. Multiple instances are logically ORed.	
SubsystemID	SubsystemID_Type	Repeated
Description	Indicates a specific source SubsystemID that is required to match the filter. If omitted, any source SubsystemID satisfies the filter. Multiple instances are logically ORed.	

GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the SignalReport must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-1125: Mission Plan Interface MA_OpZoneMT - SignalReportFilter UCI Extension Field

OpPointFilter		
Description	Indicates a name/type of OpPoint required to match the filter. If omitted, any name/type of OpPoint satisfies the filter.	
Base Type	MA_OpPointFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointID	OpPointID_Type	Repeated
Description	Indicates a specific OpPointID that is required to match the filter. If omitted, any OpPointID satisfies the filter. Multiple instances are logically ORed.	
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint category that is required to match the filter. If omitted, any OpPoint category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpPoint must fall within to satisfy the filter. Multiple instances are logically ORed.Indicates that the OpRouting type is applicable. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-1126: Mission Plan Interface MA_OpZoneMT - OpPointFilter UCI Extension Field

VehicleConfiguration		
Description	Defines vehicle configuration parameters that should change based on the planned location of a vehicle.	
Base Type	MA_VehicleCommandDataType	
Message Structure		
Field Name	Field Type	Field Usage
VehicleAction	VehicleActionEnum	Optional
Description	Defines vehicle actions that can be done along a path segment of a route.	
IFF_Settings	IFF_Type	Optional
Description	If present the IFF settings for this vehicle will be changed along this path segment.	
SurvivabilityMode	VehicleSurvivabilityModeEnum	Optional
Description	Specifies that the vehicle should put itself into a more survivable mode. Different vehicles will have specific behaviors that reduce the signature of the vehicle (doors closed, minimal use of flaps, etc.) If this element is not present then it is assumed that the aircraft being configured has no survivability mode.	
LostCommTimeout	DurationType	Optional
Description	Defines the lost communication contingency timeout. When this timeout value is exceeded, the AV considers that lost communication has occurred and begins to	

	perform contingency measures.	
LOS	boolean	Optional
Description	Use Line Of Sight (LOS) communication as backup contingency.	
LossOfLinkProcessing	VehicleLossOfLinkProcessingEnum	Optional
Description	Specifies whether the vehicle should invoke special Loss of Link processing. This could be turned off if the vehicle is going to be in a known and accepted lost communication situation.	
CommAllocationAction	CommAllocationActionType	Optional
Description	Indicates a change of communication allocation.	
QNH_Setting	PressureType	Optional
Description	Represents the barometric altimeter setting for correct MSL reading, commonly known as QNH, requested. Expressed in kilopascals (kPa).	

Table A-4-1127: Mission Plan Interface MA_OpZoneMT - VehicleConfiguration UCI Extension Field

DMPI_Filter		
Description	Indicates a name/type of DMPI required to match the filter. If omitted, any name/type of DMPI satisfies the filter.	
Base Type	MA_DMPI_FilterType	
Message Structure		
Field Name	Field Type	Field Usage
DMPI_ID	DMPI_ID_Type	Repeated
Description	Indicates a specific DMPI_ID that is required to match the filter. If omitted, any DMPI_ID satisfies the filter. Multiple instances are logically ORed.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the DMPI must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-1128: Mission Plan Interface MA_OpZoneMT - DMPI_Filter UCI Extension Field

Zone		
Description	This element represents the geospatial and temporal characteristics of the OpZone.	
Base Type	MA_OpZoneChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
GeometrySpecification	OpZoneType	Required
Description	Defines an OpZone geometry	
GeometryReference	MA_ReferentialOpZoneType	Required
Description	Defines an OpZone geometry via reference to other filtered objects	

Table A-4-1129: Mission Plan Interface MA_OpZoneMT - Zone UCI Extension Field

Category

Description	This element indicates the type of zone.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the

	IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are

	defined in the OpZoneWeatherType choice in OpZoneCategoryType.
--	--

Table A-4-1130: Mission Plan Interface MA_OpZoneMT - Category UCI Extension Field

CategoryUniqueData		
Description	Contains parameters unique to certain OpZoneCategoryEnum values.	
Base Type	MA_OpZoneCategoryType	
Message Structure		
Field Name	Field Type	Field Usage
ConstrainedEntryExit	ConstrainedEntryExitType	Required
Description	Defines boundaries which applicable Systems can only enter and exit through defined edges.	
FilterArea	OpZoneFilterAreaPET	Repeated
Description	Indicates that the OpZone can be a zone filter type.	
Jamming	OpZoneJammingType	Required
Description	Indicates that the OpZone is a jamming control zone.	
KeepIn	IngressEgressType	Required
Description	Defines boundaries to which applicable Systems must stay inside.	
MissileLaunchPoint	OpZoneMissileDataType	Required
Description	Data defining a missile type, related track, and source of launch position.	
NoFire	OpZoneNoFireType	Required
Description	Defines areas where strike impact is restricted. Does not restrict the launch of weapons.	
NoFly	OpZoneNoFlyType	Required
Description	Defines area where flight is restricted. Equivalent to MIL-STD-6016 restricted zone.	
SpeedLimits	MA_OpZoneSpeedLimitsType	Required
Description	Defines area where speeds are restricted.	
VehicleConfiguration	MA_VehicleCommandDataType	Required
Description	Defines vehicle configuration parameters that should change based on the planned location of a vehicle.	
WeaponRestriction	OpZoneWeaponRestrictionType	Required
Description	Set of restricted weapons that cannot be used against a target type and or in a zone.	
WeatherConditions	OpZoneWeatherType	Required
Description	Defines area of weather conditions with potential of mission impact.	

Table A-4-1131: Mission Plan Interface MA_OpZoneMT - CategoryUniqueData UCI Extension Field

ReferenceObjectsFilter	
Description	The geometry of all objects returned by this filter will be used for the OpZone being defined.
Base Type	MA_GeoLocatedObjectFilterType

Message Structure		
Field Name	Field Type	Field Usage
EntityFilter	EntityFilterType	Optional
Description	Indicates a name/type of Entity required to match the filter. If omitted, any name/type of Entity satisfies the filter.	
SystemFilter	SystemFilterType	Optional
Description	Indicates a name/type of System required to match the filter. If omitted, any name/type of System satisfies the filter.	
OpPointFilter	MA_OpPointFilterType	Optional
Description	Indicates a name/type of OpPoint required to match the filter. If omitted, any name/type of OpPoint satisfies the filter.	
OpLineFilter	MA_OpLineFilterType	Optional
Description	Indicates a name/type of OpLine required to match the filter. If omitted, any name/type of OpLine satisfies the filter.	
OpZoneFilter	MA_OpZoneFilterType	Optional
Description	Indicates a name/type of OpZone required to match the filter. If omitted, any name/type of OpZone satisfies the filter.	
OpVolumeFilter	MA_OpVolumeFilterType	Optional
Description	Indicates a name/type of OpVolume required to match the filter. If omitted, any name/type of OpVolume satisfies the filter.	
DMPI_Filter	MA_DMPI_FilterType	Optional
Description	Indicates a name/type of DMPI required to match the filter. If omitted, any name/type of DMPI satisfies the filter.	
SignalReportFilter	MA_SignalReportFilterType	Optional
Description	Indicates a name/type of SignalReport required to match the filter. If omitted, any name/type of SignalReport satisfies the filter.	

Table A-4-1132: Mission Plan Interface MA_OpZoneMT - ReferenceObjectsFilter UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume category that is required to match the filter. If omitted, any OpVolume category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.

CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.

NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-1133: Mission Plan Interface MA_OpZoneMT - OpVolumeCategory UCI Extension Field

GeometryReference		
Description	Defines an OpZone geometry via reference to other filtered objects	
Base Type	MA_ReferentialOpZoneType	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceObjectsFilter	MA_GeoLocatedObjectFilterType	Repeated
Description	The geometry of all objects returned by this filter will be used for the OpZone being	

	defined.	
HorizontalBuffer	DistanceType	Required
Description	The area of the resulting OpZone is the area of the referenced object, expanded by this horizontal buffer along the plane orthogonal to the NED frame's down direction	
MinAltitudeBuffer	DistanceType	Required
Description	The min altitude of the resulting OpZone is the min altitude of the referenced object, decreased by this min altitude buffer	
MaxAltitudeBuffer	DistanceType	Required
Description	The max altitude of the resulting OpZone is the max altitude of the referenced object, increased by this max altitude buffer	

Table A-4-1134: Mission Plan Interface MA_OpZoneMT - GeometryReference UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone category that is required to match the filter. If omitted, any OpZone category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational

	purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by

	friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-1135: Mission Plan Interface MA_OpZoneMT - OpZoneCategory UCI Extension Field

OpZoneFilter		
Description	Indicates a name/type of OpZone required to match the filter. If omitted, any name/type of OpZone satisfies the filter.	
Base Type	MA_OpZoneFilterType	
Message Structure		
Field Name	Field Type	Field Usage
OpZoneID	OpZoneID_Type	Repeated
Description	Indicates a specific OpZoneID that is required to match the filter. If omitted, any OpZoneID satisfies the filter. Multiple instances are logically ORed.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone category that is required to match the filter. If omitted, any OpZone category satisfies the filter. Multiple instances are logically ORed. List size for this element is based on "Select All That Apply" condition.	
GeoFilter	GeoFiltersQueryType	Repeated
Description	Indicates a zone the OpZone must fall within to satisfy the filter. Multiple instances are logically ORed.	

Table A-4-1136: Mission Plan Interface MA_OpZoneMT - OpZoneFilter UCI Extension Field

4.3.31 MA_PlanningFunctionMT UCI Extension

MA_PlanningFunctionMT	
Description	See the annotation in the associated message for an overall description of the message and this type.

	See the XSD File for more info
Ext. Fields	Process : MA_MissionPlanProcessDescriptionType RouteActivityPlan : MA_ActivityPlanPartsType ActivityPlan : MA_ActivityPlanPartsType OpVolumeCategory : MA_OpZoneCategoryEnum MissionPlan : MA_MissionPlanProcessType MessageData : MA_PlanningFunctionMDT PlanningInterfaceDetails : MA_PlanningInterfaceDetailsType TaskPlan : MA_TaskPlanPartsType OrbitActivityPlan : MA_ActivityPlanPartsType OpZoneCategory : MA_OpZoneCategoryEnum Output : MA_PlanPartsType CapabilityCommand : MA_CapabilityTypeEnum TaskType : MA_TaskTypeEnum OpLineCategory : MA_OpLineCategoryEnum OpPlan : MA_OpPlanPartsType

Table A-4-1137: Mission Plan Interface MA_PlanningFunctionMT UCI Extension

Process		
Description	Indicates details of a MissionPlan-related planning process.	
Base Type	MA_MissionPlanProcessDescriptionType	
Message Structure		
Field Name	Field Type	Field Usage
Output	MA_PlanPartsType	Required
Description	Indicates a type of Plan output by the planning process and the Parts that can be included.	
PlanningProcessID	PlanningProcessID_Type	Required
Description	Indicates the unique ID of a planning process invocable through a *PlanCommand message/interface.	
ValidationSupported	SupportedFunctionEnum	Repeated
Description	Indicates whether this process supports validation via the *PlanValidationCommand messages. List size for this element is based on "Select All That Apply" condition.	
ApplicableTo	PlanningApplicabilitySystemType	Repeated
Description	Indicates a type or instance, of System or Capabilities, that the planning process is applicable to; a System the process can create the specified *Plan type or types for.	
Supports	ApplicabilityType	Repeated
Description	Indicates a type or instance of System, Capabilities or existing *Plans which the planning process can develop support for in the new *Plan. For example, the sibling ApplicableTo element could indicate the planning process can plan electronic attack routes. This element can then indicate the type or instance of Systems, Capabilities or	

	*Plan types that can be supported by the electronic attack route/plan.	
PlanningTriggers	MissionPlanningByCaseTriggerEnum	Repeated
Description	Indicates the set of triggers that the System is able to monitor to autonomously initiate the planning process. List size for this element is based on "Select All That Apply" condition.	

Table A-4-1138: Mission Plan Interface MA_PlanningFunctionMT - Process UCI Extension Field

RouteActivityPlan		
Description	Indicates applicable RouteActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-1139: Mission Plan Interface MA_PlanningFunctionMT - RouteActivityPlan UCI Extension Field

ActivityPlan

Description	Indicates applicable ActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-1140: Mission Plan Interface MA_PlanningFunctionMT - ActivityPlan UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.

CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.

MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-1141: Mission Plan Interface MA_PlanningFunctionMT - OpVolumeCategory UCI Extension Field

MissionPlan	
Description	Indicates details of MissionPlan-related planning processes.
Base Type	MA_MissionPlanProcessType
Message Structure	

Field Name	Field Type	Field Usage
DefaultPlanningProcessID	PlanningProcessID_Type	Required
Description	Indicates which one of the sibling Process elements is the default.	
Process	MA_MissionPlanProcessDescriptionType	Repeated
Description	Indicates details of a MissionPlan-related planning process.	

Table A-4-1142: Mission Plan Interface MA_PlanningFunctionMT - MissionPlan UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the PlanningFunction message.	
Base Type	MA_PlanningFunctionMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanningFunctionID	PlanningFunctionID_Type	Required
Description	Indicates a unique ID, assigned to this PlanningFunction.	
SystemID	SystemID_Type	Required
Description	Indicates the unique ID of the System whose planning functions are being reported.	
PlanningInterfaces	PlanningInterfacesType	Repeated
Description	Indicates planning interfaces supported by the System. A supported interface isn't necessarily enabled currently; see the PlanningStatus message for current status/configuration of control interfaces advertised here.	
PlanningInterfaceDetails	MA_PlanningInterfaceDetailsType	Optional
Description	This element is used to describe the details of planning interfaces/messages, specifically *PlanCommand interfaces of a System. It provides discoverability of distinct planning process instances along with the functional scope and output *Plan type or types. A planning interface/process described here can only be invoked when the sibling Interfaces element indicates it is enabled. Planning processes are dynamically discoverable because Systems tend to have widely varying planning functionality. Decomposing planning into discrete processes allows planning functionality to be distributed across a service oriented system of systems. Making planning processes discoverable encourages planning-related services at multiple levels in a C2 hierarchy to adapt to and simultaneously support Systems with different planning functionality and processes.	
PlanActivationAutonomyDetails	SupportedPlanActivationAutonomyType	Optional
Description	Indicates capabilities of the System to perform plan activation autonomously. Plan activations can be performed either at the MissionPlan or SubPlan level.	
ScoringInterfaceDetails	PlanScoringProcessType	Optional
Description	This element is used to describe the details of scoring interfaces/messages summarized in the sibling Interfaces element. It provides discoverability of distinct scoring process instances along with the functional scope. A scoring	

	interface/process described here can only be invoked when the sibling Interfaces ActivationState element indicates it is enabled. Plan Scoring processes are dynamically discoverable because Systems tend to have varying scoring algorithms. Decomposing plan scoring into discrete processes allows scoring functionality to be distributed across a service oriented system of systems.
--	---

Table A-4-1143: Mission Plan Interface MA_PlanningFunctionMT - MessageData UCI Extension Field

PlanningInterfaceDetails		
Description		This element is used to describe the details of planning interfaces/messages, specifically *PlanCommand interfaces of a System. It provides discoverability of distinct planning process instances along with the functional scope and output *Plan type or types. A planning interface/process described here can only be invoked when the sibling Interfaces element indicates it is enabled. Planning processes are dynamically discoverable because Systems tend to have widely varying planning functionality. Decomposing planning into discrete processes allows planning functionality to be distributed across a service oriented system of systems. Making planning processes discoverable encourages planning-related services at multiple levels in a C2 hierarchy to adapt to and simultaneously support Systems with different planning functionality and processes.
Base Type		MA_PlanningInterfaceDetailsType
Message Structure		
Field Name	Field Type	Field Usage
MissionPlan	MA_MissionPlanProcessType	Optional
Description	Indicates details of MissionPlan-related planning processes.	
TaskPlan	TaskPlanProcessType	Optional
Description	Indicates details of TaskPlan-related planning processes.	
RoutePlan	RoutePlanProcessType	Optional
Description	Indicates details of RoutePlan-related planning processes.	
RouteActivityPlan	ActivityPlanProcessType	Optional
Description	Indicates details of RouteActivityPlan-related planning processes.	
ActivityPlan	ActivityPlanProcessType	Optional
Description	Indicates details of ActivityPlan-related planning processes.	
OrbitPlan	OrbitPlanProcessType	Optional
Description	Indicates details of OrbitPlan-related planning processes.	
OrbitActivityPlan	ActivityPlanProcessType	Optional
Description	Indicates details of OrbitActivityPlan-related planning processes.	

EffectPlan	EffectPlanProcessType	Optional
Description	Indicates details of EffectPlan-related planning processes.	
ActionPlanProcess	ActionPlanProcessType	Optional
Description	Indicates details of ActionPlan-related planning processes.	
ResponsePlanProcess	ResponsePlanProcessType	Optional
Description	Indicates details of ResponsePlan-related planning processes.	

Table A-4-1144: Mission Plan Interface MA_PlanningFunctionMT - PlanningInterfaceDetails UCI Extension Field

TaskPlan		
Description	Indicates applicable TaskPlan parts.	
Base Type	MA_TaskPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
TaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	

Table A-4-1145: Mission Plan Interface MA_PlanningFunctionMT - TaskPlan UCI Extension Field

OrbitActivityPlan		
Description	Indicates applicable OrbitActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional

	Description	Indicates applicable EffectPlan parts.
ActionPlan	ActionPlanPartsType	Optional
	Description	Indicates applicable ActionPlan parts.
TaskPlan	MA_TaskPlanPartsType	Optional
	Description	Indicates applicable TaskPlan parts.
ResponsePlan	ResponsePlanPartsType	Optional
	Description	Indicates applicable ResponsePlan parts.
OpPlan	MA_OpPlanPartsType	Optional
	Description	Indicates applicable OpPlan parts.

Table A-4-1146: Mission Plan Interface MA_PlanningFunctionMT - OrbitActivityPlan UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.

GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.

SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-1147: Mission Plan Interface MA_PlanningFunctionMT - OpZoneCategory UCI Extension Field

Output		
Description	Indicates a type of Plan output by the planning process and the Parts that can be included.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	

ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-1148: Mission Plan Interface MA_PlanningFunctionMT - Output UCI Extension Field

CapabilityCommand	
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_CapabilityTypeEnum
Message Structure	
Enumeration Literal	Description
ACTION	Indicates an action capability.
AIR_SAMPLE	Indicates an air sampling capability.
AMTI	Indicates an airborne moving target indication (AMTI) capability.
AO	Indicates an active optical capability.
CAP	Indicates a cargo delivery capability.
CARGO_DELIVERY	Indicates a cargo delivery capability.
COMINT	Indicates a Communications Intelligence (COMINT) capability.
COMM_RELAY	Indicates a communications relay capability.
COMM_TERMINAL	Indicates a communications terminal capability
COUNTER_SPACE	Indicates a Counter Space Capability.
EA	Indicates an electronic attack (EA) capability.
EFFECT	Indicates an effect capability.
ESM	Indicates an electronic support measures (ESM) capability.
FLIGHT	Indicates a capability for waypoint-based flight tasks/commands.
IFF	Indicates an Identification Friend or Foe (IFF) capability.
OPAQUE	Indicates a Opaque Capability
ORBIT_CHANGE	Indicates this space system has the ability to change orbits.
ORBITAL_SURVEILLANCE	Indicates a task to perform Orbital Surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates an Orbital Surveillance Sensor Capability.
PO	Indicates a passive optical capability.
RADAR_ALTIMETER	Indicates a Radar Altimeter capability
REFUEL	Indicates a capability to refuel another asset.
RESPONSE	Indicates an response capability.
SAR	Indicates a synthetic aperture radar (SAR) capability.

SMTI	Indicates a surface moving target indication (SMTI) capability.
STRIKE	Indicates a strike capability.
SYSTEM_DEPLOYMENT	Indicates a deployment capability.
TACTICAL_ORDER	Indicates a tactical order capability.
TASK	Indicates a task capability.
WEATHER_RADAR	Indicates a weather radar capability.

Table A-4-1149: Mission Plan Interface MA_PlanningFunctionMT - CapabilityCommand UCI Extension Field

TaskType	
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_TaskTypeEnum
Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.
AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.
CAP	Indicates the task is to execute a Combat Air Patrol.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESCORT	Indicates the task is to escort another entity.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.
SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.

SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-1150: Mission Plan Interface MA_PlanningFunctionMT - TaskType UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an

	aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
--	--

Table A-4-1151: Mission Plan Interface MA_PlanningFunctionMT - OpLineCategory UCI Extension Field

OpPlan		
Description	Indicates applicable OpPlan parts.	
Base Type	MA_OpPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpRouting	EmptyType	Optional
Description	Indicates an OpRouting is applicable to the associated *Plan. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-1152: Mission Plan Interface MA_PlanningFunctionMT - OpPlan UCI Extension Field

4.3.32 MA_PrioritizationListMT UCI Extension

MA_PrioritizationListMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ListType : MA_PrioritizationListEnum ListItem : MA_PrioritizationListItemType MessageData : MA_PrioritizationListMDT

Table A-4-1153: Mission Plan Interface MA_PrioritizationListMT UCI Extension

ListType	
Description	Indicates the type of prioritization list. For example, battlespace objects can be prioritized differently for targeting vs. protection as indicated by enumerates given in this element.

Base Type	MA_PrioritizationListEnum
Message Structure	
Enumeration Literal	Description
THREAT_TARGET_PRIORITIZATION_LIST	A prioritized list of battlespace objects or areas that are prioritized by an operational or tactical planner. For planning purposes, the ListItem associated with this enumeration could include, for example, an entity, a signal, a point or region.
CRITICAL_ASSET_LIST	A prioritized list of battlespace objects or areas that are prioritized by the joint force commander to be defended with the resources available. Critical assets are generally specific assets of such extraordinary importance that their loss or degradation would have a significant and debilitating effect on operations or the mission. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system or a point.
JIPTL	The Joint Integrated Prioritization Target List (JPITL) is a prioritized list of targets and associated data approved by the Joint Forces Commander or designated representative. An approved JIPTL is the central product of the target development cycle. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity or a system.
JIPTL_NOMINATION	A product of the target development phase is the JPITL nomination list. Targeters determine this list during the objectives, effects, and guidance phase and analyze which targets should be struck (or otherwise affected) to accomplish them. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity or a system.
JOINT_TARGET_LIST	A consolidated list of selected targets considered to have military significance in the combatant commander's area of responsibility. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system, a point, or area.
MISSION_TARGET_LIST	The list of battlespace targets that are considered to have military significance and are required for the successful completion of the mission. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system, a point, or area.
NO_STRIKE_LIST	A list of battlespace objects characterized as protected from the effects of military operations under international law or Engagement Criteria. Attacking these may violate Law of Armed Conflict (LOAC) or Engagement Criteria or interfere with friendly relations with indigenous personnel or governments. For planning purposes, the ListItem associated with this enumeration could typically be, for example, an entity, a system, a point, or area.
RESTRICTED_TARGET_LIST	A list of targets that have specific restrictions imposed upon them. Actions on restricted targets are prohibited until coordinated and approved by the establishing authority. Targets are restricted because certain types of actions against them may have negative political, cultural, or propaganda implications, or may interfere with projected friendly operations. The Restricted Target List (RTL) is nominated by elements of the joint force and approved by the JFC. Targets on this list may only be struck with JFC or higher approval. Actions taken by an opponent may remove a target from the RTL. For planning purposes,

	the ListItem associated with this enumeration could typically be, for example, an entity, a system, a point, or area.
DEFENDED_ASSET_LIST	The Defended Asset List (DAL) is a listing of those assets from the critical asset list prioritized by the joint force commander to be defended with the resources available. Critical assets that are reinforced with additional protection capabilities or capabilities from other combat power elements become part of the DAL. It represents what can be protected, by priority. The DAL allows commanders to apply finite protection capabilities to the most valuable assets.
PLATFORM_TARGET_LIST	A list of active entity platform targets that meet custody requirements. This list type is used in support of presenting a shot queue prioritization list with List Item of EntityID in accordance with the mission common operating picture.

Table A-4-1154: Mission Plan Interface MA_PrioritizationListMT - ListType UCI Extension Field

ListItem		
Description	Indicates an item in a prioritization list of the sibling ListType.	
Base Type	MA_PrioritizationListItemType	
Message Structure		
Field Name	Field Type	Field Usage
Subject	IdentityKindInstanceType	Required
Description	Indicates the subject of the prioritization list item.	
Priority	PrioritizationType	Repeated
Description	Indicates the priority of the item. If priority for any child PriorityType is given, then omitted PriorityTypes for the sibling Subject have no/zero priority. No duplicates allowed; at most one instance of each of the child PriorityTypes is allowed. If the child PriorityType is not used, only one instance is allowed.	
ProbabilityOfKill	PercentType	Optional
Description	Indicates the probability of kill, in a percentage where a value of 100.0 = 100%, of a selected target with an available capability.	
ObjectCorrelation	ObjectCorrelationType	Optional
Description	Object Correlation contains a description of the correlation of this object with another object as well as whether the correlating system has C2 responsibilities or not, to indicate a rough level of confidence in the information.	

Table A-4-1155: Mission Plan Interface MA_PrioritizationListMT - ListItem UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PrioritizationListMDT	
Message Structure		
Field Name	Field Type	Field Usage
PrioritizationListID	PrioritizationListID_Type	Required

	Description	Indicates the unique ID of the prioritization list.	
ListType		MA_PrioritizationListEnum	Required
	Description	Indicates the type of prioritization list. For example, battlespace objects can be prioritized differently for targeting vs. protection as indicated by enumerates given in this element.	
ListItem		MA_PrioritizationListItemType	Repeated
	Description	Indicates an item in a prioritization list of the sibling ListType.	
OpOrderTraceability		OrderTraceabilityType	Repeated
	Description	Indicates an operational order which this PrioritizationList is traceable to. This does not mean ranking. This element refers to a Planning Order, Commander's Intent, or other Order that came from a higher echelon. The higher echelon is identified by the OrderSourceID.	
OpDescription		OpDescriptionType	Optional
	Description	Indicates a human readable description of the purpose of the prioritization list.	
ApplicableSystemID		SystemID_Type	Repeated
	Description	One or more Systems to which the prioritization applies. If omitted, the prioritization applies to all Systems.	
ApplicableServiceID		ServiceID_Type	Repeated
	Description	One or more Services to which the mission response list applies. If omitted, the settings apply to all Services of the Systems given in the sibling ApplicableSystemID.	
ApplicableZone		ZoneType	Optional
	Description	Zones to which the prioritization applies.	
Schedule		ScheduleType	Optional
	Description	Scheduled times to which the prioritization applies.	
DataRecordInstanceID		DataRecordInstanceID_Type	Optional
	Description	Indicates the ID of this Data Record instance. The DataRecordInstanceID is used as a checkpoint for DataRecordManagementRequests to ensure that the state of the DataRecord (or DataRecords) that are the subject of a DataRecordManagementRequest are coherent between the requestor and the requestee.	

Table A-4-1156: Mission Plan Interface MA_PrioritizationListMT - MessageData UCI Extension Field

4.3.33 MA_ResponseMT UCI Extension

MA_ResponseMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ResponseMDT

Table A-4-1157: Mission Plan Interface MA_ResponseMT UCI Extension

MessageData

Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ResponseMDT	
Message Structure		
Field Name	Field Type	Field Usage
ResponseID	ResponseID_Type	Required
Description	Indicates the unique ID of the Response. Minor updates to the Response can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new instance with a different child UUID value.	
ResponseType	ResponseTypeEnum	Repeated
Description	Indicates the types of Response options included in the message. List size for this element is based on "Select All That Apply" condition.	
ResponseManagementConstraints	RequirementConstraintsType	Optional
Description	Indicates monitoring constraints on the Response. The constraint type used here is common to all Requirement types: Effect, Action, Task, [Capability]Command, Response. Requirement constraints can be 1) given in a [Requirement] message, 2) overridden as a planning input in a [Requirement]PlanCommand message, 3) further refined/overridden during plan creation and reported in a [Requirement]Plan message to inform subsequent planning or execution. See sibling Option element annotation for an overall description of Response structure. Constraints given here aren't conveyed to instantiated Response options for a particular triggering event. The constraints given here apply to Response management (planning, allocation and trigger monitoring prior to a triggering event). Constraints to apply to instantiated Response options, if any, are given elsewhere in the message.	
ResponseManagementGuidance	RequirementGuidanceType	Optional
Description	Indicates guidance on planning and C2 of the Response.	
ResponsePlurality	MA_TaskPluralityEnum	Optional
Description	Indicates whether the response applies a single entity or as a joint condition. A joint condition implies condiseration of the response trigger and activation of the response by all associated entities.	
Option	MA_ResponseOptionDetailsType	Repeated
Description	Indicates an Option of the Response. Responses are designed to be flexible. A Response is a set of prioritized Options to address an anticipated triggering event, events or event sequence in the battlespace. Responses are allocated to Systems via a ResponsePlan. When a ResponsePlan is activated, monitoring for the triggering events in the Options begins. When a triggering event happens, the applicable Option(s) are evaluated.	
RequirementsTemplate	MA_RequirementsTemplateType	Repeated

Description	The sibling Option element associates triggering events with a desired Response one of which is to use this element, a Requirements template, to generate or change one or more Requirements messages/objects (Effect, Action, Task, [Capability]Command). An instance of this element is a RequirementsTemplate; it indicates the types of Requirements to generate or update and their details. Each RequirementsTemplate has a unique ID and therefore can be used for multiple Options.	
Metadata	RequirementMetadataType	Optional
Description	Indicates traceability and other metadata associated with the Response.	

Table A-4-1158: Mission Plan Interface MA_ResponseMT - MessageData UCI Extension Field

4.3.34 MA_RouteActivityPlanMT UCI Extension

MA_RouteActivityPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RouteActivityPlanMDT

Table A-4-1159: Mission Plan Interface MA_RouteActivityPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_RouteActivityPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
RouteActivityPlanID	RouteActivityPlanID_Type	Required
Description	Indicates a unique ID assigned to the RouteActivityPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	RouteActivityPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the RouteActivityPlan originated from.	
Plan	MA_RouteActivityPlanType	Required
Description	Indicates the details of the RouteActivityPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	RouteActivityPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-1160: Mission Plan Interface MA_RouteActivityPlanMT - MessageData UCI Extension Field

4.3.35 MA_RoutePlanMT UCI Extension

MA_RoutePlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RoutePlanMDT

Table A-4-1161: Mission Plan Interface MA_RoutePlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_RoutePlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
RoutePlanID	RoutePlanID_Type	Required
Description	Indicates a unique ID assigned to the RoutePlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	RoutePlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the RoutePlan originated from.	
Plan	MA_RoutePlanType	Required
Description	Contains the details of the route plan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	RoutePlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-1162: Mission Plan Interface MA_RoutePlanMT - MessageData UCI Extension Field

4.3.36 MA_EngagementCriteriaMT UCI Extension

MA_EngagementCriteriaMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_EngagementCriteriaMDT

Table A-4-1163: Mission Plan Interface MA_EngagementCriteriaMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_EngagementCriteriaMDT	
Message Structure		
Field Name	Field Type	Field Usage
EngagementCriteriaID	MA_EngagementCriteriaID_Type	Required
Description	The unique identifier for the message.	
IdMatrixCriteria	MA_IdMatrixCriteriaType	Optional
Description	These markers are used to identify an Entity as a Friend, Neutral, or Enemy and which enables or confirms the Entity's Standard Identity type to be set to FRIEND, NEUTRAL, SUSPECT or HOSTILE.	
TargetDesignationCriteria	MA_TargetDesignationCriteriaType	Repeated
Description	This provides a list of criteria that when met can trigger a MA_DesignationRequestMT to be sent to a Target Authority who can use the info in this message to send a MA_DesignationMT that will designate an Entity as a Target.	
TargetAuthorityCriteria	MA_AuthorityCriteriaType	Optional
Description	This provides a list of Authorized Operators that are allowed to set an Entity as a Target and to respond to a StrikeConsentRequestMT. An Entity becomes a Target when a Designation message declares that entity to be a Target. This can also be done by an Action or Task specifying an Entity as a Target (TargetType). The associated Approval Policy will specify which Actions or Tasks make an Entity a Target and who is authorized to command them or approve a response that activates them. MA can send a MA_DesignationRequestMT to Operators identified in the Approval Authority. An Authorized operator can also directly send a MA_DesignationMT. An MA can be an authorized approver if specified, but an MA cannot send a MA_DesignationMT for itself. A Lead can send a MA_DesignationMT to a follower if a C2 has already approved the Target.	
TargetCustodyCriteria	MA_TargetCustodyCriteriaType	Repeated
Description	This describes how the Custody of a Target is confirmed and must be held through a Weapons Engagement with that Target.	
StrikeConsentRequired	boolean	Required
Description	Indicates whether (TRUE) or not (FALSE) the Strike Activities requires consent to transition from the ENABLED state to an ACTIVE state. If TRUE, each Strike Activity would be required to send a StrikeConsentRequestMT to an Authorized Operator (defined in the TargetAuthorityCriteria field) and receive a StrikeConsentRequestStatusMT before each Strike Activity can execute the Strike.	

Table A-4-1164: Mission Plan Interface MA_EngagementCriteriaMT - MessageData UCI Extension Field

4.3.37 MA_StrikeCapabilityMT UCI Extension

MA_StrikeCapabilityMT	
Description	See annotations in child elements and messages/elements that use this type for details.

	See the XSD File for more info
Ext. Fields	MessageData : MA_StrikeCapabilityMDT

Table A-4-1165: Mission Plan Interface MA_StrikeCapabilityMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_StrikeCapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_StrikeCapabilityType	Repeated
Description	Indicates a Strike Capability provided by the Subsystem.	
Carriage	StoreCarriageCapabilityType	Repeated
Description	Optional list of carriage related to the StrikeCapability.	
Verification	StoreVerificationStatusType	Optional
Description	This is a rollup of all verification of each capability in this message.	
LoadoutMnemonic	VisibleString256Type	Optional
Description	Mnemonic representation of the store loadout that the reported strike capabilities and carriage support capabilities are derived from.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.	

Table A-4-1166: Mission Plan Interface MA_StrikeCapabilityMT - MessageData UCI Extension Field

4.3.38 MA_TaskMT UCI Extension

MA_TaskMT	
Description	This message specifies a Task that a System will perform against a specific entity or geographical location. Tasks include flight, collection, strike, electronic attack, directed energy, laser designation, cargo delivery and communication relay. They are abstracted to a level of C2 and autonomy derived from UCI operational vignettes. Tasks enable services, operators and other actors to do automated, dynamic, machine-to-machine allocation of Tasks to Systems and subsequent mission planning. If necessary, authorization of Users to Task Systems can be controlled using the Authorization message. See the XSD File for more info
Ext. Fields	TaskType : MA_TaskType

	TaskPlurality : MA_TaskPluralityEnum ConstraintID : MA_ConstraintID_Type HSA_CSA : MA_HSA_CSA_Type WaypointFollowing : MA_WaypointFollowingType CurveFollowing : MA_CurveControlType Speed : PathSegmentSpeedType Heading : MA_DirectionReferenceType SpeedChoice : MA_HSA_SpeedChoiceType SpeedValue : PathSegmentSpeedValueType CurveFitMethod : MA_CurveFitMethodEnum
--	---

Table A-4-1167: Mission Plan Interface MA_TaskMT UCI Extension

TaskType		
Description	Identifies the type of this Task instance.	
Base Type	MA_TaskType	
Message Structure		
Field Name	Field Type	Field Usage
AirSample	AirSampleTaskType	Required
Description	Air sample includes direct sampling of the air (SAMPLE) and remote sensing with spectral analysis (SPECTROMETER) with the intent of detecting NBC events.	
AMTI	AMTI_TaskType	Required
Description	Indicates a Task to collect Air Moving Target Indicator (AMTI) data.	
AO	AO_TaskType	Required
Description	Indicates a Task to perform an optical emission such as laser designation.	
CAP	MA_CAP_TaskType	Required
Description	Indicates a Task to perform Combat Air Patrol.	
CargoDelivery	CargoDeliveryTaskType	Required
Description	Indicates a Task to transfer cargo between locations.	
COMINT	COMINT_TaskType	Required
Description	Indicates a Task to provide COMINT.	
CommRelay	CommRelayTaskType	Required
Description	Indicates a Task to provide communications relay support.	
CounterSpace	CounterSpaceTaskType	Required
Description	Indicates a Task to employ a CounterSpace capability.	
Escort	MA_EscortTaskType	Required
Description	Indicates a Task to escort another Entity or System.	
EA	EA_TaskType	Required

	Description	Indicates a Task to provide electronic attack support to another System. It guides/constrains the EA System by specifying where it should fly, what it should protect and what the threat is.
ESM	ESM_TaskType	Required
	Description	Indicates a Task to collect ESM data.
Flight	MA_FlightTaskType	Required
	Description	Indicates a Task to effect the flight path/plan of the System.
Jettison	MA_JettisonTaskType	Required
	Description	Indicates a Task to a jettisonable weapon from the system.
OrbitChange	OrbitChangeTaskType	Required
	Description	Indicates a task to perform an orbit change via a spacecraft maneuver.
OrbitalSurveillance	OrbitalSurveillanceTaskType	Required
	Description	Indicates an Orbital Surveillance Task.
OrbitalSurveillanceSensor	OrbitalSurveillanceSensorTaskType	Required
	Description	Indicates a task to perform orbital surveillance sensor tasking.
PO	PO_TaskType	Required
	Description	Indicates a Task to collect Passive Optical data, imagery and video as well as perform PO search and track capabilities.
Refuel	RefuelTaskType	Required
	Description	Indicates a Task for one System to refuel another.
SAR	SAR_TaskType	Required
	Description	Indicates a Task to collect a Synthetic Aperture Radar (SAR) image.
SMTI	SMTI_TaskType	Required
	Description	Indicates a Task to collect Moving Target Indicator (MTI) data.
Strike	StrikeTaskType	Required
	Description	Indicates a Task to kinetically attack/strike, with a weapon that can be released from the System.
SystemDeployment	SystemDeploymentTaskType	Required
	Description	Indicates a task to perform a deployment or release of a system at a specified location.
TacticalOrder	TacticalOrderTaskType	Required
	Description	Indicates a task to perform a tactical order.
WeatherRadar	WeatherRadarTaskType	Required
	Description	Indicates a task to collect weather radar data.

Table A-4-1168: Mission Plan Interface MA_TaskMT - TaskType UCI Extension Field

TaskPlurality	
Description	Indicates whether the task is meant to be executed by a single entity or as a joint operation. A join operation implies forming a group prior to execution. A single entity could be a single system or a single pre-formed group.

Base Type	MA_TaskPluralityEnum
Message Structure	
Enumeration Literal	Description
UNSPECIFIED	Indicates the task plurality is unspecified, and should be defaulted or determined by the receiving system.
JOINT	Indicates the task is to be executed as a joint task. A group will be formed when this task is assigned.
SINGLE_ENTITY	Indicates the task is to be executed by a single entity. A single entity could be a single system or a single pre-existing group.

Table A-4-1169: Mission Plan Interface MA_TaskMT - TaskPlurality UCI Extension Field

ConstraintID		
Description	Indicates any Constraints that apply to the Task (e.g FormationConstraint). A FormationConstraint implies that if a group is formed to execute this task, the referenced Constraint(s) should be applied to that group.	
Base Type	MA_ConstraintID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1170: Mission Plan Interface MA_TaskMT - ConstraintID UCI Extension Field

HSA_CSA		
Description	This message shall be used to provide the ability to command a new flight vector to the Platform.	
Base Type	MA_HSA_CSA_Type	
Message Structure		
Field Name	Field Type	Field Usage
Altitude	AltitudeReferenceType	Optional
Description	Altitude hold value to be achieved and reference to altitude measurement source.	
Speed	PathSegmentSpeedType	Optional
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Direction	MA_DirectionChoiceType	Optional
Description	Defines heading or course type and reference to hold	

Table A-4-1171: Mission Plan Interface MA_TaskMT - HSA_CSA UCI Extension Field

WaypointFollowing

Description	This message shall be used to provide the ability to send a new waypoint path or segment for the Platform to follow.	
Base Type	MA_WaypointFollowingType	
Message Structure		
Field Name	Field Type	Field Usage
Route	MA_RouteType	Required
Description	Indicates the Paths and Segments that make up the Route to be flown.	

Table A-4-1172: Mission Plan Interface MA_TaskMT - WaypointFollowing UCI Extension Field

CurveFollowing		
Description	Indicates the parameters for curve following control.	
Base Type	MA_CurveControlType	
Message Structure		
Field Name	Field Type	Field Usage
CurveSegments	MA_NURBS_PointType	Repeated
Description	Specifies the curve segments as a set of NURBS points.	
AppendCurve	EmptyType	Optional
Description	Specifies this curve will be appended to a previous curve command. This is only valid if the vehicle is currently executing a curve.	
EndOfCurveBehavior	MA_EndOfCurveBehaviorEnum	Optional
Description	Specifies the vehicle behavior at the completion of the curve.	

Table A-4-1173: Mission Plan Interface MA_TaskMT - CurveFollowing UCI Extension Field

Speed		
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Base Type	PathSegmentSpeedType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedChoice	PathSegmentSpeedChoiceType	Optional
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
SpeedOptimization	SpeedOptimizationEnum	Optional
Description	Indicates that the System will vary its speed autonomously according to the specified optimization algorithm.	

Table A-4-1174: Mission Plan Interface MA_TaskMT - Speed UCI Extension Field

Heading	
Description	Defines heading type and reference to hold.

Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-1175: Mission Plan Interface MA_TaskMT - Heading UCI Extension Field

SpeedChoice		
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
Base Type	MA_HSA_SpeedChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedValue	PathSegmentSpeedValueType	Required
Description	Indicates speed in meters per second (m/s).	
MachValue	MachType	Required
Description	Indicates the speed reference for the associated speed value.	

Table A-4-1176: Mission Plan Interface MA_TaskMT - SpeedChoice UCI Extension Field

SpeedValue		
Description	Indicates speed in meters per second (m/s).	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-1177: Mission Plan Interface MA_TaskMT - SpeedValue UCI Extension Field

CurveFitMethod	
Description	Method through which a curve should be fitted to the discretized points in ControlPoint.
Base Type	MA_CurveFitMethodEnum
Message Structure	

Enumeration Literal	Description
B_SPLINE	B-Spline (basis spline) fit.
BEZIER	Bezier curve fit.
CATMULL_ROM	Catmull-Rom spline fit.
NATURAL_CUBIC	Natural Cubic curve fit.

Table A-4-1178: Mission Plan Interface MA_TaskMT - CurveFitMethod UCI Extension Field

4.3.39 MA_TaskPlanMT UCI Extension

MA_TaskPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_TaskPlanMDT

Table A-4-1179: Mission Plan Interface MA_TaskPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_TaskPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlanID	TaskPlanID_Type	Required
Description	Indicates a unique ID assigned to the TaskPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	TaskPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the TaskPlan originated from.	
Plan	MA_TaskPlanType	Required
Description	Contains the details of the task allocation plan.	
ForPlanningUseOnly	Boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	MA_TaskPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-1180: Mission Plan Interface MA_TaskPlanMT - MessageData UCI Extension Field

4.3.40 MA_WEZ_MT UCI Extension

MA_WEZ_MT	
Description	This message represents a single Weapon Engagement Zone (WEZ). The WEZ represents a less dynamic capability than the DLZ for air to air engagements and is not reliant on target state data to be produced. See the XSD File for more info
Ext. Fields	MessageData : MA_WEZ_MDT WEZ_ID : MA_WEZ_ID_Type WEZ_Data : MA_WEZ_DataType RangeTurnAndClose : MA_WeaponRangeType RangeMinimum : MA_WeaponRangeType RangeTurnAndRun : MA_WeaponRangeType RangeProbabilityOfIntercept : MA_WeaponRangeType RangeMaxGuidance : MA_WeaponRangeType RangeOptimal : MA_WeaponRangeType RangeMaxAero : MA_WeaponRangeType

Table A-4-1181: Mission Plan Interface MA_WEZ_MT UCI Extension

MessageData		
Description	This represents the characteristics that identify and describe a single Weapon Engagement Zone (WEZ).	
Base Type	MA_WEZ_MDT	
Message Structure		
Field Name	Field Type	Field Usage
WEZ_ID	MA_WEZ_ID_Type	Required
Description	This is an ID to uniquely identify the Weapon Engagement Zone (WEZ).	
WEZ_RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
CapabilityID	CapabilityID_Type	Optional
Description	Indicates the weapon Capability instance that this WEZ is associated with.	
GeneratedByWeapon	boolean	Optional
Description	This element indicates if the WEZ was generated using payload algorithms.	
WEZ_Data	MA_WEZ_DataType	Required
Description	Indicates WEZ range calculations for air-to-air engagement assessments.	

Table A-4-1182: Mission Plan Interface MA_WEZ_MT - MessageData UCI Extension Field

WEZ_ID

Description	This is an ID to uniquely identify the Weapon Engagement Zone (WEZ).	
Base Type	MA_WEZ_ID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1183: Mission Plan Interface MA_WEZ_MT - WEZ_ID UCI Extension Field

WEZ_Data		
Description	Indicates WEZ range calculations for air-to-air engagement assessments.	
Base Type	MA_WEZ_DataType	
Message Structure		
Field Name	Field Type	Field Usage
RangeTurnAndClose	MA_WeaponRangeType	Repeated
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-close maneuver RangeTurnAndClose is not applicable to ballistic trajectory targets.	
RangeMinimum	MA_WeaponRangeType	Repeated
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeTurnAndRun	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed)	

	3.Target turn-and-run maneuver RangeTurnAndRun is not applicable to ballistic trajectory targets.	
RangeProbabilityOfIntercept	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeMaxGuidance	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeOptimal	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeMaxAero	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	

TimeToRelease	TimeType	Required
Description	The seconds time to activate for the proposed launch store type.	
TimeOfActivation	TimeType	Optional
Description	The time of weapon seeker activation, assuming no platform guidance or weapon errors, for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No post-launch target maneuvers	

Table A-4-1184: Mission Plan Interface MA_WEZ_MT - WEZ_Data UCI Extension Field

RangeTurnAndClose		
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-close maneuver RangeTurnAndClose is not applicable to ballistic trajectory targets.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1185: Mission Plan Interface MA_WEZ_MT - RangeTurnAndClose UCI Extension Field

RangeMinimum	
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.
Base Type	MA_WeaponRangeType
Message Structure	

Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1186: Mission Plan Interface MA_WEZ_MT - RangeMinimum UCI Extension Field

RangeTurnAndRun		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-run maneuver RangeTurnAndRun is not applicable to ballistic trajectory targets.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1187: Mission Plan Interface MA_WEZ_MT - RangeTurnAndRun UCI Extension Field

RangeProbabilityOfIntercept		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for:	
	1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	

Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1188: Mission Plan Interface MA_WEZ_MT - RangeProbabilityOfIntercept UCI Extension Field

RangeMaxGuidance		
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1189: Mission Plan Interface MA_WEZ_MT - RangeMaxGuidance UCI Extension Field

RangeOptimal		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1190: Mission Plan Interface MA_WEZ_MT - RangeOptimal UCI Extension Field

RangeMaxAero		
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1191: Mission Plan Interface MA_WEZ_MT - RangeMaxAero UCI Extension Field

4.3.41 MA_ResponsePlanMT UCI Extension

MA_ResponsePlanMT	
Description	See annotations in child elements and messages/elements that use this type for details.
	See the XSD File for more info
Ext. Fields	ObjectState : ObjectStateEnum MessageData : MA_ResponsePlanMDT

Table A-4-1192: Mission Plan Interface MA_ResponsePlanMT UCI Extension

ObjectState	
Description	Indicates the state of the internal software object that the data in the message is based upon. The state of the software object is determined by the publisher. The publisher could be the original/master publisher or an intermediary re-publisher such as a persistence/data manager. This element is not a commanded CRUD operation. It is not an indication of the state of an instance of a message. It is not a mechanism for partial, incremental, or fragmentary publication of a message. It is a signal from a publisher to subscribers. For REMOVED state, in particular, some subscribers will mirror the publisher and treat the message as if the object no longer exists, but others, such as mission recorders, might not (in order to support retaining historical records of activity, for example).
Base Type	ObjectStateEnum
Message Structure	

Enumeration Literal	Description
NEW	Indicates the internal software object corresponding to this message currently exists and this message is the first publication corresponding to the object.
UPDATED	Indicates the internal software object corresponding to this message currently exists and has been updated since the last publication of the message; this publication of the message may contain updates.
REMOVED	Indicates the internal software object corresponding to this message no longer exists; there should be no further publications of this message corresponding to the object.

Table A-4-1193: Mission Plan Interface MA_ResponsePlanMT - ObjectState UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_ResponsePlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
ResponsePlanID	ResponsePlanID_Type	Required
Description	Indicates a unique ID assigned to the ResponsePlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	ResponsePlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the ResponsePlan originated from.	
Plan	MA_ResponsePlanType	Required
Description	Contains the details of the task allocation plan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	MA_ResponsePlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-1194: Mission Plan Interface MA_ResponsePlanMT - MessageData UCI Extension Field

4.4 Mission Systems Interface

4.4.1 MA_StrikeCapabilityMT UCI Extension

MA_StrikeCapabilityMT	
Description	See annotations in child elements and messages/elements that use this type for details.

	See the XSD File for more info
Ext. Fields	MessageData : MA_StrikeCapabilityMDT

Table A-4-1195: Mission Systems Interface MA_StrikeCapabilityMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_StrikeCapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_StrikeCapabilityType	Repeated
Description	Indicates a Strike Capability provided by the Subsystem.	
Carriage	StoreCarriageCapabilityType	Repeated
Description	Optional list of carriage related to the StrikeCapability.	
Verification	StoreVerificationStatusType	Optional
Description	This is a rollup of all verification of each capability in this message.	
LoadoutMnemonic	VisibleString256Type	Optional
Description	Mnemonic representation of the store loadout that the reported strike capabilities and carriage support capabilities are derived from.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.	

Table A-4-1196: Mission Systems Interface MA_StrikeCapabilityMT - MessageData UCI Extension Field

4.4.2MA_CommErrorReportMT UCI Extension

MA_CommErrorReportMT	
Description	This message represents a general report of an communication error that is of significance to other systems, services, etc. in the network. This message is not intended for remote, centralized error logging; it is meant for "error awareness". See the XSD File for more info
Ext. Fields	MessageData : MA_CommErrorReportMDT CommErrorReportID : MA_CommErrorReportID_Type

Table A-4-1197: Mission Systems Interface MA_CommErrorReportMT UCI Extension

MessageData

Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CommErrorReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommErrorReportID	MA_CommErrorReportID_Type	Required
Description	The unique identifier for the Comm error report.	
SystemID	SystemID_Type	Required
Description	This element represents the SystemID of the service that experienced the error.	
SubsystemID	SubsystemID_Type	Optional
Description	This element represents the SubsystemID of the service that experienced the error.	
ServiceID	ServiceID_Type	Optional
Description	This element represents the SystemID of the service that experienced the error.	
ErrorDetail	VisibleString1024Type	Required
Description	Free text field to provide detail about the error in the communication.	
SoftwareExceptionDetail	VisibleString1024Type	Optional
Description	Free text field to provide detail about a software exception related to this Comm error.	
AssociatedMessage	AssociatedMessageType	Repeated
Description	Indicates an input message that is associated with or the cause of the communication error. This element should be omitted if an input message was not the cause of the error.	

Table A-4-1198: Mission Systems Interface MA_CommErrorReportMT - MessageData UCI Extension Field

CommErrorReportID		
Description	The unique identifier for the Comm error report.	
Base Type	MA_CommErrorReportID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1199: Mission Systems Interface MA_CommErrorReportMT - CommErrorReportID UCI Extension Field

4.4.3 MA_PositionReportDetailedMT UCI Extension

MA_PositionReportDetailedMT	
Description	See annotations in child elements and messages/elements that use this type for details.

	See the XSD File for more info
Ext. Fields	PositionReportData : MA_PositionReportDataType MessageData : MA_PositionReportDetailedMDT

Table A-4-1200: Mission Systems Interface MA_PositionReportDetailedMT UCI Extension

PositionReportData		
Description	If multiple instances are given, each should be of a different navigation solution type as indicated by the child element.	
Base Type	MA_PositionReportDataType	
Message Structure		
Field Name	Field Type	Field Usage
PositionSource	PositionSourceID_ChoiceType	Required
Description	The source of the positional data.	
ComponentID	ComponentID_Type	Optional
Description	The ID of the specific component within the subsystem that is the source of this data. This can be used if multiple redundant INS/GPS units are represented as a single subsystem.	
NavigationSolutionState	NavigationSolutionStateEnum	Required
Description	The navigation solution state indicates what sensor inputs the navigation unit is using to generate its kinematic solution.	
FigureOfMerit	BytePositiveType	Optional
Description	A FOM is typically calculated as the root-sum-square of the estimated errors contributing to the solution accuracy. Example criteria include: a. GPS receiver state (e.g., carrier tracking, code tracking, acquisition) b. Carrier to noise ratio c. Satellite geometry (DOP value) d. Satellite range accuracy (URA value) e. Ionospheric measurement or modeling error f. Receiver aiding used g. Kalman filter error estimates. The resultant FOM is presented as a numerical value from 1 to 9, where 1 indicates the best navigation performance.	

Kinematics	MA_DetailedKinematicsType	Required
Description	The kinematic state of the vehicle.	
KinematicsError	DetailedKinematicsErrorType	Required
Description	Indicates the covariance matrix of the vehicle, containing detailed kinematic errors of the position, velocity, and orientation. See the DetailedKinematicsErrorType element annotations for details.	
SolutionCorrections	NavigationSolutionCorrectionsType	Optional
Description	This element contains the corrections applied by the measurement unit to the reported values.	

Table A-4-1201: Mission Systems Interface MA_PositionReportDetailedMT - PositionReportData UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PositionReportDetailedMDT	
Message Structure		
Field Name	Field Type	Field Usage
PositionReportData	MA_PositionReportDataType	Repeated
Description	If multiple instances are given, each should be of a different navigation solution type as indicated by the child element.	

Table A-4-1202: Mission Systems Interface MA_PositionReportDetailedMT - MessageData UCI Extension Field

4.4.4MA_CommAvailableEndpointsMT UCI Extension

MA_CommAvailableEndpointsMT	
Description	Publishes available network endpoints as provided by network overhead messages. See the XSD File for more info
Ext. Fields	MessageData : MA_CommAvailableEndpointsMDT AvailableNetworkEndpoints : MA_AvailableNetworkEndPointsType MessageNumbering : MA_MessageNumberingType SystemID : SystemID_Type

Table A-4-1203: Mission Systems Interface MA_CommAvailableEndpointsMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CommAvailableEndpointsMDT	
Message Structure		
Field Name	Field Type	Field Usage
AvailableNetworkEndpoints	MA_AvailableNetworkEndPointsType	Repeated

Description	Publishes available network endpoints as discovered on network in accordance with the published comm plan.	
MessageNumbering	MA_MessageNumberingType	Optional
Description	Optional field for identification of total messages required to pass all network endpoints.	

Table A-4-1204: Mission Systems Interface MA_CommAvailableEndpointsMT - MessageData UCI Extension Field

AvailableNetworkEndpoints		
Description	Publishes available network endpoints as discovered on network in accordance with the published comm plan.	
Base Type	MA_AvailableNetworkEndPointsType	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Individual network endpoint's unique endpoint ID.	
EndpointLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1205: Mission Systems Interface MA_CommAvailableEndpointsMT - AvailableNetworkEndpoints UCI Extension Field

MessageNumbering		
Description	Optional field for identification of total messages required to pass all network endpoints.	
Base Type	MA_MessageNumberingType	
Message Structure		
Field Name	Field Type	Field Usage
CurrentMessage	double	Required
Description	Current message number.	
TotalMessageCount	double	Required
Description	Total number of messages to complete endpoint availability list.	

Table A-4-1206: Mission Systems Interface MA_CommAvailableEndpointsMT - MessageNumbering UCI Extension Field

SystemID		
Description	Individual network endpoint's unique endpoint ID.	
Base Type	SystemID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional

Description	Human readable text label with content meaningful to human operators.
-------------	---

Table A-4-1207: Mission Systems Interface MA_CommAvailableEndpointsMT - SystemID UCI Extension Field

4.4.5 MA_CommTeamReportMT UCI Extension

MA_CommTeamReportMT	
Description	This message provides the status for the available endpoints within the communication network. See the XSD File for more info
Ext. Fields	MessageData : MA_CommTeamReportMDT AvailableEndpoint : MA_AvailableNetworkEndPointsType SystemID : SystemID_Type

Table A-4-1208: Mission Systems Interface MA_CommTeamReportMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CommTeamReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
AvailableEndpoint	MA_AvailableNetworkEndPointsType	Repeated
Description	Lists the asset(s) or endpoint(s) part of the specific Group.	

Table A-4-1209: Mission Systems Interface MA_CommTeamReportMT - MessageData UCI Extension Field

AvailableEndpoint		
Description	Lists the asset(s) or endpoint(s) part of the specific Group.	
Base Type	MA_AvailableNetworkEndPointsType	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Individual network endpoint's unique endpoint ID.	
EndpointLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1210: Mission Systems Interface MA_CommTeamReportMT - AvailableEndpoint UCI Extension Field

SystemID	
Description	Individual network endpoint's unique endpoint ID.
Base Type	SystemID_Type
Message Structure	

Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1211: Mission Systems Interface MA_CommTeamReportMT - SystemID UCI Extension Field

4.4.6 MA_TaskMT UCI Extension

MA_TaskMT	
Description	This message specifies a Task that a System will perform against a specific entity or geographical location. Tasks include flight, collection, strike, electronic attack, directed energy, laser designation, cargo delivery and communication relay. They are abstracted to a level of C2 and autonomy derived from UCI operational vignettes. Tasks enable services, operators and other actors to do automated, dynamic, machine-to-machine allocation of Tasks to Systems and subsequent mission planning. If necessary, authorization of Users to Task Systems can be controlled using the Authorization message. See the XSD File for more info
Ext. Fields	TaskType : MA_TaskType TaskPlurality : MA_TaskPluralityEnum ConstraintID : MA_ConstraintID_Type HSA_CSA : MA_HSA_CSA_Type WaypointFollowing : MA_WaypointFollowingType CurveFollowing : MA_CurveControlType Speed : PathSegmentSpeedType Heading : MA_DirectionReferenceType SpeedChoice : MA_HSA_SpeedChoiceType SpeedValue : PathSegmentSpeedValueType CurveFitMethod : MA_CurveFitMethodEnum

Table A-4-1212: Mission Systems Interface MA_TaskMT UCI Extension

TaskType		
Description	Identifies the type of this Task instance.	
Base Type	MA_TaskType	
Message Structure		
Field Name	Field Type	Field Usage
AirSample	AirSampleTaskType	Required
Description	Air sample includes direct sampling of the air (SAMPLE) and remote sensing with spectral analysis (SPECTROMETER) with the intent of detecting NBC events.	

AMTI	AMTI_TaskType	Required
Description	Indicates a Task to collect Air Moving Target Indicator (AMTI) data.	
AO	AO_TaskType	Required
Description	Indicates a Task to perform an optical emission such as laser designation.	
CAP	MA_CAP_TaskType	Required
Description	Indicates a Task to perform Combat Air Patrol.	
CargoDelivery	CargoDeliveryTaskType	Required
Description	Indicates a Task to transfer cargo between locations.	
COMINT	COMINT_TaskType	Required
Description	Indicates a Task to provide COMINT.	
CommRelay	CommRelayTaskType	Required
Description	Indicates a Task to provide communications relay support.	
CounterSpace	CounterSpaceTaskType	Required
Description	Indicates a Task to employ a CounterSpace capability.	
Escort	MA_EscortTaskType	Required
Description	Indicates a Task to escort another Entity or System.	
EA	EA_TaskType	Required
Description	Indicates a Task to provide electronic attack support to another System. It guides/constrains the EA System by specifying where it should fly, what it should protect and what the threat is.	
ESM	ESM_TaskType	Required
Description	Indicates a Task to collect ESM data.	
Flight	MA_FlightTaskType	Required
Description	Indicates a Task to effect the flight path/plan of the System.	
Jettison	MA_JettisonTaskType	Required
Description	Indicates a Task to a jettisonable weapon from the system.	
OrbitChange	OrbitChangeTaskType	Required
Description	Indicates a task to perform an orbit change via a spacecraft maneuver.	
OrbitalSurveillance	OrbitalSurveillanceTaskType	Required
Description	Indicates an Orbital Surveillance Task.	
OrbitalSurveillanceSensor	OrbitalSurveillanceSensorTaskType	Required
Description	Indicates a task to perform orbital surveillance sensor tasking.	
PO	PO_TaskType	Required
Description	Indicates a Task to collect Passive Optical data, imagery and video as well as perform PO search and track capabilities.	
Refuel	RefuelTaskType	Required
Description	Indicates a Task for one System to refuel another.	

SAR	SAR_TaskType	Required
Description	Indicates a Task to collect a Synthetic Aperture Radar (SAR) image.	
SMTI	SMTI_TaskType	Required
Description	Indicates a Task to collect Moving Target Indicator (MTI) data.	
Strike	StrikeTaskType	Required
Description	Indicates a Task to kinetically attack/strike, with a weapon that can be released from the System.	
SystemDeployment	SystemDeploymentTaskType	Required
Description	Indicates a task to perform a deployment or release of a system at a specified location.	
TacticalOrder	TacticalOrderTaskType	Required
Description	Indicates a task to perform a tactical order.	
WeatherRadar	WeatherRadarTaskType	Required
Description	Indicates a task to collect weather radar data.	

Table A-4-1213: Mission Systems Interface MA_TaskMT - TaskType UCI Extension Field

TaskPlurality	
Description	Indicates whether the task is meant to be executed by a single entity or as a joint operation. A join operation implies forming a group prior to execution. A single entity could be a single system or a single pre-formed group.
Base Type	MA_TaskPluralityEnum
Message Structure	
Enumeration Literal	Description
UNSPECIFIED	Indicates the task plurality is unspecified, and should be defaulted or determined by the receiving system.
JOINT	Indicates the task is to be executed as a joint task. A group will be formed when this task is assigned.
SINGLE_ENTITY	Indicates the task is to be executed by a single entity. A single entity could be a single system or a single pre-existing group.

Table A-4-1214: Mission Systems Interface MA_TaskMT - TaskPlurality UCI Extension Field

ConstraintID		
Description	Indicates any Constraints that apply to the Task (e.g FormationConstraint). A FormationConstraint implies that if a group is formed to execute this task, the referenced Constraint(s) should be applied to that group.	
Base Type	MA_ConstraintID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	

DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1215: Mission Systems Interface MA_TaskMT - ConstraintID UCI Extension Field

HSA_CSA		
Description	This message shall be used to provide the ability to command a new flight vector to the Platform.	
Base Type	MA_HSA_CSA_Type	
Message Structure		
Field Name	Field Type	Field Usage
Altitude	AltitudeReferenceType	Optional
Description	Altitude hold value to be achieved and reference to altitude measurement source.	
Speed	PathSegmentSpeedType	Optional
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Direction	MA_DirectionChoiceType	Optional
Description	Defines heading or course type and reference to hold	

Table A-4-1216: Mission Systems Interface MA_TaskMT - HSA_CSA UCI Extension Field

WaypointFollowing		
Description	This message shall be used to provide the ability to send a new waypoint path or segment for the Platform to follow.	
Base Type	MA_WaypointFollowingType	
Message Structure		
Field Name	Field Type	Field Usage
Route	MA_RouteType	Required
Description	Indicates the Paths and Segments that make up the Route to be flown.	

Table A-4-1217: Mission Systems Interface MA_TaskMT - WaypointFollowing UCI Extension Field

CurveFollowing		
Description	Indicates the parameters for curve following control.	
Base Type	MA_CurveControlType	
Message Structure		
Field Name	Field Type	Field Usage
CurveSegments	MA_NURBS_PointType	Repeated
Description	Specifies the curve segments as a set of NURBS points.	
AppendCurve	EmptyType	Optional
Description	Specifies this curve will be appended to a previous curve command. This is only valid if the vehicle is currently executing a curve.	
EndOfCurveBehavior	MA_EndOfCurveBehaviorEnum	Optional

Description	Specifies the vehicle behavior at the completion of the curve.
-------------	--

Table A-4-1218: Mission Systems Interface MA_TaskMT - CurveFollowing UCI Extension Field

Speed		
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Base Type	PathSegmentSpeedType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedChoice	PathSegmentSpeedChoiceType	Optional
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
SpeedOptimization	SpeedOptimizationEnum	Optional
Description	Indicates that the System will vary its speed autonomously according to the specified optimization algorithm.	

Table A-4-1219: Mission Systems Interface MA_TaskMT - Speed UCI Extension Field

Heading		
Description	Defines heading type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-1220: Mission Systems Interface MA_TaskMT - Heading UCI Extension Field

SpeedChoice		
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
Base Type	MA_HSA_SpeedChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedValue	PathSegmentSpeedValueType	Required
Description	Indicates speed in meters per second (m/s).	
MachValue	MachType	Required
Description	Indicates the speed reference for the associated speed value.	

Table A-4-1221: Mission Systems Interface MA_TaskMT - SpeedChoice UCI Extension Field

SpeedValue		
Description	Indicates speed in meters per second (m/s).	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-1222: Mission Systems Interface MA_TaskMT - SpeedValue UCI Extension Field

CurveFitMethod	
Description	Method through which a curve should be fitted to the discretized points in ControlPoint.
Base Type	MA_CurveFitMethodEnum
Message Structure	
Enumeration Literal	Description
B_SPLINE	B-Spline (basis spline) fit.
BEZIER	Bezier curve fit.
CATMULL_ROM	Catmull-Rom spline fit.
NATURAL_CUBIC	Natural Cubic curve fit.

Table A-4-1223: Mission Systems Interface MA_TaskMT - CurveFitMethod UCI Extension Field

4.4.7 MA_TaskStatusMT UCI Extension

MA_TaskStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	Plans : MA_PlansReferenceType OpPlanID : MA_OpPlanID_Type ExecutingSystemOrPackage : MA_PackageSystemType MessageData : MA_TaskStatusMDT Traceability : MA_RequirementStatusTraceabilityType

Table A-4-1224: Mission Systems Interface MA_TaskStatusMT UCI Extension

Plans

Description	Indicates *Plans the Requirement is associated with.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-1225: Mission Systems Interface MA_TaskStatusMT - Plans UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-	

	approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1226: Mission Systems Interface MA_TaskStatusMT - OpPlanID UCI Extension Field

ExecutingSystemOrPackage		
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-1227: Mission Systems Interface MA_TaskStatusMT - ExecutingSystemOrPackage UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_TaskStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
TaskID	TaskID_Type	Required
Description	Indicates the unique ID of the Task whose execution status is being reported.	
ExecutingSystemOrPackage	MA_PackageSystemType	Required
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
ExecutionState	RequirementExecutionStateEnum	Required

Description	Identifies the state of the Requirement.	
ExecutionStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling State element. This element is only expected when the State is in a potentially undesirable state such as failed or completed with less than optimum results. It is strongly encouraged for transitions to failed or dropped.	
ActualTiming	RequirementTimingType	Repeated
Description	Indicates actual timing status for the Requirement. Allows for defining for each timing type (RequirementTimingEnum).	
PercentCompleted	PercentType	Optional
Description	Percentage of assigned Requirement completion. The percentage increments until the Requirement has COMPLETED or FAILED. A percent complete of 0 indicates the Requirement has not yet begun execution, and a failed Requirement may have any percentage between 1 - 99.	
Traceability	MA_RequirementStatusTraceabilityType	Optional
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.	
Metrics	MetricsType	Optional
Description	Specifies the actual metrics associated with the Requirements.	

Table A-4-1228: Mission Systems Interface MA_TaskStatusMT - MessageData UCI Extension Field

Traceability	
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.
Base Type	MA_RequirementStatusTraceabilityType

Message Structure		
Field Name	Field Type	Field Usage
Plans	MA_PlansReferenceType	Optional
Description	Indicates *Plans the Requirement is associated with.	
PlannedActivityID	PlannedActivityID_Type	Repeated
Description	Indicates a specific Planned Activity the Requirement is associated with.	
CapabilityID	CapabilityID_Type	Repeated
Description	Identifies a specific Capability the Requirement is associated with.	
CommandID	CommandID_Type	Repeated
Description	Indicates the ID of an associated [Capability]Command.	
ActivityID	ActivityID_Type	Repeated
Description	Indicates the ID of an associated actual/executing/executed Activity.	

Table A-4-1229: Mission Systems Interface MA_TaskStatusMT - Traceability UCI Extension Field

4.4.8 MA_TaskCommandStatusMT UCI Extension

MA_TaskCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_TaskCommandStatusMDT

Table A-4-1230: Mission Systems Interface MA_TaskCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_TaskCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	

CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-1231: Mission Systems Interface MA_TaskCommandStatusMT - MessageData UCI Extension Field

4.4.9 MA_TaskCommandMT UCI Extension

MA_TaskCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_TaskCommandMDT

Table A-4-1232: Mission Systems Interface MA_TaskCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_TaskCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Command	MA_TaskCommandType	Repeated
Description	Indicates an instance of a Task Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Capability CommandStatus message.	

Table A-4-1233: Mission Systems Interface MA_TaskCommandMT - MessageData UCI Extension Field

4.4.10 MA_ActivityPlanMT UCI Extension

MA_ActivityPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ActivityPlanMDT

Table A-4-1234: Mission Systems Interface MA_ActivityPlanMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.
Base Type	MA_ActivityPlanMDT
Message Structure	

Field Name	Field Type	Field Usage
ActivityPlanID	ActivityPlanID_Type	Required
Description	Indicates a unique ID assigned to the ActivityPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	ActivityPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which this ActivityPlan originated from.	
Plan	MA_ActivityPlanType	Required
Description	Indicates the details of the ActivityPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is a used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	ActivityPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-1235: Mission Systems Interface MA_ActivityPlanMT - MessageData UCI Extension Field

4.4.11 MA_MessagingSubscriptionSettingCommandMT UCI Extension

MA_MessagingSubscriptionSettingCommandMT	
Description	Command message to adjust the topic subscription settings for the secure messaging interface between ACP's on a network. See the XSD File for more info
Ext. Fields	MessageData : MA_MessagingSubscriptionSettingCommandMDT AddTopicSubscription : MA_TopicSubscriptionType ChangeTopicSubscription : MA_ChangeTopicSubscriptionType DataPayloadOriginatorID : SystemID_Type SubscriptionID : MA_SubscriptionID_Type SubscriptionFilterType : MA_SubscriptionFilterType SubscriptionID : MA_SubscriptionID_Type SubscriptionChangeType : MA_SubscriptionChangeTypeEnum

Table A-4-1236: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT UCI Extension

MessageData	
Description	Message field for data for topic subscription additions and removals.
Base Type	MA_MessagingSubscriptionSettingCommandMDT
Message Structure	

Field Name	Field Type	Field Usage
AddTopicSubscription	MA_TopicSubscriptionType	Repeated
Description	Field indicates the topic and possible data originator(s) for the topic to be subscribed to.	
ChangeTopicSubscription	MA_ChangeTopicSubscriptionType	Repeated
Description	Field indicates a command to change the state of an existing message subscription.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-1237: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - MessageData UCI Extension Field

AddTopicSubscription		
Description	Field indicates the topic and possible data originator(s) for the topic to be subscribed to.	
Base Type	MA_TopicSubscriptionType	
Message Structure		
Field Name	Field Type	Field Usage
Topic	VisibleString1024Type	Required
Description	Indicates the topic name.	
DataPayloadOriginatorID	SystemID_Type	Repeated
Description	Indicates a data originator for data on this topic. To subscribe to messages on the specified topic from only a subset of originators, specify those originators using this field. If no DataPayloadOriginatorID values are specified then all data originators will be allowed.	
SubscriptionID	MA_SubscriptionID_Type	Required
Description	Unique ID that represents the subscription to a topic from a set of data originators.	
SubscriptionFilterType	MA_SubscriptionFilterType	Optional
Description	Specifies a filter for the data received via this topic. The SubscriptionFilterType can be used in addition to the Topic to provide further filtering of messaging within a specific Topic, or across all Topics. This allows a system to exclude messages in the Topic that do not meet its needs during a period of operation. Could be implemented as a receive filter or transmit filter.	
Priority	ComparableRankingType	Optional
Description	Indicates the priority of the subscription relative to others. Priority gives guidance on which subscriptions to favor when resources are limited.	

Table A-4-1238: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - AddTopicSubscription UCI Extension Field

ChangeTopicSubscription		
Description	Field indicates a command to change the state of an existing message subscription.	
Base Type	MA_ChangeTopicSubscriptionType	
Message Structure		
Field Name	Field Type	Field Usage
SubscriptionID	MA_SubscriptionID_Type	Required
Description	Unique ID that represents the subscription to a topic from a set of data originators.	
SubscriptionChangeType	MA_SubscriptionChangeTypeEnum	Required
Description	Indicates the type of requested subscription change.	

Table A-4-1239: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - ChangeTopicSubscription UCI Extension Field

DataPayloadOriginatorID		
Description	Indicates a data originator for data on this topic. To subscribe to messages on the specified topic from only a subset of originators, specify those originators using this field. If no DataPayloadOriginatorID values are specified then all data originators will be allowed.	
Base Type	SystemID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1240: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - DataPayloadOriginatorID UCI Extension Field

SubscriptionID		
Description	Unique ID that represents the subscription to a topic from a set of data originators.	
Base Type	MA_SubscriptionID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1241: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - SubscriptionID UCI Extension Field

SubscriptionFilterType		
Description	Specifies a filter for the data received via this topic. The SubscriptionFilterType can be used in addition to the Topic to provide further filtering of messaging within a specific Topic, or across all Topics. This allows a system to exclude messages in the Topic that do not meet its needs during a period of operation. Could be implemented as a receive filter or transmit filter.	
Base Type	MA_SubscriptionFilterType	
Message Structure		
Field Name	Field Type	Field Usage
UCI_Message	QueryMessageType	Required
Description	Indicates a subscription aligned with specific UCI messages with optional filtering of the message.	

Table A-4-1242: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - SubscriptionFilterType UCI Extension Field

SubscriptionID		
Description	Unique ID that represents the subscription to a topic from a set of data originators.	
Base Type	MA_SubscriptionID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1243: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - SubscriptionID UCI Extension Field

SubscriptionChangeType	
Description	Indicates the type of requested subscription change.
Base Type	MA_SubscriptionChangeTypeEnum
Message Structure	
Enumeration Literal	Description
ACTIVATE	Activate the referenced subscription.
DEACTIVATE	Deactivate the referenced subscription.
DELETE	Remove the referenced subscription.

Table A-4-1244: Mission Systems Interface MA_MessagingSubscriptionSettingCommandMT - SubscriptionChangeType UCI Extension Field

4.4.12 MA_RoutePlanMT UCI Extension

MA_RoutePlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RoutePlanMDT

Table A-4-1245: Mission Systems Interface MA_RoutePlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_RoutePlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
RoutePlanID	RoutePlanID_Type	Required
Description	Indicates a unique ID assigned to the RoutePlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	RoutePlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the RoutePlan originated from.	
Plan	MA_RoutePlanType	Required
Description	Contains the details of the route plan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	RoutePlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-1246: Mission Systems Interface MA_RoutePlanMT - MessageData UCI Extension Field

4.4.13 MA_TaskPlanMT UCI Extension

MA_TaskPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_TaskPlanMDT

Table A-4-1247: Mission Systems Interface MA_TaskPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_TaskPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlanID	TaskPlanID_Type	Required
Description	Indicates a unique ID assigned to the TaskPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	TaskPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the TaskPlan originated from.	
Plan	MA_TaskPlanType	Required
Description	Contains the details of the task allocation plan.	
ForPlanningUseOnly	Boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	MA_TaskPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-1248: Mission Systems Interface MA_TaskPlanMT - MessageData UCI Extension Field

4.4.14 MA_TxDataPayloadCommandMT UCI Extension

MA_TxDataPayloadCommandMT	
Description	Command message to send a hexbinary data payload offboard to either a single or multiple network endpoints. See the XSD File for more info
Ext. Fields	MessageData : MA_TxDataPayloadCommandMDT SpecificDestinationID : SystemID_Type

Table A-4-1249: Mission Systems Interface MA_TxDataPayloadCommandMT UCI Extension

MessageData		
Description	Message field for data payload to be sent offboard.	
Base Type	MA_TxDataPayloadCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage

DestinationRouting	MA_DestinationHandlingEnum	Required
Description	Indicates whether the message should be routed only to the listed SpecificDestinationIDs or to both the topic which corresponds to the listed MessageType and also to any SpecificDestinationIDs. The command is invalid if SPECIFIC_DESTINATION_ONLY is specified and no SpecificDestinationIDs are listed.	
EncodedPayload	hexBinary	Required
Description	Indicates the encoded data payload that is to be sent to the designated destination. This is an encoded binary message intended to be sent to another system (e.g. C2, autonomous platform, etc.) for decoding.	
MessageExpiry	DateTimeType	Optional
Description	Indicates the time at which the data payload message expires.	
Priority	ComparableRankingType	Required
Description	Indicates the precedence and priority levels of the particular data payloads being sent.	
SpecificDestinationID	SystemID_Type	Repeated
Description	Indicates a unique network endpoint that is identified as a destination for the encoded payload.	
Timestamp	DateTimeType	Optional
Description	Indicates the time which the encoded payload was generated.	
MessageType	MessageTypeEnum	Required
Description	Indicates the UCI type of message in the EncodedPayload.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-1250: Mission Systems Interface MA_TxDataPayloadCommandMT - MessageData UCI Extension Field

SpecificDestinationID		
Description	Indicates a unique network endpoint that is identified as a destination for the encoded payload.	
Base Type	SystemID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1251: Mission Systems Interface MA_TxDataPayloadCommandMT - SpecificDestinationID UCI Extension Field

4.4.15 MA_WEZ_RequestMT UCI Extension

MA_WEZ_RequestMT	
Description	This message is used to request the generation of a Weapon Engagement Zone (WEZ). The WEZ represents a less dynamic capability than the DLZ for air to air engagements and is not reliant on target state data to be produced. See the XSD File for more info
Ext. Fields	MessageData : MA_WEZ_RequestMDT WEZ_RequestData : MA_WEZ_RequestDataType WEZ_ChoiceType : MA_WEZ_ChoiceType StaticWEZ : MA_WEZ_StaticType PlannedStaticWEZ : MA_WEZ_PlannedStaticType PredictedWEZ : MA_WEZ_PredictedType PlannedPredictedWEZ : MA_WEZ_PlannedPredictedType WEZ_FieldOfView : MA_WEZ_FieldOfViewEnum PlannedReleaseConditions : MA_WEZ_StateDataType WEZ_FieldOfView : MA_WEZ_FieldOfViewEnum WEZ_FieldOfView : MA_WEZ_FieldOfViewEnum PlannedReleaseConditions : MA_WEZ_StateDataType PredictedTargetStateData : MA_WEZ_StateDataType WEZ_FieldOfView : MA_WEZ_FieldOfViewEnum PredictedTargetStateData : MA_WEZ_StateDataType

Table A-4-1252: Mission Systems Interface MA_WEZ_RequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_WEZ_RequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	The ID of the system to perform the processing.	
ResultsInNativeMessage	boolean	Required
Description	If TRUE this element specifies that the response to this message should be in a MA_WEZ_MDT message. If FALSE the response to this message should be in the MA_WEZ_RequestStatusMDT.	
WEZ_RequestData	MA_WEZ_RequestDataType	Repeated

Description	Indicates the inputs needed for a specified weapon to return an array of capability ranges per azimuth from the ownship.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-1253: Mission Systems Interface MA_WEZ_RequestMT - MessageData UCI Extension Field

WEZ_RequestData		
Description	Indicates the inputs needed for a specified weapon to return an array of capability ranges per azimuth from the ownship.	
Base Type	MA_WEZ_RequestDataType	
Message Structure		
Field Name	Field Type	Field Usage
StoreInformation	WeaponneeringStoreType	Required
Description	Indicates Store Type and Category.	
WEZ_ChoiceType	MA_WEZ_ChoiceType	Required
Description	Indicates the type of WEZ that is being requested by the user.	
TargetPlatformInformation	PlatformIdentityType	Required
Description	Provides information about the Target Platform	

Table A-4-1254: Mission Systems Interface MA_WEZ_RequestMT - WEZ_RequestData UCI Extension Field

WEZ_ChoiceType		
Description	Indicates the type of WEZ that is being requested by the user.	
Base Type	MA_WEZ_ChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
StaticWEZ	MA_WEZ_StaticType	Required
Description	Indicates a target has a heading pointed at the ownship, and the same altitude and velocity as the ownship in its current state, as reported by the vehicle interface. The service will subscribe to position data as reported by the vehicle interface for ownship state data.	
PlannedStaticWEZ	MA_WEZ_PlannedStaticType	Required
Description	Indicates a target has a heading pointed at the ownship and an altitude and velocity as described in the "PlannedReleaseConditions" field. The service will use the "PlannedReleaseConditions" field for the ownship state data.	
PredictedWEZ	MA_WEZ_PredictedType	Required
Description	Indicates a target has the heading, altitude and velocity as described by the "PredictedTargetStateData" field. The service will subscribe to position data as reported by the vehicle interface for ownship state data.	

PlannedPredictedWEZ	MA_WEZ_PlannedPredictedType	Required
Description	Indicates a target has the heading, altitude and velocity as described by the "PredictedTargetStateData" field. The service will use the "PlannedReleaseConditions" field for the ownship state data.	

Table A-4-1255: Mission Systems Interface MA_WEZ_RequestMT - WEZ_ChoiceType UCI Extension Field

StaticWEZ		
Description	Indicates a target has a heading pointed at the ownship, and the same altitude and velocity as the ownship in its current state, as reported by the vehicle interface. The service will subscribe to position data as reported by the vehicle interface for ownship state data.	
Base Type	MA_WEZ_StaticType	
Message Structure		
Field Name	Field Type	Field Usage
WEZ_FieldOfView	MA_WEZ_FieldOfViewEnum	Required
Description	Identifies the region in radians for the WEZ by indicating the desired azimuth range around the ownship for which the capability ranges are being requested for. The ranges for these regions may be pre-calculated by the service prior to flight or calculated upon the request in flight.	

Table A-4-1256: Mission Systems Interface MA_WEZ_RequestMT - StaticWEZ UCI Extension Field

PlannedStaticWEZ		
Description	Indicates a target has a heading pointed at the ownship and an altitude and velocity as described in the "PlannedReleaseConditions" field. The service will use the "PlannedReleaseConditions" field for the ownship state data.	
Base Type	MA_WEZ_PlannedStaticType	
Message Structure		
Field Name	Field Type	Field Usage
WEZ_FieldOfView	MA_WEZ_FieldOfViewEnum	Required
Description	Identifies the region in radians for the WEZ by indicating the desired azimuth range around the ownship for which the capability ranges are being requested for. The ranges for these regions may be pre-calculated by the service prior to flight or calculated upon the request in flight.	
PlannedReleaseConditions	MA_WEZ_StateDataType	Required
Description	Specifies the planned ownship position and state data for the WEZ.	

Table A-4-1257: Mission Systems Interface MA_WEZ_RequestMT - PlannedStaticWEZ UCI Extension Field

PredictedWEZ	
Description	Indicates a target has the heading, altitude and velocity as described by the "PredictedTargetStateData" field. The service will subscribe to position data as reported by the vehicle interface for ownship state data.
Base Type	MA_WEZ_PredictedType
Message Structure	

Field Name	Field Type	Field Usage
WEZ_FieldOfView	MA_WEZ_FieldOfViewEnum	Required
Description	Identifies the region in radians for the WEZ by indicating the desired azimuth range around the ownship for which the capability ranges are being requested for. The ranges for these regions may be pre-calculated by the service prior to flight or calculated upon the request in flight.	
PredictedTargetStateData	MA_WEZ_StateDataType	Required
Description	Indicates predicted target state data for the WEZ.	

Table A-4-1258: Mission Systems Interface MA_WEZ_RequestMT - PredictedWEZ UCI Extension Field

PlannedPredictedWEZ		
Description	Indicates a target has the heading, altitude and velocity as described by the "PredictedTargetStateData" field. The service will use the "PlannedReleaseConditions" field for the ownship state data.	
Base Type	MA_WEZ_PlannedPredictedType	
Message Structure		
Field Name	Field Type	Field Usage
WEZ_FieldOfView	MA_WEZ_FieldOfViewEnum	Required
Description	Identifies the region in radians for the WEZ by indicating the desired azimuth range around the ownship for which the capability ranges are being requested for. The ranges for these regions may be pre-calculated by the service prior to flight or calculated upon the request in flight.	
PlannedReleaseConditions	MA_WEZ_StateDataType	Required
Description	Specifies the planned ownship position and state data for the WEZ.	
PredictedTargetStateData	MA_WEZ_StateDataType	Required
Description	Indicates predicted target state data for the WEZ.	

Table A-4-1259: Mission Systems Interface MA_WEZ_RequestMT - PlannedPredictedWEZ UCI Extension Field

WEZ_FieldOfView	
Description	Identifies the region in radians for the WEZ by indicating the desired azimuth range around the ownship for which the capability ranges are being requested for. The ranges for these regions may be pre-calculated by the service prior to flight or calculated upon the request in flight.
Base Type	MA_WEZ_FieldOfViewEnum
Message Structure	
Enumeration Literal	Description
FULL_WEZ	Represents a WEZ requested for the azimuths from 0 to 360 degrees around the ownship. Region is built out for azimuth range in radians with a default 5 degree step.
FRONT_WEZ	Represents a WEZ requested for the azimuths from 0 to 180 degrees off the nose of the ownship. Region is built out for azimuth range in radians with a default 5 degree step.
RIGHT_WEZ	Represents a WEZ requested for the azimuths from 0 to 180 degrees off the right wing of the ownship. Region is built out for azimuth range in radians with a default 5 degree

	step.
LEFT_WEZ	Represents a WEZ requested for the azimuths from 0 to 180s degree off the left wing of the ownship. Region is built out for azimuth range in radians with a default 5 degree step.

Table A-4-1260: Mission Systems Interface MA_WEZ_RequestMT - WEZ_FieldOfView UCI Extension Field

PlannedReleaseConditions		
Description	Specifies the planned ownship position and state data for the WEZ.	
Base Type	MA_WEZ_StateDataType	
Message Structure		
Field Name	Field Type	Field Usage
Position	Point3D_Type	Required
Description	Notional System position at time of release.	
Velocity	Velocity2D_Type	Required
Description	Representation of the vehicle's velocity as directional components in True Air Speed.	
MagneticHeading	AngleType	Required
Description	Indicates the heading in relationship to magnetic north.	
Orientation	OrientationType	Optional
Description	Euler Angle Sequence describing the orientation of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
WindVelocity	Velocity2D_Type	Optional
Description	This element represents wind speed at the release point.	

Table A-4-1261: Mission Systems Interface MA_WEZ_RequestMT - PlannedReleaseConditions UCI Extension Field

WEZ_FieldOfView	
Description	Identifies the region in radians for the WEZ by indicating the desired azimuth range around the ownship for which the capability ranges are being requested for. The ranges for these regions may be pre-calculated by the service prior to flight or calculated upon the request in flight.
Base Type	MA_WEZ_FieldOfViewEnum
Message Structure	
Enumeration Literal	Description
FULL_WEZ	Represents a WEZ requested for the azimuths from 0 to 360 degrees around the ownship. Region is built out for azimuth range in radians with a default 5 degree step.
FRONT_WEZ	Represents a WEZ requested for the azimuths from 0 to 180 degrees off the nose of the ownship. Region is built out for azimuth range in radians with a default 5 degree step.
RIGHT_WEZ	Represents a WEZ requested for the azimuths from 0 to 180 degrees off the right wing of the ownship. Region is built out for azimuth range in radians with a default 5 degree step.

LEFT_WEZ	Represents a WEZ requested for the azimuths from 0 to 180s degree off the left wing of the ownship. Region is built out for azimuth range in radians with a default 5 degree step.
-----------------	--

Table A-4-1262: Mission Systems Interface MA_WEZ_RequestMT - WEZ_FieldOfView UCI Extension Field

WEZ_FieldOfView	
Description	Identifies the region in radians for the WEZ by indicating the desired azimuth range around the ownship for which the capability ranges are being requested for. The ranges for these regions may be pre-calculated by the service prior to flight or calculated upon the request in flight.
Base Type	MA_WEZ_FieldOfViewEnum
Message Structure	
Enumeration Literal	Description
FULL_WEZ	Represents a WEZ requested for the azimuths from 0 to 360 degrees around the ownship. Region is built out for azimuth range in radians with a default 5 degree step.
FRONT_WEZ	Represents a WEZ requested for the azimuths from 0 to 180 degrees off the nose of the ownship. Region is built out for azimuth range in radians with a default 5 degree step.
RIGHT_WEZ	Represents a WEZ requested for the azimuths from 0 to 180 degrees off the right wing of the ownship. Region is built out for azimuth range in radians with a default 5 degree step.
LEFT_WEZ	Represents a WEZ requested for the azimuths from 0 to 180s degree off the left wing of the ownship. Region is built out for azimuth range in radians with a default 5 degree step.

Table A-4-1263: Mission Systems Interface MA_WEZ_RequestMT - WEZ_FieldOfView UCI Extension Field

PlannedReleaseConditions		
Description	Specifies the planned ownship position and state data for the WEZ.	
Base Type	MA_WEZ_StateDataType	
Message Structure		
Field Name	Field Type	Field Usage
Position	Point3D_Type	Required
Description	Notional System position at time of release.	
Velocity	Velocity2D_Type	Required
Description	Representation of the vehicle's velocity as directional components in True Air Speed.	
MagneticHeading	AngleType	Required
Description	Indicates the heading in relationship to magnetic north.	
Orientation	OrientationType	Optional
Description	Euler Angle Sequence describing the orientation of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
WindVelocity	Velocity2D_Type	Optional

Description	This element represents wind speed at the release point.
-------------	--

Table A-4-1264: Mission Systems Interface MA_WEZ_RequestMT - PlannedReleaseConditions UCI Extension Field

PredictedTargetStateData		
Description	Indicates predicted target state data for the WEZ.	
Base Type	MA_WEZ_StateDataType	
Message Structure		
Field Name	Field Type	Field Usage
Position	Point3D_Type	Required
Description	Notional System position at time of release.	
Velocity	Velocity2D_Type	Required
Description	Representation of the vehicle's velocity as directional components in True Air Speed.	
MagneticHeading	AngleType	Required
Description	Indicates the heading in relationship to magnetic north.	
Orientation	OrientationType	Optional
Description	Euler Angle Sequence describing the orientation of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
WindVelocity	Velocity2D_Type	Optional
Description	This element represents wind speed at the release point.	

Table A-4-1265: Mission Systems Interface MA_WEZ_RequestMT - PredictedTargetStateData UCI Extension Field

WEZ_FieldOfView	
Description	Identifies the region in radians for the WEZ by indicating the desired azimuth range around the ownship for which the capability ranges are being requested for. The ranges for these regions may be pre-calculated by the service prior to flight or calculated upon the request in flight.
Base Type	MA_WEZ_FieldOfViewEnum
Message Structure	
Enumeration Literal	Description
FULL_WEZ	Represents a WEZ requested for the azimuths from 0 to 360 degrees around the ownship. Region is built out for azimuth range in radians with a default 5 degree step.
FRONT_WEZ	Represents a WEZ requested for the azimuths from 0 to 180 degrees off the nose of the ownship. Region is built out for azimuth range in radians with a default 5 degree step.
RIGHT_WEZ	Represents a WEZ requested for the azimuths from 0 to 180 degrees off the right wing of the ownship. Region is built out for azimuth range in radians with a default 5 degree step.
LEFT_WEZ	Represents a WEZ requested for the azimuths from 0 to 180s degree off the left wing of the ownship. Region is built out for azimuth range in radians with a default 5 degree step.

Table A-4-1266: Mission Systems Interface MA_WEZ_RequestMT - WEZ_FieldOfView UCI Extension Field

PredictedTargetStateData		
Description	Indicates predicted target state data for the WEZ.	
Base Type	MA_WEZ_StateDataType	
Message Structure		
Field Name	Field Type	Field Usage
Position	Point3D_Type	Required
Description	Notional System position at time of release.	
Velocity	Velocity2D_Type	Required
Description	Representation of the vehicle's velocity as directional components in True Air Speed.	
MagneticHeading	AngleType	Required
Description	Indicates the heading in relationship to magnetic north.	
Orientation	OrientationType	Optional
Description	Euler Angle Sequence describing the orientation of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
WindVelocity	Velocity2D_Type	Optional
Description	This element represents wind speed at the release point.	

Table A-4-1267: Mission Systems Interface MA_WEZ_RequestMT - PredictedTargetStateData UCI Extension Field

4.4.16 MA_RouteActivityPlanMT UCI Extension

MA_RouteActivityPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RouteActivityPlanMDT

Table A-4-1268: Mission Systems Interface MA_RouteActivityPlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_RouteActivityPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
RouteActivityPlanID	RouteActivityPlanID_Type	Required
Description	Indicates a unique ID assigned to the RouteActivityPlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	RouteActivityPlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the RouteActivityPlan originated	

	from.	
Plan	MA_RouteActivityPlanType	Required
Description	Indicates the details of the RouteActivityPlan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	RouteActivityPlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-1269: Mission Systems Interface MA_RouteActivityPlanMT - MessageData UCI Extension Field

4.4.17 MA_FaultMT UCI Extension

MA_FaultMT	
Description	This represents a fault for the system. Intended to be used by services such as a health monitoring service for centralized fault management and fault isolation of a system. Allows announcing a fault state change (raised or cleared) from a service as opposed to a capability or component of a subsystem. Also conveys a service relationship in addition to a subsystem relationship. Extended to include a modified Fault Severity Enumeration for Mission Autonomy. See the XSD File for more info
Ext. Fields	MessageData : MA_FaultMDT FaultInformation : MA_SubsystemFaultType Severity : MA_FaultSeverityEnum

Table A-4-1270: Mission Systems Interface MA_FaultMT UCI Extension

MessageData		
Description	Reports a fault for the system.	
Base Type	MA_FaultMDT	
Message Structure		
Field Name	Field Type	Field Usage
FaultInformation	MA_SubsystemFaultType	Repeated
Description	Contains the fault information for the message.	

Table A-4-1271: Mission Systems Interface MA_FaultMT - MessageData UCI Extension Field

FaultInformation	
Description	Contains the fault information for the message.
Base Type	MA_SubsystemFaultType
Message Structure	

Field Name	Field Type	Field Usage
FaultID	FaultID_Type	Required
Description	The unique ID for this fault. Every fault from a Subsystem, Capability, SupportCapability, Component, or Service should have a unique ID.	
Severity	MA_FaultSeverityEnum	Optional
Description	The severity of the fault. This enumeration is modified for Mission Autonomy adaptation.	
FaultState	FaultStateEnum	Optional
Description	The state of the fault.	
FaultData	FaultDataType	Repeated
Description	Additional fault data which contains key/value pairs with format and unit indicated for the data value. This data supports fault isolation and helps to minimize false alarms.	
DetectionTime	DateTimeType	Optional
Description	Indicates the time the fault was detected; it does not indicate the time the fault was transmitted.	
FaultCode	VisibleString256Type	Required
Description	Indicates the "code" or name of the fault.	
FaultCodeCount	int	Optional
Description	Indicates the number of occurrences of the associated FaultCode and a set FaultState.	
FaultDescription	VisibleString256Type	Optional
Description	Indicates a human readable description of the fault and/or its cause. This could be different than DescriptiveLabel in the sibling FaultID field. For example, DescriptiveLabel could be "Engine 1 overheat" and the FaultDescription could be "Lubrication oil" or "Exhaust nozzle" indicating the underlying cause of the fault.	
SubsystemID	SubsystemID_Type	Optional
Description	The Subsystem that the fault occurred within.	
ServiceID	ServiceID_Type	Optional
Description	The Service that this fault occurred within.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates the unique ID of a Capability related to the fault.	
SupportCapabilityID	SupportCapabilityID_Type	Repeated
Description	Indicates the unique ID of a SupportCapability related to the fault.	
ComponentID	ComponentID_Type	Repeated
Description	Indicates the unique ID of a Component related to the fault. When multiple components are identified, it should be inferred that each Component has been individually determined to be related to the fault. In situations where the Subsystem has not yet been able to isolate the fault to individual components, the sibling AmbiguityGroup element should be used.	
AmbiguityGroup	SubsystemFaultAmbiguityGroupType	Repeated
Description	Indicates that a fault has been narrowed down to a set of components, but not yet fully isolated. Separate AmbiguityGroups can be provided when it is desirable to associate	

	specific tests with a subset of the set of components.
--	--

Table A-4-1272: Mission Systems Interface MA_FaultMT - FaultInformation UCI Extension Field

Severity	
Description	The severity of the fault. This enumeration is modified for Mission Autonomy adaptation.
Base Type	MA_FaultSeverityEnum
Message Structure	
Enumeration Literal	Description
NOMINAL	A fault that carries the nominal level indicates that fault does not impact the current mission but may indicate something that should be checked in maintenance. Faults should be tagged as nominal if they are targeting maintenance. An example might be air filter hasn't been changed in 5000 hours or queue length reached 60% of max.
ADVISORY	A fault that is important but is not a Caution or Warning; this can be a configuration change, a condition that is contributing to a degraded aircraft or subsystem operation, or an anomaly that is being automatically controlled or corrected by a higher level system.
CAUTION	A fault that is indicative of a condition that, without a timely and correct response, could result in equipment damage or failure of mission.
WARNING	A fault that is indicative of a condition requiring immediate response or attention to prevent loss of aircraft, or failure of mission.
FAILED	A fault that carries a failed level indicates the failure of a component which may preclude the use of a capability. Faults should be tagged with failed if the component state will be marked faulted. Failed components may or may not prevent the completion of the mission.

Table A-4-1273: Mission Systems Interface MA_FaultMT - Severity UCI Extension Field

4.4.18 MA_MessagingSubscriptionSettingCommandStatusMT UCI Extension

MA_MessagingSubscriptionSettingCommandStatusMT	
Description	Command status message in response to MA_MessagingSubscriptionSettingCommand. See the XSD File for more info
Ext. Fields	MessageData : MA_MessagingSubscriptionSettingCommandStatusMDT

Table A-4-1274: Mission Systems Interface MA_MessagingSubscriptionSettingCommandStatusMT UCI Extension

MessageData	
Description	Command status message in response to MA_MessagingSubscriptionSettingCommand
Base Type	MA_MessagingSubscriptionSettingCommandStatusMDT
Message Structure	

Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-1275: Mission Systems Interface MA_MessagingSubscriptionSettingCommandStatusMT - MessageData UCI Extension Field

4.4.19 MA_RxDataPayloadMT UCI Extension

MA_RxDataPayloadMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_RxDataPayloadMDT

Table A-4-1276: Mission Systems Interface MA_RxDataPayloadMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_RxDataPayloadMDT	
Message Structure		
Field Name	Field Type	Field Usage
RxDataPayloadID	MA_RxDataPayloadID_Type	Required
Description	Indicate the unique ID assigned to this DataPayload.	
DataPayloadOriginatorID	SystemID_Type	Required
Description	Indicates the unique network endpoint that is identified as the originator for the encoded payload. This field represents the original source of the payload, not the immediate sender.	
EncodedPayload	hexBinary	Required
Description	Represents the encoded data payload received by the DMS.	
Timestamp	DateTimeType	Required

Description	Indicates the time at which the encoded message was initially received.	
MessageType	MessageTypeEnum	Required
Description	Indicates the UCI type of message in the EncodedPayload.	
Priority	ComparableRankingType	Optional
Description	Indicates the precedence and priority levels of the particular data payloads being sent.	
MessageExpiry	DateTimeType	Optional
Description	Indicates the time at which the encoded message is expired.	
DestinationRouting	MA_DestinationHandlingEnum	Required
Description	Indicates whether the message was routed only to the listed SpecificDestinationIDs or to both the topic which corresponds to the listed MessageType and also to any SpecificDestinationIDs.	
SpecificDestinationID	SystemID_Type	Repeated
Description	Indicates a unique network endpoint that is identified as a destination for the encoded payload.	

Table A-4-1277: Mission Systems Interface MA_RxDataPayloadMT - MessageData UCI Extension Field

4.4.20 MA_TxDataPayloadCommandStatusMT UCI Extension

MA_TxDataPayloadCommandStatusMT	
Description	Command status message in response to MA_TxDataPayloadCommand. See the XSD File for more info
Ext. Fields	MessageData : MA_TxDataPayloadCommandStatusMDT

Table A-4-1278: Mission Systems Interface MA_TxDataPayloadCommandStatusMT UCI Extension

MessageData		
Description	Command status message in response to MA_TxDataPayloadCommand	
Base Type	MA_TxDataPayloadCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
DestinationTransmissionStatus	MA_TransmissionStatusType	Repeated
Description	Each occurrence represents the transmission status of the message to a specific destination.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the	

	Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-1279: Mission Systems Interface MA_TxDataPayloadCommandStatusMT - MessageData UCI Extension Field

4.4.21 MA_WEZ_MT UCI Extension

MA_WEZ_MT	
Description	This message represents a single Weapon Engagement Zone (WEZ). The WEZ represents a less dynamic capability than the DLZ for air to air engagements and is not reliant on target state data to be produced. See the XSD File for more info
Ext. Fields	MessageData : MA_WEZ_MDT WEZ_ID : MA_WEZ_ID_Type WEZ_Data : MA_WEZ_DataType RangeTurnAndClose : MA_WeaponRangeType RangeMinimum : MA_WeaponRangeType RangeTurnAndRun : MA_WeaponRangeType RangeProbabilityOfIntercept : MA_WeaponRangeType RangeMaxGuidance : MA_WeaponRangeType RangeOptimal : MA_WeaponRangeType RangeMaxAero : MA_WeaponRangeType

Table A-4-1280: Mission Systems Interface MA_WEZ_MT UCI Extension

MessageData		
Description	This represents the characteristics that identify and describe a single Weapon Engagement Zone (WEZ).	
Base Type	MA_WEZ_MDT	
Message Structure		
Field Name	Field Type	Field Usage
WEZ_ID	MA_WEZ_ID_Type	Required
Description	This is an ID to uniquely identify the Weapon Engagement Zone (WEZ).	
WEZ_RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
CapabilityID	CapabilityID_Type	Optional
Description	Indicates the weapon Capability instance that this WEZ is associated with.	
GeneratedByWeapon	boolean	Optional

Description	This element indicates if the WEZ was generated using payload algorithms.	
WEZ_Data	MA_WEZ_DataType	Required
Description	Indicates WEZ range calculations for air-to-air engagement assessments.	

Table A-4-1281: Mission Systems Interface MA_WEZ_MT - MessageData UCI Extension Field

WEZ_ID		
Description	This is an ID to uniquely identify the Weapon Engagement Zone (WEZ).	
Base Type	MA_WEZ_ID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1282: Mission Systems Interface MA_WEZ_MT - WEZ_ID UCI Extension Field

WEZ_Data		
Description	Indicates WEZ range calculations for air-to-air engagement assessments.	
Base Type	MA_WEZ_DataType	
Message Structure		
Field Name	Field Type	Field Usage
RangeTurnAndClose	MA_WeaponRangeType	Repeated
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-close maneuver RangeTurnAndClose is not applicable to ballistic trajectory targets.	
RangeMinimum	MA_WeaponRangeType	Repeated
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	

RangeTurnAndRun	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-run maneuver RangeTurnAndRun is not applicable to ballistic trajectory targets.	
RangeProbabilityOfIntercept	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeMaxGuidance	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeOptimal	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeMaxAero	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for:	

	1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
TimeToRelease	TimeType	Required
Description	The seconds time to activate for the proposed launch store type.	
TimeOfActivation	TimeType	Optional
Description	The time of weapon seeker activation, assuming no platform guidance or weapon errors, for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No post-launch target maneuvers	

Table A-4-1283: Mission Systems Interface MA_WEZ_MT - WEZ_Data UCI Extension Field

RangeTurnAndClose		
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-close maneuver RangeTurnAndClose is not applicable to ballistic trajectory targets.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1284: Mission Systems Interface MA_WEZ_MT - RangeTurnAndClose UCI Extension Field

RangeMinimum	
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed)

	3.No target maneuvers	
	Note: ballistic trajectory velocity changes are not considered maneuvers.	
Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1285: Mission Systems Interface MA_WEZ_MT - RangeMinimum UCI Extension Field

RangeTurnAndRun		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-run maneuver RangeTurnAndRun is not applicable to ballistic trajectory targets.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1286: Mission Systems Interface MA_WEZ_MT - RangeTurnAndRun UCI Extension Field

RangeProbabilityOfIntercept		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	

Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1287: Mission Systems Interface MA_WEZ_MT - RangeProbabilityOfIntercept UCI Extension Field

RangeMaxGuidance		
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1288: Mission Systems Interface MA_WEZ_MT - RangeMaxGuidance UCI Extension Field

RangeOptimal		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
	Base Type	
MA_WeaponRangeType		
Message Structure		
Field Name	Field Type	Field Usage

Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1289: Mission Systems Interface MA_WEZ_MT - RangeOptimal UCI Extension Field

RangeMaxAero		
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1290: Mission Systems Interface MA_WEZ_MT - RangeMaxAero UCI Extension Field

4.4.22 MA_WEZ_RequestStatusMT UCI Extension

MA_WEZ_RequestStatusMT	
Description	This message provides status for a previously submitted MA_WEZ_Request. See the XSD File for more info
Ext. Fields	MessageData : MA_WEZ_RequestStatusMDT WeaponEngagementZone : MA_WEZ_MDT WEZ_ID : MA_WEZ_ID_Type WEZ_Data : MA_WEZ_DataType RangeTurnAndClose : MA_WeaponRangeType RangeMinimum : MA_WeaponRangeType RangeTurnAndRun : MA_WeaponRangeType RangeProbabilityOfIntercept : MA_WeaponRangeType RangeMaxGuidance : MA_WeaponRangeType RangeOptimal : MA_WeaponRangeType

RangeMaxAero : MA_WeaponRangeType

Table A-4-1291: Mission Systems Interface MA_WEZ_RequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_WEZ_RequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
WeaponEngagementZone	MA_WEZ_MDT	Repeated
Description	This element defines the response to a WEZ assessment request.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-1292: Mission Systems Interface MA_WEZ_RequestStatusMT - MessageData UCI Extension Field

WeaponEngagementZone		
Description	This element defines the response to a WEZ assessment request.	
Base Type	MA_WEZ_MDT	
Message Structure		
Field Name	Field Type	Field Usage
WEZ_ID	MA_WEZ_ID_Type	Required
Description	This is an ID to uniquely identify the Weapon Engagement Zone (WEZ).	
WEZ_RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
CapabilityID	CapabilityID_Type	Optional
Description	Indicates the weapon Capability instance that this WEZ is associated with.	
GeneratedByWeapon	boolean	Optional
Description	This element indicates if the WEZ was generated using payload algorithms.	
WEZ_Data	MA_WEZ_DataType	Required
Description	Indicates WEZ range calculations for air-to-air engagement assessments.	

Table A-4-1293: Mission Systems Interface MA_WEZ_RequestStatusMT - WeaponEngagementZone UCI Extension Field

WEZ_ID		
Description	This is an ID to uniquely identify the Weapon Engagement Zone (WEZ).	
Base Type	MA_WEZ_ID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1294: Mission Systems Interface MA_WEZ_RequestStatusMT - WEZ_ID UCI Extension Field

WEZ_Data		
Description	Indicates WEZ range calculations for air-to-air engagement assessments.	
Base Type	MA_WEZ_DataType	
Message Structure		
Field Name	Field Type	Field Usage
RangeTurnAndClose	MA_WeaponRangeType	Repeated
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-close maneuver RangeTurnAndClose is not applicable to ballistic trajectory targets.	
RangeMinimum	MA_WeaponRangeType	Repeated
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeTurnAndRun	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering	

	2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-run maneuver RangeTurnAndRun is not applicable to ballistic trajectory targets.	
RangeProbabilityOfIntercept	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeMaxGuidance	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeOptimal	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
RangeMaxAero	MA_WeaponRangeType	Repeated
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers,	

	Note: ballistic trajectory velocity changes are not considered maneuvers.	
TimeToRelease	TimeType	Required
Description	The seconds time to activate for the proposed launch store type.	
TimeOfActivation	TimeType	Optional
Description	The time of weapon seeker activation, assuming no platform guidance or weapon errors, for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No post-launch target maneuvers	

Table A-4-1295: Mission Systems Interface MA_WEZ_RequestStatusMT - WEZ_Data UCI Extension Field

RangeTurnAndClose		
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-close maneuver RangeTurnAndClose is not applicable to ballistic trajectory targets.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1296: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeTurnAndClose UCI Extension Field

RangeMinimum	
Description	Launch slant range at which the weapon will intercept the target and arm its fuze, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.

Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1297: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeMinimum UCI Extension Field

RangeTurnAndRun		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.Target turn-and-run maneuver RangeTurnAndRun is not applicable to ballistic trajectory targets.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1298: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeTurnAndRun UCI Extension Field

RangeProbabilityOfIntercept		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for:	
	1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers Note: ballistic trajectory velocity changes are not considered maneuvers.	
Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage

Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1299: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeProbabilityOfIntercept UCI Extension Field

RangeMaxGuidance		
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Current steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
Base Type	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1300: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeMaxGuidance UCI Extension Field

RangeOptimal		
Description	Launch range at which the weapon will intercept the target with high energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required

Description	Indicates the azimuth the slant range pertains to.
-------------	--

Table A-4-1301: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeOptimal UCI Extension Field

RangeMaxAero		
Description	Launch range at which the weapon will intercept the target with nominal energy, assuming no platform guidance or weapon guidance errors for: 1.Optimal steering 2.Current shooter kinematic conditions (e.g., altitude/airspeed) 3.No target maneuvers, Note: ballistic trajectory velocity changes are not considered maneuvers.	
	MA_WeaponRangeType	
Message Structure		
Field Name	Field Type	Field Usage
Range	DistanceType	Required
Description	Indicates the slant range of the weapon.	
Azimuth	AngleType	Required
Description	Indicates the azimuth the slant range pertains to.	

Table A-4-1302: Mission Systems Interface MA_WEZ_RequestStatusMT - RangeMaxAero UCI Extension Field

4.4.23 MA_StrikeActivityMT UCI Extension

MA_StrikeActivityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	ActiveWeaponHSA_CSA : MA_HSA_CSA_Type Direction : MA_DirectionChoiceType MunitionActive : MA_MunitionActiveType MessageData : MA_StrikeActivityMDT ActiveWeaponState : MA_ActiveWeaponStateEnum Activity : MA_StrikeActivityType Course : MA_DirectionReferenceType Heading : MA_DirectionReferenceType Reference : MA_HeadingReferenceEnum

Table A-4-1303: Mission Systems Interface MA_StrikeActivityMT UCI Extension

ActiveWeaponHSA_CSA	
Description	Provides the heading/course, speed, and altitude of the munition while the Activity is ACTIVE_*

Base Type	MA_HSA_CSA_Type	
Message Structure		
Field Name	Field Type	Field Usage
Altitude	AltitudeReferenceType	Optional
Description	Altitude hold value to be achieved and reference to altitude measurement source.	
Speed	PathSegmentSpeedType	Optional
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Direction	MA_DirectionChoiceType	Optional
Description	Defines heading or course type and reference to hold	

Table A-4-1304: Mission Systems Interface MA_StrikeActivityMT - ActiveWeaponHSA_CSA UCI Extension Field

Direction		
Description	Defines heading or course type and reference to hold	
Base Type	MA_DirectionChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
Heading	MA_DirectionReferenceType	Optional
Description	Defines heading type and reference to hold.	
Course	MA_DirectionReferenceType	Optional
Description	Defines course type and reference to hold.	

Table A-4-1305: Mission Systems Interface MA_StrikeActivityMT - Direction UCI Extension Field

MunitionActive		
Description	Data regarding the munition while it is active or in flight.	
Base Type	MA_MunitionActiveType	
Message Structure		
Field Name	Field Type	Field Usage
ActiveWeaponState	MA_ActiveWeaponStateEnum	Repeated
Description	Provides further munition state data detail if the Activity is ENABLED, ACTIVE_* or COMPLETED as reported by the ActivityState. This message can be omitted if ActivityState is DISABLED, FAILED or DELETED. List size for this element is based on "Select All That Apply" condition.	
ActiveWeaponHSA_CSA	MA_HSA_CSA_Type	Optional
Description	Provides the heading/course, speed, and altitude of the munition while the Activity is ACTIVE_*.	

Table A-4-1306: Mission Systems Interface MA_StrikeActivityMT - MunitionActive UCI Extension Field

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.

Base Type	MA_StrikeActivityMDT	
Message Structure		
Field Name	Field Type	Field Usage
SubsystemID	SubsystemID_Type	Required
Description	Indicates the Subsystem which hosts the Strike Capabilities whose Activities are given in this message.	
Activity	MA_StrikeActivityType	Repeated
Description	Indicates the dynamic operational characteristics of an Activity of a Strike Capability.	

Table A-4-1307: Mission Systems Interface MA_StrikeActivityMT - MessageData UCI Extension Field

ActiveWeaponState	
Description	Provides further munition state data detail if the Activity is ENABLED, ACTIVE_* or COMPLETED as reported by the ActivityState. This message can be omitted if ActivityState is DISABLED, FAILED or DELETED. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_ActiveWeaponStateEnum
Message Structure	
Enumeration Literal	Description
TARGETED	Indicates that a target has been selected and the munition has not been released yet. Report with the ENABLED state generated by ActivityStateEnum.
REQUESTED	Indicates the munition has been requested for release. Report with the ENABLED state generated by ActivityStateEnum.
SEEKER_INACTIVE	Indicates the munition has been released but its local seeker has not been activated. Report with the ACTIVE_* state generated by ActivityStateEnum.
SEEKER_ACTIVE	Indicates the munition has been released and its local seeker has been activated. Report with the ACTIVE_* state generated by ActivityStateEnum.
FUZE_INACTIVE	Indicates the munition has been released but its fuze has not been activated. Report with the ACTIVE_* state generated by ActivityStateEnum.
FUZE_ACTIVE	Indicates the munition has been released and its fuze has been activated. Report with the ACTIVE_* state generated by ActivityStateEnum.
NOT_FULLY_AUTONOMOUS	Indicates the munition has been released not fully autonomous and thus not able to guide without datalink or target destination. Report with the ACTIVE_* state generated by ActivityStateEnum.
FULLY_AUTONOMOUS	Indicates the munition has been released and is fully autonomous and able guide without datalink or target destination. Report with the ACTIVE_* state generated by ActivityStateEnum.
DEFEATED	Indicates the munition has been released and but it has been out maneuvered by the assigned target. Report with the COMPLETED state generated by ActivityStateEnum.
TIMED_OUT	Indicates the munition flight has ended, and it did not intercept the assigned target. Report with the COMPLETED state generated by ActivityStateEnum.
SUCCESS	Indicates the munition flight has ended, and it intercepted the assigned target. Report with the COMPLETED state generated by ActivityStateEnum.

Table A-4-1308: Mission Systems Interface MA_StrikeActivityMT - ActiveWeaponState UCI Extension Field

Activity		
Description	Indicates the dynamic operational characteristics of an Activity of a Strike Capability.	
Base Type	MA_StrikeActivityType	
Message Structure		
Field Name	Field Type	Field Usage
SelectedForKeyLoad	boolean	Required
Description	Key Load indicates the store has been put into a state where it is ready to receive cryptographic keys.	
WeaponArmed	boolean	Required
Description	When true, the weapon is in the armed state.	
ReadyForRelease	boolean	Required
Description	The store has been prepared for launch such that when released the store will function properly.	
SelectedForRelease	boolean	Required
Description	When Master Arm, Release Consent, and any LAR or vehicle Attitude parameters enforced by the carriage are all met, this store will be released.	
SelectedForJettison	boolean	Required
Description	Jettison indicates an ejection from the host system without powering or preparing the delivery vehicle. The store will be in an inert state. When Master Arm, Release Consent, and any LAR or vehicle attitude parameters enforced by the carriage are all met, this store will be jettisoned.	
AssignedTarget	GeoLocatedObjectType	Optional
Description	Indicates the Entity target assigned to the StrikeCapability.	
AO_Code	AO_CodeType	Optional
Description	Indicates the current/set AO/laser PRF and/or PIM code.	
LAR_ID	LAR_ID_Type	Optional
Description	Indicates the ID of the associated LAR and/or LAR_Report associated with the Strike capability.	
ConsentRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) the Activity requires consent to transition from the ENABLED state to an ACTIVE state. This element is required and shall be TRUE for Activities associated with "mother may I" Capabilities.	
ConsentState	ConsentEnum	Optional
Description	Indicates the state of consent for the Activity. This element is required for Activities which require Consent.	
KineticFootprint	EnduranceFootprintType	Optional
Description	The estimated footprint of where the store may fall if released from the current position.	
TargetLockAcquired	boolean	Optional
Description	Indicated whether (TRUE) or not (FALSE) a lock on target has been acquired.	

MunitionActive	MA_MunitionActiveType	Optional
Description	Data regarding the munition while it is active or in flight.	
TimeToRelease	DurationType	Optional
Description	Time interval before strike capability is released.	

Table A-4-1309: Mission Systems Interface MA_StrikeActivityMT - Activity UCI Extension Field

Course		
Description	Defines course type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-1310: Mission Systems Interface MA_StrikeActivityMT - Course UCI Extension Field

Heading		
Description	Defines heading type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-1311: Mission Systems Interface MA_StrikeActivityMT - Heading UCI Extension Field

Reference	
Description	Reference to type of heading or course given.
Base Type	MA_HeadingReferenceEnum
Message Structure	
Enumeration Literal	Description
TRUE_NORTH	Heading value according to Geographic North.
MAGNETIC_NORTH	Heading value according to location where the planet's magnetic field points vertically downward.

Table A-4-1312: Mission Systems Interface MA_StrikeActivityMT - Reference UCI Extension Field

4.4.24 MA_AMTI_CapabilityMT UCI Extension

MA_AMTI_CapabilityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_AMTI_CapabilityMDT Capability : MA_AMTI_CapabilityType

Table A-4-1313: Mission Systems Interface MA_AMTI_CapabilityMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_AMTI_CapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_AMTI_CapabilityType	Repeated
Description	Indicates an installed AMTI Capability, its configurable characteristics and its controllability.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.	

Table A-4-1314: Mission Systems Interface MA_AMTI_CapabilityMT - MessageData UCI Extension Field

Capability		
Description	Indicates an installed AMTI Capability, its configurable characteristics and its controllability.	
Base Type	MA_AMTI_CapabilityType	
Message Structure		
Field Name	Field Type	Field Usage
MT_IIRS_Level	NIIRS_Type	Repeated
Description	Indicates a Moving Target Indication Interpretability Rating Scale level supported by the Capability. See annotations of the underlying type for further details.	
ComponentFieldOfRegard	ComponentFieldOfRegardType	Repeated
Description	Fields of Regard for each component in the capability.	
CapabilityType	AMTI_CapabilityEnum	Required

Description	Indicates the Capability's first tier type in the AMTI taxonomy. For AMTI, the first tier is an indication of the physical area covered. See enumerated type annotations for further details.	
SubCapabilityType	AMTI_SubCapabilityEnum	Repeated
Description	Indicates a SubCapability of the AMTI Capability; the second tier in the taxonomy of AMTI. For AMTI, the second tier is waveform category. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition. The selection of AUTO_SUBCAPABILITY_SELECT still requires the evaluation of all sibling attributes by the Capability.	
CapabilityOptions	AMTI_CapabilityOptionsType	Required
Description	Indicates the Capability's support for select optional elements in its accepted control interface messages. Support for these elements is expected to vary across Capability implementations but must be known in order to adapt and configure upstream Systems and Services which use the Capability.	
SupportedFrequencies	FrequencyRangeType	Repeated
Description	Indicates a frequency range used by the Capability.	
MessageOutput	AMTI_MessageOutputsEnum	Repeated
Description	Indicates a message that is an output of the Capability. See enumerated type annotations for details. List size for this element is based on "Select All That Apply" condition.	
AcceptedInterface	CapabilityControlInterfacesEnum	Repeated
Description	Indicates an accepted control interface for the Capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CommsRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) communications are required to use the Capability. Omitted is equivalent to FALSE. For example, an unmanned system with no onboard storage would require communications to disseminate the outputs of the Capability.	
CapabilityID	CapabilityID_Type	Required
Description	Indicates the unique ID of this Capability. This ID is used to invoke the Capability via Command messages, report its activity via Activity messages, etc.	
DomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates the domain/environment which the Capability is employed from and the "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
ProductOutput	ProductOutputType	Repeated
Description	Indicates a Product that can be an output of the Capability.	
PackageOperation	PackageOperationEnum	Optional
Description	Indicates if and how the operation of the Capability can be coordinated with a partner Capability of another System in a multi-System Package. Omitting this element is equivalent to the enumerate NO_PACKAGE_OPERATION. The actual Package configuration including per-Capability partnering between Systems is given in the PackageStatus message. For example, a System that can perform cooperative geolocation could advertise with this element in the ESM_Capability message. A	

	System that can navigate in a swarm with other Systems could advertise with this element in the FlightCapability message.
--	---

Table A-4-1315: Mission Systems Interface MA_AMTI_CapabilityMT - Capability UCI Extension Field

4.4.25 MA_MessagingSubscriptionStatusMT UCI Extension

MA_MessagingSubscriptionStatusMT	
Description	This message reports the active message subscriptions which may be activated, deactivated, or deleted via MA_MessagingSubscriptionSettingCommand. See the XSD File for more info
Ext. Fields	MessageData : MA_MessagingSubscriptionStatusMDT

Table A-4-1316: Mission Systems Interface MA_MessagingSubscriptionStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_MessagingSubscriptionStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
TopicSubscription	MA_TopicSubscriptionType	Repeated
Description	Indicates details of an existing topic subscription.	

Table A-4-1317: Mission Systems Interface MA_MessagingSubscriptionStatusMT - MessageData UCI Extension Field

4.4.26 MA_MissionPlanValidationCommandMT UCI Extension

MA_MissionPlanValidationCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	Inputs : MA_MissionPlanValidationInputsType OpLineCategory : MA_OpLineCategoryEnum TaskType : MA_TaskTypeEnum CapabilityCommand : MA_CapabilityTypeEnum PlanPart : MA_PlanPartsType TaskPlan : MA_TaskPlanPartsType ActivityPlan : MA_ActivityPlanPartsType OpPlan : MA_OpPlanPartsType RouteActivityPlan : MA_ActivityPlanPartsType OpZoneCategory : MA_OpZoneCategoryEnum OpVolumeCategory : MA_OpZoneCategoryEnum

OrbitActivityPlan : MA_ActivityPlanPartsType
 MessageData : MA_MissionPlanValidationCommandMDT

Table A-4-1318: Mission Systems Interface MA_MissionPlanValidationCommandMT UCI Extension

Inputs		
Description	Indicates input parameters for performing MissionPlan validation.	
Base Type	MA_MissionPlanValidationInputsType	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MissionPlanID_Type	Required
Description	Indicates the unique ID of the MissionPlan to be validated.	
PlanType	PlanTypeEnum	Repeated
Description	Indicates which sub-*Plan types to include in MissionPlan validation. If omitted, all sub-*Plans should be validated. List size for this element is based on "Select All That Apply" condition.	
PlanPart	MA_PlanPartsType	Optional
Description	Indicates which part or parts to include in MissionPlan validation. If omitted, all Parts should be validated.	
ValidateSubordinateMissionPlans	boolean	Required
Description	Indicates whether (TRUE) or not (FALSE) subordinate MissionPlans should be validated along with the parent MissionPlan given by the sibling PlanID.	
PlanningProcessID	PlanningProcessID_Type	Required
Description	ID of the Planning Process to be used for validation.	
ModifyToValidate	boolean	Required
Description	Indicates whether (TRUE) or not (FALSE) portions of the associated plan, that are found to be invalid, should be modified to make the plan valid.	
ValidationWindow	TimeWindowType	Optional
Description	Indicates the time window, within the time period of the Plan, to validate. If omitted, the entire duration of the Plan should be validated. The child Duration element, when the child Range element is omitted, indicates a time window beginning at the start time of the Plan and ending at the relative Duration. Otherwise, the child Duration element is relative to the Range element if left open ended. If the child Range element is fully specified, the child Duration element should be omitted.	
WeatherAreaData	WeatherAreaDataType	Optional
Description	This element represents an override of the existing weather data available through UCI weather messages.	

Table A-4-1319: Mission Systems Interface MA_MissionPlanValidationCommandMT - Inputs UCI Extension Field

OpLineCategory	
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.

Base Type	MA_OpLineCategoryEnum
Message Structure	
Enumeration Literal	Description
GENERAL_LINE	A general line where the function must be described by other procedures.
FORWARD_EDGE_OF_BATTLE_AREA	The foremost limits of a series of areas in which ground combat units are deployed, excluding the areas in which the covering or screening forces are operating.
GUN_TARGET_LINE	Straight line from the gun or guns to the target. Altitude, if included, is the apex of the projectile.
CORRIDOR	Line with width describing the passageway designated for travel by friendly aircraft.
HOSTILE_BOUNDARY	Line that indicates a limit beyond which exists a hostile environment.
BUFFER_ZONE_BOUNDARY	Line beyond which friendly aircraft usually do not fly in peacetime.
LOW_LEVEL_TRANSIT_ROUTE	Line describing the center line of a route through the forward missile engagement zone that must be flown by friendly aircraft to ensure they are not designated hostile by defense systems.
TACTICAL_ACTION_LINE	Line positioned in hostile airspace which may be used in conjunction with other criteria for hostile determination.
FIRE_SUPPORT_COORDINATION_LINE	Line established by the appropriate ground commander to ensure coordination of fire not under his command but which may affect current tactical operations. Attacks against ground targets behind this line must be coordinated with the appropriate ground commander.
FORWARD_LINE_OF_OWN_TROOPS	Line defining the forward position of own troops within a ground area of responsibility, that does not usually coincide with the forward edge of battle area.
LINE_OF_COMMUNICATIONS	Line the route that connects an operating military unit with its supply base.
JETWAY	Line with width that defines areas where commercial aircraft are flying through.
DEPARTURE_RADIAL	Line the defines the departure radial when performing Carrier admin departures.
RECOVERY_RADIAL	Line the defines the recovery radial that is used to define the recovery marshal. May be used when performing Carrier admin recoveries.
FINAL_BEARING	Line the defines the final bearing when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.
BRC	Base Recovery Course defines the aircraft carrier heading when an aircraft is approaching a carrier. May be used when performing Carrier admin recoveries.

Table A-4-1320: Mission Systems Interface MA_MissionPlanValidationCommandMT - OpLineCategory UCI Extension Field

TaskType	
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_TaskTypeEnum

Message Structure	
Enumeration Literal	Description
AIR_SAMPLE	Indicates the task is to sample and analyze the air around the vehicle.
AMTI	Indicates the task is to track air targets using an Airborne Moving Target Indicator.
AO	Indicates the task is to employ an Active Optical capability.
CARGO_DELIVERY	Indicates the task is to deliver cargo.
CAP	Indicates the task is to execute a Combat Air Patrol.
COMINT	Indicates the task is to employ a communications intelligence capability.
COMM_RELAY	Indicates the task is to relay communications from other battlespace participants.
COUNTER_SPACE	Indicates the task is to employ a Counter Space Capability.
EA	Indicates the task is to employ an electronic attack capability.
ESCORT	Indicates the task is to escort another entity.
ESM	Indicates the task is to employ an Electronic Support Measure.
FLIGHT	Indicates the task is to fly.
ORBIT_CHANGE	Indicates a task to perform an orbit change via a spacecraft maneuver.
ORBITAL_SURVEILLANCE	Indicates a task to perform orbital surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates a task to perform orbital surveillance via sensor collection capabilities.
PO	Indicates the task is to employ a Passive Optical capability.
REFUEL	Indicates the task is to refuel another System or Entity.
SAR	Indicates the task is to employ a Synthetic Aperture Radar capability.
SMTI	Indicates the task is to track surface targets using a Surface Moving Target Indicator.
STRIKE	Indicates the task is to strike a target.
SYSTEM_DEPLOYMENT	Indicates the task is to deploy a system.
TACTICAL_ORDER	Indicates the task is to perform a tactical order.
WEATHER_RADAR	Indicates the task is to collect weather data.

Table A-4-1321: Mission Systems Interface MA_MissionPlanValidationCommandMT - TaskType UCI Extension Field

CapabilityCommand	
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_CapabilityTypeEnum
Message Structure	
Enumeration Literal	Description
ACTION	Indicates an action capability.

AIR_SAMPLE	Indicates an air sampling capability.
AMTI	Indicates an airborne moving target indication (AMTI) capability.
AO	Indicates an active optical capability.
CAP	Indicates a cargo delivery capability.
CARGO_DELIVERY	Indicates a cargo delivery capability.
COMINT	Indicates a Communications Intelligence (COMINT) capability.
COMM_RELAY	Indicates a communications relay capability.
COMM_TERMINAL	Indicates a communications terminal capability
COUNTER_SPACE	Indicates a Counter Space Capability.
EA	Indicates an electronic attack (EA) capability.
EFFECT	Indicates an effect capability.
ESM	Indicates an electronic support measures (ESM) capability.
FLIGHT	Indicates a capability for waypoint-based flight tasks/commands.
IFF	Indicates an Identification Friend or Foe (IFF) capability.
OPAQUE	Indicates a Opaque Capability
ORBIT_CHANGE	Indicates this space system has the ability to change orbits.
ORBITAL_SURVEILLANCE	Indicates a task to perform Orbital Surveillance.
ORBITAL_SURVEILLANCE_SENSOR	Indicates an Orbital Surveillance Sensor Capability.
PO	Indicates a passive optical capability.
RADAR_ALTIMETER	Indicates a Radar Altimeter capability
REFUEL	Indicates a capability to refuel another asset.
RESPONSE	Indicates an response capability.
SAR	Indicates a synthetic aperture radar (SAR) capability.
SMTI	Indicates a surface moving target indication (SMTI) capability.
STRIKE	Indicates a strike capability.
SYSTEM_DEPLOYMENT	Indicates a deployment capability.
TACTICAL_ORDER	Indicates a tactical order capability.
TASK	Indicates a task capability.
WEATHER_RADAR	Indicates a weather radar capability.

Table A-4-1322: Mission Systems Interface MA_MissionPlanValidationCommandMT - CapabilityCommand UCI Extension Field

PlanPart		
Description	Indicates which part or parts to include in MissionPlan validation. If omitted, all Parts should be validated.	
Base Type	MA_PlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage

ActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable ActivityPlan parts.	
RoutePlan	RoutePlanPartsType	Optional
Description	Indicates applicable RoutePlan parts.	
RouteActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable RouteActivityPlan parts.	
OrbitPlan	OrbitPlanPartsType	Optional
Description	Indicates applicable OrbitPlan parts.	
OrbitActivityPlan	MA_ActivityPlanPartsType	Optional
Description	Indicates applicable OrbitActivityPlan parts.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-1323: Mission Systems Interface MA_MissionPlanValidationCommandMT - PlanPart UCI Extension Field

TaskPlan		
Description	Indicates applicable TaskPlan parts.	
Base Type	MA_TaskPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
TaskType	MA_TaskTypeEnum	Repeated
Description	Indicates a Task type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	

Table A-4-1324: Mission Systems Interface MA_MissionPlanValidationCommandMT - TaskPlan UCI Extension Field

ActivityPlan		
Description	Indicates applicable ActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated

Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-1325: Mission Systems Interface MA_MissionPlanValidationCommandMT - ActivityPlan UCI Extension Field

OpPlan		
Description	Indicates applicable OpPlan parts.	
Base Type	MA_OpPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
OpPointCategory	OpPointCategoriesType	Repeated
Description	Indicates an OpPoint type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpLineCategory	MA_OpLineCategoryEnum	Repeated
Description	Indicates an OpLine type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpZoneCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	

OpVolumeCategory	MA_OpZoneCategoryEnum	Repeated
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.	
OpRouting	EmptyType	Optional
Description	Indicates an OpRouting is applicable to the associated *Plan. List size for this element is based on there being no category type for OpRouting objects	

Table A-4-1326: Mission Systems Interface MA_MissionPlanValidationCommandMT - OpPlan UCI Extension Field

RouteActivityPlan		
Description	Indicates applicable RouteActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-1327: Mission Systems Interface MA_MissionPlanValidationCommandMT - RouteActivityPlan UCI Extension Field

OpZoneCategory	
Description	Indicates an OpZone type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.
IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.

KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.
WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.

WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.
---------------------------	--

Table A-4-1328: Mission Systems Interface MA_MissionPlanValidationCommandMT - OpZoneCategory UCI Extension Field

OpVolumeCategory	
Description	Indicates an OpVolume type applicable to the associated *Plan. List size for this element is based on "Select All That Apply" condition.
Base Type	MA_OpZoneCategoryEnum
Message Structure	
Enumeration Literal	Description
AIRBORNE_EARLY_WARNING	A point at which AEW aircraft are or will be orbiting or maneuvering.
COMBAT_AIR_PATROL	A point at which CAP aircraft are or will be orbiting or maneuvering.
CONSTRAINED_ENTRY_EXIT	Indicates an area with constrained entries and exits. The additional parameters used with this zone category are defined in the ConstrainedEntryExitType choice in OpZoneCategoryType.
CONTAMINATED	Indicates the zone is contaminated, an area caused by the deposit and/or absorption of radioactive material, or of biological or chemical agents on and by structures, areas, personnel, or objects.
DANGER	A specified area above, below, or within which there may be a potential danger.
DEFENDED_AREA	An area the source tn is capable of defending against ballistic missiles, etc.,(i.e. the source tn is operational with ready weapons and has designated the area for defense).
DIRECTED_SEARCH_AREA	Indicates the zone is a directed search area.
EOB	Indicates the zone is the boundary for an electronic order of battle request.
EXERCISE	An area for military maneuver or simulated wartime operation involving planning, preparation and execution.
FIGHTER_ENGAGE_AOR	Indicates the zone is a fighter area of responsibility (AOR), an airspace of defined dimensions within which the responsibility for engagement normally rests with fighter aircraft.
FILTER_AREA	Indicates a geographic area of interest for the purpose of limiting data. The additional parameters used with this zone category are defined in the OpZoneFilterAreaPET choice in OpZoneCategoryType.
GENERAL_HAZARD	Indicates the zone is a hazard area that doesn't have a specified operational purpose.
GENERAL_STATION	A general zone describing an air station that must be amplified by voice or predetermined procedures.
GROUND_AOR	Indicates the zone is a ground area of responsibility (AOR), an area of ground within which the responsibility for engagement normally rests with the appropriate ground force commander.
HOSTILE_TACTICAL_AREA	Indicates the zone is a hostile tactical area, an area in which hostile tactical forces (to include ground, air, or maritime) are known to be or will be operating.
HOSTILE_WEAPON	Indicates the zone is a hostile weapon zone, an area in which hostile air defense systems are capable of engagement.

IMPACT_POINT	The real or expected point that a device has or will penetrate or contact a surface.
JAMMING	Indicates the zone is a jamming control zone. The additional parameters used with this zone category are defined in the OpZoneJammingType choice in OpZoneCategoryType.
KEEP_IN	Indicates the zone is a boundary within which applicable systems must stay. The additional parameters used with this zone category are defined in the IngressEgressType choice in OpZoneCategoryType.
KILL	Indicates the zone is a kill zone, an air defense system (SOC) area in which friendly fighters may use less restrictive rules of engagement.
MISSILE_ENGAGEMENT	Indicates the zone is a missile engagement zone, a primary engagement area designated for friendly surface to air missiles.
MISSILE_LAUNCH_POINT	A point indicating the position from which a missile has been or will be launched. The additional parameters used with this zone category are defined in the OpZoneMissileLaunchDataType choice in OpZoneCategoryType.
MISSION_AREA	Indicates the zone is an area in which a mission will take place.
NAMED_AREA_OF_INTEREST	An area usually along an enemy mobility corridor where enemy activity (or inactivity) confirms a particular course of action.
NO_COMM	Indicates the zone is an area where communications use is restricted.
NO_FIRE	Indicates the zone is an area where strike impact is restricted; the zone does not restrict the launch of weapons. The additional parameters used with this zone category are defined in the OpZoneNoFireType choice in OpZoneCategoryType.
NO_FLY	Indicates the zone is an area where flight is restricted. The additional parameters used with this zone category are defined in the OpZoneNoFlyType choice in OpZoneCategoryType.
NO_IMAGE	Indicates the zone is an area where image collection is restricted.
ORBIT_FIGURE_EIGHT	A figure eight pattern within a rectangle that the aircraft is or will be tracking.
ORBIT_RACE_TRACK	An oval within a rectangle that the aircraft is or will be tracking.
ORBIT_RANDOM_CLOSED	A rectangle in which the aircraft will track randomly.
REFERENCE	Indicates the zone is an area that doesn't have a specified operational purpose.
SEARCH	An area where a search is being or will be conducted. normally associated with a SAR mission.
SEPARATION	Indicates an update in reservation volume for an individual vehicle.
SHORAD	Indicates the zone is a short range area defense (SHORAD), an area defended by friendly army short range air defense systems.
SPEED_LIMITS	An area where platform speeds are limited. The additional parameters used with this zone category are defined in the OpZoneSpeedLimitType choice in OpZoneCategoryType.
SUBMARINE_PATROL_AREA	A restricted area established to allow submarine operations to be unimpeded by the operation, or possible attack from friendly forces in wartime, or to be conducted without submerged mutual interference in peacetime.
TARGET_AREA_OF_INTEREST	An engagement area usually along an enemy mobility corridor.
VEHICLE_CONFIGURATION	Indicates the zone is a region where specific vehicle configuration parameters should be changed. The additional parameters used with this zone category are defined in the VehicleCommandDataType choice in OpZoneCategoryType.

WEAPON_RESTRICTION	Indicates the zone is an area within which a set of restricted weapons cannot be used against a target type and/or within in the zone. The additional parameters used with this zone category are defined in the OpZoneWeaponRestrictionType choice in OpZoneCategoryType.
WEATHER_CONDITIONS	Indicates the zone is an area within which weather conditions have a potential for mission impact. The additional parameters used with this zone category are defined in the OpZoneWeatherType choice in OpZoneCategoryType.

Table A-4-1329: Mission Systems Interface MA_MissionPlanValidationCommandMT - OpVolumeCategory UCI Extension Field

OrbitActivityPlan		
Description	Indicates applicable OrbitActivityPlan parts.	
Base Type	MA_ActivityPlanPartsType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityCommand	MA_CapabilityTypeEnum	Repeated
Description	Indicates an applicable CapabilityCommand-based planned Activity type; a [*Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
SupportingCapabilityCommand	SupportCapabilityTypeEnum	Repeated
Description	Indicates an applicable Supporting CapabilityCommand-based planned Activity type; a [*Supporting Capability]Command type applicable to the *ActivityPlan. List size for this element is based on "Select All That Apply" condition.	
VehicleSettings	EmptyType	Optional
Description	Indicates VehicleSettings are applicable to the *ActivityPlan.	
CommsUsage	EmptyType	Optional
Description	Indicates Comms usage is applicable to the *ActivityPlan.	
ProductTasks	EmptyType	Optional
Description	Indicates Task or Tasks for Product management (ProductDisseminationTask, ProductClassificationTask, etc.) are applicable to the *ActivityPlan.	
EffectPlan	EffectPlanPartsType	Optional
Description	Indicates applicable EffectPlan parts.	
ActionPlan	ActionPlanPartsType	Optional
Description	Indicates applicable ActionPlan parts.	
TaskPlan	MA_TaskPlanPartsType	Optional
Description	Indicates applicable TaskPlan parts.	
ResponsePlan	ResponsePlanPartsType	Optional
Description	Indicates applicable ResponsePlan parts.	
OpPlan	MA_OpPlanPartsType	Optional
Description	Indicates applicable OpPlan parts.	

Table A-4-1330: Mission Systems Interface MA_MissionPlanValidationCommandMT - OrbitActivityPlan UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanValidationCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Inputs	MA_MissionPlanValidationInputsType	Required
Description	Indicates input parameters for performing MissionPlan validation.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates any *Plan modified is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
RequestFrequencyType	RepeatEnum	Required
Description	Indicates whether this request for validation is a request for a single reply, or a request for periodic validation with a corresponding request to cease periodic validation.	
RequestFrequencyPeriod	DurationType	Optional
Description	If requesting periodic validation, this field specifies the amount of time that should elapse between the periodic validation, i.e. the repetition time interval of the validation.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-1331: Mission Systems Interface MA_MissionPlanValidationCommandMT - MessageData UCI Extension Field

4.4.27 MA_MissionPlanValidationCommandStatusMT UCI Extension

MA_MissionPlanValidationCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_MissionPlanValidationCommandStatusMDT

Table A-4-1332: Mission Systems Interface MA_MissionPlanValidationCommandStatusMT UCI Extension

MessageData	
Description	Indicates the data being conveyed by the message.
Base Type	MA_MissionPlanValidationCommandStatusMDT
Message Structure	

Field Name	Field Type	Field Usage
MissionPlanValidationID	MissionPlanValidationID_Type	Optional
Description	MissionPlanValidation message associated with this CommandStatus.	
CommandStatus	ProcessingStatusEnum	Optional
Description	Indicates the status of the processing of the command after the command has reached a RECEIVED state in the prior state machine.	
CompletionStatus	CompletionStatusType	Optional
Description	Indicates actual and predicted metrics for completion of the command.	
IncompleteItem	IncompleteProcessingType	Repeated
Description	Indicates items associated with command processing that failed to complete. For example if a particular required Capability wasn't available, it could be referenced here. This element/type is highly flexible. It can reference almost any message/concept in UCI as a planning issue. The wide range of messages/concepts it can reference makes it 1) difficult to use as a basis for software/services to resolve the issue but 2) an excellent general method for processing algorithms to convey issues to operators. This element shouldn't be used to report processing issues/results that are more directly indicated by other processing status elements. For example, for planning processing, other elements focus specifically on per-Requirement allocation results therefore this element shouldn't be used for per-Requirement allocation results.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-1333: Mission Systems Interface MA_MissionPlanValidationCommandStatusMT - MessageData UCI Extension Field

4.4.28 MA_SystemNotificationMT UCI Extension

MA_SystemNotificationMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_SystemNotificationMDT NotificationDetail : CannotComplyType NotificationDetail : CannotComplyType

Table A-4-1334: Mission Systems Interface MA_SystemNotificationMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_SystemNotificationMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemSubjectIDs	MA_PackageSystemType	Required
Description	Indicates the subject of the Notification, the thing which the Notification is about.	
SystemPerspective	NotificationPerspectiveEnum	Repeated
Description	Indicates a perspective (characteristic, behavior and/or change) of the Subject that is the basis of the Notification. List size for this element is based on "Select All That Apply" condition.	
AssociatedMessage	AssociatedMessageType	Repeated
Description	Indicates a message that is associated with the Notification.	
NotificationDetail	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the unsuccessful processing of the sibling AssociatedMessage element. This element is only expected when the Associated Message processing is not successful	
NotificationID	NotificationID_Type	Required
Description	Indicates the unique ID of the Notification.	
NotificationState	NotificationStateEnum	Required
Description	Indicates the current state within an enumerated state machine that characterizes the life cycle of a notification.	
Timestamp	DateTimeType	Required
Description	The time at which the Notification was originally triggered (ex: event time).	
Source	NotificationSourceType	Required
Description	Indicates the originating source of the Notification.	
Severity	NotificationSeverityEnum	Required
Description	Indicates the overall severity of the notification. Informational notifications are meant to provide informational context of events. Indicates the existence of a hazardous condition requiring immediate action to prevent loss of life, equipment damage, or abortion of the mission. Critical notifications indicate the need for immediate attention.	
AppliesTo	SubjectType	Repeated
Description	Indicates an Asset that the Notification applies to and/or is affected by. Optional when the Notification characterizes the Subject without regard for Assets it might affect. Omission of this element doesn't necessarily mean the Notification isn't applicable to an Asset.	
NotificationNarrative	VisibleString1024Type	Optional
Description	Human readable message for display to an operator.	

Table A-4-1335: Mission Systems Interface MA_SystemNotificationMT - MessageData UCI Extension Field

NotificationDetail		
Description	Indicates details regarding the reason for and/or a contributing factor to the unsuccessful processing of the sibling AssociatedMessage element. This element is only expected when the Associated Message processing is not successful	
Base Type	CannotComplyType	
Message Structure		
Field Name	Field Type	Field Usage
Reason	CannotComplyEnum	Required
Description	Indicates the reason why an action (Task, [Capability]Command, [SupportingCapability]Command, [Capability]Activity, etc.) was rejected, interrupted, unallocated, failed and/or generally can't be completed satisfactorily. See enumeration annotations for further details.	
Description	Indicates a human-readable text description of the reason for the "can't comply".	
AssociatedID	ID_Type	Optional
Description	Indicates an ID corresponding to another object that is associated with or the cause of the "can't comply".	

Table A-4-1336: Mission Systems Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field

NotificationDetail		
Description	Indicates details regarding the reason for and/or a contributing factor to the unsuccessful processing of the sibling AssociatedMessage element. This element is only expected when the Associated Message processing is not successful	
Base Type	CannotComplyType	
Message Structure		
Field Name	Field Type	Field Usage
Reason	CannotComplyEnum	Required
Description	Indicates the reason why an action (Task, [Capability]Command, [SupportingCapability]Command, [Capability]Activity, etc.) was rejected, interrupted, unallocated, failed and/or generally can't be completed satisfactorily. See enumeration annotations for further details.	
Description	VisibleString1024Type	Optional
Description	Indicates a human-readable text description of the reason for the "can't comply".	
AssociatedID	ID_Type	Optional
Description	Indicates an ID corresponding to another object that is associated with or the cause of the "can't comply".	

Table A-4-1337: Mission Systems Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field

4.4.29 MA_EntityMT UCI Extension

MA_EntityMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ObjectState : ObjectStateEnum MessageData : MA_EntityMDT

Table A-4-1338: Mission Systems Interface MA_EntityMT UCI Extension

ObjectState	
Description	Indicates the state of the internal software object that the data in the message is based upon. The state of the software object is determined by the publisher. The publisher could be the original/master publisher or an intermediary re-publisher such as a persistence/data manager. This element is not a commanded CRUD operation. It is not an indication of the state of an instance of a message. It is not a mechanism for partial, incremental, or fragmentary publication of a message. It is a signal from a publisher to subscribers. For REMOVED state, in particular, some subscribers will mirror the publisher and treat the message as if the object no longer exists, but others, such as mission recorders, might not (in order to support retaining historical records of activity, for example).
Base Type	ObjectStateEnum
Message Structure	
Enumeration Literal	Description
NEW	Indicates the internal software object corresponding to this message currently exists and this message is the first publication corresponding to the object.
UPDATED	Indicates the internal software object corresponding to this message currently exists and has been updated since the last publication of the message; this publication of the message may contain updates.
REMOVED	Indicates the internal software object corresponding to this message no longer exists; there should be no further publications of this message corresponding to the object.

Table A-4-1339: Mission Systems Interface MA_EntityMT - ObjectState UCI Extension Field

MessageData		
Description	Defines the characteristics of this Entity.	
Base Type	MA_EntityMDT	
Message Structure		
Field Name	Field Type	Field Usage
EntityID	EntityID_Type	Required
Description	This element represents the unique identifier of the entity.	
CreationTimestamp	DateTimeSigmaType	Required

	Description	Indicates the time at which the Entity was initially detected and/or created.	
Source		EntitySourceType	Required
	Description	Indicates the System and other details regarding the Source of the Entity. Summarizes the creation and correlation ancestry of the Entity. A given Entity has a single source but could be the result of fusion of multiple Entity children.	
EntityStatus		EntityStatusEnum	Required
	Description	Indicates the status of an Entity. This includes early status (POTENTIAL, TENTATIVE), active status (CONFIRMED), inactive status (DROP_PENDING), end status (DROPPED, DESTROYED), or unknown status (MISSING, UNKNOWN, GHOST).	
OperationalStatus		OB_OperationalStatusEnum	Optional
	Description	Indicates the degree to which the real world asset which the Entity represents is ready to perform the overall operational mission or missions for which it was organized and equipped. An Entity with this element specified will generally have an xOB contributor reference which can be used to query for additional xOB data that isn't duplicated in Entity. Thus, for example, when an enum value of "O" is used refer to available xOB OperationalStatus elements.	
Identity		EntityIdentityType	Required
	Description	This element represents the identity of the Entity. In UCI, Entity and therefore this element are abstracted to a level comparable to MIL-STD-6016 J3.X messages. In particular, the identity taxonomy used in this element is derived directly from MIL-STD-6016. It is left to applications using UCI to enforce compatibility with the portions of MIL-STD-6016 referenced herein.	
SiteEntityID		EntityID_Type	Repeated
	Description	Indicates the unique ID of an Entity that is a part of this Site Entity. When omitted, the Entity is not a Site. When one or more are given, this Entity is a Site.	
Mobility		MobilityEnum	Optional
	Description	Indicates the mobility of the Entity. Omission is equivalent to the enumerate UNDETERMINED.	
Kinematics		KinematicsType	Optional
	Description	Indicates the current kinematic information for the Entity. "Current" is subjective and varies widely by application. For example, some Service might only consider directly sensed kinematic information as current and always report extrapolated data in the sibling EstimatedKinematics element. Another Service might have "staleness" criteria which allows current kinematics to be extrapolated for some period of time before being considered stale. When the staleness criteria are met, that Service might then continue to extrapolate but report the continued extrapolation in the sibling EstimatedKinematics element while freezing this element in a "last-known-good" kinematic state.	
EstimatedKinematics		KinematicsType	Optional
	Description	This element indicates extrapolated or otherwise estimated kinematics for the Entity.	
DownLocation		Point2D_Type	Optional
	Description	When present, indicates the Entity is in a "down" state (damaged, broken or otherwise not operating) and the last known location is given. The child Timestamp element, when given, indicates the time at which the Entity entered the down state.	

PlatformStatus	PlatformStatusType	Optional
Description	General status information about the asset.	
WeaponState	MA_WeaponStateType	Optional
Description	State of the weapon flyout.	
SignalSummary	EntitySignalSummaryType	Repeated
Description	Indicates a summary of an RF Signal from the Entity.	
PulseDataID	PulseDataID_Type	Repeated
Description	Indicates the unique ID of a PulseData collection associated with the Entity.	
MeasurementID	MeasurementID_Type	Repeated
Description	Indicates the unique ID of a Measurement within an Observation Measurement Report associated with the Entity.	
Strength	StrengthType	Optional
Description	Specifies the strength for the Entity. When omitted, a single object/entity should be assumed.	
ActivityAgainst	ActivityAgainstType	Repeated
Description	This element indicates an activity, that isn't otherwise represented by UCI Tasks, Capability commands, etc. being performed on/against the Entity.	
ActivityBy	ActivityByType	Repeated
Description	This element indicates an activity, that isn't otherwise represented by UCI Tasks, Capability commands, etc. being performed by the Entity.	
Endurance	EnduranceType	Optional
Description	Indicates the Entity's remaining endurance.	
VoiceControl	VoiceControlType	Optional
Description	This type contains the connection data needed to communicate with a vehicle using voice radios.	
AssociatedID	ID_Type	Repeated
Description	This element indicates an association (not a fusion or derivation relationship) between this Entity and another UCI message or object. For example, an Entity could be associated with an OpPoint. Data content of the Entity and the associated message/object is maintained independently.	
RemoveInfo	EntityRemoveInfoType	Optional
Description	Indicates supplementary information regarding an Entity whose ObjectState indicates REMOVED.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates a capability of the Entity.	
OrbitalKinematics	OrbitalKinematicsChoiceType	Optional
Description	Indicates the current single-position orbital kinematic information for the Entity in the form of a single Cartesian state vector of position and velocity that together with its time (epoch) uniquely determine the trajectory of an orbiting body in space. Requires selection of the frame of reference and should, in general, only be propagated using the same model used for the orbit determination. Optionally includes a covariance	

	matrix that contains information about the uncertainties associated with the solution of the element corrections. "Current" is subjective and varies widely by application. For example, some Service might only consider directly sensed kinematic information as current and always report extrapolated data in the sibling EstimatedOrbitalKinematics element. Another Service might have "staleness" criteria which allows current kinematics to be extrapolated for some period of time before being considered stale. When the staleness criteria are met, that Service might then continue to extrapolate but report the continued extrapolation in the sibling EstimatedOrbitalKinematics element while freezing this element in a "last-known-good" kinematic state.	
OrbitalKinematicsParameters	OrbitalSingleVectorParametersType	Optional
Description	Indicates the parameters used in the Propagation Model for the Entity. If the OrbitalKinematics are relative to another object (Reference Object), these parameters only relate to this entity. If it is necessary to capture the parameters for the Reference Object, those parameters should be captured in the Entity message for that Reference Object, and the Reference Object's EntityID should be specified in the ReferenceAsset element of the sibling OrbitalKinematics.	
EstimatedOrbitalKinematics	OrbitalKinematicsChoiceType	Optional
Description	This element indicates extrapolated or otherwise estimated single-position orbital kinematics for the Entity.	

Table A-4-1340: Mission Systems Interface MA_EntityMT - MessageData UCI Extension Field

4.4.30 MA_GatewayActivityMT UCI Extension

MA_GatewayActivityMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	ObjectState : ObjectStateEnum MessageData : MA_GatewayActivityMDT

Table A-4-1341: Mission Systems Interface MA_GatewayActivityMT UCI Extension

ObjectState	
Description	Indicates the state of the internal software object that the data in the message is based upon. The state of the software object is determined by the publisher. The publisher could be the original/master publisher or an intermediary re-publisher such as a persistence/data manager. This element is not a commanded CRUD operation. It is not an indication of the state of an instance of a message. It is not a mechanism for partial, incremental, or fragmentary publication of a message. It is a signal from a publisher to subscribers. For REMOVED state, in particular, some subscribers will mirror the publisher and treat the message as if the object no longer exists, but others, such as mission recorders, might not (in order to support retaining historical records of activity, for example).
Base Type	ObjectStateEnum
Message Structure	

Enumeration Literal	Description
NEW	Indicates the internal software object corresponding to this message currently exists and this message is the first publication corresponding to the object.
UPDATED	Indicates the internal software object corresponding to this message currently exists and has been updated since the last publication of the message; this publication of the message may contain updates.
REMOVED	Indicates the internal software object corresponding to this message no longer exists; there should be no further publications of this message corresponding to the object.

Table A-4-1342: Mission Systems Interface MA_GatewayActivityMT - ObjectState UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_GatewayActivityMDT	
Message Structure		
Field Name	Field Type	Field Usage
GatewayServiceID	ServiceID_Type	Required
Description	This element represents the ServiceID of the Gateway Service that sent this message.	
Activity	MA_GatewayActivityType	Repeated
Description	Indicates the dynamic operational characteristics of an Activity of a GatewayCapability.	

Table A-4-1343: Mission Systems Interface MA_GatewayActivityMT - MessageData UCI Extension Field

4.4.31 MA_GatewayCommandMT UCI Extension

MA_GatewayCommandMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_GatewayCommandMDT

Table A-4-1344: Mission Systems Interface MA_GatewayCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_GatewayCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
GatewayServiceID	ServiceID_Type	Required
Description	This element represents the ServiceID of the Gateway Service that sent this message.	
Command	MA_GatewayCommandType	Repeated

Description	Indicates an instance of a Waveform Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Capability CommandStatus message.
-------------	---

Table A-4-1345: Mission Systems Interface MA_GatewayCommandMT - MessageData UCI Extension Field

4.4.32 MA_GatewayCommandStatusMT UCI Extension

MA_GatewayCommandStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_GatewayCommandStatusMDT

Table A-4-1346: Mission Systems Interface MA_GatewayCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_GatewayCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-1347: Mission Systems Interface MA_GatewayCommandStatusMT - MessageData UCI Extension Field

4.4.33 MA_DataDisseminationPlanOverrideRequestMT UCI Extension

MA_DataDisseminationPlanOverrideRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type.

	See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanOverrideRequestMDT

Table A-4-1348: Mission Systems Interface MA_DataDisseminationPlanOverrideRequestMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanOverrideRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
AllocatedToSystemIDs	MA_PackageSystemType	Repeated
Description	Indicates the unique ID of the system(s) or package that is the recipient of this command.	
AllocatedToServiceID	ServiceID_Type	Optional
Description	Indicates the unique ID of the service that is the recipient of this command.	
Request	MA_DataDisseminationPlanOverrideRequestType	Repeated
Description	Indicates an instance of a data plan override request. A data plan override request message can have multiple request instances to allow a sequence of related requests in a single coherent message. Each request instance reports status via a separate, independent DataPlanOverrideRequestStatus message.	

Table A-4-1349: Mission Systems Interface MA_DataDisseminationPlanOverrideRequestMT - MessageData UCI Extension Field

4.4.34 MA_DataDisseminationPlanOverrideRequestStatusMT UCI Extension

MA_DataDisseminationPlanOverrideRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanOverrideRequestStatusMDT

Table A-4-1350: Mission Systems Interface MA_DataDisseminationPlanOverrideRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanOverrideRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MA_DataDisseminationPlanID_Type	Required

Description	Indicates the unique ID of the DataDisseminationPlan that this override modification status applies to.	
EffectivityActivationStatus	DataPlanEffectivityActivationStatusType	Repeated
Description	This element indicates the status of pre-mission planned Data-Link gateway settings. It is used to indicate details about specific planned effectivity activations.	
OperatorModificationStatus	OperatorGatewayDesignationStatusType	Repeated
Description	This element indicates the status of operator designations. It is used to indicate details about specific designation configurations.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-1351: Mission Systems Interface MA_DataDisseminationPlanOverrideRequestStatusMT - MessageData UCI Extension Field

4.4.35 MA_DataDisseminationPlanActivationCommandMT UCI Extension

MA_DataDisseminationPlanActivationCommandMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanActivationCommandMDT

Table A-4-1352: Mission Systems Interface MA_DataDisseminationPlanActivationCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanActivationCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MA_DataDisseminationPlanID_Type	Required
Description	The DataDisseminationPlan that this command pertains to.	
CommandedState	PlanActivationCommandEnum	Required

Description	Indicates the activation to perform on the associated DataDisseminationPlan. See enumerate annotations for further details.	
Applicability	MA_PackageSystemType	Repeated
Description	The System or Package IDs, that this message applies to. A lead is able to respond with ACCEPTED for the Package or individual Systems as needed.	
EffectivityActivation	MA_DataDisseminationPlanEffectivityActivationType	Repeated
Description	Indicates an Effectivity of the DataDisseminationPlan to activate.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-1353: Mission Systems Interface MA_DataDisseminationPlanActivationCommandMT - MessageData UCI Extension Field

4.4.36 MA_DataDisseminationPlanActivationCommandStatusMT UCI Extension

MA_DataDisseminationPlanActivationCommandStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanActivationCommandStatusMDT

Table A-4-1354: Mission Systems Interface MA_DataDisseminationPlanActivationCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanActivationCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the	

	sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.
--	--

Table A-4-1355: Mission Systems Interface MA_DataDisseminationPlanActivationCommandStatusMT - MessageData UCI Extension Field

4.4.37 MA_DataDisseminationPlanActivationStatusMT UCI Extension

MA_DataDisseminationPlanActivationStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_DataDisseminationPlanActivationStatusMDT

Table A-4-1356: Mission Systems Interface MA_DataDisseminationPlanActivationStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanActivationStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MA_DataDisseminationPlanID_Type	Required
Description	The ID of the DataDisseminationPlan this status pertains to.	
ActivationState	PlanActivationStateEnum	Required
Description	Indicates the activation state of the associated DataDisseminationPlan.	
StateReason	MA_CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling ActivationState element.	
EffectivityActivationState	MA_DataDisseminationPlanEffectivityStateType	Repeated
Description	Indicates the activation state of an Effectivity of the associated DataDisseminationPlan.	
OverrideModificationState	MA_OverriderModificationStatusType	Repeated
Description	This element indicates the status of operator designations. It is used to indicate details about specific designation configurations.	

Table A-4-1357: Mission Systems Interface MA_DataDisseminationPlanActivationStatusMT - MessageData UCI Extension Field

4.4.38 MA_DataDisseminationPlanMT UCI Extension

MA_DataDisseminationPlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info

Ext. Fields	ObjectState : ObjectStateEnum
	MessageData : MA_DataDisseminationPlanMDT

Table A-4-1358: Mission Systems Interface MA_DataDisseminationPlanMT UCI Extension

ObjectState	
Description	Indicates the state of the internal software object that the data in the message is based upon. The state of the software object is determined by the publisher. The publisher could be the original/master publisher or an intermediary re-publisher such as a persistence/data manager. This element is not a commanded CRUD operation. It is not an indication of the state of an instance of a message. It is not a mechanism for partial, incremental, or fragmentary publication of a message. It is a signal from a publisher to subscribers. For REMOVED state, in particular, some subscribers will mirror the publisher and treat the message as if the object no longer exists, but others, such as mission recorders, might not (in order to support retaining historical records of activity, for example).
Base Type	ObjectStateEnum
Message Structure	
Enumeration Literal	Description
NEW	Indicates the internal software object corresponding to this message currently exists and this message is the first publication corresponding to the object.
UPDATED	Indicates the internal software object corresponding to this message currently exists and has been updated since the last publication of the message; this publication of the message may contain updates.
REMOVED	Indicates the internal software object corresponding to this message no longer exists; there should be no further publications of this message corresponding to the object.

Table A-4-1359: Mission Systems Interface MA_DataDisseminationPlanMT - ObjectState UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_DataDisseminationPlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
PlanID	MA_DataDisseminationPlanID_Type	Required
Description	Indicates the unique ID of the DataDisseminationPlan.	
AssociatedPlanID	MA_DataDisseminationPlanID_Type	Repeated
Description	Indicates the unique ID of a DataDisseminationPlan that is a parent to this one.	
Applicability	MA_PlanApplicabilityType	Repeated
Description	Indicates the System or Systems which have a direct relationship with the DataDisseminationPlan. See annotations for the underlying type and its child elements for details. If Applicability is not defined then it indicates this DataDisseminationPlan applies to ALL systems.	

IER	MA_CommIER_Planned_Type	Repeated
Description	Indicates a planned Information Exchange Requirement (IER). An IER can reflect the information needs of local or remote Systems or third party Systems coordinating on behalf of other Systems. The planned assignment of an IER to comms resources is given in the sibling Effectivity element.	
IER_DesiredService	MA_CommIER_DesiredServicesType	Repeated
Description	Defines the desired service constraints for an IER (Information Exchange Requirement), allowing multi-constrained solutions. All child elements are optional; when omitted software should apply no explicit bound for that metric.	
RateGroup	MA_CommRateGroupType	Repeated
Description	Indicates a RateGroup that can be associated with an IER to configure its transmit rate.	
Effectivity	MA_CommDataDisseminationEffectivityType	Repeated
Description	Indicates a DataDisseminationPlan "effectivity set" of items that are used together.	
Vector	MA_CommVectorPlannedType	Repeated
Description	Indicates a planned Vector. A vector describes a logical connection between nodes initiating on a specific NetworkLink (comms resource).	
DistributionGroup	MA_DistributionGroupType	Repeated
Description	Indicates a grouping of tiles or node groups and associated ip address.	
DistributionGroupMembership	MA_DistributionGroupMembershipType	Repeated
Description	Indicates a system's membership to a multicast group.	
Gateway	MA_GatewayReferenceType	Repeated
Description	Indicates a planned Gateway local to the system for which this DataDisseminationPlan is applicable to, with a summary of its Capability to be used for dissemination of IERs in the DataDisseminationPlan.	
Trigger	MA_CommTriggerType	Repeated
Description	Signifies available triggers which would automatically invoke this DataDisseminationPlan or parts within this DataDisseminationPlan. These Triggers that can be associated with activation of an Effectivity by using the TriggerID.	

Table A-4-1360: Mission Systems Interface MA_DataDisseminationPlanMT - MessageData UCI Extension Field

4.5 Vehicle Interface

4.5.1 MA_FlightCapabilityMT UCI Extension

MA_FlightCapabilityMT	
Description	Extended to indicate the type of flight capability via the FlightCapabilityEnum and provide per-control mode performance parameters. See the XSD File for more info
Ext. Fields	HSA_CSA_PerformanceProfile : MA_FlightControlModesPerformanceProfileType WaypointFollowingPerformanceProfile : MA_FlightControlModesPerformanceProfileType CurveFollowingPerformanceProfile : MA_FlightControlModesPerformanceProfileType

AccelerationLimit : MA_BodyReferenceAccelerationType
AccelerationLimitValue : MA_AccelerationLimitPairType
BodyReferenceOrientationRate : MA_BodyReferenceOrientationRateType
OrientationRateLimits : MA_BodyReferenceOrientationRateType
AirspeedPair : PathSegmentSpeedValueType

Table A-4-1361: Vehicle Interface MA_FlightCapabilityMT UCI Extension

HSA_CSA_PerformanceProfile		
Description	Indicates performance profile for HSA_CSA flight control mode.	
Base Type	MA_FlightControlModesPerformanceProfileType	
Message Structure		
Field Name	Field Type	Field Usage
MinAirspeed	MA_AirspeedLimitType	Repeated
Description	Minimum allowable airspeed given as a function of altitude.	
MaxAirspeed	MA_AirspeedLimitType	Repeated
Description	Maximum allowable airspeed given as a function of altitude.	
BestEnduranceAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum endurance given as a function of altitude.	
BestRangeAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum range given as a function of altitude.	
MinAltitude	AltitudeReferenceType	Optional
Description	Minimum allowable altitude.	
MaxAltitude	AltitudeReferenceType	Optional
Description	Maximum allowable altitude.	
MinAccelerationLimits	MA_AccelerationLimitsType	Repeated
Description	The vehicle's acceleration limits in the current operating domain of the system as a function of time. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
ExcessPowerOrAcceleration	MA_ExcessPowerOrAccelerationType	Optional
Description	Provides either specific excess power or paired acceleration and climb rate data for the platform.	
MaxOrientationLimits	MA_OrientationLimitType	Repeated
Description	Euler Angle Sequence describing the maximum orientation of the vehicle in the order yaw, pitch, roll as a function of airspeed, altitude, and weight.	
MaxOrientationRateLimits	MA_OrientationRateLimitsType	Repeated
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may	

	utilize an unbounded number of time indices to form dynamically feasible trajectories.	
MaxTurnRate	AngleRateType	Optional
Description	Maximum allowable turn rate in radians/sec.	
MaxDescentRate	MA_SpeedType	Repeated
Description	Maximum allowable descent rate as a function of airspeed, altitude, and weight.	
MaxDeceleration	MA_AccelerationLimitsType	Repeated
Description	Maximum allowable deceleration limits as a function of airspeed, altitude, and weight.	
FuelBurnRate	MA_FuelBurnRateType	Repeated
Description	Fuel burn rate as a function of airspeed, altitude, and weight.	

Table A-4-1362: Vehicle Interface MA_FlightCapabilityMT - HSA_CSA_PerformanceProfile UCI Extension Field

WaypointFollowingPerformanceProfile		
Description	Indicates performance profile for Waypoint Following flight control mode.	
Base Type	MA_FlightControlModesPerformanceProfileType	
Message Structure		
Field Name	Field Type	Field Usage
MinAirspeed	MA_AirspeedLimitType	Repeated
Description	Minimum allowable airspeed given as a function of altitude.	
MaxAirspeed	MA_AirspeedLimitType	Repeated
Description	Maximum allowable airspeed given as a function of altitude.	
BestEnduranceAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum endurance given as a function of altitude.	
BestRangeAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum range given as a function of altitude.	
MinAltitude	AltitudeReferenceType	Optional
Description	Minimum allowable altitude.	
MaxAltitude	AltitudeReferenceType	Optional
Description	Maximum allowable altitude.	
MinAccelerationLimits	MA_AccelerationLimitsType	Repeated
Description	The vehicle's acceleration limits in the current operating domain of the system as a function of time. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
ExcessPowerOrAcceleration	MA_ExcessPowerOrAccelerationType	Optional
Description	Provides either specific excess power or paired acceleration and climb rate data for the platform.	
MaxOrientationLimits	MA_OrientationLimitType	Repeated
Description	Euler Angle Sequence describing the maximum orientation of the vehicle in the order	

	yaw, pitch, roll as a function of airspeed, altitude, and weight.	
MaxOrientationRateLimits	MA_OrientationRateLimitsType	Repeated
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
MaxTurnRate	AngleRateType	Optional
Description	Maximum allowable turn rate in radians/sec.	
MaxDescentRate	MA_SpeedType	Repeated
Description	Maximum allowable descent rate as a function of airspeed, altitude, and weight.	
MaxDeceleration	MA_AccelerationLimitsType	Repeated
Description	Maximum allowable deceleration limits as a function of airspeed, altitude, and weight.	
FuelBurnRate	MA_FuelBurnRateType	Repeated
Description	Fuel burn rate as a function of airspeed, altitude, and weight.	

Table A-4-1363: Vehicle Interface MA_FlightCapabilityMT - WaypointFollowingPerformanceProfile UCI Extension Field

CurveFollowingPerformanceProfile		
Description	Indicates performance profile for Curve Following flight control mode.	
Base Type	MA_FlightControlModesPerformanceProfileType	
Message Structure		
Field Name	Field Type	Field Usage
MinAirspeed	MA_AirspeedLimitType	Repeated
Description	Minimum allowable airspeed given as a function of altitude.	
MaxAirspeed	MA_AirspeedLimitType	Repeated
Description	Maximum allowable airspeed given as a function of altitude.	
BestEnduranceAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum endurance given as a function of altitude.	
BestRangeAirspeed	MA_AirspeedLimitType	Repeated
Description	Airspeed of maximum range given as a function of altitude.	
MinAltitude	AltitudeReferenceType	Optional
Description	Minimum allowable altitude.	
MaxAltitude	AltitudeReferenceType	Optional
Description	Maximum allowable altitude.	
MinAccelerationLimits	MA_AccelerationLimitsType	Repeated
Description	The vehicle's acceleration limits in the current operating domain of the system as a function of time. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	

ExcessPowerOrAcceleration	MA_ExcessPowerOrAccelerationType	Optional
Description	Provides either specific excess power or paired acceleration and climb rate data for the platform.	
MaxOrientationLimits	MA_OrientationLimitType	Repeated
Description	Euler Angle Sequence describing the maximum orientation of the vehicle in the order yaw, pitch, roll as a function of airspeed, altitude, and weight.	
MaxOrientationRateLimits	MA_OrientationRateLimitsType	Repeated
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle. Flight control modes such as HSA and Waypoint Following should only use the first time index, while Curve Following may utilize an unbounded number of time indices to form dynamically feasible trajectories.	
MaxTurnRate	AngleRateType	Optional
Description	Maximum allowable turn rate in radians/sec.	
MaxDescentRate	MA_SpeedType	Repeated
Description	Maximum allowable descent rate as a function of airspeed, altitude, and weight.	
MaxDeceleration	MA_AccelerationLimitsType	Repeated
Description	Maximum allowable deceleration limits as a function of airspeed, altitude, and weight.	
FuelBurnRate	MA_FuelBurnRateType	Repeated
Description	Fuel burn rate as a function of airspeed, altitude, and weight.	

Table A-4-1364: Vehicle Interface MA_FlightCapabilityMT - CurveFollowingPerformanceProfile UCI Extension Field

AccelerationLimit		
Description	Specified acceleration limits in body reference or NED coordinate frame.	
Base Type	MA_BodyReferenceAccelerationType	
Message Structure		
Field Name	Field Type	Field Usage
X_Accel	AccelerationType	Required
Description	Body-referenced acceleration component along the longitudinal (x or roll) axis, measured in meters/sec^2	
Y_Accel	AccelerationType	Required
Description	Body-referenced acceleration component along the lateral (y or pitch) axis, measured in meters/sec^2	
Z_Accel	AccelerationType	Required
Description	Body-referenced acceleration component along the vertical (z or yaw) axis, measured in meters/sec^2.	
Timestamp	DateTimeType	Optional
Description	Indicates the time when the acceleration data was measured or last known to be correct. The element can also indicate the time at which a future velocity of a System, Entity, etc. will be achieved.	

Table A-4-1365: Vehicle Interface MA_FlightCapabilityMT - AccelerationLimit UCI Extension Field

AccelerationLimitValue		
Description	Value for the specified acceleration limit, provided either as a set of body referenced orientation rates, or a unitless Mach value.	
Base Type	MA_AccelerationLimitPairType	
Message Structure		
Field Name	Field Type	Field Usage
BodyReferenceOrientationRate	MA_BodyReferenceOrientationRateType	Required
Description	Body reference orientation rates to be paired with the specified acceleration limit.	
MachValue	MachType	Required
Description	Unitless Mach value to be paired with the specified acceleration limit.	

Table A-4-1366: Vehicle Interface MA_FlightCapabilityMT - AccelerationLimitValue UCI Extension Field

BodyReferenceOrientationRate		
Description	Body reference orientation rates to be paired with the specified acceleration limit.	
Base Type	MA_BodyReferenceOrientationRateType	
Message Structure		
Field Name	Field Type	Field Usage
RollRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the longitudinal (x or roll) axis, measured in radians/sec.	
PitchRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the lateral (y or pitch) axis, measured in radians/sec.	
YawRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the vertical (z or yaw) axis, measured in radians/sec.	
Timestamp	DateTimeType	Optional
Description	Indicates the time when the velocity data was measured or last known to be correct. The element can also indicate the time at which a future velocity of a System, Entity, etc. will be achieved.	

Table A-4-1367: Vehicle Interface MA_FlightCapabilityMT - BodyReferenceOrientationRate UCI Extension Field

OrientationRateLimits		
Description	Specified orientation rate limits in body reference or NED coordinate frame.	
Base Type	MA_BodyReferenceOrientationRateType	
Message Structure		
Field Name	Field Type	Field Usage
RollRate	AngleRateType	Required

Description	Body-referenced attitude rate component along the longitudinal (x or roll) axis, measured in radians/sec.	
PitchRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the lateral (y or pitch) axis, measured in radians/sec.	
YawRate	AngleRateType	Required
Description	Body-referenced attitude rate component along the vertical (z or yaw) axis, measured in radians/sec.	
Timestamp	DateTimeType	Optional
Description	Indicates the time when the velocity data was measured or last known to be correct. The element can also indicate the time at which a future velocity of a System, Entity, etc. will be achieved.	

Table A-4-1368: Vehicle Interface MA_FlightCapabilityMT - OrientationRateLimits UCI Extension Field

AirspeedPair		
Description	Airspeed pair value for associated orientation rate limit, specified in body reference or NED coordinate frame.	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-1369: Vehicle Interface MA_FlightCapabilityMT - AirspeedPair UCI Extension Field

4.5.2MA_FlightCommandMT UCI Extension

MA_FlightCommandMT	
Description	Message extension included to invoke a flight capability to perform a new flight activity or change and existing flight activity. See the XSD File for more info
Ext. Fields	Command : MA_FlightCommandType Capability : MA_FlightCapabilityCommandType HSA_CSA : MA_HSA_CSA_Type WaypointFollowing : MA_WaypointFollowingType CurveFollowing : MA_CurveControlType Speed : PathSegmentSpeedType Heading : MA_DirectionReferenceType

	SpeedChoice : MA_HSA_SpeedChoiceType
	SpeedValue : PathSegmentSpeedValueType
	CurveFitMethod : MA_CurveFitMethodEnum
	Reference : MA_HeadingReferenceEnum
	ControlPoint : MA_CurveFollowingControlPointType
	RelativeAcceleration : MA_AccelerationChoiceType
	RelativeVelocity : MA_VelocityChoiceType
	OrientationRate : MA_OrientationRateChoiceType
	Direction : MA_DirectionChoiceType
	Course : MA_DirectionReferenceType

Table A-4-1370: Vehicle Interface MA_FlightCommandMT UCI Extension

Command		
Description		Indicates an instance of a Flight Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate independent Capability CommandStatus message.
Base Type		MA_FlightCommandType
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_FlightCapabilityCommandType	Required
Description	Indicates a new invocation of a Flight Capability. Generally, if accepted, the command will result in one or more new Flight Activities being created and reported via the Flight Activity message. The request/response interaction terminates as soon as the command is accepted or rejected; this element is not used to interact with an "active" command. Updates and/or additional interaction with the resulting Activity (after the command is accepted) is accomplished via the sibling Activity element.	
Activity	MA_FlightActivityCommandType	Required
Description	Indicates a command to modify an existing Flight Activity (which was previously reported via the Flight Activity message and was marked as "interactive"). The request/response interaction terminates as soon as the modification is accepted or rejected. The modifications are reflected in subsequent Flight Activity messages.	

Table A-4-1371: Vehicle Interface MA_FlightCommandMT - Command UCI Extension Field

Capability	
Description	Indicates a new invocation of a Flight Capability. Generally, if accepted, the command will result in one or more new Flight Activities being created and reported via the Flight Activity message. The request/response interaction terminates as soon as the command is accepted or rejected; this element is not used to interact with an "active" command. Updates and/or additional interaction with the resulting Activity (after the command is accepted) is accomplished via the sibling Activity element.
Base Type	MA_FlightCapabilityCommandType

Message Structure		
Field Name	Field Type	Field Usage
Loiter	MA_LoiterType	Optional
Description	Indicates the parameters for a loiter.	
MustFly	MustFlyType	Optional
Description	Indicates the parameters for a must fly.	
Formation	MA_FormationType	Repeated
Description	Indicates the relative positions for the entities in the formation.	
FlightControlMode	MA_FlightControlModesChoiceType	Optional
Description	See annotations in child elements and messages/elements that use this type for details.	
AltitudeStackedMarshal	MA_AltitudeStackedMarshalType	Optional
Description	Indicates kinematics for an altitude stacked marshal.	
Departure	MA_DepartureType	Optional
Description	This element identifies the parameters for a departure/take-off task.	
Recovery	MA_RecoveryType	Optional
Description	This element identifies the parameters for a recovery/land task.	
RoutePlanIntercept	MA_RoutePlanInterceptType	Optional
Description	This element defines the parameters for a Route intercept	
CapabilityID	CapabilityID_Type	Required
Description	Indicates the Capability instance being commanded.	
Ranking	CapabilityCommandRankingType	Required
Description	Indicates the command's rank relative to other commands and rank-related overrides and tailoring.	
TemporalConstraints	CapabilityCommandTemporalConstraintsType	Optional
Description	Indicates temporal constraints for the command. If omitted, the command should be scheduled immediately while satisfying other applicable constraints.	
OverrideRejection	boolean	Optional
Description	Indicates that the Command shall be performed even though it was previously rejected.	
Traceability	TraceabilityType	Optional
Description	C2 sources work at different levels of detail and abstraction, progressing from what to do to how specifically to do it. Inputs from abstract tasking sources and Tasks can be decomposed into discrete, actionable Tasks and/or Capability commands. This element provides traceability to the external tasking or Task from which this Capability command was derived.	
Classification	SecurityInformationType	Optional
Description	This element provides the classification label that the Subsystem should place on messages and other data resulting from the Command.	
CommandID	CommandID_Type	Required

Description	Indicates the unique ID of the Command corresponding to this message. Used to reference the command when providing status.	
CommandState	CommandStateEnum	Required
Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	

Table A-4-1372: Vehicle Interface MA_FlightCommandMT - Capability UCI Extension Field

HSA_CSA		
Description	This message shall be used to provide the ability to command a new flight vector to the Platform.	
Base Type	MA_HSA_CSA_Type	
Message Structure		
Field Name	Field Type	Field Usage
Altitude	AltitudeReferenceType	Optional
Description	Altitude hold value to be achieved and reference to altitude measurement source.	
Speed	PathSegmentSpeedType	Optional
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Direction	MA_DirectionChoiceType	Optional
Description	Defines heading or course type and reference to hold	

Table A-4-1373: Vehicle Interface MA_FlightCommandMT - HSA_CSA UCI Extension Field

WaypointFollowing		
Description	This message shall be used to provide the ability to send a new waypoint path or segment for the Platform to follow.	
Base Type	MA_WaypointFollowingType	
Message Structure		
Field Name	Field Type	Field Usage
Route	MA_RouteType	Required
Description	Indicates the Paths and Segments that make up the Route to be flown.	

Table A-4-1374: Vehicle Interface MA_FlightCommandMT - WaypointFollowing UCI Extension Field

CurveFollowing		
Description	Indicates the parameters for curve following control.	
Base Type	MA_CurveControlType	
Message Structure		
Field Name	Field Type	Field Usage
CurveSegments	MA_NURBS_PointType	Repeated
Description	Specifies the curve segments as a set of NURBS points.	
AppendCurve	EmptyType	Optional

Description	Specifies this curve will be appended to a previous curve command. This is only valid if the vehicle is currently executing a curve.	
EndOfCurveBehavior	MA_EndOfCurveBehaviorEnum	Optional
Description	Specifies the vehicle behavior at the completion of the curve.	

Table A-4-1375: Vehicle Interface MA_FlightCommandMT - CurveFollowing UCI Extension Field

Speed		
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Base Type	PathSegmentSpeedType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedChoice	PathSegmentSpeedChoiceType	Optional
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
SpeedOptimization	SpeedOptimizationEnum	Optional
Description	Indicates that the System will vary its speed autonomously according to the specified optimization algorithm.	

Table A-4-1376: Vehicle Interface MA_FlightCommandMT - Speed UCI Extension Field

Heading		
Description	Defines heading type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-1377: Vehicle Interface MA_FlightCommandMT - Heading UCI Extension Field

SpeedChoice		
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
Base Type	MA_HSA_SpeedChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedValue	PathSegmentSpeedValueType	Required

Description	Indicates speed in meters per second (m/s).	
MachValue	MachType	Required
Description	Indicates the speed reference for the associated speed value.	

Table A-4-1378: Vehicle Interface MA_FlightCommandMT - SpeedChoice UCI Extension Field

SpeedValue		
Description	Indicates speed in meters per second (m/s).	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-1379: Vehicle Interface MA_FlightCommandMT - SpeedValue UCI Extension Field

CurveFitMethod	
Description	Method through which a curve should be fitted to the discretized points in ControlPoint.
Base Type	MA_CurveFitMethodEnum
Message Structure	
Enumeration Literal	Description
B_SPLINE	B-Spline (basis spline) fit.
BEZIER	Bezier curve fit.
CATMULL_ROM	Catmull-Rom spline fit.
NATURAL_CUBIC	Natural Cubic curve fit.

Table A-4-1380: Vehicle Interface MA_FlightCommandMT - CurveFitMethod UCI Extension Field

Reference	
Description	Reference to type of heading or course given.
Base Type	MA_HeadingReferenceEnum
Message Structure	
Enumeration Literal	Description
TRUE_NORTH	Heading value according to Geographic North.
MAGNETIC_NORTH	Heading value according to location where the planet's magnetic field points vertically downward.

Table A-4-1381: Vehicle Interface MA_FlightCommandMT - Reference UCI Extension Field

ControlPoint

Description	Control Points for the desired discretized curve or spline path.	
Base Type	MA_CurveFollowingControlPointType	
Message Structure		
Field Name	Field Type	Field Usage
Position	PointChoice4D_Type	Required
Description	Physical location of the referenced item in geospatial coordinates. The use of the timestamp in this context represents the time the positional data was last measured. Position data may be specified as either a geospatial point or relative to a separately defined reference frame.	
PositionUncertainty	UncertaintyType	Optional
Description	Uncertainty of the physical location of the referenced item.	
DomainVelocity	Velocity3D_Type	Optional
Description	Vehicle's velocity in the current operating domain of the system. Air vehicle components are in True Air Speed.	
GroundVelocity	Velocity2D_Type	Optional
Description	Representation of the vehicle's ground velocity as directional speed components.	
RelativeVelocity	MA_VelocityChoiceType	Optional
Description	Represents the vehicle's velocity, in units of m/s, in the separately defined reference frame referenced in the sibling Position element. This element should only be used when the RelativePoint choice is selected and the seperately defined reference frame is itself moving.	
DomainAcceleration	Acceleration3D_Type	Optional
Description	The vehicle's acceleration in the current operating domain of the system.	
Orientation	OrientationType	Optional
Description	Euler Angle Sequence describing the orientation of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
OrientationRate	MA_OrientationRateChoiceType	Optional
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
RelativeAcceleration	MA_AccelerationChoiceType	Optional
Description		

Table A-4-1382: Vehicle Interface MA_FlightCommandMT - ControlPoint UCI Extension Field

RelativeAcceleration		
Description		
Base Type	MA_AccelerationChoiceType	
Message Structure		
Field Name	Field Type	Field Usage

BodyReferenceAcceleration	MA_BodyReferenceAccelerationType	Required
Description	Body reference accelerations.	
NED_Acceleration	Acceleration3D_Type	Required
Description	Inertial, NED coordinate frame accelerations.	

Table A-4-1383: Vehicle Interface MA_FlightCommandMT - RelativeAcceleration UCI Extension Field

RelativeVelocity		
Description	Represents the vehicle's velocity, in units of m/s, in the separately defined reference frame referenced in the sibling Position element. This element should only be used when the RelativePoint choice is selected and the seperately defined reference frame is itself moving.	
Base Type	MA_VelocityChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
BodyReferenceVelocity	MA_BodyReferenceVelocityType	Required
Description	Velocity in body reference frame.	
NED_Velocity	Velocity3D_Type	Required
Description	Velocity in North East Down reference frame.	

Table A-4-1384: Vehicle Interface MA_FlightCommandMT - RelativeVelocity UCI Extension Field

OrientationRate		
Description	Euler Angle Sequence describing the rate of orientation change of the vehicle in the order yaw, pitch, roll. The angles are given in a locally level, North-East-Down coordinate system centered on the vehicle.	
Base Type	MA_OrientationRateChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
BodyReferenceOrientationRate	MA_BodyReferenceOrientationRateType	Required
Description	Orientation rate in body reference.	
NED_OrientationRate	OrientationRateType	Required
Description	Orientation rate in inertial reference.	

Table A-4-1385: Vehicle Interface MA_FlightCommandMT - OrientationRate UCI Extension Field

Direction		
Description	Defines heading or course type and reference to hold	
Base Type	MA_DirectionChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
Heading	MA_DirectionReferenceType	Optional

Description	Defines heading type and reference to hold.	
Course	MA_DirectionReferenceType	Optional
Description	Defines course type and reference to hold.	

Table A-4-1386: Vehicle Interface MA_FlightCommandMT - Direction UCI Extension Field

Course		
Description	Defines course type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-1387: Vehicle Interface MA_FlightCommandMT - Course UCI Extension Field

4.5.3 MA_FlightCommandStatusMT UCI Extension

MA_FlightCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_FlightCommandStatusMDT CannotComplyDetails : MA_CannotComplyDetailsType Severity : MA_FaultSeverityEnum

Table A-4-1388: Vehicle Interface MA_FlightCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_FlightCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CannotComplyDetails	MA_CannotComplyDetailsType	Optional
Description	Provides detail for why FA cannot comply with the flight command.	
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	
CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	

CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-1389: Vehicle Interface MA_FlightCommandStatusMT - MessageData UCI Extension Field

CannotComplyDetails		
Description	Provides detail for why FA cannot comply with the flight command.	
Base Type	MA_CannotComplyDetailsType	
Message Structure		
Field Name	Field Type	Field Usage
ValidationResult	MA_ValidationResultEnum	Repeated
Description	In case of flight command rejection, provides the reason for Flight Autonomy rejection. Further details can be provided by Flight Autonomy through the ValidationResultReason. List size for this element is based on "Select All That Apply" condition.	
ValidationResultReason	MA_ValidationResultReasonType	Repeated
Description	In case of flight command rejection, provides additional context for Flight Autonomy rejection.	

Table A-4-1390: Vehicle Interface MA_FlightCommandStatusMT - CannotComplyDetails UCI Extension Field

Severity	
Description	The severity of the fault. This enumeration is modified for Mission Autonomy adaptation.
Base Type	MA_FaultSeverityEnum
Message Structure	
Enumeration Literal	Description
NOMINAL	A fault that carries the nominal level indicates that fault does not impact the current mission but may indicate something that should be checked in maintenance. Faults should be tagged as nominal if they are targeting maintenance. An example might be air filter hasn't been changed in 5000 hours or queue length reached 60% of max.
ADVISORY	A fault that is important but is not a Caution or Warning; this can be a configuration change, a condition that is contributing to a degraded aircraft or subsystem operation, or an anomaly that is being automatically controlled or corrected by a higher level system.

CAUTION	A fault that is indicative of a condition that, without a timely and correct response, could result in equipment damage or failure of mission.
WARNING	A fault that is indicative of a condition requiring immediate response or attention to prevent loss of aircraft, or failure of mission.
FAILED	A fault that carries a failed level indicates the failure of a component which may preclude the use of a capability. Faults should be tagged with failed if the component state will be marked faulted. Failed components may or may not prevent the completion of the mission.

Table A-4-1391: Vehicle Interface MA_FlightCommandStatusMT - Severity UCI Extension Field

4.5.4 MA_FlightActivityMT UCI Extension

MA_FlightActivityMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	VehicleCommandState : Activity : MA_FlightActivityType Speed : PathSegmentSpeedValueType Heading : MA_DirectionReferenceType

Table A-4-1392: Vehicle Interface MA_FlightActivityMT UCI Extension

VehicleCommandState		
Description		
Base Type		
Message Structure		
Field Name	Field Type	Field Usage

Table A-4-1393: Vehicle Interface MA_FlightActivityMT - VehicleCommandState UCI Extension Field

Activity		
Description	Indicates the dynamic operational characteristics of an Activity of a System's Flight Capability.	
Base Type	MA_FlightActivityType	
Message Structure		
Field Name	Field Type	Field Usage
ActualEndPoint	MA_EndPointType	Repeated
Description	Indicates end points for the Flight activity. The current end point (the end point the System is currently flying to) is listed first followed by subsequent end points if known. If the Flight Activity was planned and the actual Activity is following the plan, the RouteActivityPlan* messages provide details relative to the plan. For planned Flight Activities against moving targets the actual, dynamically calculated kinematic details can be provided with this element.	
ActualCompletionTime	DateTimeType	Optional

Description	This field specifies the actual time when the Flight Activity completed.	
VehicleCommandState	MA_VehicleCommandStateType	Required
Description	Indicates the currently commanded parameters per the Flight Autonomy's execution of the request FlightCommand.	
CurveFollowingControl	MA_CurveFollowingControlType	Optional
Description	Indicates the curve following parameters, validity and status.	
RoutePlanInterceptStatus	MA_RoutePlanInterceptStatusType	Optional
Description	Status of the executing RoutePlan Intercept.	
ActivityID	ActivityID_Type	Required
Description	Indicates the unique ID of the Activity.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates a Capability which the Activity is an instance of. Generally an Activity is an instance of a single Capability. An Activity can be associated with multiple Capabilities when, for example, a Subsystem has distinct Capabilities for automated and manual. In this case, if a manual command is issued while an automated Activity that achieves the desired result already exists, a single Activity represents both Capabilities.	
Interactive	boolean	Required
Description	Indicates whether or not the Activity can be edited/modified via a [Capability]Command...Activity message.	
ActivityState	ActivityStateEnum	Required
Description	Indicates the current state of the Activity its state machine. See enumeration annotations for further details.	
Basis	ActivityBasisEnum	Optional
Description	Indicates the basis of the Activity. See enumerated type annotations for further details. If omitted, a basis of ACTUAL should be assumed.	
ActivityRank	ComparableRankingType	Optional
Description	Indicates the rank of the Activity amongst all other Activities of the Capability and/or Subsystem. This isn't necessarily the same as the Rank associated with the sibling ActivitySource. This element is meant to convey the Subsystem determined relative ranking of all Activities of a Capability category (ESM, EA, etc.). For Subsystems with multiple Capability categories this element is meant to convey relative ranking across all Capability categories. In addition to the rank of the ActivitySource, an Activity's rank can be influenced by Capability priority (see CapabilitySettings), RF_ControlCommands and other factors that influence the Subsystem's internal scheduling and resource allocation.	
ActivityReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling ActivityState element. This element is only expected when the Activity is in a potentially undesirable state such as constrained, failed or completed with less than optimum results.	
Source	ActivitySourceType	Repeated
Description	Indicates an originating "source" of the Activity; the command or other item which invoked this specific Activity of a Capability. A single Activity can fully or partially satisfy Activity sources.	

EstimatedStartTime	DateTimeType	Optional
Description	Indicates the estimated time when the Activity started or is expected to start.	
EstimatedCompletionTime	DateTimeType	Optional
Description	Indicates the estimated time when the Activity will complete.	
EstimatedPercentComplete	PercentType	Optional
Description	Indicates the current estimated percent complete of the Activity.	

Table A-4-1394: Vehicle Interface MA_FlightActivityMT - Activity UCI Extension Field

Speed		
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-1395: Vehicle Interface MA_FlightActivityMT - Speed UCI Extension Field

Heading		
Description	Intended heading of the aircraft.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	
Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-1396: Vehicle Interface MA_FlightActivityMT - Heading UCI Extension Field

4.5.5 MA_PositionReportDetailedMT UCI Extension

MA_PositionReportDetailedMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	PositionReportData : MA_PositionReportDataType MessageData : MA_PositionReportDetailedMDT

Table A-4-1397: Vehicle Interface MA_PositionReportDetailedMT UCI Extension

PositionReportData		
Description	If multiple instances are given, each should be of a different navigation solution type as indicated by the child element.	
Base Type	MA_PositionReportDataType	
Message Structure		
Field Name	Field Type	Field Usage
PositionSource	PositionSourceID_ChoiceType	Required
Description	The source of the positional data.	
ComponentID	ComponentID_Type	Optional
Description	The ID of the specific component within the subsystem that is the source of this data. This can be used if multiple redundant INS/GPS units are represented as a single subsystem.	
NavigationSolutionState	NavigationSolutionStateEnum	Required
Description	The navigation solution state indicates what sensor inputs the navigation unit is using to generate its kinematic solution.	
FigureOfMerit	BytePositiveType	Optional
Description	A FOM is typically calculated as the root-sum-square of the estimated errors contributing to the solution accuracy. Example criteria include: a. GPS receiver state (e.g., carrier tracking, code tracking, acquisition) b. Carrier to noise ratio c. Satellite geometry (DOP value) d. Satellite range accuracy (URA value) e. Ionospheric measurement or modeling error f. Receiver aiding used g. Kalman filter error estimates. The resultant FOM is presented as a numerical value from 1 to 9, where 1 indicates the best navigation performance.	
Kinematics	MA_DetailedKinematicsType	Required
Description	The kinematic state of the vehicle.	
KinematicsError	DetailedKinematicsErrorType	Required
Description	Indicates the covariance matrix of the vehicle, containing detailed kinematic errors of the position, velocity, and orientation. See the DetailedKinematicsErrorType element	

	annotations for details.	
SolutionCorrections	NavigationSolutionCorrectionsType	Optional
Description	This element contains the corrections applied by the measurement unit to the reported values.	

Table A-4-1398: Vehicle Interface MA_PositionReportDetailedMT - PositionReportData UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PositionReportDetailedMDT	
Message Structure		
Field Name	Field Type	Field Usage
PositionReportData	MA_PositionReportDataType	Repeated
Description	If multiple instances are given, each should be of a different navigation solution type as indicated by the child element.	

Table A-4-1399: Vehicle Interface MA_PositionReportDetailedMT - MessageData UCI Extension Field

4.5.6 MA_NavigationReportMT UCI Extension

MA_NavigationReportMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_NavigationReportMDT

Table A-4-1400: Vehicle Interface MA_NavigationReportMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_NavigationReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Indicates the unique ID of the System corresponding to this NavigationReport.	
Source	SystemSourceEnum	Required
Description	Indicates the source of the data in sibling elements. See enumeration annotations for further details.	
ContingencyLevel	SystemContingencyLevelEnum	Required
Description	Designates the current contingency state of the System. Contingencies can be an indication that the System will/has autonomously modified its means of navigation.	

Endurance	EnduranceType	Required
Description	Indicates the System's remaining endurance. It is expected that at least one of the optional children are populated in this context.	
Playtime	DurationType	Optional
Description	Estimated remaining playtime of operation/mission when taking into account RTB routing, fuel overhead, current fuel usage, current tasking, etc.	
Navigation	NavigationType	Optional
Description	Vehicle navigation method currently employed.	

Table A-4-1401: Vehicle Interface MA_NavigationReportMT - MessageData UCI Extension Field

4.5.7 MA_FaultMT UCI Extension

MA_FaultMT	
Description	This represents a fault for the system. Intended to be used by services such as a health monitoring service for centralized fault management and fault isolation of a system. Allows announcing a fault state change (raised or cleared) from a service as opposed to a capability or component of a subsystem. Also conveys a service relationship in addition to a subsystem relationship. Extended to include a modified Fault Severity Enumeration for Mission Autonomy. See the XSD File for more info
Ext. Fields	MessageData : MA_FaultMDT FaultInformation : MA_SubsystemFaultType Severity : MA_FaultSeverityEnum

Table A-4-1402: Vehicle Interface MA_FaultMT UCI Extension

MessageData		
Description	Reports a fault for the system.	
Base Type	MA_FaultMDT	
Message Structure		
Field Name	Field Type	Field Usage
FaultInformation	MA_SubsystemFaultType	Repeated
Description	Contains the fault information for the message.	

Table A-4-1403: Vehicle Interface MA_FaultMT - MessageData UCI Extension Field

FaultInformation		
Description	Contains the fault information for the message.	
Base Type	MA_SubsystemFaultType	
Message Structure		
Field Name	Field Type	Field Usage
FaultID	FaultID_Type	Required
Description	The unique ID for this fault. Every fault from a Subsystem, Capability,	

	SupportCapability, Component, or Service should have a unique ID.	
Severity	MA_FaultSeverityEnum	Optional
Description	The severity of the fault. This enumeration is modified for Mission Autonomy adaptation.	
FaultState	FaultStateEnum	Optional
Description	The state of the fault.	
FaultData	FaultDataType	Repeated
Description	Additional fault data which contains key/value pairs with format and unit indicated for the data value. This data supports fault isolation and helps to minimize false alarms.	
DetectionTime	DateTimeType	Optional
Description	Indicates the time the fault was detected; it does not indicate the time the fault was transmitted.	
FaultCode	VisibleString256Type	Required
Description	Indicates the "code" or name of the fault.	
FaultCodeCount	int	Optional
Description	Indicates the number of occurrences of the associated FaultCode and a set FaultState.	
FaultDescription	VisibleString256Type	Optional
Description	Indicates a human readable description of the fault and/or its cause. This could be different than DescriptiveLabel in the sibling FaultID field. For example, DescriptiveLabel could be "Engine 1 overheat" and the FaultDescription could be "Lubrication oil" or "Exhaust nozzle" indicating the underlying cause of the fault.	
SubsystemID	SubsystemID_Type	Optional
Description	The Subsystem that the fault occurred within.	
ServiceID	ServiceID_Type	Optional
Description	The Service that this fault occurred within.	
CapabilityID	CapabilityID_Type	Repeated
Description	Indicates the unique ID of a Capability related to the fault.	
SupportCapabilityID	SupportCapabilityID_Type	Repeated
Description	Indicates the unique ID of a SupportCapability related to the fault.	
ComponentID	ComponentID_Type	Repeated
Description	Indicates the unique ID of a Component related to the fault. When multiple components are identified, it should be inferred that each Component has been individually determined to be related to the fault. In situations where the Subsystem has not yet been able to isolate the fault to individual components, the sibling AmbiguityGroup element should be used.	
AmbiguityGroup	SubsystemFaultAmbiguityGroupType	Repeated
Description	Indicates that a fault has been narrowed down to a set of components, but not yet fully isolated. Separate AmbiguityGroups can be provided when it is desirable to associate specific tests with a subset of the set of components.	

Table A-4-1404: Vehicle Interface MA_FaultMT - FaultInformation UCI Extension Field

Severity	
Description	The severity of the fault. This enumeration is modified for Mission Autonomy adaptation.
Base Type	MA_FaultSeverityEnum
Message Structure	
Enumeration Literal	Description
NOMINAL	A fault that carries the nominal level indicates that fault does not impact the current mission but may indicate something that should be checked in maintenance. Faults should be tagged as nominal if they are targeting maintenance. An example might be air filter hasn't been changed in 5000 hours or queue length reached 60% of max.
ADVISORY	A fault that is important but is not a Caution or Warning; this can be a configuration change, a condition that is contributing to a degraded aircraft or subsystem operation, or an anomaly that is being automatically controlled or corrected by a higher level system.
CAUTION	A fault that is indicative of a condition that, without a timely and correct response, could result in equipment damage or failure of mission.
WARNING	A fault that is indicative of a condition requiring immediate response or attention to prevent loss of aircraft, or failure of mission.
FAILED	A fault that carries a failed level indicates the failure of a component which may preclude the use of a capability. Faults should be tagged with failed if the component state will be marked faulted. Failed components may or may not prevent the completion of the mission.

Table A-4-1405: Vehicle Interface MA_FaultMT - Severity UCI Extension Field

4.5.8MA_TaskMT UCI Extension

MA_TaskMT	
Description	This message specifies a Task that a System will perform against a specific entity or geographical location. Tasks include flight, collection, strike, electronic attack, directed energy, laser designation, cargo delivery and communication relay. They are abstracted to a level of C2 and autonomy derived from UCI operational vignettes. Tasks enable services, operators and other actors to do automated, dynamic, machine-to-machine allocation of Tasks to Systems and subsequent mission planning. If necessary, authorization of Users to Task Systems can be controlled using the Authorization message. See the XSD File for more info
Ext. Fields	TaskType : MA_TaskType TaskPlurality : MA_TaskPluralityEnum ConstraintID : MA_ConstraintID_Type HSA_CSA : MA_HSA_CSA_Type WaypointFollowing : MA_WaypointFollowingType CurveFollowing : MA_CurveControlType

	Speed : PathSegmentSpeedType
	Heading : MA_DirectionReferenceType
	SpeedChoice : MA_HSA_SpeedChoiceType
	SpeedValue : PathSegmentSpeedValueType
	CurveFitMethod : MA_CurveFitMethodEnum

Table A-4-1406: Vehicle Interface MA_TaskMT UCI Extension

TaskType		
Description	Identifies the type of this Task instance.	
Base Type	MA_TaskType	
Message Structure		
Field Name	Field Type	Field Usage
AirSample	AirSampleTaskType	Required
Description	Air sample includes direct sampling of the air (SAMPLE) and remote sensing with spectral analysis (SPECTROMETER) with the intent of detecting NBC events.	
AMTI	AMTI_TaskType	Required
Description	Indicates a Task to collect Air Moving Target Indicator (AMTI) data.	
AO	AO_TaskType	Required
Description	Indicates a Task to perform an optical emission such as laser designation.	
CAP	MA_CAP_TaskType	Required
Description	Indicates a Task to perform Combat Air Patrol.	
CargoDelivery	CargoDeliveryTaskType	Required
Description	Indicates a Task to transfer cargo between locations.	
COMINT	COMINT_TaskType	Required
Description	Indicates a Task to provide COMINT.	
CommRelay	CommRelayTaskType	Required
Description	Indicates a Task to provide communications relay support.	
CounterSpace	CounterSpaceTaskType	Required
Description	Indicates a Task to employ a CounterSpace capability.	
Escort	MA_EscortTaskType	Required
Description	Indicates a Task to escort another Entity or System.	
EA	EA_TaskType	Required
Description	Indicates a Task to provide electronic attack support to another System. It guides/constrains the EA System by specifying where it should fly, what it should protect and what the threat is.	
ESM	ESM_TaskType	Required
Description	Indicates a Task to collect ESM data.	
Flight	MA_FlightTaskType	Required

	Description	Indicates a Task to effect the flight path/plan of the System.
Jettison	MA_JettisonTaskType	Required
	Description	Indicates a Task to a jettisonable weapon from the system.
OrbitChange	OrbitChangeTaskType	Required
	Description	Indicates a task to perform an orbit change via a spacecraft maneuver.
OrbitalSurveillance	OrbitalSurveillanceTaskType	Required
	Description	Indicates an Orbital Surveillance Task.
OrbitalSurveillanceSensor	OrbitalSurveillanceSensorTaskType	Required
	Description	Indicates a task to perform orbital surveillance sensor tasking.
PO	PO_TaskType	Required
	Description	Indicates a Task to collect Passive Optical data, imagery and video as well as perform PO search and track capabilities.
Refuel	RefuelTaskType	Required
	Description	Indicates a Task for one System to refuel another.
SAR	SAR_TaskType	Required
	Description	Indicates a Task to collect a Synthetic Aperture Radar (SAR) image.
SMTI	SMTI_TaskType	Required
	Description	Indicates a Task to collect Moving Target Indicator (MTI) data.
Strike	StrikeTaskType	Required
	Description	Indicates a Task to kinetically attack/strike, with a weapon that can be released from the System.
SystemDeployment	SystemDeploymentTaskType	Required
	Description	Indicates a task to perform a deployment or release of a system at a specified location.
TacticalOrder	TacticalOrderTaskType	Required
	Description	Indicates a task to perform a tactical order.
WeatherRadar	WeatherRadarTaskType	Required
	Description	Indicates a task to collect weather radar data.

Table A-4-1407: Vehicle Interface MA_TaskMT - TaskType UCI Extension Field

TaskPlurality	
Description	Indicates whether the task is meant to be executed by a single entity or as a joint operation. A join operation implies forming a group prior to execution. A single entity could be a single system or a single pre-formed group.
Base Type	MA_TaskPluralityEnum
Message Structure	
Enumeration Literal	Description
UNSPECIFIED	Indicates the task plurality is unspecified, and should be defaulted or determined by the receiving system.

JOINT	Indicates the task is to be executed as a joint task. A group will be formed when this task is assigned.
SINGLE_ENTITY	Indicates the task is to be executed by a single entity. A single entity could be a single system or a single pre-existing group.

Table A-4-1408: Vehicle Interface MA_TaskMT - TaskPlurality UCI Extension Field

ConstraintID		
Description	Indicates any Constraints that apply to the Task (e.g FormationConstraint). A FormationConstraint implies that if a group is formed to execute this task, the referenced Constraint(s) should be applied to that group.	
Base Type	MA_ConstraintID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1409: Vehicle Interface MA_TaskMT - ConstraintID UCI Extension Field

HSA_CSA		
Description	This message shall be used to provide the ability to command a new flight vector to the Platform.	
Base Type	MA_HSA_CSA_Type	
Message Structure		
Field Name	Field Type	Field Usage
Altitude	AltitudeReferenceType	Optional
Description	Altitude hold value to be achieved and reference to altitude measurement source.	
Speed	PathSegmentSpeedType	Optional
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Direction	MA_DirectionChoiceType	Optional
Description	Defines heading or course type and reference to hold	

Table A-4-1410: Vehicle Interface MA_TaskMT - HSA_CSA UCI Extension Field

WaypointFollowing		
Description	This message shall be used to provide the ability to send a new waypoint path or segment for the Platform to follow.	
Base Type	MA_WaypointFollowingType	
Message Structure		
Field Name	Field Type	Field Usage

Route	MA_RouteType	Required
Description	Indicates the Paths and Segments that make up the Route to be flown.	

Table A-4-1411: Vehicle Interface MA_TaskMT - WaypointFollowing UCI Extension Field

CurveFollowing		
Description	Indicates the parameters for curve following control.	
Base Type	MA_CurveControlType	
Message Structure		
Field Name	Field Type	Field Usage
CurveSegments	MA_NURBS_PointType	Repeated
Description	Specifies the curve segments as a set of NURBS points.	
AppendCurve	EmptyType	Optional
Description	Specifies this curve will be appended to a previous curve command. This is only valid if the vehicle is currently executing a curve.	
EndOfCurveBehavior	MA_EndOfCurveBehaviorEnum	Optional
Description	Specifies the vehicle behavior at the completion of the curve.	

Table A-4-1412: Vehicle Interface MA_TaskMT - CurveFollowing UCI Extension Field

Speed		
Description	Defines speed type (reference frame) for all speed related fields in this message.	
Base Type	PathSegmentSpeedType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedChoice	PathSegmentSpeedChoiceType	Optional
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
SpeedOptimization	SpeedOptimizationEnum	Optional
Description	Indicates that the System will vary its speed autonomously according to the specified optimization algorithm.	

Table A-4-1413: Vehicle Interface MA_TaskMT - Speed UCI Extension Field

Heading		
Description	Defines heading type and reference to hold.	
Base Type	MA_DirectionReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
Value	AngleType	Required
Description	Indicates the heading or course value to hold.	

Reference	MA_HeadingReferenceEnum	Required
Description	Reference to type of heading or course given.	

Table A-4-1414: Vehicle Interface MA_TaskMT - Heading UCI Extension Field

SpeedChoice		
Description	Indicates the speed that the vehicle shall traverse the path segment. Speed can be represented as referenced speed (e.g., ground speed in m/s) or as a unitless Mach number.	
Base Type	MA_HSA_SpeedChoiceType	
Message Structure		
Field Name	Field Type	Field Usage
SpeedValue	PathSegmentSpeedValueType	Required
Description	Indicates speed in meters per second (m/s).	
MachValue	MachType	Required
Description	Indicates the speed reference for the associated speed value.	

Table A-4-1415: Vehicle Interface MA_TaskMT - SpeedChoice UCI Extension Field

SpeedValue		
Description	Indicates speed in meters per second (m/s).	
Base Type	PathSegmentSpeedValueType	
Message Structure		
Field Name	Field Type	Field Usage
Value	SpeedType	Required
Description	Indicates the speed along the PathSegment at the EndPoint.	
Reference	SpeedReferenceEnum	Required
Description	Indicates whether the given vehicle speed is reference to ground speed or true air speed.	

Table A-4-1416: Vehicle Interface MA_TaskMT - SpeedValue UCI Extension Field

CurveFitMethod	
Description	Method through which a curve should be fitted to the discretized points in ControlPoint.
Base Type	MA_CurveFitMethodEnum
Message Structure	
Enumeration Literal	Description
B_SPLINE	B-Spline (basis spline) fit.
BEZIER	Bezier curve fit.
CATMULL_ROM	Catmull-Rom spline fit.
NATURAL_CUBIC	Natural Cubic curve fit.

Table A-4-1417: Vehicle Interface MA_TaskMT - CurveFitMethod UCI Extension Field

4.5.9 MA_RoutePlanMT UCI Extension

MA_RoutePlanMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_RoutePlanMDT

Table A-4-1418: Vehicle Interface MA_RoutePlanMT UCI Extension

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_RoutePlanMDT	
Message Structure		
Field Name	Field Type	Field Usage
RoutePlanID	RoutePlanID_Type	Required
Description	Indicates a unique ID assigned to the RoutePlan. Minor updates to the Plan can be indicated by an update of the value in the child Version element. More significant updates, replacements, etc. might warrant a new Plan with a different child UUID value.	
PlanCommandID	RoutePlanCommandID_ChoiceType	Optional
Description	Indicates the unique ID of the *PlanCommand which the RoutePlan originated from.	
Plan	MA_RoutePlanType	Required
Description	Contains the details of the route plan.	
ForPlanningUseOnly	boolean	Required
Description	When TRUE, indicates the *Plan is to be used only for intermediate planning purposes. It will eventually be replaced/superseded by another *Plan or be discarded/abandoned. *Plans with this flag should only be used when explicitly referenced by other messages. These *Plans should never: trigger functionality, be subject to approvals, be activated, etc.	
PlanInputs	RoutePlanInputsType	Optional
Description	Indicates inputs that were given in the *PlanCommand (or equivalent automated replan) to create the Plan.	

Table A-4-1419: Vehicle Interface MA_RoutePlanMT - MessageData UCI Extension Field

4.5.10 MA_SystemManagementRequestMT UCI Extension

MA_SystemManagementRequestMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info

Ext. Fields	MessageData : MA_SystemManagementRequestMDT
	RequestType : MA_SystemManagementRequestType
	VehicleSettings : MA_VehicleCommandDataType

Table A-4-1420: Vehicle Interface MA_SystemManagementRequestMT UCI Extension

MessageData		
Description	This contains the message data.	
Base Type	MA_SystemManagementRequestMDT	
Message Structure		
Field Name	Field Type	Field Usage
AuthorityType	EntityManagementRequestAuthorityEnum	Optional
Description	Indicates whether this SystemManagementRequest is a request to change data or an order that must be followed. Defaults to REQUEST if not filled.	
RequestSource	RequestSourceEnum	Optional
Description	This element indicates the type of service requesting the change. Defaults to AUTOMATIC_INTERNAL if not filled.	
ReferenceSystemID	SystemID_Type	Required
Description	Indicates the system to be acted upon by this message.	
RequestType	MA_SystemManagementRequestType	Repeated
Description	Indicates the type of request to perform on a system.	
UpdateFromControllingUnit	boolean	Optional
Description	Indicates if this SystemManagementRequest came from the system controlling the referenced system. This indicates a higher confidence in the new data.	
Source	SystemMessageIdentifierType	Optional
Description	Indicates the system initiating this request and allows the requesting Service, Activity, or Network to be specified.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message.	
RequestState	RequestStateEnum	Required
Description	The state of the request message data. Indicates if a request message is a NEW request, an UPDATE to a request, or a CANCEL of a request.	

Table A-4-1421: Vehicle Interface MA_SystemManagementRequestMT - MessageData UCI Extension Field

RequestType		
Description	Indicates the type of request to perform on a system.	
Base Type	MA_SystemManagementRequestType	
Message Structure		
Field Name	Field Type	Field Usage
SetMode	MessageModeEnum	Required

Description	Indicates a request to modify the mode of a system.	
SetIdentity	SystemIdentityType	Required
Description	Indicates a request to set the identity of a system.	
SetLink16Metadata	Link16MetadataType	Required
Description	Indicates a request to modify the Link16Metadata of a system.	
SetVoiceControl	VoiceControlType	Required
Description	Set the voice control frequency of a system.	
SetSensorEntityReporting	boolean	Required
Description	When TRUE, indicates an order to report all locally derived sensor, signal, track or Entity data. When FALSE, indicates an order to stop reporting.	
VehicleSettings	MA_VehicleCommandDataType	Required
Description	Indicates a request to modify vehicle settings.	

Table A-4-1422: Vehicle Interface MA_SystemManagementRequestMT - RequestType UCI Extension Field

VehicleSettings		
Description	Indicates a request to modify vehicle settings.	
Base Type	MA_VehicleCommandDataType	
Message Structure		
Field Name	Field Type	Field Usage
VehicleAction	VehicleActionEnum	Optional
Description	Defines vehicle actions that can be done along a path segment of a route.	
IFF_Settings	IFF_Type	Optional
Description	If present the IFF settings for this vehicle will be changed along this path segment.	
SurvivabilityMode	VehicleSurvivabilityModeEnum	Optional
Description	Specifies that the vehicle should put itself into a more survivable mode. Different vehicles will have specific behaviors that reduce the signature of the vehicle (doors closed, minimal use of flaps, etc.) If this element is not present then it is assumed that the aircraft being configured has no survivability mode.	
LostCommTimeout	DurationType	Optional
Description	Defines the lost communication contingency timeout. When this timeout value is exceeded, the AV considers that lost communication has occurred and begins to perform contingency measures.	
LOS	boolean	Optional
Description	Use Line Of Sight (LOS) communication as backup contingency.	
LossOfLinkProcessing	VehicleLossOfLinkProcessingEnum	Optional
Description	Specifies whether the vehicle should invoke special Loss of Link processing. This could be turned off if the vehicle is going to be in a known and accepted lost communication situation.	
CommAllocationAction	CommAllocationActionType	Optional
Description	Indicates a change of communication allocation.	

QNH_Setting	PressureType	Optional
Description	Represents the barometric altimeter setting for correct MSL reading, commonly known as QNH, requested. Expressed in kilopascals (kPa).	

Table A-4-1423: Vehicle Interface MA_SystemManagementRequestMT - VehicleSettings UCI Extension Field

4.5.11 MA_SystemManagementRequestStatusMT UCI Extension

MA_SystemManagementRequestStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_SystemManagementRequestStatusMDT

Table A-4-1424: Vehicle Interface MA_SystemManagementRequestStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_SystemManagementRequestStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	Indicates the ID of the system responding to the SystemManagementRequest.	
ServiceID	ServiceID_Type	Required
Description	Indicates the ID of the service responding to the SystemManagementRequest.	
RequestID	RequestID_Type	Required
Description	Indicates the unique ID of the request message corresponding to this status message.	
RequestProcessingState	RequestProcessingStateEnum	Required
Description	Indicates the status of the request message. Indicates how the receiver of the request has responded to the request message.	
RequestProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling RequestProcessingState element. This element is only expected when the Request is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-1425: Vehicle Interface MA_SystemManagementRequestStatusMT - MessageData UCI Extension Field

4.5.12 MA_MissionPlanActivationCommandMT UCI Extension

MA_MissionPlanActivationCommandMT	
Description	See the annotation in the associated message for an overall description of the message and this type.

	See the XSD File for more info
Ext. Fields	OpPlanID : MA_OpPlanID_Type ApplicableToIDs : MA_PackageSystemType ByExecutionPlanSet : MA_ExecutionPlanSetActivationType MessageData : MA_MissionPlanActivationCommandMDT ActivationDetails : MA_MissionPlanActivationDetailsType Applicability : MA_PlanApplicabilityType OpPlan : MA_OpPlanActivationType Command : MA_MissionPlanActivationCommandType

Table A-4-1426: Vehicle Interface MA_MissionPlanActivationCommandMT UCI Extension

OpPlanID		
Description	Indicates the unique ID of the TaskPlan to perform the sibling activation command on.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1427: Vehicle Interface MA_MissionPlanActivationCommandMT - OpPlanID UCI Extension Field

ApplicableToIDs		
Description	Indicates the unique ID of the System (e.g. aircraft, ground-based sensor, ship, satellite, site, etc.) or Package whose Capabilities, performance, position, etc. the plan is based on. If the plan is a fully detailed one that can be activated and executed, this element indicates the System intended/responsible for executing the plan and producing the intended effects. See annotations in sibling element PlannedForID which provide additional context.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required

	Description	Indicates applies to ALL entities.	
NONE		EmptyType	Required
	Description	Indicates applies to NO entities.	
PackageID		PackageID_Type	Required
	Description	The ID of a Package.	
SystemID		SystemID_Type	Required
	Description	The ID of an ACP or C2 Operator.	

Table A-4-1428: Vehicle Interface MA_MissionPlanActivationCommandMT - ApplicableToIDs UCI Extension Field

ByExecutionPlanSet		
Description	Indicates simultaneous activation of all sub-*Plans (ActivityPlan, RoutePlan for example) of an *ExecutionPlanSet into the same activation state.	
Base Type	MA_ExecutionPlanSetActivationType	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPlanSetID	ExecutionPlanSetID_Type	Required
Description	Indicates the unique ID of the execution plan set.	
CommandType	PlanActivationCommandEnum	Required
Description	Indicates the activation to perform on the associated execution plan set.	

Table A-4-1429: Vehicle Interface MA_MissionPlanActivationCommandMT - ByExecutionPlanSet UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanActivationCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	MissionPlanActivationCommandID_Type	Required
Description	The ID of the Mission Plan Activation Command. Used to reference the command when providing status.	
ApprovalManagementCommandID	CommandID_Type	Repeated
Description	Indicates the command(s) that initiated the Activation Approvals for the *Plans identified in the sibling Command element. The approval status can be found by locating the corresponding MissionPlanActivationApprovalStatus with the ID identified here. The ActivationCommand identified in the sibling Command\ActivationDetails should be verified against the ActivationType that is identified in the associated MissionPlanActivationApprovalCommand.	
CommandState	CommandStateEnum	Required

Description	The state of the command message data. Indicates if a command message is a NEW command, an UPDATE to an existing command, or a CANCEL of an existing command.	
Command	MA_MissionPlanActivationCommandType	Repeated
Description	Indicates command or commands to change the activation state of a MissionPlan and/or its subplans or subordinate plans. If more than one instance of this element is given, each should correspond to a different MissionPlanID. For example, if the intent is to transition from one MissionPlan to another, the new MissionPlan can be activated in one instance and the old MissionPlan can be deactivated in another instance.	
Applicability	MA_PlanApplicabilityType	Optional
Description	Indicates the System or Systems who are being commanded to activate a specified plan.	

Table A-4-1430: Vehicle Interface MA_MissionPlanActivationCommandMT - MessageData UCI Extension Field

ActivationDetails		
Description	Indicates the commanded activation details.	
Base Type	MA_MissionPlanActivationDetailsType	
Message Structure		
Field Name	Field Type	Field Usage
ByMissionPlan	MissionPlanActivationType	Required
Description	Indicates simultaneous activation of all sub-*Plans (RoutePlan, RouteActivityPlan for example) of a MissionPlan into the same activation state.	
BySubPlan	MA_MissionPlanSubplanActivationType	Required
Description	Indicates activation by sub-*Plan (RoutePlan or OrbitPlan for example) of the MissionPlan, with potentially different states for each.	
ByExecutionPlanSet	MA_ExecutionPlanSetActivationType	Required
Description	Indicates simultaneous activation of all sub-*Plans (ActivityPlan, RoutePlan for example) of an *ExecutionPlanSet into the same activation state.	

Table A-4-1431: Vehicle Interface MA_MissionPlanActivationCommandMT - ActivationDetails UCI Extension Field

Applicability		
Description	Indicates the System or Systems who are being commanded to activate a specified plan.	
Base Type	MA_PlanApplicabilityType	
Message Structure		
Field Name	Field Type	Field Usage
PlannedForID	SystemID_Type	Optional
Description	Indicates the System which is the intended user of the plan. This type can have multiple meanings, but primarily enables multiple systems, possibly at different levels of warfare or C2 hierarchy levels, to maintain independent plans for the same System identified in the sibling ApplicableToID element.	

	For instance, during planning at the operational level of warfare, a non-tactical planning service may create and simulate execution of plans internally. Such plans would identify the operational level System as the PlannedFor System; they would never be activated or executed by a real world tactical System. Alternatively, the operational level System could have a tactical planning service that is functionally capable and responsible for creating fully detailed plans that can be activated and executed by real world tactical Systems. Such a tactical planning service could be used even if the operational level System does not have control authority over the tactical System at the time the plan is created. Such plans would identify the tactical level System as the PlannedFor System. As a final example, a plan which is intended to be used by the same System which produces its intended effects would have a common SystemID between the sibling PlannedForID and ApplicableToID elements. This element does not replace existing approval policies, authorization or control status and therefore does not automatically imply that the PlannedFor System has any kind of authority over the receiving system.	
ApplicableToIDs	MA_PackageSystemType	Required
Description	Indicates the unique ID of the System (e.g. aircraft, ground-based sensor, ship, satellite, site, etc.) or Package whose Capabilities, performance, position, etc. the plan is based on. If the plan is a fully detailed one that can be activated and executed, this element indicates the System intended/responsible for executing the plan and producing the intended effects. See annotations in sibling element PlannedForID which provide additional context.	

Table A-4-1432: Vehicle Interface MA_MissionPlanActivationCommandMT - Applicability UCI Extension Field

OpPlan		
Description	Indicates commanded details for activation of an OpPlan.	
Base Type	MA_OpPlanActivationType	
Message Structure		
Field Name	Field Type	Field Usage
OpPlanID	MA_OpPlanID_Type	Required
Description	Indicates the unique ID of the TaskPlan to perform the sibling activation command on.	
CommandType	PlanActivationCommandEnum	Required
Description	Indicates the activation to perform on the associated TaskPlan.	

Table A-4-1433: Vehicle Interface MA_MissionPlanActivationCommandMT - OpPlan UCI Extension Field

Command	
Description	Indicates command or commands to change the activation state of a MissionPlan and/or its subplans or subordinate plans. If more than one instance of this element is given, each should correspond to a different MissionPlanID. For example, if the intent is to transition from one MissionPlan to another, the new MissionPlan can be activated in one instance and the old

	MissionPlan can be deactivated in another instance.	
Base Type	MA_MissionPlanActivationCommandType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	Indicates the unique ID of the MissionPlan whose commanded activation state or states are summarized in the sibling element.	
ActivationDetails	MA_MissionPlanActivationDetailsType	Required
Description	Indicates the commanded activation details.	

Table A-4-1434: Vehicle Interface MA_MissionPlanActivationCommandMT - Command UCI Extension Field

4.5.13 MA_MissionPlanActivationCommandStatusMT UCI Extension

MA_MissionPlanActivationCommandStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	Plans : MA_PlansReferenceType MessageData : MA_MissionPlanActivationCommandStatusMDT ActivationCommandByState : MA_PlanActivationStatusType

Table A-4-1435: Vehicle Interface MA_MissionPlanActivationCommandStatusMT UCI Extension

Plans		
Description	Indicates the Plan or Plans in the sibling CommandState.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated

Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-1436: Vehicle Interface MA_MissionPlanActivationCommandStatusMT - Plans UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanActivationCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	MissionPlanActivationCommandID_Type	Required
Description	The ID of the MissionPlanActivationCommand this status pertains to.	
ActivationStatus	PlanCommandStatusType	Required
Description	Indicates the status of the MissionPlanActivationCommand.	
ActivationCommandByState	MA_PlanActivationStatusType	Repeated
Description	Indicates plans in a given commanded activation state. List size allows for each available PlanActivationCommandState to be represented.	

Table A-4-1437: Vehicle Interface MA_MissionPlanActivationCommandStatusMT - MessageData UCI Extension Field

ActivationCommandByState		
Description	Indicates plans in a given commanded activation state. List size allows for each available PlanActivationCommandState to be represented.	
Base Type	MA_PlanActivationStatusType	
Message Structure		
Field Name	Field Type	Field Usage
PlanActivationCommandState	PlanActivationStateEnum	Required
Description	Indicates an activation command state that one or more *Plans is in.	
Plans	MA_PlansReferenceType	Required
Description	Indicates the Plan or Plans in the sibling CommandState.	

Table A-4-1438: Vehicle Interface MA_MissionPlanActivationCommandStatusMT - ActivationCommandByState UCI Extension Field

4.5.14 MA_FlightCapabilityStatusMT UCI Extension

MA_FlightCapabilityStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	Capability : MA_FlightCapabilityType MessageData : MA_FlightCapabilityMDT

Table A-4-1439: Vehicle Interface MA_FlightCapabilityStatusMT UCI Extension

Capability		
Description	Provides a list of the specific Flight Capabilities as defined by the FlightCapabilityEnum.	
Base Type	MA_FlightCapabilityType	
Message Structure		
Field Name	Field Type	Field Usage
CapabilityType	MA_FlightCapabilityEnum	Repeated
Description	Indicates the type of Flight capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
FlightCapabilityPerformanceProfile	MA_FlightCapabilityPerformanceProfileType	Optional
Description	Provides per-control mode performance parameters. Enables autonomy commands to properly conform to envelope limits or limit summary values before sending a FlightCommand to the vehicle.	
AcceptedInterface	CapabilityControlInterfacesEnum	Repeated
Description	Indicates an accepted control interface for the Capability. See enumeration annotations for further details. List size for this element is based on "Select All That Apply" condition.	
CommsRequired	boolean	Optional
Description	Indicates whether (TRUE) or not (FALSE) communications are required to use the Capability. Omitted is equivalent to FALSE. For example, an unmanned system with no onboard storage would require communications to disseminate the outputs of the Capability.	
CapabilityID	CapabilityID_Type	Required
Description	Indicates the unique ID of this Capability. This ID is used to invoke the Capability via Command messages, report its activity via Activity messages, etc.	
DomainPairing	EnvironmentPairingEnum	Repeated
Description	Indicates the domain/environment which the Capability is employed from and the "target" domain/environment. See enumerated type annotations for further details. List size for this element is based on "Select All That Apply" condition.	
ProductOutput	ProductOutputType	Repeated
Description	Indicates a Product that can be an output of the Capability.	

PackageOperation	PackageOperationEnum	Optional
Description	Indicates if and how the operation of the Capability can be coordinated with a partner Capability of another System in a multi-System Package. Omitting this element is equivalent to the enumerate NO_PACKAGE_OPERATION. The actual Package configuration including per-Capability partnering between Systems is given in the PackageStatus message. For example, a System that can perform cooperative geolocation could advertise with this element in the ESM_Capability message. A System that can navigate in a swarm with other Systems could advertise with this element in the FlightCapability message.	

Table A-4-1440: Vehicle Interface MA_FlightCapabilityStatusMT - Capability UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_FlightCapabilityMDT	
Message Structure		
Field Name	Field Type	Field Usage
Capability	MA_FlightCapabilityType	Repeated
Description	Provides a list of the specific Flight Capabilities as defined by the FlightCapabilityEnum.	
AvailableMDF	MDF_Type	Repeated
Description	Indicates a Mission Data File (MDF) that is available for use. All MDFs currently available for use should be listed. An MDF is a collection of data, organized into files, that is used to tailor, configure or otherwise affect the behavior of a Capability. MDFs can vary from mission to mission or even by phases of a single mission. They are generally developed in pre-mission planning and are unique for each Subsystem model. Their content is not standardized by UCI, but the mechanism for advertising their availability and activating them is. Their content is abstracted by the UCI concept of Capability.	

Table A-4-1441: Vehicle Interface MA_FlightCapabilityStatusMT - MessageData UCI Extension Field

4.5.15 MA_SystemNotificationMT UCI Extension

MA_SystemNotificationMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_SystemNotificationMDT NotificationDetail : CannotComplyType NotificationDetail : CannotComplyType

Table A-4-1442: Vehicle Interface MA_SystemNotificationMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type for details.

Base Type	MA_SystemNotificationMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemSubjectIDs	MA_PackageSystemType	Required
Description	Indicates the subject of the Notification, the thing which the Notification is about.	
SystemPerspective	NotificationPerspectiveEnum	Repeated
Description	Indicates a perspective (characteristic, behavior and/or change) of the Subject that is the basis of the Notification. List size for this element is based on "Select All That Apply" condition.	
AssociatedMessage	AssociatedMessageType	Repeated
Description	Indicates a message that is associated with the Notification.	
NotificationDetail	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the unsuccessful processing of the sibling AssociatedMessage element. This element is only expected when the Associated Message processing is not successful	
NotificationID	NotificationID_Type	Required
Description	Indicates the unique ID of the Notification.	
NotificationState	NotificationStateEnum	Required
Description	Indicates the current state within an enumerated state machine that characterizes the life cycle of a notification.	
Timestamp	DateTimeType	Required
Description	The time at which the Notification was originally triggered (ex: event time).	
Source	NotificationSourceType	Required
Description	Indicates the originating source of the Notification.	
Severity	NotificationSeverityEnum	Required
Description	Indicates the overall severity of the notification. Informational notifications are meant to provide informational context of events. Indicates the existence of a hazardous condition requiring immediate action to prevent loss of life, equipment damage, or abortion of the mission. Critical notifications indicate the need for immediate attention.	
AppliesTo	SubjectType	Repeated
Description	Indicates an Asset that the Notification applies to and/or is affected by. Optional when the Notification characterizes the Subject without regard for Assets it might affect. Omission of this element doesn't necessarily mean the Notification isn't applicable to an Asset.	
NotificationNarrative	VisibleString1024Type	Optional
Description	Human readable message for display to an operator.	

Table A-4-1443: Vehicle Interface MA_SystemNotificationMT - MessageData UCI Extension Field

NotificationDetail	
Description	Indicates details regarding the reason for and/or a contributing factor to the unsuccessful processing of the sibling AssociatedMessage element. This element is only expected when the Associated Message processing is not

	successful	
Base Type	CannotComplyType	
Message Structure		
Field Name	Field Type	Field Usage
Reason	CannotComplyEnum	Required
Description	Indicates the reason why an action (Task, [Capability]Command, [SupportingCapability]Command, [Capability]Activity, etc.) was rejected, interrupted, unallocated, failed and/or generally can't be completed satisfactorily. See enumeration annotations for further details.	
Description	VisibleString1024Type	Optional
Description	Indicates a human-readable text description of the reason for the "can't comply".	
AssociatedID	ID_Type	Optional
Description	Indicates an ID corresponding to another object that is associated with or the cause of the "can't comply".	

Table A-4-1444: Vehicle Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field

NotificationDetail		
Description	Indicates details regarding the reason for and/or a contributing factor to the unsuccessful processing of the sibling AssociatedMessage element. This element is only expected when the Associated Message processing is not successful	
Base Type	CannotComplyType	
Message Structure		
Field Name	Field Type	Field Usage
Reason	CannotComplyEnum	Required
Description	Indicates the reason why an action (Task, [Capability]Command, [SupportingCapability]Command, [Capability]Activity, etc.) was rejected, interrupted, unallocated, failed and/or generally can't be completed satisfactorily. See enumeration annotations for further details.	
Description	VisibleString1024Type	Optional
Description	Indicates a human-readable text description of the reason for the "can't comply".	
AssociatedID	ID_Type	Optional
Description	Indicates an ID corresponding to another object that is associated with or the cause of the "can't comply".	

Table A-4-1445: Vehicle Interface MA_SystemNotificationMT - NotificationDetail UCI Extension Field

4.5.16 MA_TaskStatusMT UCI Extension

MA_TaskStatusMT	
Description	See the annotation in the associated message for an overall description of the message and this type.

	See the XSD File for more info
Ext. Fields	Plans : MA_PlansReferenceType OpPlanID : MA_OpPlanID_Type ExecutingSystemOrPackage : MA_PackageSystemType MessageData : MA_TaskStatusMDT Traceability : MA_RequirementStatusTraceabilityType

Table A-4-1446: Vehicle Interface MA_TaskStatusMT UCI Extension

Plans		
Description	Indicates *Plans the Requirement is associated with.	
Base Type	MA_PlansReferenceType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-1447: Vehicle Interface MA_TaskStatusMT - Plans UCI Extension Field

OpPlanID

Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1448: Vehicle Interface MA_TaskStatusMT - OpPlanID UCI Extension Field

ExecutingSystemOrPackage		
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-1449: Vehicle Interface MA_TaskStatusMT - ExecutingSystemOrPackage UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_TaskStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage

TaskID	TaskID_Type	Required
Description	Indicates the unique ID of the Task whose execution status is being reported.	
ExecutingSystemOrPackage	MA_PackageSystemType	Required
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
ExecutionState	RequirementExecutionStateEnum	Required
Description	Identifies the state of the Requirement.	
ExecutionStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling State element. This element is only expected when the State is in a potentially undesirable state such as failed or completed with less than optimum results. It is strongly encouraged for transitions to failed or dropped.	
ActualTiming	RequirementTimingType	Repeated
Description	Indicates actual timing status for the Requirement. Allows for defining for each timing type (RequirementTimingEnum).	
PercentCompleted	PercentType	Optional
Description	Percentage of assigned Requirement completion. The percentage increments until the Requirement has COMPLETED or FAILED. A percent complete of 0 indicates the Requirement has not yet begun execution, and a failed Requirement may have any percentage between 1 - 99.	
Traceability	MA_RequirementStatusTraceabilityType	Optional
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.	
Metrics	MetricsType	Optional
Description	Specifies the actual metrics associated with the Requirements.	

Table A-4-1450: Vehicle Interface MA_TaskStatusMT - MessageData UCI Extension Field

Traceability	
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture.

	For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.	
Base Type	MA_RequirementStatusTraceabilityType	
Message Structure		
Field Name	Field Type	Field Usage
Plans	MA_PlansReferenceType	Optional
Description	Indicates *Plans the Requirement is associated with.	
PlannedActivityID	PlannedActivityID_Type	Repeated
Description	Indicates a specific Planned Activity the Requirement is associated with.	
CapabilityID	CapabilityID_Type	Repeated
Description	Identifies a specific Capability the Requirement is associated with.	
CommandID	CommandID_Type	Repeated
Description	Indicates the ID of an associated [Capability]Command.	
ActivityID	ActivityID_Type	Repeated
Description	Indicates the ID of an associated actual/executing/executed Activity.	

Table A-4-1451: Vehicle Interface MA_TaskStatusMT - Traceability UCI Extension Field

4.5.17 MA_ResponseMT UCI Extension

MA_ResponseMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_ResponseMDT

Table A-4-1452: Vehicle Interface MA_ResponseMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ResponseMDT	
Message Structure		
Field Name	Field Type	Field Usage
ResponseID	ResponseID_Type	Required
Description	Indicates the unique ID of the Response. Minor updates to the Response can be indicated by an update of the value in the child Version element. More	

	significant updates, replacements, etc. might warrant a new instance with a different child UUID value.	
ResponseType	ResponseTypeEnum	Repeated
Description	Indicates the types of Response options included in the message. List size for this element is based on "Select All That Apply" condition.	
ResponseManagementConstraints	RequirementConstraintsType	Optional
Description	Indicates monitoring constraints on the Response. The constraint type used here is common to all Requirement types: Effect, Action, Task, [Capability]Command, Response. Requirement constraints can be 1) given in a [Requirement] message, 2) overridden as a planning input in a [Requirement]PlanCommand message, 3) further refined/overridden during plan creation and reported in a [Requirement]Plan message to inform subsequent planning or execution. See sibling Option element annotation for an overall description of Response structure. Constraints given here aren't conveyed to instantiated Response options for a particular triggering event. The constraints given here apply to Response management (planning, allocation and trigger monitoring prior to a triggering event). Constraints to apply to instantiated Response options, if any, are given elsewhere in the message.	
ResponseManagementGuidance	RequirementGuidanceType	Optional
Description	Indicates guidance on planning and C2 of the Response.	
ResponsePlurality	MA_TaskPluralityEnum	Optional
Description	Indicates whether the response applies a single entity or as a joint condition. A joint condition implies condisation of the response trigger and activation of the response by all associated entities.	
Option	MA_ResponseOptionDetailsType	Repeated
Description	Indicates an Option of the Response. Responses are designed to be flexible. A Response is a set of prioritized Options to address an anticipated triggering event, events or event sequence in the battlespace. Responses are allocated to Systems via a ResponsePlan. When a ResponsePlan is activated, monitoring for the triggering events in the Options begins. When a triggering event happens, the applicable Option(s) are evaluated.	
RequirementsTemplate	MA_RequirementsTemplateType	Repeated
Description	The sibling Option element associates triggering events with a desired Response one of which is to use this element, a Requirements template, to generate or change one or more Requirements messages/objects (Effect, Action, Task, [Capability]Command). An instance of this element is a RequirementsTemplate; it indicates the types of Requirements to generate or update and their details. Each RequirementsTemplate has a unique ID and therefore can be used for multiple Options.	
Metadata	RequirementMetadataType	Optional
Description	Indicates traceability and other metadata associated with the Response.	

Table A-4-1453: Vehicle Interface MA_ResponseMT - MessageData UCI Extension Field

4.5.18 MA_MissionPlanExecutionStatusMT UCI Extension

MA_MissionPlanExecutionStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	ExecutionPlanSetStatus : MA_ExecutionPlanSetExecutionStateType PlanExecutionStatus : MA_MissionPlanExecutionStateType MessageData : MA_MissionPlanExecutionStatusMDT

Table A-4-1454: Vehicle Interface MA_MissionPlanExecutionStatusMT UCI Extension

ExecutionPlanSetStatus		
Description	Indicates the execution state of an execution plan set of the MissionPlan indicated by the sibling MissionPlanID element.	
Base Type	MA_ExecutionPlanSetExecutionStateType	
Message Structure		
Field Name	Field Type	Field Usage
ExecutionPlanSetID	ExecutionPlanSetID_Type	Required
Description	Indicates the unique ID of the execution plan set.	
ExecutionPlanSetExecutionState	PlanExecutionStateEnum	Required
Description	The current state of the execution plan set.	

Table A-4-1455: Vehicle Interface MA_MissionPlanExecutionStatusMT - ExecutionPlanSetStatus UCI Extension Field

PlanExecutionStatus		
Description	Indicates the execution state of a MissionPlan of the System indicated by the sibling SystemID element.	
Base Type	MA_MissionPlanExecutionStateType	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	The ID of the MissionPlan this status pertains to.	
PlanExecutionState	PlanExecutionStateEnum	Required
Description	The current state of the plan.	
ExecutionPlanSetStatus	MA_ExecutionPlanSetExecutionStateType	Repeated
Description	Indicates the execution state of an execution plan set of the MissionPlan indicated by the sibling MissionPlanID element.	

Table A-4-1456: Vehicle Interface MA_MissionPlanExecutionStatusMT - PlanExecutionStatus UCI Extension Field

MessageData

Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanExecutionStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required
Description	The unique ID of the System whose Plan is being statused.	
Source	SystemSourceEnum	Required
Description	Indicates the source of the data in sibling elements. See enumeration annotations for further details.	
PlanExecutionStatus	MA_MissionPlanExecutionStateType	Repeated
Description	Indicates the execution state of a MissionPlan of the System indicated by the sibling SystemID element.	

Table A-4-1457: Vehicle Interface MA_MissionPlanExecutionStatusMT - MessageData UCI Extension Field

4.5.19 MA_MissionPlanActivationStatusMT UCI Extension

MA_MissionPlanActivationStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	OpPlanID : MA_OpPlanID_Type MessageData : MA_MissionPlanActivationStatusMDT Plans : MA_PlansReferenceBaseType SubPlanActivationState : MA_PlanActivationStateType

Table A-4-1458: Vehicle Interface MA_MissionPlanActivationStatusMT UCI Extension

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional

Description	Human readable text label with content meaningful to human operators.
-------------	---

Table A-4-1459: Vehicle Interface MA_MissionPlanActivationStatusMT - OpPlanID UCI Extension Field

MessageData		
Description	Indicates the data being conveyed by the message.	
Base Type	MA_MissionPlanActivationStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
MissionPlanID	MissionPlanID_Type	Required
Description	The ID of the MissionPlan this status pertains to.	
PlanActivationState	PlanActivationStateEnum	Required
Description	Indicates the activation state of the MissionPlan.	
SubPlanActivationState	MA_PlanActivationStateType	Repeated
Description	Indicates the activation state of a SubPlan or SubPlans of the associated MissionPlan. An instance of this element should include all of the SubPlans in a given state; the cardinality is based in the number of states in the associated activation state enumerated type.	

Table A-4-1460: Vehicle Interface MA_MissionPlanActivationStatusMT - MessageData UCI Extension Field

Plans		
Description	Indicates the Plan or Plans in the sibling ActivationState.	
Base Type	MA_PlansReferenceBaseType	
Message Structure		
Field Name	Field Type	Field Usage
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	

ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-1461: Vehicle Interface MA_MissionPlanActivationStatusMT - Plans UCI Extension Field

SubPlanActivationState		
Description	Indicates the activation state of a SubPlan or SubPlans of the associated MissionPlan. An instance of this element should include all of the SubPlans in a given state; the cardinality is based in the number of states in the associated activation state enumerated type.	
Base Type	MA_PlanActivationStateType	
Message Structure		
Field Name	Field Type	Field Usage
ActivationState	PlanActivationStateEnum	Required
Description	Indicates an activation state that one or more *Plans is in.	
Plans	MA_PlansReferenceBaseType	Required
Description	Indicates the Plan or Plans in the sibling ActivationState.	

Table A-4-1462: Vehicle Interface MA_MissionPlanActivationStatusMT - SubPlanActivationState UCI Extension Field

4.5.20 MA_TaskCommandStatusMT UCI Extension

MA_TaskCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_TaskCommandStatusMDT

Table A-4-1463: Vehicle Interface MA_TaskCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_TaskCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
Activity	ResultingActivityType	Repeated
Description	Indicates an Activity that satisfies the associated Command. This element is required when the sibling State element indicates ACCEPTED.	

CommandID	CommandID_Type	Required
Description	Indicates the unique ID of the command corresponding to this status message.	
CommandProcessingState	CommandProcessingStateEnum	Required
Description	Indicates the state of the command. The command state machine assumes that the Command and CommandStatus messaging interaction is only used to communicate the desired Command to the Subsystem or Service. The state machine and messaging terminates as soon as the host accepts or rejects the Command. See enumeration annotations for further details.	
CommandProcessingStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling CommandProcessingState element. This element is only expected when the Command is in a potentially undesirable state such as rejected, canceled or accepted with less than optimum results expected.	

Table A-4-1464: Vehicle Interface MA_TaskCommandStatusMT - MessageData UCI Extension Field

4.5.21 MA_TaskCommandMT UCI Extension

MA_TaskCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_TaskCommandMDT

Table A-4-1465: Vehicle Interface MA_TaskCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_TaskCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Command	MA_TaskCommandType	Repeated
Description	Indicates an instance of a Task Capability command. A Capability command message can have multiple command instances to allow a sequence of related commands in a single coherent message. Each command instance reports status via a separate, independent Capability CommandStatus message.	

Table A-4-1466: Vehicle Interface MA_TaskCommandMT - MessageData UCI Extension Field

4.5.22 MA_ActionStatusMT UCI Extension

MA_ActionStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	Traceability : MA_RequirementStatusTraceabilityType

	Plans : MA_PlansReferenceType OpPlanID : MA_OpPlanID_Type MessageData : MA_ActionStatusMDT ExecutingSystemOrPackage : MA_PackageSystemType
--	---

Table A-4-1467: Vehicle Interface MA_ActionStatusMT UCI Extension

Traceability		
Description		Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.
Base Type		MA_RequirementStatusTraceabilityType
Message Structure		
Field Name	Field Type	Field Usage
Plans	MA_PlansReferenceType	Optional
Description	Indicates *Plans the Requirement is associated with.	
PlannedActivityID	PlannedActivityID_Type	Repeated
Description	Indicates a specific Planned Activity the Requirement is associated with.	
CapabilityID	CapabilityID_Type	Repeated
Description	Identifies a specific Capability the Requirement is associated with.	
CommandID	CommandID_Type	Repeated
Description	Indicates the ID of an associated [Capability]Command.	
ActivityID	ActivityID_Type	Repeated
Description	Indicates the ID of an associated actual/executing/executed Activity.	

Table A-4-1468: Vehicle Interface MA_ActionStatusMT - Traceability UCI Extension Field

Plans		
Description		Indicates *Plans the Requirement is associated with.
Base Type		MA_PlansReferenceType
Message Structure		
Field Name	Field Type	Field Usage

MissionPlanID	MissionPlanID_Type	Repeated
Description	Indicates a reference to a MissionPlan.	
TaskPlanID	TaskPlanID_Type	Repeated
Description	Indicates a reference to a TaskPlan.	
OrbitPlanID	OrbitPlanID_Type	Repeated
Description	Indicates a reference to an OrbitPlan.	
OrbitActivityPlanID	OrbitActivityPlanID_Type	Repeated
Description	Indicates a reference to an OrbitActivityPlan.	
RoutePlanID	RoutePlanID_Type	Repeated
Description	Indicates a reference to a RoutePlan.	
RouteActivityPlanID	RouteActivityPlanID_Type	Repeated
Description	Indicates a reference to a RouteActivityPlan.	
ActivityPlanID	ActivityPlanID_Type	Repeated
Description	Indicates a reference to an ActivityPlan.	
EffectPlanID	EffectPlanID_Type	Repeated
Description	Indicates a reference to an EffectPlan.	
ActionPlanID	ActionPlanID_Type	Repeated
Description	Indicates a reference to an ActionPlan.	
ResponsePlanID	ResponsePlanID_Type	Repeated
Description	Indicates a reference to an ResponsePlan.	
OpPlanID	MA_OpPlanID_Type	Repeated
Description	Indicates a reference to an OpPlan.	

Table A-4-1469: Vehicle Interface MA_ActionStatusMT - Plans UCI Extension Field

OpPlanID		
Description	Indicates a reference to an OpPlan.	
Base Type	MA_OpPlanID_Type	
Message Structure		
Field Name	Field Type	Field Usage
Version	unsignedInt	Optional
Description	Indicates an incremental version of an item in which only minor changes have been made. An example of a change that would require a new UUID and not just a new version would be for changes that affect task allocations or changes that require re-approval.	
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional

Description	Human readable text label with content meaningful to human operators.
-------------	---

Table A-4-1470: Vehicle Interface MA_ActionStatusMT - OpPlanID UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_ActionStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
ActionID	ActionID_Type	Required
Description	Indicates the unique ID of the Action whose execution status is given by sibling elements.	
ExecutingSystemOrPackage	MA_PackageSystemType	Required
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
ExecutionState	RequirementExecutionStateEnum	Required
Description	Identifies the state of the Requirement.	
ExecutionStateReason	CannotComplyType	Optional
Description	Indicates details regarding the reason for and/or a contributing factor to the sibling State element. This element is only expected when the State is in a potentially undesirable state such as failed or completed with less than optimum results. It is strongly encouraged for transitions to failed or dropped.	
ActualTiming	RequirementTimingType	Repeated
Description	Indicates actual timing status for the Requirement. Allows for defining for each timing type (RequirementTimingEnum).	
PercentCompleted	PercentType	Optional
Description	Percentage of assigned Requirement completion. The percentage increments until the Requirement has COMPLETED or FAILED. A percent complete of 0 indicates the Requirement has not yet begun execution, and a failed Requirement may have any percentage between 1 - 99.	
Traceability	MA_RequirementStatusTraceabilityType	Optional
Description	Indicates traceability to the sources and implementation of the Requirement. During the life cycle of execution of a Requirement, the traceability can change/update. Traceability can vary depending on a given System's architecture. For example, traceability to only a CommandID is reasonable if the architecture includes [Capability]Commands without *Plans or [Capability]Activities. Both CommandID and ActivityID are reasonable for architectures where a single [Capability]Command could generate one or multiple [Capability]Activities, e.g. a SAR command could result in multiple activities to cover the area. ActivityID only is reasonable for architectures where [Capability]Activities can originate automatically without *Plans or [Capability]Commands.	

Metrics	MetricsType	Optional
Description	Specifies the actual metrics associated with the Requirements.	

Table A-4-1471: Vehicle Interface MA_ActionStatusMT - MessageData UCI Extension Field

ExecutingSystemOrPackage		
Description	Indicates the ID of the System or package executing the Requirement; the System or package whose status on execution of the Requirement is reported in sibling elements. *Plans and Requirements must be managed such that only a single System or package executes a given Requirement.	
Base Type	MA_PackageSystemType	
Message Structure		
Field Name	Field Type	Field Usage
ALL	EmptyType	Required
Description	Indicates applies to ALL entities.	
NONE	EmptyType	Required
Description	Indicates applies to NO entities.	
PackageID	PackageID_Type	Required
Description	The ID of a Package.	
SystemID	SystemID_Type	Required
Description	The ID of an ACP or C2 Operator.	

Table A-4-1472: Vehicle Interface MA_ActionStatusMT - ExecutingSystemOrPackage UCI Extension Field

4.5.23 MA_PositionReportMT UCI Extension

MA_PositionReportMT	
Description	See the annotation in the associated message for an overall description of the message and this type. See the XSD File for more info
Ext. Fields	MessageData : MA_PositionReportMDT

Table A-4-1473: Vehicle Interface MA_PositionReportMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_PositionReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
SystemID	SystemID_Type	Required

Description	The unique ID of the System corresponding to this PositionReport.	
DisplayName	VisibleString256Type	Optional
Description	This is the free-text, generally human-readable, name of the System or Resource corresponding to this PositionReport. This name isn't necessarily unique.	
Source	SystemSourceEnum	Required
Description	Indicates the source of the data in sibling elements. See enumeration annotations for further details.	
CurrentOperatingDomain	EnvironmentEnum	Required
Description	This enumerated element represents the domain/environment in which the system is currently operating.	
InertialState	MA_InertialStateType	Required
Description	This element represents the inertial state of the system or resource.	
WanderAngle	AngleType	Optional
Description	The angle by which the Inertial Navigation System (INS) rotates the geodetic frame about the vertical axis of the North-East-Down (NED) coordinate frame to avoid the introduction of a singularity at the North pole when it is calculating vehicle location. A rotation from true North towards East is reported as a positive angle.	
MagneticHeading	AngleType	Optional
Description	Indicates the heading in relationship to magnetic North.	

Table A-4-1474: Vehicle Interface MA_PositionReportMT - MessageData UCI Extension Field

4.5.24 MA_CarrierReportMT UCI Extension

MA_CarrierReportMT	
Description	See the annotation in the associated message carrier status. See the XSD File for more info
Ext. Fields	LaunchCoordinates : MA_CarrierRunwayCoordinatesType Runway : MA_CarrierRunwayType CarrierReportID : MA_CarrierReportID_Type Direction : MA_AngleRelativeType Catapult : MA_CatapultType Information : MA_CarrierInformationType CatapultID : MA_CatapultID_Type MessageData : MA_CarrierReportMDT LandingCoordinates : MA_CarrierRunwayCoordinatesType Direction : MA_AngleRelativeType

Table A-4-1475: Vehicle Interface MA_CarrierReportMT UCI Extension

LaunchCoordinates	
Description	Specifies the start coordinates of the catapult used for Launch.

Base Type	MA_CarrierRunwayCoordinatesType	
Message Structure		
Field Name	Field Type	Field Usage
Start	Point3D_RelativeType	Required
Description	The waypoint at the start of the runway.	
Threshold	Point3D_RelativeType	Optional
Description	The waypoint at the nearest point of the runway.	
Limit	Point3D_RelativeType	Optional
Description	The waypoint at the furthest point of the runway.	

Table A-4-1476: Vehicle Interface MA_CarrierReportMT - LaunchCoordinates UCI Extension Field

Runway		
Description	Contains details of the runway used for landing.	
Base Type	MA_CarrierRunwayType	
Message Structure		
Field Name	Field Type	Field Usage
RunwayID	RunwayID_Type	Required
Description	Indicates the unique ID for this Runway. Route paths may reference this runway for takeoff or landing paths.	
Direction	MA_AngleRelativeType	Optional
Description	Indicates offset angle to reference frame in radians.	
AvailableLength	DistanceType	Optional
Description	Indicates available length of runway in meters.	
Glideslope	AngleQuarterType	Optional
Description	Indicates glideslope for runway in radians.	
GCA	EmptyType	Optional
Description	Indicates Ground-Controlled Approach service is a available on runway when field is present.	
ILS	EmptyType	Optional
Description	Indicates Instrument Landing Systems service is a available on runway when field is present.	
ApproachLighting	ApproachLightingEnum	Optional
Description	Indicates available approach lighting on runway according to MIL-STD-6016.	
LandingCoordinates	MA_CarrierRunwayCoordinatesType	Optional
Description	Specifies the coordinates of the runway when used for landings.	
DefaultRunwayUsageDetails	RunwayUsageDetailsType	Optional
Description	Specifies terms for using a runway. These details can be used in the decision process when choosing a runway.	

Table A-4-1477: Vehicle Interface MA_CarrierReportMT - Runway UCI Extension Field

CarrierReportID		
Description	Indicates a unique ID, assigned to this carrier report message.	
Base Type	MA_CarrierReportID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1478: Vehicle Interface MA_CarrierReportMT - CarrierReportID UCI Extension Field

Direction		
Description	Indicates offset angle to reference frame in radians.	
Base Type	MA_AngleRelativeType	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceFrameID	ReferenceFrameID_Type	Required
Description	UUID of the reference frame object that this relative angle applies to.	
OffsetAngle	AngleType	Optional
Description	Offset angle relative to the reference frame origin.	

Table A-4-1479: Vehicle Interface MA_CarrierReportMT - Direction UCI Extension Field

Catapult		
Description	Contains details of each catapult for launching.	
Base Type	MA_CatapultType	
Message Structure		
Field Name	Field Type	Field Usage
CatapultID	MA_CatapultID_Type	Required
Description	Indicates the unique ID for this catapult. Route paths may reference this catapult for launch paths.	
Direction	MA_AngleRelativeType	Optional
Description	Indicates offset angle to reference frame in radians.	
AvailableLength	DistanceType	Optional
Description	Indicates available length of runway in meters.	
LaunchCoordinates	MA_CarrierRunwayCoordinatesType	Optional
Description	Specifies the start coordinates of the catapult used for Launch.	

Table A-4-1480: Vehicle Interface MA_CarrierReportMT - Catapult UCI Extension Field

Information		
Description	Contains information about an Carrier.	
Base Type	MA_CarrierInformationType	
Message Structure		
Field Name	Field Type	Field Usage
CrashService	CrashServiceEnum	Optional
Description	Indicates availability of crash service on Carrier.	
Runway	MA_CarrierRunwayType	Optional
Description	Contains details of the runway used for landing.	
Catapult	MA_CatapultType	Repeated
Description	Contains details of each catapult for launching.	

Table A-4-1481: Vehicle Interface MA_CarrierReportMT - Information UCI Extension Field

CatapultID		
Description	Indicates the unique ID for this catapult. Route paths may reference this catapult for launch paths.	
Base Type	MA_CatapultID_Type	
Message Structure		
Field Name	Field Type	Field Usage
UUID	UniversallyUniqueIdentifierType	Required
Description	Universally Unique Identifier (UUID). A UUID is a 128-bit number (32 hexadecimal digits, 16 bytes) that is conformant to a version and variant of IETF RFC 4122.	
DescriptiveLabel	VisibleString256Type	Optional
Description	Human readable text label with content meaningful to human operators.	

Table A-4-1482: Vehicle Interface MA_CarrierReportMT - CatapultID UCI Extension Field

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CarrierReportMDT	
Message Structure		
Field Name	Field Type	Field Usage
CarrierReportID	MA_CarrierReportID_Type	Required
Description	Indicates a unique ID, assigned to this carrier report message.	
CarrierID	SystemID_Type	Required
Description	Indicates a unique ID, assigned to this carrier report message.	
IdentityReferenceID	CarrierReferenceID_ChoiceType	Required

Description	Indicates whether message is self-reported or reported by third party.	
Information	MA_CarrierInformationType	Optional
Description	Contains information about an Carrier.	

Table A-4-1483: Vehicle Interface MA_CarrierReportMT - MessageData UCI Extension Field

LandingCoordinates		
Description	Specifies the coordinates of the runway when used for landings.	
Base Type	MA_CarrierRunwayCoordinatesType	
Message Structure		
Field Name	Field Type	Field Usage
Start	Point3D_RelativeType	Required
Description	The waypoint at the start of the runway.	
Threshold	Point3D_RelativeType	Optional
Description	The waypoint at the nearest point of the runway.	
Limit	Point3D_RelativeType	Optional
Description	The waypoint at the furthest point of the runway.	

Table A-4-1484: Vehicle Interface MA_CarrierReportMT - LandingCoordinates UCI Extension Field

Direction		
Description	Indicates offset angle to refence frame in radians.	
Base Type	MA_AngleRelativeType	
Message Structure		
Field Name	Field Type	Field Usage
ReferenceFrameID	ReferenceFrameID_Type	Required
Description	UUID of the reference frame object that this relative angle applies to.	
OffsetAngle	AngleType	Optional
Description	Offset angle relative to the reference frame origin.	

Table A-4-1485: Vehicle Interface MA_CarrierReportMT - Direction UCI Extension Field

4.5.25 MA_CarrierLaunchReadyStatusMT UCI Extension

MA_CarrierLaunchReadyStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_CarrierLaunchReadyStatusMDT

Table A-4-1486: Vehicle Interface MA_CarrierLaunchReadyStatusMT UCI Extension

MessageData	
Description	See annotations in child elements and messages/elements that use this type

	for details.	
Base Type	MA_CarrierLaunchReadyStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
Timestamp	DateTimeType	Required
Description	The time at which this status was sampled.	
Ready	boolean	Required
Description	The readiness status of the ACP for launch.	
NotReadyReason	MA_CannotComplyType	Optional
Description	When present, the reason why the ACP is not ready to launch.	

Table A-4-1487: Vehicle Interface MA_CarrierLaunchReadyStatusMT - MessageData UCI Extension Field

4.5.26 MA_CarrierDeckHandlingCommandMT UCI Extension

MA_CarrierDeckHandlingCommandMT	
Description	See annotations in child elements and messages/elements that use this type for details. See the XSD File for more info
Ext. Fields	MessageData : MA_CarrierDeckHandlingCommandMDT

Table A-4-1488: Vehicle Interface MA_CarrierDeckHandlingCommandMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CarrierDeckHandlingCommandMDT	
Message Structure		
Field Name	Field Type	Field Usage
Timestamp	DateTimeType	Required
Description	The time at which this status was sampled.	
CommandID	CommandID_Type	Required
Description	The unique ID for this deck handling command.	
Command	MA_CarrierDeckHandlingCommandChoiceType	Required
Description	The deck handling command	

Table A-4-1489: Vehicle Interface MA_CarrierDeckHandlingCommandMT - MessageData UCI Extension Field

4.5.27 MA_CarrierDeckHandlingCommandStatusMT UCI Extension

MA_CarrierDeckHandlingCommandStatusMT	
Description	See annotations in child elements and messages/elements that use this type for details.

	See the XSD File for more info
Ext. Fields	MessageData : MA_CarrierDeckHandlingCommandStatusMDT

Table A-4-1490: Vehicle Interface MA_CarrierDeckHandlingCommandStatusMT UCI Extension

MessageData		
Description	See annotations in child elements and messages/elements that use this type for details.	
Base Type	MA_CarrierDeckHandlingCommandStatusMDT	
Message Structure		
Field Name	Field Type	Field Usage
CommandID	CommandID_Type	Required
Description	The unique ID of the deck handling command being statused.	
Reason	MA_CannotComplyType	Optional
Description	When present, the reason the deck handling command failed.	

Table A-4-1491: Vehicle Interface MA_CarrierDeckHandlingCommandStatusMT - MessageData UCI Extension Field