

Document Title	Specification of Sensor Interfaces
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	912

Document Status	published
Part of AUTOSAR Standard	Adaptive Platform
Part of Standard Release	R22-11

	Document Change History			
Date	Release	Changed by	Description	
2022-11-24	R22-11	AUTOSAR Release Management	Editorials clean up;	
2021-11-25	R21-11	AUTOSAR Release Management	 Update the service interface according to ISO 23150:2021; Add the reference to ISO 23150 :2021 	
2020-11-30	R20-11	AUTOSAR Release Management	Initial release	



Disclaimer

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.



Contents

1	Introduction 11				
2	Acronyms and Abbreviations	12			
3	Related documentation	13			
	3.1 Input documents & related standards and norms3.2 Further applicable specification	13 13			
4	Constraints and assumptions	14			
	4.1 Limitations 4.1.1 ISO Optionals 4.1.2 Sensor Control Interfaces 4.1.3 Sensor Capabilities 4.2 Applicability to car domains	14 14 14 14			
5	Dependencies to other modules	15			
6	Requirements Tracing	16			
7	Functional Specification	36			
	7.1 Outline 7.1.1 Goals and scope 7.1.2 Relation to other standards 7.2 AD Sensor Service Design 7.2.1 ISO mapping to Sensor Services 7.2.1.1 Sensor Types 7.2.1.2 Sensor Data level 7.2.1.3 Supportive Sensor interfaces 7.2.2 Service Optional Elements	36 38 39 39 39 40 40			
8	API specification	42			
9	Service Interfaces 9.1 Type definitions	43 43 43 43 44			
	9.1.1.4 InterfaceId 9.1.1.5 DataQualifier 9.1.1.6 RecognizedStatus 9.1.1.7 TrackingMotionModel 9.1.1.8 MotionType 9.1.1.9 ColourModelType 9.1.1.10 RadialVelocityAmbiguityDomain	44 45 45 46 46 46 47			



	9.1.1.11	RangeAmbiguityDomain	 47
	9.1.1.12	AngleAzimuthAmbiguityDomain	 48
	9.1.1.13	AngleElevationAmbiguityDomain	 48
	9.1.1.14	InterfaceApplicability	 48
	9.1.1.15	VehicleCoordinateSystemType	 49
	9.1.1.16	Point3D	 49
	9.1.1.17	Point3DError	 50
	9.1.1.18	Orientation3D	 50
	9.1.1.19	Orientation3DError	 50
	9.1.1.20	Point3DErrorVector	 51
	9.1.1.21	Orientation3DErrorVector	 51
	9.1.1.22	VanishingPoint	 52
	9.1.1.23	VanishingPointError	52
	9.1.1.24	InformationSensorPose	 52
	9.1.1.25	InformationSensorSurrounding	 53
	9.1.1.26	InterfaceHeader	 53
	9.1.1.27	Sensorld	 54
	9.1.1.28	SensorldList	 54
	9.1.1.29	InformationInterface	 54
	9.1.1.30	InformationInterfaceExtension	 55
	9.1.1.31	ProbabilityPercentage	 55
	9.1.1.32	SensorCalibratableComponent	 55
	9.1.1.33	SensorCalibrationStatus	 56
	9.1.1.34	CaliComponentInfo	 56
	9.1.1.35	CaliComponentInfoVector	57
	9.1.1.36	Calibration	 57
	9.1.1.37	CalibrationProcessState	 58
	9.1.1.38	SensorOriginTranslationCorrectionLimit	 58
	9.1.1.39	SensorPoseAngleCorrectionLimit	 59
	9.1.1.40	SensorCluster	 59
	9.1.1.41	Point2D	 59
	9.1.1.42	Point2DError	 60
	9.1.1.43	InformationAmbiguityDomain	 60
9.1.2	Potentia	ally Moving Objects Interface Definition	 60
	9.1.2.1	MeasurementStatus	 61
	9.1.2.2	ReferencePoint	 61
	9.1.2.3	MovementStatus	 62
	9.1.2.4	RoadLevel	 62
	9.1.2.5	DimensionBox	 63
	9.1.2.6	DimensionBoxError	 63
	9.1.2.7	IncludedGeometricStructures	 64
	9.1.2.8	PotentiallyMovingObjectClassificationType	 64
	9.1.2.9	LightStatus	65
	9.1.2.10	LightType	65
	9.1.2.11	PersonPoseType	66
	9.1.2.12	ObjectLaneAssociation	66



9.1.2.13	AngleBetweenObjectEdgeAndLaneRightEdgeLeft-	
	Lane	67
9.1.2.14	AngleBetweenObjectEdgeAndLaneRightEdgeLeft-	
	LaneError	67
9.1.2.15	PercentageSideLane	68
9.1.2.16	PotentiallyMovingObjectsDynamics	68
9.1.2.17	ObjectStatus	68
9.1.2.18	PotentiallyMovingObjectsBoundingBox	69
9.1.2.19	PotentiallyMovingObjectsInformation	69
9.1.2.20	ValidPotentiallyMovingObjectClassification	70
9.1.2.21	ValidPotentiallyMovingObjectClassificationVector	70
9.1.2.22	PotentiallyMovingObjectsLight	70
9.1.2.23	PotentiallyMovingObjectsLightVector	71
9.1.2.24	PotentiallyMovingObjectsLights	71
9.1.2.25	ValidPersonPose	71
9.1.2.26	PersonPoseVector	72
9.1.2.27	PotentiallyMovingObjectsPerson	72
9.1.2.28	PotentiallyMovingObjectsLaneRelatedInformation	72
9.1.2.29	$Potentially Moving Objects Motion Related Information \ . \\$	73
9.1.2.30	ValidPotentiallyMovingObject	73
9.1.2.31	ValidPotentiallyMovingObjectVector	74
9.1.2.32	PotentiallyMovingObjects	74
9.1.2.33	ValidObservation	74
9.1.2.34	ValidObservationVector	75
9.1.2.35	ObservationStatus	75
9.1.2.36	PotentiallyMovingObjectsPosition	75
9.1.2.37	Potentially Moving Objects Camera Sensor Technolo-	
	gySpecific	76
9.1.2.38	PotentiallyMovingObjectsRadarSensorTechnology	
	Specific	76
9.1.2.39	PotentiallyMovingObjectsLidarSensorTechnolo-	
	gySpecific	77
9.1.2.40	PotentiallyMovingObjectInterface	77
9.1.3 Road O	bjects Interface Definition	77
9.1.3.1	RoadType	77
9.1.3.2	RoadSurfaceClassificationType	78
9.1.3.3	RoadConditionClassificationType	78
9.1.3.4	RoadMarkingType	79
9.1.3.5	ArrowDirection	80
9.1.3.6	SignClassificationType	80
9.1.3.7	SignValueUnit	81
9.1.3.8	ConnectionType	81
9.1.3.9	PolynomialCoefficient	82
9.1.3.10	ColourTone	82
9.1.3.11	RoadObjectInterface	82
9.1.3.12	PolynomialRangeX	83



9.1.3.13	SupportedDataRangeX	83
9.1.3.14	PolylineInterpolationMethod	83
9.1.3.15	VertexPointConfidence	84
9.1.3.16	RoadBoundaryType	84
9.1.3.17	RoadObjectLaneAssociation	85
9.1.3.18	RoadBoundaries	85
9.1.3.19	RoadSurfaceClassification	86
9.1.3.20	SignState	86
9.1.3.21	RoadSurfaceClassificationsVector	87
9.1.3.22	RoadSurfaceConditionClassification	87
9.1.3.23	RoadSurfaceConditionClassificationsVector	87
9.1.3.24	RoadSurface	88
9.1.3.25	ColourValueVector	88
9.1.3.26	RoadMarkingClassification	88
9.1.3.27	RoadMarkingClassificationVector	89
9.1.3.28	RoadMarkingsInformation	89
9.1.3.29	ValidConnection	90
9.1.3.30	ValidConnectionVector	90
9.1.3.31	ValidPolynomial	90
9.1.3.32	SupportedDataRangeVector	91
9.1.3.33	ValidPolynomialVector	91
9.1.3.34	Polynomials	92
9.1.3.35	ValidVertice	92
9.1.3.36	ValidVerticeVector	93
9.1.3.37	ValidPolyline	93
9.1.3.38	ValidPolylineVector	93
9.1.3.39	Polylines	94
9.1.3.40	RoadMarking	94
9.1.3.41	RoadMarkingVector	94
9.1.3.42	RoadMarkings	95
9.1.3.43	ValidRoadBoundaryClassification	95
9.1.3.44	ValidRoadBoundaryClassificationVector	96
9.1.3.45	RoadBoundariesInformation	96
9.1.3.46	ValidRoadBoundary	96
9.1.3.47	RoadBoundaryVector	97
9.1.3.48	SupportedAxis	97
9.1.3.49	SignClassification	97
9.1.3.50	ValidSignClassificationVector	98
9.1.3.51	SupportedDataRange	98
9.1.4 Static C	Objects Interface Definition	98
9.1.4.1	GeneralLandmarkClassificationType	99
9.1.4.2	SignGeometry	99
9.1.4.3	TrafficSignsInformation	100
9.1.4.4	TrafficLightsInformation	100
9.1.4.5	LaneRelevanceClassificationType	101
9.1.4.6	SupplementarySignClassificationType	101

Specification of Sensor Interfaces AUTOSAR AP R22-11



9.1.4.7	RelativePosition	. 102
9.1.4.8	StructureLightClassificationType	. 102
9.1.4.9	ColourClassificationType	
9.1.4.10	GeneralLandmarksInformation	. 103
9.1.4.11	LightShapeClassificationType	. 103
9.1.4.12	LightModeClassificationType	
9.1.4.13	ValidGeneralLandmarkClassificationVector	
9.1.4.14	GeneralLandmarkClassification	. 105
9.1.4.15	GeneralLandmarksPosition	. 105
9.1.4.16	BoundingBox	. 106
9.1.4.17	GeneralLandmark	. 106
9.1.4.18	GeneralLandmarkVector	. 106
9.1.4.19	GeneralLandmarks	. 107
9.1.4.20	LaneRelevanceClassification	. 107
9.1.4.21	MainSignClassification	. 107
9.1.4.22	TrafficSignsPosition	
9.1.4.23	SubObjectStatus	
9.1.4.24	TrafficSignsSupplementarySignsInformation	. 109
9.1.4.25	SupplementarySignClassification	
9.1.4.26	TrafficSignsSupplementarySignsPosition	
9.1.4.27	TrafficSignsSupplementarySign	
9.1.4.28	TrafficSignsSupplementarySignVector	
9.1.4.29	TrafficSignsSupplementarySigns	
9.1.4.30	TrafficSign	
9.1.4.31	ValidTrafficSignVector	. 111
9.1.4.32	TrafficSigns	
9.1.4.33	StructureLightClassification	
9.1.4.34	TrafficLightsPosition	. 112
9.1.4.35	ColourClassification	. 113
9.1.4.36	ColourClassificationVector	. 113
9.1.4.37	TrafficLightsSpotsColour	
9.1.4.38	LightModeClassification	. 114
9.1.4.39	LightModeClassificationVector	. 114
9.1.4.40	LightShapeClassification	. 115
9.1.4.41	TrafficLightsSpotsInformation	. 115
9.1.4.42	TrafficLightsSpotsPosition	
9.1.4.43	TrafficLightSpot	. 116
9.1.4.44	TrafficLightSpotVector	
9.1.4.45	TrafficLightSpots	
9.1.4.46	TrafficLight	. 117
9.1.4.47	ValidTrafficLightVector	
9.1.4.48	TrafficLights	
9.1.4.49	StaticObjectInterface	
9.1.4.50	ValidSupplementarySignClassificationVector	
9.1.4.51	ValidMainSignClassificationVector	
9.1.4.52	ValidLaneRelevanceClassificationVector	



9.1.4.53	LightShapeClassificationVector	119
9.1.4.54	5	119
9.1.5 Feature	Level Interface Definition	120
9.1.5.1	ShapeType	120
9.1.5.2	ShapeClassificationType	120
9.1.5.3	UltrasonicFeatureClassificationType	121
9.1.5.4		122
9.1.5.5	MeasurementStatusFeature	122
9.1.5.6	ShapeClassification	122
9.1.5.7	ValidShapeClassificationsVector	123
9.1.5.8	CameraFeaturesShapeInformation	123
9.1.5.9	I I	123
9.1.5.10	ValidShapePointVector	124
9.1.5.11	ShapePoints	124
9.1.5.12	ShapeReferencePoint	124
9.1.5.13	ValidShapeReferencePointVector	125
9.1.5.14	ShapeReferencePoints	125
9.1.5.15	FeatureStatus	126
9.1.5.16		126
9.1.5.17	ValidCameraFeatureVector	126
9.1.5.18	CameraFeatureInterface	127
9.1.5.19		127
9.1.5.20	UltrasonicFeatureClassification	128
9.1.5.21	SegmentPoint	128
9.1.5.22	.	128
9.1.5.23	UltrasonicSegmentPoints	129
9.1.5.24		129
9.1.5.25	ValidUltrasonicFeatureVector	129
9.1.5.26	UltrasonicFeatureInterface	130
9.1.5.27	ValidUltrasonicFeatureClassificationVector	130
9.1.6 Detection	on Level Interface Definition	130
9.1.6.1	Position3DSpheric	131
9.1.6.2	Position3DSphericError	131
9.1.6.3	DetectionClassificationType	131
9.1.6.4		132
9.1.6.5	UltrasonicDetectionsPosition	132
9.1.6.6		133
9.1.6.7		133
9.1.6.8		133
9.1.6.9		134
9.1.6.10		134
9.1.6.11		135
9.1.6.12	· · · · · · · · · · · · · · · · · · ·	135
9.1.6.13		135
9.1.6.14	LidarDetectionsInformation	136
9.1.6.15	LidarDetection	136



	9.1.6.16	ValidLidarDetectionVector	136
	9.1.6.17	Lidar Detections Position	137
	9.1.6.18	LidarDetectionsInterface	137
	9.1.6.19	DetectionShapeClassification	137
	9.1.6.20	ValidDetectionShapeClassificationVector	138
	9.1.6.21	CameraShapesShapeInformation	138
	9.1.6.22	ShapePointDetectionLevel	138
	9.1.6.23	ValidShapePointDetectionLevelVector	139
	9.1.6.24	CameraShapesShapePoints	139
	9.1.6.25	CameraShape	139
	9.1.6.26	ValidCameraShapeVector	140
	9.1.6.27	ShapeReferencePointDetectionLevel	140
	9.1.6.28	ValidShapeReferencePointDetectionLevelVector	140
	9.1.6.29	CameraShapesShapeReferencePoints	141
	9.1.6.30	CameraDetectionsInterface	141
	9.1.6.31	UltrasonicDetectionsInformation	141
	9.1.6.32	UltrasonicDetection	142
	9.1.6.33	ValidUltrasonicDetectionVector	142
	9.1.6.34	UltrasonicDetectionsInterface	142
9.1.7	Suppor	tive Sensor Interfaces Definition	143
	9.1.7.1	SegmentAzimuth	143
	9.1.7.2	SegmentElevation	143
	9.1.7.3	AnglePoint3D	143
	9.1.7.4	BeamDivergence	144
	9.1.7.5	SegmentsStatus	144
	9.1.7.6	BlockageStatus	145
	9.1.7.7	FieldOfViewReduction	145
	9.1.7.8	FieldOfViewReductionReasonType	146
	9.1.7.9	ValidFieldOfViewReductionReasonsVector	146
	9.1.7.10	FieldOfViewReductionReasons	147
	9.1.7.11	RecognizedObjectType	147
	9.1.7.12	DetectionRange	148
	9.1.7.13	RecognisableObjectTypes	148
	9.1.7.14	ValidRecognisableObjectTypesVector	148
	9.1.7.15	RealWorldObjectRecognitionCapabilities	149
	9.1.7.16	ReferenceTargetType	149
	9.1.7.17	ReferenceTargetTypes	149
	9.1.7.18	ValidReferenceTargetTypesVector	150
	9.1.7.19	ReferenceTargetRecognitionCapabilities	150
	9.1.7.20	RelativeRadialVelocityRange	151
	9.1.7.21	PeformanceSegment	151
	9.1.7.22	SensorOperationMode	151
	9.1.7.23	SensorDefectDetected	152
	9.1.7.24	SensorDefectReason	152
	9.1.7.25	ValidSensorOperationModeVector	153
	9.1.7.26	StatusSupplyVoltage	153

Specification of Sensor Interfaces AUTOSAR AP R22-11



		9.1.7	.27	SensorTemperatureStatus	 154
		9.1.7	.28	ValidPeformanceSegmentVector	 154
		9.1.7	.29	SensorInputSignalType	 155
		9.1.7	.30	SensorInputSignalStatus	 155
		9.1.7	.31	SensorExternalDisturbed	 156
		9.1.7	.32	SensorTransmitPowerReduced	 156
		9.1.7	.33	StatusSensorHeating	 157
		9.1.7	.34	StatusSensorCleaning	 157
		9.1.7	.35	SensorTimeSync	 157
		9.1.7	.36	SensorPerformanceSegments	 158
		9.1.7	.37	SensorPerformanceInterface	 158
		9.1.7	.38	InputSignalStatus	 159
		9.1.7	.39	ValidInputSignalStatusVector	 159
		9.1.7	.40	SensorHealthStatus	 159
		9.1.7	.41	SensorHealthInformationInterface	 160
	9.2	Service I	nterfaces	8	 160
		9.2.1	Sensor	Interfaces Port	 161
		9.2.2	Object I	evel Interfaces	 161
		9.2.3	Feature	level Interfaces	 162
		9.2.4	Detection	on level Interfaces	 163
		9.2.5	Support	tive Interfaces	 165
ın	Cana	ability Confi	iguration		167
	-	_			
	10.1	•		/ice	167
		10.1.1		ectsService Capability Vector	167
		10.1.2		tsService Capability Vector	170
		10.1.3		tsService Capability Vector	175
	10.2	Feature L			179
		10.2.1		FeatureService Capability Vector	179
		10.2.2		atureService Capability Vector	182
	10.3			Service	185
		10.3.1		etectionService Capability Vector	185
		10.3.2		etectionService Capability Vector	187
		10.3.3		DetectionService Capability Vector	190
		10.3.4		tectionService Capability Vector	192
	10.4			ce	195
		10.4.1		PerformanceService Capability Vector	195
		10.4.2	Sensorl	HealthService Capability Vector	 197



1 Introduction

This specification describes the functional description and interfaces of the function cluster <code>Sensor Interfaces</code> which belongs to <code>AUTOSAR Adaptive Platform Services.The Sensor Interfaces has the responsibility of connecting sensors to AUTOSAR Adaptive computing unit via a service interface.</code>

The Sensor Interfaces are based on the logical interface defined in [1]. The sensor types covered by the specification are the following:

- Camera Sensors
- Lidar Sensors
- Radar Sensors
- Ultrasonic Sensors

There are three levels for the sensor data reporting:

- Detection level
- Feature level
- Object level

Besides data reporting interfaces, the sensor supporing interfaces, i.e.sensor health and performance, are also defined.

The sensors as the AUTOSAR service provider and the AUTOSAR Adaptive applications are located in different ECUs. To allow the flexiblity usage of the Sensor Interfaces, it will expose its functionality via ara::com service interfaces, not direct APIs.

Further functional details are described in [2].



2 Acronyms and Abbreviations

The glossary below includes acronyms and abbreviations relevant to the Sensor Interfaces that are not included in AUTOSAR Glossary [3].

Abbreviation / Acronym:	Description:
AD	Automated Driving
ADI	Automated Driving Interfaces
AEB	Autonomous Emergency Braking
HiL	Hardware in the Loop
ISO	International Organization for Standardization
LIDAR	Light Detection And Ranging
MiL	Model in the Loop
OEM	Original Equipment Manufacturer
OSI	Open Simulation Interface
RADAR	RAdio Detection And Ranging
SAE	Society of Automotive Engineers
USS	UltraSonic Sensor
XiL	in the Loop

Terms:	Description:
V2X	Vehicle-to-X-Communication is the generic term for various communication technologies in automotive, including vehicle-to-vehicle (V2V) and vehicle-to-infrastructure (V2I) communication. The information is either transmitted directly between vehicles, between vehicle and roadside infrastructure or by using existing mobile networks.



3 Related documentation

3.1 Input documents & related standards and norms

- [1] ISO-23150 Road vehicles—Data communication between sensors and data fusion unit for automated driving functions—Logical interface
- [2] Explanation of Sensor Interfaces AUTOSAR_EXP_SensorInterfaces
- [3] Glossary
 AUTOSAR TR Glossary
- [4] Specification of Adaptive Platform Core AUTOSAR_SWS_AdaptivePlatformCore
- [5] Specification of Communication Management AUTOSAR SWS CommunicationManagement
- [6] Specification of Identity and Access Management AUTOSAR_SWS_IdentityAndAccessManagement
- [7] Requirements on Automated Driving Interfaces AUTOSAR RS Automated Driving Interfaces

3.2 Further applicable specification

AUTOSAR provides a core specification [4] which is also applicable for Automated Driving Interfaces. The chapter "General requirements for all FunctionalClusters" of this specification shall be considered as an additional and required specification for implementation of Automated Driving Interfaces.



4 Constraints and assumptions

Dedicated interfaces for particular sensors like radar, lidar, USS and camera are provided.

4.1 Limitations

4.1.1 ISO Optionals

All the ISO optionals are supported in the service defintiion, but the presence of an optional signal is decided during the design time. The optional signal presence is indicated by a capability vector. There is no change of optional presence during the run time.

4.1.2 Sensor Control Interfaces

Sensor control interfaces are not supported, e.g. actions like reset, initialization, and calibration.

4.1.3 Sensor Capabilities

The configuration of sensor capabilities is not supported, e.g. sensor opening angle and detection range.

4.2 Applicability to car domains

AUTOSAR Sensor Interfaces are used as service interfaces between dedicated sensors for environment precession and the AUTOSAR Adaptive applications.



5 Dependencies to other modules

The Automated Driving Interfaces serve as common interfaces for the AUTOSAR Adaptive applications. The sensor information is provided by a non-platform service. The sensor interfaces are exposed to client applications via the ara::com middleware. Communication Management, [5] uses Identity and Access Management [6] to validate the authorization of requests made to the specific service interfaces, i.e. the Communication Management shall check if the invoker is allowed to access the requested service interface of a specific sensor. The following Figure shows a radar and camera sensor instance which provide sensor information to a Data Fusion instance consuming sensor data.




Figure 5.1: Sensor Interfaces dependencies to other AUTOSAR Adaptive Applications.

For each sensor type like radar, lidar, USS or camera, the ISO standard will contain lots of optional sensor data or signals in addition to the required signals, e.g. the classification of an object might be optional. During development of a driving function or data fusion system, a specific set of optional signals is selected by the function or data fusion developer according to the requirements of the driving function. To reduce development costs, especially in terms of functional safety, the set of optionals and thus the resulting logical sensor interface are required to be fixed during design-time, i.e. the specified sensor signals must not suddenly disappear from the interface of the sensor during runtime of the system so that a data fusion system can rely on the presence of the specified signals. Vice versa, a sensor interface must not add additional signals during runtime, e.g. not to risk an unintentional behavior change due to the increased bandwidth requirements.



6 Requirements Tracing

The following tables reference the requirements specified in [7] and links to the fulfillment of these. Please note that if column "Satisfied by" is empty for a specific requirement this means that this requirement is not fulfilled by this document.

Requirement	Description	Satisfied by
[RS ADI 00001]	The ADI shall support the	[SWS_ADI_00001] [SWS_ADI_00100]
	camera sensor technology for	[SWS_ADI_00101] [SWS_ADI_00102]
	on-board sensors	[SWS_ADI_00103] [SWS_ADI_00104]
		[SWS_ADI_00105] [SWS_ADI_00106]
		[SWS_ADI_00107] [SWS_ADI_00108]
		[SWS_ADI_00113] [SWS_ADI_00114]
		[SWS_ADI_00115] [SWS_ADI_00116]
		[SWS ADI 00117] [SWS ADI 00118]
		[SWS_ADI_00119] [SWS_ADI_00120]
		[SWS_ADI_00121] [SWS_ADI_00122]
		[SWS_ADI_00123] [SWS_ADI_00124]
		[SWS_ADI_00125] [SWS_ADI_00124]
		[SWS_ADI_00123] [SWS_ADI_00128]
		[SWS_ADI_00127] [SWS_ADI_00128]
		[SWS_ADI_00200] [SWS_ADI_00201]
		[SWS_ADI_00202] [SWS_ADI_00203]
		[SWS_ADI_00204] [SWS_ADI_00205]
		[SWS_ADI_00206] [SWS_ADI_00207]
		[SWS_ADI_00208] [SWS_ADI_00209]
		[SWS_ADI_00210] [SWS_ADI_00211]
		[SWS_ADI_00212] [SWS_ADI_00213]
		[SWS_ADI_00214] [SWS_ADI_00215]
		[SWS_ADI_00216] [SWS_ADI_00217]
		[SWS_ADI_00218] [SWS_ADI_00219]
		[SWS_ADI_00220] [SWS_ADI_00221]
		[SWS_ADI_00222] [SWS_ADI_00223]
		[SWS_ADI_00224] [SWS_ADI_00225]
		[SWS_ADI_00226] [SWS_ADI_00227]
		[SWS_ADI_00228] [SWS_ADI_00229]
		[SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233]
		[SWS_ADI_00232] [SWS_ADI_00233]
		[SWS_ADI_00234] [SWS_ADI_00233]
		[SWS_ADI_00200] [SWS_ADI_00209]
		[SWS_ADI_00300] [SWS_ADI_00301]
		[SWS_ADI_00302] [SWS_ADI_00305]
		[SWS_ADI_00304] [SWS_ADI_00307]
		[SWS_ADI_00308] [SWS_ADI_00309]
		[SWS_ADI_00300] [SWS_ADI_00303]
		[SWS_ADI_00312] [SWS_ADI_00313]
		[SWS_ADI_00312] [SWS_ADI_00313]
		[SWS_ADI_00314] [SWS_ADI_00315]
		[SWS_ADI_00316] [SWS_ADI_00317]
		[SWS_ADI_00316] [SWS_ADI_00316]
		[SWS_ADI_00320] [SWS_ADI_00321]
		[SWS_ADI_00322] [SWS_ADI_00325]
		[SWS_ADI_00324] [SWS_ADI_00325]
		[SWS_ADI_00328] [SWS_ADI_00329]



Requirement	Description	Satisfied by
-		[SWS_ADI_00330] [SWS_ADI_00331]
		[SWS_ADI_00332] [SWS_ADI_00333]
		[SWS_ADI_00334] [SWS_ADI_00335]
		[SWS_ADI_00336] [SWS_ADI_00337]
		[SWS_ADI_00338] [SWS_ADI_00339]
		[SWS_ADI_00340] [SWS_ADI_00341]
		[SWS_ADI_00342] [SWS_ADI_00343]
		[SWS_ADI_00344] [SWS_ADI_00345]
		[SWS_ADI_00346] [SWS_ADI_00347]
		[SWS_ADI_00348] [SWS_ADI_00349]
		[SWS_ADI_00350] [SWS_ADI_00401]
		[SWS_ADI_00402] [SWS_ADI_00403]
		[SWS_ADI_00404] [SWS_ADI_00405]
		[SWS_ADI_00406] [SWS_ADI_00407]
		[SWS_ADI_00408] [SWS_ADI_00409]
		[SWS_ADI_00410] [SWS_ADI_00411]
		[SWS_ADI_00412] [SWS_ADI_00413]
		[SWS_ADI_00414] [SWS_ADI_00415]
		[SWS_ADI_00416] [SWS_ADI_00417]
		[SWS_ADI_00418] [SWS_ADI_00419]
		[SWS_ADI_00420] [SWS_ADI_00421]
		[SWS_ADI_00422] [SWS_ADI_00423]
		[SWS_ADI_00424] [SWS_ADI_00425]
		[SWS_ADI_00426] [SWS_ADI_00427]
		[SWS_ADI_00428] [SWS_ADI_00429]
		[SWS_ADI_00430] [SWS_ADI_00431]
		[SWS_ADI_00432] [SWS_ADI_00433]
		[SWS_ADI_00434] [SWS_ADI_00435]
		[SWS_ADI_00436] [SWS_ADI_00437]
		[SWS_ADI_00438] [SWS_ADI_00439]
		[SWS_ADI_00440] [SWS_ADI_00441]
		[SWS_ADI_00442] [SWS_ADI_00443]
		[SWS_ADI_00444] [SWS_ADI_00445]
		[SWS_ADI_00446] [SWS_ADI_00447]
		[SWS_ADI_00448] [SWS_ADI_00449]
		[SWS_ADI_00450] [SWS_ADI_00451]
		[SWS_ADI_00452] [SWS_ADI_00453]
		[SWS_ADI_00454] [SWS_ADI_00501]
		[SWS_ADI_00502] [SWS_ADI_00503]
		[SWS_ADI_00504] [SWS_ADI_00506]
		[SWS_ADI_00507] [SWS_ADI_00508]
		[SWS_ADI_00509] [SWS_ADI_00510]
		[SWS_ADI_00511] [SWS_ADI_00512]
		[SWS_ADI_00513] [SWS_ADI_00514]
		[SWS_ADI_00515] [SWS_ADI_00516]
		[SWS_ADI_00517] [SWS_ADI_00518]
		[SWS_ADI_00519] [SWS_ADI_00520]
		[SWS_ADI_00521] [SWS_ADI_00523]



Requirement	Description	Satisfied by
		[SWS_ADI_00524] [SWS_ADI_00525]
		[SWS_ADI_00526] [SWS_ADI_00527]
		[SWS_ADI_00528] [SWS_ADI_00529]
		[SWS_ADI_00530] [SWS_ADI_00531]
		[SWS_ADI_00532] [SWS_ADI_00533]
		[SWS_ADI_00534] [SWS_ADI_00535]
		[SWS_ADI_00536] [SWS_ADI_00537]
		[SWS_ADI_00538] [SWS_ADI_00539]
		SWS ADI 00540] SWS ADI 00541]
		SWS ADI 00542] SWS ADI 00543]
		[SWS_ADI_00544] [SWS_ADI_00545]
		[SWS_ADI_00546] [SWS_ADI_00547]
		[SWS_ADI_00548] [SWS_ADI_00549]
		[SWS_ADI_00550] [SWS_ADI_00551]
		[SWS_ADI_00601] [SWS_ADI_00602]
		SWS ADI 00608] [SWS ADI 00609]
		SWS ADI 00610] SWS ADI 00611]
		[SWS_ADI_00612] [SWS_ADI_00613]
		[SWS_ADI_00614] [SWS_ADI_00615]
		[SWS_ADI_00616] [SWS_ADI_00617]
		[SWS_ADI_00618] [SWS_ADI_00619]
		[SWS_ADI_00620] [SWS_ADI_00701]
		SWS ADI 00702] [SWS ADI 00706]
		[SWS_ADI_00720] [SWS_ADI_00721]
		[SWS_ADI_00722] [SWS_ADI_00723]
		[SWS_ADI_00724] [SWS_ADI_00725]
		[SWS_ADI_00726] [SWS_ADI_00727]
		[SWS_ADI_00728] [SWS_ADI_00729]
		[SWS_ADI_00730] [SWS_ADI_00731]
		[SWS_ADI_01000] [SWS_ADI_01001]
		[SWS_ADI_01002] [SWS_ADI_01003]
		[SWS ADI 01004] [SWS ADI 01008]
		[SWS_ADI_01010] [SWS_ADI_01011]
[RS_ADI_00002]	The ADI shall support the lidar	[SWS_ADI_00002] [SWS_ADI_00100]
. – – .	sensor technology for on-board	[SWS_ADI_00101] [SWS_ADI_00102]
	sensors	[SWS_ADI_00103] [SWS_ADI_00104]
		[SWS_ADI_00105] [SWS_ADI_00106]
		[SWS_ADI_00107] [SWS_ADI_00108]
		[SWS_ADI_00113] [SWS_ADI_00114]
		[SWS_ADI_00115] [SWS_ADI_00116]
		[SWS_ADI_00117] [SWS_ADI_00118]
		[SWS_ADI_00121] [SWS_ADI_00123]
		[SWS_ADI_00124] [SWS_ADI_00125]
		[SWS_ADI_00126] [SWS_ADI_00127]
		[SWS_ADI_00128] [SWS_ADI_00129]



[SWS_ADI_00130] [SWS_ADI_00200] [SWS_ADI_00201] [SWS_ADI_00202] [SWS_ADI_00203] [SWS_ADI_00204] [SWS_ADI_00205] [SWS_ADI_00204] [SWS_ADI_00207] [SWS_ADI_00208] [SWS_ADI_00209] [SWS_ADI_00210] [SWS_ADI_00213] [SWS_ADI_00212] [SWS_ADI_00213] [SWS_ADI_00214] [SWS_ADI_00215] [SWS_ADI_00214] [SWS_ADI_00215] [SWS_ADI_00216] [SWS_ADI_00220] [SWS_ADI_00229] [SWS_ADI_00228] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_002231] [SWS_ADI_00233] [SWS_ADI_002331] [SWS_ADI_00234] [SWS_ADI_002335] [SWS_ADI_00238] [SWS_ADI_00238] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00238] [SWS_ADI_002301]	
[SWS_ADI_00203] [SWS_ADI_00204] [SWS_ADI_00205] [SWS_ADI_00206] [SWS_ADI_00207] [SWS_ADI_00208] [SWS_ADI_00209] [SWS_ADI_00210] [SWS_ADI_00211] [SWS_ADI_00212] [SWS_ADI_00213] [SWS_ADI_00212] [SWS_ADI_00215] [SWS_ADI_00214] [SWS_ADI_00218] [SWS_ADI_00216] [SWS_ADI_00220] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_002231] [SWS_ADI_00230] [SWS_ADI_002331] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_002391]	
[SWS_ADI_00205] [SWS_ADI_00206] [SWS_ADI_00207] [SWS_ADI_00208] [SWS_ADI_00209] [SWS_ADI_00210] [SWS_ADI_00211] [SWS_ADI_00212] [SWS_ADI_00213] [SWS_ADI_00214] [SWS_ADI_00215] [SWS_ADI_00216] [SWS_ADI_00218] [SWS_ADI_00219] [SWS_ADI_00220] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00227] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00207] [SWS_ADI_00208] [SWS_ADI_00209] [SWS_ADI_00210] [SWS_ADI_00211] [SWS_ADI_00212] [SWS_ADI_00213] [SWS_ADI_00214] [SWS_ADI_00215] [SWS_ADI_00216] [SWS_ADI_00218] [SWS_ADI_00219] [SWS_ADI_00220] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00229] [SWS_ADI_00230] [SWS_ADI_00233] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00209] [SWS_ADI_00210] [SWS_ADI_00211] [SWS_ADI_00212] [SWS_ADI_00213] [SWS_ADI_00214] [SWS_ADI_00215] [SWS_ADI_00216] [SWS_ADI_00218] [SWS_ADI_00219] [SWS_ADI_00220] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00229] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00211] [SWS_ADI_00212] [SWS_ADI_00213] [SWS_ADI_00214] [SWS_ADI_00215] [SWS_ADI_00216] [SWS_ADI_00218] [SWS_ADI_00219] [SWS_ADI_00220] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00229] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00213] [SWS_ADI_00214] [SWS_ADI_00215] [SWS_ADI_00216] [SWS_ADI_00218] [SWS_ADI_00219] [SWS_ADI_00220] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00229] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00215] [SWS_ADI_00216] [SWS_ADI_00218] [SWS_ADI_00219] [SWS_ADI_00220] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00229] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00218] [SWS_ADI_00219] [SWS_ADI_00220] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00229] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00220] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00229] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00228] [SWS_ADI_00229] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301]	
[SWS_ADI_00300] [SWS_ADI_00301]	
•	
TOMO ADI 000001 TOMO ADI 000001	
[SWS_ADI_00302] [SWS_ADI_00303]	
[SWS_ADI_00304] [SWS_ADI_00305]	
[SWS_ADI_00306] [SWS_ADI_00307]	
[SWS_ADI_00308] [SWS_ADI_00310]	
[SWS_ADI_00311] [SWS_ADI_00312]	
[SWS_ADI_00313] [SWS_ADI_00314]	
[SWS_ADI_00315] [SWS_ADI_00316]	
[SWS_ADI_00317] [SWS_ADI_00318]	
[SWS_ADI_00319] [SWS_ADI_00320]	
[SWS_ADI_00321] [SWS_ADI_00322]	
[SWS_ADI_00323] [SWS_ADI_00325]	
[SWS_ADI_00326] [SWS_ADI_00327]	
[SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331]	
[SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333]	
[SWS_ADI_00332] [SWS_ADI_00335]	
[SWS_ADI_00334] [SWS_ADI_00335]	
[SWS_ADI_00338] [SWS_ADI_00339]	
[SWS_ADI_00340] [SWS_ADI_00341]	
[SWS ADI 00342] [SWS ADI 00343]	
[SWS ADI 00344] [SWS ADI 00345]	
[SWS_ADI_00346] [SWS_ADI_00347]	
[SWS_ADI_00348] [SWS_ADI_00349]	
[SWS ADI 00350] [SWS ADI 00401]	
[SWS_ADI_00402] [SWS_ADI_00403]	
[SWS_ADI_00404] [SWS_ADI_00405]	
[SWS ADI 00406] [SWS ADI 00407]	
[SWS_ADI_00408] [SWS_ADI_00410]	
[SWS_ADI_00411] [SWS_ADI_00412]	
[SWS_ADI_00413] [SWS_ADI_00414]	
[SWS_ADI_00415] [SWS_ADI_00417]	



Requirement	Description	Satisfied by
•	1	[SWS_ADI_00418] [SWS_ADI_00419]
		[SWS_ADI_00420] [SWS_ADI_00421]
		[SWS_ADI_00422] [SWS_ADI_00423]
		[SWS ADI 00424] [SWS ADI 00425]
		[SWS ADI 00426] [SWS ADI 00427]
		[SWS_ADI_00428] [SWS_ADI_00429]
		[SWS_ADI_00430] [SWS_ADI_00431]
		[SWS_ADI_00432] [SWS_ADI_00433]
		[SWS_ADI_00434] [SWS_ADI_00438]
		[SWS_ADI_00439] [SWS_ADI_00440]
		[SWS_ADI_00441] [SWS_ADI_00442]
		[SWS_ADI_00443] [SWS_ADI_00444]
		[SWS_ADI_00445] [SWS_ADI_00446]
		[SWS_ADI_00447] [SWS_ADI_00448]
		[SWS_ADI_00449] [SWS_ADI_00450]
		[SWS_ADI_00451] [SWS_ADI_00452]
		[SWS_ADI_00453] [SWS_ADI_00454]
		[SWS_ADI_00501] [SWS_ADI_00502]
		[SWS_ADI_00503] [SWS_ADI_00504]
		[SWS_ADI_00506] [SWS_ADI_00507]
		[SWS_ADI_00508] [SWS_ADI_00509]
		[SWS_ADI_00510] [SWS_ADI_00511]
		[SWS_ADI_00512] [SWS_ADI_00513]
		[SWS_ADI_00514] [SWS_ADI_00515]
		[SWS_ADI_00516] [SWS_ADI_00517]
		[SWS_ADI_00518] [SWS_ADI_00519]
		[SWS_ADI_00520] [SWS_ADI_00521]
		[SWS_ADI_00523] [SWS_ADI_00524]
		[SWS_ADI_00525] [SWS_ADI_00526]
		[SWS_ADI_00527] [SWS_ADI_00528]
		[SWS_ADI_00529] [SWS_ADI_00530] [SWS_ADI_00531] [SWS_ADI_00532]
		[SWS_ADI_00531] [SWS_ADI_00532]
		[SWS_ADI_00535] [SWS_ADI_00536]
		[SWS_ADI_00535] [SWS_ADI_00538]
		[SWS_ADI_00539] [SWS_ADI_00540]
		[SWS_ADI_00541] [SWS_ADI_00542]
		[SWS_ADI_00543] [SWS_ADI_00544]
		[SWS ADI 00545] [SWS ADI 00546]
		[SWS_ADI_00547] [SWS_ADI_00548]
		[SWS_ADI_00549] [SWS_ADI_00550]
		[SWS_ADI_00551] [SWS_ADI_00701]
		[SWS_ADI_00702] [SWS_ADI_00703]
		[SWS_ADI_00706] [SWS_ADI_00712]
		[SWS_ADI_00715] [SWS_ADI_00716]
		[SWS_ADI_00717] [SWS_ADI_00718]
		[SWS_ADI_00719] [SWS_ADI_01000]
		[SWS_ADI_01001] [SWS_ADI_01002]
		[SWS_ADI_01003] [SWS_ADI_01007]
		[SWS_ADI_01010] [SWS_ADI_01011]



Requirement	Description	Satisfied by
[RS ADI 00003]	The ADI shall support the radar	[SWS ADI 00003] [SWS ADI 00100]
	sensor technology for on-board	[SWS_ADI_00101] [SWS_ADI_00102]
	sensors	[SWS_ADI_00103] [SWS_ADI_00104]
	30110010	[SWS_ADI_00105] [SWS_ADI_00106]
		[SWS_ADI_00107] [SWS_ADI_00108]
		[SWS_ADI_00109] [SWS_ADI_00110]
		[SWS_ADI_00110] [SWS_ADI_00110]
		[SWS_ADI_00113] [SWS_ADI_00114]
		[SWS_ADI_00115] [SWS_ADI_00116]
		[SWS_ADI_00117] [SWS_ADI_00118]
		[SWS_ADI_00121] [SWS_ADI_00123]
		[SWS_ADI_00124] [SWS_ADI_00125]
		[SWS_ADI_00126] [SWS_ADI_00127]
		[SWS_ADI_00128] [SWS_ADI_00129]
		[SWS_ADI_00130] [SWS_ADI_00200]
		[SWS_ADI_00201] [SWS_ADI_00202]
		[SWS_ADI_00203] [SWS_ADI_00204]
		[SWS_ADI_00205] [SWS_ADI_00206]
		[SWS_ADI_00207] [SWS_ADI_00208]
		[SWS_ADI_00209] [SWS_ADI_00210]
		[SWS_ADI_00211] [SWS_ADI_00212]
		[SWS_ADI_00213] [SWS_ADI_00214]
		[SWS_ADI_00215] [SWS_ADI_00216]
		[SWS_ADI_00218] [SWS_ADI_00219]
		[SWS_ADI_00220] [SWS_ADI_00227]
		[SWS_ADI_00228] [SWS_ADI_00229]
		[SWS_ADI_00230] [SWS_ADI_00231]
		[SWS_ADI_00232] [SWS_ADI_00233]
		[SWS_ADI_00234] [SWS_ADI_00235]
		[SWS_ADI_00237] [SWS_ADI_00239]
		[SWS_ADI_00300] [SWS_ADI_00301]
		[SWS ADI 00302] [SWS ADI 00303]
		[SWS ADI 00304] [SWS ADI 00305]
		[SWS ADI 00306] [SWS ADI 00308]
		[SWS ADI 00310] [SWS ADI 00311]
		[SWS_ADI_00312] [SWS_ADI_00313]
		[SWS_ADI_00314] [SWS_ADI_00315]
		[SWS_ADI_00316] [SWS_ADI_00317]
		[SWS_ADI_00318] [SWS_ADI_00319]
		[SWS_ADI_00320] [SWS_ADI_00321]
		[SWS_ADI_00322] [SWS_ADI_00323]
		[SWS_ADI_00325] [SWS_ADI_00326]
		[SWS_ADI_00327] [SWS_ADI_00336]
		[SWS_ADI_00338] [SWS_ADI_00339]
		[SWS_ADI_00340] [SWS_ADI_00341]
		[SWS_ADI_00342] [SWS_ADI_00343]
		[SWS ADI 00344] [SWS ADI 00345]
		[SWS_ADI_00346] [SWS_ADI_00347]
I		[00_/151_000 10] [0110_/151_00047]



Requirement	Description	Satisfied by
•	·	[SWS_ADI_00348] [SWS_ADI_00349]
		[SWS_ADI_00350] [SWS_ADI_00401]
		[SWS_ADI_00402] [SWS_ADI_00403]
		[SWS_ADI_00404] [SWS_ADI_00405]
		[SWS_ADI_00406] [SWS_ADI_00407]
		[SWS_ADI_00408] [SWS_ADI_00410]
		[SWS_ADI_00411] [SWS_ADI_00412]
		[SWS_ADI_00413] [SWS_ADI_00414]
		[SWS_ADI_00415] [SWS_ADI_00417]
		[SWS_ADI_00418] [SWS_ADI_00419]
		[SWS_ADI_00420] [SWS_ADI_00421]
		[SWS_ADI_00422] [SWS_ADI_00423]
		[SWS_ADI_00424] [SWS_ADI_00425]
		[SWS_ADI_00426] [SWS_ADI_00427]
		[SWS_ADI_00428] [SWS_ADI_00429]
		[SWS_ADI_00430] [SWS_ADI_00431]
		[SWS_ADI_00432] [SWS_ADI_00433]
		[SWS_ADI_00434] [SWS_ADI_00438]
		[SWS_ADI_00439] [SWS_ADI_00440]
		[SWS_ADI_00441] [SWS_ADI_00442]
		[SWS_ADI_00443] [SWS_ADI_00444]
		[SWS_ADI_00445] [SWS_ADI_00446]
		[SWS_ADI_00447] [SWS_ADI_00448]
		[SWS_ADI_00449] [SWS_ADI_00450]
		[SWS_ADI_00451] [SWS_ADI_00452]
		[SWS_ADI_00453] [SWS_ADI_00454]
		[SWS_ADI_00501] [SWS_ADI_00502]
		[SWS_ADI_00503] [SWS_ADI_00504]
		[SWS_ADI_00506] [SWS_ADI_00507] [SWS_ADI_00508] [SWS_ADI_00509]
		[SWS_ADI_00508] [SWS_ADI_00509]
		[SWS ADI 00512] [SWS ADI 00513]
		[SWS_ADI_00514] [SWS_ADI_00515]
		[SWS ADI 00516] [SWS ADI 00517]
		[SWS_ADI_00518] [SWS_ADI_00519]
		[SWS_ADI_00520] [SWS_ADI_00521]
		[SWS ADI 00523] [SWS ADI 00524]
		[SWS_ADI_00525] [SWS_ADI_00526]
		[SWS ADI 00527] [SWS ADI 00528]
		[SWS ADI 00529] [SWS ADI 00530]
		[SWS_ADI_00531] [SWS_ADI_00532]
		[SWS_ADI_00533] [SWS_ADI_00534]
		[SWS_ADI_00535] [SWS_ADI_00536]
		[SWS_ADI_00537] [SWS_ADI_00538]
		[SWS_ADI_00539] [SWS_ADI_00540]
		[SWS_ADI_00541] [SWS_ADI_00542]
		[SWS_ADI_00543] [SWS_ADI_00544]
		[SWS_ADI_00545] [SWS_ADI_00546]



Requirement	Description	Satisfied by
-		[SWS_ADI_00547] [SWS_ADI_00548]
		[SWS_ADI_00549] [SWS_ADI_00550]
		[SWS_ADI_00551] [SWS_ADI_00701]
		[SWS_ADI_00702] [SWS_ADI_00703]
		[SWS_ADI_00704] [SWS_ADI_00706]
		[SWS_ADI_00707] [SWS_ADI_00708]
		[SWS_ADI_00709] [SWS_ADI_00710]
		[SWS_ADI_00711] [SWS_ADI_00712]
		[SWS_ADI_00713] [SWS_ADI_00714]
		[SWS_ADI_01000] [SWS_ADI_01001]
		[SWS_ADI_01002] [SWS_ADI_01003]
		[SWS_ADI_01006] [SWS_ADI_01010]
		[SWS_ADI_01011]
[RS_ADI_00004]	The ADI shall support the	[SWS_ADI_00004] [SWS_ADI_00100]
	ultrasonic sensor technology for	[SWS_ADI_00101] [SWS_ADI_00102]
	on-board sensors	[SWS_ADI_00103] [SWS_ADI_00104]
		[SWS_ADI_00105] [SWS_ADI_00106]
		[SWS_ADI_00107] [SWS_ADI_00108]
		[SWS_ADI_00113] [SWS_ADI_00114]
		[SWS_ADI_00115] [SWS_ADI_00116]
		[SWS_ADI_00117] [SWS_ADI_00118]
		[SWS_ADI_00121] [SWS_ADI_00123]
		[SWS_ADI_00124] [SWS_ADI_00125]
		[SWS_ADI_00126] [SWS_ADI_00127]
		[SWS_ADI_00128] [SWS_ADI_00129]
		[SWS_ADI_00130] [SWS_ADI_00200]
		[SWS_ADI_00201] [SWS_ADI_00202]
		[SWS_ADI_00203] [SWS_ADI_00204] [SWS_ADI_00205] [SWS_ADI_00206]
		[SWS_ADI_00203] [SWS_ADI_00208]
		[SWS_ADI_00209] [SWS_ADI_00200]
		[SWS_ADI_00213] [SWS_ADI_00212]
		[SWS ADI 00213] [SWS ADI 00214]
		[SWS_ADI_00215] [SWS_ADI_00216]
		[SWS_ADI_00218] [SWS_ADI_00219]
		[SWS_ADI_00220] [SWS_ADI_00227]
		[SWS_ADI_00228] [SWS_ADI_00229]
		[SWS_ADI_00230] [SWS_ADI_00231]
		[SWS_ADI_00232] [SWS_ADI_00233]
		[SWS ADI 00234] [SWS ADI 00235]
		[SWS_ADI_00239] [SWS_ADI_00300]
		[SWS ADI 00301] [SWS ADI 00302]
		[SWS_ADI_00303] [SWS_ADI_00304]
		[SWS_ADI_00305] [SWS_ADI_00306]
		[SWS_ADI_00308] [SWS_ADI_00310]
		[SWS_ADI_00311] [SWS_ADI_00312]
		[SWS_ADI_00313] [SWS_ADI_00314]
		[SWS_ADI_00315] [SWS_ADI_00316]
		[SWS_ADI_00317] [SWS_ADI_00318]



Requirement	Description	Satisfied by
•	-	[SWS_ADI_00319] [SWS_ADI_00320]
		[SWS_ADI_00321] [SWS_ADI_00322]
		[SWS_ADI_00323] [SWS_ADI_00325]
		[SWS_ADI_00326] [SWS_ADI_00327]
		[SWS_ADI_00339] [SWS_ADI_00340]
		[SWS_ADI_00341] [SWS_ADI_00342]
		[SWS_ADI_00343] [SWS_ADI_00344]
		[SWS_ADI_00345] [SWS_ADI_00346]
		[SWS ADI 00347] [SWS ADI 00348]
		[SWS_ADI_00349] [SWS_ADI_00350]
		[SWS_ADI_00401] [SWS_ADI_00402]
		[SWS_ADI_00403] [SWS_ADI_00404]
		[SWS_ADI_00405] [SWS_ADI_00406]
		[SWS_ADI_00407] [SWS_ADI_00408]
		[SWS_ADI_00410] [SWS_ADI_00411]
		[SWS_ADI_00412] [SWS_ADI_00413]
		[SWS_ADI_00414] [SWS_ADI_00415]
		[SWS_ADI_00417] [SWS_ADI_00418]
		[SWS_ADI_00419] [SWS_ADI_00420]
		[SWS_ADI_00421] [SWS_ADI_00422]
		[SWS_ADI_00423] [SWS_ADI_00424]
		[SWS_ADI_00425] [SWS_ADI_00426]
		[SWS_ADI_00427] [SWS_ADI_00428]
		[SWS_ADI_00429] [SWS_ADI_00430]
		[SWS_ADI_00431] [SWS_ADI_00432]
		[SWS_ADI_00433] [SWS_ADI_00434]
		[SWS_ADI_00438] [SWS_ADI_00439]
		[SWS_ADI_00440] [SWS_ADI_00441]
		[SWS_ADI_00442] [SWS_ADI_00443]
		[SWS_ADI_00444] [SWS_ADI_00445]
		[SWS_ADI_00446] [SWS_ADI_00447]
		[SWS_ADI_00448] [SWS_ADI_00449]
		[SWS_ADI_00450] [SWS_ADI_00451]
		[SWS_ADI_00452] [SWS_ADI_00453]
		[SWS_ADI_00454] [SWS_ADI_00501]
		[SWS_ADI_00502] [SWS_ADI_00503]
		[SWS_ADI_00504] [SWS_ADI_00505]
		[SWS_ADI_00506] [SWS_ADI_00507]
		[SWS_ADI_00508] [SWS_ADI_00509]
		[SWS_ADI_00510] [SWS_ADI_00511]
		[SWS_ADI_00512] [SWS_ADI_00513]
		[SWS_ADI_00514] [SWS_ADI_00515]
		[SWS_ADI_00516] [SWS_ADI_00517]
		[SWS_ADI_00518] [SWS_ADI_00519]
		[SWS_ADI_00520] [SWS_ADI_00521]
		[SWS_ADI_00523] [SWS_ADI_00524]
		[SWS_ADI_00525] [SWS_ADI_00526]
		[SWS_ADI_00527] [SWS_ADI_00528]



Requirement	Description	Satisfied by
		[SWS_ADI_00529] [SWS_ADI_00530] [SWS_ADI_00531] [SWS_ADI_00532] [SWS_ADI_00533] [SWS_ADI_00534] [SWS_ADI_00535] [SWS_ADI_00536] [SWS_ADI_00537] [SWS_ADI_00538] [SWS_ADI_00539] [SWS_ADI_00540] [SWS_ADI_00541] [SWS_ADI_00542] [SWS_ADI_00543] [SWS_ADI_00544] [SWS_ADI_00545] [SWS_ADI_00544] [SWS_ADI_00545] [SWS_ADI_00548] [SWS_ADI_00547] [SWS_ADI_00550] [SWS_ADI_00549] [SWS_ADI_00603] [SWS_ADI_00604] [SWS_ADI_00605] [SWS_ADI_00606] [SWS_ADI_00607] [SWS_ADI_00606] [SWS_ADI_00621] [SWS_ADI_00622] [SWS_ADI_00623] [SWS_ADI_00624] [SWS_ADI_00625] [SWS_ADI_00628] [SWS_ADI_00627] [SWS_ADI_00628] [SWS_ADI_00629] [SWS_ADI_00705] [SWS_ADI_00702] [SWS_ADI_00732] [SWS_ADI_00733] [SWS_ADI_00734] [SWS_ADI_00735] [SWS_ADI_01002] [SWS_ADI_01003] [SWS_ADI_01005] [SWS_ADI_01003] [SWS_ADI_01005] [SWS_ADI_01009] [SWS_ADI_01010] [SWS_ADI_010011]
[RS_ADI_00005] [RS_ADI_00006]	The ADI shall be open for future extensions towards new sensor technologies The ADI shall provide interfaces which enable exchangeability of service compatible AUTOSAR	[SWS_ADI_00006] [SWS_ADI_00010] [SWS_ADI_00012]
[RS_ADI_00007]	Adaptive applications without changing the rest of the system. The ADI shall enable use cases	[SWS_ADI_00011]
[RS_ADI_00012]	with different resource limitations. The ADI shall support the ISO-23150 interfaces and ISO-23150 interface signals	[SWS_ADI_00006] [SWS_ADI_00007] [SWS_ADI_00100] [SWS_ADI_00101] [SWS_ADI_00102] [SWS_ADI_00103] [SWS_ADI_00104] [SWS_ADI_00105] [SWS_ADI_00106] [SWS_ADI_00107] [SWS_ADI_00108] [SWS_ADI_00109] [SWS_ADI_00110] [SWS_ADI_00111] [SWS_ADI_00112] [SWS_ADI_00113] [SWS_ADI_00114] [SWS_ADI_00115] [SWS_ADI_00116] [SWS_ADI_00117] [SWS_ADI_00118] [SWS_ADI_00119] [SWS_ADI_00120] [SWS_ADI_00121]



[SWS. ADI_00122] [SWS_ADI_00125] [SWS. ADI_00126] [SWS_ADI_00127] [SWS. ADI_00126] [SWS_ADI_00127] [SWS. ADI_00128] [SWS_ADI_00127] [SWS. ADI_00128] [SWS_ADI_00127] [SWS. ADI_00130] [SWS_ADI_00120] [SWS. ADI_00201] [SWS_ADI_00200] [SWS_ADI_00201] [SWS_ADI_00202] [SWS_ADI_00201] [SWS_ADI_00204] [SWS_ADI_00205] [SWS_ADI_00204] [SWS_ADI_00205] [SWS_ADI_00204] [SWS_ADI_00206] [SWS_ADI_00206] [SWS_ADI_00207] [SWS_ADI_00208] [SWS_ADI_00207] [SWS_ADI_00210] [SWS_ADI_00211] [SWS_ADI_00210] [SWS_ADI_00211] [SWS_ADI_00212] [SWS_ADI_00211] [SWS_ADI_00212] [SWS_ADI_00217] [SWS_ADI_00218] [SWS_ADI_00221] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00224] [SWS_ADI_00225] [SWS_ADI_00226] [SWS_ADI_00227] [SWS_ADI_00226] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00223] [SWS_ADI_00226] [SWS_ADI_00223] [SWS_ADI_00226] [SWS_ADI_00223] [SWS_ADI_00226] [SWS_ADI_00231] [SWS_ADI_00236] [SWS_ADI_00231] [SWS_ADI_00236] [SWS_ADI_00231] [SWS_ADI_00236] [SWS_ADI_00231] [SWS_ADI_00236] [SWS_ADI_00331] [SWS_ADI_00300] [SWS_ADI_00331] [SWS_ADI_00300] [SWS_ADI_00331] [SWS_ADI_00300] [SWS_ADI_00331] [SWS_ADI_00301] [SWS_ADI_00331] [SWS_ADI_00301] [SWS_ADI_00331] [SWS_ADI_00311] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334]	Requirement	Description	Satisfied by
[SWS_ADI_00126] [SWS_ADI_00129] [SWS_ADI_00120] [SWS_ADI_00200] [SWS_ADI_00130] [SWS_ADI_00200] [SWS_ADI_00201] [SWS_ADI_00202] [SWS_ADI_00201] [SWS_ADI_00204] [SWS_ADI_00203] [SWS_ADI_00204] [SWS_ADI_00205] [SWS_ADI_00206] [SWS_ADI_00207] [SWS_ADI_00206] [SWS_ADI_00209] [SWS_ADI_00206] [SWS_ADI_00207] [SWS_ADI_00206] [SWS_ADI_00209] [SWS_ADI_00201] [SWS_ADI_00211] [SWS_ADI_00212] [SWS_ADI_00211] [SWS_ADI_00212] [SWS_ADI_00213] [SWS_ADI_00212] [SWS_ADI_00217] [SWS_ADI_00218] [SWS_ADI_00217] [SWS_ADI_00221] [SWS_ADI_00221] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00226] [SWS_ADI_00223] [SWS_ADI_00226] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00223] [SWS_ADI_00223] [SWS_ADI_00223] [SWS_ADI_00224] [SWS_ADI_00223] [SWS_ADI_00223] [SWS_ADI_00233] [SWS_ADI_00236] [SWS_ADI_00233] [SWS_ADI_00236] [SWS_ADI_00333] [SWS_ADI_00303] [SWS_ADI_00333] [SWS_ADI_00303] [SWS_ADI_00333] [SWS_ADI_00303] [SWS_ADI_00333] [SWS_ADI_00304] [SWS_ADI_00331] [SWS_ADI_00304] [SWS_ADI_00331] [SWS_ADI_00304] [SWS_ADI_00331] [SWS_ADI_003034] [SWS_ADI_00331] [SWS_ADI_00334] [SWS_ADI_00331] [SWS_ADI_00334] [SWS_ADI_00331] [SWS_ADI_00334] [SWS_ADI_00331] [SWS_ADI_00322] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00331] [SWS_ADI_00333] [SWS_ADI_00331] [SWS_ADI_00334] [SWS_ADI_00331] [SWS_ADI_00334] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334]	•	-	[SWS_ADI_00122] [SWS_ADI_00123]
[SWS_ADI_00128] [SWS_ADI_00200] [SWS_ADI_00201] [SWS_ADI_00202] [SWS_ADI_00201] [SWS_ADI_00202] [SWS_ADI_00203] [SWS_ADI_00204] [SWS_ADI_00203] [SWS_ADI_00206] [SWS_ADI_00207] [SWS_ADI_00206] [SWS_ADI_00207] [SWS_ADI_00206] [SWS_ADI_00207] [SWS_ADI_00208] [SWS_ADI_00207] [SWS_ADI_00208] [SWS_ADI_00210] [SWS_ADI_00210] [SWS_ADI_00211] [SWS_ADI_00214] [SWS_ADI_00213] [SWS_ADI_00214] [SWS_ADI_00213] [SWS_ADI_00214] [SWS_ADI_00217] [SWS_ADI_00218] [SWS_ADI_00219] [SWS_ADI_00226] [SWS_ADI_00223] [SWS_ADI_00226] [SWS_ADI_00223] [SWS_ADI_00226] [SWS_ADI_00223] [SWS_ADI_00226] [SWS_ADI_00223] [SWS_ADI_00228] [SWS_ADI_00223] [SWS_ADI_00228] [SWS_ADI_00223] [SWS_ADI_00228] [SWS_ADI_00223] [SWS_ADI_00228] [SWS_ADI_00233] [SWS_ADI_00236] [SWS_ADI_00236] [SWS_ADI_00238] [SWS_ADI_00236] [SWS_ADI_00238] [SWS_ADI_00336] [SWS_ADI_00300] [SWS_ADI_00330] [SWS_ADI_00304] [SWS_ADI_00331] [SWS_ADI_00304] [SWS_ADI_00331] [SWS_ADI_00304] [SWS_ADI_00331] [SWS_ADI_003031] [SWS_ADI_00331] [SWS_ADI_00304] [SWS_ADI_00331] [SWS_ADI_003031] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00331] [SWS_ADI_00334] [SWS_ADI_00331] [SWS_ADI_00334] [SWS_ADI_00332] [SWS_ADI_00334] [SWS_ADI_00333] [SWS_ADI_00334]			[SWS_ADI_00124] [SWS_ADI_00125]
[SWS_AD_00201] [SWS_AD_00202] [SWS_AD_00202] [SWS_AD_00203] [SWS_AD_00202] [SWS_AD_00203] [SWS_AD_00204] [SWS_AD_00206] [SWS_AD_00206] [SWS_AD_00206] [SWS_AD_00208] [SWS_AD_00208] [SWS_AD_00208] [SWS_AD_00208] [SWS_AD_00208] [SWS_AD_00208] [SWS_AD_00210] [SWS_AD_00210] [SWS_AD_00210] [SWS_AD_00212] [SWS_AD_00212] [SWS_AD_00212] [SWS_AD_00212] [SWS_AD_00213] [SWS_AD_00214] [SWS_AD_00215] [SWS_AD_00216] [SWS_AD_00216] [SWS_AD_00216] [SWS_AD_00216] [SWS_AD_00218] [SWS_AD_00218] [SWS_AD_00218] [SWS_AD_00218] [SWS_AD_00221] [SWS_AD_00222] [SWS_AD_00222] [SWS_AD_00222] [SWS_AD_00222] [SWS_AD_00222] [SWS_AD_00222] [SWS_AD_00223] [SWS_AD_00223] [SWS_AD_00223] [SWS_AD_00223] [SWS_AD_00230] [SWS_AD_00231] [SWS_AD_00230] [SWS_AD_00236] [SWS_AD_00236] [SWS_AD_00236] [SWS_AD_00330] [SWS_AD_00331] [SWS_AD_00331] [SWS_AD_00331] [SWS_AD_003312] [SWS_AD_003312] [SWS_AD_003312] [SWS_AD_003312] [SWS_AD_003313] [SWS_AD_003312] [SWS_AD_003313] [SWS_AD_00332] [SWS_AD_00332] [SWS_AD_00333] [SWS_AD_00333] [SWS_AD_00333] [SWS_AD_00333] [SWS_AD_00334] [SWS_AD_00333] [SWS_AD_00334] [SWS_AD_00333] [SWS_AD_00334] [SWS_AD_00333] [SWS_AD_00334]			[SWS_ADI_00126] [SWS_ADI_00127]
[SWS_ADI_00201] [SWS_ADI_00202] [SWS_ADI_00204] [SWS_ADI_00205] [SWS_ADI_00204] [SWS_ADI_00205] [SWS_ADI_00208] [SWS_ADI_00208] [SWS_ADI_00208] [SWS_ADI_00210] [SWS_ADI_00211] [SWS_ADI_00211] [SWS_ADI_00211] [SWS_ADI_00211] [SWS_ADI_00211] [SWS_ADI_00214] [SWS_ADI_00214] [SWS_ADI_00214] [SWS_ADI_00216] [SWS_ADI_00215] [SWS_ADI_00218] [SWS_ADI_00221] [SWS_ADI_00220] [SWS_ADI_00220] [SWS_ADI_00222] [SWS_ADI_00222] [SWS_ADI_00222] [SWS_ADI_00222] [SWS_ADI_00222] [SWS_ADI_00222] [SWS_ADI_00222] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00223] [SWS_ADI_00223] [SWS_ADI_00223] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00236] [SWS_ADI_00300] [SWS_ADI_00320] [SWS_ADI_00320] [SWS_ADI_00320] [SWS_ADI_00330] [SWS_ADI_00330] [SWS_ADI_00330] [SWS_ADI_00330] [SWS_ADI_00330] [SWS_ADI_00330] [SWS_ADI_00330] [SWS_ADI_00334]			[SWS_ADI_00128] [SWS_ADI_00129]
[SWS_ADI_00203] [SWS_ADI_00204] [SWS_ADI_00205] [SWS_ADI_00206] [SWS_ADI_00207] [SWS_ADI_00210] [SWS_ADI_00207] [SWS_ADI_00210] [SWS_ADI_00211] [SWS_ADI_00212] [SWS_ADI_00213] [SWS_ADI_00214] [SWS_ADI_00213] [SWS_ADI_00214] [SWS_ADI_00215] [SWS_ADI_00216] [SWS_ADI_00217] [SWS_ADI_00218] [SWS_ADI_00219] [SWS_ADI_00220] [SWS_ADI_00223] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00224] [SWS_ADI_00223] [SWS_ADI_00226] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00227] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00234] [SWS_ADI_00336] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00306] [SWS_ADI_00317] [SWS_ADI_00306] [SWS_ADI_00317] [SWS_ADI_00310] [SWS_ADI_00317] [SWS_ADI_00312] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00317] [SWS_ADI_00324] [SWS_ADI_00327] [SWS_ADI_00324] [SWS_ADI_00337] [SWS_ADI_00330] [SWS_ADI_00337] [SWS_ADI_00330] [SWS_ADI_00337] [SWS_ADI_00331] [SWS_ADI_00337] [SWS_ADI_003324] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_003342] [SWS_ADI_00337] [SWS_ADI_003342] [SWS_ADI_00337] [SWS_ADI_003342] [SWS_ADI_00337] [SWS_ADI_003342] [SWS_ADI_00334] [SWS_ADI_003342] [SWS_ADI_00334] [SWS_ADI_003342] [SWS_ADI_00334] [SWS_ADI_003342]			[SWS_ADI_00130] [SWS_ADI_00200]
[SWS_ADI_00205] SWS_ADI_00208] [SWS_ADI_00207] SWS_ADI_00208] [SWS_ADI_00207] SWS_ADI_00210] [SWS_ADI_00211] SWS_ADI_002112] [SWS_ADI_00213] SWS_ADI_00214] [SWS_ADI_00213] SWS_ADI_00214] [SWS_ADI_00213] SWS_ADI_00214] [SWS_ADI_00213] SWS_ADI_00216] [SWS_ADI_00217] SWS_ADI_00216] [SWS_ADI_00217] SWS_ADI_00228] [SWS_ADI_00227] SWS_ADI_00220] [SWS_ADI_00227] SWS_ADI_002224] [SWS_ADI_00223] SWS_ADI_002224] [SWS_ADI_00227] SWS_ADI_002224] [SWS_ADI_00227] SWS_ADI_00228] [SWS_ADI_00227] SWS_ADI_00228] [SWS_ADI_00227] SWS_ADI_00230] [SWS_ADI_00233] SWS_ADI_00230] [SWS_ADI_00233] SWS_ADI_00234] [SWS_ADI_00233] SWS_ADI_00234] [SWS_ADI_00237] SWS_ADI_00236] [SWS_ADI_00237] SWS_ADI_00236] [SWS_ADI_00237] SWS_ADI_00300] [SWS_ADI_00307] SWS_ADI_00300] [SWS_ADI_00307] SWS_ADI_00306] [SWS_ADI_00307] SWS_ADI_00306] [SWS_ADI_00307] SWS_ADI_00312] [SWS_ADI_00311] SWS_ADI_00312] [SWS_ADI_00311] SWS_ADI_00312] [SWS_ADI_00311] SWS_ADI_00312] [SWS_ADI_00311] SWS_ADI_00314] [SWS_ADI_00311] SWS_ADI_00316] [SWS_ADI_00311] SWS_ADI_00314] [SWS_ADI_00311] SWS_ADI_00316] [SWS_ADI_00311] SWS_ADI_00318] [SWS_ADI_00311] SWS_ADI_00318] [SWS_ADI_00311] SWS_ADI_00318] [SWS_ADI_00311] SWS_ADI_00324] [SWS_ADI_00327] SWS_ADI_00324] [SWS_ADI_00327] SWS_ADI_00324] [SWS_ADI_00327] SWS_ADI_00324] [SWS_ADI_00333] SWS_ADI_00334] [SWS_ADI_00333] SWS_ADI_00334] [SWS_ADI_00333] SWS_ADI_00334] [SWS_ADI_00333] SWS_ADI_00334] [SWS_ADI_00333] SWS_ADI_00334] [SWS_ADI_00333] SWS_ADI_003344			[SWS_ADI_00201] [SWS_ADI_00202]
SWS_ADI_00207 SWS_ADI_00210 SWS_ADI_00210 SWS_ADI_00210 SWS_ADI_00211 SWS_ADI_00211 SWS_ADI_00211 SWS_ADI_00214 SWS_ADI_00213 SWS_ADI_00214 SWS_ADI_00215 SWS_ADI_00216 SWS_ADI_00216 SWS_ADI_00216 SWS_ADI_00216 SWS_ADI_00217 SWS_ADI_00220 SWS_ADI_00221 SWS_ADI_00220 SWS_ADI_00221 SWS_ADI_00220 SWS_ADI_00222 SWS_ADI_00222 SWS_ADI_00222 SWS_ADI_00222 SWS_ADI_00222 SWS_ADI_00222 SWS_ADI_00222 SWS_ADI_00222 SWS_ADI_00226 SWS_ADI_00225 SWS_ADI_00226 SWS_ADI_00226 SWS_ADI_00237 SWS_ADI_00230 SWS_ADI_00231 SWS_ADI_00230 SWS_ADI_00231 SWS_ADI_00231 SWS_ADI_00236 SWS_ADI_00236 SWS_ADI_00236 SWS_ADI_00236 SWS_ADI_00301 SWS_ADI_00300 SWS_ADI_00301 SWS_ADI_00300 SWS_ADI_00301 SWS_ADI_00304 SWS_ADI_00306 SWS_ADI_00306 SWS_ADI_00306 SWS_ADI_00306 SWS_ADI_00301 SWS_ADI_00301 SWS_ADI_00301 SWS_ADI_00301 SWS_ADI_00306 SWS_ADI_00301 SWS_ADI_00306 SWS_ADI_00301 SWS_ADI_00306 SWS_ADI_00301 SWS_ADI_00310 SWS_ADI_00311 SWS_ADI_00316 SWS_ADI_00317 SWS_ADI_00318 SWS_ADI_00322 SWS_ADI_00322 SWS_ADI_00322 SWS_ADI_00323 SWS_ADI_00324 SWS_ADI_00332 SWS_ADI_00332 SWS_ADI_00332 SWS_ADI_00332 SWS_ADI_00333 SWS_ADI_00332 SWS_ADI_00333 SWS_ADI_00334 SWS_ADI_00333 SWS_ADI_00334 SWS_ADI_00333 SWS_ADI_00334 SWS_ADI_00333 SWS_ADI_00334 SWS_ADI_00333 SWS_ADI_00334 SWS_ADI_00333 SWS_ADI_00334			[SWS_ADI_00203] [SWS_ADI_00204]
[SWS_ADI_00219] SWS_ADI_00212] [SWS_ADI_00211] [SWS_ADI_00212] [SWS_ADI_00213] [SWS_ADI_00214] [SWS_ADI_00215] [SWS_ADI_00216] [SWS_ADI_00215] [SWS_ADI_00216] [SWS_ADI_00217] [SWS_ADI_00216] [SWS_ADI_00217] [SWS_ADI_00228] [SWS_ADI_00221] [SWS_ADI_00222] [SWS_ADI_00221] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00224] [SWS_ADI_00225] [SWS_ADI_00226] [SWS_ADI_00227] [SWS_ADI_00226] [SWS_ADI_00227] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00237] [SWS_ADI_00236] [SWS_ADI_00330] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00304] [SWS_ADI_00301] [SWS_ADI_00304] [SWS_ADI_00307] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00306] [SWS_ADI_00317] [SWS_ADI_00310] [SWS_ADI_00317] [SWS_ADI_00310] [SWS_ADI_00317] [SWS_ADI_00312] [SWS_ADI_00317] [SWS_ADI_00312] [SWS_ADI_00317] [SWS_ADI_00312] [SWS_ADI_00317] [SWS_ADI_00312] [SWS_ADI_00317] [SWS_ADI_00312] [SWS_ADI_00317] [SWS_ADI_00324] [SWS_ADI_00323] [SWS_ADI_00324] [SWS_ADI_00323] [SWS_ADI_00324] [SWS_ADI_00323] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00331] [SWS_ADI_00333] [SWS_ADI_00331] [SWS_ADI_00334] [SWS_ADI_00331] [SWS_ADI_00334] [SWS_ADI_00331] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_003344]			[SWS_ADI_00205] [SWS_ADI_00206]
[SWS_ADI_00211] [SWS_ADI_00212] [SWS_ADI_00213] [SWS_ADI_00216] [SWS_ADI_00215] [SWS_ADI_00216] [SWS_ADI_00217] [SWS_ADI_00218] [SWS_ADI_00221] [SWS_ADI_00220] [SWS_ADI_00221] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00224] [SWS_ADI_00223] [SWS_ADI_00226] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00227] [SWS_ADI_00230] [SWS_ADI_00223] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00234] [SWS_ADI_00237] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00236] [SWS_ADI_00303] [SWS_ADI_00302] [SWS_ADI_00303] [SWS_ADI_00302] [SWS_ADI_00303] [SWS_ADI_00304] [SWS_ADI_00303] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00308] [SWS_ADI_00307] [SWS_ADI_00310] [SWS_ADI_00307] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00317] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00316] [SWS_ADI_00313] [SWS_ADI_00316] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00327] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00337] [SWS_ADI_00330] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334]			[SWS_ADI_00207] [SWS_ADI_00208]
[SWS_ADI_00213] [SWS_ADI_00214] [SWS_ADI_00217] [SWS_ADI_00216] [SWS_ADI_00217] [SWS_ADI_00220] [SWS_ADI_00219] [SWS_ADI_00220] [SWS_ADI_00221] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00224] [SWS_ADI_00223] [SWS_ADI_00224] [SWS_ADI_00227] [SWS_ADI_00226] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00227] [SWS_ADI_00230] [SWS_ADI_00223] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00234] [SWS_ADI_00237] [SWS_ADI_00238] [SWS_ADI_00237] [SWS_ADI_00300] [SWS_ADI_00303] [SWS_ADI_00300] [SWS_ADI_00303] [SWS_ADI_00300] [SWS_ADI_00303] [SWS_ADI_00306] [SWS_ADI_00303] [SWS_ADI_00306] [SWS_ADI_00303] [SWS_ADI_00306] [SWS_ADI_00303] [SWS_ADI_00310] [SWS_ADI_00303] [SWS_ADI_00310] [SWS_ADI_00317] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00323] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00322] [SWS_ADI_00333] [SWS_ADI_00334]			
[SWS_ADI_00215] [SWS_ADI_00218] [SWS_ADI_00217] [SWS_ADI_00220] [SWS_ADI_00221] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00222] [SWS_ADI_00225] [SWS_ADI_00222] [SWS_ADI_00225] [SWS_ADI_00224] [SWS_ADI_00225] [SWS_ADI_00226] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00227] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00231] [SWS_ADI_00235] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00306] [SWS_ADI_00303] [SWS_ADI_00302] [SWS_ADI_00303] [SWS_ADI_00306] [SWS_ADI_00303] [SWS_ADI_00303] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00313] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00316] [SWS_ADI_00323] [SWS_ADI_00326] [SWS_ADI_00323] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00326] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00333] [SWS_ADI_00334]			
[SWS_ADI_00217] [SWS_ADI_00220] [SWS_ADI_00219] [SWS_ADI_00220] [SWS_ADI_00221] [SWS_ADI_00222] [SWS_ADI_00223] [SWS_ADI_00224] [SWS_ADI_00225] [SWS_ADI_00226] [SWS_ADI_00225] [SWS_ADI_00226] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00231] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00236] [SWS_ADI_00337] [SWS_ADI_00300] [SWS_ADI_00305] [SWS_ADI_00300] [SWS_ADI_00305] [SWS_ADI_00306] [SWS_ADI_00305] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00306] [SWS_ADI_00311] [SWS_ADI_00310] [SWS_ADI_00313] [SWS_ADI_00316] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00316] [SWS_ADI_00318] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00317] [SWS_ADI_00320] [SWS_ADI_00327] [SWS_ADI_00322] [SWS_ADI_00327] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00327] [SWS_ADI_00332] [SWS_ADI_00337] [SWS_ADI_00332] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334]			
[SWS_ADI_00219] [SWS_ADI_00220] [SWS_ADI_00221] [SWS_ADI_002221] [SWS_ADI_00223] [SWS_ADI_00224] [SWS_ADI_00223] [SWS_ADI_00224] [SWS_ADI_00225] [SWS_ADI_00226] [SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00229] [SWS_ADI_00228] [SWS_ADI_00229] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00306] [SWS_ADI_00309] [SWS_ADI_00306] [SWS_ADI_00309] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00314] [SWS_ADI_00317] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00322] [SWS_ADI_00324] [SWS_ADI_00323] [SWS_ADI_003324] [SWS_ADI_00333] [SWS_ADI_00333] [SWS_ADI_00333] [SWS_ADI_003336] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_003342]			
SWS_ADI_00221 SWS_ADI_00222 SWS_ADI_00224 SWS_ADI_00225 SWS_ADI_00226 SWS_ADI_00226 SWS_ADI_00226 SWS_ADI_00227 SWS_ADI_00228 SWS_ADI_00227 SWS_ADI_00230 SWS_ADI_00231 SWS_ADI_00232 SWS_ADI_00232 SWS_ADI_00233 SWS_ADI_00232 SWS_ADI_00233 SWS_ADI_00234 SWS_ADI_00235 SWS_ADI_00236 SWS_ADI_00236 SWS_ADI_00236 SWS_ADI_00236 SWS_ADI_00237 SWS_ADI_00236 SWS_ADI_00300 SWS_ADI_00301 SWS_ADI_00300 SWS_ADI_00301 SWS_ADI_00302 SWS_ADI_00303 SWS_ADI_00302 SWS_ADI_00306 SWS_ADI_00307 SWS_ADI_00306 SWS_ADI_00307 SWS_ADI_00306 SWS_ADI_00311 SWS_ADI_00316 SWS_ADI_00311 SWS_ADI_00312 SWS_ADI_00312 SWS_ADI_00312 SWS_ADI_00312 SWS_ADI_00312 SWS_ADI_00316 SWS_ADI_00317 SWS_ADI_00316 SWS_ADI_00317 SWS_ADI_00320 SWS_ADI_00320 SWS_ADI_00320 SWS_ADI_00320 SWS_ADI_00320 SWS_ADI_00322 SWS_ADI_00326 SWS_ADI_00326 SWS_ADI_00326 SWS_ADI_00326 SWS_ADI_00327 SWS_ADI_00328 SWS_ADI_00332 SWS_ADI_00334 SWS_ADI_00344 SWS_ADI_00334 SWS_ADI_00334 SWS_ADI_00334 SWS_ADI_00344 SWS_ADI_0034			
SWS_ADI_00223 SWS_ADI_00224 SWS_ADI_00225 SWS_ADI_00226 SWS_ADI_00227 SWS_ADI_00228 SWS_ADI_00229 SWS_ADI_00230 SWS_ADI_00231 SWS_ADI_00232 SWS_ADI_00231 SWS_ADI_00232 SWS_ADI_00233 SWS_ADI_00234 SWS_ADI_00235 SWS_ADI_00236 SWS_ADI_00237 SWS_ADI_00236 SWS_ADI_00239 SWS_ADI_00300 SWS_ADI_00303 SWS_ADI_00300 SWS_ADI_00303 SWS_ADI_00302 SWS_ADI_00305 SWS_ADI_00306 SWS_ADI_00305 SWS_ADI_00306 SWS_ADI_00307 SWS_ADI_00306 SWS_ADI_00309 SWS_ADI_00306 SWS_ADI_00311 SWS_ADI_00310 SWS_ADI_00313 SWS_ADI_00312 SWS_ADI_00315 SWS_ADI_00314 SWS_ADI_00315 SWS_ADI_00316 SWS_ADI_00315 SWS_ADI_00316 SWS_ADI_00315 SWS_ADI_00322 SWS_ADI_00323 SWS_ADI_00322 SWS_ADI_00323 SWS_ADI_00322 SWS_ADI_00323 SWS_ADI_00324 SWS_ADI_00325 SWS_ADI_00326 SWS_ADI_00337 SWS_ADI_00328 SWS_ADI_00337 SWS_ADI_00336 SWS_ADI_00337 SWS_ADI_00334 SWS_ADI_00337 SWS_ADI_00344 SWS_ADI_00347 SWS_ADI_00344			
[SWS_ADI_00225] [SWS_ADI_00226] [SWS_ADI_00227] [SWS_ADI_00220] [SWS_ADI_00229] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00238] [SWS_ADI_00237] [SWS_ADI_00238] [SWS_ADI_00301] [SWS_ADI_00302] [SWS_ADI_00301] [SWS_ADI_00302] [SWS_ADI_00307] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00308] [SWS_ADI_00307] [SWS_ADI_00310] [SWS_ADI_00307] [SWS_ADI_00316] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00314] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00317] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00337] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334]			
[SWS_ADI_00227] [SWS_ADI_00228] [SWS_ADI_00229] [SWS_ADI_00230] [SWS_ADI_002231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00238] [SWS_ADI_00237] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00302] [SWS_ADI_00303] [SWS_ADI_00304] [SWS_ADI_00305] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00326] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00337] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00344] [SWS_ADI_00337] [SWS_ADI_00342] [SWS_ADI_00337] [SWS_ADI_00344]			
[SWS_ADI_00229] [SWS_ADI_00230] [SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00234] [SWS_ADI_00237] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00300] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00302] [SWS_ADI_00305] [SWS_ADI_00304] [SWS_ADI_00305] [SWS_ADI_00306] [SWS_ADI_00305] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00306] [SWS_ADI_00311] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00316] [SWS_ADI_00319] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00325] [SWS_ADI_00322] [SWS_ADI_00327] [SWS_ADI_00322] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00327] [SWS_ADI_00332] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334]			
[SWS_ADI_00231] [SWS_ADI_00232] [SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00238] [SWS_ADI_00237] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00302] [SWS_ADI_00303] [SWS_ADI_00304] [SWS_ADI_00305] [SWS_ADI_00304] [SWS_ADI_00305] [SWS_ADI_00304] [SWS_ADI_00307] [SWS_ADI_00308] [SWS_ADI_00307] [SWS_ADI_00308] [SWS_ADI_00307] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00317] [SWS_ADI_00314] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00317] [SWS_ADI_00322] [SWS_ADI_00327] [SWS_ADI_00322] [SWS_ADI_00327] [SWS_ADI_00322] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334]			
[SWS_ADI_00233] [SWS_ADI_00234] [SWS_ADI_00235] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00238] [SWS_ADI_00237] [SWS_ADI_00300] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00302] [SWS_ADI_00303] [SWS_ADI_00302] [SWS_ADI_00305] [SWS_ADI_00304] [SWS_ADI_00305] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00308] [SWS_ADI_00307] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00312] [SWS_ADI_00315] [SWS_ADI_00312] [SWS_ADI_00315] [SWS_ADI_00314] [SWS_ADI_00317] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00322] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00336] [SWS_ADI_003331] [SWS_ADI_00330] [SWS_ADI_003331] [SWS_ADI_00334] [SWS_ADI_003331] [SWS_ADI_00334] [SWS_ADI_003331] [SWS_ADI_00334] [SWS_ADI_003331] [SWS_ADI_00338] [SWS_ADI_003331] [SWS_ADI_00338] [SWS_ADI_003331] [SWS_ADI_00338] [SWS_ADI_003341] [SWS_ADI_003342] [SWS_ADI_00341] [SWS_ADI_00344]			
[SWS_ADI_00235] [SWS_ADI_00236] [SWS_ADI_00237] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00302] [SWS_ADI_00303] [SWS_ADI_00304] [SWS_ADI_00305] [SWS_ADI_00304] [SWS_ADI_00305] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00316] [SWS_ADI_00319] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00320] [SWS_ADI_00322] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00330] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_003340] [SWS_ADI_003341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00237] [SWS_ADI_00238] [SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00302] [SWS_ADI_00303] [SWS_ADI_00304] [SWS_ADI_00305] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00308] [SWS_ADI_00307] [SWS_ADI_00308] [SWS_ADI_00307] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00315] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00325] [SWS_ADI_00324] [SWS_ADI_00327] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00331] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00341] [SWS_ADI_00344]			
[SWS_ADI_00239] [SWS_ADI_00300] [SWS_ADI_00301] [SWS_ADI_00302] [SWS_ADI_00303] [SWS_ADI_00304] [SWS_ADI_00305] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00308] [SWS_ADI_00307] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00325] [SWS_ADI_00324] [SWS_ADI_00327] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334]			
[SWS_ADI_00301] [SWS_ADI_00302] [SWS_ADI_00303] [SWS_ADI_00304] [SWS_ADI_00305] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00308] [SWS_ADI_00307] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00317] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00320] [SWS_ADI_00323] [SWS_ADI_00322] [SWS_ADI_00325] [SWS_ADI_00324] [SWS_ADI_00327] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00336] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00334]			
[SWS_ADI_00303] [SWS_ADI_00304] [SWS_ADI_00305] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00308] [SWS_ADI_00307] [SWS_ADI_00310] [SWS_ADI_00309] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00317] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00320] [SWS_ADI_00323] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00335] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00334] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00305] [SWS_ADI_00306] [SWS_ADI_00307] [SWS_ADI_00308] [SWS_ADI_00309] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00319] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00322] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00334] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00344]			
[SWS_ADI_00307] [SWS_ADI_00308] [SWS_ADI_00309] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00319] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00322] [SWS_ADI_00325] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00337] [SWS_ADI_00330] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00309] [SWS_ADI_00310] [SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00319] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00322] [SWS_ADI_00325] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00311] [SWS_ADI_00312] [SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00319] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00324] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00338] [SWS_ADI_00334] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00313] [SWS_ADI_00314] [SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00319] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00324] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00319] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00317] [SWS_ADI_00318] [SWS_ADI_00319] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00335] [SWS_ADI_00334] [SWS_ADI_00337] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00319] [SWS_ADI_00320] [SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00321] [SWS_ADI_00322] [SWS_ADI_00323] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00323] [SWS_ADI_00324] [SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00325] [SWS_ADI_00326] [SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00327] [SWS_ADI_00328] [SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00329] [SWS_ADI_00330] [SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00331] [SWS_ADI_00332] [SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00333] [SWS_ADI_00334] [SWS_ADI_00335] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00335] [SWS_ADI_00336] [SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00337] [SWS_ADI_00338] [SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00339] [SWS_ADI_00340] [SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00341] [SWS_ADI_00342] [SWS_ADI_00343] [SWS_ADI_00344]			
[SWS_ADI_00343] [SWS_ADI_00344]			
			[SWS_ADI_00345] [SWS_ADI_00346]



Requirement	Description	Satisfied by
-	-	[SWS_ADI_00347] [SWS_ADI_00348]
		[SWS_ADI_00349] [SWS_ADI_00350]
		[SWS_ADI_00401] [SWS_ADI_00402]
		[SWS_ADI_00403] [SWS_ADI_00404]
		[SWS_ADI_00405] [SWS_ADI_00406]
		[SWS_ADI_00407] [SWS_ADI_00408]
		[SWS_ADI_00409] [SWS_ADI_00410]
		[SWS_ADI_00411] [SWS_ADI_00412]
		[SWS_ADI_00413] [SWS_ADI_00414]
		[SWS_ADI_00415] [SWS_ADI_00416]
		[SWS_ADI_00417] [SWS_ADI_00418]
		[SWS_ADI_00419] [SWS_ADI_00420]
		[SWS_ADI_00421] [SWS_ADI_00422]
		[SWS_ADI_00423] [SWS_ADI_00424]
		[SWS_ADI_00425] [SWS_ADI_00426]
		[SWS_ADI_00427] [SWS_ADI_00428]
		[SWS_ADI_00429] [SWS_ADI_00430]
		[SWS_ADI_00431] [SWS_ADI_00432]
		[SWS_ADI_00433] [SWS_ADI_00434]
		[SWS_ADI_00435] [SWS_ADI_00436]
		[SWS_ADI_00437] [SWS_ADI_00438]
		[SWS_ADI_00439] [SWS_ADI_00440]
		[SWS_ADI_00441] [SWS_ADI_00442]
		[SWS_ADI_00443] [SWS_ADI_00444]
		[SWS_ADI_00445] [SWS_ADI_00446]
		[SWS_ADI_00447] [SWS_ADI_00448]
		[SWS_ADI_00449] [SWS_ADI_00450]
		[SWS_ADI_00451] [SWS_ADI_00452]
		[SWS_ADI_00453] [SWS_ADI_00454]
		[SWS_ADI_00501] [SWS_ADI_00502]
		[SWS_ADI_00503] [SWS_ADI_00504]
		[SWS_ADI_00505] [SWS_ADI_00506]
		[SWS_ADI_00507] [SWS_ADI_00508]
		[SWS_ADI_00509] [SWS_ADI_00510]
		[SWS_ADI_00511] [SWS_ADI_00512]
		[SWS_ADI_00513] [SWS_ADI_00514]
		[SWS_ADI_00515] [SWS_ADI_00516]
		[SWS_ADI_00517] [SWS_ADI_00518]
		[SWS_ADI_00519] [SWS_ADI_00520] [SWS_ADI_00521] [SWS_ADI_00523]
		[SWS_ADI_00521] [SWS_ADI_00523]
		[SWS_ADI_00524] [SWS_ADI_00525]
		[SWS_ADI_00528] [SWS_ADI_00527]
		[SWS_ADI_00528] [SWS_ADI_00529]
		[SWS_ADI_00530] [SWS_ADI_00531]
		[SWS_ADI_00532] [SWS_ADI_00535]
		[SWS_ADI_00536] [SWS_ADI_00537]
		[SWS_ADI_00538] [SWS_ADI_00539]
		[5110_7151_00000][0110_7151_00000]



Requirement	Description	Satisfied by
<u>.</u>	-	[SWS_ADI_00540] [SWS_ADI_00541]
		[SWS_ADI_00542] [SWS_ADI_00543]
		[SWS_ADI_00544] [SWS_ADI_00545]
		[SWS_ADI_00546] [SWS_ADI_00547]
		[SWS_ADI_00548] [SWS_ADI_00549]
		[SWS_ADI_00550] [SWS_ADI_00551]
		[SWS_ADI_00601] [SWS_ADI_00602]
		[SWS_ADI_00603] [SWS_ADI_00604]
		[SWS_ADI_00605] [SWS_ADI_00606]
		[SWS_ADI_00607] [SWS_ADI_00608]
		[SWS_ADI_00609] [SWS_ADI_00610]
		[SWS_ADI_00611] [SWS_ADI_00612]
		[SWS_ADI_00613] [SWS_ADI_00614]
		[SWS_ADI_00615] [SWS_ADI_00616]
		[SWS_ADI_00617] [SWS_ADI_00618]
		[SWS_ADI_00619] [SWS_ADI_00620] [SWS_ADI_00621] [SWS_ADI_00622]
		[SWS_ADI_00623] [SWS_ADI_00624]
		[SWS_ADI_00625] [SWS_ADI_00624]
		[SWS_ADI_00023] [SWS_ADI_00023]
		[SWS_ADI_00629] [SWS_ADI_00701]
		[SWS_ADI_00702] [SWS_ADI_00703]
		[SWS_ADI_00704] [SWS_ADI_00705]
		[SWS_ADI_00706] [SWS_ADI_00707]
		[SWS_ADI_00708] [SWS_ADI_00709]
		[SWS_ADI_00710] [SWS_ADI_00711]
		[SWS_ADI_00712] [SWS_ADI_00713]
		[SWS_ADI_00714] [SWS_ADI_00715]
		[SWS_ADI_00716] [SWS_ADI_00717]
		[SWS_ADI_00718] [SWS_ADI_00719]
		[SWS_ADI_00720] [SWS_ADI_00721]
		[SWS_ADI_00722] [SWS_ADI_00723]
		[SWS_ADI_00724] [SWS_ADI_00725]
		[SWS_ADI_00726] [SWS_ADI_00727]
		[SWS_ADI_00728] [SWS_ADI_00729]
		[SWS_ADI_00730] [SWS_ADI_00731]
		[SWS_ADI_00732] [SWS_ADI_00733]
[DC ADL 00040]	The ADI alcall intermedable	[SWS_ADI_00734] [SWS_ADI_00735]
[RS_ADI_00013]	The ADI shall interpret the	[SWS_ADI_00006] [SWS_ADI_00007]
	ISO-23150 compliant to AUTOSAR	[SWS_ADI_00100] [SWS_ADI_00101] [SWS_ADI_00102] [SWS_ADI_00103]
	AUTOSAN	[SWS_ADI_00102] [SWS_ADI_00103]
		[SWS_ADI_00104][SWS_ADI_00103]
		[SWS_ADI_00108] [SWS_ADI_00109]
		[SWS_ADI_00110] [SWS_ADI_00111]
		[SWS ADI 00112] [SWS ADI 00113]
		[SWS_ADI_00114] [SWS_ADI_00115]
		[SWS_ADI_00116] [SWS_ADI_00117]
		[SWS_ADI_00118] [SWS_ADI_00119]
		[SWS_ADI_00120] [SWS_ADI_00121]
1	T .	1 r =



Requirement	Description	Satisfied by
•	•	[SWS_ADI_00122] [SWS_ADI_00123]
		[SWS_ADI_00124] [SWS_ADI_00125]
		[SWS_ADI_00126] [SWS_ADI_00127]
		[SWS_ADI_00128] [SWS_ADI_00129]
		[SWS_ADI_00130] [SWS_ADI_00200]
		[SWS ADI 00201] [SWS ADI 00202]
		[SWS_ADI_00203] [SWS_ADI_00204]
		[SWS_ADI_00205] [SWS_ADI_00206]
		[SWS_ADI_00207] [SWS_ADI_00208]
		[SWS_ADI_00209] [SWS_ADI_00210]
		[SWS_ADI_00211] [SWS_ADI_00212]
		[SWS_ADI_00213] [SWS_ADI_00214]
		[SWS_ADI_00215] [SWS_ADI_00216]
		[SWS_ADI_00217] [SWS_ADI_00218]
		[SWS_ADI_00219] [SWS_ADI_00220]
		[SWS_ADI_00221] [SWS_ADI_00222]
		[SWS_ADI_00223] [SWS_ADI_00224]
		[SWS_ADI_00225] [SWS_ADI_00226]
		[SWS_ADI_00227] [SWS_ADI_00228]
		[SWS_ADI_00229] [SWS_ADI_00230]
		[SWS_ADI_00231] [SWS_ADI_00232]
		[SWS_ADI_00233] [SWS_ADI_00234]
		[SWS_ADI_00235] [SWS_ADI_00236]
		[SWS_ADI_00237] [SWS_ADI_00238]
		[SWS_ADI_00239] [SWS_ADI_00300]
		[SWS_ADI_00301] [SWS_ADI_00302]
		[SWS_ADI_00303] [SWS_ADI_00304]
		[SWS_ADI_00305] [SWS_ADI_00306]
		[SWS_ADI_00307] [SWS_ADI_00308]
		[SWS_ADI_00309] [SWS_ADI_00310]
		[SWS_ADI_00311] [SWS_ADI_00312]
		[SWS_ADI_00313] [SWS_ADI_00314]
		[SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00318]
		[SWS_ADI_00317] [SWS_ADI_00316]
		[SWS_ADI_00319][SWS_ADI_00320]
		[SWS_ADI_00321] [SWS_ADI_00322]
		[SWS_ADI_00325] [SWS_ADI_00324]
		[SWS_ADI_00327] [SWS_ADI_00328]
		[SWS_ADI_00329] [SWS_ADI_00330]
		[SWS_ADI_00331] [SWS_ADI_00332]
		[SWS_ADI_00333] [SWS_ADI_00334]
		[SWS_ADI_00335] [SWS_ADI_00336]
		[SWS_ADI_00337] [SWS_ADI_00338]
		[SWS_ADI_00339] [SWS_ADI_00340]
		[SWS_ADI_00341] [SWS_ADI_00342]
		[SWS ADI 00343] [SWS ADI 00344]
		[SWS_ADI_00345] [SWS_ADI_00346]
	I	



Requirement	Description	Satisfied by
-		[SWS_ADI_00347] [SWS_ADI_00348]
		[SWS ADI 00349] [SWS ADI 00350]
		[SWS_ADI_00401] [SWS_ADI_00402]
		[SWS_ADI_00403] [SWS_ADI_00404]
		[SWS_ADI_00405] [SWS_ADI_00406]
		[SWS_ADI_00407] [SWS_ADI_00408]
		[SWS_ADI_00409] [SWS_ADI_00410]
		[SWS_ADI_00411] [SWS_ADI_00412]
		[SWS_ADI_00413] [SWS_ADI_00414]
		[SWS_ADI_00415] [SWS_ADI_00416]
		[SWS_ADI_00417] [SWS_ADI_00418]
		[SWS_ADI_00419] [SWS_ADI_00420]
		[SWS_ADI_00421] [SWS_ADI_00422]
		[SWS_ADI_00423] [SWS_ADI_00424]
		[SWS_ADI_00425] [SWS_ADI_00426]
		[SWS ADI 00427] [SWS ADI 00428]
		[SWS_ADI_00429] [SWS_ADI_00430]
		[SWS_ADI_00431] [SWS_ADI_00432]
		[SWS ADI 00433] [SWS ADI 00434]
		[SWS_ADI_00435] [SWS_ADI_00436]
		[SWS_ADI_00437] [SWS_ADI_00438]
		[SWS_ADI_00439] [SWS_ADI_00440]
		[SWS_ADI_00441] [SWS_ADI_00442]
		[SWS_ADI_00443] [SWS_ADI_00444]
		[SWS_ADI_00445] [SWS_ADI_00446]
		[SWS_ADI_00447] [SWS_ADI_00448]
		[SWS_ADI_00449] [SWS_ADI_00450]
		[SWS_ADI_00451] [SWS_ADI_00452]
		[SWS_ADI_00453] [SWS_ADI_00454]
		[SWS_ADI_00501] [SWS_ADI_00502]
		[SWS_ADI_00503] [SWS_ADI_00504]
		[SWS_ADI_00505] [SWS_ADI_00506]
		[SWS_ADI_00507] [SWS_ADI_00508]
		[SWS_ADI_00509] [SWS_ADI_00510]
		[SWS_ADI_00511] [SWS_ADI_00512]
		[SWS_ADI_00513] [SWS_ADI_00514]
		[SWS_ADI_00515] [SWS_ADI_00516]
		[SWS_ADI_00517] [SWS_ADI_00518]
		[SWS_ADI_00519] [SWS_ADI_00520]
		[SWS_ADI_00521] [SWS_ADI_00523]
		[SWS_ADI_00524] [SWS_ADI_00525]
		[SWS_ADI_00526] [SWS_ADI_00527]
		[SWS_ADI_00528] [SWS_ADI_00529]
		[SWS_ADI_00530] [SWS_ADI_00531]
		[SWS_ADI_00532] [SWS_ADI_00533]
		[SWS_ADI_00534] [SWS_ADI_00535]
		[SWS_ADI_00536] [SWS_ADI_00537]
		[SWS_ADI_00538] [SWS_ADI_00539]



Requirement	Description	Satisfied by
•	•	[SWS_ADI_00540] [SWS_ADI_00541]
		[SWS_ADI_00542] [SWS_ADI_00543]
		[SWS_ADI_00544] [SWS_ADI_00545]
		SWS ADI 00546 SWS ADI 00547
		[SWS_ADI_00548] [SWS_ADI_00549]
		[SWS_ADI_00550] [SWS_ADI_00551]
		[SWS_ADI_00601] [SWS_ADI_00602]
		[SWS ADI 00603] [SWS ADI 00604]
		[SWS ADI 00605] [SWS ADI 00606]
		[SWS_ADI_00607] [SWS_ADI_00608]
		[SWS_ADI_00609] [SWS_ADI_00610]
		[SWS_ADI_00611] [SWS_ADI_00612]
		[SWS_ADI_00613] [SWS_ADI_00614]
		[SWS_ADI_00615] [SWS_ADI_00616]
		[SWS_ADI_00617] [SWS_ADI_00618]
		[SWS_ADI_00619] [SWS_ADI_00620]
		[SWS_ADI_00621] [SWS_ADI_00622]
		[SWS ADI 00623] [SWS ADI 00624]
		[SWS ADI 00625] [SWS ADI 00626]
		[SWS_ADI_00627] [SWS_ADI_00628]
		[SWS_ADI_00629] [SWS_ADI_00701]
		[SWS_ADI_00702] [SWS_ADI_00703]
		[SWS_ADI_00704] [SWS_ADI_00705]
		[SWS_ADI_00706] [SWS_ADI_00707]
		[SWS_ADI_00708] [SWS_ADI_00709]
		[SWS_ADI_00710] [SWS_ADI_00711]
		[SWS_ADI_00712] [SWS_ADI_00713]
		[SWS_ADI_00714] [SWS_ADI_00715]
		[SWS_ADI_00716] [SWS_ADI_00717]
		[SWS_ADI_00718] [SWS_ADI_00719]
		[SWS_ADI_00720] [SWS_ADI_00721]
		[SWS_ADI_00722] [SWS_ADI_00723]
		[SWS_ADI_00724] [SWS_ADI_00725]
		[SWS_ADI_00726] [SWS_ADI_00727]
		[SWS_ADI_00728] [SWS_ADI_00729]
		[SWS_ADI_00730] [SWS_ADI_00731]
		[SWS_ADI_00732] [SWS_ADI_00733]
		[SWS_ADI_00734] [SWS_ADI_00735]
[RS_ADI_00014]	The ADI shall be aligned with the	[SWS_ADI_00006] [SWS_ADI_00007]
	semantics of the corresponding	[SWS_ADI_00100] [SWS_ADI_00101]
	elements in the ISO-23150 .	[SWS_ADI_00102] [SWS_ADI_00103]
		[SWS_ADI_00104] [SWS_ADI_00105]
		[SWS_ADI_00106] [SWS_ADI_00107]
		[SWS_ADI_00108] [SWS_ADI_00109]
		[SWS_ADI_00110] [SWS_ADI_00111]
		[SWS_ADI_00112] [SWS_ADI_00113]
		[SWS_ADI_00114] [SWS_ADI_00115]
		[SWS_ADI_00116] [SWS_ADI_00117]
		[SWS_ADI_00118] [SWS_ADI_00119]
		[SWS_ADI_00120] [SWS_ADI_00121]



Requirement	Description	Satisfied by
•	•	[SWS_ADI_00122] [SWS_ADI_00123]
		[SWS_ADI_00124] [SWS_ADI_00125]
		[SWS_ADI_00126] [SWS_ADI_00127]
		[SWS_ADI_00128] [SWS_ADI_00129]
		[SWS_ADI_00130] [SWS_ADI_00200]
		[SWS ADI 00201] [SWS ADI 00202]
		[SWS_ADI_00203] [SWS_ADI_00204]
		[SWS_ADI_00205] [SWS_ADI_00206]
		[SWS_ADI_00207] [SWS_ADI_00208]
		[SWS_ADI_00209] [SWS_ADI_00210]
		[SWS_ADI_00211] [SWS_ADI_00212]
		[SWS_ADI_00213] [SWS_ADI_00214]
		[SWS_ADI_00215] [SWS_ADI_00216]
		[SWS_ADI_00217] [SWS_ADI_00218]
		[SWS_ADI_00219] [SWS_ADI_00220]
		[SWS_ADI_00221] [SWS_ADI_00222]
		[SWS_ADI_00223] [SWS_ADI_00224]
		[SWS_ADI_00225] [SWS_ADI_00226]
		[SWS_ADI_00227] [SWS_ADI_00228]
		[SWS_ADI_00229] [SWS_ADI_00230]
		[SWS_ADI_00231] [SWS_ADI_00232]
		[SWS_ADI_00233] [SWS_ADI_00234]
		[SWS_ADI_00235] [SWS_ADI_00236]
		[SWS_ADI_00237] [SWS_ADI_00238]
		[SWS_ADI_00239] [SWS_ADI_00300]
		[SWS_ADI_00301] [SWS_ADI_00302]
		[SWS_ADI_00303] [SWS_ADI_00304]
		[SWS_ADI_00305] [SWS_ADI_00306]
		[SWS_ADI_00307] [SWS_ADI_00308]
		[SWS_ADI_00309] [SWS_ADI_00310]
		[SWS_ADI_00311] [SWS_ADI_00312]
		[SWS_ADI_00313] [SWS_ADI_00314]
		[SWS_ADI_00315] [SWS_ADI_00316] [SWS_ADI_00317] [SWS_ADI_00318]
		[SWS_ADI_00317] [SWS_ADI_00316]
		[SWS_ADI_00319][SWS_ADI_00320]
		[SWS_ADI_00321] [SWS_ADI_00322]
		[SWS_ADI_00325] [SWS_ADI_00324]
		[SWS_ADI_00327] [SWS_ADI_00328]
		[SWS_ADI_00329] [SWS_ADI_00330]
		[SWS_ADI_00331] [SWS_ADI_00332]
		[SWS_ADI_00333] [SWS_ADI_00334]
		[SWS_ADI_00335] [SWS_ADI_00336]
		[SWS_ADI_00337] [SWS_ADI_00338]
		[SWS_ADI_00339] [SWS_ADI_00340]
		[SWS_ADI_00341] [SWS_ADI_00342]
		[SWS ADI 00343] [SWS ADI 00344]
		[SWS_ADI_00345] [SWS_ADI_00346]
	I	



Requirement	Description	Satisfied by
-		[SWS_ADI_00347] [SWS_ADI_00348]
		[SWS ADI 00349] [SWS ADI 00350]
		[SWS_ADI_00401] [SWS_ADI_00402]
		[SWS_ADI_00403] [SWS_ADI_00404]
		[SWS_ADI_00405] [SWS_ADI_00406]
		[SWS_ADI_00407] [SWS_ADI_00408]
		[SWS_ADI_00409] [SWS_ADI_00410]
		[SWS_ADI_00411] [SWS_ADI_00412]
		[SWS_ADI_00413] [SWS_ADI_00414]
		[SWS_ADI_00415] [SWS_ADI_00416]
		[SWS_ADI_00417] [SWS_ADI_00418]
		[SWS_ADI_00419] [SWS_ADI_00420]
		[SWS_ADI_00421] [SWS_ADI_00422]
		[SWS_ADI_00423] [SWS_ADI_00424]
		[SWS_ADI_00425] [SWS_ADI_00426]
		[SWS ADI 00427] [SWS ADI 00428]
		[SWS_ADI_00429] [SWS_ADI_00430]
		[SWS_ADI_00431] [SWS_ADI_00432]
		[SWS ADI 00433] [SWS ADI 00434]
		[SWS_ADI_00435] [SWS_ADI_00436]
		[SWS_ADI_00437] [SWS_ADI_00438]
		[SWS_ADI_00439] [SWS_ADI_00440]
		[SWS_ADI_00441] [SWS_ADI_00442]
		[SWS_ADI_00443] [SWS_ADI_00444]
		[SWS_ADI_00445] [SWS_ADI_00446]
		[SWS_ADI_00447] [SWS_ADI_00448]
		[SWS_ADI_00449] [SWS_ADI_00450]
		[SWS_ADI_00451] [SWS_ADI_00452]
		[SWS_ADI_00453] [SWS_ADI_00454]
		[SWS_ADI_00501] [SWS_ADI_00502]
		[SWS_ADI_00503] [SWS_ADI_00504]
		[SWS_ADI_00505] [SWS_ADI_00506]
		[SWS_ADI_00507] [SWS_ADI_00508]
		[SWS_ADI_00509] [SWS_ADI_00510]
		[SWS_ADI_00511] [SWS_ADI_00512]
		[SWS_ADI_00513] [SWS_ADI_00514]
		[SWS_ADI_00515] [SWS_ADI_00516]
		[SWS_ADI_00517] [SWS_ADI_00518]
		[SWS_ADI_00519] [SWS_ADI_00520]
		[SWS_ADI_00521] [SWS_ADI_00523]
		[SWS_ADI_00524] [SWS_ADI_00525]
		[SWS_ADI_00526] [SWS_ADI_00527]
		[SWS_ADI_00528] [SWS_ADI_00529]
		[SWS_ADI_00530] [SWS_ADI_00531]
		[SWS_ADI_00532] [SWS_ADI_00533]
		[SWS_ADI_00534] [SWS_ADI_00535]
		[SWS_ADI_00536] [SWS_ADI_00537]
		[SWS_ADI_00538] [SWS_ADI_00539]



Requirement	Description	Satisfied by
	•	[SWS_ADI_00540] [SWS_ADI_00541]
		[SWS_ADI_00542] [SWS_ADI_00543]
		[SWS_ADI_00544] [SWS_ADI_00545]
		[SWS_ADI_00546] [SWS_ADI_00547]
		[SWS_ADI_00548] [SWS_ADI_00549]
		[SWS_ADI_00550] [SWS_ADI_00551]
		[SWS_ADI_00601] [SWS_ADI_00602]
		[SWS_ADI_00603] [SWS_ADI_00604]
		[SWS_ADI_00605] [SWS_ADI_00606]
		[SWS_ADI_00607] [SWS_ADI_00608]
		[SWS_ADI_00609] [SWS_ADI_00610]
		[SWS_ADI_00611] [SWS_ADI_00612]
		[SWS_ADI_00613] [SWS_ADI_00614]
		[SWS_ADI_00615] [SWS_ADI_00616]
		[SWS_ADI_00617] [SWS_ADI_00618]
		[SWS_ADI_00619] [SWS_ADI_00620]
		[SWS_ADI_00621] [SWS_ADI_00622]
		[SWS_ADI_00623] [SWS_ADI_00624] [SWS_ADI_00625] [SWS_ADI_00626]
		[SWS_ADI_00025] [SWS_ADI_00020]
		[SWS_ADI_00027] [SWS_ADI_00020]
		[SWS ADI 00702] [SWS ADI 00703]
		[SWS_ADI_00704] [SWS_ADI_00705]
		[SWS_ADI_00706] [SWS_ADI_00707]
		[SWS_ADI_00708] [SWS_ADI_00709]
		[SWS_ADI_00710] [SWS_ADI_00711]
		[SWS_ADI_00712] [SWS_ADI_00713]
		[SWS_ADI_00714] [SWS_ADI_00715]
		[SWS_ADI_00716] [SWS_ADI_00717]
		[SWS_ADI_00718] [SWS_ADI_00719]
		[SWS_ADI_00720] [SWS_ADI_00721]
		[SWS_ADI_00722] [SWS_ADI_00723]
		[SWS_ADI_00724] [SWS_ADI_00725]
		[SWS_ADI_00726] [SWS_ADI_00727]
		[SWS_ADI_00728] [SWS_ADI_00729]
		[SWS_ADI_00730] [SWS_ADI_00731]
		[SWS_ADI_00732] [SWS_ADI_00733]
		[SWS_ADI_00734] [SWS_ADI_00735]
[RS_ADI_00015]	The ADI shall limit the	[SWS_ADI_00010] [SWS_ADI_00012]
IDO ADI COCACI	transmission of unused data.	TOWO ADL COOKOLOUNG ADL COCKO
[RS_ADI_00016]	The ADI specification shall	[SWS_ADI_00010] [SWS_ADI_00012]
	support the replacement of a	
	sensor by another one providing more profiles without	
	· ·	
	recompilation of the client software.	
[RS_ADI_00017]	The ADI specification shall	[SWS_ADI_00010] [SWS_ADI_00012]
[110_VDI_00011]	support the replacement of a	[0110_ADI_00010][0110_ADI_00012]
	sensor by another one providing	
	less profiles without	
	recompilation of the client	
	software if the removed profiles	
	are not used.	
	are not used.	



Requirement	Description	Satisfied by
[RS_ADI_00018]	The ADI specification shall enable AUTOSAR Adaptive applications to discard sensor data when newer sensor data is available.	[SWS_ADI_00005]
[RS_ADI_00019]	The ADI shall provide interface specifications that support an automatic translation of an interface specification to an implementable service interface.	[SWS_ADI_00006] [SWS_ADI_00007]



7 Functional Specification

7.1 Outline

7.1.1 Goals and scope

The specification is to provide well-defined sensor interfaces which is compliant to the sensor interface specification [1]. The ISO document covers just semantic definitions of interfaces whereas this specification aims to cover all aspects of the interfaces to make them fully compliant to the AUTOSAR Adaptive platform.

The specification shall enable the compatibility of sensors and data fusion algorithms independently of the supplier. To ensure the compatibility between sensors the interfaces are provided on implementation data type level.

The Automated Driving Interfaces serve as common interfaces for the AUTOSAR Adaptive applications. Consumers of the interfaces are AUTOSAR Adaptive applications containing functional elements as sensor data receivers, sensor data processors, data fusion applications, and automated driving functions. The sensor information is provided by a non-platform service. The non-platform service consumer is running in the apdative platfom as an AUTOSAR adaptive application, where the sensor could be deployed on different AUTOSAR platforms (Classic and Adaptive) as shown in the following figure.




Figure 7.1: Functional elements communicating via ADI

Apart from the Automated Driving Interfaces (ADI), the other relevent elements are defined as follows:



- Sensor Data Reception: A functional element which receives or reads sensor data from a sensor. Such an element can provide raw sensor data. Raw sensor data means that it provides the actual data a sensor can measure. There is no processing of the sensor data. There are no data streams provided.
- Sensor Data Processing: This element which usually processes raw sensor data, provides pre-processed and post-processed sensor data. It provides data a sensor cannot directly measure but needs a processing stage for.
- Sensor Fusion Application: The data fusion algorithm is an application which collects sensor data and fuses it to provide a unified environmental model. Data fusion applications are typical consumers of sensor data. They provide their output to Automated Driving Functions.
- Automated Driving Function: Automated Driving Functions can also directly use the interfaces.

The Automated Driving interfaces can be used in following usages to enable the interoperability between different players and improve the efficiency for the development and validation of automated driving functions:

- Sensor Supplier Interface: The automated driving use case defines the requirements to the fusion algorithm and the used sensors. The OEM wants to rely on a standardized interface which provides well defined sensor information which are defined by the ISO-23150 and on an AUTOSAR standardized interface. The scope shall be the data format between a sensor and a computing unit running an AUTOSAR Adaptive application.
- Standardized Sensor API: Sensor developers need well described and standardized interfaces to provide an implementation which can be used by automated driving applications and data fusion algorithms. So, the same information is provided to all potential consumers of the data.
- Sensor Fusion Algorithm: To combine information from different sensors and to develop sensor fusion algorithms for automated driving a detailed description of all signals provided is needed.
- Sensor Fusion Integration: Sensor fusion algorithms shall be integrated on a high-performance computing platform within an Adaptive Application as the central unit of automated driving functions.
- Sensor Implementation Testing: Testing is performed at each stage of the development of the sensor system. To create a test specification for the system testable implementations are needed which are based on well-defined interfaces and descriptions.
- Sensor Simulation: By simulating the sensor fusion algorithms before actual target integration, it is possible to ensure smooth integration during the design, development, test and safeguarding steps. This ensures compatibility of algorithm integration into AUTOSAR Adaptive ECUs.



 Sensor Data Record and Replay: To be able to test and debug sensor fusion algorithms offline it is necessary to replay sensor data recorded in real world scenarios. This enables sensor fusion designers to reproduce failures and determine faults.

7.1.2 Relation to other standards

The currently ongoing standardization of the international standard ISO 23150 "Road vehicles - Data communication between sensors and data fusion unit for automated driving functions - Logical interface" will be applicable to road vehicles with automated driving functions. It specifies the logical interface between smart in-vehicle sensors that sense the environment (e.g. camera, lidar, radar, ultrasonic, etc.) and the vehicle fusion unit. The interface is described in a modular, semantic representation allowing different types of sensor technologies and fusion concepts. The "Open Simulation Interface" (OSI) is a generic software interface for the environmental perception of automated driving functions in virtual scenarios (https://github.com/OpenSimulationInterface/opensimulation-interface). OSI ensures modularity, integrability and interchangeabil-These can be environment simulation modity of the individual components. els, sensor models, logical models for the detected environment or sensor fusion and models for automated driving functions. Additional informations can be found on https://opensimulationinterface.github.io/open-simulation-interface/.




Figure 7.2: Scope of Standardization

The Open Simulation Interface and the Autosar ADI will support the ISO 23150.



7.2 AD Sensor Service Design

7.2.1 ISO mapping to Sensor Services

7.2.1.1 Sensor Types

To comply with the ISO 23150, the specific service is defined with different sensor types. Currently, Camera, Lidar, Radar, and Ultrasonic sercives are supported in the specification. The new service will be introduced along with the evolution of [1].

[SWS_ADI_00001]{DRAFT} The Camera Sensor Data periodical Transmission [A Camera senor with Automated Driving interfaces shall provide the camera sensor data periodically to the Adaptive Applications | (RS ADI 00001)

[SWS_ADI_00002]{DRAFT} The Lidar Sensor Data periodical Transmission [A] Lidar sensor with Automated Driving interfaces shall provide the lidar sensor data periodically to the Adaptive Applications $[RS_ADI_00002]$

[SWS_ADI_00003]{DRAFT} The Radar Sensor Data periodical Transmission [A radar sensor with Automated Driving interfaces shall be able to provide the radar sensor data periodically to the Adaptive Applications | (RS_ADI_00003)

[SWS_ADI_00004]{DRAFT} The Ultrasonic Sensor Data periodical Transmission [A ultrasonic sensor with Automated Driving interfaces shall be able to provide the ultrasonic sensor data periodically to the Adaptive Applications | (RS_ADI_00004)

[SWS_ADI_00005]{DRAFT} Receving periodical sensor data [The Adaptive Applications as the sevice consumer shall process the sensor data according to the timestamp in the package, not the package arrival time. The most recent data is always the highest priority for processing.] (RS_ADI_00018)

7.2.1.2 Sensor Data level

In ISO 23150, there are three ISO logic interface levels to support different levels of fusion: object level, feature level and detection level:

- Object level interface: Potentially moving object interface, Road object interface and Static object interface;
- Feature level interface: Camera feature interface and USS feature interface;
- Detection level interface: Radar detection interface, Lidar detection interface, Camera detection interface and USS detection interface.

A sensor could provide several ISO logical interfaces, and shall provide at least one ISO interface either on object, feature, or detection level.

[SWS_ADI_00006]{DRAFT} Sensor specific services for different level ISO interfaces [To allow the flexibility of service providing by a sensor, each ISO interface shall



be mapped to a propriate ara::com means like events. The service interface shall support the defintions of ISO signals. The services for new types of sensors shall be added along with the evolution of [1]. The following AP services are defined in this specification:

- Camera, Lidar, Radar, Ultrasonic: Potentially moving object service, road object service, static object service
- Camera: Camera features service, camera detections service;
- Lidar: Lidar detections service;
- Radar: Radar detections service;
- Ultrasonic: Ultrasonic features service, Ultrasonic detection service.

|(RS_ADI_00012, RS_ADI_00013, RS_ADI_00014, RS_ADI_00019, RS_ADI_00005)

7.2.1.3 Supportive Sensor interfaces

In ISO, there are two supportive senor interfaces for the Adaptive Applications process the reliability of the used measurement method or data, which are also used to the implementation of safety concept. The two supportive sensor interfaces are sensor technology indepedent, i.e. common to camera, lidar, radar and ultrasonic sensor, but with sensor technology specific data.

[SWS_ADI_00007]{DRAFT} Sensor independent supportive services The supportive interfaces shall be mapped to two sensor indpendent AP services and support the definitions of ISO signals. The following services are defined in this specification:

- Sensor Performance service;
- Sensor Health information service.

(RS ADI 00012, RS ADI 00013, RS ADI 00014, RS ADI 00019)

7.2.2 Service Optional Elements

An individual Sensor Service design faces the challenge that each ISO interface contains a lot of optional elements. The optional elements are known and fixed at design time by service providers and service users. The present of optional elements shall not be changed during run time.

[SWS_ADI_00010]{DRAFT} **Capability Vector** [A service capability vector indicates which optional element is provided by the Service provider. The optional elements indicated by the capability vector shall be always sent during the runtime of the service. The service consumer should check the vector at the initialization time and subcribe the service if it includes all the optional elements that the consumer requires. The consumer



may ignore the optional elements, if these elements are not required. \((RS_ADI_00006, RS_ADI_00015, RS_ADI_00016, RS_ADI_00017) \)

[SWS_ADI_00011]{DRAFT} **Service Profiles** In different use cases, there are different requirements on the sensor data i.e.for different data Types, behavior, content, performance, resolution, etc. Different Service Profiles for a Sensor Type enables the flexibility of the corresponding sensor service for different use cases. In this release, only one profile is supported and more profiles should be considered in future releases. | (RS_ADI_00007)

[SWS_ADI_00012]{DRAFT} **Service Versioning** [Service Versioning covers different configurations, i.e. optionals, additional data representation, etc. The same services with different service versioning, but with the same profile, shall be backward compatible. | (RS ADI 00006, RS ADI 00015, RS ADI 00016, RS ADI 00017)



8 API specification

There are no APIs defined in this release.



9 Service Interfaces

9.1 Type definitions

This chapter lists all types provided by the ADI.

9.1.1 General Header Definition

This section lists all the data types used in the header of the service interfaces.

9.1.1.1 CapabilityVector

[SWS_ADI_00100]{DRAFT}

Name	CapabilityVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	bool
Derived from	-
Description	To identify presence of optional signal. The exact bit reference is denfined in the specification. For each service, there is exact one capability Vector table, which is deifined in chapter 10.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.2 InterfaceVersionId

[SWS_ADI_00101]{DRAFT}

Name	InterfaceVersionId	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	InterfaceVersionIdMajor uint8_t	
	InterfaceVersionIdMinor uint8_t	
	InterfaceVersionIdPatch uint8_t	
Derived from	-	
Description	Represents the version of the service.	



9.1.1.3 InterfaceCycleTimeVariation

[SWS_ADI_00102]{DRAFT}

Name	InterfaceCycleTimeVariation		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFERENCE		
Derived from	uint8_t		
Description	To indicate the cycle time variation. It represents a linear value between 0% and 100%.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.4 Interfaceld

[SWS_ADI_00103]{DRAFT}

Name	InterfaceId	
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFEREN	ICE
Derived from	uint8_t	
Description	Uniquely identify	the interface.
Range / Symbol	Limit	Description
kPotentialMovingObject	0x00	The Potential Moving Object interface.
kRoadObject	0x01	The Road Object interface.
kStaticObject	0x02	The Static Object interface.
kCameraFeature	0x03	The Camera Feature interface.
kUltrasonicFeature	0x04	The Ultrasonic Feature interface.
kRadarDetection	0x05	The Radar Detection interface.
kLidarDetection	0x06	The Lidar Detection interface.
kCameraDetection	0x07	The Camera Detection interface.
kUltrasonicDetection	0x08	The Ultrasonic Detection interface.
kSensorPerformance	0x09	The Sensor Performance interface.
kSensorHealthInformation	0x0A	The Sensor Health interface.
kUnknown	0x0B	The interface ID is unknown.



9.1.1.5 DataQualifier

[SWS_ADI_00104]{DRAFT}

Name	DataQualifier	DataQualifier	
Namespace	ara::adi::sensoritf	ara::adi::sensoritf	
Kind	TYPE_REFEREN	NCE	
Derived from	uint8_t		
Description	To identify the da	ta quality of the transmitted data.	
Range / Symbol	Limit	Description	
kNormal	0x00	Information can be used without restriction.	
kNotAvailable	0x01	Information from the senor is not available.	
kReduceInCoverage	0x02	Reported data are from the sensor in a restricted view.	
kReduceInPerformance	0x03	Reported data are from the sensor in a restricted performance.	
kReduceInViewAnd Performance	0x04	Reported data are from the sensor in a restricted view and performance.	
kTestMode	0x05	Reported data are from the sensor in a test mode.	
kInvalid	0x06	Mesaurement cycle was invalid and no valid objects will be reported.	
kUnknown	0x07	Data quality is unknown.	

\[(RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014) \]

9.1.1.6 RecognizedStatus

[SWS_ADI_00105]{DRAFT}

Name	RecognizedStatus			
Namespace	ara::adi::sensoritf			
Kind	TYPE_REFEREN	CE		
Derived from	uint8_t	uint8_t		
Description	To indicate the red	To indicate the recognition process status of the sensor due to resource limitations.		
Range / Symbol	Limit	Description		
kNormal	0x00	The performance of the sensor is enough to process all recognized entities. If additional entities would have been in the environment the sensor would have processed additional entities.		
kPreLimits	0x01	The performance of the sensor is close to the limits to process all recognized entities.		
kLimited	0x02	The performance of the sensor is not enough to process all recognized entities.		
kUnknown	0x03	The performance status of the sensor is unknown.		



9.1.1.7 TrackingMotionModel

[SWS_ADI_00106]{DRAFT}

Name	TrackingMotionM	TrackingMotionModel		
Namespace	ara::adi::sensoritt	f		
Kind	TYPE_REFEREN	TYPE_REFERENCE		
Derived from	uint8_t	uint8_t		
Description	The motion mode	The motion model for tracking moving objects.		
Range / Symbol	Limit	Limit Description		
kConstantVelocity	0x00	Motion model uses constant velocity.		
kConstantAcceleration	0x01	Motion model uses constant acceleration.		
kConstantTurnRate	0x02	Motion model uses constant turn rate.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.8 MotionType

[SWS_ADI_00107]{DRAFT}

Name	MotionType			
Namespace	ara::adi::sensoritf			
Kind	TYPE_REFEREN	TYPE_REFERENCE		
Derived from	uint8_t	uint8_t		
Description	To identify the applied motion type in the message, i.e. absolute or relative motion values.			
Range / Symbol	Limit	Description		
kRelativeValues	0x00	Relative motion values are used.		
kAbsoluteValues	0x01	Absolute motion values are used.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.9 ColourModelType

[SWS_ADI_00108]{DRAFT}

Name	ColourModelType			
Namespace	ara::adi::sensoritf	ara::adi::sensoritf		
Kind	TYPE_REFERENCE			
Derived from	uint8_t			
Description	To identify the applied colour model in the service.			
Range / Symbol	Limit	Description		
kGrey	0x00	Grey scale - 1 colour value is used for grey value.		





kRGB	0x01	Red, green, blue - 3 colour values are used for the values for red, green, blue.
kHSV	0x02	Hue, saturation, value - 3 colour values are used for the values for hue, saturation, value.
kLUV	0x03	Luminance and colour coordinates U, V - 3 colour values are used for the values for hue, saturation, value.
kColourList	0x04	Each value reference a pre-defined colour - 1 colour value.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.10 RadialVelocityAmbiguityDomain

[SWS_ADI_00109]{DRAFT}

Name	RadialVelocityAmbiguityDomain	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	Begin float	
	End float	
Derived from	-	
Description	The Doppler ambiguity caused by under sampling. m/s	

|(RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.11 RangeAmbiguityDomain

[SWS_ADI_00110]{DRAFT}

Name	RangeAmbiguityDomain	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	Begin float	
	End float	
Derived from	-	
Description	The range of the ambiguity domain. m	

\((RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)\)



9.1.1.12 AngleAzimuthAmbiguityDomain

[SWS_ADI_00111]{DRAFT}

Name	AngleAzimuthAmbiguityDomain
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Begin float
	End float
Derived from	-
Description	The azimuth angle of the ambiguity domain is defined by {begin} and {end}. The unit is {rad,rad}

](RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.13 AngleElevationAmbiguityDomain

[SWS_ADI_00112]{DRAFT}

Name	AngleElevationAmbiguityDomain
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Begin float
	End float
Derived from	-
Description	The elevation angle of the ambiguity domain is defined by {begin} and {end}. The unit is {rad,rad}.

(RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.14 InterfaceApplicability

[SWS_ADI_00113]{DRAFT}

Name	InterfaceApplicab	ility
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFEREN	ICE
Derived from	uint8_t	
Description	To identify the related interface of the service.	
Range / Symbol	Limit	Description
kObjectLevelInterfaces	0x00	Object level interfaces.
kFeatureLevelInterface	0x01	Feature level interface.
kDetectionLevelInterface	0x02	Detection level interface.
kFLlandDLl	0x03	Feature level and detection level interfaces.
kPMOI	0x04	Potential Moving Objects Interface.
kRDOI	0x05	Road Objects Interface.





kSOI	0x06	Static Objects Interface.
kAll	0x07	All interfaces.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.15 VehicleCoordinateSystemType

[SWS_ADI_00114]{DRAFT}

Name	VehicleCoordinate	eSystemType
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFEREN	ICE
Derived from	uint8_t	
Description	Defines the reference vehicle coordinate system for the interfaces of the sensor.	
Range / Symbol	Limit	Description
kRearAxle	0x00	Use vehicle rear axle coordinate system.
kRoadLevel	0x01	Use vehicle road level coordinate system.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.16 Point3D

[SWS ADI 00115]{DRAFT}

Name	Point3D
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	X float
	y float
	z float (optional)
Derived from	
Description	Represents a 3 dimension vector, the unit will be vary according to the refering data type.



9.1.1.17 Point3DError

[SWS_ADI_00116]{DRAFT}

Name	Point3DError
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	xError float
	yError float
	zError float (optional)
Derived from	-
Description	Represents Error value in 3 dimension vector, the unit will be vary according to the refering data type.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.18 Orientation3D

[SWS_ADI_00117]{DRAFT}

Name	Orientation3D
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Yaw float
	Pitch float
	Roll float
Derived from	-
Description	Represents a 3 dimension vector {yaw, pitch,roll}, the unit will be vary according to the refering data type.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.19 Orientation3DError

[SWS_ADI_00118]{DRAFT}

Name	Orientation3DError
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	YawError float
	PitchError float
	RollError float
Derived from	-
Description	Represents Error value in 3 dimension vector {yaw, pitch, roll}, the unit will be vary according to the refering data type.



\[(RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014) \]

9.1.1.20 Point3DErrorVector

[SWS_ADI_00129]{DRAFT}

Name	Point3DErrorVector
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	xxError float (optional)
	xyError float (optional)
	xzError float (optional)
	yxError float (optional)
	yyError float (optional)
	yzError float (optional)
	zxError float (optional)
	zyError float (optional)
	zzError float (optional)
Derived from	-
Description	Represents the Error value in 3 dimension vector, the unit will be vary according to the refering data type.

\[(RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014) \]

9.1.1.21 Orientation3DErrorVector

[SWS_ADI_00130]{DRAFT}

Name	Orientation3DErrorVector
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	yawyawError float (optional)
	yawpitchError float (optional)
	yawrollError float (optional)
	pitchyawError float (optional)
	pitchpitchError float (optional)
	pitchrollError float (optional)
	rollyawError float (optional)
	rollpitchError float (optional)
	rollrollError float (optional)
Derived from	-
Description	Represents the Error value in 3 dimension vector {yaw, pitch, roll}, the unit will be vary according to the referring data type.



](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.22 VanishingPoint

[SWS ADI 00119]{DRAFT}

Name	VanishingPoint
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Azimuth float
	Elevation float
Derived from	-
Description	A set of lines in the image plane that corresponds to a set of parallel surface lines in the 3D world space converges to a common point in the image space known as the Vanishing point {azimuth, elevation}. The unit is {rad,rad}.

(RS ADI 00001, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.1.23 VanishingPointError

[SWS_ADI_00120]{DRAFT}

Name	VanishingPointError			
Namespace	ara::adi::sensoritf			
Kind	STRUCTURE			
Subelements	Azimuth float			
	Elevation float			
Derived from	-			
Description	Uncertainty of the Vanishing point {azimuth, elevation}, using Error value. The unit is {rad,rad}.			

\((RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)\)

9.1.1.24 InformationSensorPose

[SWS ADI 00121]{DRAFT}

Name	InformationSensorPose		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		





Subelements	SensorOriginPoint Point3D	
	SensorOriginPointError Point3DError (optional)	
	SensorOriginPointErrorVector Point3DErrorVector (optional)	
	SensorOrientation Orientation3D	
	SensorOrientationError Orientation3DError (optional)	
	SensorOrientationErrorVector Orientation3DErrorVector (optional)	
Derived from	-	
Description	Represents the Sensor Pos info.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.25 InformationSensorSurrounding

[SWS_ADI_00122]{DRAFT}

Name	InformationSensorSurrounding		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	VanishingPoint VanishingPoint		
	VanishingPointError (optional)		
Derived from	-		
Description	Represents the vanishing point info.		

(RS ADI 00001, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.1.26 InterfaceHeader

[SWS ADI 00123]{DRAFT}

Name	InterfaceHeader			
Namespace	ara::adi::sensoritf			
Kind	STRUCTURE			
Subelements	InformationInterface InformationInterface			
	VehicleCoordinateSystem VehicleCoordinateSystemType (optional)			
	SensorPose InformationSensorPose (optional)			
	SensorCalibration Calibration (optional)			
	SensorClusterInformation SensorCluster (optional)			
	InterfaceExtension InformationInterfaceExtension (optional)			
	SensorSurrounding InformationSensorSurrounding (optional)			
Derived from	-			
Description	Represents the header of each message.			



9.1.1.27 Sensorld

[SWS_ADI_00124]{DRAFT}

Name	SensorID	
Namespace	ara::adi::sensoritf	
Kind	YPE_REFERENCE	
Derived from	uint8_t	
Description	To represent the sensor logical identity.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.28 SensorIdList

[SWS_ADI_00125]{DRAFT}

Name	SensorldList			
Namespace	ara::adi::sensoritf			
Kind	ECTOR			
Subelements	SensorID			
Derived from	-			
Description	Represents a list of Sensor ID.			

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.29 InformationInterface

[SWS ADI 00126]{DRAFT}

Name	InformationInterface		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	VersionId InterfaceVersionId		
	NumberOfValidServingSensors uint8_t		
	ValidServingSensors SensorIdList		
	InterfaceID InterfaceId (optional)		
	TimeStamp uint64_t		
	CycleCounter uint8_t (optional)		
	InterfaceCycleTime uint32_t (optional)		
	InterfaceCycleTimeVariation InterfaceCycleTimeVariation (optional)		
	DataQualifier DataQualifier		
Derived from	-		
Description	Represents the basic info of the sensor service.		



](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.30 InformationInterfaceExtension

[SWS ADI 00127]{DRAFT}

Name	InformationInterfaceExtension		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	TrackingMotionModel TrackingMotionModel (optional)		
	MotionType MotionType		
	ColourModelType ColourModelType (optional)		
	InformationAmbiguityDomain InformationAmbiguityDomain (optional)		
	InterfaceApplicability InterfaceApplicability (optional)		
Derived from	-		
Description	Represents the additional info of the sensor service.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.31 ProbabilityPercentage

[SWS ADI 00128]{DRAFT}

Name	ProbabilityPercentage		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFERENCE		
Derived from	float		
Description	Represet probability in percentage.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.32 SensorCalibratableComponent

[SWS ADI 00539]{DRAFT}

Name	SensorCalibratableComponent	
Namespace	ara::adi::sensoritf	
Kind	/PE_REFERENCE	
Derived from	uint8_t	
Description	Enumeration for the sensor component which may be calibrated.	





Range / Symbol	Limit	Description
kIntrinsic	0x00	Calibration status for the intrinsic parameters of the sensor.
kExtrinsic	0x01	Calibration status for the extrinsic parameters of the sensor.
kOnline	0x02	Calibration status for the online parameters of the sensor.
kUnknown	0x03	The sensor calibratable component is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.33 SensorCalibrationStatus

[SWS_ADI_00540]{DRAFT}

Name	SensorCalibration	nStatus
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFEREN	ICE
Derived from	uint8_t	
Description	Enumeration for t	he current calibration status of the Sensor calibratable component.
Range / Symbol	Limit	Description
kCalibrated	0x00	Sensor calibration was successful and within nominal tolerance range.
kNotCalibrated	0x01	Calibration not done or calibration failed.
kDegraded	0x02	Sensor calibrated, however performance degraded due to limited correction accuracy.
kInitialCalibrationNotPerformed	0x03	Sensor initial calibration not performed yet.
kInitialCalibrationFailed	0x04	Sensor initial calibration process failed.
kRecalibrationNeededIntrinsic	0x05	Recalibration of sensor's intrinsic parameters required.
kRecalibrationNeededExtrinsic	0x06	Recalibration of sensor's extrinsic parameters required.
kRecalibrationNeededFull	0x07	Recalibration of the complete sensor's parameters required.
kUnknown	0x08	The sensor Calibration status is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.34 CaliComponentInfo

[SWS_ADI_00544]{DRAFT}

Name	CaliComponentInfo	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	CaliComponent SensorCalibratableComponent	
	CaliStatus SensorCalibrationStatus	
	CaliProcessStatus CalibrationProcessState (optional)	





Derived from	-
Description	Represents the calibration component information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.35 CaliComponentInfoVector

[SWS ADI 00545]{DRAFT}

Name	CaliComponentInfoVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	CaliComponentInfo
Derived from	-
Description	Represents a list of calibration component information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.36 Calibration

[SWS ADI 00546]{DRAFT}

Name	Calibration
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NoValidSensorCalibratableComponents uint8_t
	ValidSensorCalibratableComponents CaliComponentInfoVector
	SensorOriginPointCorrection Point3D (optional)
	SensorOriginPointCorrectionError Point3DError (optional)
	SensorOriginTranslationCorrectionLimitRange SensorOriginTranslationCorrectionLimit (optional)
	CoorectionPosLimitMax Point3D (optional)
	SensorOrientationCorrection Orientation3D (optional)
	SensorOrientationCorrectionError Orientation3DError (optional)
	SensorPoseAngleCorrectionLimitRange SensorPoseAngleCorrectionLimit (optional)
Derived from	
Description	Represents the sensor calibration related information.



9.1.1.37 CalibrationProcessState

[SWS_ADI_00548]{DRAFT}

Name	CalibrationProces	ssState
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFEREN	ICE
Derived from	uint8_t	
Description	Provides an enumeration for the current state of the Sensor calibration component.	
Range / Symbol	Limit	Description
kInitialCalibrationPerformed	0x00	The sensor initial calibration has been performed.
kInitialCalibrationNotPerformed	0x01	The sensor initial calibration has not been performed yet.
kInitialCalibrationFailed	0x02	The sensor initial calibration process failed.
kRecalibrationNeededIntrinsic	0x03	The recalibration of sensor's intrinsic parameters is required.
kRecalibrationNeededExtrinsic	0x04	The recalibration of sensor's extrinsic parameters is required.
kRecalibrationNeededFull	0x05	The recalibration of the complete sensor's parameters is required.
kUnknown	0x06	The sensor Calibration Process State is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.38 SensorOriginTranslationCorrectionLimit

[SWS_ADI_00549]{DRAFT}

Name	SensorOriginTranslationCorrectionLimit
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	xbegin float
	xend float
	ybegin float
	yend float
	zbegin float (optional)
	zend float (optional)
Derived from	-
Description	Provides the limits of independent position corrections. Begin (minimum) and end (maximum) positions could be defined for each axis {x, y, z} separately.(m, m, m, m, m, m)



9.1.1.39 SensorPoseAngleCorrectionLimit

[SWS_ADI_00550]{DRAFT}

Name	SensorPoseAngleCorrectionLimit
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Yawbegin float
	Yawend float
	Pitchbegin float
	Pitchend float
	Rollbegin float
	Rollend float
Derived from	-
Description	Provides the limits of independent angle corrections. Begin (minimum) and end (maximum) angles could be defined for each angle {yaw, pitch, roll} separately.(rad, rad, rad, rad, rad, rad, rad)

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.40 SensorCluster

[SWS_ADI_00551]{DRAFT}

Name	SensorCluster
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidSensors uint8_t
	SensorIDReferenceList SensorIdList
Derived from	-
Description	Group of sensors of the same technology serving a common logical interface.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.41 Point2D

[SWS_ADI_00604]{DRAFT}

Name	Point2D
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	X float
	y float





Derived from	-
Description	Position with respect to the vehicle origin.

(RS ADI 00004, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.1.42 Point2DError

[SWS ADI 00605]{DRAFT}

Name	Point2DError
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	X float
	y float
Derived from	-
Description	Error values for feature's 2D position {x, y}.

(RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.1.43 InformationAmbiguityDomain

[SWS_ADI_00713]{DRAFT}

Name	InformationAmbiguityDomain		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	VelocityAmbiguity RadialVelocityAmbiguityDomain (optional)		
	RangeAmbiguity RangeAmbiguityDomain (optional)		
	AzimuthAmbiguity AngleAzimuthAmbiguityDomain (optional)		
	ElevationAmbiguity AngleElevationAmbiguityDomain (optional)		
Derived from	-		
Description	Radar Sensor Ambiguity Domain informaiton if the sensor has related capability.		

(RS ADI 00003, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.2 Potentially Moving Objects Interface Definition

This section lists all the data types used in Potentially moving object interface.



9.1.2.1 MeasurementStatus

[SWS_ADI_00200]{DRAFT}

Name	MeasurementSta	MeasurementStatus		
Namespace	ara::adi::sensorit			
Kind	TYPE_REFEREN	NCE		
Derived from	uint8_t			
Description	Represent the me	Represent the measurement Status.		
Range / Symbol	Limit	Description		
kMeasured	0x00	The tracked object is measured.		
kNew	0x01	The tracked object is new.		
kPredicted	0x02	The result is by predicted.		
kPartiallyMeasured	0x03	The tracked object is partically measured.		
kInvalid	0x04	The measurement result is invalid.		
kPredictedOccluded	0x05	Tracked object is temporarily occluded by another entity.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.2 ReferencePoint

[SWS_ADI_00201]{DRAFT}

Name	ReferencePoi	ReferencePoint	
Namespace	ara::adi::sens	ara::adi::sensoritf	
Kind	TYPE_REFER	RENCE	
Derived from	uint8_t		
Description	Represent out	ter edges of the recognized object's bounding box.	
Range / Symbol	Limit	Description	
kFrontLeftTop	0x00	Front Left Top.	
kFrontMidwidthTop	0x01	Front Midwidth Top.	
kFrontRightTop	0x02	Front Right Top.	
kMidsideLeftTop	0x03	Midside Left Top.	
kMidsideMidwidthTop	0x04	Midside Midwidth Top.	
kMidside Right Top.	0x05	Midside Right Top.	
kRearLeftTop	0x06	Rear Left Top.	
kRearMidwidthTop	0x07	Rear Midwidth Top.	
kRearRightTop	0x08	Rear Right Top.	
kFrontLeftMidheight	0x09	Front Left Midheight.	
kFrontMidwidthMidheight	0x0A	Front Midwidth Midheight.	
kFrontRightMidheight	0x0B	Front Right Midheight.	
kMidsideLeftMidheight	0x0C	Midside Left Midheight.	
kMidsideMidwidthMidheight	0x0D	Midside Midwidth Midheight.	
kMidsideRightMidheight	0x0E	Midside Right Midheight.	
kRearLeftMidheight	0x0F	Rear Left Midheight.	





kRearMidwidthMidheight	0x10	Rear Midwidth Midheight.
kRearRightMidheight	0x11	Rear Right Midheight.
kFrontLeftBottom	0x12	Front Left Bottom.
kFrontMidwidthBottom	0x13	Front Midwidth Bottom.
kFrontRightBottom	0x14	Front Right Bottom.
kMidsideLeftBottom	0x15	Midside Left Bottom.
kMidsideMidwidthBottom	0x16	Midside Midwidth Bottom.
kMidsideRightBottom	0x17	Midside Right Bottom.
kRearLeftBottom	0x18	Rear Left Bottom.
kRearMidwidthBottom	0x19	Rear Midwidth Bottom.
kRearRightBottom	0x1A	Rear Right Bottom.
kUnknown	0x1B	Unkonwn.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.3 MovementStatus

[SWS_ADI_00202]{DRAFT}

Name	MovementSt	MovementStatus		
Namespace	ara::adi::sens	soritf		
Kind	TYPE_REFE	RENCE		
Derived from	uint8_t			
Description	Represent th	Represent the relevance to ego vehicle road level.		
Range / Symbol	Limit	Description		
kUnknow	0x00	The status is unknow.		
kStoppedMoving	0x01	The object stopped moving.		
kStationary	0x02	The object is stationary.		
kMoving	0x03	The object is moving.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.4 RoadLevel

[SWS_ADI_00203]{DRAFT}

Name	RoadLevel		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFERENCE		
Derived from	uint8_t		
Description	Represent the relevance to ego vehicle road level.		
Range / Symbol	Limit	Description	





kUnknown	0x00	The road level is unknown.
kEgoRoadLevel	0x01	The object is on the same road level of the ego vehicle.
kRoadLevelAbove	0x02	The object is above the road level of the ego vehicle .
kRoadLevelBelow	0x03	The object is below the road level of the ego vehicle .

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.5 DimensionBox

[SWS_ADI_00204]{DRAFT}

Name	DimensionBox
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Length float
	Width float
	Height float (optional)
Derived from	•
Description	Represents the dimension of the bounding box. The unit is {m,m,m}.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.6 DimensionBoxError

[SWS ADI 00205]{DRAFT}

Name	DimensionBoxError
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Length float
	Width float
	Height float (optional)
Derived from	-
Description	Represents the Error value of the bounding box, the unit is {m,m,m}.



9.1.2.7 IncludedGeometricStructures

[SWS_ADI_00206]{DRAFT}

Name	IncludedGeometricStructures			
Namespace	ara::adi::sensoritf			
Kind	TYPE_REFEREN	TYPE_REFERENCE		
Derived from	uint8_t			
Description	Represent the geometrical structures that are taken into account in the bounding boxes.			
Range / Symbol	Limit Description			
kWithoutMirrors	0x00	Geometrical structures don't include the mirrors.		
kWithMirrors	0x01	Geometrical structures include the Mirrors.		
kUnknow	0x02	Geometrical structures including the mirrors or not is unknown.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.8 PotentiallyMovingObjectClassificationType

[SWS_ADI_00207]{DRAFT}

Name	PotentiallyMovingObjectClassificationType		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFEREN	NCE	
Derived from	uint8_t		
Description	Represents the p	otentially moving object classification probability type.	
Range / Symbol	Limit	Description	
kCar	0x00	Probability type car.	
kHeavyTruck	0x01	Probability type heavy truck.	
kVan	0x02	Probability type van.	
kBus	0x03	Probability type bus.	
kTrailer	0x04	Probability type trailer.	
kSemitrailer	0x05	Probability type semitrailer.	
kTram	0x06	Probability type tram.	
kTrain	0x07	Probability type train.	
kOtherVehicle	0x08	Probability type unidentified vehicle.	
kMotorbike	0x09	Probability type motorbike.	
kAnimal	0x0A	Probability type animal.	
kBicycle	0x0B	Probability type bicycle.	
kTricycle	0x0C	Probability type tricycle.	
kPedestrian	0x0D	Probability type pedestrian.	
kWheelchair	0x0E	Probability type wheelchair.	
kUnknown	0x0F	Probability type unknown.	



9.1.2.9 LightStatus

[SWS_ADI_00208]{DRAFT}

Name	LightStatus			
Namespace	ara::adi::sensoritf			
Kind	TYPE_REFEREN	ICE		
Derived from	uint8_t	uint8_t		
Description	Represents the status of an object's light.			
Range / Symbol	Limit	Description		
kOff	0x00	Light status is off.		
kOn	0x01	Light status is on.		
kFlash	0x02	Light status is cyclic flashing.		
kBrake	0x03	Light status indicates braking.		
kWarning	0x04	Light status indicates warning.		
kOther	0x06	Light status could not be determined.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.10 **LightType**

[SWS_ADI_00209]{DRAFT}

Name	LightType		
Namespace	ara::adi::sen	ara::adi::sensoritf	
Kind	TYPE_REFE	RENCE	
Derived from	uint8_t	uint8_t	
Description	Represents t	Represents the light classification.	
Range / Symbol	Limit	Description	
kLeftFlashLight	0x00	Vehicle's left flash light.	
kRightFlashLight	0x01	Probability type heavy truck.	
kHazardFlashLight	0x02	Vehicle's hazard flash light.	
kLeftBrakeLight	0x03	Vehicle's left break light.	
kRightBrakeLight	0x04	Vehicle's right break light.	
kCentreBrakeLight	0x05	Vehicle's centre break light.	
kLeftOtherLight	0x06	Vehicle's left light (no flash or break light).	
kRightOtherLight	0x07	Vehicle's right light (no flash or break light).	
kCentreOtherLight	0x08	Vehicle's light not on the left or right site (no flash or break light).	
kUnknown	0x09	Light type unknown.	



9.1.2.11 PersonPoseType

[SWS_ADI_00210]{DRAFT}

Name	PersonPose	Туре	
Namespace	ara::adi::sen	ara::adi::sensoritf	
Kind	TYPE_REFE	TYPE_REFERENCE	
Derived from	uint8_t	uint8_t	
Description	Represents t	the person pose possibility type.	
Range / Symbol	Limit	Description	
kHead	0x00	The person head pose.	
kUpperBody	0x01	The person upper body pose.	
kLeftHand	0x02	Described angles are measured between the normal to the hand palm relative to the ego-vehicle axis system.	
kRightHand	0x03	Described angles are measured between the normal to the hand palm relative to the ego-vehicle axis system.	
kLeftLowerArm	0x04	Described angles are measured between long axis of the left lower arm relative to the ego-vehicle axis system.	
kRightLowerArm	0x05	Described angles are measured between long axis of the right lower arm relative to the ego-vehicle axis system.	
kRightUpperLeg	0x06	Described angles are measured between long axis of the right upper leg relative to the ego-vehicle axis system.	
kLeftLowerLeg	0x07	Described angles are measured between long axis of the left lower leg relative to the ego-vehicle axis system.	
kRightLowerLeg	0x08	Described angles are measured between long axis of the right lower leg relative to the ego-vehicle axis system.	
kLeftLowerLeg	0x09	Described angles are measured between long axis of the left lower leg relative to the ego-vehicle axis system.	
kLeftFoot	0x0A	Described angles are measured between long axis of the left foot relative to the ego-vehicle axis system.	
kRightFoot	0x0B	Described angles are measured between long axis of the right foot relative to the ego-vehicle axis system.	
kUnknown	0x0C	The person pose is unknown.	

\[(RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014) \]

9.1.2.12 ObjectLaneAssociation

[SWS_ADI_00211]{DRAFT}

Name	ObjectLaneAssoc	iation
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFERENCE	
Derived from	uint8_t	
Description	Represents an association of the object to neighbouring lanes	
Range / Symbol	Limit	Description
kEgoLine	0x00	Object is in ego lane.





kLeftNeighbouringLane	0x01	Object is in left neighbouring lane.
kRightNeighbouringLane	0x02	Object is in right neighbouring lane.
kEgoRightLane	0x03	Object is located between ego and right neighbouring lane.
kEgoLeftLane	0x04	Object is located between ego and left neighbouring lane.
kUnknown	0x05	Object's lane association is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.13 AngleBetweenObjectEdgeAndLaneRightEdgeLeftLane

[SWS ADI 00212]{DRAFT}

Name	AngleBetweenObjectEdgeAndLaneRightEdgeLeftLane
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	LeftEdgeRightLane float
	RightEdgeLeftLane float
Derived from	-
Description	Represents the Angles to object edge to lane. The unit is {rad,rad}.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.14 AngleBetweenObjectEdgeAndLaneRightEdgeLeftLaneError

[SWS_ADI_00213]{DRAFT}

Name	AngleBetweenObjectEdgeAndLaneRightEdgeLeftLaneError	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	LeftEdgeRightLane float	
	RightEdgeLeftLane float	
Derived from	-	
Description	Represents the Error value of the angles to object edge to lane. The unit is {rad,rad}.	



9.1.2.15 PercentageSideLane

[SWS_ADI_00214]{DRAFT}

Name	PercentageSideLane
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Left uint16_t
	Right uint16_t
Derived from	-
Description	Represents the percentage value of the object width in the corresponding {left, right} lane.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.16 PotentiallyMovingObjectsDynamics

[SWS_ADI_00215]{DRAFT}

Name	PotentiallyMovingObjectsDynamics	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	VelocityObjectLevel Point3D	
	VelocityObjectLevelError Point3DError (optional)	
	Acceleration Point3D (optional)	
	AccelerationError Point3DError (optional)	
	InstantaneousCentreOfRotation Point 2D (optional)	
	InstantaneousCentreOfRotationError Point2DError (optional)	
	RotationRateAtInstantaneousCentreOfRotationYaw float (optional)	
	RotationRateAtInstantaneousCentreOfRotationYawError float (optional)	
	MovementStatus MovementStatus (optional)	
Derived from	-	
Description	Represents the dynamics of the possible moving objects.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.17 ObjectStatus

[SWS_ADI_00216]{DRAFT}

Name	ObjectStatus
Namespace	ara::adi::sensoritf
Kind	STRUCTURE





Subelements	ExistenceProbabilityObjectLevel ProbabilityPercentage
	ObjectId uint16_t
	GroupingObjectID uint8_t (optional)
	Age uint64_t
	NumberOfValidObservationsObjectLevel uint32_t (optional)
	ValidObservations ValidObservationVector (optional)
	TrackQuality uint16_t (optional)
	MeasurementStatusObjectLevel MeasurementStatus
Derived from	-
Description	Represents the dynamics of the objects.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.18 PotentiallyMovingObjectsBoundingBox

[SWS_ADI_00217]{DRAFT}

Name	PotentiallyMovingObjectsBoundingBox
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	BoundingBoxExtent DimensionBox
	BoundingBoxExtentError DimensionBoxError (optional)
	BoundingBoxGroundClearance float (optional)
	IncludedGeometricStructures IncludedGeometricStructures (optional)
Derived from	-
Description	Represents the bounding box information of the possible moving objects.

(RS ADI 00001, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.2.19 PotentiallyMovingObjectsInformation

[SWS_ADI_00218]{DRAFT}

Name	PotentiallyMovingObjectsInformation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidPotentiallyMovingObjectClassifications uint8_t
	PotentiallyMovingObjectClassifications ValidPotentiallyMovingObjectClassificationVector
Derived from	-
Description	Represents the certainty information regarding possible moving object types list.



9.1.2.20 ValidPotentiallyMovingObjectClassification

[SWS_ADI_00219]{DRAFT}

Name	ValidPotentiallyMovingObjectClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	PotentiallyMovingObjectClassificationType PotentiallyMovingObjectClassificationType
	PotentiallyMovingObjectClassificationTypeConfidence float
Derived from	-
Description	Represents the certainty information regarding a possible moving object type.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.21 ValidPotentiallyMovingObjectClassificationVector

[SWS_ADI_00220]{DRAFT}

Name	ValidPotentiallyMovingObjectClassificationVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ValidPotentiallyMovingObjectClassification
Derived from	-
Description	Represents a list of PMOCertainty.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.22 PotentiallyMovingObjectsLight

[SWS_ADI_00221]{DRAFT}

Name	PotentiallyMovingObjectsLight
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	PMOLightType LightType
	PMOLightStatus LightStatus
Derived from	-
Description	Represents the light information including light type and light status.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.2.23 PotentiallyMovingObjectsLightVector

[SWS_ADI_00222]{DRAFT} [

Name	PotentiallyMovingObjectsLightVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	PotentiallyMovingObjectsLight
Derived from	-
Description	Represents a list of light.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.24 PotentiallyMovingObjectsLights

[SWS_ADI_00223]{DRAFT}

Name	PotentiallyMovingObjectsLights
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidLights uint8_t
	$\textbf{PotentiallyMovingObjectsLightList} \ \texttt{PotentiallyMovingObjectsLightVector}$
Derived from	-
Description	Represents the lights information of the tracked object.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.25 ValidPersonPose

[SWS_ADI_00224]{DRAFT}

Name	ValidPersonPose
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	PoseType PersonPoseType
	PersonPoseInfo Orientation3D
	PersonPoseError Orientation3DError (optional)
Derived from	-
Description	Represents the Pose information including pose type and pose status.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.2.26 PersonPoseVector

[SWS_ADI_00225]{DRAFT}

Name	PersonPoseVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ValidPersonPose
Derived from	-
Description	Represents a list of Pose.

(RS ADI 00001, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.2.27 PotentiallyMovingObjectsPerson

[SWS_ADI_00226]{DRAFT}

Name	PotentiallyMovingObjectsPerson
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidPersonSPoses uint8_t
	PersonPoselist PersonPoseVector
Derived from	-
Description	Represents the poses information of the tracked person.

(RS ADI 00001, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.2.28 PotentiallyMovingObjectsLaneRelatedInformation

[SWS_ADI_00227]{DRAFT}

Name	PotentiallyMovingObjectsLaneRelatedInformation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	LaneAssociation ObjectLaneAssociation
	AngleBetweenObjectEdgeAndLane AngleBetweenObjectEdgeAndLaneRightEdgeLeftLane (optional)
	AngleBetweenObjectEdgeAndLaneError AngleBetweenObjectEdgeAndLaneRightEdgeLeftLaneError (optional)
	PercentageSideLane PercentageSideLane (optional)
Derived from	-
Description	Represents the lane related information.



9.1.2.29 PotentiallyMovingObjectsMotionRelatedInformation

[SWS_ADI_00228]{DRAFT}

Name	PotentiallyMovingObjectsMotionRelatedInformation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	AngularPositionAzimuth float
	AngularVelocityAzimuth float
Derived from	-
Description	Represents the motion related information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.30 ValidPotentiallyMovingObject

[SWS_ADI_00229]{DRAFT}

Name	ValidPotentiallyMovingObject
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	PotentiallyMovingObjectsStatus ObjectStatus
	PotentiallyMovingObjectsInformation PotentiallyMovingObjectsInformation
	PotentiallyMovingObjectsPosition PotentiallyMovingObjectsPosition
	PotentiallyMovingObjectsBoundingBox PotentiallyMovingObjectsBoundingBox (optional)
	PotentiallyMovingObjectsDynamics PotentiallyMovingObjectsDynamics
	PotentiallyMovingObjectsLights PotentiallyMovingObjectsLights (optional)
	PotentiallyMovingObjectsPerson PotentiallyMovingObjectsPerson (optional)
	PotentiallyMovingObjectsLaneRelatedInformation PotentiallyMovingObjectsLaneRelatedInformation (optional)
	PotentiallyMovingObjectsMotionInformation PotentiallyMovingObjectsMotionRelatedInformation (optional)
	CameraSensorSpecific PotentiallyMovingObjectsCameraSensorTechnologySpecific (optional)
	RadarSensorSpecific PotentiallyMovingObjectsRadarSensorTechnologySpecific (optional)
	LidarSensorSpecific PotentiallyMovingObjectsLidarSensorTechnologySpecific (optional)
Derived from	-
Description	Represents the possible moving objects tracked by a camera, radar, lidar or Ultrasonic.



9.1.2.31 ValidPotentiallyMovingObjectVector

[SWS_ADI_00230]{DRAFT}

Name	ValidPotentiallyMovingObjectVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ValidPotentiallyMovingObject
Derived from	-
Description	Represents a list of PMO.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.32 PotentiallyMovingObjects

[SWS_ADI_00231]{DRAFT}

Name	PotentiallyMovingObjects
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	RecognisedPotentiallyMovingObjectsCapability uint16_t (optional)
	RecognisedPotentiallyMovingObjectsStatus RecognizedStatus (optional)
	NumberOfValidPotentiallyMovingObjects uint16_t
	ValidPotentiallyMovingObjects ValidPotentiallyMovingObjectVector
Derived from	-
Description	Represents the possible moving object informaiton provided by a camera, lidar, radar or Ultrasonic sensor.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.33 ValidObservation

[SWS_ADI_00232]{DRAFT} [

Name	ValidObservation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	TimeStampReferenceObjectLevel uint 64_t
	ObservationStatusObjectLevel ObservationStatus
Derived from	-
Description	Represents the Observation status.



9.1.2.34 ValidObservationVector

[SWS_ADI_00233]{DRAFT}

Name	ValidObservationVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ValidObservation
Derived from	-
Description	Represents a list of Observation status

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.35 ObservationStatus

[SWS ADI 00234]{DRAFT}

Name	Observations	Status
Namespace	ara::adi::sen	soritf
Kind	TYPE_REFE	ERENCE
Derived from	uint8_t	
Description	Represent th	ne observation status of the object, which was recognized in a previous cycle.
Range / Symbol	Limit	Description
kObservationTrue	0x00	The object was observed in the current cycle.
kObservationFalse	0x01	The object was not observed in the current cycle. It may be predicted in the cycle.
kUnknown	0x02	The status is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.36 PotentiallyMovingObjectsPosition

[SWS ADI 00235]{DRAFT}

Name	PotentiallyMovingObjectsPosition	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	





Subelements	PositionObjectLevel Point3D
	PositionObjectLevelError Point3DError
	Orientation Orientation3D (optional)
	OrientationError Orientation3DError (optional)
	ReferencePoint ReferencePoint (optional)
	RoadLevel RoadLevel (optional)
Derived from	-
Description	Represents the position information fo a potentially moving object.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.37 PotentiallyMovingObjectsCameraSensorTechnologySpecific

[SWS_ADI_00236]{DRAFT}

Name	PotentiallyMovingObjectsCameraSensorTechnologySpecific
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	ScaleChangeObjectLevel float (optional)
Derived from	-
Description	Represents the Camera Sensor Sepcific information.

|(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.38 PotentiallyMovingObjectsRadarSensorTechnologySpecific

[SWS_ADI_00237]{DRAFT}

Name	PotentiallyMovingObjectsRadarSensorTechnologySpecific
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	EntityRadarCrossSection float (optional)
Derived from	-
Description	Represents the Radar Sensor Sepcific information.

(RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.2.39 PotentiallyMovingObjectsLidarSensorTechnologySpecific

[SWS_ADI_00238]{DRAFT}

Name	PotentiallyMovingObjectsLidarSensorTechnologySpecific
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	EntityLidarReflectivity float (optional)
Derived from	-
Description	Represents the Lidar Sensor Sepcific information.

|(RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.2.40 PotentiallyMovingObjectInterface

[SWS_ADI_00239]{DRAFT}

Name	PotentiallyMovingObjectInterface
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	PotentiallyMovingObjectInterfaceHeader InterfaceHeader
	PotentiallyMovingObjectList PotentiallyMovingObjects
Derived from	-
Description	Represents the possible moving object informaiton provided by a camera, lidar, radar or Ultrasonic sensor.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3 Road Objects Interface Definition

This section lists all the data types used in road object interface.

9.1.3.1 RoadType

[SWS_ADI_00300]{DRAFT}

Name	RoadType		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFERENCE		
Derived from	uint8_t		
Description	To identify the ego-vehicle relevant type of the road.		
Range / Symbol	Limit	Description	





kHighway	0x00	Represents the highway.
kRural	0x01	Represents the rural road.
kCity	0x02	Represents the city road.
kOffRoad	0x03	Represents off the road.
kUnknown	0x04	Represents the road type unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.2 RoadSurfaceClassificationType

[SWS_ADI_00301]{DRAFT}

Name	RoadSurfaceCla	RoadSurfaceClassificationType	
Namespace	ara::adi::sensori	tf	
Kind	TYPE_REFERE	NCE	
Derived from	uint8_t		
Description	To identify the e	To identify the ego-vehicle relevant type of the road surface.	
Range / Symbol	Limit	Description	
kRomanRoad	0x00	Roman Road.	
kOffRoad	0x01	Off the road.	
kFlat	0x02	Flat surface.	
kBumpy	0x03	Bumpy surface.	
kUnknown	0x04	Surface type is unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.3 RoadConditionClassificationType

[SWS ADI 00302]{DRAFT}

Name	RoadConditionClassificationType	
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFEREN	ICE
Derived from	uint8_t	
Description	To identify the ego-vehicle relevant type of the road surface.	
Range / Symbol	Limit	Description
kDry	0x00	Dry Road.
kWet	0x01	Wet road.
kSnow	0x02	Snow road.
klce	0x03	Ice Road.
kUnknown	0x04	Road Condition is unknown.



9.1.3.4 RoadMarkingType

[SWS_ADI_00303]{DRAFT}

Name	RoadMarkingType	9
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFERENCE	
Derived from	uint8_t	
Description	To identify the ego-vehicle relevant type of the road surface.	
Range / Symbol	Limit	Description
kSolid	0x00	The road marking is solid. It could also be a stop line.
kCentreLineDashedMarking	0x01	The centre line road marking is dashed.
kEdgeLineDashedMarking	0x02	The edge line road marking is dashed.
kTriangular	0x03	The road marking is a line of triangles.
kDoubleLineSolid	0x04	The road marking has two lines and the most inner line (w.r.t. the ego-vehicle) is solid.
kCentreLineDoubleLineDashed	0x05	The centre line road marking has two lines and the most inner line (w.r.t. the ego-vehicle) is dashed.
kMultipleLineSolid	0x06	The road marking has more than two lines and the most inner line (w.r.t. the ego-vehicle) is solid.
kCentreLineMultipleLine Dashed	0x07	The centre line road marking has more than two lines and the most inner line (w.r.t. the ego-vehicle) is dashed.
kEdgeLineMultipleLineDashed	0x08	The edge line road marking has more than two lines and the most inner line (w.r.t. the ego-vehicle) is dashed.
kBottsDotsCatsEyes	0x09	The road marking consists of Botts' dots or cats' eyes.
kAttentionMarker	0x0A	The road marking is an attention marker e.g. US, China and Japan.
kHatched	0x0B	The edge line road marking is dashed.
kBox	0x0C	The road marking of a junction.
kColouredArea	0x0D	The road marking is a coloured area.
kArrow	0x0E	The road marking is an arrow.
kZebraCrossing	0x0F	The road marking is a zebra crossing / continental / ladder.
kGenericSymbol	0x10	The edge line road marking has more than two lines and the most inner line (w.r.t. the ego-vehicle) is dashed.
kTrafficSignOnLane	0x11	The road marking is a traffic sign.
kGenericLine	0x12	The road marking is a generic line.
kParkingArea	0x13	The edge line road marking is dashed.
kTShapeMarkingBegin	0x14	The road marking is a parking T-shape beginning parking line.
kTShapeMarkingEnd	0x15	The road marking is a parking T-shape ending parking line.
kIShapeMarkingBegin	0x16	The road marking is a parking I-shape beginning parking line.
kIShapeMarkingEnd	0x17	The road marking is a zebra crossing / continental / ladder.
kLShapeMarkingBegin	0x18	The road marking is a parking L-shape beginning parking line.
kLShapeMarkingEnd	0x19	The road marking is a parking L-shape ending parking line.
kNets	0x1A	The road marking is a net, i.e. a non-stopping area.
kUnknown	0x1B	The road marking is unknown.



9.1.3.5 ArrowDirection

[SWS_ADI_00304]{DRAFT}

Name	ArrowDirection		
Namespace	ara::adi::sensoritf	ara::adi::sensoritf	
Kind	TYPE_REFEREN	NCE	
Derived from	uint8_t		
Description	To identify estima	ted direction of the displayed arrow.	
Range / Symbol	Limit	Description	
kForeward	0x00	Arrow has an estimated direction of 0 rad to 0.	
kLeft	0x01	Arrow has an estimated direction of +pi/2 rad to +90.	
kRight	0x02	Arrow has an estimated direction of -pi/2 rad to -90.	
kStraightLeft	0x03	Arrow is straight left and has an estimated direction of +pi/2 rad to +90.	
kStraightRight	0x04	Arrow is straight right and has an estimated direction of -pi/2 rad to -90.	
kTurningPointLeft	0x05	Arrow has an estimated direction of +pi/2 rad to +180.	
kTurningPointRight	0x06	Arrow has an estimated direction of -pi/2rad to -180.	
k45DegLeft	0x07	Arrow has an estimated direction of +pi/4 rad to +45.	
k45DegRight	0x08	Arrow has an estimated direction of -pi/4 rad to -45.	
kNoArrow	0x09	No arrow is present.	
kUnknown	0x0A	The arrow direction is unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.6 SignClassificationType

[SWS_ADI_00305]{DRAFT}

Name	SignClassifica	ationType
Namespace	ara::adi::sens	soritf
Kind	TYPE_REFE	RENCE
Derived from	uint8_t	
Description	To identify the	e type of the sign as main traffic sign or road marking.
Range / Symbol	Limit	Description
kStopSign	0x00	Stop sign.
kYieldSign	0x01	Yield sign.
kSpeedLimitSign	0x02	Speed limit sign.
kNoMainSign	0x03	No main sign, only supplementary signs.
kGreenArrowSign	0x04	Green Arrow Sign.
kHeightLimitSign	0x05	Height limit sign.
kEmptySign	0x06	Sign may be a changeable traffic sign without displaying a traffic sign symbol.
kUnknown	0x07	The Sign type is unknown.



9.1.3.7 SignValueUnit

[SWS_ADI_00306]{DRAFT}

Name	SignValueUn	it	
Namespace	ara::adi::sens	ara::adi::sensoritf	
Kind	TYPE_REFE	RENCE	
Derived from	uint8_t		
Description	To identify the	e value unit of the linked sign.	
Range / Symbol	Limit	Description	
kKilometrePerHour	0x00	Kilometre per hour	
kMilePerHour	0x01	Mile per hour	
kMeter	0x02	Meter	
kKilometre	0x03	Kilometre	
kFeet	0x04	Feet	
kMile	0x05	Mile	
kMetricTon	0x06	Metric Ton	
kShortTon	0x07	Short Ton	
kLongTon	0x08	LongTon.	
kMinute	0x09	Minute	
kHour	0x0A	Hour	
Day	0x0B	Day	
kWeekday	0x0C	Weekday	
kPercentage	0x0D	Percentage	
kUnknown	0x0E	Unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.8 ConnectionType

[SWS_ADI_00307]{DRAFT}

Name	ConnectionType		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFEREN	ICE	
Derived from	uint8_t		
Description	To identify the typ	To identify the type of connection of at least two road markings, polylines or polynomials.	
Range / Symbol	Limit	Description	
kMerge	0x00	The connection of road markings is a merge of road markings.	
kSplit	0x01	The connection of road markings is a split of road markings.	
kInterconnection	0x02	The connection of road markings is an interconnection of road markings.	
kExtension	0x03	The connection of road markings is an extension of two road markings.	
kUnknown	0x04	The connection type is unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.3.9 PolynomialCoefficient

[SWS_ADI_00308]{DRAFT}

Name	PolynomialCoefficient
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	CO float
	C1 float
	C2 float
	C3 float
Derived from	-
Description	Calculated coefficient. (m, 1, 1/m, 1/m2)

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.10 ColourTone

[SWS_ADI_00309]{DRAFT}

Name	ColourTone
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	ValidColourModel ColourValueVector
	ColourToneConfidenceObjectLevel ProbabilityPercentage (optional)
Derived from	-
Description	Represents the colour Information.

](RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.11 RoadObjectInterface

[SWS ADI 00310]{DRAFT}

Name	RoadObjectInterface		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	RoadObjectInterfaceHeader InterfaceHeader		
	RoadSurfaceObjectList RoadSurface (optional)		
	RoadMarkingObjectList RoadMarkings (optional)		
	RoadBoundariesObjectList RoadBoundaries (optional)		
Derived from	-		
Description	Represents the road object informaiton provided by a camera, lidar, radar or Ultrasonic sensor.		



](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.12 PolynomialRangeX

[SWS_ADI_00311]{DRAFT}

Name	PolynomialRangeX	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	Start float	
	End float	
Derived from	-	
Description	Valid range of the polynomial [x Start, x End].(m, m)	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.13 SupportedDataRangeX

[SWS_ADI_00312]{DRAFT}

Name	SupportedDataRangeX		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	Start float		
	End float		
Derived from	-		
Description	Supported range of the polynomial [x Start, x End] covered with measured points.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.14 PolylineInterpolationMethod

[SWS_ADI_00313]{DRAFT}

Name	PolylineInterpolationMethod		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFERENCE		
Derived from	uint8_t		
Description	To identify the type of connection of at least two road markings, polylines or polynomials.		
Range / Symbol	Limit	Description	





kLinear	0x00	Linear interpolation between two sequential points.
kSpline	0x01	Spline interpolation between two sequential points.
kCubic	0x02	Cubic interpolation between two sequential points.
kUnknown	0x03	Interpolation Method is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.15 VertexPointConfidence

[SWS_ADI_00314]{DRAFT}

Name	VertexPointConfidence	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	Vpcx ProbabilityPercentage	
	Vpcy ProbabilityPercentage	
	Vpcz ProbabilityPercentage	
Derived from	-	
Description	Measured longitudinal, lateral and vertical distance of the vertex confidence.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.16 RoadBoundaryType

[SWS_ADI_00315]{DRAFT}

Name	RoadBoundaryT	RoadBoundaryType	
Namespace	ara::adi::sensori	ara::adi::sensoritf	
Kind	TYPE_REFERE	NCE	
Derived from	uint8_t		
Description	Indicated the typ	Indicated the type of the road boundary.	
Range / Symbol	Limit	Description	
kGuardrail	0x00	The road boundary is a guardrail.	
kFence	0x01	The road boundary is a fence.	
kWand	0x02	The road boundary is a wand, a wall, a building, etc.	
kBarrier	0x03	The road boundary is a barrier.	
kTensionCableSystem	0x04	The road boundary is a tension cable system.	
kRoadEdge	0x05	The road boundary is a road edge e.g. grass, vegetation, sand, gravel, soil, etc.	
kCurb	0x06	The road boundary is a curb stone.	
kUnclassifiedElevated	0x07	The road boundary is an unclassified elevated structure.	
kUnknown	0x08	The Road boundary type is unknown.	



](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.17 RoadObjectLaneAssociation

[SWS_ADI_00316]{DRAFT}

Name	RoadObjectLane	RoadObjectLaneAssociation		
Namespace	ara::adi::sensorit	ara::adi::sensoritf		
Kind	TYPE_REFERE	NCE		
Derived from	uint8_t			
Description	To provides the a	association of a road marking or a road boundary to a lane with respect to ane.		
Range / Symbol	Limit	Description		
kEgoLane	0x00	The road marking is on the ego lane.		
kEgoLeft1Lane	0x01	The road boundary separates the ego lane from 1st left neighbouring lane. The road marking is associated to the ego lane and the 1st left neighbouring lane.		
kEgoRight1Lane	0x02	The road boundary separates the ego lane from 1st right neighbouring lane. The road marking is associated to the ego lane and the 1st right neighbouring lane.		
kLeft1Lane	0x03	The road marking is on the 1st left neighbouring lane.		
kRight1Lane	0x04	The road marking is on the 1st right neighbouring lane.		
kLeft1Left2Lane	0x05	The road boundary separates the 1st left lane from the 2nd left neighbouring lane. The road marking is associated to the 1st lane and the 2nd left neighbouring lane.		
kRight1Right2Lane	0x06	The road boundary separates the 1st right lane from the 2nd right neighbouring lane. The road marking is associated to the 1st lane and the 2nd right neighbouring lane.		
kLeft2Lane	0x07	The road marking is on the 2nd left neighbouring lane.		
kRight2Lane	0x08	The road marking is on the 2nd right neighbouring lane.		
kLeftRoadEdge	0x09	The road boundary limits at the outer edge of the leftmost lane.		
kRightRoadEdge	0x0A	The road boundary limits at the outer edge of the rightmost lane.		
kUnknown	0x0B	The road object lane association is unknown.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.18 RoadBoundaries

[SWS_ADI_00317]{DRAFT}

Name	RoadBoundaries	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	





Subelements	RecognisedRoadBoundariesCapability uint16_t (optional)	
	RecognizedRoadBoundariesStatus RecognizedStatus (optional)	
	NumberOfValidRoadBoundaries uint16_t	
	RoadBoundaryList RoadBoundaryVector	
Derived from	-	
Description	Represents the road boundaries Information.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.19 RoadSurfaceClassification

[SWS_ADI_00318]{DRAFT}

Name	RoadSurfaceClassification	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	SurfaceType RoadSurfaceClassificationType	
	${\bf Road Surface Classification Type Confidence \ {\tt Probability Percentage}}$	
Derived from	-	
Description	Represents the road suface type and probability.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.20 SignState

[SWS_ADI_00319]{DRAFT}

Name	SignState	SignState	
Namespace	ara::adi::sensorit	f	
Kind	TYPE_REFEREN	NCE	
Derived from	uint8_t	uint8_t	
Description	To provides the s	To provides the state of the sign.	
Range / Symbol	Limit	Description	
kStatic	0x00	The message sign is not a variable message sign.	
kVariable	0x01	The message sign is a variable message sign.	
kSwitchedOff	0x02	The message sign is a variable message sign which is switched off.	
kFullOutOfService	0x03	The message sign is full out of service.	
kPartlyOutOfService	0x04	Part of the message sign is out of service.	
kOutOfView	0x05	The message sign has rotated.	
kUnknown	0x06	The sign state is unknown.	



9.1.3.21 RoadSurfaceClassificationsVector

[SWS ADI 00320]{DRAFT}

Name	RoadSurfaceClassificationsVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	RoadSurfaceClassification
Derived from	-
Description	Represents a list of Road Surface.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.22 RoadSurfaceConditionClassification

[SWS ADI 00321]{DRAFT}

Name	RoadSurfaceConditionClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	RoadConditionType RoadConditionClassificationType
	RoadSurfaceConditionClassificationTypeConfidence ProbabilityPercentage
Derived from	-
Description	Represents the road suface condition and probability.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.23 RoadSurfaceConditionClassificationsVector

[SWS_ADI_00322]{DRAFT}

Name	RoadSurfaceConditionClassificationsVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	RoadSurfaceConditionClassification
Derived from	-
Description	Represents a list of Road Surface condition.



9.1.3.24 RoadSurface

[SWS_ADI_00323]{DRAFT}

Name	RoadSurface
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	RoadType RoadType
	NumberOfValidRoadSurfaceClassifications uint8_t
	$\textbf{ValidRoadSurfaceClassifications} \ \texttt{RoadSurfaceClassificationsVector}$
	RoadSurfaceRoughness float (optional)
	$Number Of Valid Road Surface Condition Classifications \verb uint8_t (optional) $
	ValidRoadSurfaceConditionClassifications
	RoadSurfaceConditionClassificationsVector
	TrackQuality uint16_t (optional)
	PMOMeasurementStatusObjectLevel MeasurementStatus (optional)
Derived from	-
Description	Represents the road suface Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.25 ColourValueVector

[SWS_ADI_00324]{DRAFT}

Name	ColourValueVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	float
Derived from	-
Description	Represents a list of Colour Value.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.26 RoadMarkingClassification

$\hbox{[SWS_ADI_00325]} \{ \hbox{DRAFT} \} \; \lceil \;$

Name	RoadMarkingClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE





Subelements	ROMarkingType RoadMarkingType
	RoadMarkingTypeConfidence ProbabilityPercentage
	RoadObjectLaneAssociation RoadObjectLaneAssociation (optional)
	RoadObjectLaneAssociationConfidence ProbabilityPercentage (optional)
	ArrowOrientation float (optional)
	ArrowDirect ArrowDirection (optional)
	NumberOfValidSignClassifications uint8_t (optional)
	ValidSignClassificationsList ValidSignClassificationVector (optional)
	ColourTone ColourTone (optional)
Derived from	-
Description	Represents the road marking type Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.27 RoadMarkingClassificationVector

[SWS_ADI_00326]{DRAFT}

Name	RoadMarkingClassificationVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	RoadMarkingClassification
Derived from	-
Description	Represents a list of Road Marking type.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.28 RoadMarkingsInformation

[SWS_ADI_00327]{DRAFT}

Name	RoadMarkingsInformation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidRoadMarkingClassifications uint8_t
	ValidRoadMarkingClassificationsList RoadMarkingClassificationVector
Derived from	-
Description	Represents the road marking type Information.



9.1.3.29 ValidConnection

[SWS_ADI_00328]{DRAFT}

Name	ValidConnection
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Type ConnectionType
	ConnectionId uint8_t
Derived from	-
Description	Represents the road marking connection information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.30 ValidConnectionVector

[SWS_ADI_00329]{DRAFT}

Name	ValidConnectionVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ValidConnection
Derived from	-
Description	Represents a list of Road marking connection information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.31 ValidPolynomial

[SWS_ADI_00330]{DRAFT}

Name	ValidPolynomial
Namespace	ara::adi::sensoritf
Kind	STRUCTURE





Subelements	PolynomialCoefficientY PolynomialCoefficient
	PolynomialCoefficientZ PolynomialCoefficient
	PolynomialYError float (optional)
	PolynomialZError float (optional)
	PolynomialRange PolynomialRangeX
	WidthPolynomial float (optional)
	WidthPolynomialError float (optional)
	WidthPolynomialsConfidence ProbabilityPercentage (optional)
	HeightPolynomial float (optional)
	HeightPolynomialError float (optional)
	HeightPolynomialConfidence ProbabilityPercentage (optional)
	NumberOfValidDataRanges uint8_t (optional)
	DataRangeList SupportedDataRangeVector (optional)
Derived from	-
Description	Represents the Polynomial Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.32 SupportedDataRangeVector

[SWS_ADI_00331]{DRAFT}

Name	SupportedDataRangeVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	SupportedDataRange
Derived from	-
Description	Represents a list of supported data range information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.33 ValidPolynomialVector

[SWS_ADI_00332]{DRAFT}

Name	ValidPolynomialVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ValidPolynomial
Derived from	-
Description	Represents a list of polynomials information.



](RS_ADI_00001, RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.34 Polynomials

[SWS_ADI_00333]{DRAFT}

Name	Polynomials
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidConnections uint8_t
	ValidConnectionList ValidConnectionVector
	NumberOfValidPolynomials uint8_t
	ValidPolynomialsList ValidPolynomialVector
Derived from	-
Description	Represents the Polynomials related Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_-00014)

9.1.3.35 ValidVertice

[SWS ADI 00334]{DRAFT}

Name	ValidVertice
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	VertexPoint Point3D
	VertexPointError Point3DError
	VertexPointConfidence VertexPointConfidence (optional)
	WidthVertex float (optional)
	WidthVertexError float (optional)
	WidthVertexConfidence ProbabilityPercentage (optional)
	HeightVertex float (optional)
	HeightVertexError float (optional)
	HeightVertexConfidence ProbabilityPercentage (optional)
Derived from	-
Description	Represents the vertex point Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.3.36 ValidVerticeVector

[SWS_ADI_00335]{DRAFT}

Name	ValidVerticeVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ValidVertice
Derived from	-
Description	Represents a list of vertex points information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.37 ValidPolyline

[SWS ADI 00336]{DRAFT}

Name	ValidPolyline
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidVertices uint8_t
	ValidVerticesList ValidVerticeVector
Derived from	-
Description	Represents the Polyline related Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.38 ValidPolylineVector

$\textbf{[SWS_ADI_00337]} \{ \texttt{DRAFT} \} \; \lceil \;$

Name	ValidPolylineVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ValidPolyline
Derived from	-
Description	Represents a list of Polyline information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_-00014)



9.1.3.39 **Polylines**

[SWS_ADI_00338]{DRAFT}

Name	Polylines
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidConnections uint8_t
	ValidConnectionList ValidConnectionVector
	InterpolationMethod PolylineInterpolationMethod
	NumberOfValidPolylines uint8_t
	ValidPolylinesList ValidPolylineVector
Derived from	-
Description	Represents the Polylines Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.40 RoadMarking

[SWS_ADI_00339]{DRAFT}

Name	RoadMarking
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	RoadMarkingsStatus ObjectStatus
	RoadMarkingsInformation RoadMarkingsInformation
	RoadMarkingsPolynomials Polynomials (optional)
	RoadMarkingsPolylines Polylines (optional)
Derived from	-
Description	Represents the road marking Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.41 RoadMarkingVector

[SWS_ADI_00340]{DRAFT}

Name	RoadMarkingVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	RoadMarking
Derived from	-
Description	Represents a list of road marking object information.



](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.42 RoadMarkings

[SWS_ADI_00341]{DRAFT}

Name	RoadMarkings
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	RecognizedRoadMarkingsCapability uint8_t (optional)
	RecognizedRoadMarkingsStatus RecognizedStatus (optional)
	NumberOfValidRoadMarkings uint16_t
	ValidRoadMarkings RoadMarkingVector
Derived from	-
Description	Represents the road marking Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.43 ValidRoadBoundaryClassification

[SWS_ADI_00342]{DRAFT}

Name	ValidRoadBoundaryClassification	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	RoadBoundaryType RoadBoundaryType	
	RoadBoundaryTypeConfidence ProbabilityPercentage	
	RoadObjectLaneAssociation RoadObjectLaneAssociation	
	RoadObjectLaneAssociationConfidence ProbabilityPercentage	
	ColourTone ColourTone (optional)	
Derived from	-	
Description	Represents the road boundary type Information.	



9.1.3.44 ValidRoadBoundaryClassificationVector

[SWS_ADI_00343]{DRAFT}

Name	ValidRoadBoundaryClassificationVector	
Namespace	ara::adi::sensoritf	
Kind	ECTOR	
Subelements	ValidRoadBoundaryClassification	
Derived from	-	
Description	Represents a list of road boundary type object information.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.45 RoadBoundariesInformation

[SWS_ADI_00344]{DRAFT}

Name	RoadBoundariesInformation		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	NumberOfValidRoadBoundaryClassifications uint8_t		
	ValidRoadBoundaryClassificationsList ValidRoadBoundaryClassificationVector		
Derived from	-		
Description	Represents the road boundary type Information.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.46 ValidRoadBoundary

[SWS ADI 00345]{DRAFT}

Name	ValidRoadBoundary	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	RoadBoundariesStatus ObjectStatus	
	RoadBoundariesInformation RoadBoundariesInformation	
	RoadBoundariesPolynomials Polynomials (optional)	
	RoadBoundariesPolylines Polylines (optional)	
Derived from	-	
Description	Represents the road boundary Information.	



9.1.3.47 RoadBoundaryVector

[SWS_ADI_00346]{DRAFT}

Name	RoadBoundaryVector	
Namespace	ara::adi::sensoritf	
Kind	VECTOR	
Subelements	ValidRoadBoundary	
Derived from	-	
Description	Represents a list of road boundary object information.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.48 SupportedAxis

$\textbf{[SWS_ADI_00347]} \{ \texttt{DRAFT} \} \; \lceil \;$

Name	SupportedAxis		
Namespace	ara::adi::sensoritf	ara::adi::sensoritf	
Kind	TYPE_REFEREN	ICE	
Derived from	uint8_t		
Description	To provide the information of the polynomial axis for Supported data range x {begin, end}.		
Range / Symbol	Limit	Description	
kY	0x00	The signal Supported data range x {begin, end} corresponds to Y-axis polynomial line of Polynomial coefficient y {c0, c1, c2, c3}.	
kZ	0x01	The signal Supported data range x {begin, end} corresponds to Z-axis polynomial line of Polynomial coefficient z {c0, c1, c2, c3}.	
kYAndZ	0x02	The signal Supported data range x {begin, end} corresponds to both Y-axis polynomial line of Polynomial coefficient z {c0, c1, c2, c3} and Z-axis polynomial line of Polynomial coefficient z {c0, c1, c2, c3}.	
kUnknown	0x03	Unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.49 SignClassification

[SWS_ADI_00348]{DRAFT}

Name	SignClassification	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	





Subelements	SignClassificationType SignClassificationType (optional)	
	SignClassificationTypeConfidence ProbabilityPercentage (optional)	
	SignValue float (optional)	
	SignValueUnit SignValueUnit (optional)	
	SignState SignState (optional)	
Derived from	-	
Description	Represents the sign Classification Information.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.50 ValidSignClassificationVector

[SWS_ADI_00349]{DRAFT}

Name	ValidSignClassificationVector	
Namespace	ara::adi::sensoritf	
Kind	/ECTOR	
Subelements	SignClassification	
Derived from	-	
Description	Represents a list of Sign Classification.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.3.51 SupportedDataRange

[SWS_ADI_00350]{DRAFT}

Name	SupportedDataRange	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	SupportedDataRangeX SupportedDataRangeX	
	SupportedAxis SupportedAxis	
Derived from	-	
Description	Supported data range info.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4 Static Objects Interface Definition

This section lists all the data types used in Static object interface.



9.1.4.1 GeneralLandmarkClassificationType

[SWS_ADI_00401]{DRAFT}

Name	GeneralLand	GeneralLandmarkClassificationType	
Namespace	ara::adi::sens	ara::adi::sensoritf	
Kind	TYPE_REFE	RENCE	
Derived from	uint8_t		
Description	Classification	of the general landmark.	
Range / Symbol	Limit	Description	
kBridge	0x00	Bridge as general landmark.	
kBeacon	0x01	Beacon as general landmark.	
kCone	0x02	Cone as general landmark.	
kBarrel	0x03	TBarrel as general landmark.	
kGuidePost	0x04	Guide post as general landmark.	
kLampPost	0x05	Lamp post as general landmark.	
kVerticalStructure	0x06	Vertical structure as general landmark.	
kOverheadObject	0x07	Overhead object as general landmark.	
kRectangularStructure	0x08	Rectangular structure as general landmark.	
kTunnel	0x09	Tunnel as general landmark.	
kReflector	0x0A	Reflector as general landmark.	
kUnknown	0x0B	The landmark class is unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.2 SignGeometry

[SWS_ADI_00402]{DRAFT}

Name	SignGeometry	,	
Namespace	ara::adi::senso	ara::adi::sensoritf	
Kind	TYPE_REFEF	RENCE	
Derived from	uint8_t		
Description	The shape of t	The shape of the sign.	
Range / Symbol	Limit	Description	
kCircle	0x00	Circle shape as sign geometry.	
kTriangleTop	0x01	Triangle with tip pointing downwards as sign geometry.	
kTriangleDown	0x02	Triangle with tip pointing upwards as sign geometry.	
kSquare	0x03	Square shape as sign geometry.	
kPole	0x04	Pole shape as sign geometry.	
kRectangle	0x05	Rectangle shape as sign geometry.	
kPlate	0x06	Plate with multiple traffic information.	
kDiamond	0x07	Diamond shape as sign geometry.	
kArrowLeft	0x08	Arrow left five edge shape as sign geometry.	





kArrowRight	0x09	Arrow right five edge shape as sign geometry.
kOctagon	0x0A	Octagon shape as sign geometry.
kUnknown	0x0B	The sign geometry is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.3 TrafficSignsInformation

[SWS_ADI_00403]{DRAFT}

Name	TrafficSignsInformation	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	NumberOfValidSignClassifications uint8_t	
	ValidMainSignClassificationsList ValidMainSignClassificationVector	
	NumberOfValidLaneRelevanceClassifications uint8_t	
	ValidLaneRelevanceClassificationList ValidLaneRelevanceClassificationVector	
Derived from	-	
Description	Represents the traffic sign Information.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.4 TrafficLightsInformation

[SWS_ADI_00404]{DRAFT}

Name	TrafficLightsInformation	
Name	nameLightsimormation	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	NumberOfValidStructureLightClassifications uint8_t	
	ValidStructureLightClassificationsList ValidStructureLightClassificationsVector	
Derived from	-	
Description	Represents the traffic light Information.	



9.1.4.5 LaneRelevanceClassificationType

[SWS_ADI_00405]{DRAFT}

Name	LaneRelevanceC	LaneRelevanceClassificationType	
Namespace	ara::adi::sensoritf	f	
Kind	TYPE_REFEREN	NCE	
Derived from	uint8_t		
Description		sign is relevant for the ego-vehicle's lane, the nearest lane to the ner relevant lanes.	
Range / Symbol	Limit	Description	
kOnTrack	0x00	Relevant on track of ego-vehicle.	
kNextLaneLeft	0x01	Relevant for the next lane to the ego-vehicle on the left site.	
kNextLaneRight	0x02	Relevant for the next lane to the ego-vehicle on the right site.	
kNextNextLaneLeft	0x03	Relevant for the second next lane to the ego-vehicle on the left site.	
kNextNextLaneRight	0x04	Relevant for the second next lane to the ego-vehicle on the right site.	
kOnTrackAndNextLaneLeft	0x05	Relevant on track of ego-vehicle and the next left lane.	
kOnTrackAndNextLaneRight	0x06	Relevant on track of ego-vehicle and the next right lane.	
kMostLeftLane	0x07	Relevant for the leftest lane.	
kMostRightLane	0x08	Relevant for the rightest lane.	
kAllLanes	0x09	Relevant for all lanes, lane to the right and left site and on track.	
kOtherLane	0x0A	Relevant for another far lane.	
kUnknown	0x0B	The lane relevance is unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.6 SupplementarySignClassificationType

[SWS_ADI_00406]{DRAFT}

Name	SupplementarySignClassificationType		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFEREN	ICE	
Derived from	uint8_t		
Description	The type of the si	The type of the sign.	
Range / Symbol	Limit Description		
kValidInformationBegin	0x00	Begin of valid zone.	
kValidInformationEnd	0x01	End of valid zone.	
kFrost	0x02	Frost sign.	
kWetRoad	0x03	Wet road sign.	
kDistance	0x04	Distance information.	
kLimitation	0x05	Limitation information.	
kUnknown	0x06	Supplementary Sign type is unknown.	



9.1.4.7 RelativePosition

[SWS_ADI_00407]{DRAFT}

Name	RelativePosition	
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFEREN	NCE
Derived from	uint8_t	
Description	The relative position of the supplemental sign w.r.t. its main sign.	
Range / Symbol	Limit Description	
kAbove	0x00	Supplementary sign is above the main sign.
kLeft	0x01	Message sign is full out of service.
kBelow	0x02	Supplementary sign is below the main sign.
kRight	0x03	Supplementary sign is right of the main sign.
kUnknown	0x04	Relative position is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.8 StructureLightClassificationType

[SWS ADI 00408]{DRAFT}

Name	StructureLightClassificationType	
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFEREN	ICE
Derived from	uint8_t	
Description	The traffic light can have different shapes.	
Range / Symbol	Limit	Description
kVertical3	0x00	Three light sources vertical.
kHorizontal3	0x01	Three light sources horizontal.
kDogHouse	0x02	Multi light sources.
kUnknown	0x03	Structure is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.9 ColourClassificationType

[SWS_ADI_00409]{DRAFT}

Name	ColourClassificationType	
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFERENCE	





Derived from	uint8_t		
Description	Colour of light spe	Colour of light spot.	
Range / Symbol	Limit	Limit Description	
kRed	0x00	The spot colour is red.	
kYellow	0x01	The spot colour is yellow.	
kGreen	0x02	The spot colour is green.	
kWhite	0x03	The spot colour is white.	
kUnknown	0x04	The spot colour is unknown.	

](RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.10 GeneralLandmarksInformation

[SWS_ADI_00414]{DRAFT}

Name	GeneralLandmarksInformation	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	NumberOfValidGeneralLandmarkClassifications uint8_t	
	LandmarkTypelist ValidGeneralLandmarkClassificationVector	
Derived from	-	
Description	Represents the ladmark type certainty Information.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.11 LightShapeClassificationType

[SWS_ADI_00411]{DRAFT}

Name	LightShapeClassi	LightShapeClassificationType	
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFEREN	ICE	
Derived from	uint8_t		
Description	The light's shape.		
Range / Symbol	Limit Description		
kNoShape	0x00	No additional shape.	
kArrowStraightAhead	0x01	Arrow straight ahead shape.	
kArrowLeft	0x02	Arrow left shape.	
kArrowDiagLeft	0x03	Arrow diagonal left shape.	
kArrowStraightAheadLeft	0x04	Arrow straight ahead and arrow left shape.	
kArrowRight	0x05	Arrow right shape.	
kArrowDiagRight	0x06	Arrow diagonal right shape.	





kArrowStraightAheadRight	0x07	Arrow straight ahead and arrow right shape.
kArrowLeftRight	0x08	Arrow left and arrow right shape.
kArrowDown	0x09	Arrow down shape.
kArrowDownLeft	0x0A	Arrow U-turn left shape.
kArrowDownRight	0x0B	Arrow U-turn right shape.
kCross	0x0C	Cross figure.
kPedestrian	0x0D	Pedestrian figure.
kWalk	0x0E	Text walk figure.
kDontWalk	0x0F	Text don't walk figure.
kBicycle	0x10	Bicycle figure.
kPedestrianAndBicycle	0x11	Pedestrian and bicycle figure.
kCountdownSecond	0x12	Countdown in seconds figure. Signal Light shape value contains the value in s.
kCountdownPercent	0x13	Countdown in percent figure. Signal Light shape value contains the value in %.
kTram	0x14	Tram figure.
kBus	0x15	Bus figure.
kBusAndTram	0x16	Bus and Tram figure.
kUnknown	0x17	The light shape is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.12 LightModeClassificationType

[SWS_ADI_00410]{DRAFT}

Name	LightModeClassif	icationType
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFEREN	ICE
Derived from	uint8_t	
Description	The light's mode.	
Range / Symbol	Limit	Description
kContinuous	0x00	Light source is continuous on.
kBlinking	0x01	One light source is blinking
kTurnedOff	0x02	Light source is turned off.
kCounting	0x03	Light source with counting.
kUnknown	0x04	Light Mode type is unknown.



9.1.4.13 ValidGeneralLandmarkClassificationVector

[SWS_ADI_00413]{DRAFT}

Name	ValidGeneralLandmarkClassificationVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	GeneralLandmarkClassification
Derived from	-
Description	Represents a list of Landmark type.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.14 GeneralLandmarkClassification

[SWS_ADI_00412]{DRAFT}

Name	GeneralLandmarkClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	GeneralLandMarkType GeneralLandmarkClassificationType
	LandmarkClassProbability ProbabilityPercentage
Derived from	-
Description	Represents the general landmark type and probability.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.15 GeneralLandmarksPosition

[SWS_ADI_00415]{DRAFT}

Name	GeneralLandmarksPosition
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Position Point3D
	PositionError Point3DError
	Orientation Orientation 3D (optional)
	OrientationError Orientation3DError (optional)
	ReferencePoint ReferencePoint (optional)
Derived from	-
Description	Represents the landmark position.



9.1.4.16 BoundingBox

[SWS_ADI_00416]{DRAFT}

Name	BoundingBox
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	BoxDimension DimensionBox
	BoxError DimensionBoxError (optional)
Derived from	-
Description	Represents the bounding box information of the static objects. This is only for camera

(RS ADI 00001, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.4.17 GeneralLandmark

[SWS ADI 00417]{DRAFT}

Name	GeneralLandmark
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	GeneralLandmarksStatus ObjectStatus
	LandmarksInformation GeneralLandmarksInformation
	GeneralLandmarksPos GeneralLandmarksPosition
	GeneralLandmarksBoundingBox BoundingBox (optional)
Derived from	-
Description	Represents the landmark Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.18 GeneralLandmarkVector

[SWS_ADI_00418]{DRAFT}

Name	GeneralLandmarkVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	GeneralLandmark
Derived from	-
Description	Represents a list of Landmark.



9.1.4.19 GeneralLandmarks

[SWS_ADI_00419]{DRAFT}

Name	GeneralLandmarks
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	RecognisedGeneralLandmarksCapability uint16_t (optional)
	RecognizedGeneralLandmarksStatus RecognizedStatus (optional)
	NumberOfValidGeneralLandmarks uint16_t
	GeneralLandmarksList GeneralLandmarkVector
Derived from	-
Description	Represents the general landmarks Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.20 LaneRelevanceClassification

[SWS ADI 00420]{DRAFT}

Name	LaneRelevanceClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	LaneRelevanceClassificationType LaneRelevanceClassificationType
	LaneRelevanceClassificationTypeConfidence ProbabilityPercentage
Derived from	-
Description	Represents the main sign lane relevance classification Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.21 MainSignClassification

[SWS_ADI_00421]{DRAFT}

Name	MainSignClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE



Subelements	MainSignClassificationType SignClassificationType
	SignClassificationTypeConfidence ProbabilityPercentage
	SignValue float
	MSignUnit SignValueUnit
	SignState SignState
	MSignGeometry SignGeometry (optional)
Derived from	-
Description	Represents the main sign Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.22 TrafficSignsPosition

[SWS ADI 00422]{DRAFT}

Name	TrafficSignsPosition
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Position Point3D
	PositionError Point3DError
Derived from	-
Description	Represents the main sign position.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.23 SubObjectStatus

[SWS ADI 00423]{DRAFT}

Name	SubObjectStatus
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	ExistenceProbabilityObjectLevel ProbabilityPercentage
	Age uint64_t
	NumberOfValidObservationsObjectLevel uint32_t (optional)
	ValidObservations ValidObservationVector (optional)
	TrackQuality uint16_t (optional)
	MeasurementStatusObjectLevel MeasurementStatus
Derived from	-
Description	Represents the dynamics of the static object.



9.1.4.24 TrafficSignsSupplementarySignsInformation

[SWS_ADI_00424]{DRAFT}

Name	TrafficSignsSupplementarySignsInformation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidSupplementarySignClassifications uint8_t
	ValidSupplementarySignClassifications ValidSupplementarySignClassificationVector
Derived from	-
Description	Represents the Supplementary sign type Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.25 SupplementarySignClassification

[SWS_ADI_00425]{DRAFT}

Name	SupplementarySignClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	SupplementarySignClassificationType SupplementarySignClassificationType
	SupplementarySignClassificationTypeConfidence ProbabilityPercentage
	SSignValue float
	SSignUnit SignValueUnit
	SignState SignState
Derived from	-
Description	Represents the Supplementary sign Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.26 TrafficSignsSupplementarySignsPosition

[SWS_ADI_00426]{DRAFT}

Name	TrafficSignsSupplementarySignsPosition
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	SSRelativePosition RelativePosition
	RelativePosOrder uint8_t
Derived from	-
Description	Represents the Supplementary sign position Information.



](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.27 TrafficSignsSupplementarySign

[SWS_ADI_00427]{DRAFT}

Name	TrafficSignsSupplementarySign
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	TrafficSignsSupplementarySignsStatus SubObjectStatus
	TrafficSignsSupplementarySignsInformation TrafficSignsSupplementarySignsInformation
	TrafficSignsSupplementarySignsColourTone ColourTone
	TrafficSignsSupplementarySignsPos TrafficSignsSupplementarySignsPosition
Derived from	-
Description	Represents the Supplementary sign Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.28 TrafficSignsSupplementarySignVector

[SWS ADI 00428]{DRAFT}

Name	TrafficSignsSupplementarySignVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	TrafficSignsSupplementarySign
Derived from	-
Description	Represents a list of Supplementary sign.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.29 TrafficSignsSupplementarySigns

[SWS_ADI_00429]{DRAFT}

Name	TrafficSignsSupplementarySigns
Namespace	ara::adi::sensoritf
Kind	STRUCTURE





Subelements	NumberOfValidTrafficSupplementarySigns uint8_t
	SSignList TrafficSignsSupplementarySignVector
Derived from	-
Description	Represents the Supplementary signs Information.

[(RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.30 TrafficSign

[SWS_ADI_00430]{DRAFT}

Name	TrafficSign
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	TrafficSignsStatus ObjectStatus
	TrafficSignsInformation TrafficSignsInformation
	ColourTone ColourTone
	TrafficSignsPosition TrafficSignsPosition
	TrafficSignsSupplementarySigns TrafficSignsSupplementarySigns
Derived from	-
Description	Represents the traffic sign Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.31 ValidTrafficSignVector

[SWS_ADI_00431]{DRAFT}

Name	ValidTrafficSignVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	TrafficSign
Derived from	-
Description	Represents a list of traffic sign.



9.1.4.32 TrafficSigns

[SWS_ADI_00432]{DRAFT}

Name	TrafficSigns
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	RecognisedTrafficSignsCapability uint16_t (optional)
	RecognizedTrafficSignsStatus RecognizedStatus (optional)
	NumberOfValidTrafficSigns uint16_t
	TrafficSignsList ValidTrafficSignVector
Derived from	-
Description	Represents the traffic sings Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.33 StructureLightClassification

[SWS_ADI_00433]{DRAFT}

Name	StructureLightClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	StructureLightClassificationType StructureLightClassificationType
	$Structure Light Classification Type Confidence \verb ProbabilityPercentage \\$
Derived from	-
Description	Represents the traffic light type certainty Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.34 TrafficLightsPosition

[SWS_ADI_00434]{DRAFT}

Name	TrafficLightsPosition
Namespace	ara::adi::sensoritf
Kind	STRUCTURE





Subelements	PositionObjectLevel Point3D
	PositionObjectLevelError Point3DError
	Orientation Orientation 3D (optional)
	OrientationError Orientation3DError (optional)
	ReferencePoint ReferencePoint (optional)
	MinimumVisibilityDistance uint16_t
Derived from	-
Description	Represents the traffic light position.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.35 ColourClassification

[SWS_ADI_00435]{DRAFT}

Name	ColourClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	ColourClassificationType ColourClassificationType
	ColourClassificationTypeConfidence ProbabilityPercentage
Derived from	-
Description	Represents the colour type and probability.

|(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.36 ColourClassificationVector

[SWS_ADI_00436]{DRAFT}

Name	ColourClassificationVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ColourClassification
Derived from	-
Description	Represents a list of colour type.

(RS ADI 00001, RS ADI 00012, RS ADI 00013, RS ADI 00014)



9.1.4.37 TrafficLightsSpotsColour

[SWS_ADI_00437]{DRAFT}

Name	TrafficLightsSpotsColour
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidColourClassifications uint8_t
	ValidColourClassificationVectorList ColourClassificationVector
	NumberOfValidLightModeClassifications uint8_t
	ValidLightModeClassificationVectorList LightModeClassificationVector
Derived from	-
Description	Represents the trafic light colour type certainty Information.

|(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.38 LightModeClassification

[SWS ADI 00438]{DRAFT}

Name	LightModeClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	LightModeClassificationType LightModeClassificationType
	LightModeClassificationTypeConfidence ProbabilityPercentage
Derived from	-
Description	Represents the traffic light mode type and probability.

\[(RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014) \]

9.1.4.39 LightModeClassificationVector

[SWS_ADI_00439]{DRAFT}

Name	LightModeClassificationVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	LightModeClassification
Derived from	
Description	Represents a list of traffic light mode type.



9.1.4.40 LightShapeClassification

[SWS_ADI_00440]{DRAFT}

Name	LightShapeClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	LightShapeClassificationType LightShapeClassificationType
	LightShapeClassificationTypeConfidence ProbabilityPercentage
	LightShapeValue uint8_t (optional)
Derived from	-
Description	Represents the trafic light shape Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.41 TrafficLightsSpotsInformation

[SWS_ADI_00441]{DRAFT}

Name	TrafficLightsSpotsInformation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidLightShapeClassifications uint8_t
	ValidLightShapeClassificationList LightShapeClassificationVector
Derived from	-
Description	Represents the trafic light spot shape Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.42 TrafficLightsSpotsPosition

[SWS_ADI_00442]{DRAFT}

Name	TrafficLightsSpotsPosition
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	PositionObjectLevel Point3D
	PositionObjectLevelError Point3DError (optional)
	NumberOfValidLaneRelevanceClassifications uint8_t
	ValidLaneRelevanceClassificationList ValidLaneRelevanceClassificationVector
Derived from	-
Description	Represents the Traffic Light Spot position.



9.1.4.43 TrafficLightSpot

[SWS_ADI_00443]{DRAFT}

Name	TrafficLightSpot
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	TrafficLightsSpotsStatus SubObjectStatus
	TrafficLightsSpotsInformation TrafficLightsSpotsInformation
	TrafficLightsSpotsColour TrafficLightsSpotsColour
	TrafficLightsSpotsPosition TrafficLightsSpotsPosition
Derived from	-
Description	Represents the traffic light sopt Information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.44 TrafficLightSpotVector

[SWS_ADI_00444]{DRAFT}

Name	TrafficLightSpotVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	TrafficLightSpot
Derived from	
Description	Represents a list of traffic light spot.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.45 TrafficLightSpots

[SWS_ADI_00445]{DRAFT}

Name	TrafficLightSpots
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	TotalNumberOfTrafficLightSpots uint8_t (optional)
	TotalNumberOfTrafficLightSpotsConfidence ProbabilityPercentage (optional)
	NumberOfValidTrafficLightSpots uint8_t
	ValidTrafficSLightSpotList TrafficLightSpotVector
Derived from	-
Description	Represents the trafic light spots Information.



9.1.4.46 TrafficLight

[SWS_ADI_00446]{DRAFT}

Name	TrafficLight		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	TrafficLightsStatus ObjectStatus		
	StructureLightsInformation TrafficLightsInformation		
	TrafficLightsPosition TrafficLightsPosition		
	TrafficLightsBoundingBox BoundingBox (optional)		
	TrafficLightsSpots TrafficLightSpots		
Derived from	-		
Description	Represents the traffic light Information.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.47 ValidTrafficLightVector

[SWS_ADI_00447]{DRAFT}

Name	ValidTrafficLightVector	
Namespace	ara::adi::sensoritf	
Kind	/ECTOR	
Subelements	TrafficLight	
Derived from	-	
Description	Represents a list of traffic light.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.48 TrafficLights

[SWS_ADI_00448]{DRAFT}

Name	TrafficLights		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	RecognisedTrafficLightsCapability uint16_t (optional)		
	RecognisedTrafficLightsStatus RecognizedStatus (optional)		
	NumberOfValidTrafficLights uint8_t		
	TrafficLightList ValidTrafficLightVector		
Derived from	-		
Description	Represents the traffic lights Information.		



](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.49 StaticObjectInterface

[SWS ADI 00449]{DRAFT}

Name	StaticObjectInterface		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	RoadObjectInterfaceHeader InterfaceHeader		
	StaticObjectGeneralLandmarks GeneralLandmarks (optional)		
	StaticObjectTrafficSigns TrafficSigns (optional)		
	StaticObjectTrafficLights TrafficLights (optional)		
Derived from	-		
Description	Represents the static object informaiton provided by a camera, lidar, radar or Ultrasonic sensor.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.50 ValidSupplementarySignClassificationVector

[SWS_ADI_00450]{DRAFT}

Name	ValidSupplementarySignClassificationVector		
Namespace	ara::adi::sensoritf		
Kind	VECTOR		
Subelements	SupplementarySignClassification		
Derived from	-		
Description	Represents a list of Supplementary sign classification.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.51 ValidMainSignClassificationVector

[SWS_ADI_00451]{DRAFT}

Name	ValidMainSignClassificationVector	
Namespace	ara::adi::sensoritf	
Kind	VECTOR	
Subelements	MainSignClassification	





Derived from	•	
Description	Represents a list of sign classification.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.52 ValidLaneRelevanceClassificationVector

[SWS ADI 00452]{DRAFT}

Name	ValidLaneRelevanceClassificationVector		
Namespace	ara::adi::sensoritf		
Kind	VECTOR		
Subelements	LaneRelevanceClassification		
Derived from	-		
Description	Represents a list of lane Revelance classification.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.53 LightShapeClassificationVector

[SWS_ADI_00453]{DRAFT}

Name	LightShapeClassificationVector	
Namespace	ra::adi::sensoritf	
Kind	TOR	
Subelements	LightShapeClassification	
Derived from	-	
Description	Represents the list of light shape classification	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.4.54 ValidStructureLightClassificationsVector

[SWS_ADI_00454]{DRAFT}

Name	ValidStructureLightClassificationsVector	
Namespace	ara::adi::sensoritf	
Kind	VECTOR	
Subelements	StructureLightClassification	





Derived from	-	
Description	Represents the list of valid structure light classification	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5 Feature Level Interface Definition

This section lists all the data types used in Camera feature and Ultrasonic feature interfaces.

9.1.5.1 ShapeType

[SWS_ADI_00601]{DRAFT}

Name	ShapeType	ShapeType		
Namespace	ara::adi::sensorit	ara::adi::sensoritf		
Kind	TYPE_REFERE	NCE		
Derived from	uint8_t	uint8_t		
Description	Classification of t	Classification of the general landmark.		
Range / Symbol	Limit	Description		
kPoint	0x00	Shape is a point.		
kBox	0x01	Shape is a box (2 or 3 points).		
kEllipse	0x02	Shape is an ellipse (2 or 3 points).		
kPolygon	0x03	Shape is a polygon (3 or more points).		
kPolyline	0x04	Shape is a polyline (2 or more points).		
kPointCloud	0x05	Shape is a point cloud (2 or more points).		
kUnknown	0x06	Shape type is unknown.		

\((RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)\)

9.1.5.2 ShapeClassificationType

[SWS ADI 00602]{DRAFT}

Name	ShapeClassificationType	
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFERENCE	
Derived from	uint8_t	
Description	The classification type for the shape.	
Range / Symbol	Limit	Description





kBackground	0x00	Shape is classified as background entity.
kForeground	0x01	Shape is classified as foreground entity.
kFlat	0x02	Shape is classified as flat entity.
kUpright	0x03	Shape is classified as upright entity.
kGround	0x04	Shape is classified as ground entity.
kBuilding	0x05	Shape is classified as building entity.
kVegetation	0x06	Shape is classified as vegetation entity.
kRoad	0x07	Shape is classified as road entity.
kNonRoad	0x08	Shape is classified as non-road entity.
kSidewalk	0x09	Shape is classified as sidewalk entity.
kPedestrian	0x0A	Shape is classified as pedestrian entity.
kVehicle	0x0B	Shape is classified as vehicle entity.
kTrafficSign	0x0C	Shape is classified as traffic sign entity.
kPedestrianFront	0x0D	Shape is classified as pedestrian front-view entity.
kPedestrianSide	0x0E	Shape is classified as pedestrian side-view entity.
kPedestrianRear	0x0F	Shape is classified as pedestrian rear-view entity.
kUnknown	0x10	Shape Class type is unknown.

| (RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.3 UltrasonicFeatureClassificationType

[SWS_ADI_00603]{DRAFT}

Name	UltrasonicFea	UltrasonicFeatureClassificationType	
Namespace	ara::adi::sens	oritf	
Kind	TYPE_REFE	RENCE	
Derived from	uint8_t	uint8_t	
Description	Ultrasonic fea feature.	Ultrasonic feature type contains information about the current measurement of this feature.	
Range / Symbol	Limit	Description	
kPoint	0x00	Defined by one point.	
kLineSegment	0x01	Defined by two or more points.	
kUnknown	0x02	The Ultrasonic feature type is unknown.	

| (RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.5.4 TrilaterationStatus

[SWS_ADI_00606]{DRAFT}

Name	TrilaterationSta	atus	
Namespace	ara::adi::sensc	ritf	
Kind	TYPE_REFER	TYPE_REFERENCE	
Derived from	uint8_t	uint8_t	
Description	Information if f	Information if feature is trilaterated with multiple signal ways or is not trilaterated.	
Range / Symbol	Limit	Description	
kNormal	0x00	The 2D position {x, y} measurement is based on at least three points.	
kNotTrilaterated	0x01	The 2D position {x, y} measurement is based on less than three points.	
kUnknown	0x02	The trilateration status is unknown.	

(RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.5 MeasurementStatusFeature

[SWS_ADI_00607]{DRAFT}

Name	MeasurementStat	MeasurementStatusFeature	
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFEREN	ICE	
Derived from	uint8_t		
Description	Information about the measurement status of the feature.		
Range / Symbol	Limit	Description	
kInitialization	0x00	No information available.	
kTracked	0x01	Not measured in this cycle.	
kMeasured	0x02	Current position of this feature was measured.	
kDelete	0x03	Tracking will be deleted in the next cycle.	
kNew	0x04	Shape is a polyline (2 or more points).	
kUnknown	0x05	The measurement status is unknown.	

](RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.6 ShapeClassification

[SWS_ADI_00608]{DRAFT}

Name	ShapeClassification	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	ShapeClassificationType ShapeClassificationType	
	ShapeClassificationTypeConfidence ProbabilityPercentage	





Derived from	-
Description	Represents the shape class type information.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.7 ValidShapeClassificationsVector

[SWS ADI 00609]{DRAFT}

Name	ValidShapeClassificationsVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ShapeClassification
Derived from	-
Description	Represents a list of shape class type information.

\((RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)\)

9.1.5.8 CameraFeaturesShapeInformation

[SWS_ADI_00610]{DRAFT}

Name	CameraFeaturesShapeInformation	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	NumberOfValidShapeClassificationsFeatureLevel uint8_t	
	ValidShapeClassificationsList ValidShapeClassificationsVector	
Derived from	-	
Description	Represents the shape related information.	

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.9 ShapePoint

[SWS_ADI_00611]{DRAFT}

Name	ShapePoint	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	PointExistenceProbability ProbabilityPercentage	
	Position Point3D	
	PositionError Point3DError	





Derived from	-
Description	Represents the Shape points information.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.10 ValidShapePointVector

[SWS ADI 00612]{DRAFT}

Name	ValidShapePointVector	
Namespace	ara::adi::sensoritf	
Kind	VECTOR	
Subelements	ShapePoint	
Derived from	-	
Description	Represents a list of shape point information.	

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.11 ShapePoints

[SWS_ADI_00613]{DRAFT}

Name	ShapePoints
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	ShapeType ShapeType
	NumberOfValidShapePoints uint16_t
	ValidShapePointsList ValidShapePointVector
Derived from	-
Description	Represents the Shape points related information.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.12 ShapeReferencePoint

[SWS_ADI_00614]{DRAFT}

Name	ShapeReferencePoint
Namespace	ara::adi::sensoritf
Kind	STRUCTURE





Subelements	PointExistenceProbability ProbabilityPercentage
	Position Point3D
	PositionError Point3DError
	ShapeSurfaceNormal Point3D (optional)
	ShapeSurfaceNormalErroor Point3DError (optional)
	TranslationRate Point 3D (optional)
	TranslationRateError Point3DError (optional)
	RotationRate Orientation3D (optional)
	RotationRateError Orientation3DError (optional)
	ScaleChange float (optional)
	ScaleChangeError float (optional)
Derived from	-
Description	Represents the Shape reference points information.

| (RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.13 ValidShapeReferencePointVector

[SWS_ADI_00615]{DRAFT}

Name	ValidShapeReferencePointVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ShapeReferencePoint
Derived from	-
Description	Represents a list of shape Reference point information.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.14 ShapeReferencePoints

[SWS_ADI_00616]{DRAFT}

Name	ShapeReferencePoints
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidShapeReferencePointsFeatureLevel uint8_t
	ShapeReferencePointsList ValidShapeReferencePointVector
Derived from	-
Description	Represents the Shape Reference points related information.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.5.15 FeatureStatus

[SWS_ADI_00617]{DRAFT}

Name	FeatureStatus
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	ExistenceProbabilityFeatureLevel ProbabilityPercentage
	FeatureId uint16_t (optional)
	FeatureGroupingId uint16_t (optional)
	ObjectIdReferenceFeatureLevel uint16_t (optional)
	TimeStampDifferenceFeatureLevel uint64_t
	NumberOfValidObservationsFeatureLevel uint8_t (optional)
	ValidObservations ValidObservationVector (optional)
Derived from	-
Description	Represents the dynamics of the features.

](RS_ADI_00001, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.16 CameraFeature

[SWS_ADI_00618]{DRAFT}

Name	CameraFeature
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	CameraFeatureStatus FeatureStatus
	CameraFeaturesShapeInformation CameraFeaturesShapeInformation
	CameraFeaturesShapeColourTone ColourTone
	CameraFeaturesShapePoints ShapePoints
	CameraFeaturesShapeReferencePoints ShapeReferencePoints (optional)
Derived from	-
Description	Represents the Camera feature information.

](RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.17 ValidCameraFeatureVector

[SWS_ADI_00619]{DRAFT}

Name	ValidCameraFeatureVector
Namespace	ara::adi::sensoritf
Kind	VECTOR





Subelements	CameraFeature
Derived from	-
Description	Represents a list of camerqa feature information.

(RS ADI 00001, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.5.18 CameraFeatureInterface

[SWS_ADI_00620]{DRAFT}

Name	CameraFeatureInterface
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	CameraFeatureInterfaceHeader InterfaceHeader
	RecognisedFeaturesCapability uint32_t (optional)
	RecognisedFeaturesStatus RecognizedStatus (optional)
	NumberOfValidFeatures uint32_t
	ValidCameraFeaturesList ValidCameraFeatureVector
Derived from	-
Description	Represents the camera feature interface information.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.19 UltrasonicSegmentInformation

[SWS_ADI_00621]{DRAFT}

Name	UltrasonicSegmentInformation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidUltrasonicFeatureClassifications uint8_t
	ValidUltrasonicFeatureClassificationsList ValidUltrasonicFeatureClassificationVector
Derived from	-
Description	Represents the segment information.

(RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.5.20 UltrasonicFeatureClassification

[SWS_ADI_00622]{DRAFT}

Name	UltrasonicFeatureClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	UltrasonicFeatureClassificationType UltrasonicFeatureClassificationType
	UltrasonicFeatureClassificationTypeConfidence ProbabilityPercentage
Derived from	-
Description	Represents the Ultrasonic segmengt type information.

|(RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.21 SegmentPoint

[SWS_ADI_00623]{DRAFT}

Name	SegmentPoint		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	Position Point3D		
	PositionError Point3DError		
	OrientationPitch float (optional)		
	OrientationPitchError float (optional)		
	Height float (optional)		
	HeightError float (optional)		
	VelocityUltrasonic Point2D (optional)		
	VelocityUltrasonicError Point2DError (optional)		
	TrilaterationStatus TrilaterationStatus		
	$Measurement Status Feature \ Level \ {\tt MeasurementStatusFeature} \ (optional)$		
Derived from	-		
Description	Represents the valid segment point information.		

](RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.22 ValidSegmentPointVector

[SWS_ADI_00624]{DRAFT}

Name	ValidSegmentPointVector	
Namespace	ara::adi::sensoritf	
Kind	VECTOR	
Subelements	SegmentPoint	





Derived from	-	
Description	Represents a list of segment points information.	

](RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.23 UltrasonicSegmentPoints

[SWS ADI 00625]{DRAFT}

Name	UltrasonicSegmentPoints		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	NumberOfValidPoints uint16_t		
	ValidSegmentPointsList ValidSegmentPointVector		
Derived from	-		
Description	Represents the segment points information.		

(RS ADI 00004, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.5.24 UltrasonicFeature

[SWS_ADI_00626]{DRAFT}

Name	UltrasonicFeature		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	UltrasonicFeaturesStatus FeatureStatus		
	UltrasonicFeaturesSegmentInformation UltrasonicSegmentInformation		
	${\bf Ultrasonic Features Segment Points} \ {\bf Ultrasonic Segment Points}$		
Derived from	-		
Description	Represents the Ultrasonic feature information.		

(RS ADI 00004, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.5.25 ValidUltrasonicFeatureVector

[SWS_ADI_00627]{DRAFT}

Name	ValidUltrasonicFeatureVector	
Namespace	ara::adi::sensoritf	
Kind	VECTOR	
Subelements	UltrasonicFeature	





Derived from	-	
Description	Represents a list of Ultrasonic feature information.	

(RS ADI 00004, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.5.26 UltrasonicFeatureInterface

[SWS ADI 00628]{DRAFT}

Name	UltrasonicFeatureInterface		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	UltrasonicFeatureInterfaceHeader InterfaceHeader		
	RecognisedFeaturesCapability uint32_t (optional)		
	RecognisedFeaturesStatus RecognizedStatus (optional)		
	NumberOfValidFeatures uint32_t		
	ValidUltrasonicFeatureSList ValidUltrasonicFeatureVector		
Derived from	-		
Description	Represents the Ultrasonic feature interface information.		

|(RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.5.27 ValidUltrasonicFeatureClassificationVector

[SWS_ADI_00629]{DRAFT}

Name	ValidUltrasonicFeatureClassificationVector		
Namespace	ara::adi::sensoritf		
Kind	ECTOR		
Subelements	UltrasonicFeatureClassification		
Derived from	-		
Description	Represents a list of Ultrasonic feature classification information.		

|(RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6 Detection Level Interface Definition

This section lists all the data types used in Lidar, Radar, Camera, and Ultrasonic Detection interfaces.



9.1.6.1 Position3DSpheric

[SWS_ADI_00701]{DRAFT}

Name	Position3DSpheric	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	elevation float	
	azimuth float	
	distance float (optional)	
Derived from	-	
Description	Represents a 3 dimension vector, the unit will be vary according to the refering data type.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.2 Position3DSphericError

[SWS_ADI_00702]{DRAFT}

Name	Position3DSphericError		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	elevation float		
	azimuth float		
	distance float (optional)		
Derived from	-		
Description	Error values of the {Azimuth, Elevation, Distance} to the Position {Azimuth, Elevation, Distance}.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.3 DetectionClassificationType

[SWS_ADI_00703]{DRAFT}

Name	DetectionClassificationType			
Namespace	ara::adi::sensoritf	ara::adi::sensoritf		
Kind	TYPE_REFEREN	TYPE_REFERENCE		
Derived from	uint8_t			
Description	The classification type for the shape.			
Range / Symbol	Limit Description			
kNoClassification	0x00	Detection entity is not classified.		





kNoise	0x01	Detection entity is noise.
kObstacle	0x02	Detection entity is an obstacle for vehicle.
kUnderdriveable	0x03	Detection entity is underdrivable for vehicle.
kOverdrivable	0x04	Detection entity is overdrivable for vehicle.
kNearest	0x05	Detection entity is the nearest detection of a measurement.
kStrongest	0x06	Detection entity has the strongest signal of a measurement.
kUnknown	0x07	The detection type is unknown.

](RS_ADI_00002, RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.4 DetectionsPosition

[SWS_ADI_00704]{DRAFT} [

Name	DetectionsPosition
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	DetectionPosition Position3DSpheric
	DetectionPositionError Position3DSphericError
Derived from	-
Description	Represents the position of the detections.

|(RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.5 UltrasonicDetectionsPosition

[SWS_ADI_00705]{DRAFT}

Name	UltrasonicDetectionsPosition
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Distance float
	Distance Error float
	HeightUltrasonic float (optional)
	HeightUltrasonicError float (optional)
Derived from	-
Description	Represents the position of the detections.

(RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.6.6 DetectionStatus

[SWS_ADI_00706]{DRAFT}

Name	DetectionStatus
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	ExistenceProbabilityDetectionLevel ProbabilityPercentage
	ObjectID uint16_t (optional)
	FeatureID uint16_t (optional)
	TimeStampDifferenceDetectionLevel uint 64_t
Derived from	•
Description	Represents the dynamics of the detections.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.7 DetectionClassification

[SWS ADI 00707]{DRAFT}

Name	DetectionClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	DetectionClassificationType DetectionClassificationType (optional)
	DetectionClassificationTypeConfidence ProbabilityPercentage (optional)
Derived from	-
Description	Represents the detection class type information.

(RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.8 ValidDetectionClassificationVector

[SWS ADI 00708]{DRAFT}

Name	ValidDetectionClassificationVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	DetectionClassification
Derived from	-
Description	Represents a list of detection class type information.

(RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.6.9 RadarDetectionsInformation

[SWS_ADI_00709]{DRAFT}

Name	RadarDetectionsInformation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	RadarCrossSection float
	RadarCrossSectionError float (optional)
	SignalToNoiseRatioDetectionLevel float
	SignalToNoiseRatioDetectionLevelError float (optional)
	MultiTargetProbability ProbabilityPercentage (optional)
	AmbiguityID uint16_t (optional)
	DetectionAmbiguityProbabilityProbabilityPercentage (optional)
	FreeSpaceProbability ProbabilityPercentage (optional)
	NumberOfValidDetectionClassifications uint8_t (optional)
	ValidDetectionClassificationList ValidDetectionClassificationVector (optional)
Derived from	-
Description	Represents the radar detection information.

|(RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.10 RadarDetection

[SWS_ADI_00710]{DRAFT}

Name	RadarDetection
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	RadarDetectionsStatus DetectionStatus
	RadarDetectionsInformation RadarDetectionsInformation
	RadarDetectionsPosition DetectionsPosition
	RadarDetectionsDynamics DetectionsDynamics
Derived from	-
Description	Represents the Radar detection information.

(RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.6.11 ValidRadarDetectionVector

[SWS_ADI_00711]{DRAFT}

Name	ValidRadarDetectionVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	RadarDetection
Derived from	-
Description	Represents a list of radar detection information.

(RS ADI 00003, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.6.12 DetectionsDynamics

[SWS_ADI_00712]{DRAFT}

Name	DetectionsDynamics
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	RelativeVelocityRadialDistance float
	RelativeVelocityRadialDistanceError float (optional)
Derived from	-
Description	Represents the dynamics of the detections.

](RS_ADI_00002, RS_ADI_00003, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.13 RadarDetectionsInterface

[SWS_ADI_00714]{DRAFT}

Name	RadarDetectionsInterface
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	RadarDetectionInterfaceHeader InterfaceHeader
	RecognisedDetectionsCapability uint32_t (optional)
	RecognizedDetectionsStatus RecognizedStatus (optional)
	NumberOfValidDetections uint32_t
	ValidRadarDetectionsList ValidRadarDetectionVector
Derived from	-
Description	Represents the radar detection interface information.

(RS ADI 00003, RS ADI 00012, RS ADI 00013, RS ADI 00014)



9.1.6.14 LidarDetectionsInformation

[SWS_ADI_00715]{DRAFT}

Name	LidarDetectionsInformation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Reflectivity float
	ReflectivityError float (optional)
	FreeSpaceProbability ProbabilityPercentage (optional)
	NumberOfValidDetectionClassifications uint8_t (optional)
	ValidDetectionClassificationList ValidDetectionClassificationVector (optional)
Derived from	-
Description	Represents the lidar detection information.

(RS ADI 00002, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.6.15 LidarDetection

[SWS_ADI_00716]{DRAFT}

Name	LidarDetection
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	LidarDetectionStatus DetectionStatus
	LidarDetectionsInformation LidarDetectionsInformation
	LidarDetectionsPosition LidarDetectionsPosition
	LidarDetectionsDynamics DetectionsDynamics
Derived from	-
Description	Represents the lidar detection information.

(RS ADI 00002, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.6.16 ValidLidarDetectionVector

[SWS_ADI_00717]{DRAFT}

Name	ValidLidarDetectionVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	LidarDetection
Derived from	-
Description	Represents a list of lidar detection information.

|(RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.6.17 LidarDetectionsPosition

[SWS_ADI_00718]{DRAFT}

Name	LidarDetectionsPosition
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	DetectionPosition Position3DSpheric
	DetectionPositionError Position3DSphericError
	HeightLidar float (optional)
	HeightLidarError float (optional)
Derived from	-
Description	Represents the position of the detections.

\((RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)\)

9.1.6.18 LidarDetectionsInterface

[SWS_ADI_00719]{DRAFT}

Name	LidarDetectionsInterface
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	LidarDetectionInterfaceHeader InterfaceHeader
	RecognisedDetectionsCapability uint32_t (optional)
	RecognizedDetectionsStatus RecognizedStatus (optional)
	NumberOfValidLidarDetections uint32_t
Derived from	-
Description	Represents the lidar detection interface information.

(RS_ADI_00002, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.19 DetectionShapeClassification

[SWS_ADI_00720]{DRAFT}

Name	DetectionShapeClassification
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	ShapeClassificationTypeDetectionLevel ShapeClassificationType
	ShapeClassificationTypeConfidenceDetectionLevel ProbabilityPercentage
Derived from	-
Description	Represents the shape classification type information.

](RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.6.20 ValidDetectionShapeClassificationVector

[SWS_ADI_00721]{DRAFT}

Name	ValidDetectionShapeClassificationVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	DetectionShapeClassification
Derived from	-
Description	Represents a list of shape class type information.

\((RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)\)

9.1.6.21 CameraShapesShapeInformation

$\textbf{[SWS_ADI_00722]} \{ \texttt{DRAFT} \} \; \lceil \;$

Name	CameraShapesShapeInformation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	FreeSpaceProbability ProbabilityPercentage (optional)
	NumberOfValidShapeClassificationsDetectionLevel uint8_t
	ValidShapeClassificationsList ValidDetectionShapeClassificationVector
	ShapeAmbiguityID uint16_t (optional)
Derived from	-
Description	Represents the Camera detection related information.

(RS ADI 00001, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.6.22 ShapePointDetectionLevel

[SWS_ADI_00723]{DRAFT}

Name	ShapePointDetectionLevel
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	PointExistenceProbabilityDetectionLevel ProbabilityPercentage
	Position Position3DSpheric
	PositionError Position3DSphericError
Derived from	-
Description	Represents the Shape point information.

\((RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)\)



9.1.6.23 ValidShapePointDetectionLevelVector

[SWS_ADI_00724]{DRAFT}

Name	ValidShapePointDetectionLevelVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ShapePointDetectionLevel
Derived from	-
Description	Represents a list of shape point information.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.24 CameraShapesShapePoints

[SWS_ADI_00725]{DRAFT}

Name	CameraShapeShapePoints
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	ShapeTypeDetectionLevel ShapeType
	NumberOfValidShapePointsDetectionLevel uint16_t
	ValidShapePointsDetectionLevelList ValidShapePointDetectionLevelVector
Derived from	-
Description	Represents the Shape points related information.

\((RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)\)

9.1.6.25 CameraShape

[SWS_ADI_00726]{DRAFT}

Name	CameraShape
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	CameraShapesStatus DetectionStatus
	CameraShapeInformation CameraShapesShapeInformation
	CameraShapeSolourTone ColourTone
	CameraShapePoints CameraShapeShapePoints
	CameraShapeReferencePoints CameraShapesShapeReferencePoints (optional)
Derived from	-
Description	Represents the Camera detection information.

|(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.6.26 ValidCameraShapeVector

[SWS_ADI_00727]{DRAFT}

Name	ValidCameraShapeVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	CameraShape
Derived from	
Description	Represents a list of Camera detection information.

|(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.27 ShapeReferencePointDetectionLevel

[SWS_ADI_00728]{DRAFT}

Name	ShapeReferencePointDetectionLevel
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	PointExistenceProbabilityDetectionLevel ProbabilityPercentage
	Position Position3DSpheric
	PositionError Position3DSphericError
	TranslationRate Point 3D (optional)
	TranslationRateError Point3DError (optional)
Derived from	-
Description	Represents the Shape reference point information.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.28 ValidShapeReferencePointDetectionLevelVector

[SWS ADI 00729]{DRAFT}

Name	ValidShapeReferencePointDetectionLevelVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	ShapeReferencePointDetectionLevel
Derived from	-
Description	Represents a list of shape reference point information.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.6.29 CameraShapesShapeReferencePoints

[SWS_ADI_00730]{DRAFT}

Name	CameraShapeShapeReferencePoints
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidShapeReferencePointsDetectionLevel uint16_t
	ValidShapeReferencePointsPointsDetectionLevelList ValidShapeReferencePointDetectionLevelVector
Derived from	
Description	Represents the Shape reference points related information.

|(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.30 CameraDetectionsInterface

[SWS_ADI_00731]{DRAFT}

Name	CameraDetectionsInterface
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	CameraDetectionInterfaceHeader InterfaceHeader
	RecognizedDetectionsCap uint32_t (optional)
	RecognizedDetectionsStatus RecognizedStatus (optional)
	NumberOfValidShapes uint32_t
	ValidCameraDetectionList ValidCameraShapeVector
Derived from	-
Description	Represents the Camera detection interface information.

(RS_ADI_00001, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.31 UltrasonicDetectionsInformation

[SWS_ADI_00732]{DRAFT}

Name	UltrasonicDetectionsInformation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	SecondSensorIdReference float (optional)
	Reflectivity float (optional)
Derived from	-
Description	Represents the Ultrasonic detection information.

(RS ADI 00004, RS ADI 00012, RS ADI 00013, RS ADI 00014)



9.1.6.32 UltrasonicDetection

[SWS_ADI_00733]{DRAFT}

Name	UltrasonicDetection
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	UltrasonicDetectionStatus DetectionStatus
	UltrasonicDetectionsInformation UltrasonicDetectionsInformation
Derived from	-
Description	Represents the Ultrasonic detection information.

(RS ADI 00004, RS ADI 00012, RS ADI 00013, RS ADI 00014)

9.1.6.33 ValidUltrasonicDetectionVector

[SWS_ADI_00734]{DRAFT}

Name	ValidUltrasonicDetectionVector
Namespace	ara::adi::sensoritf
Kind	VECTOR
Subelements	UltrasonicDetection
Derived from	-
Description	Represents a list of Ultrasonic detection information.

(RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.6.34 UltrasonicDetectionsInterface

[SWS_ADI_00735]{DRAFT}

Name	UltrasonicDetectionsInterface
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	UltrasonicDetectionsInterfaceHeader InterfaceHeader
	RecognizedDetectionsCap uint8_t (optional)
	RecognizedDetectionsStatus RecognizedStatus (optional)
	NoValidDetections uint32_t
	ValidUltrasonicDetectionList ValidUltrasonicDetectionVector
Derived from	-
Description	Represents the Ultrasonic detection interface information.

|(RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)



9.1.7 Supportive Sensor Interfaces Definition

This section lists all the data types used in Supportive Sensor interfaces.

9.1.7.1 SegmentAzimuth

[SWS_ADI_00501]{DRAFT}

Name	SegmentAzimuth
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Begin float
	End float
Derived from	-
Description	FOV defined by opening angles in sensor XY-plane. (rad, rad)

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.2 SegmentElevation

[SWS ADI 00502]{DRAFT}

Name	SegmentElevation
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Begin float
	End float
Derived from	-
Description	FOV defined by opening angles in sensor XZ-plane. (rad, rad)

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.3 AnglePoint3D

[SWS_ADI_00503]{DRAFT}

Name	AnglePoint3D
Namespace	ara::adi::sensoritf
Kind	STRUCTURE





Subelements	RadialDistance float
	Azimuth float
	Elevation float
Derived from	-
Description	The angle point, and the units are depending on the specific use cases.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.4 BeamDivergence

[SWS_ADI_00504]{DRAFT}

Name	BeamDivergence
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Azimuth float
	Elevation float
Derived from	-
Description	The Beam divergence {azimuth, elevation} of the sensor within the specified segment is the full width at half maximum (FWHM) of the beam (given as the angle in rad).(rad, rad)

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.5 SegmentsStatus

[SWS_ADI_00505]{DRAFT}

Name	SegmentsStatus
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	SegmentAzimuthInformation SegmentAzimuth
	SegmentElevationInformation SegmentElevation
	MeasurementGridResolutionInformation AnglePoint3D (optional)
	BeamDivergence BeamDivergence (optional)
	RangeGain ProbabilityPercentage (optional)
	Blockage BlockageStatus
Derived from	-
Description	Represents the sensor performance information.

(RS ADI 00004, RS ADI 00012, RS ADI 00013, RS ADI 00014)



9.1.7.6 BlockageStatus

[SWS_ADI_00506]{DRAFT}

Name	BlockageStatus		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFEREN	ICE	
Derived from	uint8_t	uint8_t	
Description	Defines the overa	Il blockage of the FOV segment.	
Range / Symbol	Limit	Description	
kFullBlockage	0x00	The sensor is completely blocked, no more feature and functionality working due to blockage condition.	
kPartialBlockageHighImpact	0x01	The sensor has detected a blockage condition which has a significant impact on sensor performance (e.g. range).	
kPartialBlockageMediumImpact	0x02	The sensor has detected a blockage condition which already has impact on sensor performance (e.g. range).	
kPartialBlockageLowImpact	0x03	The sensor detects that a blockage condition is present or is increasing, but the degree of blockage has not yet had a significant impact on sensor performance and functionality.	
kDefect	0x04	The full specified range is blocked, due to e.g. a pixel defect. This segment may overlap with other segments.	
kNone	0x05	Normal mode.	
kUnknown	0x06	The blockage Status is unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.7 FieldOfViewReduction

[SWS_ADI_00507]{DRAFT}

Name	FieldOfViewReduction	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	NumberOfValidFieldOfViewReductionReasons uint8_t	
	ValidFieldOfViewReductionReasonsList	
	ValidFieldOfViewReductionReasonsVector	
Derived from	-	
Description	Represents the FOV reduction related information.	



9.1.7.8 FieldOfViewReductionReasonType

[SWS_ADI_00508]{DRAFT}

Name	FieldOfViewRed	uctionReasonType
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFERE	NCE
Derived from	uint8_t	
Description	Defines the over	all blockage of the FOV segment.
Range / Symbol	Limit	Description
kSnow	0x00	Range reduction due to snow.
kRain	0x01	Range reduction due to rain.
kClutter	0x02	Range reduction due to clutter.
kFlyingLeaves	0x03	Range reduction due to flying leaves.
kNightAndLights	0x04	Range reduction due to night and lights.
kShades	0x05	Range reduction due to shades.
kContrastIssues	0x06	Range reduction due to contrast issues.
kJamming	0x07	Range reduction, e.g. electromagnetic compatibility.
kDeviceInterference	0x08	Range reduction, e.g. electromagnetic compatibility.
kSand	0x09	Range reduction due to sand.
kWetRoads	0x0A	Range reduction due to wet roads.
kGhosts	0x0B	Range reduction due to ghosts.
kSnowOnSensorSurface	0x0C	Near range blockage due to snow on the sensor surface.
kWaterOnSensorSurface	0x0D	Near range blockage due to water on the sensor surface.
kSoilOnSensorSurface	0x0E	Near range blockage due to soil on the sensor surface.
kScratchesOnSensorSurface	0x0F	Near range blockage due to scratches on the sensor surface.
kUnknown	0x10	FOV Reduction type is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.9 ValidFieldOfViewReductionReasonsVector

[SWS_ADI_00509]{DRAFT}

Name	ValidFieldOfViewReductionReasonsVector	
Namespace	ara::adi::sensoritf	
Kind	VECTOR	
Subelements	FieldOfViewReductionReasons	
Derived from	-	
Description	Represents a list of FOV reduction reason type information.	



9.1.7.10 FieldOfViewReductionReasons

[SWS_ADI_00510]{DRAFT}

Name	FieldOfViewReductionReasons	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	FOVReductionReasonType FieldOfViewReductionReasonType	
	FieldOfViewReductionReasonTypeConfidence ProbabilityPercentage	
Derived from	-	
Description	Represents the FOV Reduction type information.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.11 RecognizedObjectType

[SWS_ADI_00511]{DRAFT}

Name	RecognizedObject	tType
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFEREN	ICE
Derived from	uint8_t	
Description	Defines the overa	Il blockage of the FOV segment.
Range / Symbol	Limit	Description
kCar	0x00	Recognized entity is a car.
kTruck	0x01	Recognized entity is a truck.
kMotorBike	0x02	Recognized entity is a motor bike.
kBicycle	0x03	Recognized entity is a bicycle.
kPedestrian	0x04	Recognized entity is a pedestrian.
kMovingObject	0x05	Recognized entity is an unknown moving object.
kRoadBoundary	0x06	Recognized entity is a road boundary.
kRoadMarking	0x07	Recognized entity is a road marking.
kStaticObject	0x08	Recognized entity is a static object.
kTrafficSign	0x09	Recognized entity is a traffic sign.
kTrafficLight	0x0A	Recognized entity is a traffic light.
kUnknown	0x0B	The Recognized Object Type is unknown.



9.1.7.12 DetectionRange

[SWS ADI 00512]{DRAFT}

Name	DetectionRange
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	Min float
	Max float
Derived from	-
Description	Sensor detection range for one object type with Minimum classification rate this object type and Maximum false positive rate for this object type. (m, m)

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.13 RecognisableObjectTypes

[SWS_ADI_00513]{DRAFT}

Name	RecognisableObjectTypes	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	RecognisedObjectType RecognizedObjectType	
	DetectionRangeInformation DetectionRange	
	TruePositiveRate ProbabilityPercentage (optional)	
	FalsePositiveRate ProbabilityPercentage (optional)	
	PositivePredictiveValue ProbabilityPercentage (optional)	
Derived from	-	
Description	Represents the Object Detection Rate information.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.14 ValidRecognisableObjectTypesVector

[SWS_ADI_00514]{DRAFT}

Name	ValidRecognisableObjectTypesVector	
Namespace	ara::adi::sensoritf	
Kind	VECTOR	
Subelements	RecognisableObjectTypes	
Derived from	-	
Description	Represents a list of Object Detection Rate information.	



9.1.7.15 RealWorldObjectRecognitionCapabilities

[SWS_ADI_00515]{DRAFT}

Name	RealWorldObjectRecognitionCapabilities	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	NumberOfValidRecognisableObjectTypes uint8_t	
	ValidRecognisableObjectTypesList ValidRecognisableObjectTypesVector	
Derived from	-	
Description	Represents the Object Detection Rate related information.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.16 ReferenceTargetType

[SWS_ADI_00516]{DRAFT}

Name	ReferenceTarget	ReferenceTargetType	
Namespace	ara::adi::sensoritf	ara::adi::sensoritf	
Kind	TYPE_REFEREN	TYPE_REFERENCE	
Derived from	uint8_t		
Description	Provides the classification of the sensor's recognition capabilities for defined reference targets.		
Range / Symbol	Limit	Description	
kPatternA	0x00	The recognised entity is a defined pattern A.	
kPatternB	0x01	The recognised entity is a defined pattern B.	
kPatternC	0x02	The recognised entity is a defined pattern C.	
kUnknown	0x0B	The Reference Target Type is unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.17 ReferenceTargetTypes

[SWS_ADI_00517]{DRAFT}

Name	ReferenceTargetTypes	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	





Subelements	ReferenceTargetType ReferenceTargetType (optional)		
	RadarCrossSectionReferenceTarget float (optional)		
	ReflectivityReferenceTarget float (optional)		
	DetectionRangeInformation DetectionRange		
	TruePositiveRate ProbabilityPercentage (optional)		
	RelativeRadialVelocityRange RelativeRadialVelocityRange (optional)		
	SignalToNoiseRatioSupportiveLevel float		
	SpatialSeparability AnglePoint3D (optional)		
	VelocitySeparability AnglePoint3D (optional)		
Derived from	-		
Description	Represents the Reference Target Rate information.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.18 ValidReferenceTargetTypesVector

[SWS_ADI_00518]{DRAFT}

Name	ValidReferenceTargetTypesVector		
Namespace	ara::adi::sensoritf		
Kind	VECTOR		
Subelements	ReferenceTargetTypes		
Derived from	-		
Description	Represents a list of Reference Target Rate information.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.19 ReferenceTargetRecognitionCapabilities

[SWS_ADI_00519]{DRAFT}

Name	ReferenceTargetRecognitionCapabilities		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	NumberOfValidReferenceTargetTypes uint8_t		
	ValidReferenceTargetTypesList ValidReferenceTargetTypesVector		
Derived from	-		
Description	Represents the Reference Target Rate related information.		



9.1.7.20 RelativeRadialVelocityRange

[SWS_ADI_00520]{DRAFT}

Name	RelativeRadialVelocityRange		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	Begin float		
	End float		
Derived from	-		
Description	Describes the relative radial speed range in the sensor coordinate system.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.21 PeformanceSegment

[SWS_ADI_00521]{DRAFT}

Name	PeformanceSegment		
Namespace	ara::adi::sensoritf		
Kind	STRUCTURE		
Subelements	SegmentsStatus SegmentsStatus		
	FieldOfViewReductionInformation FieldOfViewReduction		
	RealWorldObjectRecognitionCapabilitiesInformation RealWorldObjectRecognitionCapabilities (optional)		
	ReferenceTargetRecognitionCapabilitiesInforamtion ReferenceTargetRecognitionCapabilities (optional)		
Derived from	-		
Description	Represents the Performance sgement information.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.22 SensorOperationMode

[SWS_ADI_00523]{DRAFT}

Name	SensorOperationMode		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFERENCE		
Derived from	uint8_t		
Description	Status information of the sensor.		
Range / Symbol	Limit	Description	
kSensorMeasuringActive	0x00	Sensor is active and performs measurements.	





kSensorMeasuringDisabled	0x01	Sensor is disabled and performs no measurement at the moment.
kSensorMeasuringTestmode	0x02	Sensor is in active measurement mode, however in test mode.
kUnknown	0x03	The Sensor operation mode is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.23 SensorDefectDetected

[SWS_ADI_00524]{DRAFT}

Name	SensorDefectDef	SensorDefectDetected	
Namespace	ara::adi::sensorit	f	
Kind	TYPE_REFEREN	NCE	
Derived from	uint8_t	uint8_t	
Description	Signal for a sens	Signal for a sensor defect is detected.	
Range / Symbol	Limit	Description	
kSensorFullyFunctional	0x00	Sensor has no defects detected.	
kNotFullyFunctionalDueTo Defect	0x01	Sensor has detected defects. Sensor can measure with limited performance.	
kOutOfOrder	0x02	Sensor has detected defects and cannot perform measurements anymore.	
kUnknown	0x03	The sensor defect detected is unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.24 SensorDefectReason

[SWS_ADI_00525]{DRAFT}

Name	SensorDefectReason		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFEREN	ICE	
Derived from	uint8_t	uint8_t	
Description	Signal for detailed information why the signal Sensor defect detected is notifying a sensor problem.		
Range / Symbol	Limit	Description	
kNoDefectDetected	0x00	No defects detected by the sensor.	
kInternalMemoryError	0x01	Sensor has detected an internal memory error.	
kElectronicDefect	0x02	The sensor has detected an electronic defect.	
kThermalDefect	0x03	Sensor has detected a thermal problem error.	
kSurgeDefect	0x04	Sensor has detected a surge defect.	
kCalibrationError	0x05	Sensor has detected a calibration error.	





kImplausibleSensor Parametrisation	0x06	Sensor has detected an implausible parametrisation.
kMechanicalDefect	0x07	Sensor has detected a mechanical defect.
kSoftwareDefect	0x08	Sensor has detected a software defect.
kComputingPowerNotSufficient	0x09	Sensor has detected a to low power supply.
kOutOfTimeSyncronisation	0x10	Sensor has detected an out of time synchronisation.
kSensorExternalDisturbed	0x11	Sensor has detected an external disturbance.
kUnknown	0x12	The sensor defect reason is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.25 ValidSensorOperationModeVector

[SWS_ADI_00526]{DRAFT}

Name	ValidSensorOperationModeVector		
Namespace	ara::adi::sensoritf		
Kind	VECTOR		
Subelements	SensorOperationMode		
Derived from	-		
Description	Represents a list of input singal information.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.26 StatusSupplyVoltage

[SWS_ADI_00527]{DRAFT}

Name	StatusSupplyVoltage			
Namespace	ara::adi::sensoritf	ara::adi::sensoritf		
Kind	TYPE_REFEREN	ICE		
Derived from	uint8_t	uint8_t		
Description	Signal for the current Status supply voltage status.			
Range / Symbol	Limit	Description		
kWithinLimits	0x00	Supply voltage is optimal.		
kLow	0x01	Supply voltage is out of valid range. Supply voltage is too low.		
kPreLow	0x02	Supply voltage still in the valid range, but close to the limit and expected to leave the valid range soon.		
kPreHigh	0x03	Supply voltage still in the valid range, but close to the limit and expected to leave the valid range soon.		
kHigh	0x04	Supply voltage is out of valid range. Supply voltage is too high.		
kUnknown	0x05	The sensor supply voltage status is unknown.		



](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.27 SensorTemperatureStatus

[SWS_ADI_00528]{DRAFT}

Name	SensorTemperatureStatus	
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFEREN	ICE
Derived from	uint8_t	
Description	Signal for the current Sensor temperature status status.	
Range / Symbol	Limit	Description
kUnderTemperature	0x00	No measurement updates available.
kPreUnderTemperature	0x01	Close before under temperature.
kTemperatureInLimits	0x02	Normal mode.
kPreOverTemperature	0x03	Close before over temperature.
kOverTemperature	0x04	No measurement updates available.
kUnknown	0x05	The sensor temperature status is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.28 ValidPeformanceSegmentVector

[SWS_ADI_00529]{DRAFT}

Name	ValidPeformanceSegmentVector	
Namespace	ara::adi::sensoritf	
Kind	VECTOR	
Subelements	PeformanceSegment	
Derived from	-	
Description	Represents a list of performance segment information.	



9.1.7.29 SensorInputSignalType

[SWS_ADI_00530]{DRAFT}

Name	SensorInputSignalType	
Namespace	ara::adi::sensoritf	
Kind	TYPE_REFEREN	ICE
Derived from	uint8_t	
Description	Classification of the Sensor input signal - type , which defines a group of sensor input signals received by the sensor.	
Range / Symbol	Limit	Description
kDynamicMotionControl	0x00	Dynamic motion control sensor input signals.
kVehicleDynamic	0x01	Vehicle dynamic sensor input signals.
kUnknown	0x02	Sensor input signal type is unknown.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.30 SensorInputSignalStatus

[SWS_ADI_00531]{DRAFT}

Name	SensorInputSignalStatus		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFEREN	ICE	
Derived from	uint8_t	uint8_t	
Description	Enumeration if valid input signals for Sensor input signal - type are received by the sensor.		
Range / Symbol	Limit	Description	
kValid	0x00	Normal mode.	
klmplausible	0x01	Signal in context of sensor signals is not plausible compared with other signals or internal calculations.	
kMissing	0x02	Signal was never received.	
kOufOfRange	0x03	Signal violated the signal range.	
kTimeout	0x04	Signal was received, however not in time period as expected.	
kUnknown	0x05	The sensor input signal status is unknown.	



9.1.7.31 SensorExternalDisturbed

[SWS_ADI_00532]{DRAFT}

Name	SensorExternalE	Disturbed	
Namespace	ara::adi::sensorit	ara::adi::sensoritf	
Kind	TYPE_REFERE	NCE	
Derived from	uint8_t		
Description	Signal about the	Signal about the disturbance of the sensor by an external source.	
Range / Symbol	Limit Description		
kFullDisturbance	0x00	The sensor is completely disturbed, no more feature and functionality working due to external disturbance.	
kDisturbanceHighImpact	0x01	The sensor has detected an external disturbance which has a significant impact on sensor performance.	
kDisturbanceMediumImpact	0x02	The sensor has detected an external disturbance which already has impact on sensor performance.	
kDisturbanceLowImpact	0x03	The sensor detects that an external disturbance is present or is increasing, but the degree of disturbance has not yet had a significant impact on sensor performance and functionality.	
kNone	0x04	Normal mode.	
kUnknown	0x05	The sensor external disturbed status is unknown.	

[(RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.32 SensorTransmitPowerReduced

$\hbox{[SWS_ADI_00533]} \{ \hbox{DRAFT} \} \; \lceil \;$

Name	SensorTransmitPo	SensorTransmitPowerReduced	
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFEREN	ICE	
Derived from	uint8_t	uint8_t	
Description	Enumeration if the sensor works with full output power.		
Range / Symbol	Limit	Description	
kNormalOperation	0x00	Transmit output power normal.	
kOutputPowerLimited	0x01	Transmit output power reduced.	
kUnknown	0x02	Sensor Transmit Power status is unknown.	



9.1.7.33 StatusSensorHeating

[SWS_ADI_00534]{DRAFT}

Name	StatusSensorHea	StatusSensorHeating	
Namespace	ara::adi::sensorit	f	
Kind	TYPE_REFEREN	NCE	
Derived from	uint8_t	uint8_t	
Description	Status of the sensor heating.		
Range / Symbol	Limit	Description	
kHeatingOff	0x00	No heating active.	
kHeatingLevel	0x01	Sensor heating active.	
kHeatingError	0x02	Sensor heating is defect.	
kUnknown	0x03	The sensor heating status is unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.34 StatusSensorCleaning

[SWS_ADI_00535]{DRAFT}

Name	StatusSensorCleaning		
Namespace	ara::adi::sensoritf		
Kind	TYPE_REFEREN	NCE	
Derived from	uint8_t	uint8_t	
Description	Status of the sensor cleaning.		
Range / Symbol	Limit	Description	
kCleaningIdle	0x00	Sensor cleaning is not active.	
kCleaningActive	0x01	Sensor cleaning is active	
kCleaningNeeded	0x02	Sensor cleaning should be performed.	
kUnknown	0x03	The sensor cleaning status is unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.35 SensorTimeSync

$\hbox{[SWS_ADI_00536]} \{ \hbox{DRAFT} \} \; \lceil \;$

Name	SensorTimeSync
Namespace	ara::adi::sensoritf
Kind	TYPE_REFERENCE
Derived from	uint8_t





Description	Status of the sen	Status of the sensor time synchronisation.	
Range / Symbol	Limit	Description	
kWithinLimits	0x00	Time synchronization inside limits.	
kOutOfLimits	0x01	Time synchronization time accuracy limits violated.	
kTimeout	0x02	Time synchronization timeout elapsed (no valid time synchronization cycle within timeout interval).	
kOffset	0x03	Time offset value. Requires: Sensor time sync offset value	
kUnknown	0x04	The time synchronization status is unknown.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.36 SensorPerformanceSegments

[SWS_ADI_00537]{DRAFT}

Name	SensorPerformanceSegments
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	NumberOfValidFieldOfViewSegments uint8_t
	ValidPeformanceSegmentsList ValidPeformanceSegmentVector
Derived from	-
Description	Represents the performance segments related information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.37 SensorPerformanceInterface

[SWS_ADI_00538]{DRAFT}

Name	SensorPerformanceInterface
Namespace	ara::adi::sensoritf
Kind	STRUCTURE
Subelements	SensorPerformanceInterfaceHeader InterfaceHeader
	SensorPerformanceSegmentsInformation SensorPerformanceSegments
Derived from	-
Description	Represents the sensor performance interface information.



9.1.7.38 InputSignalStatus

[SWS_ADI_00541]{DRAFT}

Name	InputSignalStatus	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements	InputSignalType SensorInputSignalType	
	InputSingalStatus SensorInputSignalStatus	
Derived from	-	
Description	Represents the input signal information.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.39 ValidInputSignalStatusVector

[SWS_ADI_00542]{DRAFT}

Name	ValidInputSignalStatusVector	
Namespace	ara::adi::sensoritf	
Kind	VECTOR	
Subelements	InputSignalStatus	
Derived from	-	
Description Represents a list of input singal information.		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.40 SensorHealthStatus

[SWS ADI 00543]{DRAFT}

Name	SensorHealthStatus
Namespace	ara::adi::sensoritf
Kind	STRUCTURE





Subelements	NumberOfValidSensorOperationModes uint8_t
	ValidSensorOperationModesList ValidSensorOperationModeVector
	SensorDefectDetectedInformation SensorDefectDetected
	SensorDefectReasonInformation SensorDefectReason
	SupplyVoltageStatus StatusSupplyVoltage
	SensorTemperatureStatus SensorTemperatureStatus
	NumberOfValidSensorInputSignalStatuses uint8_t
	ValidSenorInputSignalStatusList ValidInputSignalStatusVector
	SensorExternalDisturbed SensorExternalDisturbed (optional)
	SensorTransmitPowerReduced SensorTransmitPowerReduced (optional)
	SensorHeatingStatus StatusSensorHeating (optional)
	SensorCleaningStatus StatusSensorCleaning (optional)
	SensorTimeSync SensorTimeSync (optional)
	SensorTimeSyncOffsetValue float (optional)
Derived from	-
Description	Represents the sensor health related information.

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.1.7.41 SensorHealthInformationInterface

[SWS_ADI_00547]{DRAFT}

Name	SensorHealthInformationInterface	
Namespace	ara::adi::sensoritf	
Kind	STRUCTURE	
Subelements SensorHealthInformationInterfaceHeader InterfaceHeader		
	SensorHealthStatusInformation SensorHealthStatus (optional)	
	CalibrationInformation Calibration (optional)	
	SensorCluster SensorCluster (optional)	
Derived from	-	
Description	Represents the sensor Health interface information.	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004, RS_ADI_00012, RS_ADI_00013, RS_ADI_00014)

9.2 Service Interfaces

This chapter lists all provided service interfaces of the ADI.



9.2.1 Sensor Interfaces Port

[SWS_ADI_01000]{DRAFT}

Name	SensorInterface		
Kind	ProvidedPort	Interface	SensorInterface
Description			
Variation			

(RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004)

9.2.2 Object level Interfaces

[SWS_ADI_01001]{DRAFT}

Name	PotentiallyMovingObjectsService	
NameSpace	ara::adi::sensoritf	

Method	Capability	
Description	Get the capability vector of the service.	
FireAndForget	false	
Parameter	CapVector	
	Description	The capability vector of the service indicates the presence of the optional signals of the event.
	Туре	CapabilityVector
	Variation	
	Direction	OUT

Events	PotentiallyMovingObjectInterfaceEvent	
Description	The potentially moving object list is reported by a sensor in a measurement cycle.	
Туре	PotentiallyMovingObjectInterface	

(RS ADI 00001, RS ADI 00002, RS ADI 00003, RS ADI 00004)

[SWS_ADI_01002]{DRAFT}

Name	RoadObjectsService	
NameSpace	ara::adi::sensoritf	

Method	Capability	
Description	Get the capability vector of the service.	
FireAndForget	false	
Parameter	capVector	





Description	The capability vector of the servie indicates the presence of the optional signals of the event.
Туре	CapabilityVector
Variation	
Direction	OUT

Events	RoadObjectInterfaceEvent	
Description	The road object list is reported by a sensor in a measurement cycle.	
Туре	RoadObjectInterface	

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004)

[SWS_ADI_01003]{DRAFT}

Name	StaticObjectsService	
NameSpace	ara::adi::sensoritf	

Method	Capability	
Description	Get the capability vector of the service.	
FireAndForget	false	
Parameter	capVector	
	Description	The capability vector of the servie indicates the presence of the optional signals of the event.
	Туре	CapabilityVector
	Variation	
	Direction	OUT

Events	StaticObjectInterfaceEvent	
Description	The static object list is reported by a sensor in a measurement cycle.	
Туре	StaticObjectInterface	

| (RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004)

9.2.3 Feature level Interfaces

[SWS_ADI_01004]{DRAFT}

Name	CameraFeaturesService	
NameSpace	ara::adi::sensoritf	



Method	Capability	
Description	Get the capability vector of the service.	
FireAndForget	false	
Parameter	capVector	
	Description	The capability vector of the servie indicates the presence of the optional signals of the event.
	Туре	CapabilityVector
	Variation	
	Direction	OUT

Events	CameraFeatureInterfaceEvent	
Description	The camera feature list is reported by a sensor during one measurement cycle.	
Туре	CameraFeatureInterface	

](RS_ADI_00001)

[SWS_ADI_01005]{DRAFT}

Name	UltrasonicFeaturesService	
NameSpace	ara::adi::sensoritf	

Method	Capability	
Description	Get the capability vector of the service.	
FireAndForget	false	
Parameter	capVector	
	Description	The capability vector of the servie indicates the presence of the optional signals of the event.
	Туре	CapabilityVector
	Variation	
	Direction	OUT

Events	UltrasonicFeatureInterfaceEvent	
Description	The Ultrasonic Feature list is reported by a sensor in a measurement cycle.	
Туре	UltrasonicFeatureInterface	

](RS_ADI_00004)

9.2.4 Detection level Interfaces

$\textbf{[SWS_ADI_01006]} \{ \texttt{DRAFT} \} \; \lceil \;$

Name	RadarDetectionsService	
NameSpace	ara::adi::sensoritf	



Method	Capability	
Description	Get the capability vector of the service.	
FireAndForget	false	
Parameter	capVector	
	Description	The capability vector of the servie indicates the presence of the optional signals of the event.
	Туре	CapabilityVector
	Variation	
	Direction	OUT

Events	RadarDetectionsInterfaceEvent	
Description	The radar detection list is reported by a sensor in a measurement cycle.	
Туре	RadarDetectionsInterface	

](RS_ADI_00003)

[SWS_ADI_01007]{DRAFT}

Name	LidarDetectionsService
NameSpace	ara::adi::sensoritf

Method	Capability		
Description	Get the capability	Get the capability vector of the service.	
FireAndForget	false		
Parameter	capVector		
	Description	The capability vector of the servie indicates the presence of the optional signals of the event.	
	Туре	CapabilityVector	
	Variation		
	Direction	OUT	

Events	LidarDetectionsInterfaceEvent	
Description	The Lidar detection list is reported by a sensor in a measurement cycle.	
Туре	LidarDetectionsInterface	

](RS_ADI_00002)

$\hbox{[SWS_ADI_01008]} \{ \hbox{DRAFT} \} \; \lceil \;$

Name	CameraDetectionsService
NameSpace	ara::adi::sensoritf

Method	Capability
Description	Get the capability vector of the service.
FireAndForget	false





Parameter	capVector	
	Description	The capability vector of the servie indicates the presence of the optional signals of the event.
	Туре	CapabilityVector
	Variation	
	Direction	OUT

Events	CameraDetectionsEvent	
Description	The camera detection list is reported by a sensor in a measurement cycle.	
Туре	CameraDetectionsInterface	

](RS_ADI_00001)

$\hbox{[SWS_ADI_01009]} \{ \hbox{DRAFT} \} \; \lceil \;$

Name	UltrasonicDetectionsService	
NameSpace	ara::adi::sensoritf	

Method	Capability		
Description	Get the capability	Get the capability vector of the service.	
FireAndForget	false		
Parameter	capVector		
	Description	The capability vector of the servie indicates the presence of the optional signals of the event.	
	Туре	CapabilityVector	
	Variation		
	Direction	OUT	

Events	UltrasonicDetectionsInterfaceEvent	
Description	The Ultrasonic Detection list is reported by a sensor in a measurement cycle.	
Туре	UltrasonicDetectionsInterface	

](RS_ADI_00004)

9.2.5 Supportive Interfaces

$\textbf{[SWS_ADI_01010]} \{ \texttt{DRAFT} \} \; \lceil \;$

Name	SensorPerformanceService	
NameSpace	ara::adi::sensoritf	



Method	Capability		
Description	Get the capability vector of the service.		
FireAndForget	false		
Parameter	capVector		
	Description	The capability vector of the servie indicates the presence of the optional signals of the event.	
Type CapabilityVector		CapabilityVector	
	Variation		
	Direction	OUT	

Events	SensorPerformanceInterfaceEvent	
Description	The sensor performance information is reported by a sensor.	
Type SensorPerformanceInterface		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004)

[SWS_ADI_01011]{DRAFT}

Name	SensorHealthInformationService	
NameSpace	ara::adi::sensoritf	

Method	Capability			
Description	Get the capability	Get the capability vector of the service.		
FireAndForget	false	false		
Parameter	capVector			
	Description	The capability vector of the servie indicates the presence of the optional signals of the event.		
	Type CapabilityVector			
Variation				
	Direction	OUT		

Events	SensorHealthInformationInterfaceEvent	
Description	The sensor health information is reported by a sensor.	
Type SensorHealthInformationInterface		

](RS_ADI_00001, RS_ADI_00002, RS_ADI_00003, RS_ADI_00004)



10 Capability Configuration

10.1 Object Level Service

10.1.1 PMObjectsService Capability Vector

The table below includes the capability bit setting for the optional elements for PMObjectsService, which also refers to ISO 23150. The Bit setting to 1 means the presence of the optional element, while 0 means absent.

Bit	Reference Singal in ISO23150	Reference Element in PMObjectService	Option
1	Interface ID(A.1.4)	InterfaceId	Autosar Service
2	Cycle Counter(A.1.6.1)	CycleCounter	ara com
3	Interface cycle time(A.1.7)	InterfaceCycleTime	ara com
4	Interface cycle time variation(A.1.8)	InterfaceCycleTimeVariation	ara com
5	Information vehicle coordinate system(Table 46)	InformationVehicleCoordinateSystem	0
6	Information sensor pose(Table 46)	InformationSensorPose	0
7	Sensor origin point x(A.1.22)	SensorOriginPointX	ara com
8	Sensor origin point y(A.1.22)	SensorOriginPointY	ara com
9	Sensor origin point z(A.1.22)	SensorOriginPointZ	ara com
10	Sensor origin point x error(A.1.23)	SensorOriginPointXError	ara com
11	Sensor origin point y error(A.1.23)	SensorOriginPointYError	ara com
12	Sensor origin point z error(A.1.23)	SensorOriginPointZError	ara com
13	Sensor origin point x x error (A.1.23)	SensorOriginPointXXError	ara com
14	Sensor origin point x y error(A.1.23)	SensorOriginPointXYError	ara com
15	Sensor origin point x z error(A.1.23)	SensorOriginPointXZError	ara com
16	Sensor origin point y x error(A.1.23)	SensorOriginPointYXError	ara com
17	Sensor origin point y y error A.1.23)	SensorOriginPointYYError	ara com
18	Sensor origin point y z error (A.1.23)	SensorOriginPointYZError	ara com
19	Sensor origin point z x error(A.1.23)	SensorOriginPointZXError	ara com
20	Sensor origin point z y error (A.1.23)	SensorOriginPointZYError	ara com
21	Sensor origin point z z error (A.1.23)	SensorOriginPointZZError	ara com
22	Sensor orientation yaw(A.1.24)	SensorOrientationYaw	ara com
23	Sensor orientation pitch(A.1.24)	SensorOrientationPitch	ara com
24	Sensor orientation roll(A.1.24)	SensorOrientationRoll	ara com
25	Sensor orientation yaw error(A.1.25)	SensorOrientationYawError	ara com
26	Sensor orientation pitch error(A.1.25)	SensorOrientationPitchError	ara com
27	Sensor orientation roll error(A.1.25)	SensorOrientationRollError	ara com
28	Sensor orientation yaw yaw error (A.1.25)	SensorOrientationYawYawError	ara com
29	Sensor orientation yaw pitch error (A.1.25)	SensorOrientationYawPitchError	ara com
30	Sensor orientation yaw roll error (A.1.25)	SensorOrientationYawRollError	ara com
31	Sensor orientation pitch yaw error (A.1.25)	SensorOrientationPitchYawError	ara com
32	Sensor orientation pitch pitch error (A.1.25)	SensorOrientationPitchPitchError	ara com
33	Sensor orientation pitch roll error (A.1.25)	SensorOrientationPitchRollError	ara com
34	Sensor orientation roll yaw error (A.1.25)	SensorOrientationRollYawError	ara com





D.	Dis Defended Signature 10000150		
Bit	Reference Singal in ISO23150	Reference Element in PMObjectService	Option
35	Sensor orientation roll pitch error (A.1.25)	SensorOrientationRollPitchError	ara com
36	Sensor orientation roll roll error (A.1.25)	SensorOrientationRollRollError	ara com
37	Calibration(Table 48)	Calibration	0
38	Calibration process state(A.5.42)	CalibrationProcessState	ara com
39	Sensor origin point correction x(A.5.43)	SensorOriginPointCorrectionX	ara com
40	Sensor origin point correction y(A.5.43)	SensorOriginPointCorrectionY	ara com
41	Sensor origin point correction z(A.5.43)	SensorOriginPointCorrectionZ	ara com
42	Sensor origin point correction x error(A.5.44)	SensorOriginPointCorrectionXError	ara com
43	Sensor origin point correction y error(A.5.44)	SensorOriginPointCorrectionYError	ara com
44	Sensor origin point correction z error(A.5.44)	SensorOriginPointCorrectionZError	ara com
45	Sensor origin translation correction limit xbegin (A.5.45)	SensorOriginTranslationCorrection- LimitXbegin	ara com
46	Sensor origin translation correction limit xend(A.5.45)	SensorOriginTranslationCorrection- LimitXend	ara com
47	Sensor origin translation correction limit ybegin(A.5.45)	SensorOriginTranslationCorrection- LimitYbegin	ara com
48	Sensor origin translation correction limit yend(A.5.45)	SensorOriginTranslationCorrection- LimitYend	ara com
49	Sensor origin translation correction limit zbe-gin(A.5.45)	SensorOriginTranslationCorrection- LimitZbegin	ara com
50	Sensor origin translation correction limit zend(A.5.45)	SensorOriginTranslationCorrection- LimitZend	ara com
51	Sensor orientation correction yaw(A.5.46)	SensorOrientationCorrectionYaw	ara com
52	Sensor orientation correction pitch(A.5.46)	SensorOrientationCorrectionPitch	ara com
53	Sensor orientation correction roll(A.5.46)	SensorOrientationCorrectionRoll	ara com
54	Sensor orientation correction yaw error(A.5.47)	SensorOrientationCorrectionYawError	ara com
55	Sensor orientation correction pitch error(A.5.47)	SensorOrientationCorrectionPitchError	ara com
56	Sensor orientation correction roll error(A.5.47)	SensorOrientationCorrectionRollEr- ror	ara com
57	Sensor pose angle correction limit yawbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitYaw- begin	ara com
58	Sensor pose angle correction limit yawend(A.5.48)	SensorPoseAngleCorrectionLim- itYawend	ara com
59	Sensor pose angle correction limit pitchbegin(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchbegin	ara com
60	Sensor pose angle correction limit pitchend(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchend	ara com
61	Sensor pose angle correction limit rollbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitRoll-begin	ara com
62	Sensor pose angle correction limit rol- lend(A.5.48)	SensorPoseAngleCorrectionLimitRol-lend	ara com
63	Sensor cluster(Table 48)	SensorCluster	0
64	Tracking motion model(A.1.13)	TrackingMotionModel	ara com
65	Colour model type(A.1.15)	ColourModelType	ara com
66	Information ambiguity domain(Table 30)	InformationAmbiguityDomain	0
67	Radial velocity ambiguity domain begin(A.1.16)	RadialVelocityAmbiguityDomainBegin	ara com
68	Radial velocity ambiguity domain end(A.1.16)	RadialVelocityAmbiguityDomainEnd	ara com





Bit	Reference Singal in ISO23150	Reference Element in PMObjectService	Option
69	Range ambiguity domain begin(A.1.17)	RangeAmbiguityDomainBegin	ara com
70	Range ambiguity domain end(A.1.17)	RangeAmbiguityDomainEnd	ara com
71	Angle azimuth ambiguity domain begin(A.1.18)	AngleAzimuthAmbiguityDomainBegin	ara com
72	Angle azimuth ambiguity domain end(A.1.18)	AngleAzimuthAmbiguityDomainEnd	ara com
73	Angle elevation ambiguity domain begin(A.1.19)	AngleElevationAmbiguityDomainBegin	ara com
74	Angle elevation ambiguity domain end(A.1.19)	AngleElevationAmbiquityDomainEnd	ara com
75	Interface applicability(A.1.20)	InterfaceApplicability	ara com
76	Recognised potentially moving objects capability(A.1.10.1)	RecognisedPotentiallyMovingOb- jectsCapability	ara com
77	Recognised potentially moving objects status(A.1.11.1)	RecognisedPotentiallyMovingOb- jectsStatus	ara com
78	Object grouping ID(A.2.3)	ObjectGroupingId	ara com
79	Number of valid observations object level(A.2.5)	NumberOfValidObservationsOb- jectLevel	Autosar vector
80	Time stamp reference object level(A.2.6)	TimeStampReferenceObjectLevel	ara com
81	Observation status object level(A.2.7)	ObservationStatusObjectLevel	ara com
82	Track quality(A.2.8)	TrackQuality	ara com
83	Position object level z(A.2.13)	PositionObjectLevelZ	ara com
84	Position object level z error(A.2.14)	PositionObjectLevelZError	ara com
85	Orientation yaw(A.2.15)	OrientationYaw	ara com
86	Orientation pitch(A.2.15)	OrientationPitch	ara com
87	Orientation roll(A.2.15)	OrientationRoll	ara com
88	Orientation yaw error(A.2.16)	OrientationYawError	ara com
89	Orientation pitch error(A.2.16)	OrientationPitchError	ara com
90	Orientation roll error(A.2.16)	OrientationRollError	ara com
91	Reference point(A.2.17)	ReferencePoint	ara com
92	Road level(A.2.18)	RoadLevel	ara com
93	Bounding box(Table 9)	PotentiallyMovingObjectsBoundingBox	0
94	Bounding box extent height(A.2.19)	BoundingBoxExtentHeight	ara com
95	Bounding box extent length error(A.2.20)	BoundingBoxExtentLengthError	ara com
96	Bounding box extent width error(A.2.20)	BoundingBoxExtentWidthError	ara com
97	Bounding box extent height error(A.2.20)	BoundingBoxExtentHeightError	ara com
98	Bounding box ground clearance(A.2.21)	BoundingBoxGroundClearance	ara com
99	Included geometric structures(A.2.22)	IncludedGeometricStructures	ara com
100	Velocity x object level(A.2.23)	VelocityXObjectLevel	ara com
101	Velocity y object level(A.2.23)	VelocityYObjectLevel	ara com
102	Velocity z object level(A.2.23)	VelocityZObjectLevel	ara com
103	Velocity x object level error(A.2.24)	VelocityXObjectLevelError	ara com
104	Velocity y object level error(A.2.24)	VelocityYObjectLevelError	ara com
105	Velocity z object level error(A.2.24)	VelocityZObjectLevelError	ara com
106	Acceleration x(A.2.25)	AccelerationX	ara com
107	Acceleration y(A.2.25)	AccelerationY	ara com
108	Acceleration z(A.2.25)	AccelerationZ	ara com
109	Acceleration x error(A.2.26)	AccelerationXError	ara com
110	Acceleration y error(A.2.26)	AccelerationYError	ara com





Bit	Reference Singal in ISO23150	Reference Element in PMObjectService	Option
111	Acceleration z error(A.2.26)	AccelerationZError	ara com
112	Instantaneous centre of rotation x(A.2.27)	InstantaneousCentreOfRotationX	ara com
113	Instantaneous centre of rotation y(A.2.27)	InstantaneousCentreOfRotationY	ara com
114	Instantaneous centre of rotation x error(A.2.28)	InstantaneousCentreOfRotationXError	ara com
115	Instantaneous centre of rotation y error(A.2.28)	InstantaneousCentreOfRotationYError	ara com
116	Rotation rate at instantaneous centre of rotation yaw(A.2.29)	RotationRateAtInstantaneousCentre- OfRotationYaw	ara com
117	Rotation rate at instantaneous centre of rotation yaw error(A.2.30)	RotationRateAtInstantaneousCentre- OfRotationYawError	ara com
118	Movement status(A.2.31)	MovementStatus	ara com
119	Lights(Table 9)	PotentiallyMovingObjectsLights	0
120	Person(Table 9)	PotentiallyMovingObjectsPerson	0
121	Person pose yaw error(A.2.38)	PersonPoseYawError	ara com
122	Person pose pitch error(A.2.38)	PersonPosePitchError	ara com
123	Person pose roll error(A.2.38)	PersonPoseRollError	ara com
124	Lane related information(Table 9)	PotentiallyMovingObjectsLaneRelatedInformation	0
125	Angle between object edge and lane left edge right lane(A.2.40) $$	AngleBetweenObjectEdgeAndLaneLeft- EdgeRightLane	ara com
126	Angle between object edge and lane right edge left lane(A.2.40)	AngleBetweenObjectEdgeAndLaneRight- EdgeLeftLane	ara com
127	Angle between object edge and lane left edge right lane error(A.2.41)	AngleBetweenObjectEdgeAndLaneLeft- EdgeRightLaneError	ara com
128	Angle between object edge and lane right edge left lane error(A.2.41)	AngleBetweenObjectEdgeAndLaneRight- EdgeLeftLaneError	ara com
129	Percentage side lane left(A.2.42)	PercentageSideLaneLeft	ara com
130	Percentage side lane right(A.2.42)	PercentageSideLaneRight	ara com
131	Motion related information(Table 9)	PotentiallyMovingObjectsMotionRe- latedInformation	0
132	Camera sensor technology specific(Table 9)	PotentiallyMovingObjectsCameraSen- sorTechnologySpecific	0
133	Radar sensor technology specific(Table 9)	PotentiallyMovingObjectsRadarSen- sorTechnologySpecific	0
134	Lidar sensor technology specific(Table 9)	PotentiallyMovingObjectsLidarSen- sorTechnologySpecific	0

Table 10.1: Capability Vector of PMObjectService

10.1.2 RObjectsService Capability Vector

The table below includes the capability bit setting for the optional elements for RObjectService, which also refers to ISO 23150. The Bit setting to 1 means the presence of the optional element, while 0 means absent.



Bit	Reference Singal in ISO23150	Reference Element in RObjectsService	Option
1	Interface ID(A.1.4)	InterfaceId	Autosar Service
2	Cycle counter(A.1.6.1)	CycleCounter	ara com
3	Interface cycle time(A.1.7)	InterfaceCycleTime	ara com
4	Interface cycle time variation(A.1.8)	InterfaceCycleTimeVariation	ara com
5	Information vehicle coordinate system(Table 46)	InformationVehicleCoordinateSystem	0
6	Information sensor pose(Table 46)	InformationSensorPose	0
7	Sensor origin point x(A.1.22)	SensorOriginPointX	ara com
8	Sensor origin point y(A.1.22)	SensorOriginPointY	ara com
9	Sensor origin point z(A.1.22)	SensorOriginPointZ	ara com
10	Sensor origin point x error(A.1.23)	SensorOriginPointXError	ara com
11	Sensor origin point y error(A.1.23)	SensorOriginPointYError	ara com
12	Sensor origin point z error(A.1.23)	SensorOriginPointZError	ara com
13	Sensor origin point x x error (A.1.23)	SensorOriginPointXXError	ara com
14	Sensor origin point x y error (A.1.23)	SensorOriginPointXYError	ara com
15	Sensor origin point x z error (A.1.23)	SensorOriginPointXZError	ara com
16	Sensor origin point y x error (A.1.23)	SensorOriginPointYXError	ara com
17	Sensor origin point y y error (A.1.23)	SensorOriginPointYYError	ara com
18	Sensor origin point y z error (A.1.23)	SensorOriginPointYZError	ara com
19	Sensor origin point z x error (A.1.23)	SensorOriginPointZXError	ara com
20	Sensor origin point z y error (A.1.23)	SensorOriginPointZYError	ara com
21	Sensor origin point z z error (A.1.23)	SensorOriginPointZZError	ara com
22	Sensor orientation yaw(A.1.24)	SensorOrientationYaw	ara com
23	Sensor orientation pitch(A.1.24)	SensorOrientationPitch	ara com
24	Sensor orientation roll(A.1.24)	SensorOrientationRoll	ara com
25	Sensor orientation yaw error(A.1.25)	SensorOrientationYawError	ara com
26	Sensor orientation pitch error(A.1.25)	SensorOrientationPitchError	ara com
27	Sensor orientation roll error(A.1.25)	SensorOrientationRollError	ara com
28	Sensor orientation yaw yaw error (A.1.25)	SensorOrientationYawYawError	ara com
29	Sensor orientation yaw pitch error (A.1.25)	SensorOrientationYawPitchError	ara com
30	Sensor orientation yaw politicarior (A.1.25)	SensorOrientationYawRollError	ara com
31	Sensor orientation pitch yaw error (A.1.25)	SensorOrientationPitchYawError	ara com
32	Sensor orientation pitch pitch error (A.1.25)	SensorOrientationPitchPitchError	ara com
33	Sensor orientation pitch roll error (A.1.25)	SensorOrientationPitchRollError	ara com
34	Sensor orientation roll yaw error (A.1.25)	SensorOrientationRollYawError	ara com
35	Sensor orientation roll pitch error (A.1.25)	SensorOrientationRollPitchError	ara com
36	Sensor orientation roll roll error (A.1.25)	SensorOrientationRollRollError	ara com
37	Calibration(Table 48)	Calibration	0
38	Calibration process state(A.5.42)	CalibrationProcessState	ara com
39	Sensor origin point correction x(A.5.43)	SensorOriginPointCorrectionX	ara com
40	Sensor origin point correction y(A.5.43)	SensorOriginPointCorrectionY	ara com
41	Sensor origin point correction z(A.5.43)	SensorOriginPointCorrectionZ	ara com
42	Sensor origin point correction x error(A.5.44)	SensorOriginFointCorrectionXError	ara com
43	Sensor origin point correction y error(A.5.44)	SensorOriginPointCorrectionYError	ara com
44	Sensor origin point correction y error(A.5.44)		ara com
45	Sensor origin translation correction limit xbe-	SensorOriginPointCorrectionZError SensorOriginTranslationCorrection-	
40	gin(A.5.45)	LimitXbegin	ara com





Bit	Reference Singal in ISO23150	Reference Element in RObjectsService	Option
46	Sensor origin translation correction limit	SensorOriginTranslationCorrection-	ara com
	xend(A.5.45)	LimitXend	
47	Sensor origin translation correction limit ybe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitYbegin	ara com
48	Sensor origin translation correction limit yend(A.5.45)	SensorOriginTranslationCorrection- LimitYend	ara com
49	Sensor origin translation correction limit zbe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitZbegin	ara com
50	Sensor origin translation correction limit zend(A.5.45)	SensorOriginTranslationCorrection- LimitZend	ara com
51	Sensor orientation correction yaw(A.5.46)	SensorOrientationCorrectionYaw	ara com
52	Sensor orientation correction pitch(A.5.46)	SensorOrientationCorrectionPitch	ara com
53	Sensor orientation correction roll(A.5.46)	SensorOrientationCorrectionRoll	ara com
54	Sensor orientation correction yaw error(A.5.47)	SensorOrientationCorrectionYawError	ara com
55	Sensor orientation correction pitch error(A.5.47)	SensorOrientationCorrectionPitchEr- ror	ara com
56	Sensor orientation correction roll error(A.5.47)	SensorOrientationCorrectionRollEr- ror	ara com
57	Sensor pose angle correction limit yawbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitYaw- begin	ara com
58	Sensor pose angle correction limit yawend(A.5.48)	SensorPoseAngleCorrectionLim- itYawend	ara com
59	Sensor pose angle correction limit pitchbe-gin(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchbegin	ara com
60	Sensor pose angle correction limit pitchend(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchend	ara com
61	Sensor pose angle correction limit rollbe- gin(A.5.48)	SensorPoseAngleCorrectionLimitRoll-begin	ara com
62	Sensor pose angle correction limit rol- lend(A.5.48)	SensorPoseAngleCorrectionLimitRol- lend	ara com
63	Sensor cluster(Table 48)	SensorCluster	0
64	Tracking motion model(A.1.13)	TrackingMotionModel	ara com
65	Motion type(A.1.14)	MotionType	ara com
66	Colour model type(A.1.15)	ColourModelType	ara com
67	Information ambiguity domain(Table 30)	InformationAmbiguityDomain	0
68	Radial velocity ambiguity domain begin(A.1.16)	RadialVelocityAmbiguityDomainBegin	ara com
69	Radial velocity ambiguity domain end(A.1.16)	RadialVelocityAmbiguityDomainEnd	ara com
70	Range ambiguity domain begin(A.1.17)	RangeAmbiguityDomainBegin	ara com
71	Range ambiguity domain end(A.1.17)	RangeAmbiguityDomainEnd	ara com
72	Angle azimuth ambiguity domain begin(A.1.18)	AngleAzimuthAmbiguityDomainBegin	ara com
73	Angle azimuth ambiguity domain end(A.1.18)	AngleAzimuthAmbiguityDomainEnd	ara com
74	Angle elevation ambiguity domain begin(A.1.19)	AngleElevationAmbiguityDomainBegin	ara com
75	Angle elevation ambiguity domain end(A.1.19)	AngleElevationAmbiguityDomainEnd	ara com
76	Interface applicability(A.1.20)	InterfaceApplicability	ara com
77	Road surface(Table 12)	RoadSurface	0
78	Road surface roughness(A.2.52)	RoadSurfaceRoughness	ara com
79	Number of valid road surface condition classifications(A.2.53)	NumberOfValidRoadSurfaceCondition- Classifications	Autosar vector





Bit	Reference Singal in ISO23150	Reference Element in RObjectsService	Option
80	Road surface condition classification	RoadSurfaceConditionClassification-	ara com
81	type(A.2.54) Road surface condition classification type confi-	Type RoadSurfaceConditionClassification-	ara com
01	dence(A.2.55)	TypeConfidence	ara com
82	Track quality(A.2.8)	TrackQuality	ara com
83	Measurement status object level(A.2.9)	MeasurementStatusObjectLevel	ara com
84	Road markings(Table 12)	RoadMarkings	0
85	Recognized road markings capability(A.1.10.2)	RecognizedRoadMarkingsCapability	ara com
86	Recognized road markings status(A.1.11.2)	RecognizedRoadMarkingsStatus	ara com
87	Object grouping ID(A.2.3)	ObjectGroupingId	ara com
88	Number of valid observations object level(A.2.5)	NumberOfValidObservationsOb- jectLevel	Autosar vector
89	Time stamp reference object level(A.2.6)	TimeStampReferenceObjectLevel	ara com
90	Observation status object level(A.2.7)	ObservationStatusObjectLevel	ara com
91	Track quality(A.2.8)	TrackQuality	ara com
92	Road object lane association(A.2.59)	RoadObjectLaneAssociation	ara com
93	Road object lane association confidence(A.2.60)	RoadObjectLaneAssociationConfidence	ara com
94	Arrow orientation(A.2.61)	ArrowOrientation	ara com
95	Arrow direction(A.2.62)	ArrowDirection	ara com
96	Number of valid sign classifications(A.2.63)	NumberOfValidSignClassifications	Autosar vector
97	Sign classification type(A.2.64)	SignClassificationType	ara com
98	Sign classification type confidence(A.2.65)	SignClassificationTypeConfidence	ara com
99	Sign value(A.2.66)	SignValue	ara com
100	Sign value unit(A.2.67)	SignValueUnit	ara com
101	Sign state(A.2.68)	SignState	ara com
102	Colour tone(Table xxx)	ColourTone	0
103	Colour tone confidence object level(A.2.70)	ColourToneConfidenceObjectLevel	ara com
104	Polynomials(Table 12)	RoadMarkingsPolynomials	0
105	Polynomial coefficient z c0(A.2.76)	PolynomialCoefficientZCO	ara com
106	Polynomial coefficient z c1(A.2.76)	PolynomialCoefficientZC1	ara com
107	Polynomial coefficient z c2(A.2.76)	PolynomialCoefficientZC2	ara com
108	Polynomial coefficient z c3(A.2.76)	PolynomialCoefficientZC3	ara com
109	Polynomial y error(A.2.77)	PolynomialYError	ara com
110	Polynomial z error(A.2.78)	PolynomialZError	V1 ara com (opti- mizeable API)
111	Width polynomial(A.2.80)	WidthPolynomial	ara com
112	Width polynomial error(A.2.81)	WidthPolynomialError	ara com
113	Width polynomial confidence(A.2.82)	WidthPolynomialConfidence	ara com
114	Height polynomial(A.2.83)	HeightPolynomial	ara com
115	Height polynomial error(A.2.84)	HeightPolynomialError	ara com
116	Height polynomial confidence(A.2.85)	HeightPolynomialConfidence	ara com
117	Number of valid data ranges(A.2.86)	NumberOfValidDataRanges	Autosar vector
118	Supported data range x begin(A.2.87)	SupportedDataRangeXBegin	ara com
119	Supported data range x end(A.2.87)	SupportedDataRangeXEnd	ara com
120	Supported axis(A.2.88)	SupportedAxis	ara com





Bit	Reference Singal in ISO23150	Reference Element in RObjectsService	Option
121	Polylines(Table 12)	RoadMarkingsPolylines	0
122	Vertex point z(A.2.92)	VertexPointZ	ara com
123	, ,		
	Vertex point z error(A.2.93)	VertexPointZError	ara com
124	Vertex point confidence x(A.2.94)	VertexPointConfidenceX	ara com
125	Vertex point confidence y(A.2.94)	VertexPointConfidenceY	ara com
126	Vertex point confidence z(A.2.94)	VertexPointConfidenceZ	ara com
127	Width vertex(A.2.95)	WidthVertex	ara com
128	Width vertex error(A.2.96)	WidthVertexError	ara com
129	Width vertex confidence(A.2.97)	WidthVertexConfidence	ara com
130	Height vertex(A.2.98)	HeightVertex	ara com
131	Height vertex error(A.2.99)	HeightVertexError	ara com
132	Height vertex confidence(A.2.100)	HeightVertexConfidence	ara com
133	Road boundaries(Table 12)	RoadBoundaries	0
134	Recognised road boundaries capability (A.1.10.3)	RecognisedRoadBoundariesCapability	ara com
135	Recognised road boundaries status(A.1.11.3)	RecognisedRoadBoundariesStatus	ara com
136	Object grouping ID(A.2.3)	ObjectGroupingId	ara com
137	Number of valid observations object level(A.2.5)	NumberOfValidObservationsOb- jectLevel	Autosar vector
138	Time stamp reference object level(A.2.6)	TimeStampReferenceObjectLevel	ara com
139	Observation status object level(A.2.7)	ObservationStatusObjectLevel	ara com
140	Track quality(A.2.8)	TrackQuality	ara com
141	Road object lane association(A.2.59)	RoadObjectLaneAssociation	ara com
142	Road object lane association confidence(A.2.60)	RoadObjectLaneAssociationConfidence	ara com
143	Colour tone(Table xxx)	ColourTone	0
144	Colour tone confidence object level(A.2.70)	ColourToneConfidenceObjectLevel	ara com
145	Polynomials(Table 12)	RoadBoundariesPolynomials	0
146	Polynomial coefficient z c0(A.2.76)	PolynomialCoefficientZC0	ara com
147	Polynomial coefficient z c1(A.2.76)	PolynomialCoefficientZC1	ara com
148	Polynomial coefficient z c2(A.2.76)	PolynomialCoefficientZC2	ara com
149	Polynomial coefficient z c3(A.2.76)	PolynomialCoefficientZC3	ara com
150	Polynomial y error(A.2.77)	PolynomialYError	ara com
151	Polynomial z error(A.2.78)	PolynomialZError	V1 ara com (opti- mizeable API)
152	Width polynomial(A.2.80)	WidthPolynomial	ara com
153	Width polynomial error(A.2.81)	WidthPolynomialError	ara com
154	Width polynomial confidence(A.2.82)	WidthPolynomialConfidence	ara com
155	Height polynomial(A.2.83)	HeightPolynomial	ara com
156	Height polynomial error(A.2.84)	HeightPolynomialError	ara com
157	Height polynomial confidence(A.2.85)	HeightPolynomialConfidence	ara com
158	Number of valid data ranges(A.2.86)	NumberOfValidDataRanges	Autosar vector
159	Supported data range x begin(A.2.87)	SupportedDataRangeXBegin	ara com
160	Supported data range x end(A.2.87)	SupportedDataRangeXEnd	ara com
161	Supported axis(A.2.88)	SupportedAxis	ara com
162	Polylines(Table 12)	RoadBoundariesPolylines	0
	· · · · · · · · · · · · · · · · ·		I





Bit	Reference Singal in ISO23150	Reference Element in RObjectsService	Option
163	Vertex point z(A.2.92)	VertexPointZ	ara com
164	Vertex point z error(A.2.93)	VertexPointZError	ara com
165	Vertex point confidence x(A.2.94)	VertexPointConfidenceX	ara com
166	Vertex point confidence y(A.2.94)	VertexPointConfidenceY	ara com
167	Vertex point confidence z(A.2.94)	VertexPointConfidenceZ	ara com
168	Width vertex(A.2.95)	WidthVertex	ara com
169	Width vertex error(A.2.96)	WidthVertexError	ara com
170	Width vertex confidence(A.2.97)	WidthVertexConfidence	ara com
171	Height vertex(A.2.98)	HeightVertex	ara com
172	Height vertex error(A.2.99)	HeightVertexError	ara com
173	Height vertex confidence(A.2.100)	HeightVertexConfidence	ara com

Table 10.2: Capability Vector of RObjectsService

10.1.3 SObjectsService Capability Vector

The table below includes the capability bit setting for the optional elements for SObjectsService, which also refers to ISO 23150. The Bit setting to 1 means the presence of the optional element, while 0 means absent.

Bit	Reference Singal in ISO23150	Reference Element in SObjectsService	Option
1	Interface ID(A.1.4)	InterfaceId	Autosar Service
2	Cycle counter(A.1.6.1)	CycleCounter	ara com
3	Interface cycle time(A.1.7)	InterfaceCycleTime	ara com
4	Interface cycle time variation(A.1.8)	InterfaceCycleTimeVariation	ara com
5	Information vehicle coordinate system(Table 46)	InformationVehicleCoordinateSystem	0
6	Information sensor pose(Table 46)	InformationSensorPose	0
7	Sensor origin point x(A.1.22)	SensorOriginPointX	ara com
8	Sensor origin point y(A.1.22)	SensorOriginPointY	ara com
9	Sensor origin point z(A.1.22)	SensorOriginPointZ	ara com
10	Sensor origin point x error(A.1.23)	SensorOriginPointXError	ara com
11	Sensor origin point y error(A.1.23)	SensorOriginPointYError	ara com
12	Sensor origin point z error(A.1.23)	SensorOriginPointZError	ara com
13	Sensor origin point x x error (A.1.23)	SensorOriginPointXXError	ara com
14	Sensor origin point x y error (A.1.23)	SensorOriginPointXYError	ara com
15	Sensor origin point x z error (A.1.23)	SensorOriginPointXZError	ara com
16	Sensor origin point y x error (A.1.23)	SensorOriginPointYXError	ara com
17	Sensor origin point y y error (A.1.23)	SensorOriginPointYYError	ara com
18	Sensor origin point y z error (A.1.23)	SensorOriginPointYZError	ara com
19	Sensor origin point z x error (A.1.23)	SensorOriginPointZXError	ara com
20	Sensor origin point z y error (A.1.23)	SensorOriginPointZYError	ara com
21	Sensor origin point z z error (A.1.23)	SensorOriginPointZZError	ara com





Bit	Reference Singal in ISO23150	Reference Element in SObjectsService	Option
22	Sensor orientation yaw(A.1.24)	SensorOrientationYaw	ara com
23	Sensor orientation pitch(A.1.24)	SensorOrientationPitch	ara com
24	Sensor orientation roll(A.1.24)	SensorOrientationRoll	ara com
25	Sensor orientation yaw error(A.1.25)	SensorOrientationYawError	ara com
26	Sensor orientation pitch error(A.1.25)	SensorOrientationPitchError	ara com
27	Sensor orientation roll error(A.1.25)	SensorOrientationRollError	ara com
28	Sensor orientation yaw yaw error (A.1.25)	SensorOrientationYawYawError	ara com
29	Sensor orientation yaw pitch error (A.1.25)	SensorOrientationYawPitchError	ara com
30	Sensor orientation yaw roll error (A.1.25)	SensorOrientationYawRollError	ara com
31	Sensor orientation pitch yaw error (A.1.25)	SensorOrientationPitchYawError	ara com
32	Sensor orientation pitch pitch error (A.1.25)	SensorOrientationPitchPitchError	ara com
33	Sensor orientation pitch roll error (A.1.25)	SensorOrientationPitchRollError	ara com
34	Sensor orientation roll yaw error (A.1.25)	SensorOrientationRollYawError	ara com
35	Sensor orientation roll pitch error (A.1.25)	SensorOrientationRollPitchError	ara com
36	Sensor orientation roll roll error (A.1.25)	SensorOrientationRollRollError	ara com
37	Calibration(Table 48)	Calibration	0
38	Calibration process state(A.5.42)	CalibrationProcessState	ara com
39	Sensor origin point correction x(A.5.43)	SensorOriginPointCorrectionX	ara com
40	Sensor origin point correction y(A.5.43)	SensorOriginPointCorrectionY	ara com
41	Sensor origin point correction z(A.5.43)	SensorOriginPointCorrectionZ	ara com
42	Sensor origin point correction x error(A.5.44)	SensorOriginPointCorrectionXError	ara com
43	Sensor origin point correction y error(A.5.44)	SensorOriginPointCorrectionYError	ara com
44	Sensor origin point correction z error(A.5.44)	SensorOriginPointCorrectionZError	ara com
45	Sensor origin translation correction limit xbe-gin(A.5.45)	SensorOriginTranslationCorrection- LimitXbegin	ara com
46	Sensor origin translation correction limit xend(A.5.45)	SensorOriginTranslationCorrection- LimitXend	ara com
47	Sensor origin translation correction limit ybe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitYbegin	ara com
48	Sensor origin translation correction limit yend(A.5.45)	SensorOriginTranslationCorrection- LimitYend	ara com
49	Sensor origin translation correction limit zbe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitZbegin	ara com
50	Sensor origin translation correction limit zend(A.5.45)	SensorOriginTranslationCorrection- LimitZend	ara com
51	Sensor orientation correction yaw(A.5.46)	SensorOrientationCorrectionYaw	ara com
52	Sensor orientation correction pitch(A.5.46)	SensorOrientationCorrectionPitch	ara com
53	Sensor orientation correction roll(A.5.46)	SensorOrientationCorrectionRoll	ara com
54	Sensor orientation correction yaw error(A.5.47)	SensorOrientationCorrectionYawError	ara com
55	Sensor orientation correction pitch error(A.5.47)	SensorOrientationCorrectionPitchEr- ror	ara com
56	Sensor orientation correction roll error(A.5.47)	SensorOrientationCorrectionRollEr- ror	ara com
57	Sensor pose angle correction limit yawbe- gin(A.5.48)	SensorPoseAngleCorrectionLimitYaw- begin	ara com
58	Sensor pose angle correction limit yawend(A.5.48)	SensorPoseAngleCorrectionLim- itYawend	ara com





Bit	Reference Singal in ISO23150	Reference Element in SObjectsService	Option
59	Sensor pose angle correction limit pitchbe-	SensorPoseAngleCorrectionLimit-	ara com
	gin(A.5.48)	Pitchbegin	ara com
60	Sensor pose angle correction limit pitchend(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchend	ara com
61	Sensor pose angle correction limit rollbe- gin(A.5.48)	SensorPoseAngleCorrectionLimitRoll-begin	ara com
62	Sensor pose angle correction limit rol- lend(A.5.48)	SensorPoseAngleCorrectionLimitRol-lend	ara com
63	Sensor cluster(Table 48)	SensorCluster	0
64	Tracking motion model(A.1.13)	TrackingMotionModel	ara com
65	Motion type(A.1.14)	MotionType	ara com
66	Colour model type(A.1.15)	ColourModelType	ara com
67	Information ambiguity domain(Table 30)	InformationAmbiguityDomain	0
68	Radial velocity ambiguity domain begin(A.1.16)	RadialVelocityAmbiguityDomainBegin	ara com
69	Radial velocity ambiguity domain end(A.1.16)	RadialVelocityAmbiguityDomainEnd	ara com
70	Range ambiguity domain begin(A.1.17)	RangeAmbiguityDomainBegin	ara com
71	Range ambiguity domain end(A.1.17)	RangeAmbiguityDomainEnd	ara com
72	Angle azimuth ambiguity domain begin(A.1.18)	AngleAzimuthAmbiguityDomainBegin	ara com
73	Angle azimuth ambiguity domain end(A.1.18)	AngleAzimuthAmbiguityDomainEnd	ara com
74	Angle elevation ambiguity domain begin(A.1.19)	AngleElevationAmbiguityDomainBegin	ara com
75	Angle elevation ambiguity domain end(A.1.19)	AngleElevationAmbiguityDomainEnd	ara com
76	Interface applicability(A.1.20)	InterfaceApplicability	ara com
77	General landmarks(Table 12)	GeneralLandmarks	0
78	Recognised general landmarks capability(A.2.48)	RecognisedGeneralLandmarksCapabil- ity	ara com
79	Recognised general landmarks status(A.2.49)	RecognisedGeneralLandmarksStatus	ara com
80	Object grouping ID(A.2.53)	ObjectGroupingId	ara com
81	Number of valid observations object level(A.2.54)	NumberOfValidObservationsOb- jectLevel	Autosar vector
82	Time stamp reference object level()	TimeStampReferenceObjectLevel	ara com
83	Observation status object level(A.2.8)	ObservationStatusObjectLevel	ara com
84	Track quality()	TrackQuality	ara com
85	Position object level z(A.2.6)	PositionObjectLevelZ	ara com
86	Position object level z error(A.2.8)	PositionObjectLevelZError	ara com
87	Orientation yaw(A.2.9)	OrientationYaw	ara com
88	Orientation pitch()	OrientationPitch	ara com
89	Orientation roll(Table 12)	OrientationRoll	ara com
90	Orientation yaw error(A.2.56)	OrientationYawError	ara com
91	Orientation pitch error()	OrientationPitchError	ara com
92	Orientation roll error(A.2.57)	OrientationRollError	ara com
93	Reference point(A.2.58)	ReferencePoint	ara com
94	Bounding box(A.2.60)	GeneralLandmarksBoundingBox	0
95	Bounding box extent height(A.2.63)	BoundingBoxExtentHeight	ara com
96	Bounding box extent length error()	BoundingBoxExtentLengthError	ara com
97	Bounding box extent width error(A.2.64)	BoundingBoxExtentWidthError	ara com
98	Bounding box extent height error(A.2.65)	BoundingBoxExtentHeightError	ara com
			1





Bit	Reference Singal in ISO23150	Reference Element in SObjectsService	Option
99	Traffic signs()	TrafficSigns	0
100	Recognised traffic signs capability(Table xxx)	RecognisedTrafficSignsCapability	ara com
101	Recognised traffic signs status()	RecognisedTrafficSignsStatus	ara com
102	Object grouping ID()	ObjectGroupingId	ara com
103	Number of valid observations object level(A.2.71)	NumberOfValidObservationsOb- jectLevel	Autosar vector
104	Time stamp reference object level(A.2.72)	TimeStampReferenceObjectLevel	ara com
105	Observation status object level(A.2.73)	ObservationStatusObjectLevel	ara com
106	Track quality(A.2.74)	TrackQuality	ara com
107	Sign geometry(A.2.78)	SignGeometry	ara com
108	Number of valid lane relevance classifications(A.2.79)	NumberOfValidLaneRelevanceClassifi- cations	Autosar vector
109	Lane relevance classification type(A.2.81)	LaneRelevanceClassificationType	ara com
110	Lane relevance classification type confidence(A.2.82)	LaneRelevanceClassificationTypeConfidence	ara com
111	Colour tone(A.2.85)	TrafficSignsColourTone	global struct
112	(A.2.87)		
113	Position object level z(Table 12)	PositionObjectLevelZ	ara com
114	Position object level z error(A.2.72)	PositionObjectLevelZError	ara com
115	Number of valid observations object level(A.2.92)	NumberOfValidObservationsOb- jectLevel	Autosar vector
116	Time stamp reference object level(A.2.92)	TimeStampReferenceObjectLevel	ara com
117	Observation status object level(A.2.93)	ObservationStatusObjectLevel	ara com
118	Track quality(A.2.93)	TrackQuality	ara com
119	Colour tone()	TrafficSignsSupplementarySigns-ColourTone	global struct
120	Colour tone confidence object level(A.1.11.3)	ColourToneConfidenceObjectLevel	ara com
121	Traffic lights(A.2.6)	TrafficLights	0
122	Recognised traffic lights capability(A.2.7)	RecognisedTrafficLightsCapability	ara com
123	Recognised traffic lights status()	RecognisedTrafficLightsStatus	ara com
124	Object grouping ID()	ObjectGroupingId	ara com
125	Number of valid observations object level(A.2.103)	NumberOfValidObservationsOb- jectLevel	Autosar vector
126	Time stamp reference object level(A.2.60)	TimeStampReferenceObjectLevel	ara com
127	Observation status object level(Table xxx)	ObservationStatusObjectLevel	ara com
128	Track quality(A.2.69)	TrackQuality	ara com
129	Position object level z(A.2.76)	PositionObjectLevelZ	ara com
130	Position object level z error(A.2.76)	PositionObjectLevelZError	ara com
131	Orientation yaw(A.2.77)	OrientationYaw	ara com
132	Orientation pitch(A.2.78)	OrientationPitch	ara com
133	Orientation roll(A.2.79)	OrientationRoll	ara com
134	Orientation yaw error(A.2.79)	OrientationYawError	ara com
135	Orientation pitch error(A.2.80)	OrientationPitchError	ara com
136	Orientation roll error(A.2.81)	OrientationRollError	ara com
137	Reference point(A.2.82)	ReferencePoint	ara com
138	Bounding box(A.2.85)	TrafficLightsBoundingBox	0





Bit	Reference Singal in ISO23150	Reference Element in SObjectsService	Option
139	Bounding box extent length(A.2.86)	BoundingBoxExtentLength	ara com
140	Bounding box extent length error(A.2.87)	BoundingBoxExtentLengthError	ara com
141	Bounding box extent width error(A.2.88)	BoundingBoxExtentWidthError	ara com
142	Bounding box extent height error()	BoundingBoxExtentHeightError	ara com
143	Total number of traffic light spots(Table 12)	TotalNumberOfTrafficLightSpots	Autosar vector
144	Total number of traffic light spots confidence(A.2.89)	TotalNumberOfTrafficLightSpotsCon-fidence	Autosar vector
145	Number of valid observations object level(A.2.92)	NumberOfValidObservationsOb- jectLevel	Autosar vector
146	Time stamp reference object level(A.2.93)	TimeStampReferenceObjectLevel	ara com
147	Observation status object level(A.2.93)	ObservationStatusObjectLevel	ara com
148	Track quality(A.2.94)	TrackQuality	ara com
149	Light shape value(A.2.100)	LightShapeValue	ara com
150	Colour()	TrafficLightsSpotsColour	0
151	Position object level z()	PositionObjectLevelZ	ara com
152	Position object level z error()	PositionObjectLevelZError	ara com
153	Number of valid lane relevance classifications()	NumberOfValidLaneRelevanceClassifi- cations	Autosar vector
154	Lane relevance classification type()	LaneRelevanceClassificationType	ara com
155	Lane relevance classification type confidence()	LaneRelevanceClassificationTypeConfidence	ara com

Table 10.3: Capability Vector of SObjectsService

10.2 Feature Level Service

10.2.1 CameraFeatureService Capability Vector

The table below includes the capability bit setting for the optional elements for CameraFeatureService, which also refers to ISO 23150. The Bit setting to 1 means the presence of the optional element, while 0 means absent.

Bit	Reference Singal in ISO23150	Reference Element in CameraFeatureService	Option
1	Interface ID(A.1.4)	InterfaceId	Autosar Service
2	Cycle counter(A.1.6.1)	CycleCounter	ara com
3	Interface cycle time(A.1.7)	InterfaceCycleTime	ara com
4	Interface cycle time variation(A.1.8)	InterfaceCycleTimeVariation	ara com
5	Information vehicle coordinate system(Table 46)	InformationVehicleCoordinateSystem	0
6	Information sensor pose(Table 46)	InformationSensorPose	0
7	Sensor origin point x(A.1.22)	SensorOriginPointX	ara com
8	Sensor origin point y(A.1.22)	SensorOriginPointY	ara com
9	Sensor origin point z(A.1.22)	SensorOriginPointZ	ara com
10	Sensor origin point x error(A.1.23)	SensorOriginPointXError	ara com





Bit	Reference Singal in ISO23150	Reference Element in CameraFeatureService	Option
11	Sensor origin point y error(A.1.23)	SensorOriginPointYError	ara com
12	Sensor origin point z error(A.1.23)	SensorOriginPointZError	ara com
13	Sensor origin point x x error (A.1.23)	SensorOriginPointXXError	ara com
14	Sensor origin point x y error (A.1.23)	SensorOriginPointXYError	ara com
15	Sensor origin point x z error (A.1.23)	SensorOriginPointXZError	ara com
16	Sensor origin point y x error (A.1.23)	SensorOriginPointYXError	ara com
17	Sensor origin point y y error (A.1.23)	SensorOriginPointYYError	ara com
18	Sensor origin point y z error (A.1.23)	SensorOriginPointYZError	ara com
19	Sensor origin point z x error (A.1.23)	SensorOriginPointZXError	ara com
20	Sensor origin point z y error (A.1.23)	SensorOriginPointZYError	ara com
21	Sensor origin point z z error (A.1.23)	SensorOriginPointZZError	ara com
22	Sensor orientation yaw(A.1.24)	SensorOrientationYaw	ara com
23	Sensor orientation pitch(A.1.24)	SensorOrientationPitch	ara com
24	Sensor orientation roll(A.1.24)	SensorOrientationRoll	ara com
25	Sensor orientation yaw error(A.1.25)	SensorOrientationYawError	ara com
26	Sensor orientation pitch error(A.1.25)	SensorOrientationPitchError	ara com
27	Sensor orientation roll error(A.1.25)	SensorOrientationRollError	ara com
28	Sensor orientation yaw yaw error (A.1.25)	SensorOrientationYawYawError	ara com
29	Sensor orientation yaw pitch error (A.1.25)	SensorOrientationYawPitchError	ara com
30	Sensor orientation yaw roll error (A.1.25)	SensorOrientationYawRollError	ara com
31	Sensor orientation pitch yaw error (A.1.25)	SensorOrientationPitchYawError	ara com
32	Sensor orientation pitch pitch error (A.1.25)	SensorOrientationPitchPitchError	ara com
33	Sensor orientation pitch roll error (A.1.25)	SensorOrientationPitchRollError	ara com
34	Sensor orientation roll yaw error (A.1.25)	SensorOrientationRollYawError	ara com
35	Sensor orientation roll pitch error (A.1.25)	SensorOrientationRollPitchError	ara com
36	Sensor orientation roll roll error (A.1.25)	SensorOrientationRollRollError	ara com
37	Calibration(Table 48)	Calibration	0
38	Calibration process state(A.5.42)	CalibrationProcessState	ara com
39	Sensor origin point correction x(A.5.43)	SensorOriginPointCorrectionX	ara com
40	Sensor origin point correction y(A.5.43)	SensorOriginPointCorrectionY	ara com
41	Sensor origin point correction z(A.5.43)	SensorOriginPointCorrectionZ	ara com
42	Sensor origin point correction x error(A.5.44)	SensorOriginPointCorrectionXError	ara com
43	Sensor origin point correction y error(A.5.44)	SensorOriginPointCorrectionYError	ara com
44	Sensor origin point correction z error(A.5.44)	SensorOriginPointCorrectionZError	ara com
45	Sensor origin translation correction limit xbe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitXbegin	ara com
46	Sensor origin translation correction limit xend(A.5.45)	SensorOriginTranslationCorrection- LimitXend	ara com
47	Sensor origin translation correction limit ybe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitYbegin	ara com
48	Sensor origin translation correction limit yend(A.5.45)	SensorOriginTranslationCorrection- LimitYend	ara com
49	Sensor origin translation correction limit zbe-gin(A.5.45)	SensorOriginTranslationCorrection- LimitZbegin	ara com





Bit	Reference Singal in ISO23150	Reference Element in CameraFeatureService	Option
			•
50	Sensor origin translation correction limit zend(A.5.45)	SensorOriginTranslationCorrection- LimitZend	ara com
51	Sensor orientation correction yaw(A.5.46)	SensorOrientationCorrectionYaw	ara com
52	Sensor orientation correction pitch(A.5.46)	SensorOrientationCorrectionPitch	ara com
53	Sensor orientation correction roll(A.5.46)	SensorOrientationCorrectionRoll	ara com
54	Sensor orientation correction yaw error(A.5.47)	SensorOrientationCorrectionYawError	ara com
55	Sensor orientation correction pitch error(A.5.47)	SensorOrientationCorrectionPitchError	ara com
56	Sensor orientation correction roll error(A.5.47)	SensorOrientationCorrectionRollEr-ror	ara com
57	Sensor pose angle correction limit yawbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitYaw-begin	ara com
58	Sensor pose angle correction limit yawend(A.5.48)	SensorPoseAngleCorrectionLim- itYawend	ara com
59	Sensor pose angle correction limit pitchbe- gin(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchbegin	ara com
60	Sensor pose angle correction limit pitchend(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchend	ara com
61	Sensor pose angle correction limit rollbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitRoll-begin	ara com
62	Sensor pose angle correction limit rol- lend(A.5.48)	SensorPoseAngleCorrectionLimitRol-lend	ara com
63	Sensor cluster(Table 48)	SensorCluster	0
64	Tracking motion model(A.1.13)	TrackingMotionModel	ara com
65	Motion type(A.1.14)	MotionType	ara com
66	Information ambiguity domain(Table 30)	InformationAmbiguityDomain	0
67	Radial velocity ambiguity domain begin(A.1.16)	RadialVelocityAmbiguityDomainBegin	ara com
68	Radial velocity ambiguity domain end(A.1.16)	RadialVelocityAmbiguityDomainEnd	ara com
69	Range ambiguity domain begin(A.1.17)	RangeAmbiguityDomainBegin	ara com
70	Range ambiguity domain end(A.1.17)	RangeAmbiguityDomainEnd	ara com
71	Angle azimuth ambiguity domain begin(A.1.18)	AngleAzimuthAmbiguityDomainBegin	ara com
72	Angle azimuth ambiguity domain end(A.1.18)	AngleAzimuthAmbiguityDomainEnd	ara com
73	Angle elevation ambiguity domain begin(A.1.19)	AngleElevationAmbiguityDomainBegin	ara com
74	Angle elevation ambiguity domain end(A.1.19)	AngleElevationAmbiguityDomainEnd	ara com
75	Interface applicability(A.1.20)	InterfaceApplicability	ara com
76	Camera features(Table 12)	CameraFeatures	0
77	Recognised features capability(A.2.48)	RecognisedFeaturesCapability	ara com
78	Recognised features status(A.2.49)	RecognisedFeaturesStatus	ara com
79	Feature ID(A.2.52)	FeatureId	ara com
80	Feature grouping ID(A.2.53)	FeatureGroupingId	ara com
81	Object ID reference feature level()	ObjectIdReferenceFeatureLevel	ara com
82	Number of valid observations feature level(A.2.55)	NumberOfValidObservationsFea- tureLevel	Autosar vector
83	Time stamp reference feature level(A.2.8)	TimeStampReferenceFeatureLevel	ara com
84	Observation status feature level(A.2.9)	ObservationStatusFeatureLevel	ara com
85	Colour tone confidence feature level(A.2.6)	ColourToneConfidenceFeatureLevel	ara com
86	Shape reference points(A.2.63)	CameraFeaturesShapeReferencePoints	0





Bit	Reference Singal in ISO23150	Reference Element in CameraFeatureService	Option
87	Shape surface normal x(A.2.69)	ShapeSurfaceNormalX	ara com
88	Shape surface normal y()	ShapeSurfaceNormalY	ara com
89	Shape surface normal z(A.2.70)	ShapeSurfaceNormalZ	ara com
90	Shape surface normal x error()	ShapeSurfaceNormalXError	ara com
91	Shape surface normal y error()	ShapeSurfaceNormalYError	ara com
92	Shape surface normal z error()	ShapeSurfaceNormalZError	ara com
93	Translation rate x feature level(Table 12)	TranslationRateXFeatureLevel	ara com
94	Translation rate y feature level(A.2.71)	TranslationRateYFeatureLevel	ara com
95	Translation rate z feature level()	TranslationRateZFeatureLevel	ara com
96	Translation rate x feature level error(A.2.72)	TranslationRateXFeatureLevelError	ara com
97	Translation rate y feature level error(A.2.73)	TranslationRateYFeatureLevelError	ara com
98	Translation rate z feature level error()	TranslationRateZFeatureLevelError	ara com
99	Rotation rate yaw(A.2.74)	RotationRateYaw	ara com
100	Rotation rate pitch()	RotationRatePitch	ara com
101	Rotation rate roll(A.2.75)	RotationRateRoll	ara com
102	Rotation rate yaw error(A.2.75)	RotationRateYawError	ara com
103	Rotation rate pitch error(A.2.75)	RotationRatePitchError	ara com
104	Rotation rate roll error(A.2.75)	RotationRateRollError	ara com
105	Scale change feature level(A.2.76)	ScaleChangeFeatureLevel	ara com
106	Scale change feature level error(A.2.76)	ScaleChangeFeatureLevelError	ara com

Table 10.4: Capability Vector of CameraFeatureService

10.2.2 USSFeatureService Capability Vector

The table below includes the capability bit setting for the optional elements for USSFeatureService, which also refers to ISO 23150. The Bit setting to 1 means the presence of the optional element, while 0 means absent.

Bit	Reference Singal in ISO23150	Reference Element in USSFeatureService	Option
1	Interface ID(A.1.4)	InterfaceId	Autosar Service
2	Cycle counter(A.1.6.1)	CycleCounter	ara com
3	Interface cycle time(A.1.7)	InterfaceCycleTime	ara com
4	Interface cycle time variation(A.1.8)	InterfaceCycleTimeVariation	ara com
5	Information vehicle coordinate system(Table 46)	InformationVehicleCoordinateSystem	0
6	Information sensor pose(Table 46)	InformationSensorPose	0
7	Sensor origin point x(A.1.22)	SensorOriginPointX	ara com
8	Sensor origin point y(A.1.22)	SensorOriginPointY	ara com
9	Sensor origin point z(A.1.22)	SensorOriginPointZ	ara com
10	Sensor origin point x error(A.1.23)	SensorOriginPointXError	ara com
11	Sensor origin point y error(A.1.23)	SensorOriginPointYError	ara com
12	Sensor origin point z error(A.1.23)	SensorOriginPointZError	ara com





Bit	Reference Singal in ISO23150	Reference Element in USSFeatureService	Option
13	Sensor origin point x x error (A.1.23)	SensorOriginPointXXError	ara com
14	Sensor origin point x y error (A.1.23)	SensorOriginPointXYError	ara com
15	Sensor origin point x z error (A.1.23)	SensorOriginPointXZError	ara com
16	Sensor origin point y x error (A.1.23)	SensorOriginPointYXError	ara com
17	Sensor origin point y y error (A.1.23)	SensorOriginPointYYError	ara com
18	Sensor origin point y z error (A.1.23)	SensorOriginPointYZError	ara com
19	Sensor origin point z x error (A.1.23)	SensorOriginPointZXError	ara com
20	Sensor origin point z y error (A.1.23)	SensorOriginPointZYError	ara com
21	Sensor origin point z z error (A.1.23)	SensorOriginPointZZError	ara com
22	Sensor orientation yaw(A.1.24)	SensorOrientationYaw	ara com
23	Sensor orientation pitch(A.1.24)	SensorOrientationPitch	ara com
24	Sensor orientation roll(A.1.24)	SensorOrientationRoll	ara com
25	Sensor orientation yaw error(A.1.25)	SensorOrientationYawError	ara com
26	Sensor orientation pitch error(A.1.25)	SensorOrientationPitchError	ara com
27	Sensor orientation roll error(A.1.25)	SensorOrientationRollError	ara com
28	Sensor orientation yaw yaw error (A.1.25)	SensorOrientationYawYawError	ara com
29	Sensor orientation yaw pitch error (A.1.25)	SensorOrientationYawPitchError	ara com
30	Sensor orientation yaw roll error (A.1.25)	SensorOrientationYawRollError	ara com
31	Sensor orientation pitch yaw error (A.1.25)	SensorOrientationPitchYawError	ara com
32	Sensor orientation pitch pitch error (A.1.25)	SensorOrientationPitchPitchError	ara com
33	Sensor orientation pitch roll error (A.1.25)	SensorOrientationPitchRollError	ara com
34	Sensor orientation roll yaw error (A.1.25)	SensorOrientationRollYawError	ara com
35	Sensor orientation roll pitch error (A.1.25)	SensorOrientationRollPitchError	ara com
36	Sensor orientation roll roll error (A.1.25)	SensorOrientationRollRollError	ara com
37	Calibration(Table 48)	Calibration	0
38	Calibration process state(A.5.42)	CalibrationProcessState	ara com
39	Sensor origin point correction x(A.5.43)	SensorOriginPointCorrectionX	ara com
40	Sensor origin point correction y(A.5.43)	SensorOriginPointCorrectionY	ara com
41	Sensor origin point correction z(A.5.43)	SensorOriginPointCorrectionZ	ara com
42	Sensor origin point correction x error(A.5.44)	SensorOriginPointCorrectionXError	ara com
43	Sensor origin point correction y error(A.5.44)	SensorOriginPointCorrectionYError	ara com
44	Sensor origin point correction z error(A.5.44)	SensorOriginPointCorrectionZError	ara com
45	Sensor origin translation correction limit xbe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitXbegin	ara com
46	Sensor origin translation correction limit xend(A.5.45)	SensorOriginTranslationCorrection- LimitXend	ara com
47	Sensor origin translation correction limit ybe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitYbegin	ara com
48	Sensor origin translation correction limit yend(A.5.45)	SensorOriginTranslationCorrection- LimitYend	ara com
49	Sensor origin translation correction limit zbe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitZbegin	ara com
50	Sensor origin translation correction limit zend(A.5.45)	SensorOriginTranslationCorrection- LimitZend	ara com
51	Sensor orientation correction yaw(A.5.46)	SensorOrientationCorrectionYaw	ara com
52	Sensor orientation correction pitch(A.5.46)	SensorOrientationCorrectionPitch	ara com





Bit	Reference Singal in ISO23150	Reference Element in USSFeatureService	Option
53	Sensor orientation correction roll(A.5.46)	SensorOrientationCorrectionRoll	ara com
54	Sensor orientation correction yaw error(A.5.47)	SensorOrientationCorrectionYawError	ara com
55	Sensor orientation correction pitch error(A.5.47)	SensorOrientationCorrectionPitchEr- ror	ara com
56	Sensor orientation correction roll error(A.5.47)	SensorOrientationCorrectionRollEr- ror	ara com
57	Sensor pose angle correction limit yawbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitYaw- begin	ara com
58	Sensor pose angle correction limit yawend(A.5.48)	SensorPoseAngleCorrectionLim- itYawend	ara com
59	Sensor pose angle correction limit pitchbe-gin(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchbegin	ara com
60	Sensor pose angle correction limit pitchend(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchend	ara com
61	Sensor pose angle correction limit rollbe- gin(A.5.48)	SensorPoseAngleCorrectionLimitRoll-begin	ara com
62	Sensor pose angle correction limit rol- lend(A.5.48)	SensorPoseAngleCorrectionLimitRol-lend	ara com
63	Sensor cluster(Table 48)	SensorCluster	0
64	Information Interface extension(Table 30)	InformationInterfaceExtension	0
65	Tracking motion model(A.1.13)	TrackingMotionModel	ara com
66	Motion type(A.1.14)	MotionType	ara com
67	Colour model type(A.1.15)	ColourModelType	ara com
68	Information ambiguity domain(Table 30)	InformationAmbiguityDomain	0
69	Radial velocity ambiguity domain begin(A.1.16)	RadialVelocityAmbiguityDomainBegin	ara com
70	Radial velocity ambiguity domain end(A.1.16)	RadialVelocityAmbiguityDomainEnd	ara com
71	Range ambiguity domain begin(A.1.17)	RangeAmbiguityDomainBegin	ara com
72	Range ambiguity domain end(A.1.17)	RangeAmbiguityDomainEnd	ara com
73	Angle azimuth ambiguity domain begin(A.1.18)	AngleAzimuthAmbiguityDomainBegin	ara com
74	Angle azimuth ambiguity domain end(A.1.18)	AngleAzimuthAmbiguityDomainEnd	ara com
75	Angle elevation ambiguity domain begin(A.1.19)	AngleElevationAmbiguityDomainBegin	ara com
76	Angle elevation ambiguity domain end(A.1.19)	AngleElevationAmbiguityDomainEnd	ara com
77	Interface applicability(A.1.20)	InterfaceApplicability	ara com
78	Recognised features capability(A.2.48)	RecognisedFeaturesCapability	ara com
79	Recognised features status(A.2.49)	RecognisedFeaturesStatus	ara com
80	Feature ID(A.2.52)	FeatureId	ara com
81	Object ID reference feature level(A.2.53)	ObjectIdReferenceFeatureLevel	ara com
82	Number of valid observations feature level(A.2.54)	NumberOfValidObservationsFea- tureLevel	Autosar vector
83	Time stamp reference feature level()	TimeStampReferenceFeatureLevel	ara com
84	Observation status feature level(A.2.8)	ObservationStatusFeatureLevel	ara com
85	Position feature level z(A.2.6)	PositionFeatureLevelZ	ara com
86	Position feature level z error(A.2.8)	PositionFeatureLevelZError	ara com
87	Orientation feature level pitch(A.2.9)	OrientationFeatureLevelPitch	ara com
88	Orientation feature level pitch error()	OrientationFeatureLevelPitchError	ara com
89	Height feature level(Table 12)	HeightFeatureLevel	ara com
90	Height feature level error(A.2.56)	HeightFeatureLevelError	ara com
	· '	1	L





Bit	Reference Singal in ISO23150	Reference Element in USSFeatureService	Option
91	Velocity x feature level()	VelocityXFeatureLevel	ara com
92	Velocity x feature level error(A.2.58)	VelocityYObjectLevelError	ara com
93	Measurement status feature level(A.2.61)	MeasurementStatusFeatureLevel	ara com

Table 10.5: Capability Vector of USSFeatureService

10.3 Detection Level Service

10.3.1 RadarDetectionService Capability Vector

The table below includes the capability bit setting for the optional elements for RadarD-etectionService, which also refers to ISO 23150. The Bit setting to 1 means the presence of the optional element, while 0 means absent.

Bit	Reference Singal in ISO23150	Reference Element in RadarDetectionService	Option
1	Interface ID(A.1.4)	InterfaceId	Autosar Service
2	Cycle counter(A.1.6.1)	CycleCounter	ara com
3	Interface cycle time(A.1.7)	InterfaceCycleTime	ara com
4	Interface cycle time variation(A.1.8)	InterfaceCycleTimeVariation	ara com
5	Information vehicle coordinate system(Table 46)	InformationVehicleCoordinateSystem	0
6	Information sensor pose(Table 46)	InformationSensorPose	0
7	Sensor origin point x error(A.1.23)	SensorOriginPointXError	ara com
8	Sensor origin point y error(A.1.23)	SensorOriginPointYError	ara com
9	Sensor origin point z error(A.1.23)	SensorOriginPointZError	ara com
10	Sensor origin point x x error (A.1.23)	SensorOriginPointXXError	ara com
11	Sensor origin point x y error (A.1.23)	SensorOriginPointXYError	ara com
12	Sensor origin point x z error (A.1.23)	SensorOriginPointXZError	ara com
13	Sensor origin point y x error (A.1.23)	SensorOriginPointYXError	ara com
14	Sensor origin point y y error (A.1.23)	SensorOriginPointYYError	ara com
15	Sensor origin point y z error (A.1.23)	SensorOriginPointYZError	ara com
16	Sensor origin point z x error (A.1.23)	SensorOriginPointZXError	ara com
17	Sensor origin point z y error (A.1.23)	SensorOriginPointZYError	ara com
18	Sensor origin point z z error (A.1.23)	SensorOriginPointZZError	ara com
19	Sensor orientation yaw error(A.1.25)	SensorOrientationYawError	ara com
20	Sensor orientation pitch error(A.1.25)	SensorOrientationPitchError	ara com
21	Sensor orientation roll error(A.1.25)	SensorOrientationRollError	ara com
22	Sensor orientation yaw yaw error (A.1.25)	SensorOrientationYawYawError	ara com
23	Sensor orientation yaw pitch error (A.1.25)	SensorOrientationYawPitchError	ara com
24	Sensor orientation yaw roll error (A.1.25)	SensorOrientationYawRollError	ara com
25	Sensor orientation pitch yaw error (A.1.25)	SensorOrientationPitchYawError	ara com
26	Sensor orientation pitch pitch error (A.1.25)	SensorOrientationPitchPitchError	ara com
27	Sensor orientation pitch roll error (A.1.25)	SensorOrientationPitchRollError	ara com



Bit	Reference Singal in ISO23150	Reference Element in RadarDetectionService	Option
28	Sensor orientation roll yaw error (A.1.25)	SensorOrientationRollYawError	ara com
	, , ,		
29	Sensor orientation roll pitch error (A.1.25)	SensorOrientationRollPitchError	ara com
30	Sensor orientation roll roll error (A.1.25)	SensorOrientationRollRollError	ara com
31	Calibration(Table 48)	Calibration	0
32	Calibration process state(A.5.42)	CalibrationProcessState	ara com
33	Sensor origin point correction x(A.5.43)	SensorOriginPointCorrectionX	ara com
34	Sensor origin point correction y(A.5.43)	SensorOriginPointCorrectionY	ara com
35	Sensor origin point correction z(A.5.43)	SensorOriginPointCorrectionZ	ara com
36	Sensor origin point correction x error(A.5.44)	SensorOriginPointCorrectionXError	ara com
37	Sensor origin point correction y error(A.5.44)	SensorOriginPointCorrectionYError	ara com
38	Sensor origin point correction z error(A.5.44)	SensorOriginPointCorrectionZError	ara com
39	Sensor origin translation correction limit xbe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitXbegin	ara com
40	Sensor origin translation correction limit xend(A.5.45)	SensorOriginTranslationCorrection-LimitXend	ara com
41	Sensor origin translation correction limit ybe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitYbegin	ara com
42	Sensor origin translation correction limit yend(A.5.45)	SensorOriginTranslationCorrection- LimitYend	ara com
43	Sensor origin translation correction limit zbe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitZbegin	ara com
44	Sensor origin translation correction limit zend(A.5.45)	SensorOriginTranslationCorrection- LimitZend	ara com
45	Sensor orientation correction yaw(A.5.46)	SensorOrientationCorrectionYaw	ara com
46	Sensor orientation correction pitch(A.5.46)	SensorOrientationCorrectionPitch	ara com
47	Sensor orientation correction roll(A.5.46)	SensorOrientationCorrectionRoll	ara com
48	Sensor orientation correction yaw error(A.5.47)	SensorOrientationCorrectionYawError	ara com
49	Sensor orientation correction pitch error(A.5.47)	SensorOrientationCorrectionPitchEr- ror	ara com
50	Sensor orientation correction roll error(A.5.47)	SensorOrientationCorrectionRollEr-ror	ara com
51	Sensor pose angle correction limit yawbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitYaw- begin	ara com
52	Sensor pose angle correction limit yawend(A.5.48)	SensorPoseAngleCorrectionLim- itYawend	ara com
53	Sensor pose angle correction limit pitchbe-gin(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchbegin	ara com
54	Sensor pose angle correction limit pitchend(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchend	ara com
55	Sensor pose angle correction limit rollbe- gin(A.5.48)	SensorPoseAngleCorrectionLimitRoll-begin	ara com
56	Sensor pose angle correction limit rol- lend(A.5.48)	SensorPoseAngleCorrectionLimitRol-lend	ara com
57	Sensor cluster(Table 48)	SensorCluster	0
58	Tracking motion model(A.1.13)	TrackingMotionModel	ara com
59	Motion type(A.1.14)	MotionType	ara com
60	Colour model type(A.1.15)	ColourModelType	ara com
61	Radial velocity ambiguity domain begin(A.1.16)	RadialVelocityAmbiguityDomainBegin	ara com





Bit	Reference Singal in ISO23150	Reference Element in RadarDetectionService	Option
62	Radial velocity ambiguity domain end(A.1.16)	RadialVelocityAmbiguityDomainEnd	ara com
63	Range ambiguity domain begin(A.1.17)	RangeAmbiguityDomainBegin	ara com
64	Range ambiguity domain end(A.1.17)	RangeAmbiguityDomainEnd	ara com
65	Angle azimuth ambiguity domain begin(A.1.18)	AngleAzimuthAmbiguityDomainBegin	ara com
66	Angle azimuth ambiguity domain end(A.1.18)	AngleAzimuthAmbiguityDomainEnd	ara com
67	Angle elevation ambiguity domain begin(A.1.19)	AngleElevationAmbiguityDomainBegin	ara com
68	Angle elevation ambiguity domain end(A.1.19)	AngleElevationAmbiguityDomainEnd	ara com
69	Interface applicability(A.1.20)	InterfaceApplicability	ara com
70	Recognised detections capability(A.2.48)	RecognisedDetectionsCapability	ara com
71	Recognised detections status(A.2.49)	RecognisedDetectionsStatus	ara com
72	Object ID reference detection level(A.2.52)	ObjectIdReferenceDetectionLevel	ara com
73	Feature ID reference(A.2.53)	FeatureIdReference	ara com
74	Radar cross section error(A.2.8)	RadarCrossSectionError	ara com
75	Signal to noise ratio detection level error()	SignalToNoiseRatioDetectionLevelEr-ror	ara com
76	Multi target probability(Table 12)	MultiTargetProbability	ara com
77	Ambiguity ID(A.1.10.2)	AmbiguityId	ara com
78	Detection ambiguity probability(A.1.11.2)	DetectionAmbiguityProbability	ara com
79	Free space probability(A.1.12.2)	FreeSpaceProbability	ara com
80	Number of valid detection classifications()	NumberOfValidDetectionClassifications	Autosar vector
81	Detection classification type(A.2.1)	DetectionClassificationType	ara com
82	Detection classification type confidence(A.2.2)	DetectionClassificationTypeConfidence	ara com
83	Position elevation(A.2.7)	PositionElevation	ara com
84	Position elevation error(A.2.9)	PositionElevationError	ara com
85	Relative velocity radial distance error()	RelativeVelocityRadialDistanceError	ara com

Table 10.6: Capability Vector of RadarDetectionService

10.3.2 LidarDetectionService Capability Vector

The table below includes the capability bit setting for the optional elements for LidarDetectionService, which also refers to ISO 23150. The Bit setting to 1 means the presence of the optional element, while 0 means absent.

Bit	Reference Singal in ISO23150	Reference Element in LidarDetectionService	Option
1	Interface ID(A.1.4)	InterfaceId	Autosar Service
2	Cycle counter(A.1.6.1)	CycleCounter	ara com
3	Interface cycle time(A.1.7)	InterfaceCycleTime	ara com
4	Interface cycle time variation(A.1.8)	InterfaceCycleTimeVariation	ara com
5	Information vehicle coordinate system(Table 46)	InformationVehicleCoordinateSystem	0
6	Information sensor pose(Table 46)	InformationSensorPose	0





Bit	Reference Singal in ISO23150	Reference Element in LidarDetectionService	Option
7	Sensor origin point x error(A.1.23)	SensorOriginPointXError	•
	Sensor origin point x error(A.1.23) Sensor origin point y error(A.1.23)		ara com
8		SensorOriginPointYError	ara com
9	Sensor origin point z error(A.1.23)	SensorOriginPointZError	ara com
10	Sensor origin point x x error (A.1.23)	SensorOriginPointXXError	ara com
11	Sensor origin point x y error (A.1.23)	SensorOriginPointXYError	ara com
12	Sensor origin point x z error (A.1.23)	SensorOriginPointXZError	ara com
13	Sensor origin point y x error (A.1.23)	SensorOriginPointYXError	ara com
14	Sensor origin point y y error (A.1.23)	SensorOriginPointYYError	ara com
15	Sensor origin point y z error (A.1.23)	SensorOriginPointYZError	ara com
16	Sensor origin point z x error (A.1.23)	SensorOriginPointZXError	ara com
17	Sensor origin point z y error (A.1.23)	SensorOriginPointZYError	ara com
18	Sensor origin point z z error (A.1.23)	SensorOriginPointZZError	ara com
19	Sensor orientation yaw error(A.1.25)	SensorOrientationYawError	ara com
20	Sensor orientation pitch error(A.1.25)	SensorOrientationPitchError	ara com
21	Sensor orientation roll error(A.1.25)	SensorOrientationRollError	ara com
22	Sensor orientation yaw yaw error (A.1.25)	SensorOrientationYawYawError	ara com
23	Sensor orientation yaw pitch error (A.1.25)	SensorOrientationYawPitchError	ara com
24	Sensor orientation yaw roll error (A.1.25)	SensorOrientationYawRollError	ara com
25	Sensor orientation pitch yaw error (A.1.25)	SensorOrientationPitchYawError	ara com
26	Sensor orientation pitch pitch error (A.1.25)	SensorOrientationPitchPitchError	ara com
27	Sensor orientation pitch roll error (A.1.25)	SensorOrientationPitchRollError	ara com
28	Sensor orientation roll yaw error (A.1.25)	SensorOrientationRollYawError	ara com
29	Sensor orientation roll pitch error (A.1.25)	SensorOrientationRollPitchError	ara com
30	Sensor orientation roll roll error (A.1.25)	SensorOrientationRollRollError	ara com
31	Calibration(Table 48)	Calibration	0
32	Calibration process state(A.5.42)	CalibrationProcessState	ara com
33	Sensor origin point correction x(A.5.43)	SensorOriginPointCorrectionX	ara com
34	Sensor origin point correction y(A.5.43)	SensorOriginPointCorrectionY	ara com
35	Sensor origin point correction z(A.5.43)	SensorOriginPointCorrectionZ	ara com
36	Sensor origin point correction x error(A.5.44)	SensorOriginPointCorrectionXError	ara com
37	Sensor origin point correction y error(A.5.44)	SensorOriginPointCorrectionYError	ara com
38	Sensor origin point correction z error(A.5.44)	SensorOriginPointCorrectionZError	ara com
39	Sensor origin translation correction limit xbe-gin(A.5.45)	SensorOriginTranslationCorrection- LimitXbegin	ara com
40	Sensor origin translation correction limit xend(A.5.45)	SensorOriginTranslationCorrection- LimitXend	ara com
41	Sensor origin translation correction limit ybe-gin(A.5.45)	SensorOriginTranslationCorrection- LimitYbegin	ara com
42	Sensor origin translation correction limit yend(A.5.45)	SensorOriginTranslationCorrection- LimitYend	ara com
43	Sensor origin translation correction limit zbe-gin(A.5.45)	SensorOriginTranslationCorrection- LimitZbegin	ara com
44	Sensor origin translation correction limit zend(A.5.45)	SensorOriginTranslationCorrection- LimitZend	ara com
45	Sensor orientation correction yaw(A.5.46)	SensorOrientationCorrectionYaw	ara com
46	Sensor orientation correction pitch(A.5.46)	SensorOrientationCorrectionPitch	ara com





Recognised detections capability (A.1.10.8) RecognisedDetectionsCapability Recognised detections status (A.1.11.8) RecognisedDetectionsStatus RecognisedDetectionStatus ReflectivityError ReflectivityError ReflectivityError Reflectivi			Δ	
Sensor orientation correction yaw error(A.5.47) Sensor orientation correction pitch error(A.5.47) Sensor orientation correction pitch error(A.5.47) Sensor orientation correction orientation correction pitch error(A.5.47) Sensor pose angle correction limit yawbe gin(A.5.48) Sensor pose angle correction limit pitches gin(A.5.48) Sensor pose angle correction limit rolles gin(A.5.48) Sensor pose angle correction limit rolled gin(A.5.48) Sensor pose angle correction limit r	Bit	Reference Singal in ISO23150	Reference Element in LidarDetectionService	Option
Sensor orientation correction pitch error(A.5.47) Sensor orientation correction foll error(A.5.47) Sensor orientation correction foll error(A.5.47) Sensor orientation correction folleror (A.5.47) Sensor orientation correction folleror (A.5.47) Sensor orientation correction folleror (A.5.47) Sensor orientation correction folleror (A.5.48) Sensor orientation correction folling for	47	Sensor orientation correction roll(A.5.46)	SensorOrientationCorrectionRoll	ara com
Sensor pose angle correction limit yawbe- gin(A.5.48) Sensor pose angle correction limit pitchele- gin(A.5.48) Sensor pose angle correction limit roll- pitchend(A.5.48) Sensor pose angle correction limit roll- pitchend pitch	48	Sensor orientation correction yaw error(A.5.47)	SensorOrientationCorrectionYawError	ara com
Sensor pose angle correction limit yawbe- gin(A.5.48) Sensor pose angle correction limit sensorPoseAngleCorrectionLimityaw- gyawond(A.5.48) Sensor pose angle correction limit pitchbe- gin(A.5.48) Sensor pose angle correction limit pitchbe- gin(A.5.48) Sensor pose angle correction limit pitchbe- gin(A.5.48) Sensor pose angle correction limit roll- pitchend(A.5.48) Sensor pose angle correction limit roll- gin(A.5.48) Sensor pose angle correction limit roll- gin(A.5.48) Sensor pose angle correction limit roll- lend(A.5.48) Sensor pose angle correction limit rol- lend(A.5.48) Sensor pose limit rol- lend(A.5.48) Sensor pose angle correction limit rol- lend(A.5.48) Sensor pose a	49	Sensor orientation correction pitch error(A.5.47)		ara com
Sensor pose angle correction limit SensorPoseAngleCorrectionLimit strawond straw	50	Sensor orientation correction roll error(A.5.47)		ara com
yawend(A.5.48) Sensor pose angle correction limit pitchbe- gin(A.5.48) Sensor pose angle correction limit pitchbe- pitchbegin pose angle correction limit pitchbe- pitchend(A.5.48) Sensor pose angle correction limit rollbe- gin(A.5.48) Sensor pose angle correction limit rollbe- gin(A.5.48) Sensor pose angle correction limit rollbe- gin(A.5.48) Sensor pose angle correction limit roll- begin Sensor pose angle correction limit roll- lend(A.5.48) Sensor pose angle correction limit roll- lend(A.5.48) Sensor pose angle correction limit roll- lend(A.5.48) Sensor pose angle correction limit roll- sensor pose angle correction limit roll- lend(A.5.40) Radial velocity ambiguity domain begin A.1.16) Radial velocity ambiguity domain begin A.1.16) Radial velocity ambiguity domain pose pose	51	, ,	_	ara com
gin(A.5.48) Sensor pose angle correction limit pitchend(A.5.48) Sensor pose angle correction limit rollibegin SensorPoseAngleCorrectionLimit-pitchend(A.5.48) Sensor pose angle correction limit rollibegin SensorPoseAngleCorrectionLimitRoll-gin(A.5.48) Sensor pose angle correction limit rollibegin SensorPoseAngleCorrectionLimitRoll-gin(A.5.48) Sensor cluster(Table 48) Sensor cluster(Table 48) Sensor cluster (Table 48) Sensor cluster (Table 48) Information Interface extension(Table 30) InformationInterfaceExtension Tracking motion model(A.1.13) Tracking motion model(A.1.14) Motion type(A.1.14) Motion type(A.1.15) Colour model type(A.1.15) Colour model type(A.1.15) Colour model type(A.1.15) Colour model type(A.1.16) Radial velocity ambiguity domain begin(A.1.16) Radial velocity ambiguity domain begin(A.1.16) Radial velocity ambiguity domain end(A.1.17) RangeAmbiguityDomainBegin Range ambiguity domain end(A.1.17) RangeAmbiguityDomainBegin Range ambiguity domain end(A.1.18) RangeAmbiguityDomainBegin Range armuth ambiguity domain begin(A.1.18) RangeAmbiguityDomainEnd ara com Angle azimuth ambiguity domain end(A.1.18) AngleAzimuthAmbiguityDomainBegin Ara com Angle alevation ambiguity domain begin(A.1.19) AngleElevationAmbiguityDomainBegin Ara com Angle alevation ambiguity domain end(A.1.19) AngleElevationAmbiguityDomainBegin Ara com Angle elevation ambiguity domain end(A.1.19) Recognised Detections Status(A.1.11.8) Recognised DetectionsCapability Ara com Reflectivity error Recognised detections Status(A.1.11.8) RecognisedDetectionsStatus Ara com Feature ID reference detection level(A.4.2) Object ID reference detection level(A.4.2) Pree Space Probability Reflectivity error Reflectivity error Reflectivity error ara com Reflectivity error Reflectivity error ara com Pree space probability(A.1.10) Reflectivity error Reflectivity error ara com Reflectivity error ara com Pree space probability(A.1.10) Reflectivity error Reflectivity error Reflectivity error ara	52		=	ara com
pitchend(A.5.48) Sensor pose angle correction limit rollbegin SensorPoseAngleCorrectionLimitRoll-gin(A.5.48) Sensor pose angle correction limit rollbegin SensorPoseAngleCorrectionLimitRoll-lend ara com lend(A.5.48) Sensor pose angle correction limit rollbegin SensorPoseAngleCorrectionLimitRoll-lend SensorCluster O Information Interface extension(Table 30) InformationInterfaceExtension O Tracking motion model(A.1.13) Tracking motion model(A.1.14) MotionType ara com ara com ara com o Information InterfaceExtension O Tracking motion model(A.1.15) ColourModelType ara com ara com ara com o Information ambiguity domain Degin(A.1.16) Radial velocity person ara com o Information ara com o Information ambiguity domain begin(A.1.16) Radial velocity ambiguity domain begin(A.1.16) Radial velocity ambiguity domain end(A.1.17) RangeAmbiguityDomainEnd ara com a	53		=	ara com
begin Sensor pose angle correction limit rol- lend(A.5.48) Sensor pose angle correction limit rol- lend(A.5.48) Sensor cluster(Table 48) SensorCluster O Information Interface extension(Table 30) InformationInterfaceExtension O Tracking motion model(A.1.13) TrackingMotionModel ara com Motiontype(A.1.14) SensorCluster Colour model type(A.1.14) Colour model type(A.1.15) Information ambiguity domain(Table 30) InformationAmbiguityDomain A gadial velocity ambiguity domain begin(A.1.16) Radial velocityAmbiguityDomainBegin A Radial velocity ambiguity domain end(A.1.16) Radial velocityAmbiguityDomainBegin A Radial velocity ambiguity domain end(A.1.17) RangeAmbiguityDomainBegin Ara com Range ambiguity domain begin(A.1.18) RangeAmbiguityDomainBegin Ara com Angle azimuth ambiguity domain begin(A.1.18) AngleAzimuthAmbiguityDomainBegin Ara com Angle elevation ambiguity domain end(A.1.19) Angle elevation ambiguity domain end(A.1.19) Angle elevation ambiguity domain end(A.1.19) Recognised detections capability(A.1.20) Therface applicability(A.1.20) Recognised detections status(A.1.11.8) RecognisedDetectionsCapability Ara com Reflectivity error(A.4.23) Reflectivity Error And Detection classification type(A.4.14) Detection classification type(A.4.14) Detection classification type confidence(A.4.15) Detection classification type confidence(A.4.15) ReightLidar Height lidar error(A.4.21) Recognised Height lidar error(A.4.21) Reight lidar error(A.4.21)	54	, ,	=	ara com
lend(A.5.48) lend Sensor Cluster(Table 48) Sensor Cluster Information Interface extension(Table 30) InformationInterfaceExtension Information Interface extension(Table 30) InformationInterfaceExtension Information model(A.1.13) ara com Tracking motion model(A.1.14) MotionType ara com Colour model type(A.1.15) ColourModelType ara com Information ambiguity domain(Table 30) InformationAmbiguityDomain Information ambiguity domain(Table 30) InformationAmbiguityDomainBegin ara com Radial velocity ambiguity domain begin(A.1.16) RadialVelocityAmbiguityDomainBegin ara com Range ambiguity domain begin(A.1.17) RangeAmbiguityDomainBegin ara com Range ambiguity domain end(A.1.17) RangeAmbiguityDomainEnd ara com Angle azimuth ambiguity domain begin(A.1.18) AngleAzimuthAmbiguityDomainBegin ara com Angle alaimuth ambiguity domain begin(A.1.18) AngleAzimuthAmbiguityDomainBegin ara com Angle elevation ambiguity domain begin(A.1.19) AngleElevationAmbiguityDomainEnd ara com Angle elevation ambiguity domain end(A.1.19) AngleElevationAmbiguityDomainEnd ara com Interface applicability(A.1.20) InterfaceApplicability ara com Recognised detections capability(A.1.10.8) RecognisedDetectionsCapability ara com Recognised detections status(A.1.11.8) RecognisedDetectionsCapability ara com Reflectivity error ara com Feature ID reference detection level(A.4.2) ObjectIdReference ara com Reflectivity error(A.4.23) ReflectivityError ara com Reflectivity error(A.4.23) ReflectivityError ara com Number of valid detection classifications(A.4.13) NumberOfValidDetectionClassificat Autosar vector tions Detection classification type (A.1.4) DetectionClassificationType ara com Betectivity error(A.4.20) HeightLidar Height lidar error(A.4.21) HeightLidarError ara com	55		_	ara com
Information Interface extension (Table 30) Information Interface extension (Table 30) Iracking motion model(A.1.13) Iracking Motion Type Iracking motion model(A.1.14) Motion Type Iracking motion model (bype(A.1.15) Information Ambiguity Domain (Table 30) Information Ambiguity Domain Domain (Table 30) Information Ambiguity Domain Domain Domain Degin(A.1.16) Iracking Motion Iracking Motion Information Ambiguity Domain Domain Domain Degin(A.1.16) Iracking Motion Iracking	56		=	ara com
Tracking motion model(A.1.13) Tracking MotionType Tracking motion type(A.1.14) MotionType Tracking motion type(A.1.14) MotionType Tracking motion type(A.1.14) MotionType Tracking motion type(A.1.15) Tracking MotionType Tracking Tracking MotionType Tracking MotionType Tracking MotionType Tracking Tracking MotionType Tracking Tracking Tracking Tracking Tracom Tracking	57	Sensor cluster(Table 48)	SensorCluster	0
Motion type(A.1.14) MotionType ara com Colour model type(A.1.15) ColourModelType ara com Andial velocity ambiguity domain (Table 30) Information Ambiguity Domain (Table 30) Radial velocity ambiguity domain begin(A.1.16) RadialVelocityAmbiguityDomainBegin ara com Andial velocity ambiguity domain end(A.1.16) RadialVelocityAmbiguityDomainBegin ara com Radial velocity ambiguity domain end(A.1.17) RangeAmbiguityDomainBegin ara com Range ambiguity domain begin(A.1.17) RangeAmbiguityDomainBegin ara com Range ambiguity domain end(A.1.17) RangeAmbiguityDomainBegin ara com Range azimuth ambiguity domain begin(A.1.18) RangeAzimuthAmbiguityDomainBegin ara com Range elevation ambiguity domain begin(A.1.19) Angle elevation ambiguity domain begin(A.1.19) AngleElevationAmbiguityDomainBegin ara com Interface applicability(A.1.20) InterfaceApplicability Ara com Recognised detections capability(A.1.10.8) Recognised DetectionStatus Recognised detections status(A.1.11.8) Recognised DetectionStatus Recognised Detection level(A.4.2) Object ID reference detection level(A.4.2) Object ID reference detection level(A.4.2) Peature ID reference(A.4.3) Reflectivity error (A.4.23) Reflectivity error (A.4.24) Recognised Detection Classification type (A.4.14) Recognised Detection Classification type (A.4.14) Recognised Detection Classification type (A.4.14)	58	Information Interface extension(Table 30)	InformationInterfaceExtension	0
Colour model type(A.1.15) Colour model type(A.1.16) Information ambiguity domain (Table 30) Radial velocity ambiguity domain begin(A.1.16) Radial velocity ambiguity domain end(A.1.16) Radial velocity ambiguity domain end(A.1.17) Range Ambiguity Domain Begin ara com Range ambiguity domain end(A.1.17) Range Ambiguity Domain End ara com Range ambiguity domain end(A.1.17) Range Ambiguity Domain End ara com Range ambiguity domain end(A.1.18) Angle Azimuth Ambiguity Domain Begin ara com Range armuth ambiguity domain begin(A.1.18) Angle Azimuth Ambiguity Domain End ara com Range elevation ambiguity domain end(A.1.19) Angle Elevation Ambiguity Domain End ara com Recognised detection ambiguity domain end(A.1.19) Angle Elevation Ambiguity Domain End ara com Interface applicability(A.1.20) InterfaceApplicability Ara com Recognised detections capability(A.1.10.8) Recognised Detection Status Recognised Detection Status Ara com Recognised Detection Level(A.4.2) Object ID reference detection level(A.4.2) Object ID reference detection level(A.4.2) Reflectivity error Reflectivity error(A.4.23) Reflectivity error Reflectivity error(A.4.23) Reflectivity Error Ara com Number of valid detection classifications(A.4.13) Number of valid detection classifications(A.4.13) Detection classification type (A.4.14) Detection Classification Type Reight Lidar Reight Lidar Recognised Detection Level Reight Lidar Recognised Level Reight Lidar Recognised Detection Classification Type Autosar vector toons Reflectivity error Reflectivit	59	Tracking motion model(A.1.13)	TrackingMotionModel	ara com
Information ambiguity domain(Table 30) InformationAmbiguityDomain Radial velocity ambiguity domain begin(A.1.16) Radial velocity ambiguity domain begin(A.1.16) Radial velocity ambiguity domain begin(A.1.16) Radial velocity ambiguity domain begin(A.1.17) RangeAmbiguityDomainBegin ara com Range ambiguity domain begin(A.1.17) RangeAmbiguityDomainBegin ara com Range ambiguity domain end(A.1.17) RangeAmbiguityDomainBegin ara com Range azimuth ambiguity domain begin(A.1.18) Angle azimuth ambiguity domain begin(A.1.18) Angle azimuthAmbiguityDomainBegin ara com Range elevation ambiguity domain begin(A.1.19) Angle elevation Angle elevation ambiguity domain end(A.1.19) Angle elevation Angle elevation ara com Interface applicability Ara com Recognised detections capability(A.1.10.8) Recognised Detection Status Ara com Recognised detections Status (A.1.11.8) Recognised Detection Status Ara com Detection Preference detection level(A.4.2) Object ID reference Detection Level Ara com Reflectivity error(A.4.23) Reflectivity error Free space probability (A.4.12) Free Space Probability Autosar vector tions Number of valid detection classifications(A.4.13) Number of valid Detection Classification Type Ara com Detection classification type (A.4.14) Detection Classification Type Confidence Reight Lidar Ara com	60	Motion type(A.1.14)	MotionType	ara com
Radial velocity ambiguity domain begin(A.1.16) Radial velocity Ambiguity domain begin(A.1.16) Radial velocity Ambiguity domain end(A.1.16) Radial velocity Ambiguity domain end(A.1.17) Range Ambiguity Domain Engin Range ambiguity domain begin(A.1.17) Range Ambiguity Domain Engin Range ambiguity domain end(A.1.18) Range ambiguity domain begin(A.1.18) Range Ambiguity Domain End Range azimuth ambiguity domain begin(A.1.18) Range Ambiguity Domain End Range azimuth ambiguity domain begin(A.1.18) Range Elevation Ambiguity Domain End Range elevation ambiguity domain end(A.1.19) Range Elevation Ambiguity Domain End Range elevation ambiguity domain begin(A.1.19) Range Elevation Ambiguity Domain End Range elevation ambiguity domain end(A.1.19) Range Elevation Ambiguity Domain End Range elevation ambiguity domain end(A.1.19) Range Elevation Ambiguity Domain End	61	Colour model type(A.1.15)	ColourModelType	ara com
Radial velocity ambiguity domain end(A.1.16) Radial velocity Ambiguity domain end(A.1.17) Range Ambiguity Domain Begin Range ambiguity domain begin(A.1.17) Range Ambiguity Domain Begin Range ambiguity domain end(A.1.17) Range Ambiguity Domain End Range ambiguity domain end(A.1.18) Range Ambiguity Domain End Range azimuth ambiguity domain begin(A.1.18) Range Ambiguity Domain End Range azimuth ambiguity domain begin(A.1.18) Range Azimuth Ambiguity Domain End Range azimuth ambiguity domain end(A.1.18) Range Elevation Ambiguity Domain End Range elevation ambiguity domain end(A.1.19) Range Elevation Ambiguity Domain End Range elevation ambiguity domain end(A.1.19) Range Elevation Ambiguity Domain End Range elevation ambiguity domain end(A.1.19) Range Elevation Ambiguity Domain End Range elevation ambiguity domain end(A.1.19) Range Elevation Ambiguity Domain End Range elevation ambiguity domain end(A.1.19) Range Elevation Ambiguity Domain End Range elevation ambiguity domain end(A.1.19) Range Elevation Ambiguity Domain End Range elevation ambiguity domain end(A.1.19) Range Ambiguity Domain End Range embiguity Embiguity Domain End Range Embiguity Embiguity Embiguity Domain End Range Embiguity Embi	62	Information ambiguity domain(Table 30)	InformationAmbiguityDomain	0
Range ambiguity domain begin(A.1.17) RangeAmbiguityDomainBegin ara com Range ambiguity domain end(A.1.17) RangeAmbiguityDomainBegin ara com Range ambiguity domain end(A.1.18) RangeAmbiguityDomainEnd ara com Range azimuth ambiguity domain begin(A.1.18) RangleAzimuthAmbiguityDomainBegin ara com Rangle azimuth ambiguity domain end(A.1.18) RangleAzimuthAmbiguityDomainEnd ara com Rangle elevation ambiguity domain begin(A.1.19) RangleElevationAmbiguityDomainEnd ara com Rangle elevation ambiguity domain end(A.1.19) RangleElevationAmbiguityDomainEnd ara com Recognised detections capability(A.1.20) RecognisedDetectionsCapability ara com Recognised detections status(A.1.11.8) RecognisedDetectionsCapability ara com Recognised detections status(A.1.11.8) RecognisedDetectionsStatus ara com Diject ID reference detection level(A.4.2) Object ID referenceDetectionLevel ara com Reflectivity error(A.4.23) ReflectivityError ara com Reflectivity error(A.4.23) ReflectivityError ara com Number of valid detection classifications(A.4.13) NumberOfValidDetectionClassification Number of valid detection type (A.4.14) DetectionClassificationType Recognised Capability (A.4.20) Reflectivity error(A.4.20) RecognisedDetectionClassificationTypeConfinara com Recognised detection classification type confidence(A.4.15) Recog	63	Radial velocity ambiguity domain begin(A.1.16)	RadialVelocityAmbiguityDomainBegin	ara com
Range ambiguity domain end(A.1.17) RangeAmbiguityDomainEnd Angle azimuth ambiguity domain begin(A.1.18) AngleAzimuthAmbiguityDomainBegin Range ambiguity domain begin(A.1.18) AngleAzimuthAmbiguityDomainBegin Range azimuth ambiguity domain end(A.1.18) AngleAzimuthAmbiguityDomainEnd Range alevation ambiguity domain begin(A.1.19) AngleElevationAmbiguityDomainBegin Range applicability(A.1.20) Recognised detections capability(A.1.20) Recognised detections capability(A.1.10.8) RecognisedDetectionsCapability Recognised detections status(A.1.11.8) RecognisedDetectionsStatus Recognised detections status(A.1.11.8) RecognisedDetectionsStatus Recognised DetectionsCapability Reflectivity Proference detection level(A.4.2) Detection Preference detection level(A.4.2) ReflectivityError Reflectivity error(A.4.23) ReflectivityError Reflectivity error(A.4.23) ReflectivityError Respace probability(A.4.12) RespaceProbability RespacePr	64	Radial velocity ambiguity domain end(A.1.16)	RadialVelocityAmbiguityDomainEnd	ara com
Angle azimuth ambiguity domain begin(A.1.18) AngleAzimuthAmbiguityDomainBegin ara com Angle azimuth ambiguity domain end(A.1.18) AngleAzimuthAmbiguityDomainEnd ara com Angle elevation ambiguity domain begin(A.1.19) AngleElevationAmbiguityDomainBegin ara com Angle elevation ambiguity domain end(A.1.19) AngleElevationAmbiguityDomainBegin ara com Interface applicability(A.1.20) InterfaceApplicability Ara com Recognised detections capability(A.1.10.8) RecognisedDetectionsCapability ara com Recognised detection status(A.1.11.8) RecognisedDetectionsStatus ara com Object ID reference detection level(A.4.2) ObjectIdReferenceDetectionLevel ara com Feature ID reference(A.4.3) ReflectivityError ara com Reflectivity error(A.4.23) ReflectivityError ara com Number of valid detection classifications(A.4.13) Number of valid detection level(A.4.14) DetectionClassificationType Detection classification type(A.4.14) DetectionClassificationTypeConfidence Height lidar (A.4.20) Height LidarError Ara com Ara com Ara com Belight lidar error(A.4.21) Height LidarError Ara com Ara com	65	Range ambiguity domain begin(A.1.17)	RangeAmbiguityDomainBegin	ara com
Angle azimuth ambiguity domain end(A.1.18) AngleAzimuthAmbiguityDomainEnd ara com Angle elevation ambiguity domain begin(A.1.19) AngleElevationAmbiguityDomainBegin ara com Angle elevation ambiguity domain end(A.1.19) AngleElevationAmbiguityDomainEnd ara com Interface applicability(A.1.20) InterfaceApplicability Recognised detections capability(A.1.10.8) RecognisedDetectionsCapability ara com Recognised detections status(A.1.11.8) RecognisedDetectionsStatus ara com Object ID reference detection level(A.4.2) ObjectIdReferenceDetectionLevel ara com Feature ID reference(A.4.3) ReflectivityError ara com Reflectivity error(A.4.23) ReflectivityError Ara com Number of valid detection classifications(A.4.13) Number of valid detection type(A.4.14) DetectionClassificationType Detection classification type confidence(A.4.15) DetectionClassificationTypeConfidence Height lidar (A.4.20) Height lidar error(A.4.21) Height Lidar error Angle elevation Angle ElevationAmbiguityDomainEnd ara com RecognisedDetectionAmbiguityDomainEnd ara com RecognisedDetectionScapability Ara	66	Range ambiguity domain end(A.1.17)	RangeAmbiguityDomainEnd	ara com
Angle elevation ambiguity domain begin(A.1.19) AngleElevationAmbiguityDomainBegin ara com Angle elevation ambiguity domain end(A.1.19) AngleElevationAmbiguityDomainBegin ara com Interface applicability(A.1.20) InterfaceApplicability ara com Recognised detections capability(A.1.10.8) RecognisedDetectionsCapability ara com Recognised detections status(A.1.11.8) RecognisedDetectionsStatus ara com Object ID reference detection level(A.4.2) ObjectID reference(A.4.3) FeatureIdReference ara com Reflectivity error(A.4.23) ReflectivityError ara com Reflectivity error (A.4.23) ReflectivityError ara com Number of valid detection classifications(A.4.13) NumberOfValidDetectionClassificat Autosar vector tions Detection classification type(A.4.14) DetectionClassificationType ara com Relight lidar(A.4.20) Height Lidar Height lidar error(A.4.21) HeightLidarError ara com	67	Angle azimuth ambiguity domain begin(A.1.18)	AngleAzimuthAmbiguityDomainBegin	ara com
Angle elevation ambiguity domain end(A.1.19) AngleElevationAmbiguityDomainEnd ara com Interface applicability(A.1.20) InterfaceApplicability ara com Recognised detections capability(A.1.10.8) RecognisedDetectionsCapability ara com Recognised detections status(A.1.11.8) RecognisedDetectionsStatus ara com Object ID reference detection level(A.4.2) ObjectIdReferenceDetectionLevel ara com Feature ID reference(A.4.3) FeatureIdReference ara com Reflectivity error(A.4.23) ReflectivityError ara com Number of valid detection classifications(A.4.13) NumberOfValidDetectionClassification Number of valid detection type(A.4.14) DetectionClassificationType ara com Detection classification type confidence(A.4.15) Height lidar (A.4.20) Height Lidar Height lidar error(A.4.21) HeightLidar ara com	68	Angle azimuth ambiguity domain end(A.1.18)	AngleAzimuthAmbiguityDomainEnd	ara com
Interface applicability (A.1.20) Recognised detections capability (A.1.10.8) Recognised Detections Capability Recognised Detection Capability Recognised D	69	Angle elevation ambiguity domain begin(A.1.19)	AngleElevationAmbiguityDomainBegin	ara com
Recognised detections capability (A.1.10.8) RecognisedDetectionsCapability RecognisedDetectionsStatus RecognisedDetectionStatus RecognisedD	70	Angle elevation ambiguity domain end(A.1.19)	AngleElevationAmbiguityDomainEnd	ara com
Recognised detections status(A.1.11.8) RecognisedDetectionsStatus ara com 74 Object ID reference detection level(A.4.2) 75 Feature ID reference(A.4.3) Reflectivity error(A.4.23) Reflectivity error 76 Reflectivity error(A.4.23) Reflectivity Error 77 Free space probability(A.4.12) RespaceProbability RespaceProbabili	71	Interface applicability(A.1.20)	InterfaceApplicability	ara com
Object ID reference detection level(A.4.2) Object IdReferenceDetectionLevel ara com Feature ID reference(A.4.3) FeatureIdReference ara com Reflectivity error(A.4.23) ReflectivityError ara com Number of valid detection classifications(A.4.13) Detection classification type(A.4.14) DetectionClassificationType Petection classification type confidence(A.4.15) DetectionClassificationTypeConfidence Height lidar(A.4.20) Height Lidar Height lidar error(A.4.21) Ara com ReflectivityError Ara com PreeSpaceProbability Ara com DetectionClassificationType Autosar vector DetectionClassificationType Ara com ReflectivityError Ara com PreeSpaceProbability Autosar vector DetectionClassificationType Ara com ReflectivityError Ara com ReflectivityError Ara com PreeSpaceProbability Autosar vector DetectionClassificationType Ara com ReflectivityError	72	Recognised detections capability(A.1.10.8)	RecognisedDetectionsCapability	ara com
Feature ID reference (A.4.3) FeatureIdReference Reflectivity error (A.4.23) ReflectivityError Free space probability (A.4.12) ReflectivityError ReflectivityErr	73	Recognised detections status(A.1.11.8)	RecognisedDetectionsStatus	ara com
Reflectivity error(A.4.23) ReflectivityError ara com Free space probability (A.4.12) FreeSpaceProbability Rumber of valid detection classifications(A.4.13) RumberOfValidDetectionClassification Detection classification type(A.4.14) DetectionClassificationType ara com Detection classification type confidence(A.4.15) DetectionClassificationTypeConfidence Height lidar(A.4.20) HeightLidar ReflectivityError ara com ReflectivityError ara com Hutosar vector tions DetectionClassificationType ara com ReflectivityError ara com Height lidar error(A.4.21) ReflectivityError ara com HeightLidar ara com ReflectivityError ara com HeightLidarError ara com ReflectivityError ara com HeightLidarError ara com	74	Object ID reference detection level(A.4.2)	ObjectIdReferenceDetectionLevel	ara com
Free Space Probability (A.4.12) Free Space Probability Rumber of valid detection classifications (A.4.13) Petection classification type (A.4.14) Detection classification type confidence (A.4.15) Detection classification type confidence (A.4.15) Detection classification type confidence (A.4.15) Height lidar (A.4.20) Height Lidar Height lidar error (A.4.21) Free Space Probability Autosar vector ara com ara com Height Lidar Autosar vector tions Autosar vector tions Autosar vector tions Autosar vector tions Heteror Classification Type ara com Height Lidar Ara com Autosar vector tions Autosar vector tions Autosar vector tions Autosar vector tions Heteror Classification Type Ara com Ara com Height Lidar error (A.4.21)	75	Feature ID reference(A.4.3)	FeatureIdReference	ara com
Number of valid detection classifications(A.4.13) NumberOfValidDetectionClassification Autosar vector tions Detection classification type(A.4.14) DetectionClassificationType ara com Detection classification type confidence(A.4.15) DetectionClassificationTypeConfidence Height lidar(A.4.20) HeightLidar Autosar vector ara com Height lidar(A.4.21) HeightLidarError Autosar vector ara com ara com	76	Reflectivity error(A.4.23)	ReflectivityError	ara com
Number of valid detection classifications(A.4.13) NumberOfValidDetectionClassification Autosar vector tions Detection classification type(A.4.14) DetectionClassificationType ara com Detection classification type confidence(A.4.15) DetectionClassificationTypeConfidence Height lidar(A.4.20) HeightLidar Autosar vector ara com Height lidar(A.4.21) HeightLidarError Autosar vector ara com ara com	77	Free space probability(A.4.12)	FreeSpaceProbability	ara com
B0 Detection classification type confidence(A.4.15) DetectionClassificationTypeConfidence B1 Height lidar(A.4.20) HeightLidar ara com B2 Height lidar error(A.4.21) HeightLidarError ara com	78	Number of valid detection classifications(A.4.13)		Autosar vector
dence 81 Height lidar(A.4.20) HeightLidar ara com 82 Height lidar error(A.4.21) HeightLidarError ara com	79	Detection classification type(A.4.14)	DetectionClassificationType	ara com
82 Height lidar error(A.4.21) HeightLidarError ara com	80	Detection classification type confidence(A.4.15)		ara com
	81	Height lidar(A.4.20)	HeightLidar	ara com
83 Dynamics(Table 33) LidarDetectionsDynamics was in 715	82	Height lidar error(A.4.21)	HeightLidarError	ara com
	83	Dynamics(Table 33)	LidarDetectionsDynamics	was in 715





Bit	Reference Singal in ISO23150	Reference Element in LidarDetectionService	Option
84	Relative velocity radial distance error(A.4.19)	RelativeVelocityRadialDistanceError	ara com

Table 10.7: Capability Vector of LidarDetectionService

10.3.3 CameraDetectionService Capability Vector

The table below includes the capability bit setting for the optional elements for CameraDetectionService, which also refers to ISO 23150. The Bit setting to 1 means the presence of the optional element, while 0 means absent.

Bit	Reference Singal in ISO23150	Reference Element in CameraDetectionService	Option
1	Interface ID(A.1.4)	InterfaceId	Autosar Service
2	Cycle counter(A.1.6.1)	CycleCounter	ara com
3	Interface cycle time(A.1.7)	InterfaceCycleTime	ara com
4	Interface cycle time variation(A.1.8)	InterfaceCycleTimeVariation	ara com
5	Information vehicle coordinate system(Table 46)	InformationVehicleCoordinateSystem	0
6	Information sensor pose(Table 46)	InformationSensorPose	0
7	Sensor origin point x error(A.1.23)	SensorOriginPointXError	ara com
8	Sensor origin point y error(A.1.23)	SensorOriginPointYError	ara com
9	Sensor origin point z error(A.1.23)	SensorOriginPointZError	ara com
10	Sensor origin point x x error (A.1.23)	SensorOriginPointXXError	ara com
11	Sensor origin point x y error (A.1.23)	SensorOriginPointXYError	ara com
12	Sensor origin point x z error (A.1.23)	SensorOriginPointXZError	ara com
13	Sensor origin point y x error (A.1.23)	SensorOriginPointYXError	ara com
14	Sensor origin point y y error (A.1.23)	SensorOriginPointYYError	ara com
15	Sensor origin point y z error (A.1.23)	SensorOriginPointYZError	ara com
16	Sensor origin point z x error (A.1.23)	SensorOriginPointZXError	ara com
17	Sensor origin point z y error (A.1.23)	SensorOriginPointZYError	ara com
18	Sensor origin point z z error (A.1.23)	SensorOriginPointZZError	ara com
19	Sensor orientation yaw error(A.1.25)	SensorOrientationYawError	ara com
20	Sensor orientation pitch error(A.1.25)	SensorOrientationPitchError	ara com
21	Sensor orientation roll error(A.1.25)	SensorOrientationRollError	ara com
22	Sensor orientation yaw yaw error (A.1.25)	SensorOrientationYawYawError	ara com
23	Sensor orientation yaw pitch error (A.1.25)	SensorOrientationYawPitchError	ara com
24	Sensor orientation yaw roll error (A.1.25)	SensorOrientationYawRollError	ara com
25	Sensor orientation pitch yaw error (A.1.25)	SensorOrientationPitchYawError	ara com
26	Sensor orientation pitch pitch error (A.1.25)	SensorOrientationPitchPitchError	ara com
27	Sensor orientation pitch roll error (A.1.25)	SensorOrientationPitchRollError	ara com
28	Sensor orientation roll yaw error (A.1.25)	SensorOrientationRollYawError	ara com
29	Sensor orientation roll pitch error (A.1.25)	SensorOrientationRollPitchError	ara com
30	Sensor orientation roll roll error (A.1.25)	SensorOrientationRollRollError	ara com
31	Calibration(Table 48)	Calibration	0





		\triangle	
Bit	Reference Singal in ISO23150	Reference Element in CameraDetectionService	Option
32	Calibration process state(A.5.42)	CalibrationProcessState	ara com
33	Sensor origin point correction x(A.5.43)	SensorOriginPointCorrectionX	ara com
34	Sensor origin point correction y(A.5.43)	SensorOriginPointCorrectionY	ara com
35	Sensor origin point correction z(A.5.43)	SensorOriginPointCorrectionZ	ara com
36	Sensor origin point correction x error(A.5.44)	SensorOriginPointCorrectionXError	ara com
37	Sensor origin point correction y error(A.5.44)	SensorOriginPointCorrectionYError	ara com
38	Sensor origin point correction z error(A.5.44)	SensorOriginPointCorrectionZError	ara com
39	Sensor origin translation correction limit xbe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitXbegin	ara com
40	Sensor origin translation correction limit xend(A.5.45)	SensorOriginTranslationCorrection- LimitXend	ara com
41	Sensor origin translation correction limit ybe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitYbegin	ara com
42	Sensor origin translation correction limit yend(A.5.45)	SensorOriginTranslationCorrection- LimitYend	ara com
43	Sensor origin translation correction limit zbe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitZbegin	ara com
44	Sensor origin translation correction limit zend(A.5.45)	SensorOriginTranslationCorrection- LimitZend	ara com
45	Sensor orientation correction yaw(A.5.46)	SensorOrientationCorrectionYaw	ara com
46	Sensor orientation correction pitch(A.5.46)	SensorOrientationCorrectionPitch	ara com
47	Sensor orientation correction roll(A.5.46)	SensorOrientationCorrectionRoll	ara com
48	Sensor orientation correction yaw error(A.5.47)	SensorOrientationCorrectionYawError	ara com
49	Sensor orientation correction pitch error(A.5.47)	SensorOrientationCorrectionPitchEr-ror	ara com
50	Sensor orientation correction roll error(A.5.47)	SensorOrientationCorrectionRollEr- ror	ara com
51	Sensor pose angle correction limit yawbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitYaw- begin	ara com
52	Sensor pose angle correction limit yawend(A.5.48)	SensorPoseAngleCorrectionLim- itYawend	ara com
53	Sensor pose angle correction limit pitchbe- gin(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchbegin	ara com
54	Sensor pose angle correction limit pitchend(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchend	ara com
55	Sensor pose angle correction limit rollbe- gin(A.5.48)	SensorPoseAngleCorrectionLimitRoll-begin	ara com
56	Sensor pose angle correction limit rol- lend(A.5.48)	SensorPoseAngleCorrectionLimitRol-lend	ara com
57	Sensor cluster(Table 48)	SensorCluster	0
58	Tracking motion model(A.1.13)	TrackingMotionModel	ara com
59	Motion type(A.1.14)	MotionType	ara com
60	Information ambiguity domain(Table 30)	InformationAmbiguityDomain	0
61	Radial velocity ambiguity domain begin(A.1.16)	RadialVelocityAmbiguityDomainBegin	ara com
62	Radial velocity ambiguity domain end(A.1.16)	RadialVelocityAmbiguityDomainEnd	ara com
63	Range ambiguity domain begin(A.1.17)	RangeAmbiguityDomainBegin	ara com
64	Range ambiguity domain end(A.1.17)	RangeAmbiguityDomainEnd	ara com
65	Angle azimuth ambiguity domain begin(A.1.18)	AngleAzimuthAmbiguityDomainBegin	ara com





Bit	Reference Singal in ISO23150	Reference Element in CameraDetectionService	Option
66	Angle azimuth ambiguity domain end(A.1.18)	AngleAzimuthAmbiguityDomainEnd	ara com
67	Angle elevation ambiguity domain begin(A.1.19)	AngleElevationAmbiguityDomainBegin	ara com
68	Angle elevation ambiguity domain end(A.1.19)	AngleElevationAmbiguityDomainEnd	ara com
69	Interface applicability(A.1.20)	InterfaceApplicability	ara com
70	Recognised detections capability(A.1.10.8)	RecognisedDetectionsCapability	ara com
71	Recognised detections status(A.1.11.8)	RecognisedDetectionsStatus	ara com
72	Object ID reference detection level(A.4.2)	ObjectIdReferenceDetectionLevel	ara com
73	Feature ID reference(A.4.3)	FeatureIdReference	ara com
74	Free space probability(A.4.12)	FreeSpaceProbability	ara com
75	Shape ambiguity ID(A.4.27)	ShapeAmbiguityId	ara com
76	Colour tone confidence detection level(A.4.29)	ColourToneConfidenceDetectionLevel	ara com
77	Position radial distance(A.4.16)	PositionRadialDistance	ara com
78	Position radial distance error(A.4.17)	PositionRadialDistanceError	ara com
79	Shape reference points(Table 36)	CameraShapesShapeReferencePoints	0
80	Position radial distance(A.4.16)	PositionRadialDistance	ara com
81	Position radial distance error(A.4.17)	PositionRadialDistanceError	ara com
82	Translation rate x detection level(A.4.34)	TranslationRateXDetectionLevel	ara com
83	Translation rate y detection level(A.4.34)	TranslationRateYDetectionLevel	ara com
84	Translation rate z detection level(A.4.34)	TranslationRateZDetectionLevel	ara com
85	Translation rate x detection level error(A.4.35)	TranslationRateXDetectionLevelError	ara com
86	Translation rate y detection level error(A.4.35)	TranslationRateYDetectionLevelError	ara com
87	Translation rate z detection level error(A.4.35)	TranslationRateZDetectionLevelError	ara com

Table 10.8: Capability Vector of CameraDetectionService

10.3.4 USSDetectionService Capability Vector

The table below includes the capability bit setting for the optional elements for USSDetectionService, which also refers to ISO 23150. The Bit setting to 1 means the presence of the optional element, while 0 means absent.

Bit	Reference Singal in ISO23150	Reference Element in USSDetectionService	Option
1	Interface ID(A.1.4)	InterfaceId	Autosar Service
2	Cycle counter(A.1.6.1)	CycleCounter	ara com
3	Interface cycle time(A.1.7)	InterfaceCycleTime	ara com
4	Interface cycle time variation(A.1.8)	InterfaceCycleTimeVariation	ara com
5	Information vehicle coordinate system(Table 46)	InformationVehicleCoordinateSystem	0
6	Information sensor pose(Table 46)	InformationSensorPose	0
7	Sensor origin point x error(A.1.23)	SensorOriginPointXError	ara com
8	Sensor origin point y error(A.1.23)	SensorOriginPointYError	ara com
9	Sensor origin point z error(A.1.23)	SensorOriginPointZError	ara com





Bit	Reference Singal in ISO23150	Reference Element in USSDetectionService	Option
			•
10	Sensor origin point x x error (A.1.23)	SensorOriginPointXXError	ara com
	Sensor origin point x y error (A.1.23)	SensorOriginPointXYError	ara com
12	Sensor origin point x z error (A.1.23)	SensorOriginPointXZError	ara com
13	Sensor origin point y x error (A.1.23)	SensorOriginPointYXError	ara com
14	Sensor origin point y y error (A.1.23)	SensorOriginPointYYError	ara com
15	Sensor origin point y z error (A.1.23)	SensorOriginPointYZError	ara com
16	Sensor origin point z x error (A.1.23)	SensorOriginPointZXError	ara com
17	Sensor origin point z y error (A.1.23)	SensorOriginPointZYError	ara com
18	Sensor origin point z z error (A.1.23)	SensorOriginPointZZError	ara com
19	Sensor orientation yaw error(A.1.25)	SensorOrientationYawError	ara com
20	Sensor orientation pitch error(A.1.25)	SensorOrientationPitchError	ara com
21	Sensor orientation roll error(A.1.25)	SensorOrientationRollError	ara com
22	Sensor orientation yaw yaw error (A.1.25)	SensorOrientationYawYawError	ara com
23	Sensor orientation yaw pitch error (A.1.25)	SensorOrientationYawPitchError	ara com
24	Sensor orientation yaw roll error (A.1.25)	SensorOrientationYawRollError	ara com
25	Sensor orientation pitch yaw error (A.1.25)	SensorOrientationPitchYawError	ara com
26	Sensor orientation pitch pitch error (A.1.25)	SensorOrientationPitchPitchError	ara com
27	Sensor orientation pitch roll error (A.1.25)	SensorOrientationPitchRollError	ara com
28	Sensor orientation roll yaw error (A.1.25)	SensorOrientationRollYawError	ara com
29	Sensor orientation roll pitch error (A.1.25)	SensorOrientationRollPitchError	ara com
30	Sensor orientation roll roll error (A.1.25)	SensorOrientationRollRollError	ara com
31	Calibration(Table 48)	Calibration	0
32	Calibration process state(A.5.42)	CalibrationProcessState	ara com
33	Sensor origin point correction x(A.5.43)	SensorOriginPointCorrectionX	ara com
34	Sensor origin point correction y(A.5.43)	SensorOriginPointCorrectionY	ara com
35	Sensor origin point correction z(A.5.43)	SensorOriginPointCorrectionZ	ara com
36	Sensor origin point correction x error(A.5.44)	SensorOriginPointCorrectionXError	ara com
37	Sensor origin point correction y error(A.5.44)	SensorOriginPointCorrectionYError	ara com
38	Sensor origin point correction z error(A.5.44)	SensorOriginPointCorrectionZError	ara com
39	Sensor origin translation correction limit xbe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitXbegin	ara com
40	Sensor origin translation correction limit xend(A.5.45)	SensorOriginTranslationCorrection- LimitXend	ara com
41	Sensor origin translation correction limit ybe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitYbegin	ara com
42	Sensor origin translation correction limit yend(A.5.45)	SensorOriginTranslationCorrection- LimitYend	ara com
43	Sensor origin translation correction limit zbe-gin(A.5.45)	SensorOriginTranslationCorrection- LimitZbegin	ara com
44	Sensor origin translation correction limit zend(A.5.45)	SensorOriginTranslationCorrection- LimitZend	ara com
45	Sensor orientation correction yaw(A.5.46)	SensorOrientationCorrectionYaw	ara com
46	Sensor orientation correction pitch(A.5.46)	SensorOrientationCorrectionPitch	ara com
47	Sensor orientation correction roll(A.5.46)	SensorOrientationCorrectionRoll	ara com
48	Sensor orientation correction yaw error(A.5.47)	SensorOrientationCorrectionYawError	ara com
	1 ' '	l .	l





Bit	Reference Singal in ISO23150	Reference Element in USSDetectionService	Option
49	Sensor orientation correction pitch error(A.5.47)	SensorOrientationCorrectionPitchEr- ror	ara com
50	Sensor orientation correction roll error(A.5.47)	SensorOrientationCorrectionRollEr- ror	ara com
51	Sensor pose angle correction limit yawbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitYaw- begin	ara com
52	Sensor pose angle correction limit yawend(A.5.48)	SensorPoseAngleCorrectionLim- itYawend	ara com
53	Sensor pose angle correction limit pitchbe-gin(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchbegin	ara com
54	Sensor pose angle correction limit pitchend(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchend	ara com
55	Sensor pose angle correction limit rollbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitRoll-begin	ara com
56	Sensor pose angle correction limit rol- lend(A.5.48)	SensorPoseAngleCorrectionLimitRol-lend	ara com
57	Sensor cluster(Table 48)	SensorCluster	0
58	Information Interface extension(Table 30)	InformationInterfaceExtension	0
59	Tracking motion model(A.1.13)	TrackingMotionModel	ara com
60	Motion type(A.1.14)	MotionType	ara com
61	Colour model type(A.1.15)	ColourModelType	ara com
62	Information ambiguity domain(Table 30)	InformationAmbiguityDomain	0
63	Radial velocity ambiguity domain begin(A.1.16)	RadialVelocityAmbiguityDomainBegin	ara com
64	Radial velocity ambiguity domain end(A.1.16)	RadialVelocityAmbiguityDomainEnd	ara com
65	Range ambiguity domain begin(A.1.17)	RangeAmbiguityDomainBegin	ara com
66	Range ambiguity domain end(A.1.17)	RangeAmbiguityDomainEnd	ara com
67	Angle azimuth ambiguity domain begin(A.1.18)	AngleAzimuthAmbiguityDomainBegin	ara com
68	Angle azimuth ambiguity domain end(A.1.18)	AngleAzimuthAmbiguityDomainEnd	ara com
69	Angle elevation ambiguity domain begin(A.1.19)	AngleElevationAmbiguityDomainBegin	ara com
70	Angle elevation ambiguity domain end(A.1.19)	AngleElevationAmbiguityDomainEnd	ara com
71	Interface applicability(A.1.20)	InterfaceApplicability	ara com
72	Recognised detections capability(A.1.10.8)	RecognisedDetectionsCapability	ara com
73	Recognised detections status(A.1.11.8)	RecognisedDetectionsStatus	ara com
74	Object ID reference detection level(A.4.2)	ObjectIdReferenceDetectionLevel	ara com
75	Feature ID reference(A.4.3)	FeatureIdReference	ara com
76	Second sensor ID reference(A.4.36)	SecondSensorIdReference	ara com
77	Reflectivity(A.4.22)	Reflectivity	ara com
78	Height ultrasonic(A.4.39)	HeightUltrasonic	ara com
79	Height ultrasonic error(A.4.40)	HeightUltrasonicError	ara com

Table 10.9: Capability Vector of USSDetectionService



10.4 Supportive Service

10.4.1 SensorPerformanceService Capability Vector

The table below includes the capability bit setting for the optional elements for Sensor-PerformanceService, which also refers to ISO 23150. The Bit setting to 1 means the presence of the optional element, while 0 means absent.

Bit	Reference Singal in ISO23150	Reference Element in SensorPerformance- Service	Option
1	Interface ID(A.1.4)	InterfaceId	Autosar Service
2	Message counter(A.1.6.2)	MessageCounter	ara com
3	Interface cycle time(A.1.7)	InterfaceCycleTime	ara com
4	Interface cycle time variation(A.1.8)	InterfaceCycleTimeVariation	ara com
5	Sensor origin point x error(A.1.23)	SensorOriginPointXError	ara com
6	Sensor origin point y error(A.1.23)	SensorOriginPointYError	ara com
7	Sensor origin point z error(A.1.23)	SensorOriginPointZError	ara com
8	Sensor origin point x x error (A.1.23)	SensorOriginPointXXError	ara com
9	Sensor origin point x y error (A.1.23)	SensorOriginPointXYError	ara com
10	Sensor origin point x z error (A.1.23)	SensorOriginPointXZError	ara com
11	Sensor origin point y x error (A.1.23)	SensorOriginPointYXError	ara com
12	Sensor origin point y y error (A.1.23)	SensorOriginPointYYError	ara com
13	Sensor origin point y z error (A.1.23)	SensorOriginPointYZError	ara com
14	Sensor origin point z x error (A.1.23)	SensorOriginPointZXError	ara com
15	Sensor origin point z y error (A.1.23)	SensorOriginPointZYError	ara com
16	Sensor origin point z z error (A.1.23)	SensorOriginPointZZError	ara com
17	Sensor orientation yaw error(A.1.25)	SensorOrientationYawError	ara com
18	Sensor orientation pitch error(A.1.25)	SensorOrientationPitchError	ara com
19	Sensor orientation roll error(A.1.25)	SensorOrientationRollError	ara com
20	Sensor orientation yaw yaw error (A.1.25)	SensorOrientationYawYawError	ara com
21	Sensor orientation yaw pitch error (A.1.25)	SensorOrientationYawPitchError	ara com
22	Sensor orientation yaw roll error (A.1.25)	SensorOrientationYawRollError	ara com
23	Sensor orientation pitch yaw error (A.1.25)	SensorOrientationPitchYawError	ara com
24	Sensor orientation pitch pitch error (A.1.25)	SensorOrientationPitchPitchError	ara com
25	Sensor orientation pitch roll error (A.1.25)	SensorOrientationPitchRollError	ara com
26	Sensor orientation roll yaw error (A.1.25)	SensorOrientationRollYawError	ara com
27	Sensor orientation roll pitch error (A.1.25)	SensorOrientationRollPitchError	ara com
28	Sensor orientation roll roll error (A.1.25)	SensorOrientationRollRollError	ara com
29	Calibration(Table 48)	Calibration	0
30	Calibration process state(A.5.42)	CalibrationProcessState	ara com
31	Sensor origin point correction x(A.5.43)	SensorOriginPointCorrectionX	ara com
32	Sensor origin point correction y(A.5.43)	SensorOriginPointCorrectionY	ara com
33	Sensor origin point correction z(A.5.43)	SensorOriginPointCorrectionZ	ara com
34	Sensor origin point correction x error(A.5.44)	SensorOriginPointCorrectionXError	ara com
35	Sensor origin point correction y error(A.5.44)	SensorOriginPointCorrectionYError	ara com
36	Sensor origin point correction z error(A.5.44)	SensorOriginPointCorrectionZError	ara com



		Δ	
Bit	Reference Singal in ISO23150	Reference Element in SensorPerformance- Service	Option
37	Sensor origin translation correction limit xbe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitXbegin	ara com
38	Sensor origin translation correction limit xend(A.5.45)	SensorOriginTranslationCorrection- LimitXend	ara com
39	Sensor origin translation correction limit ybe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitYbegin	ara com
40	Sensor origin translation correction limit yend(A.5.45)	SensorOriginTranslationCorrection- LimitYend	ara com
41	Sensor origin translation correction limit zbe- gin(A.5.45)	SensorOriginTranslationCorrection- LimitZbegin	ara com
42	Sensor origin translation correction limit zend(A.5.45)	SensorOriginTranslationCorrection- LimitZend	ara com
43	Sensor orientation correction yaw(A.5.46)	SensorOrientationCorrectionYaw	ara com
44	Sensor orientation correction pitch(A.5.46)	SensorOrientationCorrectionPitch	ara com
45	Sensor orientation correction roll(A.5.46)	SensorOrientationCorrectionRoll	ara com
46	Sensor orientation correction yaw error(A.5.47)	SensorOrientationCorrectionYawError	ara com
47	Sensor orientation correction pitch error(A.5.47)	SensorOrientationCorrectionPitchEr- ror	ara com
48	Sensor orientation correction roll error(A.5.47)	SensorOrientationCorrectionRollEr-ror	ara com
49	Sensor pose angle correction limit yawbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitYaw-begin	ara com
50	Sensor pose angle correction limit yawend(A.5.48)	SensorPoseAngleCorrectionLim- itYawend	ara com
51	Sensor pose angle correction limit pitchbe-gin(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchbegin	ara com
52	Sensor pose angle correction limit pitchend(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchend	ara com
53	Sensor pose angle correction limit rollbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitRoll-begin	ara com
54	Sensor pose angle correction limit rol- lend(A.5.48)	SensorPoseAngleCorrectionLimitRol-lend	ara com
55	Sensor cluster(Table 48)	SensorCluster	0
56	Tracking motion model(A.1.13)	TrackingMotionModel	ara com
57	Motion type(A.1.14)	MotionType	ara com
58	Colour model type(A.1.15)	ColourModelType	ara com
59	Information ambiguity domain(Table 30)	InformationAmbiguityDomain	0
60	Radial velocity ambiguity domain begin(A.1.16)	RadialVelocityAmbiguityDomainBegin	ara com
61	Radial velocity ambiguity domain end(A.1.16)	RadialVelocityAmbiguityDomainEnd	ara com
62	Range ambiguity domain begin(A.1.17)	RangeAmbiguityDomainBegin	ara com
63	Range ambiguity domain end(A.1.17)	RangeAmbiguityDomainEnd	ara com
64	Angle azimuth ambiguity domain begin(A.1.18)	AngleAzimuthAmbiguityDomainBegin	ara com
65	Angle azimuth ambiguity domain end(A.1.18)	AngleAzimuthAmbiguityDomainEnd	ara com
66	Angle elevation ambiguity domain begin(A.1.19)	AngleElevationAmbiguityDomainBegin	ara com
67	Angle elevation ambiguity domain end(A.1.19)	AngleElevationAmbiguityDomainEnd	ara com
68	Interface applicability(A.1.20)	InterfaceApplicability	ara com
69	Information sensor surrounding(Table 46)	InformationSensorSurrounding	0
70	Vanishing point azimuth error(A.1.27)	VanishingPointAzimuthError	ara com





Bit	Reference Singal in ISO23150	Reference Element in SensorPerformance- Service	Option
71	Vanishing point elevation error(A.1.27)	VanishingPointElevationError	ara com
72	Measurement grid resolution radial distance(A.5.3)	MeasurementGridResolutionRadialDis- tance	ara com
73	Measurement grid resolution azimuth(A.5.3)	MeasurementGridResolutionAzimuth	ara com
74	Measurement grid resolution elevation(A.5.3)	MeasurementGridResolutionElevation	ara com
75	Beam divergence azimuth(A.5.4)	BeamDivergenceAzimuth	ara com
76	Beam divergence elevation(A.5.4)	BeamDivergenceElevation	ara com
77	Range gain(A.5.5)	RangeGain	ara com
78	Field of view reduction(Table 46)	FieldOfViewReduction	0
79	Real world object recognition capabilities (Table 46)	RealWorldObjectRecognitionCapabili- ties	0
80	True positive rate(A.5.13)	TruePositiveRate	ara com
81	False positive rate(A.5.14)	FalsePositiveRate	ara com
82	Positive predictive value(A.5.15)	PositivePredictiveValue	ara com
83	Reference target recognition capabilities(Table 46)	ReferenceTargetRecognitionCapabilities	0
84	Reference target type(A.5.17)	ReferenceTargetType	ara com
85	Radar cross section reference target(A.5.18)	RadarCrossSectionReferenceTarget	ara com
86	Reflectivity reference target(A.5.19)	ReflectivityReferenceTarget	ara com
87	True positive rate(A.5.13)	TruePositiveRate	ara com
88	Relative radial velocity range begin(A.5.20)	RelativeRadialVelocityRangeBegin	ara com
89	Relative radial velocity range end(A.5.20)	RelativeRadialVelocityRangeEnd	ara com
90	Spatial separability radial distance(A.5.22)	SpatialSeparabilityRadialDistance	ara com
91	Spatial separability azimuth(A.5.22)	SpatialSeparabilityAzimuth	ara com
92	Spatial separability elevation(A.5.22)	SpatialSeparabilityElevation	ara com
93	Velocity separability radial distance(A.5.23)	VelocitySeparabilityRadialDistance	ara com
94	Velocity separability azimuth(A.5.23)	VelocitySeparabilityAzimuth	ara com
95	Velocity separability elevation(A.5.23)	VelocitySeparabilityElevation	ara com

Table 10.10: Capability Vector of SensorPerformanceService

10.4.2 SensorHealthService Capability Vector

The table below includes the capability bit setting for the optional elements for SensorHealthService, which also refers to ISO 23150. The Bit setting to 1 means the presence of the optional element, while 0 means absent.

Bit	Reference Singal in ISO23150	Reference Element in SensorHealthService	Option
1	Interface ID(A.1.4)	InterfaceId	Autosar Service
2	Message counter(A.1.6.2)	MessageCounter	ara com
3	Interface cycle time(A.1.7)	InterfaceCycleTime	ara com
4	Interface cycle time variation(A.1.8)	InterfaceCycleTimeVariation	ara com





Reference Singal in ISO23150	Reference Element in SensorHealthService	Option
		0
, , ,	InformationSensorPose	0
Sensor origin point x error(A.1.23)	SensorOriginPointXError	ara com
3 1 , ,		ara com
Sensor origin point z error(A.1.23)	SensorOriginPointZError	ara com
Sensor origin point x x error (A.1.23)	SensorOriginPointXXError	ara com
5 1 , ,	SensorOriginPointXYError	ara com
Sensor origin point x z error (A.1.23)	SensorOriginPointXZError	ara com
Sensor origin point y x error (A.1.23)		ara com
<u> </u>		ara com
<u> </u>		ara com
Sensor origin point z x error (A.1.23)		ara com
Sensor origin point z y error (A.1.23)	SensorOriginPointZYError	ara com
• • • • • • • •	SensorOriginPointZZError	ara com
9 1	SensorOrientationYawError	ara com
	SensorOrientationPitchError	ara com
. , , ,	SensorOrientationRollError	ara com
` ,	SensorOrientationYawYawError	ara com
	SensorOrientationYawPitchError	ara com
• • • • • • • • • • • • • • • • • • • •	SensorOrientationYawRollError	ara com
Sensor orientation pitch yaw error (A.1.25)	SensorOrientationPitchYawError	ara com
Sensor orientation pitch pitch error (A.1.25)	SensorOrientationPitchPitchError	ara com
Sensor orientation pitch roll error (A.1.25)	SensorOrientationPitchRollError	ara com
Sensor orientation roll yaw error (A.1.25)	SensorOrientationRollYawError	ara com
Sensor orientation roll pitch error (A.1.25)	SensorOrientationRollPitchError	ara com
Sensor orientation roll roll error (A.1.25)	SensorOrientationRollRollError	ara com
Calibration(Table 48)	Calibration	Q This should be in the header or in the body for Sensor Health information
Calibration process state(A.5.42)	CalibrationProcessState	ara com
Sensor origin point correction x(A.5.43)	SensorOriginPointCorrectionX	ara com
Sensor origin point correction y(A.5.43)	SensorOriginPointCorrectionY	ara com
Sensor origin point correction z(A.5.43)	SensorOriginPointCorrectionZ	ara com
Sensor origin point correction x error(A.5.44)	SensorOriginPointCorrectionXError	ara com
Sensor origin point correction y error(A.5.44)	SensorOriginPointCorrectionYError	ara com
Sensor origin point correction z error(A.5.44)	SensorOriginPointCorrectionZError	ara com
Sensor origin translation correction limit xbe-gin(A.5.45)	SensorOriginTranslationCorrection- LimitXbegin	ara com
Sensor origin translation correction limit xend(A.5.45)	SensorOriginTranslationCorrection- LimitXend	ara com
Sensor origin translation correction limit ybegin(A.5.45)	SensorOriginTranslationCorrection- LimitYbegin	ara com
Sensor origin translation correction limit yend(A.5.45)	SensorOriginTranslationCorrection- LimitYend	ara com
Sensor origin translation correction limit zbe-	SensorOriginTranslationCorrection-	ara com
	Sensor origin point y error(A.1.23) Sensor origin point z error(A.1.23) Sensor origin point x x error (A.1.23) Sensor origin point x y error (A.1.23) Sensor origin point x z error (A.1.23) Sensor origin point y x error (A.1.23) Sensor origin point y y error (A.1.23) Sensor origin point y y error (A.1.23) Sensor origin point z x error (A.1.23) Sensor origin point z x error (A.1.23) Sensor origin point z y error (A.1.23) Sensor origin point z y error (A.1.23) Sensor origin point z z error (A.1.23) Sensor origin point z z error (A.1.23) Sensor orientation yaw error(A.1.25) Sensor orientation pitch error(A.1.25) Sensor orientation roll error(A.1.25) Sensor orientation yaw yaw error (A.1.25) Sensor orientation pitch yaw error (A.1.25) Sensor orientation pitch pitch error (A.1.25) Sensor orientation pitch pitch error (A.1.25) Sensor orientation pitch roll error (A.1.25) Sensor orientation roll yaw error (A.1.25) Sensor orientation roll pitch error (A.1.25) Sensor orientation roll pitch error (A.1.25) Sensor orientation roll pitch error (A.1.25) Sensor orientation roll roll error (A.1.25) Sensor orientation roll roll error (A.1.25) Sensor orientation roll roll error (A.1.25) Sensor origin point correction x(A.5.43) Sensor origin point correction y error(A.5.44) Sensor origin point correction z error(A.5.44) Sensor origin point correction z error(A.5.44) Sensor origin point correction z error(A.5.44) Sensor origin translation correction limit xbe-gin(A.5.45) Sensor origin translation correction limit ybe-gin(A.5.45) Sensor origin translation correction limit ybe-gin(A.5.45)	Information vehicle coordinate system(Table 46) Information sensor pose(Table 46) Information sensor pose(Table 46) Sensor origin point x error(A.1.23) Sensor origin point x error(A.1.23) Sensor origin point x error (A.1.23) Sensor origin point x z error (A.1.23) Sensor origin point z x error (A.1.25) Sensor orientation yaw error (A.1.25) Sensor orientation pitch error (A.1.25) Sensor orientation pitch error (A.1.25) Sensor orientation yaw yaw error (A.1.25) Sensor orientation yaw pitch error (A.1.25) Sensor orientation pitch yaw error (A.1.25) Sensor orientation pitch yaw error (A.1.25) Sensor orientation pitch yaw error (A.1.25) Sensor orientation pitch pitch error (A.1.25) Sensor orientation pitch error (A.1.25) Sensor orie





Bit	Reference Singal in ISO23150	Reference Element in SensorHealthService	Option
44	Sensor origin translation correction limit zend(A.5.45)	SensorOriginTranslationCorrection- LimitZend	ara com
45	Sensor orientation correction yaw(A.5.46)	SensorOrientationCorrectionYaw	ara com
46	Sensor orientation correction pitch(A.5.46)	SensorOrientationCorrectionPitch	ara com
47	Sensor orientation correction roll(A.5.46)	SensorOrientationCorrectionRoll	ara com
48	Sensor orientation correction yaw error(A.5.47)	SensorOrientationCorrectionYawError	ara com
49	Sensor orientation correction pitch error(A.5.47)	SensorOrientationCorrectionPitchEr-ror	ara com
50	Sensor orientation correction roll error(A.5.47)	SensorOrientationCorrectionRollEr- ror	ara com
51	Sensor pose angle correction limit yawbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitYaw- begin	ara com
52	Sensor pose angle correction limit yawend(A.5.48)	SensorPoseAngleCorrectionLim- itYawend	ara com
53	Sensor pose angle correction limit pitchbe-gin(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchbegin	ara com
54	Sensor pose angle correction limit pitchend(A.5.48)	SensorPoseAngleCorrectionLimit- Pitchend	ara com
55	Sensor pose angle correction limit rollbe-gin(A.5.48)	SensorPoseAngleCorrectionLimitRoll-begin	ara com
56	Sensor pose angle correction limit rol- lend(A.5.48)	SensorPoseAngleCorrectionLimitRol-lend	ara com
57	Sensor cluster(Table 48)	SensorCluster	0
58	Information Interface extension(Table 30)	InformationInterfaceExtension	0
59	Tracking motion model(A.1.13)	TrackingMotionModel	ara com
60	Motion type(A.1.14)	MotionType	ara com
61	Colour model type(A.1.15)	ColourModelType	ara com
62	Information ambiguity domain(Table 30)	InformationAmbiguityDomain	0
63	Radial velocity ambiguity domain begin(A.1.16)	RadialVelocityAmbiguityDomainBegin	ara com
64	Radial velocity ambiguity domain end(A.1.16)	RadialVelocityAmbiguityDomainEnd	ara com
65	Range ambiguity domain begin(A.1.17)	RangeAmbiguityDomainBegin	ara com
66	Range ambiguity domain end(A.1.17)	RangeAmbiguityDomainEnd	ara com
67	Angle azimuth ambiguity domain begin(A.1.18)	AngleAzimuthAmbiguityDomainBegin	ara com
68	Angle azimuth ambiguity domain end(A.1.18)	AngleAzimuthAmbiguityDomainEnd	ara com
69	Angle elevation ambiguity domain begin(A.1.19)	AngleElevationAmbiguityDomainBegin	ara com
70	Angle elevation ambiguity domain end(A.1.19)	AngleElevationAmbiguityDomainEnd	ara com
71	Interface applicability(A.1.20)	InterfaceApplicability	ara com
72	Sensor externally disturbed(A.5.33)	SensorExternallyDisturbed	ara com
73	Sensor transmit power reduced(A.5.34)	SensorTransmitPowerReduced	ara com
74	Status sensor heating(A.5.35)	StatusSensorHeating	ara com
75	Status sensor cleaning(A.5.36)	StatusSensorCleaning	ara com
76	Sensor time sync(A.5.37)	SensorTimeSync	ara com
77	Sensor time sync offset value(A.5.38)	SensorTimeSyncOffsetValue	ara com

Table 10.11: Capability Vector of SensorHealthService