## Displayパネルを開く Line Series から Ux を選択 arc\_length を選択 Scatter Plot を選択 Properties Display Information Show Line Series in Chart Scatter Plot Plot Type Attribute Mode · Point Data - X Axis Data Use Array Index From Y Axis Data Use Data Array arc length Distance Component I ine Series Variable Legend Name X Ux Ux □ Uv UV □ Uz 1.17 U: Magnitude U: Magnitude □ U: X U: X U: Y □ U: Y □ U: Z U: Z original coordinates... original coordinates: Mag... original coordinates: X original coordinates: X original coordinates: Y original coordinates: Y original coordinates: Z original coordinates: Z arc length arc length □ Enable Line Series Line Color O Choose Color... Line Thickness Line Style Chart Axes