Line Series から U x を選択 arc\_lengthを選択 Line Sourceを選択 Properties Properties Apply Reset **X** Delete Search ... (use Esc to clear text) Properties (PlotOverLine1) Probe Type High Resolution Line Source X Show Line Snap On Mesh Point Pick Both Points Point1 0.05 n 0.005 Point2 0.05 0.1 0.005 X Axis Y Axis Z Axis Resolution 100 Note: Move mouse and use 'P' key to change point position \* Pass Partial Arrays X Compute Tolerance Attribute Type Point Data X Axis Parameters Use Index For XAxis X Array Name arc\_length Series Parameters ✓ Variable Legend Name p p arc\_length arc\_length UZ U Z UY UY X U X U X U Magnit.. U Magnitude Line Thickness Line Style Marker Style Chart Axes