
SP S



The Der El

This document is designed to get you familiarized with your X-Rite SP60 Series Spectrophotometer. If you need any further

Unpack and Inspect

Charge the Battery



Only use the AC Adapter supplied. The battery pack must remain in the instrument at all times to operate.

The shoe must also be open to gain access to the battery compartment when the battery requires replacement.

l r

Hold the shoe next to the instrument housing and lift upward on the spring-loaded latch.

- L this menu item is used to change the lock status of the current standard. Locked standards cannot be changed. Downloaded standards cannot be unlocked.
- I this menu item only appears when the

Run Job Screen (SP64 only)

The Run Job function is used to select a job sequence downloaded from X-Rite's QA-Master 2000 software program. A typical job prompts you on the instrument scribye 0 QA-thce

O E E H E E H M E E

Opening a Mode or Menu

ļ

Opening a mode or menu allows you access to additional items

You may set up your instrument according to your specific

HEEE E H MEE

% &

The Hardware Setup configuration allows you to determine the following settings:

• Serial Port

Switch Only

O E E HEEE H MEE