Summary - Socket Write

Name	$socket_write$
Worker Type	Application (Testing)
Version	v1.3
Release Date	February 2018
Component Library	ocpi.assets.util_comps
Workers	socket_write.rcc
Tested Platforms	linux-c7-x86_64, linux-x13_3-arm

Functionality


The Socket Write component forwards all incoming data to a TCP port or acts as a demultiplexer/router by parsing any protocol and routing different opcodes to various output ports.

The serving/listening TCP ports, along with various ways to determine the Worker's "done" status, are extremely configurable using Properties.

This Component provides *minimal* error checking and is **not recommended for production use**, but is only intended for prototyping and testing of other Components.

Block Diagrams

Top level



Source Dependencies

socket_write.rcc

- $\bullet \ ocpiassets/components/util_comps/socket_write.rcc/socket_write.cc \\$
- ocpiassets/components/util_comps/socket_write.rcc/ext_src/connection.cpp
- ocpiassets/components/util_comps/socket_write.rcc/ext_src/connection.hpp
- ocpiassets/components/util_comps/socket_write.rcc/ext_src/connection_manager.cpp

- ocpiassets/components/util_comps/socket_write.rcc/ext_src/connection_manager.hpp
- ocpiassets/components/util_comps/socket_write.rcc/ext_src/outbound.hpp
- ocpiassets/components/util_comps/socket_write.rcc/ext_src/server.cpp
- ocpiassets/components/util_comps/socket_write.rcc/ext_src/server.hpp
- ocpiassets/components/util_comps/socket_write.rcc/asio/* 1

socket_write.rcc Compilation

Because OpenCPI maintains backwards compatibility with older compilers, a fully-compliant C++11 environment is not required. However, the workaround is that the ASIO library has dependencies on the Boost² library. On CentOS 6 or 7, it requires the boost-devel RPM along with the OS-specific package that provides the boost_thread library.

To build this component targeting a non-x86 platform, the vendor must provide the appropriate boost_system and boost_thread static library files. The Worker's build system will attempt to find them using the locate command in a subdirectory that has \${OCPI_CROSS_HOST} within the path.

See the enclosed README file for more information, including how to add new platforms.

¹Externally provided ASIO library for asynchronous IO with C++, with OpenCPI-specific build system

 $^{^2 {}m http://www.boost.org/}$

Component Spec Properties

Name	Type	SequenceLength	ArrayDimensions	Accessibility	Valid Range	Default	Usage
outSocket ¹	Struct	-	-	Writable, Readable	-	-	TCP socket(s) to use for listening
outSocket.address	String	16	-	"	-	0.0.0.0	Address/interface to use for port ² , e.g. 127.0.0.1
outSocket.port	UShort	-	-	"	1025 - 65535	-	Output port to use if all data should remain combined ³
outSocket.ports	UShort	-	256	"	-	-	A list of port numbers to listen on, with 0 indicating unused 5 6
outSocket .messagesInStream	Bool	-	256	"	-	false	Write out data in "message" mode with embedded opcode
current	Struct	-	-	Volatile	-	-	Current statistics for each opcode
current.Total	Struct	-	-	"	-	-	Statistics across all opcodes
current.Total.bytes	ULongLong	-	-	"	Standard	-	Number of bytes received
current.Total.messages	ULongLong	-	-	"	Standard	-	Number of messages received
current.Opcode	Struct	-	256	"	-	-	Statistics for each opcode
current.Opcode.*	Various	-	"	-	-	-	Various ⁷
stop0n	Struct	-	-	Writable, Readable	-	-	Condition(s) required to have Worker report completion ⁸
stopOn.Total	Struct	-	-	"	-	-	Stops if any non-zero value is exceeded when counting all
							data received
stopOn.Total.bytes	ULongLong	-	-	"	Standard	0	Stop on number of bytes received
stopOn.Total.messages	ULongLong	-	-	,,	Standard	0	Stop in number of messages received
stopOn.Opcode	Struct	-	256	"	-	-	Stops if any non-zero value is exceeded when counting data received using a specific opcode
stopOn.Opcode.*	Various	-	-	"	-	-	Various ⁹
stopOn.Any	Struct	-	-	"	-	-	Stops if any non-zero value is exceeded when counting data received using any single opcode
stopOn.Any.*	Various	-	-	"	-	-	Various ⁹
stopOn.ZLM	UShort	-	-	"	0 - 256	0	Stops if a \mathbf{Z} ero \mathbf{L} ength \mathbf{M} essage is received using a given opcode. 10

¹This structure is only read at Component START to configure.

Worker Properties

socket_write.rcc

Control Operations³ Start, Stop

²The default listens on all interfaces.

³ICANN reserves up to 49151.

⁴Attempting to use a port that is used by another process will cause a fatal error.

⁵See "Performance and Resource Utilization."

⁶This Property is only used when port is set to 0.

⁷Internal structure equivalent to current. Total and not explicitly shown.

⁸Any matched condition will halt the processing.

⁹Internal structure equivalent to stopOn. Total and not explicitly shown.

¹⁰Default is opcode 0; set to invalid opcode 256 if this feature is *not* desired.

³All TCP connections are terminated in the **Stop** state, while listening ports are opened in the **Start** state. If the Component is **Stop**ped, any clients will be *disconnected* (i.e. not paused) and must reconnect after it is **Start**ed.

Component Ports

Name	Producer	Protocol	Optional	Advanced	Usage
in	false	-	false	numberofopcodes=256	Data to be streamed to sockets(s)
out	true	-	true	numberofopcodes=256	Data pass-through

Worker Interfaces

There are no implementation-specific interfaces for this component.

Performance and Resource Utilization

socket_write.rcc

Processor Type	Processor Frequency	Run Function Time
linux-c6-x86_64 Intel(R) Xeon(R) CPU E5-1607	3.00 GHz	TBD
linux-c7-x86_64 Intel(R) Core(TM) i7-3630QM	2.40 GHz	TBD
linux-13_3-arm ARMv7 Processor rev 0 (v7l)	666 MHz	TBD

Each listening port requires system resources, such as an open file descriptor. When opening more than a handful of ports, the user may need to use ulimit to increase the number of open file descriptors. To do this temporarily, the command ulimit -n 2048 can *sometimes* fix the currently running shell. Consult the documentation for your Operating System to permanently increase the limit for all processes.

TCP connections have a large overhead when compared to other transport processes, such as the OpenCPI internal messaging system. Currently, this component **does not** combine Messages to optimize the outbound connection, *e.g.* taking into account TCP Maximum Segment Size (MSS). It is *highly* recommended that users of this Component use a minimum message size of 4K or combine multiple messages in some way in an upstream Component.

Data buffers are not returned to the framework nor sent out the optional "out" port until all TCP clients have received their data. This may result in throttling or a possible denial-of-service attack if a malicious client connects but never accepts data.

Test and Verification

Usage (local/x86)

After building the component, the user needs to type make tests RCC_CONTAINERS=1 in the socket_write.test directory. Various properties and data flows will be tested to try to cover as many use cases as possible.

If the user would like to execute only one test, TESTS=test_XX can be added to the end of the command.

Usage (remote/ARM)

Full test environment configuration (e.g. NFS mounting, OCPI_CDK_DIR, etc.) on the remote GPP is beyond the scope of this document. The test procedures assume that both shells' current working directory is the socket_write.test directory (NFS-mounted on remote) and ocpirun is in the remote's current PATH. NFS must be used for the scripts to properly verify the outputs.

In the host shell, the user types make tests IP=xx.xx.xx. A command that can be copied and then pasted into the remote shell will be displayed. This command should be executed in less than a minute to ensure the test system begins listening before the host times out. The timeout can be changed using the LISTEN_TIMEOUT variable. Once the remote shell returns to the bash prompt, pressing "Enter" on the host will begin the verification process.

Single tests can be performed in the same manner as documented above.

Specific Platform Note - Matchstiq-Z1

Some tests have had "Segmentation Faults" or "Alignment Errors" in certain scenarios on the Z1. The problem becomes most evident when there are multiple clients connected, but has been more rarely observed with even a single client. This seems to happen when both USB ports are used to simultaneously transmit a large amount of data, e.g. high log-level output to a USB serial console as well as NFS-mounted output files over a USB-to-Ethernet adapter. The default test setup avoids triggering this by limiting output that is fed to the user, but users should be aware of this issue if non-default test scenarios are attempted. If ssh is used to have all data routed through the USB-to-Ethernet adapter, this failure mode is avoided.

Detailed Theory of Operation

Each test_XX subdirectory has the following files:

- description a one-line description of the test
- application.xml the OAS XML for the test setup
- portmap (optional) list of TCP ports paired to output files
- localinclude.mk (optional) custom Makefile rules needed for test
- golden.md5 (optional) MD5 checksums of golden/expected output
- generate. [sh|pl|py] (optional) script to generate test data
- verify.sh (optional) script to verify output(s)

Data is sourced with a source component (often pattern or file_read) within the OAS. If the former, the source data is encapsulated in the OAS. When the latter, a generate.py script generates the required data. Most OASs dump the "current" property to a file UUT.current.dump, which is also confirmed to match expected output. Some tests connect a file_write_demux to the out port to verify pass-through operation.

If generate.sh does not exist, a default one is created that will run generate.pl and/or generate.py if they exist and are executable. This default script is removed with make clean.

At test launch, if a file portmap exists, it launches a Python-based utility script busy_loop_socket.py, which opens a client on a given port and repeatedly attempts to connect. Each line is a port number followed by a (relative) file path where the data is written upon successful connection.

If verify.sh does not exist, a default one is created that will ensure the application did not time out and then run md5sum to verify all the checksums listed in golden.md5. This default script is also removed upon make clean.