KS22Kit Pin Config

Function	PIN Number	ALT	OTHERS
CAN0	PTA12 CANO_TX	ALT 2	
	PTA13 - CANO_RX	ALT 2	
CAN1	PTB2 – CAN1_RX	ALT 7	
	PTB3 – CAN1_TX	ALT 7	
UARTO – Debug	PTA1 – UARTO_RX	ALT 2	
	PTA2 – UARTO_TX	ALT 2	
UART1 – RS232	PTEO – UART1_TX	ALT 3	
	PTE1 – UART1_RX	ALT 3	
UART2 TTL	PTD2 – UART2_RX	ALT 3	
	PTD3 – UART2_TX	ALT 3	
LPUARTO – RS485	PTC3 – LPUARTO_RX	ALT 7	
	PTC4 – LPUARTO_TX	ALT 7	
	PTC2 – S485_SE	ALT 1	GPIO_OUT
SPI1 – SPI Flash	PTD4 - SPI1_CS0	ALT 7	
	PTD5 – SPI1_SCK	ALT 7	
	PTD6 – SPI1_MOSI	ALT 7	
	PTD7 – SPI1_MISO	ALT 7	
SPIO – Nrf24L01	PTC1 - SPIO_CS3	ALT 2	
	PTC5 – SPIO_SCK	ALT 2	
	PTC6 – SPIO_MOSI	ALT 2	
	PTC7 – SPIO_MISO	ALT 2	
	PTC8 - SPI_IO1	ALT 1	GPIO
	PTC9 – SPI_IO2	ALT 1	GPIO
I2C1 – EEPROM	PTC10 - LPI2C1_SCL	ALT 2	
	PTC11 - LPI2C1_SDA	ALT 2	
I2C0 - 扩展	PTC6 – LPI2CO_SCL	ALT 7	
(TTL)	PTC7 – LPI2CO_SCL	ALT 7	
FlexIO	PTB17 – FlexIO_D0	ALT 7	
	PTB18 – FlexIO_D1	ALT 7	
	PTB19 – FlexIO_D2	ALT 7	
	PTC0 – FlexIO_D3	ALT 6	
	PTB0 – FlexIO_D4	ALT 6	
	PTB1 – FlexIO_D5	ALT 6	
	PTD0 – FlexIO_D6	ALT 7	
	PTD1 – FlexIO_D7	ALT 7	
LED	PTA18 – LED1	ALT 1	GPIO_OUT
	PTA19 – LED2	ALT 1	GPIO_OUT
KEY	PTA4 – KEY1	ALT 1	GPIO_IN
	PTB16 – KEY2	ALT 1	GPIO_IN
TPM	PTA5 – TPM0_CH2	ALT 3	