Оре	enKasugai	i Demo		
	v1.0.0			
	Оре		OpenKasugai Demo	

Contents

1.	Demo	onstrat	ion procedure of basic functions	3
	1.1	Advance	preparation	4
		1.1.1	Deployment of test scripts	4
		1.1.2	Editing DataFlow yaml	5
	1.2	Environm	nent initialization	5
		1.2.1	Write FPGA Bitstream and auto collect & rerun CM creation tool	5
		1.2.2	CRC start up	6
	1.3	Video str	ream	8
		1.3.1	DataFlow deployment	8
		1.3.2	Start video reception	9
		1.3.3	Start of video stream	11
		1.3.4	Video stream and reception stop	13
	1.4 Environmental shutdown		nental shutdown	13
		1.4.1	Delete DataFlow, Delete various CRs, Stop each CRC	13
2.	[App	endix] l	Extension demonstration procedure	15
	2.1	Advance	preparation	15
		2.1.1	Deploying test scripts	15
		2.1.2	Editing DataFlow yaml	15
2.2 Environment initiali		Environm	nent initialization	16
	2.3	Video str	ream	16
		2.3.1	DataFlow deployment	16
		2.3.2	Start video reception	17
		2.3.3	Start of video stream	20
		2.3.4	Video stream/reception stop	21
	2.4	Environm	nental shutdown	21

1. Demonstration procedure of basic functions

This document shows the procedure from DataFlow (DF) deployment to data communication confirmation as a demonstration procedure of the OpenKasugai controller's basic functions.

- Deploy DF using FPGA F/R (Filter & Resize). Deploy two DFs with the same configuration.
 - ightharpoonup df-test-1-1: CPU Decode (PCIe connection) ightharpoonup FPGA F/R (PCIe connection) ightharpoonup GPU Advanced Inference
 - ightharpoonup df-test-1-2: CPU Decode (PCIe connection) ightharpoonup FPGA F/R (PCIe connection) ightharpoonup GPU Advanced Inference




Figure 1: Deployment image of two DFs with FPGA F/R

1.1 Advance preparation

1.1.1 Deployment of test scripts

Target: K8s control plane, all K8s nodes

Deploy the scripts used in this document to simplify the evaluation procedures (various shell scripts and YAML files for deploying video streaming and receiving tools).

1. Copy the test script directory (script) in the acquired material "CRC Source Code & Sample Data" to the home directory.

```
$ cd ~/
$ cp -rf ~/controller/test/script .
```

2. If necessary, modify the following variables in each script appropriately for the environment.

File name	Target	Variable name	Setting value
run_controllers.sh	control plane	YAML_DIR K8S_SOFT_DIR	absolute path of yaml/absolute path of controller/
delete_all.sh		YAML_DIR K8S_SOFT_DIR	· absolute path of yaml/ · absolute path of controller/
reset_ph3_fpga.sh	node with FPGA card	BIT_DIR	Absolute path of the directory containing BIT files

*In the above reset_ph3_fpga.sh, Bitstream is written using the mcap tool, but the 'x (PCI device ID specification) and 's (BDF specification) options in the mcap command are environment-dependent values, so it is necessary to change them according to the environment to be built. The values of 'x and 's for each environment (K8s node) can be checked with the lspci command. In the execution example of lspci below, the information of the number of FPGA cards is displayed, and xx: xx.x (e.g., 1f: 0.0) is the BDF, and 903f is the PCI device ID. The blue letters are the 's value, and the red letters are the 'x value.

```
$ lspci |grep Xilinx
xx:xx.x Processing accelerators: Xilinx Corporation Device 903f
...

$ vi ~/script/reset_ph3_fpga.sh
...
BIT_DIR=$HOME/hardware-design/example-design/bitstream
cd $BIT_DIR
$ sudo mcap -x 903f -s xx:xx.x -p OpenKasugai-fpga-example-design-1.0.0-2.bit
...
```

1.1.2 Editing DataFlow yaml

Target: K8s control plane

For each DataFlow yaml deployed in Section 1.3.1, change the network information (IP address and port number) used by Pod of each processing module in DataFlow as necessary.

If the IP address set for each server's 100G NIC is different from the IP address shown in Figure 1 in Section 1.1 of the separate "OpenKasugai-Controller-Install Manual," change the IP address.

For instructions on how to make the changes, please refer to the sheet "2 (Supplement). DataFlow yaml settings" in the separate document "OpenKasugai-Controller-InstallManual_Attachment1".

Table 2 List of DataFlow yaml deployed in Section 1.3.1

DataFlow Types	yaml to be edited
1st FPGA F/R DF	~/controller/test/sample-data/sample-data-
(df-test-1-1)	demo/yaml/dataflows/test-1/df-test-1-1.yaml
2nd FPGA F/R DF	~/controller/test/sample-data/sample-data-
(df-test-1-2)	demo/yaml/dataflows/test-1/df-test-1-2.yaml

^{*} When changing DataFlow name (metadata.name value) in the above sample data, the name must be 14 characters or less. Refer to the attached "OpenKasugai-Controller_Attachment1 (CR/CM Specification)" for details on the character limit.

1.2 Environment initialization

*When redeploying DataFlow and streaming video, be sure to perform "1.3.4 Video stream and reception stop" and "1.4 Stop Environment" before starting from the following steps.

1.2.1 Write FPGA Bitstream and auto collect & rerun CM creation tool

Target: K8s node with FPGA card

(1) Writing FPGA Bitstream

Execute the following script to write the Bitstream to the FPGA and reset it.

```
$ cd ~/script
$ ./reset_ph3_fpga.sh
```

(2) Running the automatic collection & CM creation tool

Run the automatic collection & CM creation tool on the target K8s node to restore the ConfigMap and CustomResource associated with the FPGA to their initial state.

```
$ export
PKG_CONFIG_PATH=${PKG_CONFIG_PATH}:$HOME/controller/src/submodules/fpga-
software/lib/build/pkgconfig
$ cd ~/controller/src/tools/InfoCollector/
$ ln -s ../../fpgadb/test/bitstream_id-config-table.json bitstream_id-config-
table.json
$ make all
```

^{*} Writing the Bitstream takes several tens of seconds. If the writing is successful, "FPGA Configuration Done!!" will be displayed in the log.

^{*}In case of K8s Node without NVIDIA GPU, since DCGM is not installed, the following error message is output in the InfoCollector log, but it can be ignored.

"INFO infocollect/infocollect.go:405 dcgm.Init() Error but Maybe there are NOT any GPU. {"error": "libdcgm.so not Found"}

1.2.2 CRC start up

Target: K8s control plane

(1) Running each CRC

Execute the following command to start each CRC and apply the function catalog yaml.

- \$ cd ~/script
- \$./run controllers.sh

(2) Checking CRC startup and CRD installation.

Enter the following command to check that each CRC pod is running, all CRDs (19 types) are installed, and the FunctionChain of cpu-decode-filter-resize-high-infer-chain is Ready.

If the check result is different from the output shown below, identify the cause by checking the log of each Pod or the result of kubectl describe, and then execute "1.4 Environmental shutdown". After taking the corrective action, start again from "1.2 Environment initialization"

```
$ kubectl get pod
NAME
                                     READY
                                            STATUS
                                                        RESTARTS
                                                                   AGE
                                     1/1
crc-cpufunction-daemon-gh4gb
                                             Running
                                                        0
                                                                   15s
                                     1/1
crc-cpufunction-daemon-xzf9s
                                             Running
                                                        0
                                                                   15s
crc-deviceinfo-daemon-qgv5w
                                     1/1
                                             Running
                                                        0
                                                                   18s
crc-deviceinfo-daemon-rwmqh
                                     1/1
                                             Running
                                                        0
                                                                   18s
{\tt crc-ethernet} connection-{\tt daemon-h67pj} \quad {\tt 1/1}
                                             Running
                                                        0
                                                                   15s
\verb|crc-ethernetconnection-daemon-t2hnm| 1/1
                                             Running
                                                        0
                                                                   15s
crc-fpgafunction-daemon-ts8lt
                                     1/1
                                             Running
                                                        0
                                                                   15s
crc-fpgafunction-daemon-zxxrs
                                     1/1
                                             Running
                                                        0
                                                                   15s
                                     1/1
crc-gpufunction-daemon-mzkwk
                                             Running
                                                        0
                                                                   15s
crc-gpufunction-daemon-r596t
                                     1/1
                                             Running
                                                        0
                                                                   15s
crc-pcieconnection-daemon-hvrg6
                                     1/1
                                             Running
                                                        0
                                                                   15s
crc-pcieconnection-daemon-tg79x
                                     1/1
                                             Running
                                                        0
                                                                   15s
$ kubectl get pod -n whitebox-k8s-flowctrl-system
                                                                     STATUS
                                                                               RESTARTS AGE
                                                              READY
whitebox-k8s-flowctrl-controller-manager-74b469d866-c8q7f
                                                              2/2
                                                                      Running
                                                                              0
                                                                                         5m47s
$ kubectl get pod -n wbfunction-system
NAME
                                                              READY
                                                                      STATUS
                                                                               RESTARTS AGE
wbfunction-controller-manager-6df5bf76d6-wvj65
                                                              2/2
                                                                               0
                                                                      Running
                                                                                         5m40s
$ kubectl get pod -n wbconnection-system
NAME
                                                              READY
                                                                      STATUS
                                                                               RESTARTS AGE
wbconnection-controller-manager-78b44dd58b-lbpnq
                                                              2/2
                                                                      Running 0
                                                                                         6h44m
$ kubectl get crd |grep example.com
                                                    2024-11-11T00:18:56Z
childbs.example.com
                                                     2024-11-11T07:29:35Z
computeresources.example.com
connectiontargets.example.com
                                                     2024-11-11T07:29:35Z
                                                     2024-11-11T07:29:35Z
connectiontypes.example.com
                                                    2024-11-08T08:29:56Z
cpufunctions.example.com
                                                    2024-11-11T07:29:36Z
dataflows.example.com
                                                    2024-11-10T22:56:32Z
deviceinfoes.example.com
                                                     2024-11-11T07:29:36Z
ethernetconnections.example.com
fpgafunctions.example.com
                                                    2024-11-11T00:18:56Z
                                                    2024-11-11T00:18:56Z
fpgas.example.com
                                                    2024-11-11T07:29:36Z
functionchains.example.com
                                                    2024-11-11T07:29:36Z
functiontargets.example.com
functiontypes.example.com
                                                    2024-11-11T07:29:36Z
                                                    2024-11-11T00:25:38Z
gpufunctions.example.com
                                                     2024-11-11T07:29:36Z
pcieconnections.example.com
schedulingdata.example.com
                                                    2024-11-11T07:29:36Z
topologyinfos.example.com
                                                    2024-11-11T07:29:36Z
wbconnections.example.com
                                                    2024-11-11T07:29:36Z
                                                    2024-11-11T07:29:36Z
wbfunctions.example.com
$ kubectl get functionchains.example.com -A
NAMESPACE
                                                         STATUS
chain-imgproc cpu-decode-filter-resize-high-infer-chain Ready
. . .
```

1.3 Video stream

1.3.1 DataFlow deployment

Target: K8s control plane

(1) Deploying DataFlow

The following describes how to deploy the DataFlow (DF) of the pattern A shown at the beginning of the chapter.

Apply the DF yaml of the sample data df-test-1-1 and df-test-1-2 one by one.

```
$ cd ~/controller/test/sample-data/sample-data-demo
$ kubectl apply -f yaml/dataflows/test-1/df-test-1-1.yaml
$ kubectl get dataflow -A
(Wait about 30 seconds for STATUS to be Deployed)
$ kubectl apply -f yaml/dataflows/test-1/df-test-1-2.yaml
```

(2) Checking deployment results

Check the results (STATUS) of the kubectl get command to ensure that each custom resource is generated normally and each Pod is deployed normally.

Check the following from the command execution result.

- \cdot Status of each DataFlow is Deployed
- The STATUS of each CPUFunction, GPUFunction, FPGAFunction, EthernetConnection, and PCIeConnection is Running.
- FROMFUNC_STATUS and TOFUNC_STATUS of each EthernetConnection and PCIeConnection are OK.
- No resources have been created for each EthernetConnection ("No resources found" is displayed)
- · The STATUS for each Pod is Running

```
$ kubectl get dataflows.example.com -A
$ kubectl get cpufunctions.example.com -A
$ kubectl get gpufunctions.example.com -A
$ kubectl get fpgafunctions.example.com -A
$ kubectl get pcieconnections.example.com -A
$ kubectl get ethernetconnections.example.com -A
$ kubectl get pod -n test01 -o wide
```

1.3.2 Start video reception

Target: K8s control plane

- (1) Method for starting video reception
 - i. Deployment of video reception tool and creation of reception script (advanced inference result reception ×2).

(Only perform the first time, Step i is unnecessary from the second time onward.)

```
$ cd ~/controller/sample-functions/utils/rcv_video_tool/
$ kubectl create ns test
$ kubectl apply -f rcv video tool.yaml
$ kubectl get pod -n test
                            *Checking the pod name of video stream tool
$ kubectl exec -n test -it rcv-video-tool-xxx -- bash *The xxx part is
changed according to the pod name confirmed above.
# vi start_test1.sh *Paste the following and save it.
#!/bin/bash -x
for i in `seq -w 01 02`
do
   gst-launch-1.0 -e udpsrc buffer-size=21299100 mtu=8900 port=20${i} !
'application/x-rtp, media=(string)video, clock-rate=(int)90000, encoding-
name=(string)RAW, sampling=(string)BGR, depth=(string)8, width=(string)1280,
height=(string)1280, payload=(int)96' ! rtpvrawdepay ! queue ! videoconvert !
'video/x-raw, format=(string)I420' ! openh264enc ! 'video/x-h264, stream-
format=byte-stream, profile=(string)high'
                                             ! perf
                                                       name=stream${i}
h264parse ! qtmux ! filesink location=/tmp/output_st${i}.mp4 sync=false >
/tmp/rcv_video_tool_st${i}.log &
done
# chmod +x start_test1.sh
# exit
```

ii. In a new window, open a terminal for the receiving tool, climb into the Pod and start receiving video.

```
$ kubectl exec -n test -it rcv-video-tool-xxx -- bash *Change pod name to
suit your environment
# ./start_test1.sh
```

(CRITICAL/WARNING logs are output only on the first time, but you can return to the prompt by pressing Enter. If the process startup can be confirmed in the next step, there is no problem.)

- iii. Check the startup of the video reception tool inside the container.
 - * Verify that there are two processes starting with COMMAND as Ψ_{s} gst-launch-1.0 running using ps auxwwf.

```
# ps auxwwf
USER
            PID %CPU %MEM
                            VSZ
                                  RSS TTY
                                               STAT START
                                                           TIME COMMAND
root
            971 5.0 0.0
                           6048 2836 pts/49
                                               Rs+ 10:03
                                                           0:00 ps auxwwf
. . .
            954 0.0 0.0 317188 13380 pts/48
                                               Sl+ 09:57
root
                                                            0:00 ¥_ gst-
launch-1.0 -e udpsrc buffer-size=21299100 mtu=8900 port=2008 !
application/x-rtp, media=(string)video, clock-rate=(int)90000, encoding-
name=(string)RAW, sampling=(string)BGR, depth=(string)8, width=(string)1280,
height=(string)1280, payload=(int)96 ! rtpvrawdepay ! queue ! videoconvert !
video/x-raw, format=(string)I420 ! openh264enc ! video/x-h264, stream-
format=byte-stream, profile=(string)high ! queue ! perf name=stream08 !
h264parse ! qtmux ! filesink location=/tmp/output_st08.mp4 sync=1
            943 0.0 0.0 317188 13392 pts/47
                                               S1+ 09:57 0:00 ¥_ gst-
launch-1.0 -e udpsrc buffer-size=21299100 mtu=8900 port=2007 !
application/x-rtp, media=(string)video, clock-rate=(int)90000, encoding-
name=(string)RAW, sampling=(string)BGR, depth=(string)8, width=(string)1280,
height=(string)1280, payload=(int)96 ! rtpvrawdepay ! queue ! videoconvert !
video/x-raw, format=(string)I420 ! openh264enc ! video/x-h264, stream-
format=byte-stream, profile=(string)high ! queue ! perf name=stream07 !
h264parse ! qtmux ! filesink location=/tmp/output_st07.mp4 sync=1
```

1.3.3 Start of video stream

Target: K8s control plane

- (1) Method for starting video distribution
 - i. Deployment of video streaming tools and creation of streaming scripts (two 4K 15fps streams for advanced inference)

(Execute only the first time, Step i is unnecessary from the second time onward)

```
$ cd ~/controller/sample-functions/utils/send_video_tool/
$ kubectl apply -f send_video_tool.yaml
$ kubectl get pod -n test
                    *Checking the pod name of video stream tool
$ kubectl exec -n test -it send-video-tool-xxx -- bash *Change pod name to
suit your environment
# vi start_test1.sh
                *Paste and save the following
#!/bin/bash
sleep_time=$1
${sleep_time:-3}
${sleep_time:-3}
# chmod +x start_test1.sh
# exit
```

Table 3: Explanation of arguments for start_gst_sender.sh in the above script

nth	Description	About Values
1 Video file path		Specifies the video file to be delivered. Change the settings according to the
		movie file to be used. (The above example video was created in section 7.8 of the
		"OpenKasugai-Controller-InstallManual".)
		Use 4 K 15fps video files. The length of the video is preferably about 30 to 60
		seconds.
2	Destination IP	Specify the destination IP address. Change it to match the IP address assigned
		to the CPU decoding described in the DataFlow yaml.
3	Destination Port	Specify the destination port number. Change the port number to match the
		reception port number set for the CPU decoding described in the DataFlow
		yaml.
4	Number of startup	Specify the number of delivery processes to generate (If you specify 2 or more,
	processes	start the specified number of processes that distribute the same video file to the
		same destination IP. Destination port number is incremented each time the
		delivery process is started)

5	Streaming Delay	Video streaming start delay [seconds] (interval for starting streaming
	Interval	processes when 2 or more is specified for the fourth argument)

ii. In a new window, you open a terminal for the distribution tool, climb into the Pod, and start streaming.

```
$ kubectl exec -n test -it send-video-tool-xxx -- bash *Change pod name to
suit your environment
# ./start_test1.sh
```

(A CRITICAL log may be output only the first time, but you can return to the prompt by pressing Enter. There is no problem if the process startup can be confirmed in the next step.)

iii. Confirm the startup of the video streaming tool inside the container.

*Verify that two gst-launch runs on ps aux.

```
# ps aux | grep gst-launch
          2335 0.0 0.0 309636 12272 pts/3
                                                        0:00 gst-launch-
root
                                                 11:17
1.0 filesrc location=/mnt/input_4K_15fps.mp4 ! qtdemux ! video/x-h264 !
h264parse ! rtph264pay config-interval=-1 seqnum-offset=1 ! udpsink
host=192.174.91.81 port=5004 buffer-size=2048
          2336 0.0 0.0 309636 12272 pts/3
root
                                                 11:17
                                                        0:00 gst-launch-
                                             Sl
1.0 filesrc location=/mnt/input_4K_15fps.mp4 ! qtdemux ! video/x-h264 !
h264parse ! rtph264pay config-interval=-1 seqnum-offset=1 ! udpsink
host=10.38.119.67 port=5004 buffer-size=2048
```

(2) Video input/output check of DataFlow

By following this procedure, video input from the video distribution tool is processed by the deployed DataFlow, and the resulting video is delivered to the video receiving tool. The video file of the distributed video will stop streaming once the video time elapses, but you can stop the distribution at any time by following the steps in the next section.

You can check if the video is being received by monitoring the mp4 files under/tmp in the video receiving tool container.

```
$ kubectl exec -n test -it rcv-video-tool-xxx -- bash *Change pod name to suit
your environment
# cd /tmp/
# ls -l
(Check the increase in size of each mp4 file.)
```

1.3.4 Video stream and reception stop

Target: K8s control plane

1. Stop within the container of the video distribution tool started in Section 1.3.3 and confirm that it has stopped.

2. Stop within the container of the video reception tool as follows and confirm that it has stopped.

```
$ kubectl exec -n test -it rcv-video-tool-xxx -- bash *Change pod name to suit
your environment
# pgrep gst-launch-1.0 | xargs kill -2 > /dev/null
# ps aux
    (Make sure that gst-launch is not running)
```

*The following error message may be output, but it can be ignored.

[OpenH264] this = 0x0x7fccc40058c0, Error:CWelsH264SVCEncoder::EncodeFrame(), cmInitParaError.

3. Copy each output video file to the host.

```
$ kubectl -n test cp rcv-video-tool-xxx:/tmp/output_stXX.mp4 ./output_stXX.mp4
    --retries 10
  (XX:01~02)
```

- *Execute the command with the --retries 10 option because the copy operation may fail.
- *Even if the following message is output, it can be ignored if the video file is copied.
- "tar: Removing leading '/' from member names"
- 4. The video output is a video in which the Bounding Box(BB) for the detected person is drawn.
 *In the case of an DF that includes the configuration of "FPGA F/R (PCIe connection) to GPU advanced inference" deployed in Section 1.3.1, a blank image is shown for the first approximately

one minute of the output video, and then a BB image is shown, which is a normal result. The blank image is the dummy input data when no data has yet come to GPU advanced inference.

1.4 Environmental shutdown

1.4.1 Delete DataFlow, Delete various CRs, Stop each CRC

Target: K8s control plane

Execute the following script to delete DataFlow, delete various CRs, and stop each CRC.

```
$ cd ~/script
$ ./delete_all.sh
```

After executing the above script, it is normal that some CRD and ConfigMap registered in the separate "OpenKasugai-Controller-InstallManual" procedure remain as shown below, so there is no need to manually delete them.

```
$ kubectl get crd |grep example.com
childbs.example.com
                                                    2024-11-11T00:18:56Z
cpufunctions.example.com
                                                    2024-11-08T08:29:56Z
deviceinfoes.example.com
                                                    2024-11-10T22:56:32Z
ethernetconnections.example.com
                                                     2024-11-11T23:30:33Z
fpgafunctions.example.com
                                                    2024-11-11T00:18:56Z
fpgas.example.com
                                                    2024-11-11T00:18:56Z
gpufunctions.example.com
                                                    2024-11-11T00:25:38Z
pcieconnections.example.com
                                                     2024-11-11T23:29:56Z
$ kubectl get cm
NAME
                                        DATA
                                               AGE
                                                6d11h
connectionkindmap
                                         1
                                                 6d11h
cpufunc-config-copy-branch
                                          1
cpufunc-config-decode
                                          1
                                                 6d11h
cpufunc-config-filter-resize-high-infer
                                           1
                                                  6d11h
cpufunc-config-filter-resize-low-infer
                                           1
                                                  6d11h
cpufunc-config-glue-fdma-to-tcp
                                                 6d11h
                                           1
deployinfo
                                         1
                                                22d
filter-resize-ch
                                         1
                                                22d
fpgafunc-config-filter-resize-high-infer
                                                  6d11h
                                           1
fpgafunc-config-filter-resize-low-infer
                                                  6d11h
function-unique-info
                                                6d11h
functionkindmap
                                         1
                                                6d11h
gpufunc-config-high-infer
                                                 6d11h
                                          1
gpufunc-config-low-infer
                                          1
                                                 6d11h
infrastructureinfo
                                          1
                                                22d
kube-root-ca.crt
                                         1
                                                83d
                                          1
                                                6d11h
region-unique-info
```

Target: All K8s node with an FPGA card

Use the following command to remove related files for use with PCIe connections.

```
$ sudo rm -rf /var/run/dpdk/*
$ sudo rm -rf /dev/hugepages/*
```

*When deploying DataFlow and distributing video again, start from "1.2 Initializing the environment."

2. [Appendix] Extension demonstration procedure

In this chapter, as a demonstration procedure of the OpenKasugai controller extension function, the procedure from the deployment of copy branch DataFlow and Glue DataFlow to the confirmation of data communication is shown.

- 1. Deploy one DF that branches into multiple functions in the middle using copy branch
 - df-test-ext-1-1: CPU Decode —(Ethernet connection) \rightarrow CPU F/R —(Ethernet connection) \rightarrow CPU Copy Branch —(Ethernet connection) \rightarrow GPU Advanced Inference $\times 2$




Figure 2 DF deployment image branching into multiple functions

- 2. Use connection type conversion processing (Glue) to deploy a single DF that connects functions with different connection types.
 - df-test-ext-2-1: CPU Decode (PCIe connection) \rightarrow FPGA F/R (PCIe connection) \rightarrow CPU Glue -(Ethernet connection) \rightarrow GPU advanced inference




Figure 3 DF deployment image connecting functions of different connection types

2.1 Advance preparation

2.1.1 Deploying test scripts

Targe: K8s control plane, all K8s nodes

Perform step 1.1.1. If already performed, skip this step.

2.1.2 Editing DataFlow yaml

Target: K8s control plane

For each DataFlow yaml deployed in Section 2.3.1, change the network information (IP address and port number) used by Pod of each processing module in DataFlow as necessary.

If the IP address set for each server's 100G NIC is different from the IP address shown in Figure 1 in Section 1.1 of the separate "OpenKasugai-Controller-Install Manual," change the IP address. For the method of change, refer to the separate sheet of "OpenKasugai-Controller-InstallManual_Attachment1" "2 (Supplement) DataFlow yaml settings"

Table 4 List of DataFlow yaml to deploy in Section 2.3.1

DataFlow Types		yaml to edit
1.	Copy Branch DF	~/controller/test/sample-data/sample-data-
	(df-test-ext-1-1)	demo/yaml/dataflows/test-ext-1/df-test-ext-1-1.yaml
2.	Glue DF	~/controller/test/sample-data/sample-data-
	(df-test-ext-2-1)	demo/yaml/dataflows/test-ext-2/df-test-ext-2-1.yaml

2.2 Environment initialization

Execute section 1.2.

2.3 Video stream

2.3.1 DataFlow deployment

Target: K8s control plane

(1) Deploying DataFlow

The following describes how to deploy DataFlow as shown at the beginning of Chapter 2.

i. For copy branch DF

Apply the DataFlow yaml in the sample data df-test-ext-1-1.

```
$ cd ~/controller/test/sample-data/sample-data-demo
$ kubectl apply -f yaml/dataflows/test-ext-1/df-test-ext-1-1.yaml
$ kubectl get dataflow -A
(Wait about 20 seconds until it becomes Deployed)
```

ii. For DF with Glue conversion

Apply the DataFlow yaml in the sample data df-test-ext-2-1.

```
$ cd ~/controller/test/sample-data/sample-data-demo
$ kubectl apply -f yaml/dataflows/test-ext-2/df-test-ext-2-1.yaml
$ kubectl get dataflow -A
(Wait about 20 seconds until it becomes Deployed)
```

(2) Checking deployment results

Check the results (STATUS) of the kubectl get command to ensure that each custom resource is generated normally and each Pod is deployed normally.

i. In the case of copy branch DF:

Check the following from the command execution result:

- · Each DataFlow has a STATUS of Deployed
- · Status is Running for each CPUFunction, GPUFunction, and EthernetConnection
- · FROMFUNC STATUS and TOFUNC STATUS are OK for each EthernetConnection
- · The STATUS for each Pod is Running

```
$ kubectl get dataflows.example.com -A
$ kubectl get cpufunctions.example.com -A
$ kubectl get gpufunctions.example.com -A
$ kubectl get ethernetconnections.example.com -A
$ kubectl get pod -n test01 -o wide
```

ii. In the case of Glue conversion DF

Check the following from the command execution result:

- · Each DataFlow has a STATUS of Deployed
- $\hbox{$^{\bullet}$ Status is Running for each CPUFunction, GPUFunction, FPGAFunction, PCIeConnection, and Ethernet Connection} \\$
- ${\boldsymbol \cdot}$ FROMFUNC_STATUS and TOFUNC_STATUS for each PCIeConnection and each EthernetConnection must be OK.
 - The STATUS for each Pod is Running

```
$ kubectl get dataflows.example.com -A
$ kubectl get cpufunctions.example.com -A
$ kubectl get gpufunctions.example.com -A
$ kubectl get ethernetconnections.example.com -A
$ kubectl get fpgafunctions.example.com -A
$ kubectl get pcieconnections.example.com -A
$ kubectl get pcieconnections.example.com -A
$ kubectl get pod -n test01 -o wide
```

2.3.2 Start video reception

Target: K8s control plane

- (1) Method for starting video reception
- i. For copy branch DF

Execute the same procedure as in section 1.3.2.

ii. For DF with Glue conversion

Deployment of the video distribution tool and creation of a receiving script (1 for receiving advanced inference results).

(Execute only the first time, step i is unnecessary from the second time onward)

```
$ cd ~/controller/sample-functions/utils/rcv_vide_tool/
$ kubectl create ns test
$ kubectl apply -f rcv video tool.yaml
$ kubectl get pod -n test  *Checking the pod name of video stream tool
$ kubectl exec -n test -it rcv-video-tool-xxx -- bash *The xxx part is
changed according to the pod name confirmed above.
# vi start_test2.sh *Paste and save the following
#!/bin/bash -x
for i in `seq -w 01 01`
   gst-launch-1.0 -e udpsrc buffer-size=21299100 mtu=8900 port=20${i} !
'application/x-rtp, media=(string)video, clock-rate=(int)90000, encoding-
name=(string)RAW, sampling=(string)BGR, depth=(string)8, width=(string)1280,
height=(string)1280, payload=(int)96' ! rtpvrawdepay ! queue ! videoconvert !
'video/x-raw, format=(string)I420' ! openh264enc ! 'video/x-h264, stream-
format=byte-stream, profile=(string)high' ! perf name=stream${i} ! h264parse !
                         location=/tmp/output_st${i}.mp4
             filesink
                                                            sync=false
/tmp/rcv_video_tool_st${i}.log &
done
# chmod +x start_test2.sh
# exit
```

In a new window, open a terminal for the receiving tool, climb into the Pod and start receiving video.

```
$ kubectl exec -n test -it rcv-video-tool-XXX -- bash *Change pod name to
suit your environment
# ./start_test2.sh
```

Check the start of the video reception tool.

*ps auxwwf to see that 1 process with COMMAND starting at \(\mathbb{Y}_\) gst-launch-1.0 is running.

```
$ ps auxwwf
USER
            PID %CPU %MEM
                            VSZ
                                  RSS TTY
                                              STAT START
                                                           TIME COMMAND
            971 5.0 0.0 6048 2836 pts/49 Rs+ 10:03
                                                           0:00 ps auxwwf
root
. . .
            954 0.0 0.0 317188 13380 pts/48 Sl+ 09:57
                                                           0:00 ¥_ gst-
root
launch-1.0 -e udpsrc buffer-size=21299100 mtu=8900 port=2008 !
application/x-rtp, media=(string)video, clock-rate=(int)90000, encoding-
name=(string)RAW, sampling=(string)BGR, depth=(string)8,
width=(string)1280, height=(string)1280, payload=(int)96 ! rtpvrawdepay !
queue ! videoconvert ! video/x-raw, format=(string)I420 ! openh264enc !
video/x-h264, stream-format=byte-stream, profile=(string)high ! queue !
perf name=stream08 ! h264parse ! qtmux ! filesink
location=/tmp/output_st08.mp4 sync=1
```

2.3.3 Start of video stream

Target: K8s control plane

- (1) Method for starting video stream
 - *Copy Branch DF and Glue Transform DF Common
 - i. Deployment of video stream tool and creation of stream script
 - (4K 15fps (-for advanced inference) × 1 stream)

(Perform this procedure only for the first time. This procedure (1) is not necessary for the second and subsequent times.)

- \$ cd ~/controller/sample-functions/utils/send_video_tool/
 \$ kubectl apply -f send_video_tool.yaml
 \$ kubectl get pod -n test *Checking the pod name of video stream tool
 \$ kubectl exec -n test -it send-video-tool-xxx -- bash *The xxx part is changed according to the pod name confirmed above.
 # vi start_test2.sh *Paste and save the following
 #!/bin/bash

 sleep_time=\$1

 ./start_gst_sender.sh /opt/video/input_4K_15fps.mp4 192.174.90.101 5004 1
 \${sleep_time:-3}

 # chmod +x start_test2.sh
 # exit
- ♦ Explanation of arguments for start_gst_sender.sh written in the above script.
 - *See paragraph 1.3.3 (1).

ii. In a new window, you open a terminal for the distribution tool, climb into the Pod, and start streaming.

```
$ kubectl exec -n test -it send-video-tool-XXX -- bash *Change pod name to
suit your environment
# ./start_test2.sh
```

(A CRITICAL log may be output only on the first time, but you can return to the prompt by pressing Enter. If the process startup can be confirmed in the next step, there is no problem.)

iii. Confirm start within the video stream tool's container.

*Verify that one gst-launch is running on ps aux.

```
# ps aux | grep gst-launch
root 2335 0.0 0.0 309636 12272 pts/3 Sl 11:17 0:00 gst-launch-
1.0 filesrc location=/mnt/input_4K_15fps.mp4 ! qtdemux ! video/x-h264 !
h264parse ! rtph264pay config-interval=-1 seqnum-offset=1 ! udpsink
host=192.174.90.101 port=5004 buffer-size=2048
```

(2) Video input/output check of DataFlow

Confirm using the same procedure as in section 1.3.3 (2).

2.3.4 Video stream/reception stop

Check section 1.3.4.

2.4 Environmental shutdown

Check section 1.4.