

OpenLCB Standard				
Message Network				
Mar 30, 2023	Draft			

1 Introduction

This Standard contains normative information about the OpenLCB Message Network. Corresponding discussion and background can be found in the corresponding OpenLCB Message Network Technical Note.

5 The protocol is described via three components: the state machine within the node(s); the messages; and the basic interactions in which the nodes take part. These are separately described below in terms of the general format as well as specific message definitions.

Messages are transported across a specific data-link level implementation, for example using CAN frames, TCP/IP sockets, or other transports. The messages are described first in general terms, then mapped to specific implementations (see Sections 8 and beyond). The states and interactions are the same across all data-link implementations.

2 Intended Use

20

The messages and interactions described here are used by all OpenLCB nodes to connect to the OpenLCB network. **They are mandatory.**

15 **2.1 References and Context**

For background information on format and presentation, see:

OpenLCB Common Information Technical Note

This Standard is in the context of the following OpenLCB Standard:

• The OpenLCB Unique Identifiers Standard, which specifies Unique Identifiers and how they are defined.

This Standard is in the context of the following OpenLCB CAN Standards:

- The OpenLCB CAN Frame Transfer Standard, which specifies transfer of OpenLCB messages over CAN segments. "CAN" refers to the electrical and protocol specifications as defined in ISO 11898-1:2003 and ISO 11898-2:2003 and their successors.
- 25 This Standard is in the context of the following OpenLCB-TCP/IP Standards:
 - The OpenLCB-TCP/IP Segment Transfer Standard, which specifies transfer of OpenLCB messages over TCP/IP links.

Copyright 2011-2023. All rights reserved. See http://openleb.org/Licensing.html for license terms.

Page 1 of 19 - Mar 30, 2023

Conformance with a later version of a referenced standard shall be accepted as conformance with the referenced versions.

30 3 Messages

40

3.1 Message Format

OpenLCB messages are sent using the transfer mechanism and format described in the Standard for a specific wire protocol.

All messages shall contain a source Node ID and a Message Type Indicator (MTI). The MTI defines both the general format of the message and its specific type. All messages with the same MTI are of the same type.

3.1.1 Message Type Indicators

The general Message Type Indicator (MTI) is a 16-bit quantity. The MTI values are remapped for specific wire protocols, see the appropriate sections of this document for adaptation to CAN and TCP/IP.

The current allocations are documented in a separate spreadsheet¹. We keep them in just that one place to avoid conflicting updates. Those allocations are normative.

	MTI – Message Type Indicator															
Bit(s)	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Field Reserved		Special	Stream or	Prio	rity	Γ	ур	e w	ithi	n	Simple	Address	Event	Mod	lifier	
				Datagram			Priority		Protocol	Present	Present					

¹See Appendix 1, and the associated TN, which it provides concrete examples that may help you understand the material in this document.

		-	MTI Bit-	field Descriptions
Field Name	Bit Position	Size bits	Mask hex	Description
Reserved	14 - 15	2	0xC000	Reserved for future use, send and check as zero.
Special	13	1	0x2000	Operationally special, 1=do not forward through Gateways
Stream or Datagram	12	1	0x1000	0=Regular message, 1=Stream or Datagram message
Priority	10 - 11	2	0x0C00	Gross priority of message, 0 is highest priority
Type within Priority	5 - 9	5	0x03E0	Minor priority determination
Simple Protocol	4	1	0x0010	1=This message should be handled by simple nodes
Address Present	3	1	0x0008	1=This message has a destination address-field
Event Present	2	1	0x0004	1=This message has an event-field
Modifier	0 - 1	2	0x0003	Message-specific extra information

Note that these fields inform the intent of the message, but also the overall format of the rest of the message.

3.1.2 Message Content

The message content consists of:

The MTI

50

- The source Node ID
- If the MTI flags it as being present, the destination Node ID
- If the MTI flags it as being present, an Event ID
- Any other content as defined for the specific message type.
- The exact format and order are defined by the specific wire protocols, but in all cases the message shall be fully decodable based on the flag-bit information in the MTI.

3.2 States

The message network layer in an OpenLCB node has two states:

- Uninitialized
- Initialized

Nodes shall start in the Uninitialized state.

A node in the Uninitialized state may transmit an Initialization Complete message, but shall not transmit any other message type.

A node in the Initialized state may transmit any message type.

65

60

70

3.3 Definition of Specific Messages

This section defines the format of common core messages. Although there is a short description of the purpose of the message, and related interactions, this is just for identification and explanatory purposes. The meaning of the messages is defined by the interactions in which they take part. These are described in later sections.

When a Node ID is present in the data content of the message, the full 48-bit identifier shall be sent for all wire protocols, specifically including CAN, even if an alias or alternate form is available elsewhere in the message.

3.3.1 Initialization Complete

75 Indicates that the sending-node initialization is complete and, once the message is delivered, it is reachable on the network.

Name	Description	Simple Protocol	Dest ID	Event ID	Common MTI	Data Content
Initialization	Full Protocol Required	<u>0</u> N	<u>N0</u>	<u>N0</u>	0x0100	Source Node ID
Complete	Simple-set Sufficient	<u>0</u> N	<u>N0</u>	<u>N0</u>	0x0101	Source Node ID

This message has two MTIs, distinguished by the modifier field, to indicate whether the node requires delivery of all the messages in the full protocol, or whether delivery of the Simple Protocol subset is sufficient.

80 3.3.2 Verify Node ID

Issued to determine which node(s) are present and can be reached.

Name	Description	Simple Protocol	Dest ID	Event ID	Common MTI	Data Content
Verify Node	Addressed	<u>0</u> -2	¥ <u>1</u>	<u>N0</u>	0x0488	Optional Full Node
ID	Global	<u>1</u> ¥	<u>N0</u>	<u>N0</u>	0x0490	ID

3.3.3 Verified Node ID

Reply to the Verify Node ID message.

Name	Description	Simple Protocol		Event ID	Common MTI	Data Content
Verified Node	Full Protocol Required	¥ <u>1</u>	<u>N0</u>	<u>N0</u>	0x0170	Source Node ID
ID Number	Simple Subset Sufficient	¥ <u>1</u>	<u>N0</u>	<u>N0</u>	0x0171	Source Node ID

² Addressed messages are always directed to the destination node, regardless of the content of the Simple bit. See section 4By definition, all addressed messages are received by the addressee, so the simple bit is ignored. See TN.

This message has two MTIs, distinguished by the modifier field, to indicate whether the node requires delivery of all the messages in the full protocol, or whether delivery of the Simple Protocol subset is sufficient

3.3.4 Optional Interaction Rejected (OIR)

This is a reply indicating failure.

Name	Simple Protocol	Dest ID	Event ID	Common MTI	Data Content
Optional Interaction Rejected	<u>0</u> N	<u>¥1</u>	<u>N0</u>	0x0068	Error code, MTI, optional info

- 90 The data contents are, in order:
 - Two bytes of error code.
 - Two bytes of MTI. If the frame transport only delivered part of the MTI³, that content is returned with the rest of the MTI bits set to zero.
 - Any extra bytes that the node wishes to include. There can be zero or more of these, to a maximum of 64 bytes. These shall be described in the node documentation.

Nodes shall process this message even if not all of the contents are provided.

For Error Codes see section 3.5.6 Error Codes, and section 3.5 Error Handling.

3.3.5 Terminate Due to Error

This is a reply indicating failure.

Name	Simple Protocol	Dest ID	Event ID	Common MTI	Data Content
Terminate Due to Error	<u>0</u> N	<u>¥1</u>	<u>0</u> N	0x00A8	Error code, MTI, optional info

- 100 The contents are, in order:
 - Two bytes of error code.
 - Two bytes of MTI. If the frame transport only delivered part of the MTI⁴, that content is returned with the rest of the MTI bits set to zero.
 - Any extra bytes that the node wishes to include. There can be zero or more of these, to a maximum of 64 bytes. These shall be described in the node documentation.

Nodes shall process this message even if not all of the contents are provided.

For error codes see section 3.5.5 Error Codes and section 3.4.3. Error Handling.

3.3.6 Protocol Support Inquiry

Requests that the addressed node reply with an indication of which protocols it supports.

95

105

³For example, in this case, CAN delivers 12+1 bits of the MTI via each frame (the special bit is known to be zero).

⁴For example, in this case, CAN delivers 12+2 bits of the MTI via each frame (the special bit is known to be zero and the stream/datagram bit can be inferred).

Name	Simple Protocol	Dest ID	Event ID	Common MTI	Data Content
Protocol Support Inquiry	<u>0</u> -	¥ <u>1</u>	<u>N0</u>	0x0828	(none)

110

115

3.3.7 Protocol Support Reply

Replying indicating the protocols that the node supports.

Name	Simple Protocol		Event ID	Common MTI	Data Content
Protocol Support Reply	<u>0</u> -	¥ <u>1</u>	<u>N0</u>		One or more bytes identifying the supported protocols; see Table immediately below for coding.

A 1 in a bit position of the data indicates that the corresponding protocol is supported by the transmitting node. A 0 in the bit position indicates that the corresponding protocol is not supported by the transmitting node.

If a node transmits less than the full length of the currently-defined reply data, any missing bits shall be interpreted as zero.

Protocol	—Protocol Flags	LCC Adopted	OpenLCB Adopted
Simple Protocol subset	0x80 00 00	<u>X</u>	<u>X</u>
Datagram Protocol	0x40 00 00	<u>X</u>	<u>X</u>
Stream Protocol	0x20 00 00		<u>2</u>
Memory Configuration Protocol	0x10 00 00	<u>X</u>	<u>X</u>
Reservation Protocol	0x08 00 00		<u>3</u>
Event Exchange (Producer/Consumer) Protocol	0x04 00 00	<u>X</u>	<u>X</u>
Identification Protocol	0x02 00 00		<u>3</u>
Teaching/Learning Configuration Protocol	0x01 00 00		<u>4</u>
Remote Button Protocol	0x00 80 00		<u>3</u>
Abbreviated Default CDI Protocol	0x00 40 00	X	<u>X</u>
Display Protocol	0x00 20 00		<u>3</u>
Simple Node Information Protocol	0x00 10 00	<u>X</u>	<u>X</u>
Configuration Description Information (CDI)	0x00 08 00	<u>X</u>	<u>X</u>
Traction Control Protocol (Train Protocol)	0x00 04 00		<u>2</u>
Function Description Information (FDI)	0x00 02 00		<u>2</u>
DCC Command Station Protocol	0x00 01 00		<u>3</u>
Simple Train Node Information Protocol	0x00 00 80		<u>2</u>
Function Configuration	0x00 00 40		<u>2</u>
Firmware Upgrade Protocol	0x00 00 20	1	<u>X</u>
Firmware Upgrade Active	0x00 00 10	1	<u>X</u>
Reserved for future protocol bits. Shall be sent as 0 and ignored upon receipt. Trailing 0-bytes do not need to be sent.	All others		

¹⁾ In Review for adoption

3.4 Interactions

<u>All</u> nodes shall be able to take part in all standard interactions, as defined below.

²⁾ Protocol development is active and in work

³⁾ Protocol is reserved for future use but is not actively in work

<u>4) Detailed working note available on OpenLCB website, early adoption nodes implemented this protocol but it is not required for conformance</u>

120 **3.4.1 Node Initialization**

Newly functional nodes, once their start-up is complete and they are fully operational, shall send an Initialization Complete message and enter the Initialized state. Nodes shall not emit any other OpenLCB message before the Initialization Complete message.

3.4.2 Node ID Detection

Upon receipt of a directed (addressed) Verify Node ID message addressed to it, a node shall reply with an unaddressed Verified Node ID message.

Upon receipt of a global (unaddressed) Verify Node ID message that <u>does not contain</u> an (optional) Node ID, a node shall reply with an unaddressed Verified Node ID message.

Upon receipt of a global (unaddressed) Verify Node ID message that <u>contains</u> an (optional) Node ID, a node will reply with an unaddressed Verified Node ID message, <u>if and only if</u> the receiving node's Node ID matches the one received.

If a node receives multiple Verify Node ID messages before it replies to one or more, it may, but is not required to, combine multiple responses into one.

3.4.3 Protocol Support Inquiry and Response

On receipt of a Protocol Support Inquiry message, a node will reply with a Protocol Support Response with bit values corresponding to the protocols that the node implements.

3.5 Error Handling

145

There are multiple error-handling scenarios defined.

140 3.5.1 Reject Addressed Optional Interaction

If a Node receives an addressed message with an MTI that is not part of the mandatory set, and it does not want to take part in that interaction, it shall send an Optional-Interaction Rejected (OIR) message addressed to the originating node, with the original MTI in the message content to indicate that the MTI is not recognized or not implemented by this node. The OIR message content may also contain a reason code and a data value, as defined by the protocol, as listed below in section 3.5.6.

3.5.2 Reject Unaddressed Optional Interaction

If a Node receives an unaddressed message with an MTI that indicates the start of a non-mandatory / optional interaction, and the Node does not take part in that optional interaction, it may silently drop the message without reply.

150 3.5.3 Reject Addressed Standard Interaction Due to Error

If a Node is taking part in an addressed interaction with another node, where either node may be able to send the next message, and some error condition prevents this Node from continuing the interaction, to terminate the interaction, this Node shall send a Terminate Due to Error message to the other Node. It shall reset its state so as to no longer be taking part in the addressed interaction. The message content

shall contain the most recent MTI received in this interaction, a mandatory reason code and an optional data value.

In addition, upon receipt of the Terminate Due to Error message, the other Node also shall reset its state so as to no longer be taking part in the addressed interaction.

3.5.4 Duplicate Node ID Discovery

OpenLCB nodes shall indicate an error when they detect an incoming message with a Source Node ID equal to their own using whatever indication technology is available. See the General Event documentation for one method of indication that uses a well-known Global-Event.

3.5.5 Error codes

Numerous messages are defined to carry status information and error codes. An OpenLCB Error code is a 2-byte value of the following format:

	Error Code Format								
Bits	Description								
12-15	Error type flags. Zero or one bit shall be selected.								
8-11	Reserved. Send as zero, ignored on receipt.								
4-7	General Error Enumeration 0-15. Default as zero, and ignored on receipt.								
0-3	Reserved for use of specific protocols for error reporting. Interpretation of these bits will be defined in the specific protocol documentation. A value of zero in this field means no further information is available. Default as 0, and ignored on receipt.								

The following General Error Codes are defined. All protocols shall use at least Error Codes 0x0000, 0x1000, and 0x2000, and may use the extended Error Codes.

	General Error Codes
Value	Description
Permanent Erro	r Enumeration. Re-trying the same interaction will result in the same error.
0x100x	Permanent error.
0x101x	Reserved.
0x102x	Source not permitted.
0x103x	Reserved. Not found.
0x104x	Not implemented.
0x105x-0x107x	Reserved
0x108x	Invalid arguments. Some of the values sent in the message fall outside of the expected range, or do not match the expectations of the receiving node.
0x109x-0x10Fx	Reserved.
Temporary Erro	r (resend OK). Re-trying the same interaction later is likely to succeed.
0x200x	Temporary error, not further not specified.
0x201x	Timeout, the expected message or message-part did not arrive in time.
0x202x	Buffer unavailable or destination node busy.
0x203x	Reserved.
0x204x	Not expected, Out of order. An inconsistency was found in the message or frame sequence received, the arrived message is unexpected or does not match the state of the receiving node.
0x205x-0x207x	Reserved.
0x208x	Transfer error. The message or received message was ill-formed, failed checksum, or is otherwise uninterpretable. On CAN, this is handled by the hardware.
0x209x-0x20Fx	Reserved.
Reserved	
0x300x-0x70Fx	Reserved. Write as zero, ignored on read.
Accept Flag	
0x800x	Accept, no error. This value shall not be used in reject messages.

NB: Nodes may return 0x0000 as an error-code.

The following Error Codes may be specifically used by the Message Network Protocol:

	Message Network Specific Error Codes					
Value	Value Description					
Permanent Err	Permanent Error Enumeration. Re-trying the same interaction will result in the same error.					
0x1041	Not implemented, subcommand is unknown.					
0x1042	Not implemented, Datagram-type, Stream-type, or command is unknown.					
0x1043	Not implemented, unknown MTI, or Transport protocol (datagrams/streams) is not supported.					
Temporary Err	ror (resend OK). Re-trying the same interaction later is likely to succeed.					
0x2011	Time-out, waiting for End-frame.					
0x2041	Out of Order, Middle- or End-frame without a Start-frame.					
0x2042	Out of Order, Start-frame before finishing previous message.					

175 **3.6 Routing**

180

All messages may be, but are not required to be, presented to every node for processing.

Addressed messages shall to be routed to the addressed node. The node transmitting an addressed message addressed to itself shall take part in any interactions required by the message.

Unless otherwise specified in a protocol document, global messages shall be forwarded to all nodes. The node transmitting a global message shall take part in any interactions required by the message.

3.7 Delays and Timeouts

Nodes shall send messages required by OpenLCB protocols within 750 milliseconds, unless otherwise indicated in the documentation for the specific protocol interaction.

Nodes may, but are not required to, use a timeout mechanism to protect against messages lost due to malfunctions. Such a timeout shall not be shorter than 3 seconds.

4 Simple Node Protocol Subset

OpenLCB uses the Simple Node Protocol to distinguish a subset of global message types that are never needed by certain "simple" nodes. They can then be rapidly ignored by those nodes, and gateways can filter them from segments that contain only simple nodes, etc. It is not normative.

190 **4.1 Protocol Description**

Operationally, the simple node protocol is defined by the MTIs that carry a set Simple Node bit, plus all addressed messages. This section summarize received transmitted messages.

4.1.1 Messages Transmitted

Simple nodes may transmit any message, which shall be propagated normally.

195 **4.1.2** Messages Received

Simple nodes shall receive any message specifically addressed to them, plus the following unaddressed global messages:

- Verify Node ID;
- Verified Node ID:
- Protocol Support Inquiry;
- Identify Consumers;
- Identify Producers;
- Identify Events;
- Learn Event;
- P/C Event Report;

200

225

In the future, additional MTIs will be defined. If simple nodes need to received them, the MTI will indicate that via the Simple bit – see previous section.

4.1.3 Messages Not Received

Messages <u>not</u> listed in the section above do <u>not</u> need to be received by simple nodes.

210 4.1.4 Messages Directed at Gateways

Gateways need to know which nodes consider themselves to be Simple. These nodes shall use the variants of the Initialization Complete and Verified Node ID messages that indicate Simple Set Sufficient (0x0101 and 0x0171, respectively) to indicate to Gateways that they are simple nodes.

5 Gateway Processing

215 No Standard content, see TN for discussion.

6 Expansion

No Standard content, see TN for discussion.

7 CAN Adaptations

7.1 Introduction

- This section specifies how the Common Protocols are mapped to the CAN. While CAN is relatively inexpensive and robust, it is limited by its bandwidth and its total frame size, which is about 12-bytes, and by its speed (125 kbps). Each CAN frame includes a header (29-bits) and a data-part (8-bytes). In addition, the CAN-header has special properties which both enhance and limit its use. The Common Messages are adapted to CAN by:
 - The Common-MTI is shortened to 12 bits, and carried in the header.
 - Node IDs are shortened to 12 bit CAN-Aliases.
 - Longer messages are fragmented into one or more CAN-frames. Special frames formats are used to implement Datagrams and Streams.

These mappings result in a set of modified formats as documented in this section. This section's numbering parallels that of the Common sections.

Common Message	CAN Mapping	Comment
Most messages	Usually single frame	Multiple frames are used for longer messages.
Datagram	First-, Middle-,, Last- frames	Small Datagrams may be carried by a single Only-frames.
Stream	Stream-Data-frames	A common Stream-message will be mapped to one or more Stream-Data-frames.

7.2 Intended Use

CAN is intended as a local transport for smaller layouts, or for local segments on larger layouts.

Accommodation and specialization is necessary to implement the protocols onto CAN because CAN frames are limited to about 12 bytes of information. The main mappings include a shortened CAN-MTI (12-bits) and the use of 12 bit aliases for Node Ids. These have implications for Gateways which are specified below.

7.2.1 References and Context

- 240 This Standard is in the context of the following OpenLCB CAN Standards:
 - The OpenLCB CAN Frame Transfer Standard, which specifies transfer of OpenLCB messages over CAN segments. "CAN" refers to the electrical and protocol specifications as defined in ISO 11898-1:2003 and ISO 11898-2:2003 and their successors.

7.3 Messages

245

7.3.1 Message Format

The CAN mapping uses several formats. The general form of the CAN header is:

	29-bit CAN Header									
Field	CAN pro	etiv	rame Format	Variable Field			Sou	rce ID		
Size & location	2 bits 0x1800,0		3 bits 700,0000	12 bits 0x00FF,F000						2 bits 00,0FFF
Value(s)	3	1,2,3	,4,5,or 7	CAN-MTI or Destination Node Alias			as Source	Node Alias		
	Up to 8 Byte Data-Part									
Byte#	0	1	2	3	4	5	6	7		
Values	variable	variable	(Data)	(Data)	(Data)	(Data)	(Data)	(Data)		

Table 1: CAN Frame Format

CAN frames also contain other bit fields not detailed here, including a DLC or length field.

7.3.1.1 CAN Prefix Field

250 The CAN Prefix Field contains control bits specific to CAN.

7.3.1.2 CAN MTI Mapping

The Common MTI is mapped to one of eight frame typeformats:

Frame TypeFormat	Meaning
0	(Reserved)
1	Global & Addressed MTI
2	Datagram complete in frame
3	Datagram first frame
4	Datagram middle frame
5	Datagram final frame
6	(Reserved)
7	Stream Data

Table 2: CAN Frame TypeFormat Values

[7.3.1.3] Global and Addressed Messages, CAN Frame TypeFormat 1

Global and Addressed messages are those Common MTIs with the "stream and datagram" bits set to 0, and are mapped to and from CAN MTI typeformat 1.

The CAN MTI is carried in the CAN header. It consists of the lowest-order 12 bits of the Common MTI, and, by implication has the "stream or datagram" and "special" bits as zeros.

	29-bit CAN Header									
Field	CAN prefix	Frame TypeFo rmat	Static Priority	Type within Priority	Simple Node flag	Addre Preser	$\begin{bmatrix} ss \\ t \end{bmatrix}$ I	ent D sent	Modifier Bits	Source ID
Size & location	2 bits 0x1800, 0000	3 bits 0x0700, 0000	2 bits 0x00C0, 0000	5 bits 0x003E, 0000	1 bit 0x0001, 0000	1 bit 0x0000 8000), $0x0$	bit 000, 000	2 bits 0x0000, 3000	12 bits 0x0000, 0FFF
Value(s)	3	1		CAN-MTI					Source Node Alias	
	Up to 8-Byte Data-Part									
Byte#	C)	1		2	3	4	5	6	7
Value	Optional	Flags/Des	tn Alias o	or (Data)	(Data)	(Data)	(Data)	(Data	a) (Data)	(Data)

Table 3: CAN Frame TypeFormat 1-Format

If the Address Present bit is set to 1, then the destination address is placed in the 1st two bytes of the data part of the CAN frame: the top nibble of the 1st byte contains flags (see below); the lower nibble of the 1st byte and the entire 2nd byte contain the 12-bit destination alias.

The format of this in binary is: **0brrff dddd, dddd dddd** (or in hex: **0xfddd**)

265 where:

- The two rr bits are reserved, and read and send as zeros.
- The two ff bits can be used for packing and unpacking large messages to a sequence of CAN frames, see below. The coding is:
 - 00 Only frame
 - 01 First frame of more than one
 - 10 Last frame of more than one
 - 11 Middle frame of more than 2.
- You can think of these as active-zero start and end bits, respectively.

CAN frames marked as First or Middle frame shall carry eight total data bytes. CAN frames marked as Last or Only frame shall have from two through eight total data bytes. 275

[7.3.1.4] Datagram and Stream Messages, CAN Frame TypeFormats 2-5 and 7

Frame TypeFormats 2-5 and 7 are used specifically for Datagram and Stream messages.

7.3.2 **States**

280 There are no special provisions for CAN transport layer.

260

270

7.3.3 Definition of Specific Messages

CAN messages definitions parallel the common messages in section #3.3.Definition of Specific Messages.

7.3.3.1 Initialization Complete

Name	Description	CAN-MTI	CAN Header	Data Content
Initialization	Full protocol	0x100	[0x1910,0sss]	Full Source Node ID
Complete	Simple-set sufficient	0x101	[0x1910,1sss]	Full Source Node ID

285 **7.3.3.2 Verify Node ID**

Name	Description	CAN-MTI	CAN Header	Data Content
Verify Node ID	Addressed	0x488	[0x1948,8sss]	fddd ⁵ , Optional Full Node ID
Verify Node ID	Global	0x490	[0x1949,0sss]	Optional Full Node ID

7.3.3.3 Verified Node ID.

Name	Description	CAN-MTI	CAN Header	Data Content
Verified Node ID	Full protocol	0x170	[0x1917,0sss]	Full Source Node ID
verified Node ID	Simple-set sufficient	0x171	[0x1917,1sss]	ruii source Node ID

7.3.3.4 Optional Interaction Rejected

Name	CAN-MTI	CAN Header	Data Content
Optional Interaction Rejected	0x068	[0x1906,8sss]	fddd, error, MTI, optional info

⁵ "fddd" refers to a flag-nibble "f", containing multipart flags, and the 12-bit Destination Node Alias "ddd". See TN.

7.3.3.5 Terminate Due to Error

Name	CAN-MTI	CAN Header	Data Content
Terminate Due to Error	0x0A8	[0x190A,8sss]	fddd, error, MTI, optional info

7.3.3.6 Protocol Support Inquiry

Name	CAN-MTI	CAN Header	Data Content
Protocol Support Inquiry	0x828	[0x1982,8sss]	fddd

7.3.3.7 Protocol Support Reply

Name	CAN-MTI	CAN Header	Data Content
Protocol Support Reply	0x668	[0x1966,8sss]	fddd, Protocol flags

This shall be a multi-part message when there are more than 48 protocol-bits.

7.3.4 Extensibility

290

295

Since the earlier nodes may reply as soon as they have processed only the data of which they are aware, their replies may be earlier than the last message fragment is received. Sending-nodes shall be able to receive and process these replies as they are received.

7.3.5 Interactions

There are no special provisions for CAN transport layer.

7.3.6 Error Handling

There are no special provisions for CAN transport layer.

300 **7.3.7 Routing and Sequencing**

CAN implementations shall send the frames of a message together to reduce buffering consecutively on the CAN bus, with no frames of equal or lower priority being interspersed. –Higher-priority messages may be sent in the middle of a lower-priority message, including when the higher priority message itself is fragmented into multiple frames.

Gateways shall reassemble the frames of fragmented messages before sending them out on data links that support the necessary message length, unless otherwise stated by a specific Standard.—

T	able of Contents	
1	Introduction	1
2	Intended Use	1
	2.1 References and Context	1
3	Messages	
	3.1 Message Format.	2
	3.1.1 Message Type Indicators	2
	3.1.2 Message Content	3
	3.2 States	3
	3.3 Definition of Specific Messages.	4
	3.3.1 Initialization Complete	4
	3.3.2 Verify Node ID	
	3.3.3 Verified Node ID.	4
	3.3.4 Optional Interaction Rejected (OIR)	5
	3.3.5 Terminate Due to Error	
	3.3.6 Protocol Support Inquiry	5
	3.3.7 Protocol Support Reply	6
	3.4 Interactions	7
	3.4.1 Node Initialization.	8
	3.4.2 Node ID Detection	8
	3.4.3 Protocol Support Inquiry and Response.	8
	3.5 Error Handling	8
	3.5.1 Reject Addressed Optional Interaction	
	3.5.2 Reject Unaddressed Optional Interaction	
	3.5.3 Reject Addressed Standard Interaction Due to Error	
	3.5.4 Duplicate Node ID Discovery	9
	3.5.5 Error codes	
	3.6 Routing	
	3.7 Delays and Timeouts.	
4	Simple Node Protocol Subset.	
	4.1 Protocol Description.	
	4.1.1 Messages Transmitted	
	4.1.2 Messages Received	
	4.1.3 Messages Not Received	
	4.1.4 Messages Directed at Gateways	
	Gateway Processing	
	Expansion.	
7	CAN Adaptations	
	7.1 Introduction	
	7.2 Intended Use	
	7.2.1 References and Context.	
	7.3 Messages	
	7.3.1 Message Format	
	7.3.1.1 CAN Prefix Field	
	7.3.1.2 CAN MTI Mapping	.14

7.3.1.3 Global and Addressed Messages, CAN Frame Type 1	14
7.3.1.4 Datagram and Stream Messages, CAN Frame Types 2-5 and 7	15
7.3.2 States	
7.3.3 Definition of Specific Messages	16
7.3.3.1 Initialization Complete	
7.3.3.2 Verify Node ID.	
7.3.3.3 Verified Node ID.	
7.3.3.4 Optional Interaction Rejected	16
7.3.3.5 Terminate Due to Error.	16
7.3.3.6 Protocol Support Inquiry	16
7.3.3.7 Protocol Support Reply	17
7.3.4 Extensibility	
7.3.5 Interactions	17
7.3.6 Error Handling	17
7.3.7 Routing and Sequencing	