

## USB charger + power path







Diagram showing the connection of pin 3 (GND) to the GND pin of the J1 connector. The text "ESP32" is visible in the background.



3.3V buck-boost<sup>6</sup>



2x PhotoMOS



|                                                                                          |         |
|------------------------------------------------------------------------------------------|---------|
| Ported from EasyEDA Pro project ESP32C3CameraTrigger 2026-09-02 (rev with side-entry U4) |         |
| Sheet: /                                                                                 |         |
| File: openrz67.kicad_sch                                                                 |         |
| <b>Title: OpenRZ67 camera trigger</b>                                                    |         |
| Size: User                                                                               | Rev: 2  |
| Date: 2026-09-03                                                                         | Id: 1/1 |
| KiCad E.D.A. 10.0.6                                                                      |         |