Definitions (v1.2)

	Format	Remarks
Message type	XML	Commonly used
File name	GUID	
File extension	XML	
Coding	UTF8	
Case	XML Elements are case insensitive	
Booleans	true / false	
Full datetimes	<testdatevalue>2019-01-07T09:39:54.5407889+01:00</testdatevalue>	Adding a time zone indicates an offset between sender and receiver.
Local datetimes	<testdatevalue>2018-09-05T15:30:00</testdatevalue>	Datetimes that are local to the receiving party are given without time zone
Weights	Ordinal number of kilograms	
Temperatures	Ordinal number of Celsius	
Depot Service Provider services enumerator	 Cleaning = 1 Repair = 2 HandIn = 4 HandOut = 8 Handling = 12 * Heating = 16 	Enumerator combinations Enumerators can be combined. E.g.: To request for handling, cleaning, repair and storage, put 47 (1 + 2 + 12 + 32) *About Handling enumerators Handling (12) denotes a combination of IN + OUT. But there is a special case for
	 Storage = 32 Additional = 64 ** Parts = 128 Transport = 256 HeelDisposal = 512 Transhipment = 1024 Leasing = 2048 ProjectItem = 4096 Drumming = 8192 Cargo = 16384 Trading = 1048576 	workflow status messages: Status messages can appear for 4, 8 and 12 independently, in THAT case 12 means "any other form of handling other than in or out". **About Additional (64) enumerator Additional (64) will always be accompanied by a textual description of what it actually is. To request for some additional service in a pre-advise, use the additional wishes table and NOT enumerator 64.
Equipment Group enumerator	 Undetermined = 0 TankContainer = 1 BoxContainer = 2 Trailer = 3 IBC = 4 Reefer = 5 RailWagon = 6 Liquid = 7 Silo = 8 Machinery = 12 Generator = 13 Hose = 14 Truck = 16 Chassis = 17 	