Definitions (v1.3)

	Format	Remarks
Message type	XML	Commonly used
File name	GUID	
File extension	.XML	
Coding	UTF8	
Case	XML Elements are case insensitive	
Booleans	true / false	
Full datetimes	<testdatevalue>2019-01-07T09:39:54.5407889+01:00</testdatevalue>	Adding a time zone indicates an offset between sender and receiver.
Local datetimes	<testdatevalue>2018-09-05T15:30:00</testdatevalue>	Datetimes that are local to the receiving party are given without time zone
Weights	Ordinal number of kilograms	
Temperatures	Ordinal number of Celsius	
Depot Service Provider services	Cleaning = 1	Enumerator combinations
enumerator	• Repair = 2	Enumerators can be combined.
	• Handin = 4	■ E.g.: To request for handling, cleaning, repair and storage, put 47 (1 + 2 + 12
	HandOut = 8	+ 32)
	Handling = 12 *	*About Handling enumerators
	• Heating = 16	Handling (12) denotes a combination of IN + OUT. But there is a special case for
	• Storage = 32	workflow status messages: Status messages can appear for 4, 8 and 12 independently, in THAT case 12 means
	Additional = 64 **	"any other form of handling other than in or out".
	• Parts = 128	**About Additional (64) enumerator
	• Transport = 256	Additional (64) will always be accompanied by a textual description of what it actually is.
	HeelDisposal = 512	To request for some additional service in a pre-advise, use the additional wishes
	Transhipment = 1024	table and NOT enumerator 64.
	Leasing = 2048 ProjectItem = 4096	
	Projection = 4090 Drumming = 8192	
	Cargo = 16384	
	• Trading = 1048576	
Equipment Crown on morester		
Equipment Group enumerator	Undetermined = 0 Truthouthing 4	
	TankContainer = 1 BoxContainer = 2	
	Trailer = 3	
	• IBC = 4	
	Reefer = 5	
	RailWagon = 6	
	• Liquid = 7	
	• Silo = 8	
	Machinery = 12	
	Generator = 13	
	• Hose = 14	
	• Truck = 16	
	• Chassis = 17	