## SPARE PARTS / Parrot Disco / Motor


To replace the motor of the Parrot Disco, you need a PH2 screwdriver, a T6 screwdriver and a T10 screwdriver.

It is recommended to use the Parrot Toolbox for this operation.

## DIFFICULTY LEVEL

Parrot





Open the cowling.

