




INSTRUCTIONS ROBOTIC ARM WITH LEGO WEDO 2.0 + MICRO:BIT





V 1.0


giancarlo.tech@gmail.com https://www.facebook.com/codingasprincess

















































10 B 2x 1x




























16 P

















LETS CODE USING LEGO WEDO 2.0 APP





































LETS CODE USING MICROBIT AND SCRATCH

1.- Install Scratch from this link:


https://play.google.com/store/apps/details?id=org.scratch&hl=es

2.- Create a new Scratch Project

After you create a Scratch project



3.- Add micro:bit extension




4.- Install Scratch Link ONLY if you will work with Scratch in PC, with devices (Tablets) is not needed, but in this tutorial we are working with a tablet.

You will need to install Scratch Link from this LINK

https://downloads.scratch.mit.edu/link/windows.zip

After you install Scratch link, make sure it is up and running, it should be in the toolbar.



4.- Install Sractch micro:bit HEX file in your micro:bit

This file needs to be added in microbit by using USB cable.




Connect micro:bit to your PC with a USB cable





Download the file Scratch micro:bit HEX from this link.

3




Drag and Drop the HEX file into the micro:bit

https://downloads.scratch.mit.edu/microbit/scratch-microbit-1.1.0.hex.zip


4.- Bind Scratch with micro:bit

Now in Scratch you should see your micro:bit listed so click in "Connect"




4.- Code in Scratch

Now lets add some coding blocks to make this work from the scratch side.



5.- glove to manipulate the robotic arm

You can use platinum paper, and scotch paper





THANK YOU

