


Steering Motor

## **Batteries in Battery Tray**



## Notes:

Drawings not to scale See schematic for wiring details Relays are located above battery 5

