quickstart.md 2024-02-03

Quick Start

Default storage: the kernel is set with usb storage.

The manual is here: https://orix-software.github.io/

Important informations

- Twilighte board is the hardware, Orix is the OS
- The board always boots without any storage device (sdcard or usb). If it does not, it's probably a incompatibility with the Oric: add an amplibus before the board
- In order to work properly, Orix needs storage device connected (usb mass storage or sdcard) with all files from sdcard.tgz: http://repo.orix.oric.org/dists/official/tgz/6502/sdcard.tgz

For board with 39SF040 eeprom, only use orixcfg equal or greater than 2023.2. Check version under Orix with:

orixcfg -v

Beta version is here: http://repo.orix.oric.org/dists/alpha/tgz/6502/orixcfg.tgz

To check which eeprom version is installed (Device Id fielld):

orixcfg -i

How the board must be plugged



If there is incompatibility issue use next board usage.

How the board must be plugged when board does not with the oric (keyboard is lost or prompt does not appears)

quickstart.md 2024-02-03

