Rechnerarchitektur Serie 4

Dominik Bodenmann 08-103-053 Orlando Signer 12-119-715

29. April 2014

1 Theorie-Teil

1.1 Aufgabe 1

Da bei beq und bne die Positionen , an die gesprungen werden soll, relativ zur aktuellen Positin angegeben wird, braucht es negative Werte.

Ebenfalls bei den Load und Store Befehlen kann der Offset zur Basisadresse negativ sein.

1.2 Aufgabe 2

Eingabe	Ausgabe
0xFE & 0xEF	0xEE
0xFE && 0xEF	1
0xFE 0xEF	0xFF
0xFE 0xEF	1
$\sim 0xFE$	-0xFF
!0xFE	0

1.3 Aufgabe 3

Mittels Schnittstellen, an denen die Hardware entsprechende Informationen zur Verfügung stellt

Als Beispiel: Die Switches des Boards, die, je nachdem wie sie gestellt sind, ein Feld entweder mit 0 oder 1 füllen.

1.4 Aufgabe 4

- 1. Singlecycle-Implementation Das Resultat einfach invertieren, falls die ALU beim Vergleich 0 zurück gibt. (NOT-Gatter am 0-Ausgang der ALU)
- 2. Multicycle-Implementation Analog Singlecycle-Implementation.

1.5 Aufgabe 5

Um die Daten, die für den nächsten Rechenschritt gebraucht werden, zwischenzuspeichern, da die nächste Berechnungsstufe möglicherweise noch nicht zur Verfügung steht.

1.6 Aufgabe 6

Structural Hazard: Tritt auf, falls während einem Clock-Cycle die gleiche Resource von zwei verschiedenen Instruktionen benötigt wird. Z.B. wenn eine Instruktion im 4. Schritt etwas vom Memory liest, gleichzeitig aber eine andere Instruktion in der Pipeline ihre Instruktion vom Memory liest. Dies kann umgangen werden, indem es separate Memories für Instruktionen und Daten gibt.

Data Hazard: Tritt auf, wenn eine Instruktion noch nicht ausgeführt werden kann, da sie vom Resultat einer anderen Instruktion abhängt. Z.B. eine Instruktion berechnet einen Wert und schreibt ihn in Register \$1. Benötigt die nächste Instruktion den Wert von \$1, so muss sie in der Pipeline warten, bis die erste Instruktion den Wert ins Register geschrieben hat. Mittels Forwarding kann dieses Problem umgangen werden. Dabei dient der berechnete Wert von der ALU direkt als Input für die ALU. Mittels Mux kann dann vor der ALU entschieden werden, welcher Wert übernommen wird.

Control Hazard: Tritt bei Instruktionen auf, die den Befehlszäher verändern (PC!=PC+4), z.B. bei Branching oder Jumps. Dabei sind bei nach einem Branch/Jump eventuell falsche Instruktionen in der Pipeline, die geflusht werden müssen. Deshalb ist es wichtig, die Zieladresse so früh wie möglich zu berechnen, damit nicht zu viele unnötige Instruktionen in der Pipeline geflusht werden.

- 1.7 Aufgabe 7
- 1.8 Aufgabe 8

2 Praktischer Teil

Listing 1: knightRider.s

```
/\star TODO: Task (b) Please fill in the following lines, then remove this line.
1
2
                Dominik Bodenmann
    * author(s):
3
          Orlando Signer
4
   * modified:
               2014-04-29
5
6
   */
7
8
   .include "nios_macros.s"
9
   .include "address_map.s"
10
11
  /******************************
12
   * TEXT SECTION
13
   */
14
   .text
15
16
  17
  * Entry point.
18
   */
19
  .global _start
20
  _start:
21
22
    /* set up sp and fp */
   movia sp, 0x007FFFFC
                             # stack starts from largest memory address
23
           fp, sp
    /\star This program exercises a few features of the DE1 basic computer.
26
27
     * It performs the following:
28
           1. displays a red light wandering from LEDR0 to LEDR9 and back again
29
          (and so on...)
           2. speed of light can be increased by KEY3, decreased by KEY1 and
30
         initial value can be restored by KEY2
31
32
     /* set up timer interval = 0x0000C350 steps * 1/(50 \text{ MHz}) = 1 millisecond*/
    movia r15, TIMER_COUNTER_LOW
    movui r16, 0xC350
35
           r16, 0(r15)
36
    sthio
37
    movia r15, TIMER_COUNTER_HIGH
38
    movui r16, 0x0000
39
    sthio r16, 0(r15)
40
41
    /* start interval timer, enable its interrupts */
42
    movia r15, TIMER_STOP_START_CONT_ITO
43
           r16, 0b0111
                       \# START = 1, CONT = 1, ITO = 1
44
    sthio r16, 0(r15)
```

```
/* enable pushbutton interrupts */
47
    movia r16, PUSHBUTTON_BASE
48
     movi r15, 0b01110  # set all 3 interrupt mask bits to 1 (bit 0 is Nios
49
     II Reset)
     stwio r15, 8(r16)
50
51
     /* enable processor interrupts */
52
    movi r16, 0b011 # enable interrupts for timer and pushbuttons
53
     wrctl ienable, r16
54
55
     movi
             r16, 1
     wrctl status, r16
    /\star r15 stores the memory address for the LEDs
     * r17 stores the active LED
59
      \star r18 the direction to move (0 -> downwards, 1 -> upwards)
60
      * r19 stores the delay-time
61
      * r20 and r21 are for temporary use
62
     */
63
64
     /* Initialize first red LED (light up) */
65
   movia r15, RED_LED_BASE
66
            r17, 0x1 # Bitmask for first LED
     movi
            r18, 0x0 # Direction bit (will be inverted first)
     movia r19, 0xC8 # Wait 0xC8 = 200 msecs
69
70
71
   CHECK_BORDER:
72
                        # Set value for lowest bit
    movi r20, 0x1
73
            r17, r20, INVERT_DIRECTION # If we are on the lowest bit, invert
74
     direciton
     movi r20, 0x200  # Set value for highest bit
beq r17, r20, INVERT_DIRECTION # If we are on the highest bit, invert
75
76
      direction
77
    CHECK_DIRECTION:
78
     movi r20, 0x1 beq r18, r20, MOVE_UP \# Check the direction we move, MOVE_UP if
79
80
     the move-bit is 1
    br MOVE_DOWN
                              # else MOVE_DOWN
81
82
    MOVE_UP:
83
           r17, 0(r15) # Write LED-Bitmask to memory r17, r17, 0x1 # left-shift the value by one
    stwio r17, 0(r15)
84
85
                            # Delay the next output
    br
            DELAY
86
87
   MOVE_DOWN:
88
                            # Write LED-Bitmask to memory
# right-shift the value by one
   stwio r17, 0(r15)
89
    srai r17, r17, 0x1 # right-shift the va
90
    br
91
92
93
    DELAY:
    movia r20, TIME
ldwio r21, 0(r20)
94
                                # Get the Time from the Counter
```

```
r20, r19, DELAY
                              # Check if we waited more than (r19) steps (
     go to DELAY else)
     stwio r0, 0(r20)
                              # Reset Time counter
97
    br CHECK_BORDER
                             # Go to check the borders (--> start again)
98
99
    INVERT_DIRECTION:
100
   xori r18, r18, 0x1
                            # Invert the direction
101
    br
           CHECK_DIRECTION
102
103
104
105
106
   /****************************
107
   * DATA SECTION
108
   */
109
110 .data
111
^{112} /* to count how much time has passed*/
113 .global TIME
114 TIME:
115
    .word 0
116
117 /* TODO: Task (c) you may also want to add things here (but you don't need to
    ) */
118 .end
```

Listing 2: pushbutton.s

```
_{1} /* TODO: Task (b) Please fill in the following lines, then remove this line.
   * author(s): Dominik Bodenmann
3
        Orlando Signer
4
   * modified: 2014-04-29
5
6
7
   */
  .include "nios_macros.s"
9
  .include "address_map.s"
10
11
12
  13
   * Pushbutton - Interrupt Service Routine
14
15
   **************************************
  .global PUSHBUTTON_ISR
17
18 PUSHBUTTON_ISR:
19
    /*
20
     * r19 stores the delay time
21
     * r20 stores the button pressed values
22
     \star r21 is for temporary use
23
     */
^{24}
25
    movia
          r21, PUSHBUTTON_BASE # Memory address for pushed buttons
27
    ldwio r20, 0xC(r21) # read register with values of buttons
    stwio r0, 0xC(r21)
                           # reset the pushed buttons
28
29
           r21, 0b100
    movia
30
           r20, r21, DEFAULT # Check if KEY2 is pressed
    beq
31
           r21, 0b1000
    movia
32
           r20, r21, FASTER
                            # Check if KEY3 is pressed
    beq
33
           r21, 0b10
    movia
34
35
    beq
           r20, r21, SLOWER # Check if KEY1 is pressed
36
    ret
37
38
    DEFAULT:
    movia r19, 0xC8
                         # Set the default delay
39
40
    ret
41
    FASTER:
42
          r19, r19, 0x32
                            # Subtract 0x32 (50) msecs to delay
    subi
43
    ret
44
45
    SLOWER:
46
    addi r19, r19, 0x32
                            # Add 0x32 (50) msecs to delay
47
48
    ret
49
50 .end
```