中南大学FYT战队电控组培训讲义

主讲人: 黄杰

学习要点

- 1. 简单了解寄存器的基本作用
- 2. 学会配置STM32标准库开发环境
- 3. 了解STM32不同编程开发环境的区别
- 4. 熟练掌握HAI库配置开发

学前准备

- 1. 芯片标准库包
- 2. Keil MDK
- 3. STM32CubeMX
- 4. 芯片对应参考手册

学习内容

一、操作寄存器方式点灯

看原理图,找到LED对应引脚GPIO,例如PF9

新建工程

打开KEIL、stm32f4xx中文参考手册,在Keil里新建project,文档中新建User 文件夹,新建main.c文件。

输入如下代码,作为框架:

```
int main(void)
{
    while(1)
    {
    }
}
```

打开时钟

打开stm32f4xx中文参考手册(53页),发现GPIOF 挂载在AHB1总线

1		
	BKPSRAM	0x4002 4000 - 0x4002 4FFF
	Flash 接口寄存器	0x4002 3C00 - 0x4002 3FFF
	RCC	0x4002 3800 - 0x4002 3BFF
AHB1	CRC	0x4002 3000 - 0x4002 33FF
ALIDI	GPIOI	0x4002 2000 - 0x4002 23FF
	GPIOH	0x4002 1C00 - 0x4002 1FFF
	GPIOG	0x4002 1800 - 0x4002 1BFF
	GPIOF	0x4002 1400 - 0x4002 17FF
	GPIOE	0x4002 1000 - 0x4002 13FF
	GPIOD	0x4002 0C00 - 0x4002 0FFF
	GPIOC	0x4002 0800 - 0x4002 0BFF
	GPIOB	0x4002 0400 - 0x4002 07FF
	GPIOA	0x4002 0000 - 0x4002 03FF

第 3.8 节: Flash 接口寄存器 第 171 页的第 6.3.32 节: RCC 第 85 页的第 4.4.4 节: CRC 寄

第 192 页的第 7.4.11 节: GPIO

打开至AHB1的寄存器地址表(查找【RCC AHB1ENR】):

6.3.12 RCC AHB1 外设时钟使能寄存器 (RCC_AHB1ENR)

RCC AHB1 peripheral clock enable register

偏移地址: 0x30

复位值: 0x0010 0000

访问: 无等待周期, 按字、半字和字节访问。



31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
Reser- ved	OTGHS ULPIEN	OTGHS EN	ETHMA CPTPE N	ETHINA	ETHMA CTXEN	ETHMA CEN	Reserved		DMA2EN	DMA1EN	CCMDATA RAMEN	Res.	BKPSR AMEN	l	erved
	rw	rw	rw	rw	rw	rw			rw	rw			rw		
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	Reserved		CRCEN Reserved		d	GPIOIE N	GPIOH EN	GPIOGE N	GPIOFE N	GPIOEEN	GPIOD EN	GPIOC EN	GPIOB EN	GPIOA EN	
			rw	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			rw	rw	rw	rw	rw	rw	rw	rw	rw

keil 中书写代码:

```
int main(void)
{
    RCC_AHB1ENR |= 1<<5;
    while(1)
    {
    }
}</pre>
```

设置GPIO

配置端口模式寄存器GPIOx MODER为输出模式, ctrl+f 寻找【GPIOx MODER】

7.4.1 GPIO 端口模式寄存器 (GPIOx_MODER) (x = A..I)

GPIO port mode register

偏移地址: 0x00

复位值:

- 0xA800 0000 (端口 A)
- 0x0000 0280 (端口 B)
- 0x0000 0000 (其它端口)

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
MOD	DER15[1:0] MODER14[1:0]		MODER	R13[1:0]	MODER12[1:0]		MODER11[1:0]		MODER10[1:0]		MODER9[1:0]		MODER8[1:0]		
rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
MOE	MODER7[1:0] MODER6[1:0]		MODE	R5[1:0]	MODE	R4[1:0]	MODE	R3[1:0]	MODE	R2[1:0]	MODE	R1[1:0]	MODE	R0[1:0]	
rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw

位 2y:2y+1 MODERy[1:0]: 端口 x 配置位 (Port x configuration bits) (y = 0..15)

这些位通过软件写入,用于配置 I/O 方向模式。

- 00: 输入(复位状态)
- 01: 通用输出模式
- 10: 复用功能模式
- 11: 模拟模式

由手册53页,可以看到GPIOF的基地址为0x40021400,在这里我们要使用的是PF9引脚,因此配置GPIOx_MODER时,它的偏移地址就相对于GPIOF的基地址而言。

在这里我们是需要将19和18位中的数据赋值为0和1,代表着将PF9选择为输出模式。同时为了不影响其他位的数值,先将19和18位这两位清零,然后或上01。

```
int main(void)
{
    RCC_AHB1ENR |= 1<<5;
    GPIOF_MODER &= ~(0x03<<2 * 9);
    GPIOF_MODER |= (0x01<<2 * 9);
    while(1)
    {
    }
}</pre>
```

接下来选择输出模式,找到GPIO端口输出类型寄存器(GPIOx OTYPER)。

7.4.2 GPIO 端口输出类型寄存器 (GPIOx_OTYPER) (x = A..I)

GPIO port output type register

偏移地址: 0x04

复位值: 0x0000 0000

GPIOF_OTYPER寄存器地址计算: GPIOF基地址+偏移地址

0x40021400+0x04

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	Reserved														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
OT15	OT14	OT13	OT12	OT11	OT10	OT9	OT8	OT7	OT6	OT5	OT4	OT3	OT2	OT1	OT0
rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw

将该位置0,为PF9引脚选择推挽输出

位 31:16 保留,必须保持复位值。

位 15:0 OTy[1:0]: 端口 x 配置位 (Port x configuration bits) (y = 0..15)

这些位通过软件写入,用于配置 I/O 端口的输出类型。

0: 输出推挽(复位状态)

1: 输出开漏

```
RCC_AHB1ENR |= 1<<5;

GPIOF_MODER &= ~(0x03<<2 * 9);

GPIOF_MODER |= (0x01<<2 * 9);

GPIOF_OTYPER &= ~(0x01<<9);</pre>
```

引脚PF9选择推挽输出。

接下来是GPIO端口输出速度寄存器, GPIO端口输出速度寄存器 (GPIOx_OSPEEDR) (x = A..I/)。其实这里端口输出速度对于我们点亮led灯没有什么实际用处,配不配置都行,不过在这里我们还是给它配置一个50MHz的输出速度。

```
int main(void)
{
    RCC_AHB1ENR |= 1<<5;
    GPIOF_MODER &= ~(0x03<<2 * 9);
    GPIOF_MODER |= (0x01<<2 * 9);
    GPIOF_OTYPER &= ~(0x01<<9);
    GPIOF_OSPEEDR &= ~(0x03<<2*9);
    GPIOF_OSPEEDR |= (0x02<<2*9);
    while(1)
    {}
}</pre>
```

配置上拉或下拉, GPIO 端口上拉/下拉寄存器 (GPIOx_PUPDR) (x = A..I/)。在这里我们选择配置为no pull/no down输出:

```
GPIOF_PUPDR \&= \sim (0x03 << 2*9);
GPIOF_PUPDR |= (0x00 << 2*9);
```

最后终于到我们的数据输出寄存器了,GPIO 端口输出数据寄存器 (GPIOx_ODR) (x = A..I),将该寄存器中的第九位数值赋0,即可让GPIO输出高电平,即LED亮(有些板子LED电路需要GPIO输出低电平)。

```
GPIOF_ODR \&= \sim (0x01 << 9);
```

最终代码:

```
int main(void)
{
    RCC_AHB1ENR |= 1<<5;

    GPIOF_MODER &= ~(0x03<<2 * 9);
    GPIOF_MODER |= (0x01<<2 * 9);

    GPIOF_OTYPER &= ~(0x01<<9);

    GPIOF_OSPEEDR &= ~(0x03<<2*9);
    GPIOF_OSPEEDR |= (0x02<<2*9);

    GPIOF_PUPDR &= ~(0x03<<2*9);
    GPIOF_PUPDR |= (0x00<<2*9);
</pre>
```

```
GPIOF_ODR &= ~(0x01<<9);
while(1)
{
}
</pre>
```

宏定义:

```
#define RCC_BASEADDR
                         0x40023800
#define RCC_AHB1ENR
                         *((volatile unsigned int *)
(RCC_BASEADDR+0x30))
#define GPIOF_BASEADDR
                         0x40021400
#define GPIOF_MODER
                         *((volatile unsigned int *)
(GPIOF_BASEADDR+0x00))
                         *((volatile unsigned int *)
#define GPIOF_OTYPER
(GPIOF_BASEADDR+0x04))
#define GPIOF_OSPEEDR
                         *((volatile unsigned int *)
(GPIOF_BASEADDR+0x08))
                         *((volatile unsigned int *)
#define GPIOF_PUPDR
(GPIOF_BASEADDR+0x0C))
#define GPIOF_ODR
                         *((volatile unsigned int *)
(GPIOF_BASEADDR+0x014))
```

代码编译后出现报错:

```
Build Output

Build started: Project: reg_demo

*** Using Compiler 'V6.18', folder: 'D:\KEIL\ARM\ARMCLANG\Bin'
Build target 'reg_demo'
linking...

.\Objects\reg_demo.sct(7): error: L6236E: No section matches selector - no section to be FIRST/LAST.

Not enough information to list image symbols.

Not enough information to list load addresses in the image map.
Finished: 2 information, 0 warning and 1 error messages.

".\Objects\reg_demo.axf" - 1 Error(s), 0 Warning(s).

Target not created.

Build Time Elapsed: 00:00:00
```

这下需要汇编代码。打开STM32F4xx_DSP_StdPeriph_Lib_V1.9.0 文件夹,打开路径: .\STM32F4xx_DSP_StdPeriph_Lib_V1.9.0\Libraries\CMSIS\Device\ST\STM32F4xx\Source\Templates\arm 在文件夹中找到启动汇编文件startup_stm32f40xx.s,

将其添加至project中,汇编文件会启动main函数与SystemInit函数。

```
Reset_Handler PROC

EXPORT Reset_Handler [WEAK]

IMPORT SystemInit

IMPORT __main

LDR R0, =SystemInit

BLX R0

LDR R0, =__main

BX R0

ENDP
```

顺便写个SystemInit 骗过编译器,最终代码如下:

```
#define RCC_BASEADDR
                          0x40023800
#define RCC_AHB1ENR
                          *((volatile unsigned int *)
(RCC_BASEADDR+0x30))
#define GPIOF_BASEADDR
                         0x40021400
#define GPIOF_MODER
                          *((volatile unsigned int *)
(GPIOF_BASEADDR+0x00))
#define GPIOF_OTYPER
                          *((volatile unsigned int *)
(GPIOF_BASEADDR+0x04))
                          *((volatile unsigned int *)
#define GPIOF_OSPEEDR
(GPIOF_BASEADDR+0x08))
#define GPIOF_PUPDR
                          *((volatile unsigned int *)
(GPIOF_BASEADDR+0x0C))
#define GPIOF_ODR
                          *((volatile unsigned int *)
(GPIOF_BASEADDR+0x014))
void SystemInit(void)
{
}
int main(void)
{
    RCC_AHB1ENR |= 1 << 5;
    GPIOF_MODER \&= \sim (0 \times 03 << 2 * 9);
```

```
GPIOF_MODER |= (0x01<<2 * 9);

GPIOF_OTYPER &= ~(0x01<<9);

GPIOF_OSPEEDR &= ~(0x03<<2*9);

GPIOF_OSPEEDR |= (0x02<<2*9);

GPIOF_PUPDR &= ~(0x03<<2*9);

GPIOF_PUPDR |= (0x00<<2*9);

GPIOF_ODR &= ~(0x01<<9);

while(1)
{
}
</pre>
```

编译成功。

没错,上面就是不依赖任何库,通过直接操作寄存器来实现的点亮第一个LED (话说翻看手册看得有点眼花,这是正常的,因为寄存器实在是太多了......)

而且有没有发现,上面的代码基本上是对一堆数字(地址)进行操作,一旦离开手册,你又如何记得那些数字代表什么呢?纵使记忆力惊人,这全部记下来也是不现实的,那么接下来我们将它包装一下,让它看起来人性化一点:那就有下面所讲的标准库/HAL库...........

二、标准库开发环境配置及点灯

STM32标准库开发环境配置

过程略 ------ 上课培训再讲,在下面放一个标准库目录树

```
|demo
|-Doc
|-Libraries
| |-CMSIS
| | |-Device
| | | LST
| | LSTM32F4xx
| | | |-Include
```

```
stm32f4xx.h
                        system_stm32f4xx.h
                 ∟Source
                     └─Templates
                           system_stm32f4xx.c
                         ∟arm
                                 startup_stm32f40xx.s
      └Include
             arm_common_tables.h
              core_sc300.h
   └─STM32F4xx_StdPeriph_Driver
       ⊢inc
             misc.h
             stm32f4xx_adc.h
             stm32f4xx_can.h
             stm32f4xx_tim.h
             stm32f4xx_usart.h
             stm32f4xx_wwdg.h
       ∟src
              misc.c
               stm32f4xx_adc.c
               stm32f4xx_can.c
               stm32f4xx_usart.c
               stm32f4xx_wwdg.c
|—Listings
├─Objects
      demo.hex
∟User
    ⊢inc
          stm32f4xx_conf.h
           stm32f4xx_it.h
    ∟src
```

```
main.c
stm32f4xx_it.c
```

使用标准库点灯

```
#include "stm32f4xx.h"
int main(void)
{
       //声明一个结构体变量
       GPIO_InitTypeDef GPIO_InitStructure;
       //使能GPIO外设时钟
        RCC_AHB1PeriphClockCmd(RCC_AHB1Periph_GPIOF, ENABLE);
           //定义一个结构体
       GPIO_InitStructure.GPIO_Pin=GPIO_Pin_9 | GPIO_Pin_10;//连接
LED的引脚
       GPIO_InitStructure.GPIO_Mode=GPIO_Mode_OUT;
                                                          //输出模
式
       GPIO_InitStructure.GPIO_Speed=GPIO_Speed_100MHz;
 //100MHz
       GPIO_InitStructure.GPIO_OType=GPIO_OType_PP;
                                                          //推挽
                                                          //上拉
       GPIO_InitStructure.GPIO_PuPd=GPIO_PuPd_UP;
       GPIO_Init(GPIOF,&GPIO_InitStructure);
   while(1)
    }
}
```

三、STM32CubeMX HAL库方式点灯

务必熟练掌握

CubeMX配置教程

过程略 ------ 上课培训再讲

