#### VISOIL User Manual

Last updated Jul 28, 2020

This article explains how to register a new account with VisOil, and use the interactive graph features


## Register New User

In order to log in, you must first create an account

- 1. Fill in your personal information, including email address and password
- 2. Click 'Register Account'


A

Please use the email given to you by your organization






A confirmation email will be sent to your email address. Click the link, and verify that a confirmation message is displayed




### **Choose Well Site**

To view a static graph of a completed well site, choose from the available drop-down


1. Select the drop down list



2. Select from available well sites



3. A graph of the drilling data will be displayed



# **Toggle Layers**

Turn graph values on and off


1. Click on the toggle buttons to turn graph values on and off



### Print to PDF

Print the static graph to pdf


1. First, click the 3 dots in the upper right corner of the graph



2. Select 'Print to PDF'




3. Customize print settings, and press Print



### Live Preview

#### Watch a live graph

1. First, expand the live graph component of the dashboard



2. Next, click the 'START' button to begin the preview



3. To stop the live preview, click 'STOP'



4. To clear the graph, click 'CLEAR'



A popup will display, indicating that the database has been cleared of the live preview data



X




The live preview is for demo purposes only! Stopping and Starting the preview without clearing the graph may result in unexpected behavior

# Logout

To end your session, log out of VISOIL

1. Click on the profile icon in the upper left corner



2. Click 'Logout'



3. Confirm that you want to end your session

