Volca Modular

Features

Cheat Sheet Version:1.0 (02/2021) by os68ng

| Function | |
|------------------|-----|
| Velocity (MIDI) | NO |
| Pitch Bend | NO |
| Paraphonic | NO |
| Patterns | 16 |
| Tempo Division | NO |
| Pattern Chain | YES |
| Step Jump | NO |
| Motion Recording | YES |
| Auto Tune | ? |

Global Parameters (FUNC+PwrOn)

| Key | Function | LED |
|-----|-------------------------------|--------|
| 1 | Auto Power Off | On |
| 2 | Battery Type (NiMH/Alkaline) | NiMH |
| 3 | Sync Out Polarity (Fall/Rise) | Fall |
| 4 | Sync In Polarity (Fall/Rise) | Fall |
| 5 | Tempo Range | Full |
| 6* | MIDI Clock Src (Auto/Int) | Auto |
| 7* | MIDI RX Short Message | On |
| 8 | Sync Unit | 1 Step |

(REC: Save, Play: Cancel)

FUNC

| Category | Function | Description | |
|-----------|-------------|----------------------------|--|
| | Scale | Scale | |
| | Tonic | Root note | |
| Microtun. | Edit | Press note + Microtune | |
| | Clear | Clear all microtunings | |
| Octave | Up | Transpose one oct. up | |
| | Down | Transpose one oct. down | |
| Randomize | Note | Randomize notes in seq. | |
| | Act. Step | Randomize active steps | |
| | Microtuning | Randomize microtuning | |
| Gate | Long | Long gate | |
| Mode | Bounce | Sequence runs back & forth | |
| | Stoch. | Stochastic mode (-1/+2) | |
| Motion | On/Off | Enables motion recording | |
| | Clear | Clears motion recording | |
| Clear | Act. Stp | Reset active steps / Undo | |
| | All | Clear sequence | |

MIDI Channel:

(MEMORY+Power On: Set MIDI chan)

MIDI Controller

| СС | Function | Rec | Ctrl |
|----|----------|-----|------|
| 40 | Ratio | ~ | |
| 41 | Fold | ~ | |
| 42 | Mod | ~ | |
| 43 | Attack | ~ | |
| 44 | Release | ~ | |
| 45 | Shape | ~ | |
| 46 | Time | ~ | |
| 47 | Cutoff 1 | ~ | |
| 48 | Cutoff 2 | ~ | |
| 49 | Reverb | ~ | |
| 50 | Func (C) | • | |

^{*)} Only with MIDI In modification

