# Volca Sample

## **Features**

Cheat Sheet Version:1.0 (02/2021) by os68ng

Function Velocity (MIDI) YES Pitch Bend NO Polyphony 8 10 Tempo Division NO Pattern Chain Songs Step Jump YES Motion Recording YES

#### Global Parameters (FUNC+PwrOn)

Key	Function	LED
1	Auto Power Off	On
2	Battery Type (NiMH/Alkaline)	NiMH
3	Sync Out Polarity (Fall/Rise)	Fall
4	Sync In Polarity (Fall/Rise)	Fall
5	Tempo Range	Full
6	MIDI Clock Src (Auto/Int)	Auto
7	MIDI RX Short Message	On
8	Sync Unit	1 Step
9*	Original MIDI (chan 1-10)	On
10*	Sequencer MIDI (chan 11)	On

(REC: Save, Play: Cancel)

#### **FUNC**

Category	Function	Description	
Part	1-10	Select without trigger/sound	
Loop	On/Off	Loop sample	
	On/Off	Motion on/off	
Motion Seq	Clr. All	Clear all motion recording	
	Act. Step	Reset active steps / undo	
Clear	Part	Clear active part	
	All	Clear sequence	
Pajen*	Sample	Extended menu	

#### Pajen Extended Menu

Category	Function	Description
	Off	None
	Sel	Original behavior
Omni	Samp	Sample 1-100 mapping
	PAtr	Pattern trigger (C to A)
	Py2-4	Polyphonic mode
	PROB	Probability (0-100%)
	BrFL	Bar filter
	ntFL	Note filter (t n v)
	CPrt	Copy part
	Rb.ty	Reverb type (0-2)
	dron	Drone mode

\*) Pajen only

# **MIDI Channel:**

(MEMORY+Power On: Set MIDI chan)

## MIDI Controller (split)

СС	Function	Rec	Ctrl
7	Volume	~	
10	Pan	V	
40	Start Point	V	
41	Length	~	
42	Hi Cut	~	
43	Speed	~	
44	EG Pitch Int	~	
45	EG Pitch Attack	~	
46	EG Pitch Decay	~	
47	EG Amp Attack	~	
48	EG Amp Decay	~	
50*	Sample Select		
51*	Reverb Level		
52*	Reverb Type		
54*	Part Select		
55*	Loop		
56*	Reverse Part		
57*	Reverb On/Off		
58*	Mute Part		
59*	Solo Part		

