# Volca FM

#### Features

Cheat Sheet Version:1.0 (02/2021) by os68ng

Function	
Velocity (MIDI)	YES*
Pitch Bend	YES
Polyphony	3
Patterns	16
Tempo Division	YES
Pattern Chain	YES
Step Jump	NO
Motion Recording	YES

### Global Parameters (FUNC+PwrOn)

Key	Function	LED
1	Auto Power Off	On
2	Battery Type (NiMH/Alkaline)	NiMH
3	Sync Out Polarity (Fall/Rise)	Fall
4	Sync In Polarity (Fall/Rise)	Fall
5	Tempo Range	Full
6	MIDI Clock Src (Auto/Int)	Auto
7	MIDI RX Short Message	On
8	Sync Unit	1 Step
9*	MIDI Velocity	On
10*	Yamaha Patch Compatibility	On
11*	Patch Change Notes On/Off	On

(REC: Save, Play: Cancel)

\*) Only with Pajen

#### **FUNC**

Category	Function	Description	
	Poly	Polyphony mode (3 notes)	
Voice Mode	Mono	Mono mode with one OSC	
	Unison	Unisono mode with 3 OSC	
	Chorus	Enable chorus	
	Arp On/Off	Enable arpeggiator	
Tempo	1/1	Normal	
	1/2	Half speed	
	1/4	1/4 speed	
	Metronome	Activate metronome	
	Warp Act.Step	Fill deactivated steps silently	
	Transps Note	Transpose slider semitones	
	On/Off	Motion on/off	
Motion Sequence	Smooth	Smooth value changes	
	Clear	Clear all motion recording	
Clear	Act. Stp	Reset active steps / undo	
	All	Clear sequence	
REC	Erase	Clear at position during PLAY	

## MIDI Channel:

(MEMORY+Power On: Set MIDI chan)

#### MIDI Controller

СС	Function	Rec	Ctrl
40	Transpose	~	
41	Velocity	~	
42	Modulator Attack	~	
43	Modulator Decay	~	
44	Carrier Attack	~	
45	Carrier Decay	~	
46	LFO Rate	~	
47	LFO Pitch Depth	~	
48	Algorithm		
49	Arp Type		
50	Arp Div		
49	EG Attack	~	
85*	Chorus		
86*	Chorus Stereo Wth		
87*	Chorus Speed		
88*	Load Patch		
89*	Load Pattern		
90*	Tempo Divisor		
91*	Mod Wheel Map		

