AOn Page 1

AOn Switch on power to the SCC and the -5 volt supply

#include < <u>Power.h</u>> <u>Power Manager</u>

void **AOn**(void);

returns none

The **AOn** procedure always switches on power to the SCC and the -5 volt supply. If the internal modem is installed and is connected to port A, this procedure also switches on power to the modem. If either of these conditions is not met, the **AOn** procedure switches on power to the serial driver chips.