**SwapDataCache** Enable or disable the data cache

#include < Memory.h> Memory Manager

Boolean SwapDataCache(cacheEnable);

<u>Boolean</u> cacheEnable; the desired state of the data cache

**returns** the previous state of the data cache

The **SwapDataCache** function enables or disables the data cache, depending on whether the *cacheEnable* parameter is set to <u>TRUE</u> or <u>FALSE</u>. **SwapDataCache** returns the previous state of the data cache.

Notes: Be sure to check that the trap \_HWPriv is implemented before calling this routine. See <u>Using the Gestalt Manager</u> for sample code that shows how to determine whether a trap is implemented. If you call this routine and \_HWPriv is not implemented, you application will crash.

The MC68030 and MC68040 microprocessors have data caches.