**AOnIgnoreModem** Switch on power to SCC, -5 volt supply and serial driver chips

#include < <u>Power.h</u>> <u>Power Manager</u>

void AOnIgnoreModem(void);

**returns** none

The **AOnIgnoreModem** procedure switches on power to the SCC, the -5 volt supply, and the serial driver chips. This procedure does not switch on power to the internal modem, even if the user has used the Portable control panel to select the modem.