


## AirMedia User Instructions

1. Open your web browser and enter the IP address found in the bottom left corner of the screen





- 2. Download the Client for Windows AirMedia software.
- 3. Run the application. Enter the login code displayed below the IP address