
FST Hearing Room




Tap anywhere on the screen to start system

Welcome to the Hearing Room.

How would you like to use the room?



Presentation



Audio Conferencing



3:02 PM February 9, 2021





Manually power the display On/Off



Shutdown system

Select either Presentation or Audio Conference mode



Room Volume adjusts the overall volume of the system

Mute will mute the in-room speakers

Privacy will mute the in-room mics





Presentation

This page allows the user to select which source to display on each screen.



Use AirMedia to wirelessly share content from device



HDMI Input at Registrars desk



In-room PC controlling the camera and mics



Send currently active camera to screen



Stop sharing and turn off display



3:02 PM

February 9, 2021





PRESENTATION

Send content to a display. Audio follows last selection.

West Display:









East Display:


None

000











Room Volume



Televic System

To use the cameras and mics in an online meeting, connect to the USB port at the registrar's desk.

Microphones

The microphone are activated by voice detection and will tuen on when you begin speaking.

When the leds are green the mic is active.

Cameras

The camera system is completely automated.

When you activate a mic, the camera will focus on that seating position.



Audio Conference

This page allows the user to make phone calls using the inroom AV equipment.

Audio Conference Volume will adjust the in-call volume.



Use the Mute button to mute the call and Privacy to mute the microphones.






3:02 PM

February 9, 2021







Shutdown

When the power icon is selected, the system begins to shutdown. This will turn off displays, mute microphones and put cameras in privacy mode.

Shutdown Now

Shutdown now will immediately shutdown the system.

Return

Return will abort shutdown.

