Pioneer
Car Service Center

USER MANUAL

Technician

Your job cards on your phone: start, pause and stop the time, request parts and mark the job done.

Step 6 · Customer decision & work

Your role at a glance

You work from your phone. The job cards your Team Leader assigns to you appear on your home screen. You **book your time** with Start / Pause / Stop, **request parts** from the Store, and press **Job done** when the work is finished — the job card then goes to the quality check.

Where you fit in the job card workflow

1	2	3	4	5	6	7
Customer classification	**Vehicle information & issue**	**Job card opened**	**Inspection & pricing**	**Estimate to customer**	**Customer decision & work**	**Quality check, pickup & closure**
Service Advisor	Service Advisor	System · Service Advisor	Service Advisor · Technician	Store · Supervisor · Service Advisor	Customer · Team Leader · Technician · Store	Supervisor · Service Advisor

What the system lets you do

Step 6 Book time (Start / Pause / Stop) and mark jobs done

Step 6 Raise material requisitions (request parts)

In this manual

1 Signing in

2 Your job cards


3 Book your time

4 Request parts

5 Job done

1. Signing in

1. Open the workshop system in your browser (Chrome, Edge or Safari).
2. Type your **username or e-mail** and your **password**, then press **Sign In**.
3. The system opens your dashboard. Your role — **Technician** — is shown at the top right.




The sign-in page on a phone.


TIP Use the **EN** button at the top of any page to switch language (Arabic and 10 others). Your choice is remembered on this device.

NOTE Your account is created by the Workshop Manager. Forgot your password? Use **FORGOT PASSWORD?** on the sign-in page or ask the manager to reset it.

2. Your job cards



Your job cards on the home screen.




A job card: the complaint, the approved work and (1) Start.


Each card shows the vehicle, the customer's complaint and the **approved work**. Only job cards assigned to you are shown.

3. Book your time STEP 6

1. Press **Start** when you begin working on the job card. The clock runs.
2. Press **Pause** for a break or while you wait for parts; press **Resume** to carry on.
3. Press **Stop** when you leave the job for now (end of shift, moved to another car).



Time running — (1) Pause, (2) Stop, (3) Job done, (4) Request parts.




Paused — Resume to carry on.


NOTE The time on each job card is what the workshop uses for your hours and for the job's labour, so start and stop it as you actually work.

4. Request parts STEP 6

1. Press **Request parts** on the job card.
2. Describe each part and the quantity (**Add another part** for more).
3. Press **Send to the Store**. The Store is notified.




Requesting parts.




Parts status: issued, waiting, or not on the shelf with the expected date.

5. Job done STEP 6

1. When the work is finished press **Job done** and confirm.
2. Any running time stops and the job card goes to the Supervisor for the **quality check**.



Confirm Job done.



Waiting for the quality check.

THE SYSTEM CHECKS Job done is refused if no time was booked. After Job done you cannot book more time unless the quality check fails.

Rework: if the quality check fails, the job card comes back marked **Rework needed** with the inspector's comment. Start the time again, fix it, and press Job done.