ORIGINAL NAME

LINE –0184BBR1T115

AREA: Barreirinhas

CLIENT: Exploration Services/TGS Nopec

NEW NAME

LINE: 0258-5184

AREA: 0258-2D_SPEC_BM_BAR

CLIENT: TGS-Nopec.

ACQUISITION REPORT Sequence-0115

Survey:

Client	Exploration Services
Area	Para-Maranhao
Vessel	GECO_TAU
JobNumber	7443B
Survey Type	2D

Sequence:

Linename	0184BBR1T115
Preplot	0184BBR
Direction	276.0°
SOL Date	17:42:45utc 02-Mar-2001
EOL Date	16:54:24utc 03-Mar-2001

Attributes:

Wind Force	4.0	[knots]	Dir SE
Swell Height	1.5	[meters]	Dir SE
Propellor rpm		[avg]	
Propellor pitch	30	[avg]	

	SOL	EOL	
Waterdepth	393.0	2946.5	[meters]
Bottomspeed	5.5	5.73	[knots]
Featherangle	port -2.5	port -0.6	[deg]
Cable noise	13.4	4.0	[µBar rms]
Lowcut filter	3	3	[hz]
Filter slope	18	18	[dB]
Streamer Depth	10.5	10.5	

Production

	Shotpoint	File	Time [utc]
SOL Noise Record(s)			
SOL Dummy Record(s)			
FSP Start of Line	1617		17:42:45
MSP	3368	3368	23:59:58
LSP End of Line	8064	8064	16:54:24
EOL Dummy Record(s)	8065 - 8074	8065 - 8074	16:54:37 - 16:56:34
EOL Noise Record(s)			

Line-segments:

SPs	Files	Times [utc]	Type	# CMPs	Status	Remarks
1617 - 8064	- 8064	-16:54:24	Prime	1	Valid	

Remarks:

Navigation	
Recording QC	Cable bent at SOL noise test.

Tape-list

Stream 2

Shot(s)	Files	Deck	Reel	Remark
1605 - 3485	1605 - 3485	2	201	
3486 - 5373	3486 - 5373	1	202	
5374 - 7246	5374 - 7246	2	203	
7247 - 8076	7247 - 8076	1	204	

Stream 4

Shot(s)	Files	Deck	Reel	Remark
1605 - 1692	1605 - 1692	3	1205	
1693 - 3563	1693 - 3563	4	1206	
3564 - 5441	3564 - 5441	4	1207	
5442 - 7305	5442 - 7305	3	1208	
7306 - 8076	7306 - 8076	3	1209	

Seismic Data Annotations

NTBP

Shot(s)	File(s)	Trace(s)	Type	Remark
1617-EOL	EOL	2	Killed traces	
1617-EOL	EOL	70	Bad trace	Intermittent spikey trace
1694		ALL	Missing File	File not recorded by recording system
2116		ALL	Missing File	File not recorded by recording system
2242	2242	ALL	Gun timing error	Gun 3-1 error (ms) : 2.20
2773		ALL	Missing File	File not recorded by recording system
2791		ALL	Missing File	File not recorded by recording system
2932		ALL	Missing File	File not recorded by recording system
3050		ALL	Missing File	File not recorded by recording system
3204		ALL	Missing File	File not recorded by recording system
3300		ALL	Missing File	File not recorded by recording system
3308		ALL	Missing File	File not recorded by recording system
3403		ALL	Missing File	File not recorded by recording system
3477		ALL	Missing File	File not recorded by recording system
3549		ALL	Missing File	File not recorded by recording system
3605		ALL	Missing File	File not recorded by recording system
3814		ALL	Missing File	File not recorded by recording system
3993		ALL	Missing File	File not recorded by recording system
4039	4039	ALL	Autofire	Early fire of the next shot
4040		ALL	Missing File	File not recorded by recording system
4054		ALL	Missing File	File not recorded by recording system
4118		ALL	Missing File	File not recorded by recording system
4155		ALL	Missing File	File not recorded by recording system
4222	4222	ALL	Autofire	Early fire of the next shot
4223		ALL	Missing File	File not recorded by recording system
4226		ALL	Missing File	File not recorded by recording system
4432	4432	ALL	Gun timing error	Misfire Gun 6-2
4526	4526	ALL	Gun not fired	Misfire sub array 5
4527	4527	ALL	Gun not fired	Misfire sub-array 5
4528	4528	ALL	Gun timing error	Misfire Gun 6-1
4529	4529	ALL	Gun timing error	Misfire Gun 6-2
4530	4530	ALL	Gun timing error	Misfire Gun 6-2
4531	4531	ALL	Gun timing error	Misfire Gun 6-2

4537	4537	ALL	Gun misfire	Sub arrary 5
4888		ALL	Missing File	File not recorded by recording system
4954	4954	ALL	Gun not fired	Gun-status lost for gun 5-4
4955	4955	ALL	Gun not fired	Gun-status lost for gun 5-4
4957	4957	ALL	Gun timing error	Misfire Gun 6-2
4959	4959	ALL	Gun timing error	Misfire sub-array 5
4977	4977	ALL	Guns not fired	no guns fired
4985	4985	ALL	Gun not fired	Gun-status lost for gun 5-6
4986	4986	ALL	Gun not fired	Gun-status lost for gun 5-6
4987	4987	ALL	Gun not fired	Gun-status lost for gun 5-6
4991-4992	4991-4992	ALL	Gun disabled	misfire d.t. gun volume
4994	4994	ALL	Gun timing error	Misfire Gun 6-2
4995	4995	ALL	Gun timing error	Misfire Gun 6-2
5004		ALL	Missing File	File not recorded by recording system
5005	5005	ALL	Gun timing error	Misfire sub-array 5
5096	5096	ALL	Gun timing error	Misfire Gun 6-2
5098		ALL	Missing File	File not recorded by recording system
5099	5099	ALL	Gun timing error	Misfire sub-array 5
5216	5216	ALL	Gun not fired	Gun-status lost for gun 5-6
5219	5219	ALL	Gun timing error	Gun 6-2 error (ms) : -2.40
5221		ALL	Missing File	File not recorded by recording system
5222	5222	ALL	Gun timing errors	Misfires on array 5
5240		ALL	Missing File	File not recorded by recording system
5265		ALL	Missing File	File not recorded by recording system
5269		ALL	Missing File	File not recorded by recording system
5285		ALL	Missing File	File not recorded by recording system
5291		ALL	Missing File	File not recorded by recording system
5343		ALL	Missing File	File not recorded by recording system
5796	5796	ALL	Gun not fired	Gun-status lost for guns 5-4 and 5-6
5797	5797	ALL	Gun not fired	Gun-status lost for all guns in array 5
5799	5799	ALL	Gun timing error	Gun 6-2 error (ms) : -3.00
5800	5800	ALL	Gun timing error	Gun 6-2 error (ms) : -2.30
5803	5803	ALL	Gun misfires	Misfires on all guns in Array 5.
5804-5805	5804-5805	ALL	Gun misfires	Misfires on all guns in Array 5.
5810		ALL	Missing File	File not recorded by recording system
5811	5811	ALL	Guns disabled	No guns fired
5812	5812	ALL	Gun timing errors	Misfires on many guns in array 5.
5897	5897	ALL	Gun not fired	Gun-status lost for gun 5-4
5900	5900	ALL	Gun timing error	Gun 6-2 error (ms) : -2.40
5901	5901	ALL	Gun timing error	Gun 6-2 error (ms) : -2.20
5902	5902	ALL	Gun timing error	Gun 6-2 error (ms) : -2.30
5905	5905	ALL	Gun timing errors	Many misfires on array 5.
6326		ALL	Missing File	File not recorded by recording system
6339		ALL	Missing File	File not recorded by recording system

6344		ALL	Missing File	File not recorded by recording system
6446	6446	ALL	Gun not fired	Gun-status lost for gun 5-6
6447	6447	ALL	Gun timing error	Gun 1-1 error (ms) : 2.10
6448	6448	ALL	Gun timing error	Gun 6-2 error (ms) : -2.60
6453	6453	ALL	Gun timing errors	Many misfires on array 5
6509	6509	ALL	Gun not fired	Gun-status lost for gun 5-4
6510	6510	ALL	Gun not fired	Gun-status lost for gun 5-1
6513	6513	ALL	Gun timing error	Gun 6-2 error (ms) : -2.30
6520	6520	ALL	Gun timing error	Many misfires on array 5.
6573	6573	ALL	Gun not fired	Gun-status lost for gun 5-4 and 5-6.
6576	6576	ALL	Gun timing error	Gun 6-2 error (ms) : -2.10
6577	6577	ALL	Gun timing error	Gun 6-2 error (ms) : -2.20
6579	6579	ALL	Gun timing error	Gun 6-2 error (ms) : -2.10
6586	6586	ALL	Gun timing errors	Many misfires on Array 5.
6705	6705	ALL	Guns not fired	Gun-status lost for gun 5-4 and 5-6
6706	6706	ALL	Guns enabled/disabled	Array 5 disabled, spares not enabled; volume 6418 cu in.
6708	6708	ALL	Gun timing error	Gun 6-2 error (ms) : -2.20
6709	6709	ALL	Gun timing error	Gun 6-2 error (ms) : -2.50
6711	6711	ALL	Gun timing error	Many misfires array 5
6711	6711	ALL	Gun timing error	Gun 6-2 error (ms) : -2.30
6743	6743	ALL	Guns not fired	Gun-status lost for guns 5-4 and 5-6
6746	6746	ALL	Gun timing error	Gun 6-2 error (ms) : -2.80
6747	6747	ALL	Gun timing error	Gun 6-2 error (ms) : -2.30
6748	6748	ALL	Gun timing error	Gun 6-2 error (ms) : -2.20
6750	6750	ALL	Gun timing errors	Many misfires on array 5
6762		ALL	Missing File	File not recorded by recording system
6888	6888	ALL	Gun not fired	Gun-status lost for gun 5-4
6889	6889	ALL	Gun not fired	Gun-status lost for gun 5-4
6891	6891	ALL	Gun timing error	Gun 6-2 error (ms) : -2.20
6892	6892	ALL	Gun timing error	Gun 6-2 error (ms) : -2.10
6895	6895	ALL	Gun timing errors	Many misfires on array 5.
7480	7480	ALL	Gun not fired	Gun-status lost for gun 5-4
7483	7483	ALL	Gun timing error	Misfire Gun 6-2
7484	7484	ALL	Gun timing error	Misfire Gun 6-2
7485	7485	ALL	Gun timing error	Misfire Gun 6-2
7490	7490	ALL	Gun timing error	Misfire sub-array 5
7493	7493	ALL	Gun timing error	Misfire Gun 6-2
7507	7507	ALL	Gun timing error	Misfire Gun 3-1
7699	7699	ALL	Gun timing error	Gun 5-1 error (ms) : -2.20
7707	7707	ALL	Gun timing error	Gun 5-1 error (ms) : 2.30
7708	7708	ALL	Gun timing error	Gun 5-1 error (ms) : 2.10
7718	7718	ALL	Gun timing error	Gun 5-1 error (ms) : -2.10
7779	7779	ALL	Gun not fired	Gun-status lost for gun 5-4
7780	7780	ALL	Gun not fired	Gun-status lost for gun 5-4
7782	7782	ALL	Gun timing error	Gun 6-2 error (ms) : -2.20
7785	7785	ALL	Gun timing error	Gun 6-2 error (ms) : -2.20
7786	7786	ALL	Gun timing error	Several guns array # 5
7813		ALL	Missing File	File not recorded by recording system
7883	7883	ALL	Gun autofire	Gun 6-4 at 93 ms after aimpoint

Warning

Shot(s)	File(s)	Trace(s)	Type	Remark
1617-EOL	EOL	136, 197	Killed traces	Traces 6 dB down

1617		ALL	Swell Noise	Swell noise affecting 3% of traces, rms average 9uBars, peaks 50uBars
1734	1734	ALL	Gun timing error	Gun 3-1 error (ms) : 2.00
1780	1780	ALL	Gun timing error	Gun 3-1 error (ms) : 1.70
1882	1882	220-260	Ship noise	From abeam, Noise level 6 ubar, moveout 50ms/km
1916	1916	ALL	Ship noise	no longer appearent
1954	1954	ALL	Gun timing error	Gun 3-1 error (ms) : 1.60
1960	1960	ALL	Gun timing error	Gun 5-1 error (ms) : -1.70
2098	2098	ALL	Gun timing error	Gun 3-1 error (ms) : 1.60
2196	2196	ALL	Gun timing error	Gun 5-1 error (ms) : 1.70
2241	2241	ALL	Gun timing error	Gun 3-1 error (ms) : 1.60
2277	2277	200-320	Ship noise	From astern, Noise level 8 ubar, moveout 100 ms/km
2317	2317	160-320	Ship noise	From astern, Noise level 8 ubar, moveout 100 ms/km
2337	2337	ALL	Gun timing error	Gun 3-1 error (ms) : 1.60
2347	2347	ALL	Gun timing error	Gun 2-2 error (ms) : -1.60
2352	2352	ALL	Ship noise	From astern, Noise level 8 ubar, moveout 200 ms/km
2362	2362	ALL	Gun timing error	Gun 3-1 error (ms) : 1.70
2365	2365	ALL	Gun timing error	Gun 5-1 error (ms) : 1.80
2401	2401	ALL	Ship noise	From astern, Noise level 10-12 ubar, moveout 200 ms/km
2407	2407	ALL	Seismic data parity errors	Above 0.000% of total samples (3 parity errors)
2421	2421	ALL	Gun timing error	Gun 2-2 error (ms) : 1.80
2500	2500	ALL	Ship noise	no longer appearent
2519	2519	ALL	Gun timing error	Gun 3-1 error (ms) : 1.80
2571	2571	ALL	Gun timing error	Gun 5-1 error (ms) : -1.90
2696	2696	ALL	Gun timing error	Gun 5-1 error (ms) : 1.80
2732	2732	ALL	Gun timing error	Gun 5-1 error (ms) : 1.60
2759	2759	ALL	Gun timing error	Gun 3-1 error (ms) : 1.60
2788	2788	ALL	Gun timing error	Gun 3-1 error (ms) : 1.60
2799	2799	ALL	Gun timing error	Gun 3-1 error (ms) : 1.60
2834	2834	ALL	Gun timing error	Gun 5-1 error (ms) : 1.80
2872	2872	ALL	Gun timing error	Gun 5-1 error (ms) : -1.60
2903	2903	ALL	Gun timing error	Gun 1-2 error (ms) : -1.60
2910	2910	ALL	Gun timing error	Gun 5-1 error (ms) : -1.60
2979	2979	ALL	Gun timing error	Gun 5-1 error (ms) : -1.80
3083	3083	ALL	Gun timing error	Gun 3-1 error (ms) : 1.80
3133	3133	ALL	Gun timing error	Gun 5-1 error (ms) : 1.60
3482	3482	ALL	Gun timing error	Gun 3-1 error (ms) : -1.90
3665	3665	ALL	Gun timing error	Gun 3-1 error (ms) : -1.60
3827	3827	ALL	Gun timing error	Gun 5-1 error (ms) : -1.80
4207	4207	ALL	Gun timing error	Gun 5-1 error (ms) : 1.60
4307	4307	ALL	Gun timing error	Gun 3-1 error (ms) : 1.60
4538	4538	ALL	Gun timing error	Gun 5-2 error (ms) : 1.60
4538	4538	ALL	Gun timing error	Gun 6-2 error (ms) : 1.60
4540	4540	ALL	Gun timing error	Gun 6-2 error (ms) : 1.60
4868	4868	ALL	Gun timing error	Gun 3-1 error (ms) : 1.80
4957	4957	ALL	Gun timing error	Gun 1-2 error (ms) : -1.80
4958	4958	ALL	Gun timing error	Gun 6-2 error (ms) : -1.90
4959	4959	ALL	Gun timing error	Gun 6-2 error (ms) : -2.00
4996	4996	ALL	Gun timing error	Gun 6-2 error (ms) : -1.60
5100	5100	ALL	Gun timing error	Gun 6-2 error (ms) : -1.60
5219	5219	ALL	Gun timing error	Gun 1-2 error (ms) : -1.60
5646	5646	ALL	Gun timing error	Gun 5-1 error (ms) : -1.60
5798	5798	ALL	Gun timing error	Gun 6-1 error (ms) : 1.80

5799	5799	ALL	Gun timing error	Gun 1-2 error (ms) : -1.60
5801	5801	ALL	Gun timing error	Gun 6-2 error (ms) : -2.00
5803-5805	5803-5805	ALL	Guns enabled/disabled	Array 5 enabled, spares disabled, volume 7918 cu in.
5814	5814	ALL	Gun timing error	Gun 6-2 error (ms) : 1.60
5910	5910	ALL	Gun timing error	Gun 6-2 error (ms) : 1.60
6113	6113	ALL	Gun timing error	Gun 5-1 error (ms) : 1.60
6443	6443	ALL	Gun timing error	Gun 3-6 error (ms) : -1.80
6448	6448	ALL	Gun timing error	Gun 1-2 error (ms) : -1.70
6449	6449	ALL	Gun timing error	Gun 6-2 error (ms) : -1.70
6452	6452	ALL	Manifold pressure low	Subarray 2 below 1800 psi
6512	6512	ALL	Gun timing error	Gun 1-2 error (ms) : -1.70
6512	6512	ALL	Gun timing error	Gun 6-2 error (ms) : -2.00
6514	6514	ALL	Gun timing error	Gun 6-2 error (ms) : -1.60
6518	6518	ALL	Manifold pressure low	Subarray 1 below 1800 psi
6518	6518	ALL	Manifold pressure low	Subarray 2 below 1800 psi
6518	6518	ALL	Manifold pressure low	Subarray 3 below 1800 psi
6518	6518	ALL	Manifold pressure low	Subarray 4 below 1800 psi
6518	6518	ALL	Manifold pressure low	Subarray 6 below 1800 psi
6521	6521	ALL	Gun timing error	Gun 6-2 error (ms) : 1.60
6523	6523	ALL	Gun timing error	Gun 6-2 error (ms) : 1.60
6578	6578	ALL	Gun timing error	Gun 6-2 error (ms) : -1.90
6588	6588	ALL	Gun timing error	Gun 6-2 error (ms) : 1.60
6589	6589	ALL	Gun timing error	Gun 6-2 error (ms) : 1.70
6623	6623	ALL	Gun timing error	Gun 4-1 error (ms) : 1.60
6698	6698	ALL	Gun timing error	Gun 5-1 error (ms) : -1.90
6710	6710	ALL	Gun timing error	Gun 6-2 error (ms) : -1.80
6847	6847	ALL	Gun timing error	Gun 5-1 error (ms) : 1.60
6891	6891	ALL	Gun timing error	Gun 1-2 error (ms) : -2.00
6893	6893	ALL	Gun timing error	Gun 1-2 error (ms) : -1.90
6893	6893	ALL	Gun timing error	Gun 6-2 error (ms) : -2.00
6895	6895	ALL	Gun timing error	Gun 6-2 error (ms) : -1.70
6923	6923	ALL	Gun timing error	Gun 3-1 error (ms) : 1.60
6936	6936	ALL	Gun timing error	Gun 5-1 error (ms) : 1.60
7158	7158	ALL	Gun timing error	Gun 1-2 error (ms) : -1.90
7287	7287	ALL	Gun timing error	Gun 5-1 error (ms) : 1.80
7483	7483	ALL	Gun timing error	Gun 1-2 error (ms) : -2.00
7491	7491	ALL	Gun timing error	Gun 6-2 error (ms) : 2.00
7492	7492	ALL	Gun timing error	Gun 6-2 error (ms) : 1.70
7493	7493	ALL	Gun timing error	Gun 1-2 error (ms) : 1.70
7535	7535	ALL	Gun timing error	Gun 5-1 error (ms) : -2.00
7536	7536	ALL	Gun timing error	Gun 5-1 error (ms) : -1.70
7561	7561	ALL	Gun timing error	Gun 5-1 error (ms) : -1.60
7563	7563	ALL	Gun timing error	Gun 5-1 error (ms) : 1.90
7567	7567	ALL	Gun timing error	Gun 5-1 error (ms) : 1.70
7570	7570	ALL	Gun timing error	Gun 1-2 error (ms) : -1.60
7680	7680	ALL	Gun timing error	Gun 5-1 error (ms) : -1.60
7697	7697	ALL	Gun timing error	Gun 5-1 error (ms) : -1.70
7700	7700	ALL	Gun timing error	Gun 5-1 error (ms) : -1.80
7709	7709	ALL	Gun timing error	Gun 5-1 error (ms) : 1.90
7716	7716	ALL	Gun timing error	Gun 1-2 error (ms) : -1.90
7782	7782	ALL	Gun timing error	Gun 1-2 error (ms) : -2.00
7783	7783	ALL	Gun timing error	Gun 6-2 error (ms) : -2.00
7784	7784	ALL	Gun timing error	Gun 6-2 error (ms) : -1.60
7785	7785	ALL	Manifold pressure low	Subarray 5 below 1800 psi
7878	7878	ALL	Gun timing error	Gun 5-1 error (ms) : -1.70
7929	7929	ALL	Gun timing error	Gun 5-1 error (ms) : 1.80
7930	7930	ALL	Gun timing error	Gun 5-1 error (ms) : 1.60
7952	7952	ALL	Gun timing error	Gun 5-1 error (ms) : -1.80
7959	7959	ALL	Gun timing error	Gun 5-1 error (ms) : -1.60

7979	7979	ALL	Gun timing error	Gun 5-1 error (ms) : -1.60
8035	8035	ALL	Gun timing error	Gun 4-1 error (ms) : 1.60

Comment

Shot(s)	File(s)	Trace(s)	Type	Remark
1617		ALL	Guns disabled	Spare guns, volume at SOL: 7918 cu.in.
4528-4537	4528-4537	ALL	Gun disabled	Sub-array 5 disabled spare guns enabled New source volume 7118 cu.in.
4956-4958	4956-4958	ALL	Gun disabled	Sub-array 5 disabled spare guns enabled New source volume 7118 cu.in.
4975-4984	4975-4984	ALL	Gun disabled	Gun 5-4 disabled new source volume 7723 cu.in.
4988-5003	4988-5003	ALL	Gun not fired	Sub-array 5 disabled spare guns enabled New source volume 7118 cu.in.
5100-5217	5100-5217	ALL	Gun disabled	Gun 1-1. Source volume at shot 5100 : 7918 cu.in.
5100-5217	5100-5217	ALL	Gun disabled	Gun 6-1. Source volume at shot 5100 : 7918 cu.in.
5217-5221	5217-	ALL	Guns disabled/enabled	Array 5 disabled, spares enabled, source volume 7118 cu in.
5222-5796	5222-5796	ALL	Guns disabled/enabled	Array 5 enabled, spares disabled, source volume 7918 cu in.
5798-5808	5798-5808	ALL	Guns enabled/disabled	Array 5 disabled, spares enabled; volume 7118 cu in.
5806-5812	5806-5812	ALL	Guns disabled/enabled	Array 5 disabled, spares enabled, Volume 7118 cu in.
5813-5898	5813-5898	ALL	Guns enabled/disabled	Array 5 enabled, spares disabled; source volume 7918 cu in.
5898-5904	5898-5904	ALL	Guns enabled/disabled	Array 5 disabled, spares enabled; volume 7118 cu in.
5905-6446	5905-6446	ALL	Guns enabled/disabled	Array 5 enabled, spares disabled; volume 7918 cu in.
6447-6452	6447-6452	ALL	Guns enabled/disabled	Array 5 disabled, spares enabled, volume 7118 cu in.
6454-6510	6454-6510	ALL	Guns disabled/enabled	Array 5 enabled, spares disabled; volume 7918 cu in.
6510-6519	6510-6519	ALL	Guns enabled/disabled	Array 5 disabled, spares enabled, volume 7118 cu in.
6520-6574	6520-6574	ALL	Guns enabled/disabled	Array 5 enabled, spares disabled; volume 7918 cu in.
6574-6586	6574-6586	ALL	Guns enabled/disabled	Array 5 disabled, spares enabled, volume 7118 cu in.
6587-6706	6587-6706	ALL	Guns enabled/disabled	Array 5 enabled, spares disabled, volume 7918 cu in.
6707-6710	6707-6710	ALL	Guns enabled/disabled	Spare guns enabled, volume 7118 cu in.
6711-6744	6711-6744	ALL	Guns disabled/enabled	Array 5 enabled, spares disabled, volume 7918 cu.in.
6744-6749	6744-6749	ALL	Guns enabled/disabled	Array 5 disabled, spares enabled; volume 7118 cu in.
6750-6889	6750-6889	ALL	Guns enabled/disabled	Array 5 enabled, spares disabled; volume 7918 cu in.
6890-6894	6890-6894	ALL	Guns disabled/enabled	Array 5 disabled, spares enabled, volume 7118 cu in.
6895-7481	6895-7481	ALL	Guns enabled/disabled	Array 5 enabled, spares disabled; volume 7918 cu in.

6895-7481	6895-7481	ALL	Gun disabled	Gun 6-1. Source volume at shot 6895 : 7918 cu.in.
7481-7489	7481-7489	ALL	Guns enabled/disabled	Array 5 disabled, spares enabled, volume 7118 cu in.
7781-7785	7781-7785	ALL	Guns enabled/disabled	Array 5 disabled, spares enabled, volume 7118 cu in.
7785	7785	ALL	Gun not fired	Gun-status lost for gun 5-1
7785	7785	ALL	Gun not fired	Gun-status lost for gun 5-2

List of used abbreviations:

SOL/EOL	Start/End of line.	Deg	Degrees: e[0,360]
FSP/LSP	First/Last shotpoint of the line.	rev	Revolutions
FCSP/LCSP	First/Last chargeable shotpoint	utc	Universal Time Coordinated
MSP	Midnight (last) shotpoint of the day		
FGSP/LGSP	First/Last Good Shotpoint	SPs	Shotpoints
FOSP/LOSP	First/Last Overlap Shotpoint	CMPs	Common midpoints
FSP/LSP R/O	First/Last Shotpoint Runout	NTBP	Not to be processed
		SI	Seismic interference

TRILOGY INFORMATION MANAGER - ACQUISITION REPORT - GENERATED 21:18:20utc 03-Mar-2001