

Options

Title: Phase noise

Author: edecoux

Output Language: Python

Generate Options: No GUI

Run Options: Prompt for Exit

Variable

ID: samp_rate

Value: 4e6=4M

Parameter

ID: magnitude

Type: Float

Value: 0

Short ID: m

QT GUI Range

ID: magnitude

Default Value: 0

Start: 0

Stop: 6

Step: 0.00001=10u

Variable

ID: magnitude

Value: 25m

Import

Import: *import numpy as np=np*

Noise Source

Noise Type: *analo..._GAUSSIAN*=Gaussian

Amplitude: *magnitude*=0

Seed: 0

out

in

Phase Mod
Sensitivity: 1

out

command

in0

in1

async_msgs

Noise Source

Noise Type: *analo..._GAUSSIAN*=Gaussian

Amplitude: *magnitude*=0

Seed: 42

out

in

Phase Mod
Sensitivity: 1

out

UHD: USRP Sink

Device Arguments: type=b200

Sync: No Sync

Mb0: Clock Source: External

Mb0: Time Source: External

Samp rate (Sps): *samp_rate*=4M

Ch0: Center Freq (Hz): 200e6=200M

Ch0: Gain Value: 79

Ch1: Center Freq (Hz): 200e6=200M

Ch1: Gain Value: 79

Ch1: Antenna: "TX/RX"=TX/RX

N210: addr=192.168.42.2

B210: type=b200