Requirements

Physical Materials

Packages and Libraries

Steps

Installation

Dependencies

Requirements

Physical Materials

- Air Traffic Controller (ATC) computer
- Drone
 - Raspberry Pi
 - MicroSD card
 - Pixhawk
 - Pixhawk GPS attachment
- Virtual Reality (VR) headset

Packages and Libraries

- ATC
 - Python 3.7
 - Mavlink
 - Mavproxy
 - Motive eSoftware
 - QGroundControl
 - Rospy
 - Paho mqtt
- Master Pi
 - Python 3.7
 - Mosquito
- Drone Pis
 - Python 3.7
 - Paho mqtt

Steps

Installation

- 1. Install the Raspberry Pi OS
 - a. Download the Raspberry Pi Imager from: https://www.raspberrypi.com/software/
 - b. Run the imager and select the *Raspberry Pi OS (Legacy)* from the other OS options, insert and format a microSD card, then select *write*.



- 2. Following the steps from https://varhowto.com/install-ros-noetic-raspberry-pi-4/, install ROS Noetic
 - a. Do not install ros-noetic-desktop-full, ros-noetic-desktop, etc. Instead, install individual packages and dependencies and build them
- 3. Make sure you have Python 3.7 installed on your Raspberry Pi and ATC computer.

Physical Connection Steps

1. Connect the Pixhawk to the Pi through UART&ITCB using pins 1 or 2(red wire), 3(yellow wire), 4(blue wire), and 5(black wire).

Dependencies