COLECOVISION PROGRAMMERS' MANUAL Rev. 5 ©Coleco Industries, Inc. 1982 CONFIDENTIAL DOCUMENT - DO NOT COPY

1

2

3

4

5

6

7

8

9

10

11

13

14

15

16

17

18

19

20

21

22

23

24

15

26

APPENDIX E JUMP TABLE

PLAY\_SONGS ACTIVATED 1F61 1F64 1F67 PUTDBJP REFLECT\_VERTICAL REFLECT\_MORIZONTAL ROTATE\_98 ENLARGE 1F6A 1F6D 1F70 1F73 CUNTROLLER\_SCAN 1F76 1F79 DECODER GAME\_OPT LOAD\_ASCII FILL\_VRAM MODE\_1 UPDATE\_SPINNER 1F7C 1F82 1F85 UPDATE SPINNER
INIT\_TADLEP
GET\_VRAMP
PUT\_VRAMP
INIT\_SPR\_ORDERP
WR\_SPR\_NH\_TBLP
INIT\_TIMERP
FREE\_SIGNALP 1F88 1FBB 1FBE 1F91 1F94 1F97 1F9A 1F9D REQUEST SIGNALP 1FAS TEST\_SIGNALP
WRITE\_REGISTERP
WRITE\_URAMP
READ\_URAMP
INIT\_WRITERP
SCUUND\_INITP
PLAY\_ITP
INIT\_TAHLE
GET\_URAM
PUT\_URAM
PUT\_URAM
INIT\_SPR\_DRDER
AR SPR NM TRL 1FA3 1FA6 1FAC 1FAF 1FB2 1FB5 1FBB 1FBB 1FBE 1FC1 MR\_SPR\_NM\_TBL INIT\_TIMER FREE\_SIGNAL 1FC4 1FC7 1FCA REQUEST\_SIGNAL RESULST\_SIGNAL TEST\_SIGNAL TIME\_MGR TURN\_OFF\_SOUND WRITE\_REGISTER READ\_REGISTER WRITE\_VRAM READ\_VRAM INIT\_WRITER WRITER 1FCD 1FD8 1FD3 1FD6 1FD9 1FDC 1FDF 1FE2 IFES WRITER 1FE8 POLLER IFEB SOUND INIT 1FEE 1FF1 SOUND\_MAN 1FF4 ACTIVATE 1FF7 PUTOBJ 1FFA 1FFD RAND GEN