

TECHNICAL EQUIPMENT SERVICE MANUAL — UNIT AX-200

Section 1: Power Requirements

The AX-200 controller requires a nominal input voltage of 24 V DC.

The permitted input voltage range is 22–28 V DC.

Section 2: Operating Temperature

The AX-200 is designed to operate between 0°C and 50°C.

Section 3: Maintenance

Inspect the cooling fan and ventilation openings every 500 operating hours.

Section 4: Safety

Before servicing the controller, disconnect the 24 V DC power supply.

Wait at least 5 minutes after disconnection before opening the enclosure.

Section 5: Hydraulic Operation

The recommended operating flow rate is 8–12 L/min.

The minimum permitted flow rate is 8 L/min.

Section 6: General Information

The enclosure uses a powder-coated steel housing.

The front panel contains three status indicators.

The service manual weighs approximately 1.1 kg.