

DTF Cheat Sheet: Cricut EasyPress

● SUB CAMP 2026 · NINJA TRANSFERS

EasyPress, EasyPress 2, EasyPress 3, or Mini. Same DTF transfer. Same answer.

EasyPress settings by fabric

Hard pressure on every press. Parchment between EasyPress and transfer always. If a section won't adhere, bump temp +15°F at a time. You can't overpress a Ninja DTF transfer.

FABRIC	EASYPRESS TEMP	TIME · PRESSURE
Cotton (light or dark)	320°F	20s · hard
50/50 blends, triblends	320°F	20s · hard
Polyester, jerseys, mesh	320°F	20s · hard + pillow
Denim, canvas, heavy	340°F	20s · hard
Hoodies (multi-layer)	320°F	20s · hard + pillow at seams
Hats / structured	EasyPress Mini · 320°F	20s · tape edges, work in sections

Steps

1. Place the design on the garment. Adult tee: 3 to 4 inches down from the collar. Youth: 2 to 3 inches.
2. Set EasyPress to 320°F and 20 seconds. Hard pressure.
3. Cover with the parchment included with your transfer.
4. Press the EasyPress straight down with hard pressure for the full 20 seconds. Don't slide it around.
5. For larger designs, lift and reposition to overlapping sections so every part of the design gets the full time.

The Peel

Wait at least 5 seconds after lifting the EasyPress, then peel the film in one smooth motion. Hot peel is fine. The transfer should still be warm.

If any part of the design lifts, lay it back down, give that area another 5 to 8 seconds of pressure, then re-peel.

YOU CAN'T OVERPRESS

A Ninja DTF transfer won't degrade from extra presses. If it isn't sticking, press again — bump temp +15°F at a time until it does.

The Second Press

DON'T SKIP THIS

The step most crafters skip is the one that matters most for wash durability.

After peeling, cover the design with fresh parchment (or a single layer of T-shirt material) and press again at the **same temp and time as your first press for 20 seconds**. Improves hand feel, reduces shine, locks in long-term wash performance. Wait 24 hours before the first wash.

When Something Goes Wrong

ISSUE	FIX (NINJA TRANSFERS)
Parts of the design not sticking	Lay it back down and press again with added pressure and heat (+15°F). If unsuccessful, increase heat by 15°F increments until it works.
Forgetting protective cover sheets	Always use a protective guard sheet or parchment paper over your garments.
Incorrect design placement	Invest in a DTF alignment ruler set to eliminate guesswork. Secure transfers with thermal heat tape.
Skipping the second press	Cover your exposed design with a protective guard sheet and press for about 10 to 15 seconds using the same temperature and pressure settings.

What You Can Press Next

Same EasyPress, different transfer. Once you nail cotton, none of these are scary.

Hoodies

Fleece

Denim

Tote bags

Hats (Mini)

Dark cotton

Heavy cotton

Glow

Foil

Glitter

Spangle

UV DTF on hard goods