

# PA-32-260 CHEROKEE SIX

## NORMAL OPERATIONS

### PREFLIGHT / TAXI

#### ► FLOW

- ☐ Fuel Quantity — CHECK /
- ☐ PROPER TANK
- ☐ Oil — CHECK
- ☐ Controls — FREE / CORRECT
- ☐ Flight Instruments — SET / NO
- ☐ FLAGS
- ☐ Trim — SET TAKEOFF
- ☐ Brakes — CHECK
- ☐ Avionics — AS REQUIRED
- ☐ Taxi — CLEAR / CONTROLLED
- ☐

### RUN-UP / BEFORE TAKEOFF

#### ► FLOW

- ☐ Parking Brake — SET
- ☐ Throttle — 2000 RPM
- ☐ Magnetos — CHECK (within limits)
- ☐ Carburetor Heat — CHECK → OFF
- ☐ Engine Gauges — GREEN
- ☐ Suction — CHECK
- ☐ Throttle — IDLE / SMOOTH

#### ✓ VERIFY

- ☐ Stable RPM
- ☐ No abnormal vibration
- ☐ Engine indications normal
- ☐

### TAKEOFF / CLIMB

#### ► FLOW

- ☐ Fuel Pump — ON
- ☐ Lights — AS REQUIRED
- ☐ Flaps — SET
- ☐ Airspeed Alive — CHECK
- ☐ Rotate — **65 MPH**
- ☐ Climb — **Vy 105 MPH**
- ☐

## INSTRUMENT FLIGHT RULES (IFR)

### ✈ IFR — DEPARTURE / ENROUTE

#### ► FLOW

- ☐ Clearance — REVIEW (route / altitude / frequencies)
- ☐ Bugs — HDG / ALT / MINs SET
- ☐ Navigation Source — CONFIRM
- ☐ Instruments — CHECK (gyro / CDI sensing)
- ☐ Fuel Pump — ON
- ☐ Lights — AS REQUIRED
- ☐

### IFR — APPROACH CONFIGURATION

#### ► FLOW

- ☐ Power — SET
- ☐ Pitch — SET
- ☐ Configuration — FLAPS \_\_\_\_°
- ☐ Airspeed — \_\_\_\_ MPH
- ☐ Sink Rate — \_\_\_\_ FPM
- ☐ Goal: Stabilized by FAF

### IFR PERFORMANCE PROFILES

| Phase            | Power      | Pitch     | Config | Speed   | V/S      |
|------------------|------------|-----------|--------|---------|----------|
| Cruise           | ~15 in MP  | 0°        | Clean  | —       | —        |
| Descent          | Low / Idle | -2 to -3° | Clean  | 138 MPH | -500 fpm |
| Approach Level 1 | ~15 in MP  | 0 to -1°  | 25°    | 104 MPH | -500     |
| Approach Level 2 | ~17 in MP  | 0°        | 33°    | 104 MPH | -800     |
| Missed           | FULL       | +7°       | Clean  | 97 MPH  | +800     |

## **MISSED APPROACH (MEMORY ITEMS)**

### **IMMEDIATE ACTIONS**

- |                                        |            |
|----------------------------------------|------------|
| <input type="checkbox"/> Power         | — FULL     |
| <input type="checkbox"/> Pitch         | — +7°      |
| <input type="checkbox"/> Configuration | — CLEAN    |
| <input type="checkbox"/> Airspeed      | — 97 MPH   |
| <input type="checkbox"/> Climb         | — +800 fpm |

## **LANDING / GO-AROUND**

### **LANDING — FLOW**

- |                          |                        |
|--------------------------|------------------------|
| <input type="checkbox"/> | Airspeed — AS REQUIRED |
| <input type="checkbox"/> | Flaps — AS REQUIRED    |

### **GO-AROUND — FLOW**

- |                          |                           |
|--------------------------|---------------------------|
| <input type="checkbox"/> | Power — FULL              |
| <input type="checkbox"/> | Carb Heat — OFF           |
| <input type="checkbox"/> | Flaps — RETRACT IN STAGES |
| <input type="checkbox"/> | Airspeed — $\geq 95$ MPH  |

## EMERGENCY & ABNORMAL OPERATIONS

### CRITICAL MEMORY ITEMS

- ☐ Engine Failure **100 MPH**
- ☐ — **MPH**
- ☐ Engine Fire **Mixture**
- ☐ (In-Flight) — **IDLE CUTOFF**
- ☐ Electrical Fire / **MASTER**
- ☐ Smoke — **OFF**

### ENGINE FAILURE — IN FLIGHT

- ☐ Airspeed **100 MPH**
- ☐ — **(BEST GLIDE)**
- ☐ Fuel Selector —
- ☐ FULLEST TANK
- ☐ Fuel Pump — ON
- ☐ Mixture — FULL RICH
- ☐ Carb Heat — ON
- ☐ Throttle — OPEN
- ☐ Power restored →
- ☐ Resume normal operations

### ENGINE RESTART — IN FLIGHT (POH)

- ☐ Fuel Selector —
- ☐ FULLEST
- ☐ Fuel Pump — ON
- ☐ Mixture — FULL RICH
- ☐ Carb Heat — ON
- ☐ Throttle — 1" OPEN
- ☐ Magnetos — BOTH
- ☐ Primer — AS REQUIRED
- ☐ Engine Gauges —
- ☐ CHECK

### FORCED LANDING

- ☐ Airspeed — **100 MPH**
- ☐ Landing Site — SELECT
- ☐ Mixture — IDLE CUTOFF
- ☐ Fuel Selector — OFF
- ☐ Fuel Pump — OFF
- ☐ Magnetos — OFF
- ☐ Master — OFF
- ☐ Seatbelts — SECURE
- ☐ Door — UNLATCH
- ☐ Flaps — AS REQUIRED
- ☐

### ENGINE FIRE — IN FLIGHT

- ☐ Mixture — IDLE
- ☐ CUTOFF
- ☐ Fuel Selector — OFF
- ☐ Fuel Pump — OFF
- ☐ Magnetos — OFF
- ☐ Cabin Heat / Air — OFF
- ☐ Airspeed **125 MPH** → Proceed to **Engine Failure / Forced Landing**
- ☐ — **MPH (TOP WHITE ARC)**

### ELECTRICAL FIRE / SMOKE (POH-ALIGNED)

- ☐ Master Switch — OFF
- ☐ All Electrical Switches — OFF
- ☐ Cabin Heat — OFF
- ☐ Air / Vents — OPEN (ventilate)
- ☐ Smoke dissipating
- ☐ Master — ON
- ☐ Essential **ONE AT A TIME**
- ☐ Circuits — ON
- ☐ If smoke returns → Master OFF → **Land ASAP**

### ALTERNATOR FAILURE / NO CHARGE

- ☐ Electrical Load — REDUCE
- ☐ Alternator Field CB — CHECK / RESET
- ☐ Alternator Output CB — CHECK / RESET
- ☐ Alternator — OFF (30 sec) → ON
- ☐ Ammeter shows system load
- ☐ If no output → Alternator OFF → Minimal load → **Land ASAP / Practical**