

PA-32-260 CHEROKEE SIX

☐ NORMAL OPERATIONS

☐ PREFLIGHT / TAXI

► FLOW

- ☐ Fuel Quantity — CHECK / PROPER TANK
- ☐ Oil — CHECK
- ☐ Controls — FREE / CORRECT
- ☐ Flight Instruments — SET / NO FLAGS
- ☐ Trim — SET TAKEOFF
- ☐ Brakes — CHECK
- ☐ Avionics — AS REQUIRED
- ☐ Taxi — CLEAR / CONTROLLED

☐ RUN-UP / BEFORE TAKEOFF

► FLOW

- ☐ Parking Brake — SET
- ☐ Throttle — 2000 RPM
- ☐ Magnetos — CHECK (within limits)
- ☐ Carburetor Heat — CHECK → OFF
- ☐ Engine Gauges — GREEN
- ☐ Suction — CHECK
- ☐ Throttle — IDLE / SMOOTH

✓ VERIFY

- ☐ Stable RPM
- ☐ No abnormal vibration
- ☐ Engine indications normal

☐ TAKEOFF / CLIMB

► FLOW

- ☐ Fuel Pump — ON
- ☐ Lights — AS REQUIRED
- ☐ Flaps — SET
- ☐ Airspeed Alive — CHECK
- ☐ Rotate — **65 MPH**
- ☐ Climb — **Vy 105 MPH**

☐ INSTRUMENT FLIGHT RULES (IFR)

☐ → IFR — DEPARTURE / ENROUTE

► FLOW

- ☐ Clearance — REVIEW (route / altitude / frequencies)
- ☐ Bugs — HDG / ALT / MINs SET
- ☐ Navigation Source — CONFIRM
- ☐ Instruments — CHECK (gyro / CDI sensing)
- ☐ Fuel Pump — ON
- ☐ Lights — AS REQUIRED

☐ IFR — APPROACH CONFIGURATION

► FLOW

- ☐ Power — SET
- ☐ Pitch — SET
- ☐ Configuration — FLAPS ____°

☐ Airspeed — ___ MPH

☐ Sink Rate — ___ FPM

| Goal: Stabilized by FAF

IFR PERFORMANCE PROFILES

Phase	Power	Pitch	Config	Speed	V/S
Cruise	~15 in MP	0°	Clean	—	—
Descent	Low / Idle	−2 to −3°	Clean	138 MPH	−500 fpm
Approach Level 1	~15 in MP	0 to −1°	25°	104 MPH	−500
Approach Level 2	~17 in MP	0°	33°	104 MPH	−800
Missed	FULL	+7°	Clean	97 MPH	+800

● MISSED APPROACH (MEMORY ITEMS)

IMMEDIATE ACTIONS

☐ Power

— FULL

☐ Pitch

— +7°

☐ Configuration

— CLEAN

☐ Airspeed

— 97 MPH

☐ Climb

— +800 fpm

LANDING / GO-AROUND

LANDING — FLOW

☐ Airspeed — AS REQUIRED

☐ Flaps — AS REQUIRED

GO-AROUND — FLOW

☐ Power — FULL

☐ Carb Heat — OFF

☐ Flaps — RETRACT IN STAGES

☐ Airspeed — ≥95 MPH

EMERGENCY & ABNORMAL OPERATIONS

● CRITICAL MEMORY ITEMS

- ☐ Engine Failure — **100 MPH**
- ☐ Engine Fire (In-Flight) — **Mixture IDLE CUTOFF**
- ☐ Electrical Fire / Smoke — **MASTER OFF**

● ENGINE FAILURE — IN FLIGHT

► FLOW

- ☐ Airspeed — **100 MPH (BEST GLIDE)**
- ☐ Fuel Selector — FULLEST TANK
- ☐ Fuel Pump — ON
- ☐ Mixture — FULL RICH
- ☐ Carb Heat — ON
- ☐ Throttle — OPEN

✓ VERIFY

- ☐ Power restored → Resume normal operations

● ENGINE RESTART — IN FLIGHT (POH)

► FLOW

- ☐ Fuel Selector — FULLEST
- ☐ Fuel Pump — ON
- ☐ Mixture — FULL RICH
- ☐ Carb Heat — ON
- ☐ Throttle — 1" OPEN
- ☐ Magnetos — BOTH
- ☐ Primer — AS REQUIRED
- ☐ Engine Gauges — CHECK

● FORCED LANDING

► FLOW

- ☐ Airspeed — **100 MPH**
- ☐ Landing Site — SELECT
- ☐ Mixture — IDLE CUTOFF
- ☐ Fuel Selector — OFF
- ☐ Fuel Pump — OFF
- ☐ Magnetos — OFF
- ☐ Master — OFF
- ☐ Seatbelts — SECURE
- ☐ Door — UNLATCH
- ☐ Flaps — AS REQUIRED

● ENGINE FIRE — IN FLIGHT

► FLOW

- ☐ Mixture — IDLE CUTOFF
- ☐ Fuel Selector — OFF
- ☐ Fuel Pump — OFF
- ☐ Magnetos — OFF
- ☐ Cabin Heat / Air — OFF
- ☐ Airspeed — **125 MPH (TOP WHITE ARC)**

● ⚡ ELECTRICAL FIRE / SMOKE (POH-ALIGNED)

► FLOW

- ☐ Master Switch — OFF
- ☐ All Electrical Switches — OFF
- ☐ Cabin Heat — OFF
- ☐ Air / Vents — OPEN (ventilate)

✓ VERIFY

- ☐ Smoke dissipating

IF ELECTRICAL POWER REQUIRED

- ☐ Master — ON
- ☐ Essential Circuits — **ON ONE AT A TIME**
- ☐ If smoke returns:

● ⚠ ALTERNATOR FAILURE / NO CHARGE

► FLOW

- ☐ Electrical Load — REDUCE
- ☐ Alternator Field CB — CHECK / RESET

- ☐ Alternator Output CB — CHECK / RESET
- ☐ Alternator — OFF (30 sec) → ON

✓ **VERIFY**

- ☐ Ammeter shows system load
 - ☐ If no output:
-