

PA-32-260 CHEROKEE SIX

NORMAL OPERATIONS

PREFLIGHT / TAXI

- ☐ Fuel Quantity — CHECK / PROPER TANK
- ☐ Oil — CHECK
- ☐ Controls — FREE / CORRECT
- ☐ Flight Instruments — SET / NO FLAGS
- ☐ Trim — SET TAKEOFF
- ☐ Brakes — CHECK
- ☐ Avionics — AS REQUIRED
- ☐ Taxi — CLEAR / CONTROLLED

RUN-UP / BEFORE TAKEOFF

- ☐ Parking Brake — SET
- ☐ Throttle — 2000 RPM
- ☐ Magnetos — CHECK (within limits)
- ☐ Carburetor Heat — CHECK → OFF
- ☐ Engine Gauges — GREEN
- ☐ Suction — CHECK
- ☐ Throttle — IDLE / SMOOTH
- ☐ Stable RPM
- ☐ No abnormal vibration
- ☐ Engine indications normal

TAKEOFF / CLIMB

- ☐ Fuel Pump — ON
- ☐ Lights — AS REQUIRED
- ☐ Flaps — SET
- ☐ Airspeed Alive — CHECK
- ☐ Rotate — **65 MPH**
- ☐ Climb — **Vy 105 MPH**

INSTRUMENT FLIGHT RULES (IFR)

✈ IFR — DEPARTURE / ENROUTE

- ☐ Clearance — REVIEW (route / altitude / frequencies)
- ☐ Bugs — HDG / ALT / MINs SET
- ☐ Navigation Source — CONFIRM
- ☐ Instruments — CHECK (gyro / CDI sensing)
- ☐ Fuel Pump — ON
- ☐ Lights — AS REQUIRED

IFR — APPROACH CONFIGURATION

- ☐ Power — SET
 - ☐ Pitch — SET
 - ☐ Configuration — FLAPS ____°
 - ☐ Airspeed — ____ MPH
 - ☐ Sink Rate — ____ FPM
- Goal: Stabilized by FAF*

IFR PERFORMANCE PROFILES

Phase	Power	Pitch	Config	Speed	V/S
Cruise	~15 in MP	0°	Clean	—	—
Descent	Low / Idle	-2 to -3°	Clean	138 MPH	-500 fpm
Approach Level 1	~15 in MP	0 to -1°	25°	104 MPH	-500
Approach Level 2	~17 in MP	0°	33°	104 MPH	-800
Missed	FULL	+7°	Clean	97 MPH	+800

MISSSED APPROACH (MEMORY ITEMS)

IMMEDIATE ACTIONS

- ☐ Power — FULL
- ☐ Pitch — +7°
- ☐ Configuration — CLEAN
- ☐ Airspeed — 97 MPH
- ☐ Climb — +800 fpm

LANDING / GO-AROUND

- ☐ Airspeed — AS REQUIRED
- ☐ Flaps — AS REQUIRED
- ☐ Power — FULL
- ☐ Carb Heat — OFF
- ☐ Flaps — RETRACT IN STAGES
- ☐ Airspeed — ≥95 MPH

EMERGENCY & ABNORMAL OPERATIONS

CRITICAL MEMORY ITEMS

- ☐ Engine Failure — **100 MPH**
- ☐ Engine Fire (In-Flight) — **Mixture IDLE CUTOFF**
- ☐ Electrical Fire / Smoke — **MASTER OFF**

ENGINE FAILURE — IN FLIGHT

- ☐ Airspeed — **100 MPH (BEST GLIDE)**
- ☐ Fuel Selector — **FULLEST TANK**
- ☐ Fuel Pump — **ON**
- ☐ Mixture — **FULL RICH**
- ☐ Carb Heat — **ON**
- ☐ Throttle — **OPEN**
- ☐ Power restored → Resume normal operations

ENGINE RESTART — IN FLIGHT (POH)

- ☐ Fuel Selector — **FULLEST**
- ☐ Fuel Pump — **ON**
- ☐ Mixture — **FULL RICH**
- ☐ Carb Heat — **ON**
- ☐ Throttle — **1" OPEN**
- ☐ Magnetos — **BOTH**
- ☐ Primer — **AS REQUIRED**
- ☐ Engine Gauges — **CHECK**

FORCED LANDING

- ☐ Airspeed — **100 MPH**
- ☐ Landing Site — **SELECT**
- ☐ Mixture — **IDLE CUTOFF**
- ☐ Fuel Selector — **OFF**
- ☐ Fuel Pump — **OFF**
- ☐ Magnetos — **OFF**
- ☐ Master — **OFF**
- ☐ Seatbelts — **SECURE**
- ☐ Door — **UNLATCH**
- ☐ Flaps — **AS REQUIRED**

ENGINE FIRE — IN FLIGHT

- ☐ Mixture — **IDLE CUTOFF**
- ☐ Fuel Selector — **OFF**
- ☐ Fuel Pump — **OFF**
- ☐ Magnetos — **OFF**
- ☐ Cabin Heat / Air — **OFF**
- ☐ Airspeed **125 MPH (TOP WHITE ARC)** → Proceed to **Engine Failure / Forced Landing**

ELECTRICAL FIRE / SMOKE (POH-ALIGNED)

- ☐ Master Switch — **OFF**
- ☐ All Electrical Switches — **OFF**
- ☐ Cabin Heat — **OFF**
- ☐ Air / Vents — **OPEN (ventilate)**
- ☐ Smoke dissipating
- ☐ Master — **ON**
- ☐ Essential Circuits — **ONONE AT A TIME**
- ☐ If smoke returns → Master OFF → **Land ASAP**

⚠ ALTERNATOR FAILURE / NO CHARGE

- ☐ Electrical Load — **REDUCE**
- ☐ Alternator Field CB — **CHECK / RESET**
- ☐ Alternator Output CB — **CHECK / RESET**
- ☐ Alternator — **OFF (30 sec) → ON**
- ☐ Ammeter shows system load
- ☐ If no output → Alternator OFF → Minimal load → **Land ASAP / Practical**