

运控接口文档

接口列表

接口示例

uocs-cof

查询系统所有基站（用于地图展示）

接口编号：INT_COF_089

接口地址：/uocs-cof/base/getSiteForMap

方法：POST

标签：地面站接口

请求示例：

```
{
    "requestDate": "615619268",    //请求时间
    "requestId": "615619268",      //请求Id
    "userCode": "42470400"         // 请求工号
}
```

响应示例：

```
{
    "requestId": null,
    "success": true,
    "business": null,
    "errorCode": null,
    "errorMessage": null,
    "params": null,
    "date": "2024-09-25 20:36:52",
    "version": "1.0",
    "obj": [
        {
            "siteNo": 4293920816,    //基站编号
            "latitude": 22.8839452,  //基站位置纬度
            "siteName": "2096--12",  //基站名称
            "state": 0,              //基站状态
        }
    ]
}
```

```

        "siteType": 2,                //基站类型
        "longitude": 113.8463272,    //基站位置经度
        "height": 107.83             //基站位置高度
    }, {
        "siteNo": 4293920780,
        "latitude": 26.1476939,
        "siteName": "赣州_2060_14",
        "state": 0,
        "siteType": 1,
        "longitude": 114.5383530,
        "height": 349.23
    }
]
}

```

查询基站明细数据（用于地图展示）

接口编号：INT_COF_090

接口地址：/uocs-cof/base/getSiteDetailInfoForMap

标签：地面站接口

方法：POST

请求示例：

```

{
    "requestDate": "507454498",
    "requestId": "507454498",
    "siteNo": 4293920994           //基站编号
}

```

响应示例：

```

{
    "requestId": null,
    "success": true,
    "business": null,
    "errorCode": null,
    "errorMessage": null,
    "params": null,
    "date": "2024-09-26 16:10:45",
    "version": "1.0",
    "obj": {
        "posState": 1,           //定位状态 0：未定位 1：已定位 2：校准中 3：校准失败
        "siteRssi": "-51",      //基站4Grssi
    }
}

```

```

        "siteChannel": 5,          //基站信道
        "city": "深圳市",         //市(根据经纬度输出)
        "reportTm": "2024-09-26 16:10:45", //rtk上报时间
        "latitude": "22.6941613",    //rtk纬度
        "siteName": "755BS起降场 2274-5", //基站名称
        "posMode": 1,                //设备工作模式 0 自主定位 1 固定坐标
        "operator": "中国移动",       //运营商
        "isFrequencySuccess": 1, //射频开启关闭：初始为0空、1开启、2关闭/3开失败 电压低、4关失败
    无人机接入
        "faultInfo": [],            //故障
        "siteNo": 4293920994,       //基站编号
        "province": "广东省",        //省(根据经纬度输出)
        "jammingState": 1, //通信干扰状态 0正常 1正常 2存在干扰,但仍可用 3通信被干扰,不可用
        "temperature": 32.3, //温度
        "humidity": 64,
        "state": 1,
        "windSpeed": 1.26,
        "siteType": 3,
        "rtkState": 1,
        "longitude": "113.9184134",
        "height": "82.54",
        "uv": 713,
        "rainfall": 0.0,
        "siteCode": "2274",
        "address": "广东省深圳市宝安区爱群路13号爱群路西厂区",
        "signalStrength": -95,
        "siteVol": "43.9461",
        "uvi": 2,
        "siteSoc": "100.0",
        "pressure": 99.886,
        "siteVersion": "V02.38.005",
        "gusetSpeed": 2.24,
        "light": 57032.5,
        "errCode": 0,
        "reportBeatTime": "2024-09-26 16:10:37",
        "district": "宝安区",
        "statNum": 26,
        "windDirect": 244
    }
}

```

查询基站下飞机信息

接口编号：INT_COF_041

接口地址：uocs-cof/radio/queryRadioList

方法：POST

标签：地面站接口

请求示例：

```
{
    "baseId": 4293918721    //基站编号
}
```

响应示例：

```
{
    "requestId": null,
    "success": true,
    "business": null,
    "errorCode": null,
    "errorMessage": "ok",
    "params": null,
    "date": null,
    "version": null,
    "obj": {
        "radioNum": 4,        //基站下的所有飞机
        "radioIds": [        //基站下所有无人机编号
            35103,
            35114,
            35102,
            3335428320
        ],
        "sysTime": "2024-10-17 16:47:22"
    }
}
```

查询基站明细数据，用于地图展示

接口编号：INT_COF_090

接口地址：/uocs-cof/base/getSiteDetailInfoForMap

方法：POST

标签：地面站接口

请求示例：

```
{
    "baseId": 4293921019    //基站编号
}
```

响应示例：

```
{
  "requestId": null,
  "success": true,
  "business": null,
  "errorCode": null,
  "errorMessage": "ok",
  "params": null,
  "date": null,
  "version": null,
  "obj": {
    "radioNum": 1,                //在线数量
    "radioIds": [                //在线无人机列表
      5170
    ],
    "sysTime": "2024-09-26 17:19:51"
  }
}
```

uocs-fis

Dji发送指令

接口编号：INT_FIS_038

接口地址：/uocs-fis/qgc/sendDjiCommand

方法：POST

标签：地面站接口

请求示例：

```
{
  "cmd": "DJI_TAKEOFF",          //DJI无人机指令
  "comNum": 30008,               //DJI无人机
  "requestDate": "8643077",      //请求日期
  "requestId": "8643076"        //请求ID
}
```

响应示例：

```
{
  "requestId": null,
  "success": true,               //执行成功
  "business": null,
```

```
    "errorCode": null,
    "errorMessage": null,
    "params": null,
    "date": "2024-09-25 20:36:52",
    "version": "1.0",
    "obj":{
        "comNum": 30008
    }
}
```

推送航路变更结果

接口编号：INT_FIS_048

接口地址：/uocs-fis/qgc/pushAirwayAuthorityResult

方法：POST

标签：地面站接口

请求示例：

```
{
    "airRouteId": 921,                //航路ID
    "applyer": "491285",              //申请人工号
    "applyerName": "张子成",          //申请人姓名
    "captainCode": "ta177758",        //当前机长工号
    "captainName": "刘颂",            //当前机长姓名
    "requestDate": "1667833512",       //请求时间
    "requestId": "1667833512",         //请求ID
    "result": 2,                      //结果
    "type": 3                         //变更类型
}
```

响应示例：

```
{
    "requestId": null,                //请求的 requestId
    "success": true,                  //执行成功
    "business": null,
    "errorCode": null,
    "errorMessage": null,
    "params": null,
    "date": "2024-09-25 20:36:52",
    "version": "1.0",                 //后台的版本号
    "obj":null
}
```

查询航路下航班任务状态

接口编号：INT_FIS_063

接口地址：/uocs-fis/qgc/getFlightStatusListByAirRouteId

方法：POST

标签：地面站接口

请求示例：

```
{
  "airRouteId": 1069,           //航路ID
  "requestDate": "782321858",
  "requestId": "782321858"
}
```

响应示例：

```
{
  "requestId": "782321858",
  "success": true,
  "errorCode": null,
  "date": "2024-09-26 18:05:02",
  "timestamp": 1727345102360,
  "version": "1.0",
  "errorMessage": null,
  "obj": [
    {
      "comNum": 5117,           //无人机编号
      "airRouteId": 1069,      //航路ID
      "routeId": 2009,         //航线ID
      "routeDirection": 2,     //航向
      "flightId": 481801,      //航班ID
      "status": "WP"           //航班状态
    }
  ]
}
```

手动结束任务

接口编号：INT_FIS_074

接口地址：/uocs-fis/qgc/endFlight

方法：POST

标签：地面站接口

请求示例：

```
{
    "comNum": 5097,                //无人机编号
    "requestDate": "246641948",
    "requestId": "246641948"
}
```

响应示例：

```
{
    "requestId": "246641948",
    "success": false,
    "errorCode": "10108",
    "date": "2024-09-26 18:24:10",
    "timestamp": 1727346250884,
    "version": "1.0",
    "errorMessage": "飞机失联或已关机才允许删除",
    "obj": null
}

{
    "requestId": "246641948",
    "success": true,
    "errorCode": "10001",
    "date": "2024-09-26 18:25:20",
    "timestamp": 1727346320292,
    "version": "1.0",
    "errorMessage": "结束任务",
    "obj": 1
}
```

向飞机发送请求获取设备信息（**key**的获取）

接口编号：INT_FIS_047

接口地址：/uocs-fis/qgc/reqUavDeviceInfo

方法：POST

标签：地面站接口

请求示例：

```
{
    "comNum": 5155,                //飞机编号
    "deviceKey": 1000,            //飞机请求key 1000
}
```

```
        "requestDate": "594794570",      //请求时间
        "requestId": "594794570"         //请求ID
    }
```

响应示例：

```
//其它不支持反馈
{
    "requestId": null,
    "success": false,
    "errorCode": "20096",
    "date": "2024-09-27 16:31:52",
    "timestamp": 1727425912739,
    "version": "1.0",
    "errorMessage": "指令不支持",
    "obj": null
}

//key: 1000
{
    "requestId": null,
    "success": true,
    "errorCode": null,
    "date": "2024-09-27 16:10:33",
    "timestamp": 1727424633475,
    "version": "1.0",
    "errorMessage": null,
    "obj": {
        "softVersion": "0.1.3.32",          //软件版本
        "uavType": "FZ90",                 //机型代码
        "uavCumulativeVoyage": 11206789,    //无人机里程
        "uavTypeInt": "24",                 //无人机FCC机型代码
        "factoryTime": "2024-01-03",        //出厂时间
        "uavCumulativeWorkingHours": 380040, //无人机开机时间
        "typeCode": "F04",                  //机型结构
        "uavCumulativeFlightTime": 158,      //无人机飞行时间
        "airspaceState": 1,                  //空域管控开关:1-恢复管制|2-解除管制
        "gitCommit": "0x1b8d59dd",          //git提交版本
        "hardVersion": "0.0.6.2",           //硬件版本
        "regNum": "UAS03945928",            //无人机注册码
        "sfkState": 0,                       //sfk状态:1|lock、0|unlock
        "subsrcStatus": 255,                 //RC接收机状态:0正常|1未连接|2数据不可用|3数据
        "comNum": 9319,                     //无人机编号
        "sn": "DG124012003YHCT006",        //无人机SN
    }
}
```

```
        "parachuteStatus": 3,                //伞状态
        "rtkState": 1                        //RTK使能状态：1使能|0未使能
    }
}
```

查询航路下航班任务状态

接口编号：INT_FIS_047

接口地址：/uocs-fis/qgc/reqUavDeviceInfo

方法：POST

标签：地面站接口

请求示例：

```
{
    "comNum": 5155,                //飞机编号
    "deviceKey": 1000,            //飞机请求key 1000
    "requestDate": "594794570",    //请求时间
    "requestId": "594794570"       //请求ID
}
```

响应示例：

```
//其它不支持反馈
{
    "requestId": null,
    "success": false,
    "errorCode": "20096",
    "date": "2024-09-27 16:31:52",
    "timestamp": 1727425912739,
    "version": "1.0",
    "errorMessage": "指令不支持",
    "obj": null
}

//key: 1000
{
    "requestId": null,
    "success": true,
    "errorCode": null,
    "date": "2024-09-27 16:10:33",
    "timestamp": 1727424633475,
    "version": "1.0",
    "errorMessage": null,
    "obj": {
```

```
        "softVersion": "0.1.3.32",          //软件版本
        "uavType": "FZ90",                  //机型代码
        "uavCumulativeVoyage": 11206789,     //无人机里程
        "uavTypeInt": "24",                  //无人机FCC机型代码
        "factoryTime": "2024-01-03",         //出厂时间
        "uavCumulativeWorkingHours": 380040, //无人机开机时间
        "typeCode": "F04",                   //机型结构
        "uavCumulativeFlightTime": 158,       //无人机飞行时间
        "airspaceState": 1,                  //空域管控开关:1-恢复管制|2-解除管制
        "gitCommit": "0x1b8d59dd",           //git提交版本
        "hardVersion": "0.0.6.2",            //硬件版本
        "regNum": "UAS03945928",             //无人机注册码
        "sfkState": 0,                       //sfk状态:1|lock、0|unlock
        "subsrcStatus": 255,                  //RC接收机状态:0正常|1未连接|2数据不可用|3数据
        失联
        "comNum": 9319,                      //无人机编号
        "sn": "DG124012003YHCT006",          //无人机SN
        "parachuteStatus": 3,                 //伞状态
        "rtkState": 1                        //RTK使能状态:1使能|0未使能
    }
}
```

QGC获取航班信息

接口编号：INT_FIS_062

接口地址：/uocs-fis//qgc/getMissionInfo

方法：POST

标签：地面站接口

请求示例：

```
{
    "flightId": 510895,                      //航班ID
    "requestDate": "25096540",
    "requestId": "25096540"
}
```

响应示例：

```
{
    "requestId": "25096540",
    "success": true,
    "errorCode": null,
    "date": "2024-10-18 14:15:27",
}
```

```

    "timestamp": 1729232127247,
    "version": "1.0",
    "errorMessage": null,
    "obj": {
      "isPreFlightCheck": 1,          // '是否需要航前检:0-是|1-否'
      "routeId": 1760,                // 航线ID
      "flightCode": "CNC010002R0HD2410180004", // 航班
      "captainCode": "42490037",     // 机长工号
      "captainName": "徐亮",          // 机长姓名
      "routeDirection": 2,            // 航线类别: 1去程航线|2返程航线
      "flightId": 510895,              // 航班id
      "flightDirection": 2,           // 航班方向类型
      "lineCrc": "0",                 // 航线的md5值
      "comNum": 5133,                 // 无人机编号
      "source": 1                     // 航班源
    }
  }
}

```

QGC根据无人机获取航班信息

接口编号：INT_FIS_061

接口地址：/uocs-fis/qgc/getMissionInfoByComNum

方法：POST

标签：地面站接口

请求示例：

```

{
  "comNum": 5128,          // 无人机编号
  "requestDate": "698087386",
  "requestId": "698087386"
}

```

响应示例：

```

{
  "requestId": "698087386",
  "success": true,
  "errorCode": null,
  "date": "2024-10-18 17:22:08",
  "timestamp": 1729243328963,
  "version": "1.0",
  "errorMessage": null,
  "obj": {
    "isPreFlightCheck": 1,          // '是否需要航前检:0-是|1-否'

```

```

        "routeId": 1883, //航线ID
        "flightCode": "CNC010013R00W241018002R", //航班
        "captainCode": "ta180380", //机长工号
        "captainName": "黄健荣", //机长姓名
        "routeDirection": 1, //航线类别：1去程航线|2返程航线
        "flightId": 511507, //航班id
        "flightDirection": 1, //航班方向类型
        "lineCrc": "0", //航线的md5值
        "comNum": 8337, //无人机编号
        "source": 1
    }
}

```

获取气象站的最新气象数据

接口编号：INT_FIS_050

接口地址：/uocs-fis/qgc/getWeatherStationInfo

方法：POST

标签：地面站接口

请求示例：

```

{
    "requestDate": "889817945",
    "requestId": "889817945",
    "teleCode": "4293921125" //基站编号
}

```

响应示例：(translateFile.json)

```

{
    "requestId": "889817945",
    "success": true,
    "errorCode": null,
    "date": "2024-10-18 17:42:01",
    "timestamp": 1729244521707,
    "version": "1.0",
    "errorMessage": null,
    "obj": {
        "rainfall": 0.0, //降雨量(mm/h)
        "light": 0.0, //光强(lux)
        "weatherCode": "4293921125", //基站编号
        "temperature": 26.6, //温度(℃)
        "humidity": 76, //湿度(%)
        "pressure": 101.01, //气压(Kpa)
    }
}

```

```
        "windSpeed": 0.0,                //风速(m/s)
        "windDirect": 121                //风向(°)
    }
}
```

QGC查询航线信息

接口编号：INT_FIS_073

接口地址：/uocs-fis/qgc/getAirlineInfo

方法：POST

标签：地面站接口

请求示例：

```
{
    "requestDate": "792186688",
    "requestId": "792186688",
    "routeId": 2157                //航线ID
}
```

响应示例：

```
{
    "requestId": "889817945",
    "success": true,
    "errorCode": null,
    "date": "2024-10-18 17:42:01",
    "timestamp": 1729244521707,
    "version": "1.0",
    "errorMessage": null,
    "obj": {
        "rainfall": 0.0,            //降雨量(mm/h)
        "light": 0.0,              //光强(lux)
        "weatherCode": "4293921125", //基站编号
        "temperature": 26.6,        //温度(°C)
        "humidity": 76,             //湿度(%)
        "pressure": 101.01,         //气压(Kpa)
        "windSpeed": 0.0,          //风速(m/s)
        "windDirect": 121          //风向(°)
    }
}
```

查询航路所有可用在线机长

接口编号：INT_FIS_060

接口地址：/uocs-fis/qgc/getOnlineCaptainList

方法：POST

标签：地面站接口

请求示例：

```
{
    "airRouteId": 1264,           //航路ID
    "requestDate": "14056306",
    "requestId": "14056306"
}
```

响应示例：

```
{
    "requestId": "14056306",
    "success": true,
    "errorCode": null,
    "date": "2024-10-18 18:00:03",
    "timestamp": 1729245603814,
    "version": "1.0",
    "errorMessage": null,
    "obj": [
        {
            "captainCode": "42158429", //机长工号
            "captainName": "黄毅"      //机长姓名
        }
    ]
}
```

QGC功能模块切换

接口编号：INT_FIS_031

接口地址：/uocs-fis/qgc/switchFunctionModule

方法：POST

标签：地面站接口

请求示例：

```
{
    "moduleCode": "QGC_FLIGHT_TEST", //需要切换成的模块代码
}
```

```
    "requestDate": "79360328",
    "requestId": "79360328",
    "userCode": "ta194640"           //切换人的工号
}
```

响应示例：

```
{
    "requestId": "79360328",
    "success": false,                 //false: 切换失败;   //true: 切换成功
    "errorCode": "10103",
    "date": "2024-10-28 14:47:14",
    "timestamp": 1730098034653,
    "version": "1.0",
    "errorMessage": "功能模块切换异常返回false",    //如果成功，则该字段为空
    "obj": null
}
```

航路绑定或者移交

接口编号：INT_FIS_077

接口地址：/uocs-fis/qgc/changeAirwayAuthority

方法：POST

标签：地面站接口

请求示例：

```
//1绑定航路
{
    "airRouteId": 372,                //航路ID
    "applyer": "ta154197",           //申请工号
    "applyerName": "洪金淇",         //申请姓名
    "captainCode": null,
    "captainName": null,
    "requestDate": "188739641",
    "requestId": "188739641",
    "type": 1                         //1绑定航路 | 2移交航路 | 3请求接管 | 4解除绑定
}

//2移交航路
{
    "airRouteId": 301,
    "applyer": "881822",
```

```

    "applyerName": "叶少秋",
    "captainCode": "854277",
    "captainName": "江建莉",
    "requestDate": "41384971",
    "requestId": "41384971",
    "type": 2
}
//3请求接管
{
    "airRouteId": 745,
    "applyer": "881822",           //请求接航路的人
    "applyerName": "叶少秋",       //请求接航路姓名
    "captainCode": "854277",       //airRouteId当前管控机长
    "captainName": "江建莉",       //airRouteId当前管控机长
    "requestDate": "1552178505",   //请求时间
    "requestId": "1552178505",     //请求ID
    "type": 3                       //请求类型
}

```

响应示例：

```

{
    "requestId": "188739641",
    "success": true,                //成功|失败
    "errorCode": null,
    "date": "2024-10-28 15:13:44",
    "timestamp": 1730099624487,
    "version": "1.0",
    "errorMessage": null,
    "obj": null
}

```

切换管控中心

接口编号：INT_FIS_032

接口地址：/uocs-fis/qgc/switchControlCenter

方法：POST

标签：地面站接口

请求示例：

```
{
    "centreId": 41,           //待切换管控中心ID
    "regionId": 1,           //区域ID
    "requestDate": "8699260", //请求日期
    "requestId": "8699260",   //请求ID
    "userCode": "01381137"   //切换人工号
}
```

响应示例：

```
{
    "requestId": "8699260",    //请求ID
    "success": true,          //请求成功
    "errorCode": null,
    "date": "2024-11-01 14:18:16",
    "timestamp": 1730441896437,
    "version": "1.0",
    "errorMessage": null,
    "obj": null
}
```

查询航路详情

接口编号：INT_FIS_032

接口地址：/uocs-fis/qgc/getAirwayInfo

方法：POST

标签：地面站接口

请求示例：

```
{
    "airRouteId": 562,        //航路ID
    "requestDate": "621919658",
    "requestId": "621919658"
}
```

响应示例：

```
{
    "requestId": "621919658", //响应请求ID
    "success": true,          //响应成功
    "errorCode": null,
}
```

```
"date": "2024-11-01 14:48:30",           //响应时间
"timestamp": 1730443710302,
"version": "1.0",                         //版本号
"errorMessage": null,                     //错误信息
"obj": {
    "warningAreaRadius": 36,
    "landingDispatchCode": "CN110019-QA005",
    "landingRtkLongitude": null,
    "code": "CN040002R007",
    "takeoffRtkAltitude": null,
    "flyDirection": 1,
    "uavList": [],
    "landingDispatchType": "Q",
    "exitBoundaryRadius": 37,
    "takeoffDispatchName": "广成教育起降场",
    "takeoffLatitude": "22.5631610",
    "aircraftType": "ARK60",
    "takeoffSiteLightCode": "",
    "captainName": "",
    "landingLatitude": "22.5610200",
    "refAirRouteId": null,
    "aLogo": 255,
    "landingDispatchId": 1693,
    "id": 562,
    "takeoffRtkLatitude": null,
    "landingDispatchName": "宝安地铁站起降场",
    "minProtectBoundaryRadius": 38,
    "landingLongitude": "113.8868460",
    "takeoffDispatchType": "Q",
    "captainCode": "",
    "bLogo": 255,
    "landingFcBoxCode": null,
    "takeoffFcBoxCode": null,
    "takeoffDispatchId": 1694,
    "takeoffLongitude": "113.8841680",
    "landingRtkLatitude": null,
    "bQrCode": null,
    "aQrCode": null,
    "maxProtectBoundaryRadius": 39,
    "landingAltitude": "30",
    "takeoffAltitude": "20",
    "takeoffRtkLongitude": null,
    "name": "广成--宝安",
    "takeoffDispatchCode": "CN110019-QA006",
    "aAirspaceState": 1,
```

```
        "bAirspaceState": 1,  
        "weatherList": [],  
        "isLoadBox": 2,  
        "landingRtkAltitude": null  
    }  
}
```

uocs-uav

下载机型Json信息文件

接口编号：INT_UAV_128

接口地址：/uocs-uav/file/downloadAircraftTypeJsonFile

方法：GET

标签：地面站接口

请求示例：

响应示例：

```
{  
  "creationUser": "SYS",  
  "typeInfo": [  
    {  
      "minOperatingTemperature": -100.0,  
      "recCruisingSpeed": 11.47,  
      "rtkLimitDistance": 20.0,  
      "regCompName": "飞行控制单元",  
      "createEmp": "01304522",  
      "gpsTlCylinderRadius": 8.0,  
      "manufacturerAddress": null,  
      "windResistance": 8,  
      "gpsCruiseCapsuleHoriz": 15.0,  
      "type": 18,  
      "modelTypeCode": "F01",  
      "exitBoundaryRadius": 100,  
      "fvposDeviationRemind": 0.5,  
      "rtkTlCylinderRadius": 3.0,  
      "createTm": "2020-11-20 16:49:48",  
      "gpsCruiseCapsuleUpperh": 30.0,  
    }  
  ]  
}
```

```
"id": 1,
"maxTakeoffHeight": 500,
"typeGrade": "中型 ( 起飞重量≤150kg ) ",
"maxRainfall": 3.0,
"minProtectBoundaryRadius": 100,
"rtkCdsExt": 0.0,
"rtkDispatchFlyDistance": 500.0,
"verticalTakeoffSpeed": 4.0,
"licence": "",
"gpsCruiseCapsuleExt": 0.0,
"relaDispatchRadius": 2.6,
"isExternal": 0,
"emptyWeight": 20.0,
"modelClass": 4,
"mhposDeviationRemind": 0.8,
"maxRange": 100,
"modelType": 1,
"registerComponentName": "飞行控制单元",
"mvposDeviationWarn": 4.0,
"rtkCruiseCapsuleExt": 0.0,
"lifespanFlyCalendar": 1000,
"isPreFlightCheck": 1,
"maxCruisingTime": 60,
"name": "方舟ARK40",
"verticalLandingSpeed": 1.0,
"typeId": 18,
"lifespanFlyHour": 1000.0,
"maxCruisingSpeed": 150.0,
"rtkCruiseCapsuleHoriz": 3.0,
"warningAreaRadius": 100,
"code": "ARK40",
"registerComponentCode": "FCC",
"maxOperatingTemperature": 100.0,
"typeName": "方舟ARK40",
"fhposDeviationRemind": 0.5,
"rtkCruiseCapsuleLowerh": 5.0,
"modelClassName": "中型 ( 起飞重量≤150kg ) ",
"manufacturer": null,
"rtkLimitHeight": 10.0,
"maxLight": 50000.0,
"recVdownSpeed": 0.25,
"rtkCruiseCapsuleUpperh": 25.0,
"isCheckFault": 2,
"protectionLevel": "IP12",
"fwWindResistance": 2,
```

```
        "lifespanFlyCycle": 1000,  
        "gpsCdsExt": 0.0,  
        "fhposDeviationWarn": 5.0,  
        "maxSnowfall": 2.0,  
        "minCruisingSpeed": 50.0,  
        "lifespanFlyMileage": 1000.0,  
        "isDelete": "N",  
        "mhposDeviationWarn": 4.0,  
        "mvposDeviationRemind": 0.8,  
        "gpsLimitDistance": 20.0,  
        "regComp": "FCC",  
        "maxOperatingHumidity": 99.0,  
        "cruisingSpeed": 14.0,  
        "recVupSpeed": 2.2,  
        "updateEmp": "80000934",  
        "typeCode": "ARK40",  
        "typeVersion": "P2",  
        "maxProtectBoundaryRadius": 300,  
        "maxTakeoffWeight": 30.0,  
        "priorLandingWait": 600,  
        "fvposDeviationWarn": 5.0,  
        "updateTm": "2024-09-25 15:25:00",  
        "gpsLimitHeight": 40.0,  
        "priorLandingElec": 15000,  
        "gpsCruiseCapsuleLowerh": 10.0  
    }  
]  
}
```

设置无人机占用空域开关

接口编号：INT_UAV_249

接口地址：/uocs-uav/aircraft/setAirspaceState

方法：POST

标签：地面站接口

请求示例：

```
{  
    "airRouteId": 1006,  
    "requestDate": "594790683",  
    "requestId": "594790683"  
}
```

响应示例：

地面站下载translateFile.json文件

接口编号：INT_UAV_235

接口地址：/uocs-uav/aircraftFault/downloadTranslateFile

方法：GET

标签：地面站接口

请求示例：

```
{  
}
```

响应示例：(translateFile.json)



translateFileInfo.zip
0.2MB

地面站获取机型Json文件MD5

接口编号：

接口地址：/uocs-uav/aircraftFault/getAircraftTypeJsonMd5

方法：GET

标签：地面站接口

请求示例：

```
{  
}
```

响应示例：(translateFile.json)

```
{  
  "requestId": null,  
  "success": true,  
  "business": null,  
  "errorCode": null,  
  "errorMessage": null,  
  "params": null,  
  "date": "2024-10-18 17:31:35",  
  "version": "1.0",  
  "obj": {  
    "md5": "cb56960247741a768c31eaf6fe17bf82" //获取机型文件MD5值  
  }  
}
```

uocs-eas

查询无人机故障信息

接口编号：INT_EAS_040

接口地址：/uocs-eas/access/selectUavFaultInfoList

方法：POST

标签：地面站接口

请求示例：

```
{
    "comNum": 9310,                //无人机编号
    "requestDate": "1794291126",
    "requestId": "1794291126",
    "type": 0                      //0:实时故障 1：历史故障
}
```

响应示例：

```
{
    "id": 123,
    "flySource": 1,                //1-运营|2-飞行
    "comNum": 9310,                //无人机编号
    "type": 2,                     //故障类别 0:紧急 2:危机 3:错误 4:警告 5:通知
    "sourceCode": "S_1",           //错误源
    "status": 1,                   //故障状态 0：故障恢复 1：有故障
    "faultCode": "F001",           //故障编码
    "startTm": "2023-10-01T10:00:00", //故障开始时间
    "endTm": "2023-10-01T11:00:00",  //故障结束时间
    "reportTm": "2023-10-01T10:15:00", //故障上报时间
    "flightId": 789012345678        // 航班ID
}
```

查询接入机列表

接口编号：INT_EAS_041

接口地址：/uocs-eas/access/selectAccessList

方法：POST

标签：地面站接口

请求示例：

```

{
    "area": 1, //区域: 1 (数据流物理隔离基本已废弃)
    "requestDate": "371562753",
    "requestId": "371562753",
    "serviceType": 10 //10: 地面站 | 14: 基站
}

```

响应示例：

```

{
    "requestId": null,
    "success": true,
    "business": null,
    "errorCode": null,
    "errorMessage": null,
    "params": null,
    "date": "2024-10-28 15:24:17",
    "version": "1.0",
    "obj": [
        {
            "id": 4,
            "type": 1,
            "serviceType": 10, //地面站标记
            "area": "1", //区域id(暂时无任何作用)
            "insideIp": "10.206.230.253", //内网IP
            "insidePort": 10881, //内网端口
            "outsideIp": "101.52.239.165", //公网IP
            "outsidePort": 10888, //公网IP端口
            "outsideUdpPort": 10881, //公网UDP端口
            "topic": "UOCS_ACCESS_TOPIC_1", //数据存储主题
            "enabled": 1, //节点是否可用
            "connLimit": 100, //连接数据限制
            "createEmp": "01304522", //创建人工号
            "createTm": "2020-11-11 16:31:40", //创建时间
            "updateEmp": "881822", //更新人工号
            "updateTm": "2024-10-28 15:23:46", //更新时间
            "connNum": 2, //当前连接数量
            "connUsers": "[4294902021,4294902097]" //连接地面站qgcNumber编号
        },
        {
            "id": 3,
            "type": 1,
            "serviceType": 10,
            "area": "1",
            "insideIp": "10.206.230.169",

```

```
        "insidePort": 10881,
        "outsideIp": "101.52.239.165",
        "outsidePort": 10887,
        "outsideUdpPort": 10881,
        "topic": "UOCS_ACCESS_TOPIC_1",
        "enabled": 1,
        "connLimit": 100,
        "createEmp": "01304522",
        "createTm": "2020-11-11 16:31:02",
        "updateEmp": "881822",
        "updateTm": "2024-10-28 15:23:46",
        "connNum": 5,
        "connUsers": "[4294902023,4294902081,4294902084,4294902025,4294
902068]"
    }
}
]
```

uocs-sys

发送验证码

接口编号：INT_SYS_113

接口地址：/uocs-sys/auth/getVerifyCode

方法：POST

标签：地面站接口

请求示例：

```
-- 特别说明：请求参数接口是个map，参数是任意动态变化的
{
    "appKey": "IE-UOCS-QGC",           //网关appkey
    "appSecret": "sf123456",           //网关appSecret
    "phone": "18682193031",            //发送验证码的手机号
    "requestDate": "882638290",        //请求日期
    "requestId": "882638290",          //请求类型
    "verifyType": "0"                  //0:是正常的获取验证码| 1:异地登录的验证码 | 其它值根据工号发送对应的手机号验证码
}
```

响应示例：

```
{
    "id": 123,
    "flySource": 1,                      //1-运营|2-飞行
    "comNum": 9310,                      //无人机编号
    "type": 2,                          //故障类别 0:紧急 2:危机 3:错误 4:警告 5:通知
    "sourceCode": "S_1",                //错误源
    "status": 1,                        //故障状态 0:故障恢复 1:有故障
    "faultCode": "F001",                //故障编码
    "startTm": "2023-10-01T10:00:00",   //故障开始时间
    "endTm": "2023-10-01T11:00:00",    //故障结束时间
    "reportTm": "2023-10-01T10:15:00",  //故障上报时间
    "flightId": 789012345678           // 航班ID
}
```

uocs-pfs

根据mantis bug id编号获取问题相关信息

接口编号：INT_PFS_038

接口地址：/uocs-pfs/issue/qgc/detail

方法：POST

标签：地面站接口

请求示例：

```
{
    "bugId": "4019",
    "requestDate": "597756392",
    "requestId": "597756392"
}
```

响应示例：

```
{
  "requestId": null,
  "success": true,
  "business": null,
  "errorCode": null,
  "errorMessage": null,
  "params": null,
  "date": "2024-10-28 14:08:09",
  "version": "1.0",
  "obj": {
    "summary": "后台起降场RTK坐标突然清空，第一次新建起降场都设置了RTK坐标", //问题摘要
    "submitName": "黄毅", //提交人姓名
    "submitter": "42158429", //提交人工号
    "bugId": "25629", //mantis问题id
    "uavNo": "0", //无人机编号
    "happenTime": "2024/10/19 17:45" //发生时间
  }
}
```