# Chapter 7 Water Supply

Municipal water supply systems

commercia

fire fighting + losses

\* Water quantity and quality  $\rightarrow$  selection of feasible sources



## M


## Factors affecting water use:

- climate → more water is consumed in warmer climates
- characteristics of population → socio-economic status
- population size → per capita use is bigger in big cities due to greater industrial use, more parks, etc.
- @ life standards → US (500 L/cap/day) versus Turkey (100 L/cap/day)
- environmental concerns
  - water quality
  - sustainable development
  - use of flow reduction devices
  - reuse of waste water
- @ water rates and metering  $\rightarrow$  cost of water  $\uparrow$ es consumption  $\downarrow$ es
- $\bigcirc$  industry and commerce  $\rightarrow$  1 ton of paper consumes 250 m<sup>3</sup> water
- operating pressures

## м

## Design steps of municipal water supply systems:

- 1. Estimation of future population and total demand
- 2. Examination of sources of water supply \( \squality \& quantity \)
- 3. Examination of storage facilities
- 4. Design of storage and transmission facilities
  - dam(s)
  - municipal water supply systems
    - transmission lines
    - city network
- 5. Water treatment and quality control
- 6. Construction of the system
  - use of sound and proper material
  - minimization of water loss = f(type, age, operating pressure)
- 7. Establishment of operational organization





System should meet future demands

Life time of the system? = f(type of system, availability of techn., mat'l.s, econ. factors)

- Future demand (D) ⇔ good quality supply (S)
- Municipal Water Requirements:
  - domestic use (L/cap/day) drinking and sanitary purposes
  - public use schools, hospitals, parks
  - commercial and industrial uses ex: textile, food
  - use for fire fighting

municipal demand

М

@ Future demand forecasting  $\Rightarrow$  population estimation

End of life time of project,  $t_n$ 



Projected population, Pn

- Factors to be considered in population estimation:
  - Topographic and climatic conditions
  - Socio-economic facilities available in the city
- may impact migration

- Past records of census results
- Population growth rate & characteristics of community



## Population estimation methods

- 1- Arithmetic extrapolation
- 2-Geometric (logarithmic) extrapolation  $\leftarrow$  good for communities 3-) The Turkish Bank of Provinces method with large resources
  - 4- Mathematical curve fitting method
  - 5- Logistic S-curve method
  - 6- Decreasing rate of increase method
  - 7- Ratio and correlation method
  - 8- Component method
  - 9- Employment forecasts


### Before selecting the population projection method:

- examine previous census records
- socio-economic developments in the region

and power



## Population growth phases in settlements



facilities are limited to support population growth beyond a certain value, the population growth follows a declining phase & the population tends to a saturation value, P<sub>sat</sub>

Idealized Growth Pattern




## Arithmetic Extrapolation Method

Rate of population growth is constant

$$\frac{dP}{dt} = K_a$$
 constant

$$K_a = \frac{P_2 - P_1}{t_2 - t_1}$$

$$P_n = P_2 + K_a(t_n - t_2)$$
projected population





## Geometric Extrapolation Method


$$\frac{dP}{dt} = K_g P$$

rate of change of population is assumed to be proportional to the population

$$K_g = \frac{lnP_2 - lnP_1}{t_2 - t_1}$$

$$\int_{P_2}^{P_n} \frac{dP}{P} = K_g \int_{t_2}^{t_n} dt$$

$$lnP_n = lnP_2 + K_g(t_n - t_2)$$





## Turkish Bank of Provinces Method

$$P_n = P_2 \left( 1 + \frac{k}{100} \right)^{35+n}$$

$$k = \left(\sqrt[t_2-t_1]{\frac{P_2}{P_1}} - 1\right) * 100$$

lifetime of the project


P<sub>n</sub> = population at the end of the life time of the project k = growth rate factor

n = number of years between the last census and beginning of project

$$k=3$$
 if  $k \ge 3$ 

$$k=1$$
 if  $k \leq 1$ 

k is as it is if 1 < k < 3



## Average total demands


daily average demand


P <sub>n</sub>	D <sub>ad</sub> (It/cap/day)	(lt/s)
3000	60	2.1
$\frac{60 L}{cap.day} \times 3000 \ ca$	$p \times \frac{1 \ day}{24 \ hr} \times \frac{1 \ hr}{60 \ min} \times$	$\frac{1  min}{60  \sec} = 2.1  L/\sec$
50000	120	69.4
100000	170	196.8
500000	230	1330.0
1000000	280	3240.0
2000000	330	7640.0
3000000	370	12850.0




### Hourly, daily, monthly fluctuations in water use depend on:

- climatic conditions
- size of the urban area
- @ socio-economical structure of community





Dec.31



$$(P.F.)_{day} = \frac{D_{md}}{D_{ad}}$$

Jan.1

$$(P.F.)_{hour} = \frac{D_{mh}}{D_{ah}}$$

(P.F.)<sub>day</sub> = daily peak factor

 $D_{md}$  = maximum daily demand  $D_{ad}$  = average daily demand

(P.F.)<sub>hour</sub> = hourly peak factor

 $D_{mh}$  = maximum hourly demand

 $D_{ah}$  = average hourly demand



## Elements of municipal water supply systems

Water is conveyed from a source(s):

- e storage reservoir(s)
- @ river(s)
- @ fresh water lake(s)
- groundwater
- @ sea

to community mainly in closed conduits because of:

- The requirement of pressurized flow
- Less likelihood of pollution



#### • Use of closed conduits:

- requirement for pressurized flow
- environmental concerns


### • Necessary energy for flow:

- Gravity ← when source is located substantially above the level of the city
- pumping
- # gravity + pumping ← In Ankara there are over 60
  pumping stations & distribution reservoirs

#### @ Selection of suitable conduits and routes:

- topography
- available materials
- economy





Transmission line is designed to carry

$$D_{md} = D_{ad} * (P.F)_{day}$$

Main feeder is designed to carry


$$D_{mh} = D_{ad}*(P.F)_{day}*(P.F)_{hour}$$

Codes of the Turkish Bank of Provinces

D<sub>md</sub> for the transmission line D<sub>md</sub> + fire discharge for the main feeder

#### Are designed to

- meet hourly fluctuations
- store water for fire fighting
- stabilize pressures in the distribution system






A water distribution network is composed of:

Receives water from the main feeder

& delivers it to individual consumers


- pipes
- valves
- hydrants
- pumps
- distribution (service) reservoirs
- Oistribution by: gravity and/or pumping
- Pumping without storage is not desirable emergency use like fires or repair works?
- Pumping with storage is desirable






## Types of distribution network:

- a) a branching pattern with dead ends
- b) a gridiron pattern with central feeder





### Distribution Reservoirs

- In large cities (P > 100000)
- Pumping stations and distribution (service) reservoirs are operated in conjunction with each other
- Pressure requirements dictate level of interference!
  - Pumping schedule  $\Rightarrow$  capacity of distribution reservoir
  - a) Pumping of  $D_{ad}$  24 hours  $\Rightarrow$  Small capacity  $\Rightarrow$  Not feasible!
  - b) Pumping during off-demand hours

Greater capacity  $\Rightarrow$  Feasible


Location of the distribution reservoir → should be located close to the center of use.

## M


## Types of distribution reservoir

- elevated tanks
- buried reservoirs
- stand pipe

Usually reinforced-concrete used Circular x-section
Top is sloped for proper drainage



Buried reservoir





- @ Maximum capacity: Cylindrical container
- Capacity determination:
  - a) Storage to meet hourly fluctuations:
    - 1. Obtain demand values of maximum demand day
    - 2. Apply mass curve technique
  - b) Required storage to put out a fire
  - c) Storage to meet emergencies
- No additional volume if a and b are considered jointly

$$P \le 10\ 000$$
,  $C_{\rm fire} = 36\ {
m m}^3$   $C_{\rm fire} = 72\ {
m m}^3$   $C_{\rm fire} = 7000$ ,  $C_{\rm fire} = 700$   $C_{\rm fire} = 360\ {
m m}^3$   $C_{\rm fire} = 360\ {
m m}^3$ 



### Pipe material should be strong enough to resist:

- \* the forces produced by the static pressure of water
- centrifugal forces at the bends
- external loads like soil load and traffic load
- changes in temperature
- water hammer

### Pipe materials:

- reinforced concrete
- asbestos cement
- ductile iron
- steel
- plastic

Each type of material pipe is available at different sizes & can take different pressures & stresses



#### Ductile iron pipes

have high durability and long life subject to corrosion! ⇒interior coating with cement

#### Steel pipes

in cases with large D and (P/ $\gamma$ ) buckling under high negative pressures coating  $\Rightarrow$  resistance for corrosion and buckling

## Reinforced concrete pipes

used in large projects carry excessive stresses no corrosion problem Corrosion: a process in which a metal is converted into salts or oxides with a loss of mechanical strength



#### Asbestos cement pipes

extremely smooth inner surfaces
limited use cancerous effect of asbestos fibers

#### Plastic pipes

highly smooth and light require a small diameter easily installed and removed limited use according to the project size



#### Valves

Flow regulation and isolation

```
* sluice or gate valves - Used to isolate flow esp. during repairs
```

- \* butterfly valves —— Usually used at the exit of distribution
- \* check valves —

reservoirs for regulation and isolation purposes

To stop flow automatically in the reverse direction

### Hydrants


Withdrawal of pressurized flow for fires



### Construction & maintenance of water supply systems

### • Laying of pipes:

- need for stiff foundation to limit settlement
- excavation of trenches
- transportation & handling of pipes & appurtenances
- backfilling and repaving
- avoid sharp curvatures
- bends should be blocked
- The depth of burial of pipes
  - depth of frost line
  - external loads acting on the pipe






## Hydraulic design criteria

 $\bigcirc$  velocity:  $0.5 \text{ m/s} \le u \le 2.0 \text{ m/s}$ 

@ pressure:  $3-5 \text{ m} \leq P/\gamma \leq 80 \text{ m} \rightarrow \text{transmission line}$ 


**Q** 20 - 30 m  $\leq$  P/ $\gamma \leq$  80 m

→ city network



## .

## Hydraulics and Operation of Gravity Pipelines





## The energy equation between points A and B:

$$H_A + z_A + \frac{P_A}{\gamma} + \frac{u_A^2}{2g} = z_B + \frac{u_B^2}{2g} + \frac{P_B}{\gamma} + h_f$$

 $P_A = P_B = 0$ ,  $z_B = 0$ , and  $u^2/2g \approx 0$  for u < 2.0 m/s:

$$H_A + z_A = h_f$$

Using Darcy-Weisbach equation:


$$H_A + z_A = \frac{8fL}{g\pi^2 D^5} Q^2$$



#### For given f, L, and D:

$$H_A + z_A = KQ^2$$

$$Q_{max} = \left(\frac{H_{max} + z_A}{K}\right)^{1/2} \qquad Q_0 = \left(\frac{H_{max} + z_A}{K}\right)^{1/2}$$



$$Q_0 = \left(\frac{z_A}{K}\right)^{1/2}$$

 $Q_0$  is minimum pressurized flow rate.

When Q>Q<sub>max</sub>, Q-Q<sub>max</sub> spills

When  $Q < Q_0$ , open channel flow! (use exit valve)


$$H_A + z_A = KQ^2 + H_v$$

## ۲

#### Air entrainment

Consider a gravity pipeline with L=5000 m, f=0.02, and  $\phi$ 1000 for all pipes.


Energy equation between points A and D gives  $Q=1.1 \text{ m}^3/\text{s}$  (!!!)




a) Air suction due to negative pressure

M

Air or surrounding groundwater is sucked into the pipeline through the joints and  $H_c$  will rise to atmospheric value ( $H_c$ =115 m and Q=0.95 m<sup>3</sup>/s)




b) Air blockage from dissolved air




c) Air free operation


## Air-relief valve



## Example 23

- The following transmission line is analyzed. In the problem, consider the following criterion: 0.5 m/s  $\le$  u  $\le$  2.0 m/s and 3 m  $\le$  P/y  $\le$  80 m. Take f = 0.02, D = 0.15 m, and L = 2000 m for all pipes.
- 1. It is desired to keep the water surface elevation at 207 m in the upper reservoir. Determine the discharge that can pass through this system. Determine also the maximum pressure head in the pipeline system.
- 2. Determine the minimum possible pressurized flow rate that can pass through this system. Determine also the headloss at the exit valve.
- 3. Determine the maximum possible discharge to be transmitted through this system. Find the population of the settlement, which is served by this discharge of this system. The daily and hourly peak factors are 1.5 and 2.5, respectively.





a)

$$h_{LAB} = h_{LBC} = h_{LCD} = h_{L}$$
  $h_{L} = 7 \text{ m}$ 

$$h_L = [ (8*f*L) / (\pi^2*g*D^5) ] * Q^2$$

$$A = \pi^* D^2 / 4$$

$$A = 0.018 \text{ m}^2$$

7 = [ 
$$(8.0.02*2000) / (\pi^2*9.81*0.15^5)$$
 ] \* Q<sup>2</sup>

$$Q = 0.013 \text{ m}^3/\text{s} = 13 \text{ lt/s}$$

 $Q = 0.013 \text{ m}^3/\text{s} = 13 \text{ lt/s}$  Max pressure is at B = 70 m

$$V = Q / A = 0.722 \text{ m/s} OK!$$

b)

Minimum velocity = 0.5 m/s

$$Q_{min} = 0.5 * 0.018 = 0.009 \text{ m}^3/\text{s} = 9 \text{ lt/s}$$

$$193 + h_{LBC} + h_{LAB} = H_{res}$$

$$H_{res} = 193 + 2 * h_L = 200 m NOT OK!$$

$$H_{res} = 203$$
 (min. value)  $203 - 193 = 2 * h_L$ 

$$h_L = 5 \text{ m} \rightarrow Q_{min} = 0.011 \text{ m}^3/s = 11 \text{ lt/s}$$

$$H_{CD} = 193 - h_{LCD} = 193 - 5 = 188 \text{ m}$$

c)

Maximum velocity = 2 m/s

$$Q_{max} = 2 * 0.018 = 0.036 \text{ m}^3/\text{s} = 36 \text{ lt/s}$$

$$H_{res} = 193 + h_{LAB} + h_{LBC}$$


$$h_L = [(8*0.02*2000) / (\pi^2*9.81*0.15^5)] * 0.036^2 = 56 m$$

NOT POSSIBLE !!!  $H_{res}$  cannot be greater than 211 m

$$211 - 193 = h_{LAB} + h_{LBC}$$

$$h_1 = 9 \rightarrow Q_{max} = 0.0143 \text{ m}^3/\text{s} = 14.3 \text{ lt/s}$$

Example 24 A water transmission system is shown below. 20 lt/s enters to reservoir A and 5 lt/s is withdrawn along the line at points B and C.




- a) Find and draw the piezometric line along the system when the valve at point D is fully open. Compute piezometric elevations at A, B, C and D.
- b) Find the necessary amount of head loss in the valve at point D to avoid air entrainment problem,  $(P_{min}/\gamma) = 3 \text{ m}$ .
- c) Assuming no flow is withdrawn at B and C, find the maximum discharge that can be conveyed from reservoir A to reservoir D.

Solution:

a)

$$h_{f_{AB}} = 0.02 * \frac{1500}{0.2} * \frac{0.020^{2}}{\left(\frac{\pi * 0.2^{2}}{4}\right)^{2}} * \frac{1}{2 * 9.81} = 3.10m$$


$$h_{f_{BC}} = 0.02 * \frac{500}{0.15} * \frac{0.015^{2}}{\left(\frac{\pi * 0.15^{2}}{4}\right)^{2}} * \frac{1}{2 * 9.81} = 2.45m$$



340


D

b)




$$H_A = h_{valve} + 3.10 + 2.45 + 16.52 + 340$$

$$h_{valve} = 35.93m$$




Q = 18 lt/s

## Design of Gravity Transmission lines



$$S_{min} = \frac{H_A - (z_c + P_{min}/\gamma)}{L_{AC}}$$





Choose one next size available at market

$$u = \frac{Q}{A} = \frac{4Q}{\pi D^2}$$

If  $u_{min}$  u u then O.K.



## If u<u<sub>min</sub>, place a booster pump

$$\mathbf{H}_{\mathbf{A}} + \mathbf{H}_{P} = z_{C} + \frac{P_{min}}{\gamma} + f \frac{L}{D} \frac{u_{min}^{2}}{2g}$$

If u>u<sub>max</sub>

Compute new D from

$$\frac{\pi D^2}{4} \times u_{max} = Q$$

Install a pressure reduction valve if necessary

Repeat the same procedure for C-D-E and E-F separately

- w
  - $\bigcirc$  Maintenance & operation  $\rightarrow$  Governmental organization
  - © City maps: location of pipes, hydrants, valves, etc.
  - Periodic records
    - for monitoring situation of pipes
    - detecting the excessive leakage
  - The pipeline system should be
    - as watertight as possible
    - tested against leakage under pressure
    - disinfected periodically