

ESB-05_2-2 1/200 ↑ → 1/200 REFERANCE ELEVATION=145	150							150
KIRMIZI KOT	145	148.100	148.100	148.100	148.100	148.100	148.100	145
EXISTING SURFACE	149.697	149.684	149.676 -	149.678	149.671	149.662	149.628	149.600
STATION	0+00:000	0+002:000	0+010.000	0+015.000 -	0+020.000-	0+025.000 -	0+030.000-	_0+034.000_

	155																<u></u> 155
<b>ESB-05_A-A</b> 1/200 ↑	150												//////		7/////	///////////////////////////////////////	150
→ 1/200 REFERANCE ELEVATION=145	145		ı		ı		ı		ı		T		T		ı		<u></u> 14
KIRMIZI KOT			148.100	148.100	148.100	148.100	148.100	148.100	148.100	148.100	148.100	148.100	148.100	148.100	148.100	148.100	
EXISTING SURFACE	7 () ()	000000000000000000000000000000000000000	150.530 -	150.411-	150.292 -	150.174 -	150.055 -	149.928 -	149.775 -	149.614	149.471-	149.329 -	149.187	149.044 -	148.899	148.749 -	148.600
STATION		000.000+0	0+002.000 -	0+010.000-	0+015.000 -	0+020.000-	0+025.000 -	0+030.000-	0+035.000 -	0+040.000-	0+045.000 -	0+050.000-	0+055.000-	0+060.000-	0+065.000-	0+070.000 -	0+075.000

	155 -	-								<b>⊤155</b>
ESB-05_B-B 1/200 ↑ → 1/200 REFERANCE ELEVATION=145	150									150
KIRMIZI KOT	145	148.100	148.100	148.100	148.100	148.100	148.100	148.100	148.100	145
EXISTING SURFACE	7 C C Z	150.127	150.013	149.888 -	- 149.751-	- 149.613	- 149.474 -	149.332 -	149.191	149.050
STATION	() () () ()	000000000000000000000000000000000000000	0+010.000	0+015.000 -	0+050.000	0+025.000 -	0+030.000-	0+035.000-	0+040.000 -	0+045.000

ESB-05_3-3 1/200 ↑ → 1/200 REFERANCE ELEVATION=145	150 —	\/////		
KIRMIZI KOT	145	148.100	148.100	145
EXISTING SURFACE	148.889	148.906 -	148.921	148.929
STATION	000:000+0	0+002.000 -	0+010.000 -	0+015.000

