Calculation Results

INCOMPLETE — provisional study

System: Sample Substation Bay

Voltage: 125.0 V

Highest peak on one DC supply: Incomplete study (not available)

Loads

Load	Quantity	Current per unit	Total current	Note
52-1 - Trip Coil 1	1	12 A	12 A	breaker:breaker_1; Primary trip; DC 1

Calculation Steps

1. Group actions by zone and operating stage.
2. Count each physical coil or motor once per stage; multiply entered current by the verified unit count.
3. Sum currents per DC supply within each stage, then take each supply's maximum across complete zones.
4. Stages and separate zone faults are not added together. Flagged zones have provisional results only.

Evaluation Output

```
Momentary DC protection-zone study: Sample Substation Bay
INCOMPLETE — configure/review flagged zones; partial totals are not final.
Each configured zone is a separate fault event. Same-stage loads are
simultaneous; other stages are separate.
DC supplies are reported separately. No battery amp-hour calculation.

BUS-1 Bus Zone (Bus)
  CT boundaries: ct:ct_1
  Equipment: breaker:breaker_1, bus:bus_1, ct:ct_1
  REVIEW: Confirm this zone's CT boundaries, operating loads, stages, DC
supplies and units.
  Provisional Primary trip: 12 A across assigned supplies
    DC 1: 12 A
    52-1 - Trip Coil 1: 12 A × 1 = 12 A (DC 1)

Detected topology regions (not automatically added to the calculation):
  Primary region: GND-1 (enclosed; 1 conductors)
  Primary region: 52-1, BUS-1 (enclosed; 2 conductors)
  Composite region: 52-1, BUS-1, CT-1 ... (outermost; 3 conductors)

Peak per supply among confirmed, complete configured zones:
  Not available until zone assignments and currents are complete.
```