# Furhat Setup How-To

Connect to Furhat and get Interface

In your browser, connect to the following IP to get to the Furhat interface like the one for the virtual furhat:
http://192.168.0.9/

Running skill directly from IntelliJ (preferred)

To get to the Edit Config Window, click on the down arrow next to main.kt (not the green one)


Paste the following in the run config for main.kt in the VM field (with the -): -Dfurhatos.skills.brokeraddress=192.168.0.9

Alternative: Packing and uploading skill

To the right in the Gradle Tab, find and run the Shadowjar task. Look for the skill file on your computer. Should be named furhatinterviewrobot-all.skill (or very similar, can't remember). Upload it via the furhat interface and run.

Let's go!

Start the audio recording on your external recording program then start skill.