

Open CASCADE Technology 7.2.0

Visualization

August 30, 2017

CONTENTS 1

# **Contents**

1	Intro	duction	1	3			
2	Fundamental Concepts						
	2.1	Presen	ntation	5			
		2.1.1	Structure of the Presentation	5			
		2.1.2	Presentation packages	5			
		2.1.3	A Basic Example: How to display a 3D object	6			
	2.2	Selecti	on	6			
		2.2.1	Terms and notions	7			
		2.2.2	Algorithm	9			
		2.2.3	Packages and classes	12			
		2.2.4	Examples of usage	13			
_	A I		Internation Comitee	40			
3			Interactive Services	16			
3.1			oction	16			
	3.2		tive objects	16			
		3.2.1	Presentations	16			
		3.2.2	Hidden Line Removal	17			
		3.2.3	Presentation modes	18			
		3.2.4	Selection	19 19			
		3.2.5	Complementary Services	20			
		3.2.6					
		_	Object hierarchy	21			
	0.0	3.2.8	Instancing	21			
	3.3		tive Context	23			
		3.3.1	Rules	23			
		3.3.2	Groups of functions	24			
	0.4	3.3.3	Management of the Interactive Context	24			
	3.4	3.4.1	Selection	24 24			
		3.4.1	Selection Modes				
		_	Filters	25 25			
	3.5	3.4.3	Selection				
	3.5	3.5.1	ard Interactive Object Classes	26 27			
		3.5.2	Object	27			
		3.5.3	Relations	29			
				29			
	0.0	3.5.5	MeshVS_Mesh	29			
	3.6 Dynamic Selection			31			

CONTENTS

4	3D P	resenta	ations	32
	4.1	Glossa	ry of 3D terms	32
4.2		Graphi	c primitives	32
		4.2.1	Structure hierarchies	33
		4.2.2	Graphic primitives	33
		4.2.3	Primitive arrays	33
		4.2.4	Text primitive	34
		4.2.5	Materials	35
		4.2.6	Textures	35
		4.2.7	Shaders	35
	4.3	Graphi	c attributes	36
		4.3.1	Aspect package overview	36
	4.4	3D viev	w facilities	36
		4.4.1	Overview	36
		4.4.2	A programming example	36
		4.4.3	Define viewing parameters	37
		4.4.4	Orthographic Projection	38
		4.4.5	Perspective Projection	38
		4.4.6	Stereographic Projection	39
		4.4.7	View frustum culling	40
		4.4.8	View background styles	41
		4.4.9	Dumping a 3D scene into an image file	41
		4.4.10	Ray tracing support	42
		4.4.11	Display priorities	42
		4.4.12	Z-layer support	43
		4.4.13	Clipping planes	44
		4.4.14	Automatic back face culling	45
	4.5	Examp	lles: creating a 3D scene	45
		4.5.1	Create attributes	45
		4.5.2	Create a 3D Viewer (a Windows example)	46
		4.5.3	Create a 3D view (a Windows example)	46
		4.5.4	Create an interactive context	47
		4.5.5	Create your own interactive object	47
		4.5.6	Create primitives in the interactive object	47
_	Maal	h Vieus	lization Services	49
	IVIE S	v. SIIA	11/ 01 11 11 1 1 1 1 1 1 1 1 1 1 1 1 1 1	

1 Introduction 3

## 1 Introduction

Visualization in Open CASCADE Technology is based on the separation of:

• on the one hand – the data which stores the geometry and topology of the entities you want to display and select, and

• on the other hand – its **presentation** (what you see when an object is displayed in a scene) and **selection** (possibility to choose the whole object or its sub-parts interactively to apply application-defined operations to the selected entities).

Presentations are managed through the **Presentation** component, and selection through the **Selection** component.

**Application Interactive Services** (AIS) provides the means to create links between an application GUI viewer and the packages, which are used to manage selection and presentation, which makes management of these functionalities in 3D more intuitive and consequently, more transparent.

AIS uses the notion of the *Interactive Object*, a displayable and selectable entity, which represents an element from the application data. As a result, in 3D, you, the user, have no need to be familiar with any functions underlying AIS unless you want to create your own interactive objects or selection filters.

If, however, you require types of interactive objects and filters other than those provided, you will need to know the mechanics of presentable and selectable objects, specifically how to implement their virtual functions. To do this requires familiarity with such fundamental concepts as the Sensitive Primitive and the Presentable Object.

The the following packages are used to display 3D objects:

- AIS;
- · StdPrs;
- Prs3d;
- · PrsMgr,
- V3d;
- · Graphic3d.

The packages used to display 3D objects are also applicable for visualization of 2D objects.

The figure below presents a schematic overview of the relations between the key concepts and packages in visualization. Naturally, "Geometry & Topology" is just an example of application data that can be handled by *AIS*, and application-specific interactive objects can deal with any kind of data.

1 Introduction 4




Figure 1: Key concepts and packages in visualization

To answer different needs of CASCADE users, this User's Guide offers the following three paths in reading it.

- If the 3D services proposed in AIS meet your requirements, you need only read chapter 3 AIS: Application Interactive Services.
- If you need more detail, for example, a selection filter on another type of entity you should read chapter 2 Fundamental Concepts, chapter 3 AIS: Application Interactive Services, and 4 3D Presentations. You may want to begin with the chapter presenting AIS.

For advanced information on visualization algorithms, see our E-learning & Training offerings.

# 2 Fundamental Concepts

### 2.1 Presentation

In Open CASCADE Technology, presentation services are separated from the data, which they represent, which is generated by applicative algorithms. This division allows you to modify a geometric or topological algorithm and its resulting objects without modifying the visualization services.

#### 2.1.1 Structure of the Presentation

Displaying an object on the screen involves three kinds of entities:

- · a presentable object, the AIS\_InteractiveObject
- · a viewer
- an interactive context, the AIS\_InteractiveContext.

#### The presentable object

The purpose of a presentable object is to provide the graphical representation of an object in the form of *Graphic3d* structure. On the first display request, it creates this structure by calling the appropriate algorithm and retaining this framework for further display.

Standard presentation algorithms are provided in the *StdPrs* and *Prs3d* packages. You can, however, write specific presentation algorithms of your own, provided that they create presentations made of structures from the *Graphic3d* packages. You can also create several presentations of a single presentable object: one for each visualization mode supported by your application.

Each object to be presented individually must be presentable or associated with a presentable object.

#### The viewer

The viewer allows interactively manipulating views of the object. When you zoom, translate or rotate a view, the viewer operates on the graphic structure created by the presentable object and not on the data model of the application. Creating Graphic3d structures in your presentation algorithms allows you to use the 3D viewers provided in Open CASCADE Technology for 3D visualisation.

### The Interactive Context

The interactive context controls the entire presentation process from a common high-level API. When the application requests the display of an object, the interactive context requests the graphic structure from the presentable object and sends it to the viewer for displaying.

#### 2.1.2 Presentation packages

Presentation involves at least the *AIS*, *PrsMgr*, *StdPrs* and *V3d* packages. Additional packages, such as *Prs3d* and *Graphic3d* may be used if you need to implement your own presentation algorithms.

- AIS package provides all classes to implement interactive objects (presentable and selectable entities).
- *PrsMgr* package provides low level services and is only to be used when you do not want to use the services provided by AIS. It contains all classes needed to implement the presentation process: abstract classes *Presentation and PresentableObject* and concrete class *PresentationManager3d*.
- StdPrs package provides ready-to-use standard presentation algorithms for specific geometries: points, curves and shapes of the geometry and topology toolkits.

Prs3d package provides generic presentation algorithms such as wireframe, shading and hidden line removal
associated with a Drawer class, which controls the attributes of the presentation to be created in terms of
color, line type, thickness, etc.

- V3d package provides the services supported by the 3D viewer.
- Graphic3d package provides resources to create 3D graphic structures.
- Visual3d package contains classes implementing commands for 3D viewer.
- DsgPrs package provides tools for display of dimensions, relations and XYZ trihedrons.

#### 2.1.3 A Basic Example: How to display a 3D object

```
Handle(V3d_Viewer) theViewer;
Handle(AIS_InteractiveContext) aContext = new AIS_InteractiveContext (theViewer);

BRepPrimAPI_MakeWedge aWedgeMaker (theWedgeDX, theWedgeDY, theWedgeDZ, theWedgeLtx);
TopoDS_Solid aShape = aWedgeMaker.Solid();
Handle(AIS_Shape) aShapePrs = new AIS_Shape (aShape); // creation of the presentable object aContext->Display (aShapePrs); // display the presentable object in the 3d viewer
```

The shape is created using the *BRepPrimAPI\_MakeWedge* command. An *AIS\_Shape* is then created from the shape. When calling the *Display* command, the interactive context calls the Compute method of the presentable object to calculate the presentation data and transfer it to the viewer. See figure below.




Figure 2: Processes involved in displaying a presentable shape

#### 2.2 Selection

Standard OCCT selection algorithm is represented by 2 parts: dynamic and static. Dynamic selection causes objects to be automatically highlighted as the mouse cursor moves over them. Static selection allows to pick

particular object (or objects) for further processing.

There are 3 different selection types:

- Point selection allows picking and highlighting a single object (or its part) located under the mouse cursor;
- Rectangle selection allows picking objects or parts located under the rectangle defined by the start and end mouse cursor positions;
- Polyline selection allows picking objects or parts located under a user-defined non-self-intersecting poly-

For OCCT selection algorithm, all selectable objects are represented as a set of sensitive zones, called **sensitive entities**. When the mouse cursor moves in the view, the sensitive entities of each object are analyzed for collision.

#### 2.2.1 Terms and notions

This section introduces basic terms and notions used throughout the algorithm description.

#### Sensitive entity

Sensitive entities in the same way as entity owners are links between objects and the selection mechanism.

The purpose of entities is to define what parts of the object will be selectable in particular. Thus, any object that is meant to be selectable must be split into sensitive entities (one or several). For instance, to apply face selection to an object it is necessary to explode it into faces and use them for creation of a sensitive entity set.




Figure 3: Example of a shape divided into sensitive entities

Depending on the user's needs, sensitive entities may be atomic (point or edge) or complex. Complex entities contain many sub-elements that can be handled by detection mechanism in a similar way (for example, a polyline stored as a set of line segments or a triangulation).

Entities are used as internal units of the selection algorithm and do not contain any topological data, hence they have a link to an upper-level interface that maintains topology-specific methods.

### **Entity owner**

Each sensitive entity stores a reference to its owner, which is a class connecting the entity and the corresponding selectable object. Besides, owners can store any additional information, for example, the topological shape of the sensitive entity, highlight colors and methods, or if the entity is selected or not.

#### Selection

To simplify the handling of different selection modes of an object, sensitive entities linked to their owners are organized into sets, called **selections**. Each selection contains entities created for a certain mode along with the sensitivity and update states.

### Selectable object

Selectable object stores information about all created selection modes and sensitive entities.

All successors of a selectable object must implement the method that splits its presentation into sensitive entities according to the given mode. The computed entities are arranged in one selection and added to the list of all selections of this object. No selection will be removed from the list until the object is deleted permanently.

For all standard OCCT shapes, zero mode is supposed to select the whole object (but it may be redefined easily in the custom object). For example, the standard OCCT selection mechanism and *AIS\_Shape* determine the following modes:

- 0 selection of entire object (AIS\_Shape);
- 1 selection of the vertices;
- 2 selection of the edges;
- 3 selection of the wires;
- 4 selection of the faces;
- 5 selection of the shells;
- 6 selection of the constituent solids.




Figure 4: Hierarchy of references from sensitive entity to selectable object




Figure 5: The principle of entities organization within the selectable object

#### Viewer selector

For each OCCT viewer there is a **Viewer selector** class instance. It provides a high-level API for the whole selection algorithm and encapsulates the processing of objects and sensitive entities for each mouse pick. The viewer selector maintains activation and deactivation of selection modes, launches the algorithm, which detects candidate entities to be picked, and stores its results, as well as implements an interface for keeping selection structures up-to-date.

#### Selection manager

Selection manager is a high-level API to manipulate selection of all displayed objects. It handles all viewer selectors, activates and deactivates selection modes for the objects in all or particular selectors, manages computation and update of selections for each object. Moreover, it keeps selection structures updated taking into account applied changes.




Figure 6: The relations chain between viewer selector and selection manager

# 2.2.2 Algorithm


All three types of OCCT selection are implemented as a single concept, based on the search for overlap between frustum and sensitive entity through 3-level BVH tree traversal.

#### **Selection Frustum**


The first step of each run of selection algorithm is to build the selection frustum according to the currently activated selection type.

For the point or the rectangular selection the base of the frustum is a rectangle built in conformity with the pixel tolerance or the dimensions of a user-defined area, respectively. For the polyline selection, the polygon defined by the constructed line is triangulated and each triangle is used as the base for its own frustum. Thus, this type of selection uses a set of triangular frustums for overlap detection.

The frustum length is limited by near and far view volume planes and each plane is built parallel to the corresponding view volume plane.



The image above shows the rectangular frustum: a) after mouse move or click, b) after applying the rectangular selection.



In the image above triangular frustum is set: a) by a user-defined polyline, b) by triangulation of the polygon based on the given polyline, c) by a triangular frustum based on one of the triangles.

# **BVH** trees

To maintain selection mechanism at the viewer level, a speedup structure composed of 3 BVH trees is used.

The first level tree is constructed of axis-aligned bounding boxes of each selectable object. Hence, the root of this tree contains the combination of all selectable boundaries even if they have no currently activated selections. Objects are added during the display of *AIS\_InteractiveObject* and will be removed from this tree only when the object is destroyed. The 1st level BVH tree is build on demand simultaneously with the first run of the selection algorithm.

The second level BVH tree consists of all sensitive entities of one selectable object. The 2nd level trees are built automatically when the default mode is activated and rebuilt whenever a new selection mode is calculated for the first time.

The third level BVH tree is used for complex sensitive entities that contain many elements: for example, triangulations, wires with many segments, point sets, etc. It is built on demand for sensitive entities with under 800K sub-elements.




Figure 7: Selection BVH tree hierarchy: from the biggest object-level (first) to the smallest complex entity level (third)

### Stages of the algorithm

The algorithm includes pre-processing and three main stages.

### **Pre-processing**

Implies calculation of the selection frustum and its main characteristics.

First stage - traverse of the first level BVH tree

After successful building of the selection frustum, the algorithm starts traversal of the object-level BVH tree. The nodes containing axis-aligned bounding boxes are tested for overlap with the selection frustum following the terms of *separating axis theorem (SAT)*. When the traversal goes down to the leaf node, it means that a candidate object with possibly overlapping sensitive entities has been found. If no such objects have been detected, the algorithm stops and it is assumed that no object needs to be selected. Otherwise it passes to the next stage to process the entities of the found selectable object.

Second stage - traversal of the second level BVH tree

At this stage it is necessary to determine if there are candidates among all sensitive entities of one object.

First of all, at this stage the algorithm checks if there is any transformation applied for the current object. If it has its own location, then the correspondingly transformed frustum will be used for further calculations. At the next step the nodes of the second level BVH tree of the given object are visited to search for overlapping leaves. If no such leafs have been found, the algorithm returns to the second stage. Otherwise it starts processing the found entities by performing the following checks:

- activation check the entity may be inactive at the moment as it belongs to deactivated selection;
- tolerance check current selection frustum may be too large for further checks as it is always built with the maximum tolerance among all activated entities. Thus, at this step the frustum may be scaled.

After these checks the algorithm passes to the last stage.

Third stage – overlap or inclusion test of a particular sensitive entity

If the entity is atomic, a simple SAT test is performed. In case of a complex entity, the third level BVH tree is traversed. The quantitative characteristics (like depth, distance to the center of geometry) of matched sensitive entities is analyzed and clipping planes are applied (if they have been set). The result of detection is stored and the algorithm returns to the second stage.

### 2.2.3 Packages and classes

Selection is implemented as a combination of various algorithms divided among several packages – *SelectBasics*, *Select3D*, *SelectMgr* and *StdSelect*.

#### **SelectBasics**

SelectBasics package contains basic classes and interfaces for selection. The most notable are:

- SelectBasics\_SensitiveEntity the base definition of a sensitive entity;
- SelectBasics\_EntityOwner the base definition of the an entity owner the link between the sensitive entity and the object to be selected;
- SelectBasics\_PickResult the structure for storing quantitative results of detection procedure, for example, depth and distance to the center of geometry;
- SelectBasics\_SelectingVolumeManager the interface for interaction with the current selection frustum.

Each custom sensitive entity must inherit at least SelectBasics SensitiveEntity.

#### Select3D

Select3D package provides a definition of standard sensitive entities, such as:

- box;
- · circle:
- curve;
- face;
- group;
- point;
- segment;
- · triangle;
- · triangulation;
- · wire.

Each basic sensitive entity inherits Select3D\_SensitiveEntity, which is a child class of SelectBasics\_SensitiveEntity. The package also contains two auxiliary classes, Select3D\_SensitivePoly and Select3D\_SensitiveSet.

Select3D\_SensitiveSet – a base class for all complex sensitive entities that require the third level BVH usage. It implements traverse of the tree and defines an interface for the methods that check sub-entities.

Select3D\_SensitivePoly – describes an arbitrary point set and implements basic functions for selection. It is important to know that this class does not perform any internal data checks. Hence, custom implementations of sensitive entity inherited from Select3D\_SensitivePoly must satisfy the terms of Separating Axis Theorem to use standard OCCT overlap detection methods.

### SelectMgr

*SelectMgr* package is used to maintain the whole selection process. For this purpose, the package provides the following services:

- · activation and deactivation of selection modes for all selectable objects;
- · interfaces to compute selection mode of the object;
- · definition of selection filter classes;
- · keeping selection BVH data up-to-date.

A brief description of the main classes:

- SelectMgr\_FrustumBase, SelectMgr\_Frustum, SelectMgr\_RectangularFrustum, SelectMgr\_Triangluar←
   Frustum and SelectMgr\_TriangularFrustumSet interfaces and implementations of selecting frustums, these
   classes implement different SAT tests for overlap and inclusion detection. They also contain methods to
   measure characteristics of detected entities (depth, distance to center of geometry);
- SelectMgr\_SensitiveEntity, SelectMgr\_Selection and SelectMgr\_SensitiveEntitySet store and handle sensitive entities; SelectMgr\_SensitiveEntitySet implements a primitive set for the second level BVH tree;
- SelectMgr\_SelectableObject and SelectMgr\_SelectableObjectSet describe selectable objects. They also manage storage, calculation and removal of selections. SelectMgr\_SelectableObjectSet implements a primitive set for the first level BVH tree;
- SelectMgr\_ViewerSelector encapsulates all logics of the selection algorithm and implements the third level BVH tree traverse:
- SelectMgr\_SelectionManager manages activation/deactivation, calculation and update of selections of every selectable object, and keeps BVH data up-to-date.

#### **StdSelect**

StdSelect package contains the implementation of some SelectMgr classes and tools for creation of selection structures. For example,

- StdSelect\_BRepOwner defines an entity owner with a link to its topological shape and methods for high-lighting;
- StdSelect\_BRepSelectionTool contains algorithms for splitting standard AIS shapes into sensitive primitives;
- StdSelect\_ViewerSelector3d an example of SelectMgr\_ViewerSelecor implementation, which is used in a
  default OCCT selection mechanism;
- StdSelect\_FaceFilter, StdSelect\_EdgeFilter implementation of selection filters.

#### 2.2.4 Examples of usage

The first code snippet illustrates the implementation of <code>SelectMgr\_SelectableObject::ComputeSelection()</code> method in a custom interactive object. The method is used for computation of user-defined selection modes. Let us assume it is required to make a box selectable in two modes – the whole shape (mode 0) and each of its edges (mode 1). To select the whole box, the application can create a sensitive primitive for each face of the interactive object. In this case, all primitives share the same owner – the box itself. To select box's edge, the application must create one sensitive primitive per edge. Here all sensitive entities cannot share the owner since different geometric primitives must be highlighted as the result of selection procedure.

```
case 0: // creation of face sensitives for selection of the whole box
{
    Handle(SelectMgr_EntityOwner) anOwner = new SelectMgr_EntityOwner (this, 5);
    for (Standard_Integer aFaceIter = 1; aFaceIter <= myNbFaces; ++aFaceIter)
{
        Select3D_TypeOfSensitivity aSensType = myIsInterior;
        theSel->Add (new Select3D_SensitiveFace (anOwner, myFaces[aFaceIter]->PointArray(), aSensType));
    }
    break;
}
case 1: // creation of edge sensitives for selection of box edges only
{
    for (Standard_Integer anEdgeIter = 1; anEdgeIter <= 12; ++anEdgeIter)
    {
            // 1 owner per edge, where 6 is a priority of the sensitive
            Handle(MySelection_EdgeOwner) anOwner = new MySelection_EdgeOwner (this, anEdgeIter, 6);
            theSel->Add (new Select3D_SensitiveSegment (anOwner, myFirstPnt[anEdgeIter]),
            myLastPnt[anEdgeIter]));
    }
    break;
}
break;
}
```

The algorithms for creating selection structures store sensitive primitives in *SelectMgr\_Selection* instance. Each *SelectMgr\_Selection* sequence in the list of selections of the object must correspond to a particular selection mode. To describe the decomposition of the object into selectable primitives, a set of ready-made sensitive entities is supplied in *Select3D* package. Custom sensitive primitives can be defined through inheritance from *SelectBasics—SensitiveEntity*. To make custom interactive objects selectable or customize selection modes of existing objects, the entity owners must be defined. They must inherit *SelectMgr\_EntityOwner* interface.

Selection structures for any interactive object are created in *SelectMgr\_SelectableObject::ComputeSelection()* method. The example below shows how computation of different selection modes of the topological shape can be done using standard OCCT mechanisms, implemented in *StdSelect BRepSelectionTool*.

The *StdSelect\_BRepSelectionTool* class provides a high level API for computing sensitive entities of the given type (for example, face, vertex, edge, wire and others) using topological data from the given *TopoDS\_Shape*.

The traditional way of highlighting selected entity owners adopted by Open CASCADE Technology assumes that each entity owner highlights itself on its own. This approach has two drawbacks:

- each entity owner has to maintain its own Prs3d\_Presentation object, that results in a considerable memory overhead:
- · drawing selected owners one by one is not efficient from the visualization point of view.

Therefore, to overcome these limitations, OCCT has an alternative way to implement the highlighting of a selected presentation. Using this approach, the interactive object itself will be responsible for the highlighting, not the entity owner.

On the basis of SelectMgr\_EntityOwner::IsAutoHilight() return value, AIS\_InteractiveContext object either uses the traditional way of highlighting (in case if IsAutoHilight() returns TRUE) or groups such owners according to their selectable objects and finally calls SelectMgr\_SelectableObject::HilightSelected() or SelectMgr\_SelectableObject::ClearSelected(), passing a group of owners as an argument.

Hence, an application can derive its own interactive object and redefine virtual methods *HilightSelected()*, *Clear*← *Selected()* and *HilightOwnerWithColor()* from *SelectMgr\_SelectableObject*. *SelectMgr\_SelectableObject*::Get←

HilightPresentation and SelectMgr\_SelectableObject::GetSelectPresentation methods can be used to optimize filling of selection and highlight presentations according to the user's needs. The AIS\_InteractiveContext::Highlight Selected() method can be used for efficient redrawing of the selection presentation for a given interactive object from an application code.

After all the necessary sensitive entities are computed and packed in SelectMgr\_Selection instance with the corresponding owners in a redefinition of SelectMgr\_SelectableObject::ComputeSelection() method, it is necessary to register the prepared selection in SelectMgr\_SelectionManager through the following steps:

- if there was no AIS\_InteractiveContext opened, create an interactive context and display the selectable object in it:
- load the selectable object to the selection manager of the interactive context using AIS\_InteractiveContext
   ::Load() method. If the selection mode passed as a parameter to this method is not equal to -1, Compute
   Selection() for this selection mode will be called;
- activate or deactivate the defined selection mode using AIS\_InteractiveContext::Activate() or AIS\_←
  InteractiveContext::Deactivate() methods.

After these steps, the selection manager of the created interactive context will contain the given object and its selection entities, and they will be involved in the detection procedure.

The code snippet below illustrates the above steps. It also contains the code to start the detection procedure and parse the results of selection.

```
// Suppose there is an instance of class InteractiveBox from the previous sample.
// It contains an implementation of method InteractiveBox::ComputeSelection() for selection
// modes 0 (whole box must be selected) and 1 (edge of the box must be selectable)
Handle (InteractiveBox) theBox;
Handle(AIS_InteractiveContext) theContext;
^{\prime\prime} To prevent automatic activation of the default selection mode
theContext->SetAutoActivateSelection (false);
theContext->Display (theBox, false);
// Load a box to the selection manager without computation of any selection mode
theContext->Load (theBox, -1, true);
// Activate edge selection
theContext->Activate (theBox, 1);
// Run the detection mechanism for activated entities in the current mouse coordinates and in the current
       view.
// Detected owners will be highlighted with context highlight color
theContext->MoveTo (aXMousePos, aYMousePos, myView);
// Select the detected owners
theContext->Select();
// Iterate through the selected owners
for (theContext->InitSelected(); theContext->MoreSelected() && !aHasSelected; theContext->NextSelected())
  Handle(AIS_InteractiveObject) anIO = theContext->SelectedInteractive();
// deactivate all selection modes for aBox1
theContext->Deactivate (aBox1);
```

It is also important to know, that there are 2 types of detection implemented for rectangular selection in OCCT:

- **inclusive** detection. In this case the sensitive primitive is considered detected only when all its points are included in the area defined by the selection rectangle;
- **overlap** detection. In this case the sensitive primitive is considered detected when it is partially overlapped by the selection rectangle.

The standard OCCT selection mechanism uses inclusion detection by default. To change this, use the following code:

```
// Assume there is a created interactive context
const Handle(AIS_InteractiveContext) theContext;
// Retrieve the current viewer selector
const Handle(StdSelect_ViewerSelector3d) & aMainSelector = theContext->MainSelector();
// Set the flag to allow overlap detection
aMainSelector->AllowOverlapDetection (true);
```

# 3 Application Interactive Services


### 3.1 Introduction

Application Interactive Services allow managing presentations and dynamic selection in a viewer in a simple and transparent manner. The central entity for management of visualization and selections is the **Interactive Context**. It is connected to the main viewer.

Interactive context by default starts at **Neutral Point** with each selectable object picked as a whole, but the user might activate **Local Selection** for specific objects to make selectable parts of the objects. Local/global selection is managed by a list of selection modes activated for each displayed object with 0 (default selection mode) usually meaning Global (entire object) selection.

**Interactive Objects** are the entities, which are visualized and selected. You can use classes of standard interactive objects for which all necessary functions have already been programmed, or you can implement your own classes of interactive objects, by respecting a certain number of rules and conventions described below.

An Interactive Object is a "virtual" entity, which can be presented and selected. An Interactive Object can have a certain number of specific graphic attributes, such as visualization mode, color and material. When an Interactive Object is visualized, the required graphic attributes are taken from its own **Drawer** (*Prs3d\_Drawer*) if it has the required custom attributes or otherwise from the context drawer.



It can be necessary to filter the entities to be selected. Consequently there are **Filter** entities, which allow refining the dynamic detection context. Some of these filters can be used only within at the Neutral Point, others only within Local Selection. It is possible to program custom filters and load them into the interactive context.

### 3.2 Interactive objects


Entities which are visualized and selected in the AIS viewer are objects. They connect the underlying reference geometry of a model to its graphic representation in AIS. You can use the predefined OCCT classes of standard interactive objects, for which all necessary functions have already been programmed, or, if you are an advanced user, you can implement your own classes of interactive objects.

#### 3.2.1 Presentations

An interactive object can have as many presentations as its creator wants to give it. 3D presentations are managed by **Presentation Manager** (*PrsMgr\_PresentationManager*). As this is transparent in AIS, the user does not have to

worry about it.

A presentation is identified by an index (*Display Mode*) and by the reference to the Presentation Manager, which it depends on. By convention, the default mode of representation for the Interactive Object has index 0.



Calculation of different presentations of an interactive object is done by the *Compute* functions inheriting from *PrsMgr\_PresentableObject::Compute* functions. They are automatically called by *PresentationManager* at a visualization or an update request.

If you are creating your own type of interactive object, you must implement the Compute function in one of the following ways:

#### For 3D:

#### For hidden line removal (HLR) mode in 3D:

#### 3.2.2 Hidden Line Removal

The view can have two states: the normal mode or the computed mode (Hidden Line Removal mode). When the latter is active, the view looks for all presentations displayed in the normal mode, which have been signalled as accepting HLR mode. An internal mechanism allows calling the interactive object's own *Compute*, that is projector function.

By convention, the Interactive Object accepts or rejects the representation of HLR mode. It is possible to make this declaration in one of two ways:

- Initially by using one of the values of the enumeration PrsMgr TypeOfPresentation:
  - PrsMgr TOP AllView,
  - PrsMgr\_TOP\_ProjectorDependant
- Later by using the function PrsMgr PresentableObject::SetTypeOfPresentation

AlS\_Shape class is an example of an interactive object that supports HLR representation. The type of the HLR algorithm is stored in *Prs3d\_Drawer* of the shape. It is a value of the *Prs3d\_TypeOfHLR* enumeration and can be set to:

- Prs3d\_TOH\_PolyAlgo for a polygonal algorithm based on the shape's triangulation;
- Prs3d\_TOH\_Algo for an exact algorithm that works with the shape's real geometry;
- Prs3d\_TOH\_NotSet if the type of algorithm is not set for the given interactive object instance.

The type of the HLR algorithm used for AIS\_Shape can be changed by calling the AIS\_Shape::SetTypeOfHLR() method. The current HLR algorithm type can be obtained using AIS\_Shape::TypeOfHLR() method is to be used.

These methods get the value from the drawer of *AlS\_Shape*. If the HLR algorithm type in the *AlS\_Drawer* is set to *Prs3d\_TOH\_NotSet*, the *AlS\_Drawer* gets the value from the default drawer of *AlS\_InteractiveContext*. So it is possible to change the default HLR algorithm used by all newly displayed interactive objects. The value of the HLR algorithm type stored in the context drawer can be *Prs3d\_TOH\_Algo* or *Prs3d\_TOH\_PolyAlgo*. The polygonal algorithm is the default one.

### 3.2.3 Presentation modes

There are four types of interactive objects in AIS:

- · the "construction element" or Datum,
- the Relation (dimensions and constraints)
- · the Object
- the None type (when the object is of an unknown type).

Inside these categories, additional characterization is available by means of a signature (an index.) By default, the interactive object has a NONE type and a signature of 0 (equivalent to NONE). If you want to give a particular type and signature to your interactive object, you must redefine two virtual functions:

- · AIS InteractiveObject::Type
- AIS\_InteractiveObject::Signature.

**Note** that some signatures are already used by "standard" objects provided in AIS (see the List of Standard Interactive Object Classes).

The interactive context can have a default mode of representation for the set of interactive objects. This mode may not be accepted by a given class of objects. Consequently, to get information about this class it is necessary to use virtual function AIS InteractiveObject::AcceptDisplayMode.

#### **Display Mode**

The functions AIS\_InteractiveContext::SetDisplayMode and AIS\_InteractiveContext::UnsetDisplayMode allow setting a custom display mode for an objects, which can be different from that proposed by the interactive context.

# **Highlight Mode**

At dynamic detection, the presentation echoed by the Interactive Context, is by default the presentation already on the screen.

The functions AIS\_InteractiveObject::SetHilightMode and AIS\_InteractiveObject::UnSetHilightMode allow specifying the display mode used for highlighting (so called highlight mode), which is valid independently from the active representation of the object. It makes no difference whether this choice is temporary or definitive.

Note that the same presentation (and consequently the same highlight mode) is used for highlighting *detected* objects and for highlighting *selected* objects, the latter being drawn with a special *selection color* (refer to the section related to *Interactive Context* services).

For example, you want to systematically highlight the wireframe presentation of a shape - non regarding if it is visualized in wireframe presentation or with shading. Thus, you set the highlight mode to 0 in the constructor of the interactive object. Do not forget to implement this representation mode in the *Compute* functions.

# Infinite Status

If you do not want an object to be affected by a *FitAll* view, you must declare it infinite; you can cancel its "infinite" status using *AIS\_InteractiveObject::SetInfiniteState* and *AIS\_InteractiveObject::IsInfinite* functions.

Let us take for example the class called IShape representing an interactive object:

An interactive object can have an indefinite number of selection modes, each representing a "decomposition" into sensitive primitives. Each primitive has an **Owner** (*SelectMgr\_EntityOwner*) which allows identifying the exact interactive object or shape which has been detected (see Selection chapter).

The set of sensitive primitives, which correspond to a given mode, is stocked in a **Selection** (SelectMgr\_Selection).

Each selection mode is identified by an index. By convention, the default selection mode that allows us to grasp the interactive object in its entirety is mode 0. However, it can be modified in the custom interactive objects using method SelectMgr\_SelectableObject::setGlobalSelMode().

The calculation of selection primitives (or sensitive entities) is done in a virtual function *ComputeSelection*. It should be implemented for each type of interactive object that is assumed to have different selection modes using the function *AIS\_InteractiveObject::ComputeSelection*. A detailed explanation of the mechanism and the manner of implementing this function has been given in Selection chapter.

There are some examples of selection mode calculation for the most widely used interactive object in OCCT –  $Al \leftarrow S\_Shape$  (selection by vertex, by edges, etc). To create new classes of interactive objects with the same selection behavior as  $AlS\_Shape$  – such as vertices and edges – you must redefine the virtual function  $AlS\_Interactive \leftarrow Object::AcceptShapeDecomposition$ .

#### 3.2.5 Graphic attributes

Graphic attributes manager, or *Prs3d\_Drawer*, stores graphic attributes for specific interactive objects and for interactive objects controlled by interactive context.

Initially, all drawer attributes are filled out with the predefined values which will define the default 3D object appearance. When an interactive object is visualized, the required graphic attributes are first taken from its own drawer if one exists, or from the context drawer if no specific drawer for that type of object exists.

Keep in mind the following points concerning graphic attributes:

- Each interactive object can have its own visualization attributes.
- By default, the interactive object takes the graphic attributes of the context in which it is visualized (visualization mode, deflection values for the calculation of presentations, number of isoparameters, color, type of line, material, etc.)
- In the AIS\_InteractiveObject abstract class, standard attributes including color, line thickness, material, and transparency have been privileged. Consequently, there is a certain number of virtual functions, which allow acting on these attributes. Each new class of interactive object can redefine these functions and change the behavior of the class.




Figure 8: Redefinition of virtual functions for changes in AIS Shape and AIS TextLabel.

The following virtual functions provide settings for color, width, material and transparency:

- AIS InteractiveObject::UnsetColor
- · AIS\_InteractiveObject::SetWidth
- AIS\_InteractiveObject::UnsetWidth
- · AIS InteractiveObject::SetMaterial
- AIS InteractiveObject::UnsetMaterial
- AIS\_InteractiveObject::SetTransparency
- AIS\_InteractiveObject::UnsetTransparency

These methods can be used as a shortcut assigning properties in common way, but result might be not available. Some interactive objects might not implement these methods at all or implement only a sub-set of them. Direct modification of *Prs3d\_Drawer* properties returned by *AIS\_InteractiveObject::Attributes* can be used for more precise and predictable configuration.

It is important to know which functions may imply the recalculation of presentations of the object. If the presentation mode of an interactive object is to be updated, a flag from *PrsMgr\_PresentableObject* indicates this. The mode can be updated using the functions *Display* and *Redisplay* in *AIS\_InteractiveContext*.

### 3.2.6 Complementary Services

When you use complementary services for interactive objects, pay special attention to the cases mentioned below.

Change the location of an interactive object

The following functions allow "moving" the representation and selection of Interactive Objects in a view without recalculation (and modification of the original shape).

- · AIS\_InteractiveContext::SetLocation
- · AIS InteractiveContext::ResetLocation
- AIS\_InteractiveContext::HasLocation
- · AIS\_InteractiveContext::Location

Connect an interactive object to an applicative entity

Each Interactive Object has functions that allow attributing it an Owner in form of a Transient.

AIS\_InteractiveObject::SetOwner

AIS InteractiveObject::HasOwner

AIS\_InteractiveObject::Owner

An interactive object can therefore be associated or not with an applicative entity, without affecting its behavior.

**NOTE:** Don't be confused by owners of another kind - *SelectBasics\_EntityOwner* used for identifying selectable parts of the object or object itself.

Resolving coincident topology

Due to the fact that the accuracy of three-dimensional graphics coordinates has a finite resolution the elements of topological objects can coincide producing the effect of "popping" some elements one over another.

To the problem when the elements of two or more Interactive Objects are coincident you can apply the polygon offset. It is a sort of graphics computational offset, or depth buffer offset, that allows you to arrange elements (by modifying their depth value) without changing their coordinates. The graphical elements that accept this kind of offsets are solid polygons or displayed as boundary lines and points. The polygons could be displayed as lines or points by setting the appropriate interior style.

The methods AIS\_InteractiveObject::SetPolygonOffsets and AIS\_InteractiveContext::SetPolygonOffsets allow setting up the polygon offsets.

#### 3.2.7 Object hierarchy

Each *PrsMgr\_PresentableObject* has a list of objects called *myChildren*. Any transformation of *PrsMgr\_ PresentableObject* is also applied to its children. This hierarchy does not propagate to *Graphic3d* level and below.

*PrsMgr\_PresentableObject* sends its combined (according to the hierarchy) transformation down to *Graphic3d\_*← *Structure*. The materials of structures are not affected by the hierarchy.

Object hierarchy can be controlled by the following API calls:

- PrsMgr PresentableObject::AddChild;
- PrsMgr\_PresentableObject::RemoveChild.

#### 3.2.8 Instancing

The conception of instancing operates the object hierarchy as follows:

- Instances are represented by separated AIS objects.
- · Instances do not compute any presentations.

Classes AIS\_ConnectedInteractive and AIS\_MultipleConnectedInteractive are used to implement this conception.

AIS\_ConnectedInteractive is an object instance, which reuses the geometry of the connected object but has its own transformation, material, visibility flag, etc. This connection is propagated down to *OpenGI* level, namely to *OpenGI\_Structure*. *OpenGI\_Structure* can be connected only to a single other structure.

AIS\_ConnectedInteractive can be referenced to any AIS\_InteractiveObject in general. When it is referenced to another AIS\_ConnectedInteractive, it just copies the reference.

AIS\_MultipleConnectedInteractive represents an assembly, which does not have its own presentation. The assemblies are able to participate in the object hierarchy and are intended to handle a grouped set of instanced objects.

It behaves as a single object in terms of selection. It applies high level transformation to all sub-elements since it is located above in the hierarchy.

All AIS\_MultipleConnectedInteractive are able to have child assemblies. Deep copy of object instances tree is performed if one assembly is attached to another.

Note that AIS\_ConnectedInteractive cannot reference AIS\_MultipleConnectedInteractive. AIS\_Connected Interactive copies sensitive entities of the origin object for selection, unlike AIS\_MultipleConnectedInteractive that re-uses the entities of the origin object.


Instances can be controlled by the following DRAW commands:

- · vconnect: Creates and displays AIS MultipleConnectedInteractive object from input objects and location.
- · vconnectto: Makes an instance of object with the given position.
- · vdisconnect: Disconnects all objects from an assembly or disconnects an object by name or number.
- · vaddconnected: Adds an object to the assembly.
- · vlistconnected: Lists objects in the assembly.

Have a look at the examples below:


```
pload ALL
vinit
psphere s 1
vdisplay s
vconnectto s2 3 0 0 s # make instance
vfit
```

See how proxy *OpenGl\_Structure* is used to represent instance:



The original object does not have to be displayed in order to make instance. Also selection handles transformations of instances correctly:

3.3 Interactive Context 23



Here is the example of a more complex hierarchy involving sub-assemblies:

```
pload ALL vinit box b 1 1 1 psphere s 0.5 vdisplay b s vsetlocation s 0 2.5 0 box d 0.5 0.5 3 box d2 0.5 3 0.5 vdisplay d d2 vconnectto b1 -2 0 0 b s vconnect z 2 4 0 0 d d2 vconnect z 3 6 0 0 z z 2 vfit
```

### 3.3 Interactive Context

### 3.3.1 Rules

The Interactive Context allows managing in a transparent way the graphic and **selectable** behavior of interactive objects in one or more viewers. Most functions which allow modifying the attributes of interactive objects, and which were presented in the preceding chapter, will be looked at again here.

There is one essential rule to follow: the modification of an interactive object, which is already known by the Context, must be done using Context functions. You can only directly call the functions available for an interactive object if it has not been loaded into an Interactive Context.

```
Handle(AIS_Shape) aShapePrs = new AIS_Shape (theShape);
myIntContext->Display (aShapePrs, AIS_Shaded, 0, false, aShapePrs->AcceptShapeDecomposition());
myIntContext->SetColor(aShapePrs, Quantity_NOC_RED);
```

## You can also write

```
Handle(AIS_Shape) aShapePrs = new AIS_Shape (theShape);
aShapePrs->SetColor (Quantity_NOC_RED);
aShapePrs->SetDisplayMode (AIS_Shaded);
myIntContext->Display (aShapePrs);
```

3.4 Local Selection 24

#### 3.3.2 Groups of functions

**Neutral Point** and **Local Selection** constitute the two operating modes or states of the **Interactive Context**, which is the central entity which pilots visualizations and selections. The **Neutral Point**, which is the default mode, allows easily visualizing and selecting interactive objects, which have been loaded into the context. Activating **Local Selection** for specific Objects allows selecting of their sub-parts.

#### 3.3.3 Management of the Interactive Context

An interactive object can have a certain number of specific graphic attributes, such as visualization mode, color, and material. Correspondingly, the interactive context has a set of graphic attributes, the *Drawer*, which is valid by default for the objects it controls. When an interactive object is visualized, the required graphic attributes are first taken from the object's own *Drawer* if it exists, or from the context drawer if otherwise.

The following adjustable settings allow personalizing the behavior of presentations and selections:

- Default Drawer, containing all the color and line attributes which can be used by interactive objects, which do not have their own attributes.
- Default Visualization Mode for interactive objects. By default: mode 0;
- Highlight color of entities detected by mouse movement. By default: Quantity\_NOC\_CYAN1;
- Pre-selection color. By default: Quantity\_NOC\_GREEN;
- Selection color (when you click on a detected object). By default: Quantity\_NOC\_GRAY80;

All of these settings can be modified by functions proper to the Context. When you change a graphic attribute pertaining to the Context (visualization mode, for example), all interactive objects, which do not have the corresponding appropriate attribute, are updated.

Let us examine the case of two interactive objects: theObj1 and theObj2:

```
theCtx->Display (theObj1, false);
theCtx->Display (theObj2, true); // TRUE for viewer update
theCtx->SetDisplayMode (theObj1, 3, false);
theCtx->SetDisplayMode (2, true);
// theObj2 is visualised in mode 2 (if it accepts this mode)
// theObj1 stays visualised in its mode 3
```

PresentationManager and Selector3D, which manage the presentation and selection of present interactive objects, are associated to the main Viewer.

### 3.4 Local Selection

### 3.4.1 Selection Modes

The Local Selection is defined by index (Selection Mode). The Selection Modes implemented by a specific interactive object and their meaning should be checked within the documentation of this class. See, for example, MeshVS SelectionModeFlags for MeshVS Mesh object.

The interactive object, which is used the most by applications, is *AlS\_Shape*. Consequently, there are standard functions, which allow you to easily prepare selection operations on the constituent elements of shapes (selection of vertices, edges, faces, etc.). The Selection Mode for a specific shape type (*TopAbs\_ShapeEnum*) is returned by method *AlS\_Shape::SelectionMode()*.

The function AIS\_InteractiveObject::Display (without argument taking Selection Mode) activates the object's default Selection Mode. The functions AIS\_InteractiveContext::Activate and AIS\_InteractiveContext::Deactivate activate and deactivate specific Selection Mode.

More than one Selection Mode can be activated at the same time (but default 0 mode for selecting entire object is exclusive - it cannot be combined with others). The list of active modes can be retrieved using function  $AIS\_\leftarrow InteractiveContext::ActivatedModes$ .

3.4 Local Selection 25

#### 3.4.2 Filters

To define an environment of dynamic detection, you can use standard filter classes or create your own. A filter questions the owner of the sensitive primitive to determine if it has the desired qualities. If it answers positively, it is kept. If not, it is rejected.

The root class of objects is *SelectMgr\_Filter*. The principle behind it is straightforward: a filter tests to see whether the owners (*SelectMgr\_EntityOwner*) detected in mouse position by selector answer *OK*. If so, it is kept, otherwise it is rejected. You can create a custom class of filter objects by implementing the deferred function *SelectMgr\_Filter* :: *isOk()*.

In *SelectMgr*, there are also Composition filters (AND Filters, OR Filters), which allow combining several filters. In Interactive Context, all filters that you add are stored in an OR filter (which answers *OK*).

There are Standard filters, which have already been implemented in several packages:

- StdSelect\_EdgeFilter for edges, such as lines and circles;
- StdSelect FaceFilter for faces, such as planes, cylinders and spheres;
- StdSelect\_ShapeTypeFilter for shape types, such as compounds, solids, shells and wires;
- AIS TypeFilter for types of interactive objects;
- AIS\_SignatureFilter for types and signatures of interactive objects;
- AIS\_AttributeFilter for attributes of Interactive Objects, such as color and width.

There are several functions to manipulate filters:

- AIS InteractiveContext::AddFilter adds a filter passed as an argument.
- AIS InteractiveContext::RemoveFilter removes a filter passed as an argument.
- AIS InteractiveContext::RemoveFilters removes all present filters.
- · AIS\_InteractiveContext::Filters gets the list of filters active in a context.

#### Example

```
// shading visualization mode, no specific mode, authorization for decomposition into sub-shapes
const TopoDS_Shape theShape;
Handle(ATS_Shape) aShapePrs = new AIS_Shape (theShape);
myContext->Display (aShapePrs, AIS_Shaded, -1, true, true);

// activates decomposition of shapes into faces
const int aSubShapeSelMode = AIS_Shape::SelectionMode (TopAbs_Face);
myContext->Activate (aShapePrs, aSubShapeSelMode);

Handle(StdSelect_FaceFilter) aFil1 = new StdSelect_FaceFilter (StdSelect_Revol);
Handle(StdSelect_FaceFilter) aFil2 = new StdSelect_FaceFilter (StdSelect_Plane);
myContext->AddFilter (aFil1);
myContext->AddFilter (aFil2);

// only faces of revolution or planar faces will be selected
myContext->MoveTo (thePixelX, thePixelY, myView);
```

#### 3.4.3 Selection

Dynamic detection and selection are put into effect in a straightforward way. There are only a few conventions and functions to be familiar with:

- AIS\_InteractiveContext::MoveTo passes mouse position to Interactive Context selectors.
- AIS\_InteractiveContext::Select stores what has been detected at the last MoveTo. Replaces the previously selected object. Empties the stack if nothing has been detected at the last move.

- AIS\_InteractiveContext::ShiftSelect if the object detected at the last move was not already selected, it is added to the list of the selected objects. If not, it is withdrawn. Nothing happens if you click on an empty area.
- AIS InteractiveContext::Select selects everything found in the surrounding area.
- AIS\_InteractiveContext::ShiftSelect selects what was not previously in the list of selected, deselects those already present.

Highlighting of detected and selected entities is automatically managed by the Interactive Context. The Highlight colors are those dealt with above. You can nonetheless disconnect this automatic mode if you want to manage this part yourself:

```
AIS_InteractiveContext::SetAutomaticHilight AIS_InteractiveContext::AutomaticHilight
```

You can question the Interactive context by moving the mouse. The following functions can be used:

- AIS\_InteractiveContext::HasDetected checks if there is a detected entity;
- AIS\_InteractiveContext::DetectedOwner returns the (currently highlighted) detected entity.

After using the *Select* and *ShiftSelect* functions, you can explore the list of selections. The following functions can be used:

- AIS InteractiveContext::InitSelected initializes an iterator;
- AIS InteractiveContext::MoreSelected checks if the iterator is valid;
- AIS\_InteractiveContext::NextSelected moves the iterator to the next position;
- AIS\_InteractiveContext::SelectedOwner returns an entity at the current iterator position.

The owner object  $SelectMgr\_EntityOwner$  is a key object identifying selectable entitiy in the viewer (returned by methods  $AlS\_InteractiveContext::DetectedOwner$  and  $AlS\_InteractiveContext::SelectedOwner$ ). The Interactive Object itself can be retrieved by method  $SelectMgr\_EntityOwner::Selectable$ , while identifying sub-part depends on type of Interactive Object. In case of  $AlS\_Shape$ , the (sub)shape is returned by method  $StdSelect\_BRep \hookrightarrow Owner::Shape$ .

#### #### Example

```
for (myAISCtx->InitSelected(); myAISCtx->MoreSelected(); myAISCtx->NextSelected())
{
   Handle(SelectMgr_EntityOwner) anOwner = myAISCtx->SelectedOwner();
   Handle(AIS_InteractiveObject) anObj = Handle(AIS_InteractiveObject)::DownCast (anOwner->Selectable());
   if (Handle(StdSelect_BRepOwner) aBRepOwner = Handle(StdSelect_BRepOwner)::DownCast (anOwner))
   {
        // to be able to use the picked shape
        TopoDS_Shape aShape = aBRepOwner->Shape();
   }
}
```

### 3.5 Standard Interactive Object Classes

Interactive Objects are selectable and viewable objects connecting graphic representation and the underlying reference geometry.

They are divided into four types:

- the **Datum** a construction geometric element;
- the **Relation** a constraint on the interactive shape and the corresponding reference geometry;
- the Object a topological shape or connection between shapes;

• **None** – a token, that instead of eliminating the object, tells the application to look further until it finds an acceptable object definition in its generation.

Inside these categories, there is a possibility of additional characterization by means of a signature. The signature provides an index to the further characterization. By default, the **Interactive Object** has a *None* type and a signature of 0 (equivalent to *None*). If you want to give a particular type and signature to your interactive object, you must redefine the two virtual methods: *Type* and *Signature*.

#### 3.5.1 Datum

The **Datum** groups together the construction elements such as lines, circles, points, trihedrons, plane trihedrons, planes and axes.

AIS\_Point, AIS\_Axis, AIS\_Line, AIS\_Circle, AIS\_Plane and AIS\_Trihedron have four selection modes:

- mode 0 : selection of a trihedron;
- mode 1 : selection of the origin of the trihedron;
- · mode 2 : selection of the axes;
- mode 3: selection of the planes XOY, YOZ, XOZ.

when you activate one of modes: 1 2 3 4, you pick AIS objects of type:

- · AIS\_Point;
- AIS Axis (and information on the type of axis);
- AIS\_Plane (and information on the type of plane).

AIS\_PlaneTrihedron offers three selection modes:

- mode 0 : selection of the whole trihedron;
- mode 1 : selection of the origin of the trihedron;
- mode 2 : selection of the axes same remarks as for the Trihedron.

For the presentation of planes and trihedra, the default length unit is millimeter and the default value for the representation of axes is 10. To modify these dimensions, you must temporarily recover the object **Drawer**. From it, take the *DatumAspect()* and change the value *FirstAxisLength*. Finally, recalculate the presentation.

### 3.5.2 Object

The **Object** type includes topological shapes, and connections between shapes.

AIS\_Shape has two visualization modes:

- mode 0 : Line (default mode)
- mode 1 : Shading (depending on the type of shape)

AIS\_ConnectedInteractive is an Interactive Object connecting to another interactive object reference, and located elsewhere in the viewer makes it possible not to calculate presentation and selection, but to deduce them from your object reference. AIS\_MultipleConnectedInteractive is an object connected to a list of interactive objects (which can also be Connected objects. It does not require memory-hungry presentation calculations).

*MeshVS\_Mesh* is an Interactive Object that represents meshes, it has a data source that provides geometrical information (nodes, elements) and can be built up from the source data with a custom presentation builder.

The class AIS\_ColoredShape allows using custom colors and line widths for TopoDS\_Shape objects and their sub-shapes.

```
AIS_ColoredShape aColoredShape = new AIS_ColoredShape (theShape);

// setup color of entire shape
aColoredShape->SetColor (Quantity_NOC_RED);

// setup line width of entire shape
aColoredShape->SetWidth (1.0);

// set transparency value
aColoredShape->SetTransparency (0.5);

// customize color of specified sub-shape
aColoredShape->SetCustomColor (theSubShape, Quantity_NOC_BLUE1);

// customize line width of specified sub-shape
aColoredShape->SetCustomWidth (theSubShape, 0.25);
```

The presentation class *AIS\_PointCloud* can be used for efficient drawing of large arbitrary sets of colored points. It uses *Graphic3d\_ArrayOfPoints* to pass point data into OpenGl graphic driver to draw a set points as an array of "point sprites". The point data is packed into vertex buffer object for performance.

- The type of point marker used to draw points can be specified as a presentation aspect.
- The presentation provides selection by a bounding box of the visualized set of points. It supports two display / highlighting modes: points or bounding box.




Figure 9: A random colored cloud of points

### Example:

```
Handle(Graphic3d_ArrayOfPoints) aPoints = new Graphic3d_ArrayOfPoints (2000, Standard_True);
aPoints->AddVertex (gp_Pnt(-40.0, -40.0, -40.0), Quantity_Color (Quantity_NOC_BLUE1));
aPoints->AddVertex (gp_Pnt (40.0, 40.0, 40.0), Quantity_Color (Quantity_NOC_BLUE2));
Handle(AIS_PointCloud) aPntCloud = new AIS_PointCloud();
aPntCloud->SetPoints (aPoints);
```

The draw command *vpointcloud* builds a cloud of points from shape triangulation. This command can also draw a sphere surface or a volume with a large amount of points (more than one million).

#### 3.5.3 Relations

The **Relation** is made up of constraints on one or more interactive shapes and the corresponding reference geometry. For example, you might want to constrain two edges in a parallel relation. This constraint is considered as an object in its own right, and is shown as a sensitive primitive. This takes the graphic form of a perpendicular arrow marked with the || symbol and lying between the two edges.

The following relations are provided by AIS:

- · AIS ConcentricRelation
- · AIS\_FixRelation
- · AIS IdenticRelation
- · AIS ParallelRelation
- · AIS PerpendicularRelation
- · AIS Relation
- AIS\_SymmetricRelation
- AIS\_TangentRelation

The list of relations is not exhaustive.

#### 3.5.4 Dimensions

- · AIS AngleDimension
- · AIS\_Chamf3dDimension
- · AIS DiameterDimension
- AIS\_DimensionOwner
- AIS\_LengthDimension
- AIS\_OffsetDimension
- · AIS RadiusDimension

#### 3.5.5 MeshVS Mesh

*MeshVS\_Mesh* is an Interactive Object that represents meshes. This object differs from the *AIS\_Shape* as its geometrical data is supported by the data source *MeshVS\_DataSource* that describes nodes and elements of the object. As a result, you can provide your own data source.

However, the *DataSource* does not provide any information on attributes, for example nodal colors, but you can apply them in a special way – by choosing the appropriate presentation builder.

The presentations of *MeshVS\_Mesh* are built with the presentation builders *MeshVS\_PrsBuilder*. You can choose between the builders to represent the object in a different way. Moreover, you can redefine the base builder class and provide your own presentation builder.

You can add/remove builders using the following methods:

There is a set of reserved display and highlighting mode flags for *MeshVS\_Mesh*. Mode value is a number of bits that allows selecting additional display parameters and combining the following mode flags, which allow displaying mesh in wireframe, shading and shrink modes:

```
MeshVS_DMF_WireFrame
MeshVS_DMF_Shading
MeshVS_DMF_Shrink
```

It is also possible to display deformed mesh in wireframe, shading or shrink modes usung:

```
MeshVS_DMF_DeformedPrsWireFrame
MeshVS_DMF_DeformedPrsShading
MeshVS_DMF_DeformedPrsShrink
```

The following methods represent different kinds of data:

```
MeshVS_DMF_VectorDataPrs
MeshVS_DMF_NodalColorDataPrs
MeshVS_DMF_ElementalColorDataPrs
MeshVS_DMF_TextDataPrs
MeshVS_DMF_EntitiesWithData
```

The following methods provide selection and highlighting:

```
MeshVS_DMF_SelectionPrs
MeshVS_DMF_HilightPrs
```

MeshVS\_DMF\_User is a user-defined mode.

These values will be used by the presentation builder. There is also a set of selection modes flags that can be grouped in a combination of bits:

- MeshVS SMF 0D
- MeshVS\_SMF\_Link
- MeshVS\_SMF\_Face
- MeshVS\_SMF\_Volume
- MeshVS SMF Element groups OD, Link, Face and Volume as a bit mask;
- · MeshVS SMF Node
- MeshVS\_SMF\_All groups Element and Node as a bit mask;
- MeshVS\_SMF\_Mesh
- MeshVS\_SMF\_Group

Such an object, for example, can be used for displaying the object and stored in the STL file format:

```
// read the data and create a data source
Handle(Poly_Triangulation) aSTLMesh = RWStl::ReadFile (aFileName);
Handle(XSDRAWSTLVRML_DataSource) aDataSource = new XSDRAWSTLVRML_DataSource (aSTLMesh);
// create mesh
Handle(MeshVS_Mesh) aMeshPrs = new MeshVS();
aMeshPrs->SetDataSource (aDataSource);
// use default presentation builder
Handle(MeshVS_MeshPrsBuilder) aBuilder = new MeshVS_MeshPrsBuilder (aMeshPrs);
aMeshPrs->AddBuilder (aBuilder, true);
```

MeshVS\_NodalColorPrsBuilder allows representing a mesh with a color scaled texture mapped on it. To do this you should define a color map for the color scale, pass this map to the presentation builder, and define an appropriate value in the range of 0.0 - 1.0 for every node. The following example demonstrates how you can do this (check if the view has been set up to display textures):

### 3.6 Dynamic Selection

The dynamic selection represents the topological shape, which you want to select, by decomposition of *sensitive primitives* – the sub-parts of the shape that will be detected and highlighted. The sets of these primitives are handled by the powerful three-level BVH tree selection algorithm.

For more details on the algorithm and examples of usage, please, refer to Selection chapter.

4 3D Presentations 32

### 4 3D Presentations

### 4.1 Glossary of 3D terms

• **Group** – a set of primitives and attributes on those primitives. Primitives and attributes may be added to a group but cannot be removed from it, unless erased globally. A group can have a pick identity.

- **Light** There are five kinds of light source ambient, headlight, directional, positional and spot. The light is only activated in a shading context in a view.
- **Primitive** a drawable element. It has a definition in 3D space. Primitives can either be lines, faces, text, or markers. Once displayed markers and text remain the same size. Lines and faces can be modified e.g. zoomed. Primitives must be stored in a group.
- Structure manages a set of groups. The groups are mutually exclusive. A structure can be edited, adding or removing groups. A structure can reference other structures to form a hierarchy. It has a default (identity) transformation and other transformations may be applied to it (rotation, translation, scale, etc). It has no default attributes for the primitive lines, faces, markers, and text. Attributes may be set in a structure but they are overridden by the attributes in each group. Each structure has a display priority associated with it, which rules the order in which it is redrawn in a 3D viewer. If the visualization mode is incompatible with the view it is not displayed in that view, e.g. a shading-only object is not visualized in a wireframe view.
- View is defined by a view orientation, a view mapping, and a context view.
- · Viewer manages a set of views.
- View orientation defines the manner in which the observer looks at the scene in terms of View Reference Coordinates.
- **View mapping** defines the transformation from View Reference Coordinates to the Normalized Projection Coordinates. This follows the Phigs scheme.
- **Z-Buffering** a form of hidden surface removal in shading mode only. This is always active for a view in the shading mode. It cannot be suppressed.

### 4.2 Graphic primitives

The *Graphic3d* package is used to create 3D graphic objects in a 3D viewer. These objects called **structures** are made up of groups of primitives and attributes, such as polylines, planar polygons with or without holes, text and markers, and attributes, such as color, transparency, reflection, line type, line width, and text font. A group is the smallest editable element of a structure. A transformation can be applied to a structure. Structures can be connected to form a tree of structures, composed by transformations. Structures are globally manipulated by the viewer.

Graphic structures can be:

- · Displayed,
- · Highlighted,
- · Erased.
- · Transformed,
- Connected to form a tree hierarchy of structures, created by transformations.

#### There are classes for:

- · Visual attributes for lines, faces, markers, text, materials,
- · Vectors and vertices,
- Graphic objects, groups, and structures.

#### 4.2.1 Structure hierarchies

The root is the top of a structure hierarchy or structure network. The attributes of a parent structure are passed to its descendants. The attributes of the descendant structures do not affect the parent. Recursive structure networks are not supported.

### 4.2.2 Graphic primitives

#### Markers

- Have one or more vertices,
- Have a type, a scale factor, and a color,
- Have a size, shape, and orientation independent of transformations.

### Triangulation

- Have at least three vertices,
- Have nodal normals defined for shading.
- Have interior attributes style, color, front and back material, texture and reflection ratio,

#### · Polylines or Segments

- Have two or more vertices,
- Have the following attributes type, width scale factor, color.

#### Text

- Has geometric and non-geometric attributes,
- Geometric attributes character height, character up vector, text path, horizontal and vertical alignment, orientation, three-dimensional position, zoomable flag
- Non-geometric attributes text font, character spacing, character expansion factor, color.

### 4.2.3 Primitive arrays

The different types of primitives could be presented with the following primitive arrays:

- · Graphic3d\_ArrayOfPoints,
- Graphic3d\_ArrayOfPolylines,
- · Graphic3d ArrayOfSegments,
- Graphic3d\_ArrayOfTriangleFans,
- · Graphic3d\_ArrayOfTriangles,
- · Graphic3d ArrayOfTriangleStrips.

The *Graphic3d\_ArrayOfPrimitives* is a base class for these primitive arrays. Method set *Graphic3d\_ArrayOf*← *Primitives::AddVertex* allows adding vertices to the primitive array with their attributes (color, normal, texture coordinates). You can also modify the values assigned to the vertex or query these values by the vertex index.

The following example shows how to define an array of points:

```
// create an array
Handle(Graphic3d_ArrayOfPoints) anArray = new Graphic3d_ArrayOfPoints (theVerticiesMaxCount);

// add vertices to the array
anArray->AddVertex (10.0, 10.0, 10.0);
anArray->AddVertex (0.0, 10.0, 10.0);

// add the array to the structure
Handle(Graphic3d_Group) aGroup = thePrs->NewGroup();
aGroup->AddPrimitiveArray (anArray);
aGroup->SetGroupPrimitivesAspect (myDrawer->PointAspect()->Aspect());
```

If the primitives share the same vertices (polygons, triangles, etc.) then you can define them as indices of the vertices array. The method <code>Graphic3d\_ArrayOfPrimitives::AddEdge</code> allows defining the primitives by indices. This method adds an "edge" in the range <code>[1, VertexNumber()]</code> in the array. It is also possible to query the vertex defined by an edge using method <code>Graphic3d\_ArrayOfPrimitives::Edge</code>.

The following example shows how to define an array of triangles:

```
// create an array
Standard Boolean hasNormals
                                 = false:
Standard_Boolean hasColors
                                = false;
Standard_Boolean hasTextureCrds = false;
Handle(Graphic3d_ArrayOfTriangles) anArray = new Graphic3d_ArrayOfTriangles (theVerticesMaxCount,
       theEdgesMaxCount, hasNormals, hasColors, hasTextureCrds);
// add vertices to the array
anArray->AddVertex (-1.0, 0.0, 0.0); // vertex 1
anArray->AddVertex ( 1.0, 0.0, 0.0); // vertex 2
anArray->AddVertex ( 0.0, 1.0, 0.0); // vertex 3
anArray->AddVertex ( 0.0,-1.0, 0.0); // vertex 4
// add edges to the array
anArray->AddEdge (1); // first triangle
anArray->AddEdge (2);
anArray->AddEdge (3);
anArray->AddEdge (1); // second triangle
anArray->AddEdge (2);
anArray->AddEdge (4);
// add the array to the structure
Handle(Graphic3d_Group) aGroup = thePrs->NewGroup();
aGroup->AddPrimitiveArray (anArray);
aGroup->SetGroupPrimitivesAspect (myDrawer->ShadingAspect()->Aspect());
```

#### 4.2.4 Text primitive

TKOpenGL toolkit renders text labels using texture fonts. *Graphic3d* text primitives have the following features:

- · fixed size (non-zoomable) or zoomable,
- · can be rotated to any angle in the view plane,
- · support unicode charset.

The text attributes for the group could be defined with the *Graphic3d\_AspectText3d* attributes group. To add any text to the graphic structure you can use the following methods:

the Text parameter is the text string, the Point is the three-dimensional position of the text, the Height is the text height, the Angle is the orientation of the text (at the moment, this parameter has no effect, but you can specify the text orientation through the Graphic3d\_AspectText3d attributes). the Tp parameter defines the text path, the Hta is the horizontal alignment of the text, the Vta is the vertical alignment of the text. You can pass FALSE as the To Eval MinMax if you do not want the graphic3d structure boundaries to be affected by the text position.

**Note** that the text orientation angle can be defined by *Graphic3d\_AspectText3d* attributes.

```
const Graphic3d_VerticalTextAlignment theVta,
    const Standard_Boolean theToEvalMinMax);
void Graphic3d_Group::Text (const TCcollection_ExtendedString& theText,
    const Graphic3d_Vertex& thePoint,
    const Standard_Real theHeight,
    const Standard_Boolean theToEvalMinMax);
```

#### See the example:

```
// get the group
Handle(Graphic3d_Group) aGroup = thePrs->NewGroup();

// change the text aspect
Handle(Graphic3d_AspectText3d) aTextAspect = new Graphic3d_AspectText3d();
aTextAspect->SetTextZoomable (true);
aTextAspect->SetTextAngle (45.0);
aGroup->SetPrimitivesAspect (aTextAspect);

// add a text primitive to the structure
Graphic3d_Vertex aPoint (1, 1, 1);
aGroup->Text (Standard_CString ("Text"), aPoint, 16.0);
```

### 4.2.5 Materials

A Graphic3d MaterialAspect is defined by:

- · Transparency;
- Diffuse reflection a component of the object color;
- · Ambient reflection:
- Specular reflection a component of the color of the light source;
- · Refraction index.

The following items are required to determine the three colors of reflection:

- · Color;
- · Coefficient of diffuse reflection;
- · Coefficient of ambient reflection;
- · Coefficient of specular reflection.

### 4.2.6 Textures

A *texture* is defined by a name. Three types of texture are available:

- 1D;
- 2D;
- · Environment mapping.

### 4.2.7 Shaders

OCCT visualization core supports GLSL shaders. Shaders can be assigned to a generic presentation by its drawer attributes (Graphic3d aspects). To enable custom shader for a specific AIS\_Shape in your application, the following API functions can be used:

```
// Create shader program
Handle(Graphic3d_ShaderProgram) aProgram = new Graphic3d_ShaderProgram();

// Attach vertex shader
aProgram->AttachShader (Graphic3d_ShaderObject::CreateFromFile (Graphic3d_TOS_VERTEX, "<Path to VS>"));

// Attach fragment shader
aProgram->AttachShader (Graphic3d_ShaderObject::CreateFromFile (Graphic3d_TOS_FRAGMENT, "<Path to FS>"));

// Set values for custom uniform variables (if they are)
aProgram->PushVariable ("MyColor", Graphic3d_Vec3 (0.0f, 1.0f, 0.0f));

// Set aspect property for specific AIS_Shape
theAISShape->Attributes()->ShadingAspect()->Aspect()->SetShaderProgram (aProgram);
```

## 4.3 Graphic attributes

## 4.3.1 Aspect package overview

The Aspect package provides classes for the graphic elements in the viewer:

- · Groups of graphic attributes;
- · Edges, lines, background;
- · Window;
- Driver;
- Enumerations for many of the above.

## 4.4 3D view facilities

# 4.4.1 Overview

The *V3d* package provides the resources to define a 3D viewer and the views attached to this viewer (orthographic, perspective). This package provides the commands to manipulate the graphic scene of any 3D object visualized in a view on screen.

A set of high-level commands allows the separate manipulation of parameters and the result of a projection (Rotations, Zoom, Panning, etc.) as well as the visualization attributes (Mode, Lighting, Clipping, etc.) in any particular view.

The *V3d* package is basically a set of tools directed by commands from the viewer front-end. This tool set contains methods for creating and editing classes of the viewer such as:

- · Default parameters of the viewer,
- · Views (orthographic, perspective),
- · Lighting (positional, directional, ambient, spot, headlight),
- · Clipping planes,
- · Instantiated sequences of views, planes, light sources, graphic structures, and picks,
- · Various package methods.

## 4.4.2 A programming example

This sample TEST program for the *V3d* Package uses primary packages *Xw* and *Graphic3d* and secondary packages *Visual3d*, *Aspect*, *Quantity* and *math*.

```
// create a default display connection
Handle(Aspect_DisplayConnection) aDispConnection = new Aspect_DisplayConnection();
// create a Graphic Driver
Handle(OpenGl_GraphicDriver) aGraphicDriver = new OpenGl_GraphicDriver (aDispConnection);
// create a Viewer to this Driver
Handle(V3d_Viewer) VM = new V3d_Viewer (aGraphicDriver);
VM->SetDefaultBackgroundColor (Quantity_NOC_DARKVIOLET);
VM->SetDefaultViewProj (V3d_Xpos);
// Create a structure in this Viewer
Handle(Graphic3d_Structure) aStruct = new Graphic3d_Structure (VM->Viewer());
// Type of structure
aStruct->SetVisual (Graphic3d_TOS_SHADING);
// Create a group of primitives in this structure
Handle(Graphic3d_Group) aPrsGroup = new Graphic3d_Group (aStruct);
// Fill this group with one guad of size 100
Handle(Graphic3d_ArrayOfTriangleStrips) aTriangles = new Graphic3d_ArrayOfTriangleStrips (4);
aTriangles->AddVertex (-100./2., -100./2., 0.0);
aTriangles->AddVertex (-100./2., 100./2., 0.0);
aTriangles->AddVertex (100./2., -100./2., 0.0);
aTriangles->AddVertex ( 100./2.,
                                  100./2., 0.0);
aPrsGroup->AddPrimitiveArray (aTriangles);
aPrsGroup->SetGroupPrimitivesAspect (new Graphic3d_AspectFillArea3d());
// Create Ambient and Infinite Lights in this Viewer
Handle(V3d_AmbientLight) aLight1 = new V3d_AmbientLight (VM, Quantity_NOC_GRAY50);
Handle(V3d_DirectionalLight) aLight2 = new V3d_DirectionalLight (VM, V3d_XnegYnegZneg, Quantity_NOC_WHITE);
// Create a 3D quality Window with the same DisplayConnection
Handle (Xw_Window) aWindow = new Xw_Window (aDispConnection, "Test V3d", 0.5, 0.5, 0.5, 0.5);
// Map this Window to this screen
aWindow->Map();
// Create a Perspective View in this Viewer
Handle(V3d_View) aView = new V3d_View (VM);
aView->Camera()->SetProjectionType (Graphic3d_Camera::Projection_Perspective);
// Associate this View with the Window
aView ->SetWindow (aWindow);
// Display ALL structures in this View
VM->Viewer()->Display();
// Finally update the Visualization in this View
aView->Update();
// Fit view to object size
V->FitAll();
```

### 4.4.3 Define viewing parameters

View projection and orientation in OCCT *V3d\_View* are driven by camera. The camera calculates and supplies projection and view orientation matrices for rendering by OpenGL. The allows to the user to control all projection parameters. The camera is defined by the following properties:

- Eye defines the observer (camera) position. Make sure the Eye point never gets between the Front and Back clipping planes.
- Center defines the origin of View Reference Coordinates (where camera is aimed at).
- Direction defines the direction of camera view (from the Eye to the Center).
- Distance defines the distance between the Eye and the Center.
- Front Plane defines the position of the front clipping plane in View Reference Coordinates system.
- Back Plane defines the position of the back clipping plane in View Reference Coordinates system.
- **ZNear** defines the distance between the Eye and the Front plane.
- **ZFar** defines the distance between the Eye and the Back plane.

Most common view manipulations (panning, zooming, rotation) are implemented as convenience methods of *V3d*← \_*View* class, however *Graphic3d\_Camera* class can also be used directly by application developers:

Example:

```
// rotate camera by X axis on 30.0 degrees
gp_Trsf aTrsf;
aTrsf.SetRotation (gp_Ax1 (gp_Pnt (0.0, 0.0, 0.0), gp_Dir (1.0, 0.0, 0.0)), 30.0);
aView->Camera()->Transform (aTrsf);
```

### 4.4.4 Orthographic Projection





Figure 10: Perspective and orthographic projection

The following code configures the camera for orthographic rendering:

```
// Create an orthographic View in this Viewer
Handle(V3d_View) aView = new V3d_View (VM);
aView->Camera()->SetProjectionType (Graphic3d_Camera::Projection_Orthographic);
// update the Visualization in this View
aView->Update();
```

## 4.4.5 Perspective Projection

Field of view (FOVy) – defines the field of camera view by y axis in degrees (45 is default).



**Perspective Projection**: The camera's view frustum is specified via 4 view parameters: fovy, aspect, zNear and zFar.

Figure 11: Perspective frustum

The following code configures the camera for perspective rendering:

```
// Create a perspective View in this Viewer
Handle(V3d_View) aView = new V3d_View(VM);
aView->Camera()->SetProjectionType (Graphic3d_Camera::Projection_Perspective);
aView->Update();
```

# 4.4.6 Stereographic Projection

**IOD** – defines the intraocular distance (in world space units).

There are two types of IOD:

- IODType\_Absolute: Intraocular distance is defined as an absolute value.
- IODType\_Relative: Intraocular distance is defined relative to the camera focal length (as its coefficient).

Field of view (FOV) – defines the field of camera view by y axis in degrees (45 is default).

**ZFocus** – defines the distance to the point of stereographic focus.




Figure 12: Stereographic projection

To enable stereo projection, your workstation should meet the following requirements:

- · The graphic card should support quad buffering.
- · You need active 3D glasses (LCD shutter glasses).
- The graphic driver needs to be configured to impose quad buffering for newly created OpenGI contexts; the viewer and the view should be created after that.

In stereographic projection mode the camera prepares two projection matrices to display different stereo-pictures for the left and for the right eye. In a non-stereo camera this effect is not visible because only the same projection is used for both eyes.

To enable quad buffering support you should provide the following settings to the graphic driver opengl\_caps:

```
Handle(OpenGl_GraphicDriver) aDriver = new OpenGl_GraphicDriver();
OpenGl_Caps& aCaps = aDriver->ChangeOptions();
aCaps.contextStereo = Standard_True;
```

The following code configures the camera for stereographic rendering:

```
// Create a Stereographic View in this Viewer
Handle(V3d_View) aView = new V3d_View(VM);
aView->Camera()->SetProjectionType (Graphic3d_Camera::Projection_Stereo);
// Change stereo parameters
aView->Camera()->SetIOD (IODType_Absolute, 5.0);
// Finally update the Visualization in this View
aView->Update();
```

# 4.4.7 View frustum culling

The algorithm of frustum culling on CPU-side is activated by default for 3D viewer. This algorithm allows skipping the presentation outside camera at the rendering stage, providing better performance. The following features support this method:

Graphic3d\_Structure::CalculateBoundBox() is used to calculate axis-aligned bounding box of a presentation
considering its transformation.

- V3d\_View::SetFrustumCulling enables or disables frustum culling for the specified view.
- Classes OpenGI\_BVHClipPrimitiveSet and OpenGI\_BVHTreeSelector handle the detection of outer objects and usage of acceleration structure for frustum culling.
- BVH BinnedBuilder class splits several objects with null bounding box.

## 4.4.8 View background styles

There are three types of background styles available for V3d View: solid color, gradient color and image.

To set solid color for the background you can use the following method:

```
void V3d_View::SetBackgroundColor (const Quantity_Color& theColor);
```

The gradient background style could be set up with the following method:

The *theColor1* and *theColor2* parameters define the boundary colors of interpolation, the *theFillStyle* parameter defines the direction of interpolation.

To set the image as a background and change the background image style you can use the following method:

The *theFileName* parameter defines the image file name and the path to it, the *theFillStyle* parameter defines the method of filling the background with the image. The methods are:

- Aspect FM NONE draws the image in the default position;
- Aspect\_FM\_CENTERED draws the image at the center of the view;
- Aspect FM TILED tiles the view with the image;
- Aspect\_FM\_STRETCH stretches the image over the view.

## 4.4.9 Dumping a 3D scene into an image file

The 3D scene displayed in the view can be dumped into image file with resolution independent from window size (using offscreen buffer). The *V3d View* has the following methods for dumping the 3D scene:

```
Standard_Boolean V3d_View::Dump (const Standard_CString theFile, const Image_TypeOfImage theBufferType);
```

Dumps the scene into an image file with the view dimensions. The raster image data handling algorithm is based on the *Image\_AlienPixMap* class. The supported extensions are ".png", ".bmp", ".jpg" and others supported by **FreeImage** library. The value passed as *theBufferType* argument defines the type of the buffer for an output image \*(RGB, RGBA, floating-point, RGBF, RGBAF)\*. Method returns TRUE if the scene has been successfully dumped.

```
Standard_Boolean V3d_View::ToPixMap (Image_PixMap& theImage, const V3d_ImageDumpOptions& theParams);
```

Dumps the displayed 3d scene into a pixmap with a width and height passed through parameters structure *the*← *Params*.

### 4.4.10 Ray tracing support

OCCT visualization provides rendering by real-time ray tracing technique. It is allowed to switch easily between usual rasterization and ray tracing rendering modes. The core of OCCT ray tracing is written using GLSL shaders. The ray tracing has a wide list of features:

- · Hard shadows
- Refractions
- · Reflection
- Transparency
- · Texturing
- · Support of non-polygon objects, such as lines, text, highlighting, selection.
- · Performance optimization using 2-level bounding volume hierarchy (BVH).

The ray tracing algorithm is recursive (Whitted's algorithm). It uses BVH effective optimization structure. The structure prepares optimized data for a scene geometry for further displaying it in real-time. The time-consuming re-computation of the BVH is not necessary for view operations, selections, animation and even editing of the scene by transforming location of the objects. It is only necessary when the list of displayed objects or their geometry changes. To make the BVH reusable it has been added into an individual reusable OCCT package *TKMath/BVH*.

There are several ray-tracing options that user can switch on/off:

- · Maximum ray tracing depth
- · Shadows rendering
- · Specular reflections
- · Adaptive anti aliasing
- · Transparency shadow effects

### Example:

```
Graphic3d_RenderingParams& aParams = aView->ChangeRenderingParams();
// specifies rendering mode
aParams.Method = Graphic3d_RM_RAYTRACING;
// maximum ray-tracing depth
aParams.RaytracingDepth = 3;
// enable shadows rendering
aParams.IsShadowEnabled = true;
// enable specular reflections.
aParams.IsReflectionEnabled = true;
// enable adaptive anti-aliasing
aParams.IsAntialiasingEnabled = true;
// enable light propagation through transparent media.
aParams.IsTransparentShadowEnabled = true;
// update the view
aView->Update();
```

# 4.4.11 Display priorities

Structure display priorities control the order, in which structures are drawn. When you display a structure you specify its priority. The lower is the value, the lower is the display priority. When the display is regenerated, the structures with the lowest priority are drawn first. The structures with the same display priority are drawn in the same order as they have been displayed. OCCT supports eleven structure display priorities.

### 4.4.12 Z-layer support

OCCT features depth-arranging functionality called z-layer. A graphical presentation can be put into a z-layer. In general, this function can be used for implementing "bring to front" functionality in a graphical application.

### Example:

```
// set z-layer to an interactive object
Handle(AIS_InteractiveContext) theContext;
Handle(AIS_InteractiveObject) theInterObj;
Standard_Integer anId = 3;
aViewer->AddZLayer (anId);
theContext->SetZLayer (theInterObj, anId);
```

For each z-layer, it is allowed to:

- · Enable / disable depth test for layer.
- · Enable / disable depth write for layer.
- · Enable / disable depth buffer clearing.
- · Enable / disable polygon offset.

You can get the options using getter from V3d Viewer. It returns Graphic3d ZLayerSettings for a given LayerId.

## Example:

```
// change z-layer settings
Graphic3d_ZLayerSettings aSettings = aViewer->ZLayerSettings (anId);
aSettings.SetEnableDepthTest (true);
aSettings.SetEnableDepthWrite(true);
aSettings.SetClearDepth (true);
aSettings.SetPolygonOffset (Graphic3d_PolygonOffset());
aViewer->SetZLayerSettings (anId, aSettings);
```

Another application for Z-Layer feature is treating visual precision issues when displaying objects far from the World Center. The key problem with such objects is that visualization data is stored and manipulated with single precision floating-point numbers (32-bit). Single precision 32-bit floating-point numbers give only 6-9 significant decimal digits precision, while double precision 64-bit numbers give 15-17 significant decimal digits precision, which is sufficient enough for most applications.

When moving an Object far from the World Center, float number steadily eats precision. The camera Eye position adds leading decimal digits to the overall Object transformation, which discards smaller digits due to floating point number nature. For example, the object of size 0.0000123 moved to position 1000 has result transformation 1000.  $\leftarrow$  0000123, which overflows single precision floating point - considering the most optimistic scenario of 9 significant digits (but it is really not this case), the result number will be 1000.00001.

This imprecision results in visual artifacts of two kinds in the 3D Viewer:

- Overall per-vertex Object distortion. This happens when each vertex position has been defined within World Coordinate system.
- The object itself is not distorted, but its position in the World is unstable and imprecise the object jumps during camera manipulations. This happens when vertices have been defined within Local Coordinate system at the distance small enough to keep precision within single precision float, however Local Transformation applied to the Object is corrupted due to single precision float.

The first issue cannot be handled without switching the entire presentation into double precision (for each vertex position). However, visualization hardware is much faster using single precision float number rather than double precision - so this is not an option in most cases. The second issue, however, can be negated by applying special rendering tricks.

So, to apply this feature in OCCT, the application:

 Defines Local Transformation for each object to fit the presentation data into single precision float without distortion.

- Spatially splits the world into smaller areas/cells where single precision float will be sufficient. The size of such cell might vary and depends on the precision required by application (e.g. how much user is able to zoom in camera within application).
- Defines a Z-Layer for each spatial cell containing any object.
- Defines the Local Origin property of the Z-Layer according to the center of the cell.

```
Graphic3d_ZLayerSettings aSettings = aViewer->ZLayerSettings (anId);
aSettings.SetLocalOrigin (400.0, 0.0, 0.0);
```

Assigns a presentable object to the nearest Z-Layer.

Note that Local Origin of the Layer is used only for rendering - everything outside will be still defined in the World Coordinate System, including Local Transformation of the Object and Detection results. E.g., while moving the presentation between Z-layers with different Local Origins, the Object will stay at the same place - only visualization quality will vary.

## 4.4.13 Clipping planes

The ability to define custom clipping planes could be very useful for some tasks. OCCT provides such an opportunity.

The *Graphic3d\_ClipPlane* class provides the services for clipping planes: it holds the plane equation coefficients and provides its graphical representation. To set and get plane equation coefficients you can use the following methods:

```
Graphic3d_ClipPlane::Graphic3d_ClipPlane (const gp_Pln& thePlane) void Graphic3d_ClipPlane::SetEquation (const gp_Pln& thePlane) Graphic3d_ClipPlane::Graphic3d_ClipPlane (const Equation& theEquation) void Graphic3d_ClipPlane::SetEquation (const Equation& theEquation) gp_Pln Graphic3d_ClipPlane::ToPlane() const
```

The clipping planes can be activated with the following method:

```
void Graphic3d_ClipPlane::SetOn (const Standard_Boolean theIsOn)
```

The number of clipping planes is limited. You can check the limit value via method *Graphic3d\_GraphicDriver::*InquireLimit();

Let us see for example how to create a new clipping plane with custom parameters and add it to a view or to an object:

```
// create a new clipping plane
const Handle(Graphic3d_ClipPlane) & aClipPlane = new Graphic3d_ClipPlane();
// change equation of the clipping plane
Standard_Real aCoeffA = ...
Standard_Real aCoeffB =
Standard_Real aCoeffC =
Standard_Real aCoeffD = ...
aClipPlane->SetEquation (gp_Pln (aCoeffA, aCoeffB, aCoeffC, aCoeffD));
// set capping
aClipPlane->SetCapping (aCappingArg == "on");
// set the material with red color of clipping plane
Graphic3d_MaterialAspect aMat = aClipPlane->CappingMaterial();
Quantity_Color aColor (1.0, 0.0, 0.0, Quantity_TOC_RGB);
aMat.SetAmbientColor (aColor);
aMat.SetDiffuseColor (aColor);
aClipPlane->SetCappingMaterial (aMat);
// set the texture of clipping plane
```

```
Handle(Graphic3d_Texture2Dmanual) aTexture = ...
aTexture->EnableModulate();
aClipPlane->SetCappingTexture (aTexture);
// add the clipping plane to an interactive object
Handle(AIS_InteractiveObject) aIObj = ...
aIObj->AddClipPlane (aClipPlane);
// or to the whole view
aView->AddClipPlane (aClipPlane);
// activate the clipping plane
aClipPlane->SetOn(Standard_True);
// update the view
aView->Update();
```

# 4.4.14 Automatic back face culling

Back face culling reduces the rendered number of triangles (which improves the performance) and eliminates artifacts at shape boundaries. However, this option can be used only for solid objects, where the interior is actually invisible from any point of view. Automatic back-face culling mechanism is turned on by default, which is controlled by  $V3d\_View::SetBackFacingModel()$ .

The following features are applied in *StdPrs\_ToolShadedShape::IsClosed()*, which is used for definition of back face culling in *ShadingAspect*:

- disable culling for free closed Shells (not inside the Solid) since reversed orientation of a free Shell is a valid case:
- · enable culling for Solids packed into a compound;
- · ignore Solids with incomplete triangulation.

Back face culling is turned off at TKOpenGI level in the following cases:

- · clipping/capping planes are in effect;
- · for translucent objects;
- · with hatching presentation style.

# 4.5 Examples: creating a 3D scene

To create 3D graphic objects and display them in the screen, follow the procedure below:

- 1. Create attributes.
- 2. Create a 3D viewer.
- 3. Create a view.
- 4. Create an interactive context.
- 5. Create interactive objects.
- 6. Create primitives in the interactive object.
- 7. Display the interactive object.

# 4.5.1 Create attributes

Create colors.

```
Quantity_Color aBlack (Quantity_NOC_BLACK);
Quantity_Color aBlue (Quantity_NOC_MATRABLUE);
Quantity_Color aBrown (Quantity_NOC_BROWN4);
Quantity_Color aFirebrick (Quantity_NOC_FIREBRICK);
Quantity_Color aForest (Quantity_NOC_FORESTGREEN);
Quantity_Color aGray (Quantity_NOC_GRAY70);
Quantity_Color aMyColor (0.99, 0.65, 0.31, Quantity_TOC_RGB);
Quantity_Color aBeet (Quantity_NOC_BEET);
Quantity_Color aWhite (Quantity_NOC_WHITE);
```

#### Create line attributes.

```
Handle(Graphic3d_AspectLine3d) anAspectBrown = new Graphic3d_AspectLine3d();
Handle(Graphic3d_AspectLine3d) anAspectBlue = new Graphic3d_AspectLine3d();
Handle(Graphic3d_AspectLine3d) anAspectWhite = new Graphic3d_AspectLine3d();
anAspectBrown->SetColor (aBrown);
anAspectBlue ->SetColor (aBlue);
anAspectWhite->SetColor (aWhite);
```

#### Create marker attributes.

```
Handle(Graphic3d_AspectMarker3d aFirebrickMarker = new Graphic3d_AspectMarker3d();
// marker attributes
aFirebrickMarker->SetColor (Firebrick);
aFirebrickMarker->SetScale (1.0);
aFirebrickMarker->SetType (Aspect_TOM_BALL);
// or this
// it is a preferred way (supports full-color images on modern hardware).
aFirebrickMarker->SetMarkerImage (theImage)
```

#### Create facet attributes.

```
Handle(Graphic3d_AspectFillArea3d) aFaceAspect = new Graphic3d_AspectFillArea3d();
Graphic3d_MaterialAspect aBrassMaterial (Graphic3d_NOM_BRASS);
Graphic3d_MaterialAspect aGoldMaterial (Graphic3d_NOM_GOLD);
aFaceAspect->SetInteriorStyle (Aspect_IS_SOLID);
aFaceAspect->SetInteriorColor (aMyColor);
aFaceAspect->SetDistinguishOn ();
aFaceAspect->SetFrontMaterial (aGoldMaterial);
aFaceAspect->SetBackMaterial (aBrassMaterial);
aFaceAspect->SetEdgeOn();
```

## Create text attributes.

# 4.5.2 Create a 3D Viewer (a Windows example)

```
// create a default connection
Handle(Aspect_DisplayConnection) aDisplayConnection;
// create a graphic driver from default connection
Handle(OpenGl_GraphicDriver) aGraphicDriver = new OpenGl_GraphicDriver (aDisplayConnection);
// create a viewer
myViewer = new V3d_Viewer (aGraphicDriver);
// set parameters for V3d_Viewer
// defines default lights -
// positional-light 0.3 0.0 0.0
// directional-light V3d_XnegYposZpos
// directional-light V3d_XnegYposZpos
// ambient-light
a3DViewer->SetDefaultLights();
// activates all the lights defined in this viewer
a3DViewer->SetLightOn();
// set background color to black
a3DViewer->SetDefaultBackgroundColor (Quantity_NOC_BLACK);
```

# 4.5.3 Create a 3D view (a Windows example)

It is assumed that a valid Windows window may already be accessed via the method *GetSafeHwnd()* (as in case of MFC sample).

```
Handle(WNT_Window) aWNTWindow = new WNT_Window (GetSafeHwnd());
myView = myViewer->CreateView();
myView->SetWindow (aWNTWindow);
```

### 4.5.4 Create an interactive context

```
myAISContext = new AIS_InteractiveContext (myViewer);
```

You are now able to display interactive objects such as an AIS\_Shape.

```
TopoDS_Shape aShape = BRepAPI_MakeBox (10, 20, 30).Solid();
Handle(AIS_Shape) anAISShape = new AIS_Shape (aShape);
myAISContext->Display (anAISShape);
```

### 4.5.5 Create your own interactive object

Follow the procedure below to compute the presentable object:

- 1. Build a presentable object inheriting from AIS InteractiveObject (refer to the Chapter on Presentable Objects).
- 2. Reuse the Prs3d\_Presentation provided as an argument of the compute methods.

**Note** that there are two compute methods: one for a standard representation, and the other for a degenerated representation, i.e. in hidden line removal and wireframe modes.

Let us look at the example of compute methods

# 4.5.6 Create primitives in the interactive object

Get the group used in *Prs3d\_Presentation*.

```
Handle(Graphic3d_Group) aGroup = thePrs->NewGroup();
```

Update the group attributes.

```
aGroup->SetGroupPrimitivesAspect (anAspectBlue);
```

## Create two triangles in aGroup.

Use the polyline function to create a boundary box for the thePrs structure in group aGroup.

```
Standard_Real Xm, Ym, Zm, XM, YM, ZM;
thePrs->MinMaxValues (Xm, Ym, Zm, XM, YM, ZM);
Handle(Graphic3d_ArrayOfPolylines) aPolylines = new Graphic3d_ArrayOfPolylines (16, 4);
aPolylines->AddBound (4);
```

```
aPolylines->AddVertex (Xm,
                            Ym, Zm);
aPolylines->AddVertex (Xm,
                            Ym, ZM);
aPolylines->AddVertex (Xm,
                           YM, ZM);
aPolylines->AddVertex (Xm, YM, Zm);
aPolylines->AddBound (4);
aPolylines->AddVertex (Xm,
                            Ym, Zm);
aPolylines->AddVertex (XM, Ym, Zm);
aPolylines->AddVertex (XM,
aPolylines->AddVertex (XM, YM, ZM);
aPolylines->AddBound (4);
aPolylines->AddVertex (XM,
                            YM, Zm);
aPolylines->AddVertex (XM,
                            Ym, Zm);
aPolylines->AddVertex (XM,
                            YM, Zm);
aPolylines->AddVertex (Xm,
                            YM, Zm);
aPolylines->AddBound (4);
aPolylines->AddVertex (Xm,
                            YM, ZM);
aPolylines->AddVertex (XM,
                            YM, ZM);
aPolylines->AddVertex (XM,
                            Ym, ZM);
aPolylines->AddVertex (Xm,
                            Ym, ZM);
aGroup->AddPrimitiveArray(aPolylines);
aGroup->SetGroupPrimitivesAspect (new Graphic3d_AspectLine3d());
```

## Create text and markers in group aGroup.

# 5 Mesh Visualization Services

MeshVS (Mesh Visualization Service) component extends 3D visualization capabilities of Open CASCADE Technology. It provides flexible means of displaying meshes along with associated pre- and post-processor data.

From a developer's point of view, it is easy to integrate the *MeshVS* component into any mesh-related application with the following guidelines:

- Derive a data source class from the MeshVS\_DataSource class.
- Re-implement its virtual methods, so as to give the *MeshVS* component access to the application data model. This is the most important part of the job, since visualization performance is affected by performance of data retrieval methods of your data source class.
- · Create an instance of MeshVS Mesh class.
- Create an instance of your data source class and pass it to a *MeshVS\_Mesh* object through the *SetData Source()* method.
- Create one or several objects of *MeshVS\_PrsBuilder*-derived classes (standard, included in the *MeshVS* package, or your custom ones).
- Each *PrsBuilder* is responsible for drawing a *MeshVS\_Mesh* presentation in a certain display mode(s) specified as a *PrsBuilder* constructor's argument. Display mode is treated by *MeshVS* classes as a combination of bit flags (two least significant bits are used to encode standard display modes: wireframe, shading and shrink).
- Pass these objects to the MeshVS\_Mesh::AddBuilder() method. MeshVS\_Mesh takes advantage of improved selection highlighting mechanism: it highlights its selected entities itself, with the help of so called "highlighter" object. You can set one of PrsBuilder objects to act as a highlighter with the help of a corresponding argument of the AddBuilder() method.

Visual attributes of the *MeshVS\_Mesh* object (such as shading color, shrink coefficient and so on) are controlled through *MeshVS\_Drawer* object. It maintains a map "Attribute ID --> attribute value" and can be easily extended with any number of custom attributes.

In all other respects, *MeshVS\_Mesh* is very similar to any other class derived from *AIS\_InteractiveObject* and it should be used accordingly (refer to the description of *AIS package* in the documentation).