RESET AND PROGRAMMING CIRCUITRY (SAMD21G18)

EXTERNAL CRYSTAL (SAMD21G18)

DECOUPLING CAPACITORS (SAMD21G18)

SAMD21G18

Local I2C: PA08=SDA, PA09=SCL (SERCOM0, mux C).
SPI: SERCOM2. Watchdog WDI: PA10.
R3/R4 pull up only to 3V3_PROT: never V_MTQ.

CAN CONTROLLER

CAN TRANSCEIVER

CAN PERIPHERALS

IMU

BNO055 RESET CIRCUIT

LoRa Transceiver

LoRa Reset

Radio supply bulk bypass

LoRa

WATCHDOG

PC104 connectors

notes:
make sure u are using the latest PC104
Please use the same net label neames as used here
SP = spare

PC104

OCPC

VIN(UV) = VUVLO(R) x (Ra + Rb + Rc)/(Rb+Rc)

VIN(OV) = VOVLO(R) x (Ra + Rb + Rc)/Rc

RILIM = 50000/ILIM

Where VUVLO(R) is the EN/UVLO pin rising threshold and VOVLO(R) is the OVLO pin rising threshold.

Sheet: / File: EPS_Beacon.kicad_sch		
Title:		
Size: A3	Date:	**Rev:**
KiCad E.D.A. 10.0.7		Id: 1/1