## WIFI (UNTUK RB INCLUDE WIFI MODULE)

WAN - MIKROTIK - LAN

WAN: 192.168.2.1/24 static

MIKROTIK ETH1: 192.168.2.2/24 static


MIKROTIK ETH2: 192.168.88.1/24 dhcp server

LAN WIRED: 192.168.88.0/24 dhcp


MIKROTIK WLAN1: 192.168.3.1/24 dhcp server

LAN WIFI: 192.168.3.0/24 dhcp


## 1. set wireless



## 2. set ip address



## 3. set dhcp server



Dok 16/05/2015 padliyulian@ymail.com